

OPEL GT



Operation, Safety, Maintenance

Data specific to your vehicle

Please enter your vehicle's data here to keep it easily accessible.

This information is available under the section "Technical data" as well as on the identification plate.

Fuel

Designation

Engine oil

Grade

Viscosity

Tyre pressure

Tyre size
Summer tyres

with full load
Front Rear

Winter tyres

Front Rear

Weights

Permissible Gross Vehicle Weight

- EC kerb weight

= Loading

Your Opel GT

is an intelligent combination of forward-looking technology, impressive safety, environmental friendliness and economy.

It now lies with you to drive your vehicle safely and ensure that it performs perfectly. This Owner's Manual provides you with all the necessary information to that end.

Make sure your passengers are aware of the possible risk of accident and injury which may result from improper use of the vehicle.

You must always comply with the specific laws of the country that you are travelling through. These laws may differ from the information in this Owner's Manual.

When instructed to consult a workshop, we recommend that you consult an Opel Service Partner.

All Opel Service Partners offer first-class service at reasonable prices.

You will receive quick, reliable and individual service.

Experienced mechanics, trained by Opel, work according to specific Opel instructions.

The Owner's Manual should always be kept in the vehicle: Ready to hand in the glove compartment.

Make use of the Owner's Manual:

- Its "In brief" section will give you an initial overview.
- The table of contents at the beginning of the Owner's Manual and within the individual chapters will show you where everything is.
- Its index will help you find what you want.
- It will familiarise you with the sophisticated technology.
- It will increase your pleasure in your vehicle.
- It will help you to handle your vehicle expertly.


The Owner's Manual is designed to be clearly laid-out and easily understood.

This symbol signifies:

▶ Continue reading on next page.

* The asterisk signifies equipment not fitted to all vehicles (model variants, engine options, models specific to one country, optional equipment, Opel genuine parts and accessories).

Warning

Text marked  **Warning** provides information on risk of accident or injury. Disregard of the instructions may lead to injuries or endanger life. Inform your passengers accordingly.

Yellow arrows in the illustrations serve as points of reference or indicate some action to be performed.

Black arrows in the illustrations indicate a reaction or a second action to be performed.

Directional data, e.g. left or right, or front or back, in the descriptions always relates to the direction of travel.

We wish you many hours of pleasurable driving

Your Opel Team

Contents


In brief	6
Locks, doors, windows	21
Seats, interior	37
Instruments, controls	55
Lighting	73
Infotainment system	78
Climate control	102
Driving and operation	110
Self-help, vehicle care	130
Service, maintenance	165
Technical data	172
Index	184

In brief



S 13935

To unlock and open the doors:
Press button  on remote control to unlock driver's door, pull door handle


Press button  again within 5 seconds to unlock passenger's door.

The luggage compartment remains closed.

- ▶ Door locks - see page 21,
- Keys - see page 21,
- Electronic immobiliser - see page 21,
- Remote control - see page 22,
- Central locking system - see page 24.



S 13936

To open luggage compartment:
Press and hold button  on remote control, lift luggage compartment lid towards rear of vehicle

- ▶ Remote control - see page 22,
- Central locking system - see page 24,
- Luggage compartment - see page 26,
- Luggage compartment release button - see page 27,
- Emergency luggage compartment release handle - see page 27,
- Soft top - see page 31.



S 13907

To adjust seats:
Pull handle, slide seat,
release handle

► Seats - see page 37,
 Seat position - see page 38.




S 13908

Adjusting seat backrests:
Turn handwheel

Move seat backrest to suit seating position.

Do not lean on seat when adjusting the
 seat backrest.

► Seats - see page 37,
 Seat position - see page 38.



S 13909

Adjusting driver's seat height:
Press and hold switch up or down
until desired position is reached

► Seats - see page 37,
 Seat position - see page 38.



S 13941

Fitting seat belt:
Draw seat belt smoothly from inertia reel, guide over shoulder, engage in buckle

The belt must not be twisted at any point. The lap belt must lie snugly against the body.

The backrests must not be tilted back too far (recommended maximum tilting angle approx. 25°).

To release belt, press red button on belt buckle.

► Seat position - see page 38,
 Three-point seat belts - see page 40,
 Opel Full Size airbag system - see page 45.




S 13943

Adjusting electrical exterior mirrors:
Four way switch in driver's door

Move switch below four way switch to left or right from centre position: four way switch operates corresponding mirror.

► Further information - see page 29.



S 13942

Adjusting interior mirror:
Swivel mirror housing

Swivel lever on underside of mirror housing to reduce dazzle at night.

Take care when driving with interior mirror adjusted for night vision. Rear view may be slightly distorted in this position.

► Further information - see page 29.



S 13842

Steering column lock and ignition: Rotate steering wheel slightly, turn key to position ACC

Positions:

- O** = Ignition off
- ACC** = Steering unlocked, ignition off
- I** = Ignition on
- C** = Start

To lock the steering wheel, switch ignition off, remove key and turn steering wheel slightly until lock is engaged.

- ▶ Starting - see page 17,
- Parking the vehicle - see page 17,
- Electronic immobiliser - see page 21.




S 13843

Steering wheel adjustment: Swivel lever down, adjust height, swivel lever up, engage

Do not adjust steering wheel unless vehicle is stationary and steering column lock has been released.

Push the lever firmly upwards to ensure that the steering wheel is locked in position.

- ▶ Opel Full Size airbag system - see page 45.





	Page
1 Side air vents	103
2 Door window defroster vents	103
3 Turn signals	14, 74
high or low beam	13, 74
head lamp flash	13, 74
parking lamps	13, 73
auto light control	73
4 Cruise control remote control on steering wheel..	121
5 Driver information centre remote control on steering wheel....	60
6 Instruments.....	55
7 Driver's airbag.....	45
Horn	14
8 Driver information centre	59


	Page
9 Infotainment system * remote control on steering wheel....	79
10 Windscreen wipers, windscreen washer system... 15, 71, 72	72
11 Centre air vents	102
12 Hazard warning.....	14, 75
13 Climate control	102
14 Infotainment system*	78
15 Passenger's airbag	45
16 Glove compartment.....	51
17 Fuse box (under instrument panel)	143
18 Luggage compartment release (in glove compartment)	27
19 Accessory socket.....	54


	Page
20 ESP/Traction Control	118
21 Gear shift lever	16
22 Passenger's seat belt warning device	43
Seat occupancy recognition	48
23 Ignition switch.....	9
24 Steering wheel adjustment	9
25 Instrument panel, information display illumination	76
26 Front fog lamps, fog tail lamp	13, 75
27 Bonnet release (under instrument panel)	130

Control indicators


 **Anti-lock Brake System (ABS):**
see pages 55, 124.


 **Luggage compartment open:**
see pages 28, 55.


 **Fog tail lamp:**
see pages 55, 75.


 **Turn signals:**
see pages 14, 56, 74.


 **Headlamp high beam:**
see pages 13, 56, 74.


 **Exhaust emissions:**
see pages 56, 116.


 **Brake system, clutch system:**
see pages 56, 70, 124, 156.


 **Engine oil pressure:**
see page 57.


 **Coolant temperature:**
see page 57.

 **Airbag systems, belt tensioners:**
see pages 41, 45, 57.


 **Driver's seat belt:**
see pages 39, 43, 57.


 **Alternator:**
see page 58.


 **Electronic Stability Program (ESP),
Electronic Stability Control (ESC):**
see pages 58, 118.

 **Front fog lamps:**
see pages 58, 75.

 **Electronic immobiliser:**
see pages 21, 58.

 **Seat occupancy recognition:**
passenger's airbag deactivated -
see page 48.

 **Seat occupancy recognition:**
passenger's airbag activated -
see page 49.

 **Passenger's seat belt:**
see pages 39, 43.



S 13845

Exterior lamps: Turn light switch

- ☰D = High or low beam
- ⇒⇐ = Parking lamps
- AUTO = Auto light control
- ⏻ = Auto light control off/on

► Headlamp warning device - see page 71,
Lighting - see page 73,
Headlamps when driving abroad -
see page 77.



S 14000

Front fog lamps, fog tail lamp: Press button

- ☰D = Front fog lamps
- ⊖ = Fog tail lamp

► Front fog lamps - see page 75,
Fog tail lamp - see page 75.



S 13846

Headlamp flash, high and low beam:

- Headlamp flash = Pull lever towards steering wheel and release
- High beam = Push lever forwards
- Low beam = Pull lever towards steering wheel

► High beam, headlamp flash -
see page 74.



S 13847

Activate turn signals:

Right = Move lever up

Left = Move lever down

► Turn signals - see page 74.



S 13849

Hazard warning lamps:

On = Press ▲

Off = Press ▲ again

► Hazard warning lamps - see page 75.



S 13848

Activate horn:

Press  on steering wheel

► Opel Full Size airbag system - see page 45,

Remote control on steering wheel - see page 79.



S13850

Windscreen wipers:

Move lever from rest position

- = **Fast**
- = **Slow**
- 🔊 = **Timed interval wipe**
- = **Off**
- 🌫️ = **Misting function**

► Windscreen wipers - see page 71,
Adjustable wiper interval - see page 71,
Further information - see pages 163, 157.




S13851

Windscreen washer system:

Press button on end of lever

Washer fluid is sprayed onto the windscreen and at the same time the wipers are operated for four cycles.

► Windscreen washer system - see page 72,
Further information - see pages 163, 158.



S 13944

Heated rear window:




Press  = **On**
Press  again = **Off**

The control indicator in the button illuminates when rear window heating is on.

Do not turn on rear window heating when the soft top has been stowed in the luggage compartment.

► Climate control - see page 102,
Heated rear window - see page 103.



**Drying misted-up windows:
Air distribution to ,
rotary switches for temperature
and fan to the right;
press buttons  and **

Open side air vents and direct them towards the door windows.

► Climate control - see page 102.



Manual transmission:

Reverse: with the vehicle stationary, engage the gear.

If the gear does not engage, set the lever in neutral, release the clutch pedal and depress again; then repeat gear selection.

Before starting-off, check:

- Tyre pressures and tyre condition - see pages 125, 180.
- Engine oil level and fluid levels in engine compartment - see pages 152 to 157.
- All windows, mirrors, exterior lighting and license plates are free from dirt, snow and ice and are operational.
- Objects are securely located and will not be thrown forward in the event of sudden braking.
- No objects are placed on the instrument panel or in the area in which the airbags inflate.
- Seats, seat belts and mirrors are correctly adjusted.
- Brake operation.



S 13852

Starting the engine:
Transmission in neutral, depress clutch pedal fully, do not accelerate, turn key to \odot and release


The engine cranking is computer controlled and will continue until the engine starts or up to a maximum of 15 seconds. To stop the engine cranking, turn the ignition key back to the **ACC** or \odot position.

When the fuel level is low, the controlled cranking feature is disabled to prevent engine damage. Hold the key in the \odot position to start the engine.

Start attempts should not last longer than 15 seconds. If engine does not start, wait 10 seconds before repeating procedure.

To switch on ignition, only turn the key to I.


- ▶ Electronic immobiliser - see page 21,
- Further information - see pages 110 to 114



S 13934

Releasing the hand brake:
Raise lever slightly, press release button, lower lever fully

- ▶ Hand brake - see page 124.



S 13947

Parking the vehicle:
Apply hand brake firmly, switch ignition off, engage steering column lock, lock the vehicle

- ▶ To lock vehicle, press button \mathbb{L} .
- ▶ Further information - see page 21, Remote control - see page 22,
- ▶ Central locking system - see page 24, Vehicle decommissioning - see page 160.

Advice when parking:


- Do not park the vehicle on easily ignitable surfaces. The high temperature of the exhaust system could ignite the surface.
- Always apply the hand brake firmly. Apply the hand brake as firmly as possible on uphill or downhill slopes. To reduce operating forces, depress brake pedal at the same time.
- Close windows.
- Before switching off ignition, engage first or reverse gear.
- If the vehicle is parked on a level surface or an uphill incline, engage first gear before switching off ignition. On an uphill incline, also turn the front wheels away from the kerb.
- If the vehicle is on a downhill incline, engage reverse gear before switching off the ignition. Also turn the front wheels towards the kerb.

- Turn steering wheel until lock is felt to engage (anti-theft protection), removing ignition key beforehand.
- Switch off exterior lamps, otherwise the headlamp warning device will sound when the driver's door is opened.
- The engine cooling fans may run after the engine has been switched off - see page 152.
- ▶ Further information - see pages 159 to 160.

That was the most important information for your first drive in your vehicle in brief.

The other pages of this chapter contain a summary of the interesting functions in your vehicle.

The remaining chapters of the Owner's Manual contain important information on operation, safety and maintenance as well as a complete index.



Opel Full Size airbag system

The airbag system is triggered in the event of a serious accident involving a frontal impact and forms safety cushions for the driver and passenger. The forward movement of the driver and passenger is checked and the risk of injuries to the upper body and head are thereby substantially reduced.

► Opel Full Size airbag system - see page 45.



Remote control on steering wheel

The functions of the Infotainment system * and the driver information centre can be operated with the buttons on the steering wheel.

► Driver information centre - see page 59,
Remote control on steering wheel - see page 79,
Infotainment system * - see page 78.



Driver information centre

Information display

The information display provides information on driving data, which is continually recorded and evaluated electronically.

Functions:

- Outside air temperature and odometer,
- Trip odometer A,
- Trip odometer B,
- Fuel range,
- Average fuel consumption,
- Average speed,
- Engine oil life monitor,
- Coolant temperature,
- Turbo boost.

► Information display - see page 60.



Check control

The check control software monitors:



- Fluid levels
- Engine
- Fuel filler cap
- Remote control battery
- Airbag systems
- Vehicle features including cruise control, traction control and Electronic Stability Program (ESP).

► Check control - see page 68.



Competitive mode

To activate:

Press button  twice within 5 seconds; "COMPETITIVE MODE" appears in the driver information centre and control indicator  illuminates in the instrument panel.

Competitive mode allows the driver full control of the rear wheels. The traction control aspect of the Electronic Stability Program (ESP) is deactivated for high performance driving, while ESP continues to assist in maintaining driving stability.

- Driver information centre - see page 59,
- Check control warning message - see page 69,
- Electronic Stability Programme (ESP) - see page 118,
- Competitive mode - see page 120.

Locks, doors, windows

Replacement keys	21
Car Pass *.....	21
Electronic immobiliser.....	21
Remote control	22
Central locking system	24
Manual locking or unlocking	26
Luggage compartment	26
Vehicle locator and panic alarm	28
Exterior mirrors.....	29
Interior mirror	29
Electric windows.....	30
Soft top	31
Sun visors.....	36

Replacement keys

The key number is specified in the vehicle documents and in the Car Pass *.

The key is a constituent of the electronic immobiliser. Ordering keys from an Opel Service Partner guarantees problem-free operation of the electronic immobiliser.

Keep the spare key accessible in a safe place.

Locks - see page 164.

Car Pass *

The Car Pass contains all of the vehicle's data and should therefore not be kept in the vehicle.

Have your Car Pass ready to hand when consulting your Opel Service Partner.



S 13854

Electronic immobiliser

The system checks whether the vehicle is allowed to be started using the key that has been inserted. If the key is recognised as "authorised", the vehicle can be started. The checking takes place via a transponder in the key.

The electronic immobiliser activates itself automatically after the key has been removed from the ignition switch.

The code number of the electronic immobiliser is shown in the Car Pass *.



Control indicator for immobiliser

Illuminates briefly when the ignition is switched on.

If the control indicator stays illuminated after the ignition is switched on, there is a fault in the system; the engine cannot be started. Switch off the ignition, remove the key and repeat the start attempt.

If the control indicator fails to extinguish, try to start the engine using the spare key and consult a workshop.

Note

The immobiliser does not lock the doors. Therefore, after leaving the vehicle always lock it. See page 24.



Remote control

Used to operate:

- Central locking system,
- Luggage compartment release,
- Vehicle locator and panic alarm.

The remote control has a range of approx. 3 metres. This range can be affected by outside influences.

Handle the remote control with care, protect it from moisture and high temperatures and avoid unnecessary operation.

When enabled through driver information centre personalisation mode, illumination of hazard warning lamps indicates remote control operation.

Driver information centre - see page 59.

Central locking system,
see page 24.

Delayed locking,
see page 24.

Automatic locking,
see page 25.

Automatic unlocking,
see page 25.

Luggage compartment release,
see page 26.

Vehicle locator and panic alarm,
see page 28.

Welcome light function,
see page 67.

Fault

If the remote control does not operate correctly, it may be due to the following:

- The range of the remote control has been exceeded.
- Remote control battery voltage is too low. See "Remote control battery replacement".
- Frequent, repeated operation of the remote control outside the reception range of the vehicle (e.g. too far from the vehicle, remote control is then no longer recognised). See "Radio remote control synchronisation".
- Overloading the central locking system by operating at frequent intervals. The power supply may be interrupted for a short time. The system is protected by a fuse in the fuse box – see page 141.
- Interference from higher-power radio waves from other sources.

To eliminate the cause of the fault, consult a workshop.


Open driver's door with key - see page 26.



S 13956

Remote control battery replacement

Replace the battery in accordance with the chapter "Service, Maintenance" on page 165 or when the range of the remote control begins to decrease.

Open remote control by inserting a suitable screwdriver into the notch below button  and prise apart the two halves of the remote control.



S 13955

Remove used battery, taking care to avoid touching any of the circuitry.

Replace battery - battery type, see page 181 - ensuring the new battery is installed correctly with positive (+) side facing up.

Close remote control.

Make sure that you dispose of old batteries in accordance with environmental protection regulations.

Radio remote control synchronisation

After changing the battery, unlock the door with the key in the lock. Inserting the key in the ignition switch synchronises the remote control.



S 13959


Central locking system

For doors only.

To unlock:

Press button  on remote control.


- Driver's door is unlocked.

Press button  on remote control twice within 5 seconds:

- Passenger's door is unlocked.

When enabled through the driver information centre personalisation mode:

- Hazard warning lamps flash twice.
- Horn activates twice.

If button  is pressed again after the doors are unlocked, the hazard warning lamps may flash twice to indicate the doors are already unlocked.



S 13957

To lock:


Close doors and windows before locking.

Press button  on remote control.


- Both doors are locked.


When enabled through the driver information centre personalisation mode:


- Hazard warning lamps flash once.
- Horn activates once.


If button  is pressed again after the doors are locked, the horn activates once and the hazard warning lamps may flash once to indicate the doors are already locked.

Delayed locking:


When enabled through the driver information centre personalisation mode, locking of the doors is delayed until 5 seconds after the last door is closed, when button  is pressed on the remote control.

If a door is open when button  is pressed, the hazard warning lamps will flash when the doors are locked after the delay.


To override the delay, press button  again. Doors lock immediately.


 Warning
For safety reasons, remove the key from the ignition switch before locking the vehicle.

Driver information centre - see page 59.



Central locking switch for locking and unlocking the doors from inside the vehicle

Move switch in driver's door or passenger's door to position : doors are locked.

Move switch in driver's door or passenger's door to position : doors are unlocked.

Note

- If the central locking system is locked, the doors cannot be unlocked by pulling the interior handle.
- Locked doors unlock themselves automatically when an accident of a certain severity occurs (for outside assistance), and the hazard warning lamps come on. The key must also be in the ignition.

Automatic locking


The central locking system automatically locks the doors as soon as a speed of approx. 8 km/h (5 mph) is reached.

Fault

In the event of a fault, e.g. automatic locking doesn't take place, ensure all the doors have been properly closed.


If the automatic locking function still fails to operate, we recommend that you consult a workshop.

Automatic unlocking

When enabled through the driver information centre personalisation mode, the central locking system automatically unlocks either the driver's door or both doors when the key is turned to ignition switch position .

This feature can also be disabled via the driver information centre personalisation mode.

Driver information centre - see page 59.




S 13962

Manual locking or unlocking

To unlock:

Turn key in driver's door lock towards front of vehicle as far as it will go. Turn key back to a vertical position and remove.

Both doors will be unlocked.



S 13961

To lock:

Turn key in driver's door lock towards rear of vehicle as far as it will go. Turn key back to a vertical position and remove.

Both doors will be locked.




S 13936

Luggage compartment

To open with remote control:

Press and hold button  on the remote control.




S 13964

To open with release button in glove compartment:

Key in ignition switch position **O** or **ACC**, or with hand brake applied:

Press the luggage compartment release button located in the glove compartment.



S 13963

With soft top in raised position, the buttresses are unlatched automatically before the luggage compartment is opened. Soft top - see page 31.

Lift luggage compartment lid towards rear of vehicle to open fully.



S 13965

To open from within luggage compartment:

Pull emergency luggage compartment release handle. Push luggage compartment lid from the inside to open.

The emergency luggage compartment release handle glows in the dark for greater visibility in the event of people becoming trapped in the luggage compartment.

⚠ Warning

Do not use the emergency luggage compartment release handle to secure items in the luggage compartment, to avoid causing damage to the vehicle.




S 13066

To close

Warning

Ensure the soft top is properly stowed (see page 31) and ensure no objects are placed in the area within the luggage compartment in which the soft top is stored.

To close the luggage compartment lid, stand behind the vehicle and, with two hands laid flat on the surface of the lid, close the lid with a swift, firm motion.

If the luggage compartment lid is open or is not closed properly, "TRUNK AJAR" will appear in the driver information centre when the ignition is on. Control indicator  also illuminates in the instrument panel. Close luggage compartment lid. Driver information centre - see page 59.


Warning


Do not drive with the luggage compartment open or ajar, e.g. when transporting bulky objects, to avoid causing damage to the vehicle.




S 14031

Vehicle locator and panic alarm

The remote control has both a vehicle locator and a panic alarm feature, activated via button .

To aid location of the vehicle, e.g. when the vehicle is parked in a car park, press and release button ; the horn will sound three times and the hazard warning lamps and courtesy lamps will flash three times.

To activate the panic alarm, press and hold the button for 3 seconds; the horn will sound and the hazard warning lamps and courtesy lamps will flash for 30 seconds.

Press button  again to switch off the panic alarm, or turn key in ignition switch to position ACC or I.

The vehicle locator and panic alarm features are operational only with the ignition off.



Exterior mirrors

Adjust using the switches in the driver's door. Select relevant exterior mirror and adjust.



For the safety of pedestrians, the exterior mirrors will swing out of their normal mounting position if they are bumped with sufficient force. Reposition the mirror by applying slight pressure to the mirror housing.



Interior mirror

To adjust, swivel the mirror housing.

Swivel lever on underside of mirror housing to reduce dazzle at night.

Take care when driving with interior mirror adjusted for night vision. Rear view may be slightly distorted in this position.

Electric windows

Warning

Take care when operating the electric windows. Risk of injury, especially for children.


Vehicle passengers should be informed accordingly.

Keep a close watch on the windows when closing them. Ensure that nothing becomes trapped in them as they move.

The electric windows can be used:

- with the key in ignition switch positions **ACC**, **I** or **⊖**.
- within approx. 5 minutes of switching key to position **⊖**.

The function standby after switching off the ignition is cancelled when the driver's door is opened.




The driver's and passenger's window are operated via the switches located in the driver's door handle.

For incremental operation, briefly pull or press the switch. To open or close fully, pull or press the switch for longer.

For automatic opening, press the switch down fully. Pull the switch to stop the movement.

In the event of difficulty due to frost or the like, press the relevant window switch several times until the window is closed.



The passenger's window is operated via a switch in the door handle.

For incremental operation, briefly pull or press the switch. To open or close fully, pull or press the switch for longer.

Warning

Before leaving the vehicle, remove the ignition key in order to prevent unauthorized operation of the windows - risk of injury.

Overload

If the windows are repeatedly operated at short intervals, the power supply is briefly cut off.

The system is protected by a fuse in the fuse box - see page 141.

Soft top

Take care when lowering or raising the soft top. Risk of injury. Vehicle passengers should be informed accordingly.

Keep a close watch on the moving parts when lowering or raising the soft top. Ensure that nothing becomes trapped as the soft top is moved.

Lowering soft top


Only with vehicle stationary.

With vehicle parked on a level surface, engage first or reverse gear, switch off ignition and apply hand brake.

Place no objects in the area within the luggage compartment in which the soft top is to be stored.

Ensure that soft top canopy is dry before lowering soft top.

Open the luggage compartment - see page 26.



S 13070

Release the locking lever located in the centre of the header rail by pulling it down and rotating it anti-clockwise. The retaining hook will unhook.




S 13071

To avoid damaging the soft top or the roof mechanism, the lever must remain in the open position during the lowering procedure.



S 13072

From the side of the vehicle, pull the soft top away from the windscreen frame and fold it down into the luggage compartment.




To allow the luggage compartment lid to close correctly, ensure the soft top is properly stowed by applying a firm, even push in the centre of the soft top.

To close the luggage compartment lid, stand behind the vehicle and, with two hands laid flat on the surface of the lid, close the lid with a swift, firm motion.

Warning

Do not turn on rear window heating when the soft top has been stowed in the luggage compartment.



Raising soft top

Only with vehicle stationary.

With vehicle parked on a level surface, engage first or reverse gear, switch off ignition, apply hand brake and open the windows.

Open the luggage compartment - see page 26.

From the side of the vehicle, pull the soft top upwards and forwards, towards the windscreen frame.




Fully raise the soft top ensuring the alignment pins locate correctly in both sides of the windscreen frame and on each side of the body adjacent to the seat backrests.




S 13978

Ensure the retaining hook is correctly aligned within its aperture before attempting to engage the locking lever.




S 13979

Engage the locking lever by rotating it clockwise and pushing it up. The retaining hook will hook into position.




S 13980

The lever must remain in the closed position when the soft top is raised.



Close the luggage compartment lid by standing behind the vehicle and, with two hands laid flat on the surface of the lid, close the lid with a swift, firm motion.

Push the two butresses, located at the rear of the soft top, downwards.



Press the butresses into the corresponding apertures on either side of the vehicle with a swift, firm motion, ensuring they are latched correctly into the top of the luggage compartment lid.

Warning

A clear protective film has been installed on the upper surface of the luggage compartment lid, under the butresses. To prevent damage to the paintwork, do not remove the protective film.

Soft top care - see page 162.



S 13096

Sun visors

The sun visors can be folded down to protect against glare.

The driver's sun visor includes a mirror. Slide cover to the right to use the mirror. The mirror cover should be closed while driving.

Seats, interior

Seats	37
Three-stage restraint system	39
Three-point seat belts	40
Belt tensioners	41
Using the belts	42
Child restraint systems *	44
Opel Full Size airbag system	45
Notes on loading the vehicle	50
Stowage compartments	51
Ashtrays	53
First-aid kit ☹️* , warning triangle ⚠️*	53
Power outlets	53




Seats

⚠️ Warning

Never adjust seats while driving, since they could move uncontrollably.

Adjust seat in longitudinal direction
To adjust, pull handle under seat, slide seat and release handle.


Ensure seat is engaged in position before starting-off.



Adjust seat backrest

To adjust, turn handwheel on outboard side of seat without leaning on seat backrest.

Move seat backrest to suit seating position.



Adjust driver seat height

Press and hold switch up or down until desired position is reached.



Seat position

Adjust driver's seat such that, with the driver sitting upright, the steering wheel is held in the area of its upper spokes with the driver's arms slightly bent.

Push passenger's seat as far back as possible.

⚠ Warning

Failure to observe these descriptions could lead to injuries which could be fatal. Vehicle passengers should be informed accordingly before starting-off.



Head restraints

The head restraints are an integral part of the seat backrest and are designed to provide protection in the event of a rear impact, thereby reducing the risk of neck and shoulder injuries.



S 14034

Folding seat backrests

Lift release lever on outboard side of backrest and fold seat backrest forwards.

To move upright, lift release lever, move seat backrest backwards and audibly engage.

Three-stage restraint system

Comprising:

- Three-point seat belts,
- Belt tensioners,
- Airbag systems for driver and passenger.

The three stages are activated in sequence depending on the seriousness of the accident:

- The automatic seat belt locking devices prevent the belt strap from being pulled out and thus ensure that the vehicle occupants are retained in their seats.
- The seat belts are pulled down at the belt buckles. This makes the belts fit snugly, the occupants are decelerated together with the vehicle, and the body is subjected to less stress.
- The airbag systems are also triggered in the event of serious accidents and form a safety cushion for the occupants. Depending on the severity of the accident, the airbags inflate in two stages.

Warning

The airbag systems are supplementary to the three-point seat belts and belt tensioners, and the seat belts must therefore always be worn. Disregarding these instructions may lead to injuries or endanger life. Vehicle passengers should be informed accordingly.



Three-point seat belts

The vehicle is equipped with three-point seat belts with automatic retractors and locking devices, allowing freedom of body movement although the spring tensioned belts are always a snug fit.

For information on correct seating position – see pages 38, 42, 46.


The belts are locked during rapid vehicle acceleration or deceleration.

Warning

Always wear your seat belt, and that means also in urban traffic. It can save your life!

Also, pregnant women must always wear a seat belt – see page 43.

In the event of an accident, persons not wearing seat belts endanger their fellow occupants and themselves.

Control indicator  for passenger's seat belt – see page 43.

Control indicator  for driver's seat belt – see pages 43, 57.

Seat belts are only designed for use by one person at a time. They are not suitable for persons younger than 12 years of age or smaller than 150 cm.

Belt force limiters

Belt force limiters on the seats reduce the stress on the body due to controlled release of the belt during a collision. This means that the occupants move forward under control.

Inspection of belts

Please check all parts of the belt system occasionally for damage and correct operation. Have damaged parts replaced. After an accident, have belts and deployed belt tensioners replaced by a workshop.

Do not perform any alterations on the belts, their anchorages, the automatic retractors or the belt buckles.

Make sure that belts are not damaged or trapped by sharp-edged objects.




S 11739

Belt tensioners

The seat belts are fitted with belt tensioners. The seat belts are pulled down at the buckles in the event of frontal impacts above a certain severity. This tightens the belts.

Actuation of belt tensioners

Indicated by continuous illumination of control indicator  in the instrument panel.


The belt tensioners must be replaced after activation. Consult a workshop.

Further information – see page 43.




S 13856

Control indicator for belt tensioners

The operation of the belt tensioners is monitored electronically together with seat occupancy recognition and the airbag systems and is indicated by control indicator .

When the ignition is switched on, the control indicator flashes for approx. 5 seconds. If it does not flash, does not go out after 5 seconds or illuminates while driving, there is a fault in the belt tensioners, seat occupancy recognition or the airbag systems – see also pages 45, 48. The systems may fail to deploy in the event of an accident.

Deployment of the belt tensioners is indicated by continuous illumination of .

Warning

Have the cause of the fault remedied by a workshop.

The system's integrated self-diagnostics allows faults to be quickly remedied. Consult a workshop.


Important

- Accessories and other objects not specifically approved for your vehicle type must not be affixed or placed within the action zone of the belt tensioners (near the retractor) as this could result in injury if the belt tensioners are triggered.
- Do not make any modifications to the components of the belt tensioners, as this will render the vehicle unroadworthy.

Warning

Incorrect handling (e.g. removal or fitting of belts or belt buckles) can deploy the belt tensioners with risk of injury.

- The belt tensioner and airbag system control electronics can be found in the centre console area. In order to avoid malfunctions, do not store magnetic objects in this area.

- We recommend that you have the seats removed by a workshop in the event of actuation of the belt tensioners.
- The belt tensioners are for single use only, which is indicated by continuous illumination of control indicator . Have deployed belt tensioners replaced by a workshop.
- Applicable safety directives must always be observed when disposing of the vehicle. For this reason, disposal should be done by an authorised recycling company.



Using the belts

Fitting the belt

Pull the belt out from the retractor and guide it across the body, making certain that it is not twisted.

Insert the latch plate into the buckle. The seat backrest must not be tilted back too far (the recommended maximum tilting angle is approx. 25°).

Make sure that the lap belt is not twisted and that it fits snugly across the body. Tension the belt frequently while driving by tugging the diagonal part of the belt.



171071


Warning


On pregnant women in particular, the lap belt must be positioned as low as possible across the pelvis so as not to put too much pressure on the abdomen.

Thick layers of clothing prevent the belt from fitting snugly. The belt must not rest against hard or fragile objects in the pockets of your clothing (e.g. ballpoint pen, keys, spectacles), since this could cause injury. No objects such as handbags, mobile phones etc. must be present between the belt and your body.




S 14168


Driver's seat belt warning device 

Control indicator  illuminates in the instrument panel for approx. 20 seconds when the ignition is switched on, or until driver's seat belt is fastened. Flashes for a further 60 seconds if seat belt remains unfastened.

When the vehicle is being driven, if the driver's seat belt remains unfastened, the control indicator will illuminate for approx. 20 seconds and flash for a further 60 seconds or until the belt is fastened.


Apply seat belt – see page 42.
Control indicator goes out immediately.

Control indicator  for driver's seat belt - see page 57.



S 14035


Passenger's seat belt warning device 

Control indicator  illuminates in the centre console after a approx. 20 seconds when the ignition is switched on, if passenger's seat belt is unfastened and the seat occupancy recognition system detects that the passenger's seat is occupied. Stays illuminated for a further 20 seconds then flashes for approx. 60 seconds if seat belt remains unfastened.

When the vehicle is being driven, if the passenger's seat is occupied and the belt remains unfastened, the control indicator will illuminate for a approx. 20 seconds and then flash for a further 60 seconds or until the belt is fastened.

Apply seat belt – see page 42.
Control indicator goes out immediately.


Seat occupancy recognition - see page 48.



17109 T

Removing the belt

To remove the belt, depress the red pushbutton on the buckle; the belt will retract automatically.



S 13087

Child restraint systems *

⚠ Warning

Vehicle with front passenger airbag:
Rear-facing child seats must not be fitted, danger of fatal injury.

Specifically approved forward-facing child restraints can be fitted on the front passenger's seat, provided that the latter is moved as far back as it will go.

Opel has approved child restraint systems from the 'DUO' and 'KID' ranges.

A warning sticker on the sun visors reminds that the use of rearward facing child restraint systems poses a risk of fatal injury.

When using a child restraint system, always observe the instructions on installation and use.

The country in which you are travelling may not permit the use of child restraint systems on certain seats. Always comply with the local or national regulations.

⚠ Warning

Never carry child restraint systems on your lap, risk of fatal injury.

Note

- Children under 12 years or under 150 cm tall should only travel in an appropriate child safety seat.
- When transporting children, use a child restraint system that is suitable for the child's weight.
- The covers of the child restraint system can be wiped clean.
- Do not stick anything on the child restraint systems and do not cover them with any other materials.
- Only allow children to enter and exit the vehicle at the side facing away from the traffic.
- A child restraint system which has been subjected to stress in an accident must be replaced.

Permissible options for fitting a child safety seat

Weight and age class	On front passenger seat ¹⁾
Group 0: up to 10 kg or approx. 10 months	X
Group 0+: up to 13 kg or approx. 2 years	
Group I: 9 to 18 kg or approx. 8 months to 2 years	L
Group II: 15 to 25 kg or approx. 3 to 7 years	L
Group III: 22 to 36 kg or approx. 6 to 12 years	

¹⁾ Ensure seat is in its rearmost position.

X = No child restraint of any class allowed in this seating position

L = Suitable only for specifically approved child restraints. Opel has approved child restraint systems from the 'DUO' and 'KID' ranges.




S 13983

Opel Full Size airbag system

The airbag system is identified by the word **AIRBAG** on the steering wheel and above the glove compartment.

The airbag system comprises:

- an airbag with inflator in the steering wheel and a second one in the instrument panel,
- control electronics with impact sensors,
- control indicator for airbag systems in instrument panel,
- seat occupancy recognition.



S 14036


The airbag system is triggered:

- depending on the severity of the accident,
- depending on the type of impact, within the range shown in the illustration.

Exception: The seat occupancy recognition system deactivates the airbag on the passenger's side if the passenger's seat is unoccupied – see page 48.

Examples of events triggering the airbag system:

- Impact against a non-yielding obstacle: the airbags are triggered at a low vehicle speed.
- Impact against a yielding obstacle (such as another vehicle): the airbags are only triggered at a higher vehicle speed.



S 17375 T

When triggered, the airbags inflate in milliseconds to form a safety cushion for the driver and passenger. The forward movement of the seat occupants is checked, thereby substantially reducing the risk of injury to the upper body and head.

No impairment of view will occur, because the airbags inflate and deflate so quickly that it is often not even noticed in an accident.



S 14033

⚠ Warning

The airbag system provides optimum protection when the seat and backrest are correctly adjusted.

Adjust the driver's seat according to the occupant's height such that, with the driver sitting upright, the steering wheel is held in the area of its upper spokes with the driver's arms slightly bent.

The passenger's seat should be as far back as possible, with the backrest upright – see pages 7, 37, 38.

Do not place the head, body, hands or feet on the cover of the airbag systems.

Do not place any objects in the area in which the airbags inflate. Important information – see page 49.



S 13941

⚠ Warning

The three-point seat belt must be correctly fitted (see page 42).

The airbag system will not be triggered in the event of:

- the ignition being switched off,
- minor frontal collisions,
- accidents in which the vehicle overturns,
- collisions involving a side or rear impact where it would not be of benefit to the occupants.

Warning

Seat belts must always be worn. The airbag system serves to supplement the three-point seat belts.

If you do not wear your seat belt, you risk being seriously injured, or even thrown from the vehicle, in the event of an accident.

If an accident occurs, the belt helps to maintain the correct seat position that is required for the airbag system to provide you with effective protection.


In addition, the airbag system will not be triggered for the passenger in versions with seat occupancy recognition if:

- the passenger's seat is unoccupied.


Seat occupancy recognition – see page 48.



Control indicator for airbag systems

The operation of the airbag systems is monitored electronically together with seat occupancy recognition and the belt tensioners and is indicated by control indicator .

When the ignition is switched on, the control indicator flashes for approx. 5 seconds. If it does not flash, does not go out after 5 seconds or illuminates while driving, there is a fault in the airbag systems, the seat occupancy recognition or the belt tensioners – see also pages 41, 48. The systems may fail to deploy in the event of an accident.

Deployment of the airbags is indicated by continuous illumination of .





Warning

Have the cause of the fault remedied by a workshop.

The system's integrated self-diagnostics allows faults to be quickly remedied. Consult a workshop.


Seat occupancy recognition


The seat occupancy recognition system deactivates the passenger's airbag if the passenger's seat is not occupied.

Control indicators  and  for seat occupancy recognition are located on the centre console. Both control indicators illuminate for approx. 5 seconds after the ignition is switched on, then either  or  illuminates continuously.

If both control indicators illuminate continuously, or neither illuminates after the ignition is switched on, there is a fault in the seat occupancy recognition system. The airbag and belt tensioner systems may fail to deploy in the event of an accident or may deploy unnecessarily. Have cause of fault remedied immediately by a workshop.


Belt tensioners - see page 41,
Airbag systems - see page 45.





Control indicator  illuminates continuously as soon as the system has detected that the passenger's seat is not occupied. The airbag for the passenger's seat is deactivated.


Pay attention to the control indicators for seat occupancy recognition.


Warning

If the passenger's seat is not occupied, control indicator  must illuminate continuously in the centre console after the ignition is switched on.

If control indicator  does not illuminate while driving, the airbag systems have not been deactivated on the passenger's side and may deploy unnecessarily in the event of an accident.


In this case, check that the seat backrest is not pushing down onto the seat cushion. Recline backrest if necessary. If control indicator  does not illuminate after adjusting backrest, have cause of fault remedied by a workshop.




Control indicator  illuminates continuously as soon as the system has detected that the passenger's seat is occupied and the passenger is correctly seated. When a passenger occupies the passenger's seat, the airbag for the passenger's seat is activated and may inflate in the event of an accident.



Pay attention to the control indicators for seat occupancy recognition.

Warning

If the passenger's seat is occupied, control indicator  must illuminate continuously in the centre console after the ignition is switched on.

If control indicator  does not illuminate while driving, the airbag systems have not been activated on the passenger's side; risk of fatal injury.

In this case, turn off the ignition, ensure the passenger's seat backrest is in an upright position and the passenger is sitting upright in the seat. Restart the vehicle. If the control indicator does not illuminate while driving, have cause of fault remedied by a workshop.

If control indicator  for airbag systems and belt tensioners illuminates in the instrument panel and  is illuminated in the centre console while the passenger's seat is occupied, consult a workshop immediately.


Important

- Accessories and other objects must not be affixed or stored in the area in which the airbags inflate, since they could cause injury if the airbags are deployed.
- Do not place any objects between the airbag systems and the vehicle occupants; risk of injury.

Warning

Never carry child restraint systems or other objects on your lap; risk of fatal injury.

- The airbag systems and belt tensioner control electronics can be found in the centre console area. In order to avoid malfunctions, do not store magnetic objects in this area.
- Do not stick anything on the steering wheel or instrument panel, or cover either of these areas with other materials.
- Use only a dry cloth or Interior/ Upholstery Cleaner to clean the steering wheel and instrument panel. Do not use any aggressive cleaning agents.



- The airbag systems are triggered depending on the severity of the accident and the type of impact.
- Each airbag can be triggered only once, which is indicated by continuous illumination of control indicator . Once triggered, an airbag must be replaced without delay. Consult a workshop.
- The speeds, directions of movement and deformation properties of the vehicles, and the properties of the obstacle concerned, determine the severity of the accident and triggering of the airbags. The degree of damage to your vehicle and the resulting repair costs alone are not indicative that the criteria for triggering of the airbags were met.
- Do not modify airbag system components, since this would render the vehicle unroadworthy.

 **Warning**

If handled im properly, the airbag systems can be triggered in an explosive manner; risk of injury!

- Applicable safety directives must always be observed when disposing of the vehicle. For this reason, disposal should be done by an authorised recycling company.
- Persons weighing less than 35 kg should only travel in a vehicle suitable for fitting a child restraint system. The use of child restraint systems in your vehicle is not recommended.
- Do not place any heavy objects on the passenger's seat when the seat is unoccupied, otherwise the airbag for the passenger's seat may be triggered unnecessarily in the event of an accident.
- To prevent malfunctions in the seat occupancy recognition system, do not use protective covers or seat cushions on the passenger's seat.


Notes on loading the vehicle

- Secure heavy objects in the luggage compartment. If objects are to be stacked, the heavier objects should be placed at the bottom. Unsecured objects in the luggage compartment would be thrown forward with great force in the event of heavy braking, for example.
- If heavy loads slip when the vehicle is braked heavily or driven around a bend, the handling of the vehicle may change.
- The warning triangle  and first-aid kit (cushion)  should always be freely accessible.

- No objects should be placed on the instrument panel. They are reflected in the glass, obstruct the driver's view and will be thrown through the vehicle in the event of heavy braking, for example.
- Objects must not be stored in the airbag inflation area, because they could cause injury if the airbag system is deployed.
- Loads must not obstruct the operation of the pedals, hand brake and gear shift lever, or hinder the freedom of movement of the driver. Do not place any unsecured objects in the interior.
- Do not drive with luggage compartment open when transporting bulky objects, for example, to avoid causing damage to the vehicle.

⚠ Warning

Failure to observe these descriptions can lead to injuries which may be fatal. Vehicle passengers should be informed accordingly.



S 13091

Storage compartments

Glove compartment

To open, pull handle.

The glove compartment can be locked using the ignition key.




S 13092

Console box between seats

To open, press button in centre of console box, rotate it left or right and pull cover down.

To close, push cover up until it latches in position and press the button.




S 13093

Net pockets

Located on the panel behind both seats.

Lift backrest release lever and fold seat forward to access the net pockets.




S 13094

Backrest pockets

Located on the rear side of the backrests on both seats.

Lift backrest release lever and fold seat forward to access the backrest pockets.



S 13095

Seat cushion pockets

Located on the front of the seat cushion on both seats.



S 13990

First-aid kit ☹️ *, warning triangle ⚠️ *

Your first-aid kit and warning triangle can be accommodated in the luggage compartment.



S 13988

Ashtrays

To be used only for ash and not for combustible rubbish.

⚠️ Warning

Failure to observe these descriptions can lead to injuries which may be fatal. Vehicle passengers should be informed accordingly.

To open: pull lid upwards.

To empty: pull ashtray out of the recess by gripping the lid and pulling upwards.

To install: seat the bottom edges of the ashtray in the recess and push the ashtray fully in.


Power outlets

Cigarette lighter 🔌

Press in cigarette lighter.

Pops up automatically once the element is heated. Pull out lighter.

The cigarette lighter socket can also be used as an accessory socket.



S 13089

Accessory socket

Accessory sockets can be used to connect electrical accessories. The battery is discharged if the engine is not running.

Do not damage the sockets by using unsuitable plugs. The maximum power consumption of electrical accessories must not exceed 120 watts.

Do not connect any current-delivering accessories, e.g. electrical charging devices or batteries.

Electrical accessories connected to the socket must comply with the electromagnetic compatibility requirements laid down in DIN VDE 40 839, otherwise vehicle malfunctions may occur.

If the tyre repair kit is being used, consumers must not be connected to the auxiliary socket at the same time.

Instruments, controls

Control indicators 55
 Instrument display 58
 Driver information centre 59
 Check control warning messages 68
 Warning buzzers 71
 Windscreen wipers 71
 Windscreen washer system 72



S 13858

Control indicators

The control indicators described here are not present in all vehicles. The descriptions however, apply to all instrument versions.

The control indicator colours mean:

- Red Danger, important reminder,
- Yellow Warning, information, fault,
- Green Engagement confirmation,
- Blue Engagement confirmation.



Anti-lock Brake System (ABS)

Control indicator illuminates in yellow.
 See page 124.



Luggage compartment open

Control indicator illuminates in yellow.
 See page 28.



Fog tail lamp

Control indicator illuminates in yellow.
 Illuminates when the fog tail lamp is on – see page 75.



Turn signals

Control indicator flashes in green.

The relevant control indicator flashes when the turn signal is on. Both control indicators flash with the hazard warning lamps on.

Rapid flashing: Failure of a turn signal lamp or associated fuse.

Turn signals - see pages 14, 74,

Change bulbs – see page 146,

Fuses – see page 141.



Headlamp high beam

Control indicator illuminates in blue.

Illuminates when high beam is on and during headlamp flash – see pages 13, 74.



Exhaust emissions

Control indicator illuminates or flashes in yellow.

Illuminates when the ignition is switched on and goes out shortly after the engine has started.

If it illuminates when the engine is running:

Fault in emission control system.

The permitted emission limits may be exceeded. Consult a workshop.

If it flashes when the engine is running:

Fault that can lead to destruction of the catalytic converter – see page 116.

Consult a workshop immediately.



Brake system, clutch system

Control indicator illuminates or flashes in red.

Illuminates when the ignition is switched on if the hand brake is applied or if the brake/clutch fluid level is too low.


Flashes at speeds over 8 km/h (5 mph) if hand brake is applied.

Release hand brake before continuing journey, to avoid overheating and damaging the brake system.

Further information - see pages 68, 124, 156.

Warning

If it illuminates when the hand brake is not applied: Stop the vehicle; interrupt your journey immediately. Consult a workshop.



Engine oil pressure

Control indicator illuminates in red.

Illuminates when the ignition is switched on and goes out shortly after the engine has started.

If it illuminates when the engine is running:
Engine lubrication may be interrupted. This may result in damage to the engine and/or locking of the drive wheels:

1. Move out of the flow of traffic as quickly as possible without impeding other vehicles.
2. Depress clutch.
3. Shift into neutral.
4. Switch off ignition.

Warning

When the engine is off, considerably more force is needed to brake and steer. Do not remove key until vehicle has come to a standstill, otherwise the steering column lock could engage unexpectedly.

Check engine oil level before consulting a workshop.



Coolant temperature

Control indicator illuminates in red.

If it illuminates when the engine is running:
Stop and switch off engine. Coolant temperature too high: Danger of engine damage. Check coolant level – see page 154.



Airbag systems, belt tensioners

Control indicator illuminates in red.

If it illuminates when the engine is running:
Fault in airbag system or belt tensioners – see pages 41, 45.



Driver's seat belt

Control indicator illuminates or flashes in red.

Illuminates for approx. 20 seconds when the ignition is switched on, or until driver's seat belt is fastened. Flashes for a further 60 seconds if seat belt remains unfastened.

If seat belt remains unfastened when the vehicle is being driven, control indicator illuminates for approx. 20 seconds and flashes for a further 60 seconds.

Apply seat belt – see page 42.
Control indicator goes out immediately.

Seat belts - see page 39,
Further information - see page 43.



Alternator

Control indicator illuminates in red.

Illuminates for a few seconds when the ignition is switched on.

If it illuminates when the engine is running:

Stop and switch off engine. Battery is not being charged: Engine cooling may not be operating. Consult a workshop.



Electronic Stability Program (ESP),

Electronic Stability Control (ESC)

Control indicator illuminates or flashes in yellow.

Flashing during driving:

System actively engaged - see page 118.

If it illuminates while driving:

System switched off or fault in Electronic Stability Program (ESP) – see page 118.



Front fog lamps

Control indicator illuminates in green.

Illuminates when the front fog lamps are on – see page 75.



Electronic immobiliser

Control indicator illuminates or flashes in yellow.

If it illuminates when the ignition is on:

Fault in the immobiliser system; the engine cannot be started - see page 21.




Instrument display

Tachometer

Making use of the tachometer helps to save fuel; it indicates the engine speed.

Warning zone on right: maximum permissible engine speed exceeded, danger to engine.

If possible, drive in each gear in the low engine speed range (between approx. 2000 and 3000 rpm) and maintain an even vehicle speed.



Speedometer

Indicates the vehicle speed.



Fuel gauge

Pointer in left zone = Fill up – see page 114.

Never run the tank dry!

Because of the fuel remaining in the tank, the amount of fuel required to fill the tank may be less than the specified tank capacity.



Driver information centre

Displays vehicle information and also check control warning messages when the ignition is on.



The type of information and how it is displayed depends on the settings made in personalisation mode. Some information and warning messages appear on the display in abbreviated form.



Information display - see page 60,
Personalisation mode - see page 64,
Check control warning messages - see page 68.



Selecting functions

Functions and settings can be accessed via the driver information centre.


This is done using buttons  and  located on the left side of the steering wheel. The relevant menu options are then shown on the display one after the other.


If check control warning messages are displayed, the display is blocked for other functions. Acknowledge the message by pressing button  or . If there are several warning messages, acknowledge them one at a time.

Information display - see next column,
Check control warning messages - see page 68.

Information display

The information display provides information on driving data, which is continually recorded and evaluated electronically.

With the ignition on, press button  to reach the next menu item.

Press and hold button  to reset relevant menu items.

Some information appears on the display in abbreviated form.

The menu items are displayed in the following order:

- Outside air temperature and odometer,
- TRIP A (Trip odometer),
- TRIP B (Trip odometer),
- FUEL RANGE (distance to empty),
- ECON (Average fuel consumption),
- AV SPEED (Average speed),
- OIL LIFE,
- COOLANT,
- BOOST.

When the ignition is switched off and back on again, the previously displayed menu item is shown.



Outside temperature and odometer

Displays outside temperature and record of total kilometres/miles driven (odometer) when the ignition is on.

With the ignition off, the odometer is presented for approx. 10 seconds when a door is opened.



A fall in temperature is indicated immediately and a rise in temperature after a time delay.

The outside temperature is displayed in either degrees Celsius (°C) or degrees Fahrenheit (°F), depending on the units of measurement chosen in personalisation mode - see page 64.

If outside temperature is low, "ICE POSSIBLE" appears in the display as a warning for icy road surfaces.

Warning

Caution: the road surface may already be icy even before the message appears in the display.



Trip odometer

Displays distance travelled in kilometres (km) or miles (mi) since the last reset.

Select menu item **TRIP A** or **TRIP B** in the information display.

Both odometers can be used at the same time.

Each trip odometer can be reset to zero separately at any time.




Fuel range

Displays the remaining distance the vehicle can travel in kilometres (km) or miles (mi), based on current fuel tank contents and average fuel consumption. The display shows average values.

The vehicle updates the range automatically after a brief delay when the vehicle has been refuelled.

Select menu item **FUEL RANGE** in the information display.

The fuel range cannot be reset.



If the fuel level is low, a warning message "FUEL RANGE LOW" appears in the display.

Check control warning messages - see page 68.



Average fuel consumption

Displays the average amount of fuel used in litres per 100 kilometres (L/100km) or miles per gallon (MPG), based on the distance travelled and the amount of fuel used since the last reset.

Select menu item **ECON** in the information display.

The measurement can be reset at any time.



Average speed

Displays the average vehicle speed in kilometres per hour (km/h) or miles per hour (mph) since the last reset.

Select menu item **AV SPEED** in the information display.

The measurement can be reset at any time.

Stoppages in the journey with the ignition off are not included in the calculations.

Interruption of power supply

If the power supply has been interrupted or the battery voltage drops too low, the values stored in the information display will be lost.




Engine oil life monitor

Displays an estimate of the engine oil's remaining useful life as a percentage, since the last reset.

When the system has been reset after an engine oil change, the display will show 100%.

Select menu item **OIL LIFE** in the information display.

Engine oil life monitor - see pages 69, 151.



Coolant temperature

Displays engine coolant temperature in degrees Celsius (°C) or degrees Fahrenheit (°F).

Select menu item **COOLANT** in the information display.





Turbo boost

Displays amount of boost the engine is currently receiving in kilopascals (kPa) or pounds per square inch (psi).

Select menu item **BOOST** in the information display.





Personalisation mode


With the ignition on and the vehicle stationary, press and hold buttons  and  at the same time to enter the personalisation mode.

Menu item **OIL LIFE RESET** will appear.

Engine oil life monitor - see pages 63, 69, 151.

Press button  to reach the next menu item.

Press and hold button  for approx. 1 second to scroll through the available settings for each menu item.

Press button  to select the currently displayed setting and progress to the next menu item.

If no selection is made within a approx. 10 seconds, the personalisation mode ends and the display goes back to the previously displayed information display mode.

The personalisation mode will also end immediately if the ignition is switched off.

If vehicle speed exceeds 3 km/h (2 mph), only the **UNITS** menu will be available.

Some information appears on the display in abbreviated form.

The menu items are displayed in the following order:

- OIL LIFE RESET,
- UNITS,
- LOCK HORN,
- UNLOCK HORN,
- LIGHT FLASH,
- DELAY LOCK,
- AUTO UNLK (Unlock),
- EXT LIGHTS (Exterior lamps),
- LANGUAGE.

The default settings for these menu items were set during vehicle production.

Scroll through the available settings and select the desired setting to progress to the next menu item.



Setting units of measurement

You can select which units of measurement are to be used.

Select menu item **UNITS** in the personalisation mode.


Settings include "ENGLISH" and "METRIC".

When "ENGLISH" is selected, all information will be displayed in English units, e.g. distance will be shown in miles (mi) and fuel consumption in miles per gallon (MPG).

When "METRIC" (default) is selected, all information will be displayed in metric units, e.g. distance will be shown in kilometres (km) and fuel consumption in litres per 100 kilometres (L/100km).





Lock horn

This feature causes the horn to sound every time button  is pressed on the remote control and can be enabled or disabled.

Select menu item **LOCK HORN** in the personalisation mode.


Settings include "OFF" and "ON".

When "OFF" (default) is selected, the horn will not sound on the first press of button . The horn will still sound on the second press, to confirm locking has already taken place.

When "ON" is selected, the horn will sound every time button  is pressed.





Unlock horn

This feature causes the horn to sound on the first press of button  on the remote control and can be enabled or disabled.

Select menu item **UNLOCK HORN** in the personalisation mode.




Settings include "OFF" and "ON".

When "OFF" (default) is selected, the horn will not sound when button  is pressed.

When "ON" is selected, the horn will sound on the first press of button .









Light flash

This feature causes the hazard warning lamps to flash every time button ,  or  is pressed on the remote control and can be enabled or disabled.

Select menu item **LIGHT FLASH** in the personalisation mode.

Settings include "OFF" and "ON".

When "OFF" is selected, the hazard warning lamps will not flash when button ,  or  is pressed.

When "ON" (default) is pressed, the hazard warning lamps will flash every time button ,  or  is pressed.





Delayed locking


This feature delays the actual locking of the doors and can be enabled or disabled.

Select menu item **DELAY LOCK** in the personalisation mode.

Settings include "OFF" and "ON".

When "OFF" is selected, the doors will lock immediately when button  is pressed on the remote control.

When "ON" (default) is selected, the doors will not lock until approx. 5 seconds after the last door is closed when button  is pressed on the remote control.

To bypass the delay, press button  again. The doors will lock immediately.



Automatic unlocking

This feature enables certain doors to unlock automatically when the key is turned to ignition switch position **O** and can be enabled or disabled.

Select menu item **AUTO UNLK** in the personalisation mode.


Settings include "ALL", "DRIVER" and "NONE".

When "ALL" (default) is selected, both doors will unlock automatically.

When "DRIVER" is selected, only the driver's door will unlock automatically.

When "NONE" is selected, neither door will unlock automatically.

Central locking system - see page 24.



Welcome light function

This feature actuates the exterior lamps when button **Ⓜ** is pressed on the remote control. This feature can be enabled or disabled.

Select menu item **EXT LIGHTS** in the personalisation mode.

Settings include "OFF" and "ON".

When "ON" (default) is selected, the exterior lamps will illuminate for approx. 20 seconds or until a door is opened when button **Ⓜ** is pressed on the remote control.

When "OFF" is selected, exterior lamps will not illuminate when button **Ⓜ** is pressed on the remote control.





Language selection

You can select the display language for some functions.

Select menu item **LANGUAGE** in the personalisation mode.

Settings include "ENGLISH", "FRENCH", "SPANISH" and "GERMAN".

The personalisation mode ends after making your language selection and the display goes back to the previously displayed menu item in the information display - see page 60.

Alternatively, press and hold buttons  and  at the same time to exit the personalisation mode.

Remote control - see page 22,
Central locking - see page 24,
Delayed locking - see page 24,
Automatic locking - see page 25,
Automatic unlocking - see page 25.

Check control warning messages

Check control monitors several fluid levels, the remote control battery, the engine, the fuel filler cap and the status of several vehicle features including cruise control, traction control, the Electronic Stability Program (ESP) and the airbag systems.

"ESC" appears in some warning messages. Electronic Stability Control (ESC) is a component part of the Electronic Stability Program (ESP), improving driving stability.

Warning messages appear in the driver information centre and a chime may sound when the message is displayed. If there are several warning messages, they are displayed one after the other.

Some of the warning messages appear on the display in abbreviated form.

Examples of warning messages are shown on the following pages.

Acknowledge warning messages as described on page 60. The messages will clear from the display when the condition no longer exists.

Unacknowledged warning messages will be redisplayed later if the condition still exists.



Warning messages:

AUTO LIGHTS OFF

Auto light control is disabled via the switch on the lighting lever.

AUTO LIGHTS ON

Auto light control is re-enabled via the switch on the lighting lever.

The message will only appear when auto light control has been switched off and back on again.

It will not appear when the ignition is switched on.

BRAKE FLUID

Brake/clutch fluid level is low. Control indicator (D) also illuminates in the instrument panel. Top up brake/clutch fluid.

After correcting brake/clutch fluid level, have the cause of fluid loss remedied by a workshop.



Brake and clutch fluid level - see page 156.

CHANGE OIL SOON


Engine oil life has expired. Change engine oil.


Make an appointment with a workshop for Service work as soon as possible.

Engine oil change, engine oil filter change - see page 154.

Acknowledging the message by pressing button  or  does not reset the engine oil life monitor. See engine oil life monitor on pages 63, 151 for further information.

COMPETITIVE MODE

Competitive driving mode has been selected via button  on the centre console.

Control indicator  illuminates in the instrument panel.

Adjust your driving accordingly.

Competitive mode - see page 120.

CRUISE ENGAGED

Cruise control has been activated via the buttons located on the left side of the steering wheel.

Cruise control - see page 121.

DOOR AJAR


One or more of the doors are not closed properly. Close driver's door and passenger's door.

ENGINE DISABLED

Starting of the engine has been disabled.

Consult a workshop immediately.


ESC ACTIVE


ESP has come into action, to assist driving stability in slippery road conditions. Control indicator  also flashes in the instrument panel. Adjust your driving accordingly.

The message may remain for a short while after ESP assistance has ended.

Electronic Stability Program (ESP) - see page 118.

ESC OFF

ESP has been switched off via button  on the centre console, or a fault is present.

Control indicator  also illuminates in the instrument panel. Adjust your driving accordingly.

Electronic Stability Program (ESP) - see page 118.

FUEL RANGE LOW

Fuel level is low. Fill up fuel tank.

Refuelling - see page 114.

ICE POSSIBLE

Icy road conditions are possible due to low outside air temperature. Adjust your driving accordingly.

Extreme driving conditions - see page 113.

KEY FOB BATT LOW


Battery voltage of remote control is too low. Replace battery - see page 23.

LOW COOLANT

Engine coolant level is low. Top up coolant level and have cause of loss remedied by a workshop.

Coolant level - see page 155.

LOW TRACTION


Traction control has come into action, to limit wheel spin in slippery road conditions. Control indicator  also flashes in the instrument panel.

Adjust your driving accordingly.

The message may remain for a short while after traction control has ended.

Electronic Stability Program (ESP) - see page 118.


PARKING BRAKE

The hand brake is applied at speeds over 8 km/h (5 mph). Control indicator  also flashes in the instrument panel.


Release hand brake before continuing journey, to avoid overheating and damaging the brake system.

Hand brake - see page 124.

SERVICE AIR BAG

Fault in airbag system. Control indicator  also illuminates in the instrument panel. The airbags may fail to trigger in the event of an accident. Consult a workshop immediately.


SERVICE ESC

Fault in ESP. Control indicator  also illuminates in the instrument panel. In slippery road conditions, the system will not assist driving stability. Adjust your driving accordingly.

If the message appears while driving, stop the vehicle and switch the ignition off and back on again. If the message still appears, consult a workshop as soon as possible.

Electronic Stability Program (ESP) - see page 118.



SERVICE TRACTION

Fault in traction control. Control indicator  also illuminates in the instrument panel. In slippery road conditions, the system will not limit wheel spin. Adjust your driving accordingly.

Consult a workshop as soon as possible.


Electronic Stability Program (ESP) - see page 118.

TRACTION OFF

Traction control has been deactivated via button  on the centre console. Control indicator  also illuminates in the instrument panel. Adjust your driving accordingly.

Electronic Stability Program (ESP) - see page 118.

TRUNK AJAR

The luggage compartment lid is open or is not closed properly. Control indicator  also illuminates in the instrument panel. Close luggage compartment lid.

Do not drive with the luggage compartment open.

Luggage compartment - see pages 26, 55.

Warning buzzers

When starting the engine or while driving:

- if driver's seat belt is not fastened,
- if passenger's seat belt is not fastened when the seat occupancy recognition system detects that the passenger's seat is occupied,
- if the doors or the luggage compartment have not been properly closed when starting-off,
- if the hand brake is applied at speeds over 8 km/h (5 mph),
- while operating the indicators.

When the vehicle is parked and the driver's door is opened:

- if the head lamps or parking lamps are switched on,
- when the key is in the ignition switch,
- if any door remains open when the doors are locked with the remote control ✱.

Driving hints - see page 110,
Saving fuel, protecting the environment - see page 112.



S13850

Windscreen wipers

To switch on, push lever upwards.

- = Fast
- = Slow
- ☒ = Timed interval wipe
- = Off
- ☒ = Misting function

Switch to next setting up or down:
gently push lever.

In case of light rain or mist, move lever downwards from position ○ to position ☒ and release: Single swipe. Hold for additional wiping cycles. Lever returns automatically to position ○ when released.

Return the lever to its original position to switch off.

Further information - see pages 163, 157.



S14006


Adjustable wiper interval

To set the wiper interval to a value between 3 and 10 seconds:

Switch on ignition. Move lever upwards from position ○ to timed interval wipe ☒.

Swivel adjustment band ☒ to the desired setting: The bars to the left of the adjustment band represent wiping frequency.

Larger bars near the top represent more frequent wiping, and the smaller bars near the bottom represent less frequent wiping.

With lever in position , wiping frequency is also dependent upon vehicle speed. As vehicle speed increases, wiping will become more frequent.

The wiping frequency selected via the adjustment band remains stored until it is changed again.

Further information - see pages 163, 157.



S13851

Windscreen washer system

To operate, press button  on end of lever.

Washer fluid is sprayed onto the windscreen and at the same time the wipers are operated for four cycles.

Further information - see pages 163, 158.

Lighting

Exterior lamps.....	73
High beam, headlamp flash.....	74
Turn signals.....	74
Front fog lamps D	75
Fog tail lamp D	75
Reversing lamp	75
Hazard warning lamps	75
Instrument illumination, information display illumination	76
Courtesy lamps	76
Reading lamps	76
Battery discharge protection.....	77
Lamp covers.....	77
Headlamps when driving abroad	77



S 13845

Exterior lamps

Turn light switch:

- D = High or low beam
- P = Parking lamps
- AUTO = Auto light control
- O = Auto light control off/on

Light switch to **AUTO**: Exterior lamps come on automatically when the engine is running and if outside light conditions warrant it.

For reasons of safety, the light switch should always remain in the **AUTO** position.

If necessary, auto light control can be switched off; turn the light switch to position O and release. Light switch returns to **AUTO** position and the driver information centre shows "AUTO LIGHTS OFF" briefly.

Turn light switch to position O again and release to switch auto light control back on. Light switch returns to **AUTO** position and the driver information centre shows "AUTO LIGHTS ON" briefly.

Auto light control will switch on automatically when the ignition is switched off and back on again.

Depending on outside light conditions, the headlamps illuminate for approx. 20 seconds when the key is removed from the ignition switch.

Driver information centre - see page 59, Check control warning messages - see page 68.

Welcome light function

Exterior lamps illuminate for approx. 20 seconds or until a door is opened when the vehicle is unlocked with the remote control. See page 67.




S 13846

High beam, headlamp flash

To switch from low to high beam, push lever forwards.

To switch to low beam, pull lever back towards steering wheel.

To activate the headlamp flash, pull lever towards steering wheel. The high beam is switched on while activated.

The blue control indicator  illuminates when the high beam or headlamp flash is on.



S 13847

Turn signals

To switch on, push lever up or down.


Lever up = Right turn signal
Lever down = Left turn signal

After operation, the turn signal lever returns to its starting position.

If lever is moved past resistance point, turn signal lamp remains on. When steering wheel moves back towards the straight-ahead position, turn signal lamp is automatically deactivated.

Tap signal: Move lever to resistance point and release, to activate the turn signals when changing lanes or the like. Move lever to resistance point and hold for the turn signals to flash for longer.

Switch the turn signal off manually by moving the lever slightly.




Front fog lamps \mathcal{D}

- On = Press \mathcal{D} , \mathcal{D} in instrument panel illuminates
- Off = Press \mathcal{D} again or switch ignition or parking lamps off

The fog lamps can only be switched on when both the ignition and parking lamps are on.

Follow the regulations of the country in which you are driving when using front fog lamps.



Fog tail lamp $\mathcal{Q}\ddot{\mathcal{E}}$

- On = Press $\mathcal{Q}\ddot{\mathcal{E}}$, $\mathcal{Q}\ddot{\mathcal{E}}$ in instrument panel illuminates
- Off = Press $\mathcal{Q}\ddot{\mathcal{E}}$ again or switch ignition or headlamps off

The fog tail lamp can only be switched on when both the ignition and headlamps are on.

Reversing lamp

Comes on when reverse gear is engaged and ignition is switched on.



Hazard warning lamps

To switch on, push button \triangle ; to switch off, push button \triangle again.

To aid location of the button, the red surface is illuminated with the ignition switched on. When the button is pressed, its control indicator flashes in time with the hazard warning lamps.




S 13066

Instrument illumination, information display illumination

In high ambient light conditions, the auto lighting turns on the illumination with fixed intensity to indicate that the exterior lamps are on.

In most other lighting conditions, brightness can be adjusted when the ignition is on by turning a adjuster wheel up or down.

When the light switch is turned to position \odot , instrument panel backlighting goes out and the driver information centre is illuminated at its maximum brightness.




S 14046

Courtesy lamps

Automatically switch on when the doors are unlocked with the remote control, when a door is opened or when the key is removed from the ignition switch.

Courtesy lamps switch off approx. 20 seconds after closing the doors and immediately when the ignition is switched on or after locking the doors with the remote control.



S 14047

Reading lamps

Reading lamps on the left and right are individually operable.

Press button on underside of interior mirror on relevant side to switch on reading lamp. Button extends.

Press button again to switch off reading lamp. Button retracts.

Cigarette lighter illumination

Comes on when the ignition is switched on.

Luggage compartment lighting

Comes on when the luggage compartment is opened.

Battery discharge protection

To prevent the battery from becoming discharged, the courtesy lamps, reading lamps and luggage compartment lighting switch off automatically 20 minutes after the ignition is switched off.

Lamp covers

The inside of the lamp covers may mist up briefly in poor, wet and cold weather conditions, in heavy rain or after washing. The mist disappears quickly by itself; to help, switch on the lamps.

Headlamps when driving abroad


The asymmetrical dipped beam extends visibility at the edge of the road at the passenger's side.

This causes glare for oncoming traffic if the vehicle is driven in countries where traffic drives on the opposite side of the road.

Consult a workshop.

Infotainment system


Brief overview..... 78
 General information 80
 Operation 81
 Main menu 82
 Sound settings 84
 Radio 86
 CD/MP3 player 90
 Troubleshooting..... 97
 General advice..... 98
 Glossary 100
 Radio reception 101
 Mobile telephones and radio
 equipment (CB) * 101





S 17717


Brief overview

Operating elements

- 1** **LOAD** Loading discs with six-disc CD player * Press
- or -
-  Setting time/date: Press
- 2** **FAV** View and save favourite stations: Press
- 3** **i** Display additional text information for RDS stations or MP3 files: Press
- 4** **MENU** Display menus
- 5** Display panel

- 6** **1...6** Preset buttons 1 to 6
Select options in corresponding display panel labels
Radio:
View and save favourite stations
- 7** **EQ** Select preset equalisation settings: Press
- 8**  Adjust sound settings: Press and turn
CD: Select track; turn
Radio: Select station; turn
- 9** **CAT** Change category
CD: Toggle between CD audio and MP3 files




- 10 EJECT** Eject CD: Press
- 11 CD/AUX** Switch to CD mode/
auxiliary input device:
Press
- 12** Auxiliary input jack
- 13 FWD** Fast forward during
CD playback:
Press and hold
- 14 REV** Reverse during
CD playback:
Press and hold
- 15**  Switching on and off:
Press
Volume adjustment:
Turn
- 16 SEEK ▷** Search button
Radio: Search forwards
CD: Skip forwards
- 17 SEEK ◁** Search button
Radio:
Search backwards
CD: Skip backwards
- 18 BAND** Switch on radio mode,
select waveband (FM, AM)
- 19 -** CD slot





S 17718

Steering wheel remote control

Audio controls are located on the right-hand side of the steering wheel.

- 20**  Decrease volume
- 21**  Increase volume
- 22**  Mute button

- 23**  Search button
Radio:
Search backwards
CD:
Skip backwards
- 24**  Search button
Radio:
Search forwards
CD:
Skip forwards

General information

The audio system offers you state-of-the-art vehicle infotainment. The illustrations on the previous pages show the Infotainment system and the steering wheel mounted remote control buttons.

The radio has a total of 36 station memories for a combination of both wavebands (FM, AM).

The RDS (Radio Data System) functionality makes it much easier to find an FM channel and guarantees interference-free reception. It also provides additional useful functions.

You can enjoy both audio and MP3-CDs on the integrated CD player. A six-disc CD player * is also available as an option.

The Infotainment system features Speed Compensated Volume (SCV) regulation. The volume regulation setting can be changed.

The sound processor offers you a range of preset equalization settings, to optimise the sound.

An enhanced, high-power audio amplifier and subwoofer * for the Infotainment system are available as an option.

The well-thought out design of the operating elements, clearly structured menus on the large display and a large on/volume knob enable you to operate the system easily.

General notes on these operating instructions

For an overview of the different functions of the Infotainment system, see the section "Brief overview" on page 78, together with the relevant illustration, which shows all of the display and operating elements.


You can find a description of the basic steps for operating the Infotainment system in the section "Operation" on page 81.

You can find detailed functional descriptions for your Infotainment system in the sections "Radio" on page 86 and "CD/MP3 player" on page 90.

Should your Infotainment system not function the way you expect it to, please read the sections "Troubleshooting" on page 97 and "General advice" on page 98. In many cases, this will allow you to fix a suspected fault quickly.

The section "Glossary" on page 100 explains technical terms.

The following symbols will help you to read these operating instructions easily:

-  A hand in front of the text asks you to perform an action.
- ✓ A tick in front of the text identifies the Infotainment system's response.
- A bullet point in front of the text identifies additional information on the subject.
- A hyphen in front of the text marks items of a list.
- △ A safety or warning note contains important information on how to use your Infotainment system safely. Failure to observe this information may result in a risk of damage or injury. Therefore, please observe this information with particular care.

Important information on operation and road safety

Use your Infotainment system in such a way that you can always drive safely. If you have any doubts, stop the vehicle and operate the Infotainment system while the vehicle is not moving.

Theft protection

The Infotainment system is equipped with an electronic theft-deterrent feature which works by learning part of the Vehicle Identification Number (VIN).

The Infotainment system only works in your vehicle and is therefore of no value to thieves.

Retained Accessory Power (RAP)

This feature allows the Infotainment system to be played even after the ignition is turned off.



Display

The following information can be shown on the central display panel:

- Radio information,
- Time,
- Date,
- Sound settings,
- CD/MP3 information.

Operation

Switching on/off

 Press the  15 knob.



- ✓ The Infotainment system switches on/off.

Information displayed

The illuminated display shows information for the radio, the CD/MP3 player, time and the sound settings.

When the Infotainment system is switched on, the display illuminates and the most recently selected audio source plays at the previous volume setting.

Volume

 Turn the  15 knob; clockwise to increase the volume or anticlockwise to decrease the volume.

- When it is switched on, the Infotainment system plays at the most recently set volume.
- The radio volume can be adjusted automatically to compensate for road and wind noise, depending on vehicle speed. See “Speed Compensated Volume (SCV)” on page 86 for further information.

Steering wheel remote control

The following steering wheel controls are supplied for your convenience and to improve road safety:

Buttons 20 and 21

Volume control

Press the plus or minus button to increase or decrease the volume of the audio source currently selected.

Button 22

Mute/unmute sound

Press the button to mute the sound. Press again to turn the sound back on.

Buttons 23 and 24

Search buttons

- Radio:
 - Press to search for next/previous station memory.
 - Press and hold for approx. 1 second to advance to next/previous station with a strong signal in the selected waveband.
- CD:
 - Press to skip to next/previous track.
 - Press and hold for approx. 1 second to continue skipping forwards or backwards to other tracks on the disc.

Main menu

The main menu is the display that appears after the Infotainment system is switched on. The following information may be displayed:

- Waveband,
- Radio station frequency or name,
- Time,
- CD/MP3 information,
- Display, playback, sound or station memory labels etc..

Audio Information

The following information is shown in the display:








- Current waveband or CD.
- Current station frequency, CD track number or elapsed track time.
- If the RDS function is active, the station name or station call letters appear on the display. See "RDS (Radio Data System)" on page 87.
- If there is a CD in the CD slot, the "CD" symbol illuminates on the display. See "CD/MP3 Player" on page 90.
- If the CD is in random mode, the "RDM" symbol illuminates on the display. See "Random Mode" on page 94.








Time and date

Display of the current time and date.

Single-disc CD player

In vehicles with a single-disc CD player, set the time and date as follows:

-  Turn ignition key to ACC or RUN.
-  Press the  **15** knob.
- ✓ The Infotainment system switches on.
-  Press the  **1** clock button.
- ✓ The HR, MIN, M.M, DD, YYYY (hour, minute, month, day and year) labels appear on the display.
-  Press the appropriate button **6** located below the label that you wish to change.
-  Press the same button **6** again to increase the time/date.
- ✓ The value selected increases by one (hour/minute/month/day/year) every time the same button **6** is pressed again.

- The value selected can also be changed using the **SEEK ▷ 16**, **SEEK ◁ 17**, **FWD 13** and **REV 14** buttons and the  **8** tune knob, as follows:
 -  Press the **SEEK ▷ 16** button or the **FWD 13** button.
 - ✓ The value selected increases (hour/minute/month/day/year).
 - or -
 -  Press the **SEEK ◁ 17** button or the **REV 14** button.
 - ✓ The value selected decreases (hour/minute/month/day/year).
 - or -
 -  Turn the  **8** tune knob clockwise or anticlockwise.
 - ✓ The value selected increases or decreases (hour/minute/month/day/year).
- The date does not display automatically. To display the date, proceed as follows:
-  Press the  **1** clock button with the Infotainment system on.
 - ✓ The date appears.
 - After a few seconds, the display reverts back to the normal radio and time display.

Six-disc CD player *

In vehicles with a six-disc CD player, set the time and date as follows:

- 👉 Turn ignition key to ACC or RUN.
- 👉 Press the **15** knob.
- ✓ The Infotainment system switches on.
- 👉 Press the **MENU 4** button until the set-up menu is displayed.
- ✓ The clock option label appears on the display.
- 👉 Press the appropriate button **6** located below the clock option label.
- ✓ The HR, MIN, MM, DD, YYYY (hour, minute, month, day and year) labels appear on the display.
- 👉 Press the appropriate button **6** located below the label that you wish to change.
- 👉 Press the same button **6** a gain to increase the time/date.
- ✓ The value selected increases by one (hour/minute/month/day/year) every time the same button **6** is pressed again.

- The value selected can also be changed using the **SEEK ▷ 16**, **SEEK ◁ 17**, **FWD 13** and **REV 14** buttons and the **8** tune knob, as follows:
 - 👉 Press the **SEEK ▷ 16** button or the **FWD 13** button.
 - ✓ The value selected increases (hour/minute/month/day/year).
 - or -
 - 👉 Press the **SEEK ◁ 17** button or the **REV 14** button.
 - ✓ The value selected decreases (hour/minute/month/day/year).
 - or -
 - 👉 Turn the **8** tune knob clockwise or anticlockwise.
 - ✓ The value selected increases or decreases (hour/minute/month/day/year).
- The date does not display automatically. To display the date, proceed as follows:
 - 👉 Press the **MENU 4** button followed by the button **6** located below the clock option label, with the Infotainment system on.
 - ✓ The date appears.
- After a few seconds, the display reverts back to the normal radio and time display.


Changing default time and date settings

The default time and date settings can be changed from a 12 hour clock to a 24 hour clock and from the date format MM/DD/YYYY (month/day/year) to DD/MM/YYYY (day/month/year).

Change the default time or date settings as follows:

- 👉 Press the **1** clock button (single-disc CD player)
 - or -
 - Press the **MENU 4** button (six-disc CD player *).
- 👉 Press the appropriate button **6** located below the forward arrow label on the display.
- ✓ The 12H, 24H, MM/DD/YYYY and DD/MM/YYYY labels appear on the display.
- 👉 Press the appropriate button **6** located below the label that you wish to select.
- 👉 Press the **1** clock button or the **MENU 4** button to apply the selection.
- ✓ The selection is applied.
- Alternatively, allow the screen to time out and the selection made will become the default time/date setting.

Sound settings








Use the  8 tune knob to adjust the following sound settings:

- Bass: Low-frequency sounds,
- Midrange: Middle-frequency sounds,
- Treble: High-frequency sounds,
- Balance: Volume distribution left – right,
- Fade: Volume distribution front speakers – rear speakers.



Setting the tone


(bass/midrange/treble)

The bass, midrange and treble tones can be adjusted to suit personal requirements. To adjust the settings, proceed as follows:

-  Press the  8 tune knob until the tone control labels appear on the display.
- ✓ The BASS, MID and TREB labels appear on the display.
-  Press the  8 tune knob continuously to highlight the desired label.
- or -
-  Press the appropriate button 6 located below the label that you wish to select.
-  Turn the  8 tune knob; clockwise to increase the level or anticlockwise to decrease the level.
- ✓ The highlighted setting is adjusted.


- The highlighted setting can also be adjusted using the **SEEK ▷ 16**, **SEEK ◁ 17**, **FWD 13** and **REV 14** buttons, as follows:

-  Press the **SEEK ▷ 16** button or the **FWD 13** button.
- ✓ The level is increased.
- or -
-  Press the **SEEK ◁ 17** button or the **REV 14** button.
- ✓ The level is decreased.

- To quickly adjust bass, midrange, or treble to the middle position, proceed as follows:
 - ☞ Press and hold the appropriate button **6** located below the BASS, MID, or TREB label for more than two seconds.
 - ✓ A beep sounds and the level is adjusted to the middle position.
- To quickly adjust all tone and speaker controls to the middle position, proceed as follows:
 - ☞ Press the  **8** tune knob for more than two seconds.
 - ✓ A beep sounds and all tone and speaker controls are adjusted to the middle position.
- If a radio station's signal is weak, or if there is static, decrease the treble.




Equalizer (EQ)

A range of preset equalization settings can be selected (instead of manually adjusting the bass, midrange and treble tones), as follows:

- ☞ Press the **EQ 7** button.
 - ✓ The equalizer labels appear on the display.
- ☞ Press the appropriate button **6** located below the label you wish to select.
 - ✓ The preset equalization settings are applied.
- ☞ Press the **EQ 7** button again to return to the manual mode ('Manual' appears on the display).
 - or -
- ☞ Manually adjust the bass, midrange and treble with the  **8** tune knob to return to the manual mode.

Adjusting the speakers (balance/fade)

The volume for the driver and passenger sides, and the front and rear speaker volume can be adjusted to suit personal requirements. To adjust the settings, proceed as follows:

- ☞ Press the  **8** tune knob and the speaker control labels appear on the display.
 - ✓ The BAL and FADE labels appear on the display.
- ☞ Press the  **8** tune knob continuously to highlight the desired label.
 - or -
- ☞ Press the appropriate button **6** located below the label that you wish to select.
- ☞ Turn the  **8** tune knob clockwise or anticlockwise to adjust the highlighted setting.
 - ✓ The highlighted setting is adjusted.

- The highlighted setting can also be adjusted using the **SEEK ▷ 16**, **SEEK ◁ 17**, **FWD 18** and **REV 14** buttons, as follows:
 - ☞ Press the **SEEK ▷ 16** button or the **FWD 18** button until the desired level is obtained.
 - or -
 - ☞ Press the **SEEK ◁ 17** button or the **REV 14** button until the desired level is obtained.
- ✓ The highlighted setting is adjusted.
- To quickly adjust balance or fade to the middle position, proceed as follows:
 - ☞ Press and hold the appropriate button **6** located below the **BAL** or **FADE** label for more than two seconds.
- ✓ A beep sounds and the level is adjusted to the middle position.
- To quickly adjust all speaker and tone controls to the middle position, proceed as follows:
 - ☞ Press the **🎵 6** tune knob for more than two seconds.
- ✓ A beep sounds and all speaker and tone controls are adjusted to the middle position.

Speed Compensated Volume (SCV)

To compensate for ambient and rolling noise, the Infotainment system volume adjusts to the speed of the vehicle.

Activate/deactivate the SCV function or change the level of radio volume compensation as follows:

- ☞ Set the volume to the desired level. See "Volume" on page 81.
- ☞ Press the **MENU 4** button until the radio set-up menu appears.
- ✓ The 'AUTO VOLUM' option label appears on the display.
- ☞ Press the appropriate button **6** located below the 'AUTO VOLUM' option label on the display.
- ✓ The OFF, Low, Med and High labels appear on the display.
- ☞ Press the appropriate button **6** located below the label that you wish to select.
- ✓ The new setting is applied.
- The display times out after approx. 10 seconds.
- Each higher setting allows for more radio volume compensation at higher vehicle speeds.

Radio

Switch on the Infotainment system

- ☞ Press the **🎵 15** knob.
- ✓ The Infotainment system switches on.
- ✓ The most recent audio source plays.

Radio mode

If you wish to listen to the radio while a CD is playing, proceed as follows:

- ☞ Press the **BAND 18** button.
- ✓ The station most recently selected is displayed.
- ✓ The station recently selected plays.
- The CD remains in the CD slot, ready for future listening.

Select waveband



- ✓ The radio is on.
- ☞ Press the **BAND 18** button.
- ✓ The radio switches between the AM and FM wavebands.
- ✓ The current waveband and the station to which the radio was tuned most recently are displayed.
- ✓ The station recently selected plays.
- Waveband selection:
 - AM = Amplitude Modulation (MW),
 - FM = Frequency Modulation.

Station search

Different types of search are available:


Manual station search

Stations for which the frequencies are known can be set as follows;

 Turn the  tune knob; clockwise to search forwards or anticlockwise to search backwards, until the frequency of the required station is reached.


- ✓ The station selected is displayed.
- ✓ The selected station plays.

Automatic station search

 Press the **SEEK ▷ 16** or **SEEK ◁ 17** button.

- ✓ Radio goes to next or previous station.

Seek and scan

 Press and hold the **SEEK ▷ 16** or **SEEK ◁ 17** button for a few seconds.

- ✓ A beep sounds and the radio goes to the next or previous station, plays for a few seconds, then goes to the following station in the respective direction.

 Press the **SEEK ▷ 16** or **SEEK ◁ 17** button again to stop the seek and scan.

- ✓ The current station is displayed.
- ✓ The current station plays.
- The radio only seeks and scans stations with a strong signal within the selected waveband.

Radio Data System (RDS)

RDS is a service provided by the radio broadcasters which makes it much easier to find an FM station and helps to ensure reception is free from interference.

- RDS is only possible on the FM waveband with FM stations that broadcast RDS information.
- When the radio is tuned to an FM-RDS station, the station name or call letters appear on the display.
- RDS relies upon receiving specific information from FM-RDS stations and only works when the information is available.
- In extremely rare cases, a radio station may broadcast incorrect information that causes radio features to work incorrectly. Contact the radio station in question for assistance.

Displaying additional RDS text information

A choice of additional text information related to the current FM-RDS station can be displayed, e.g. channel, song and artist.

To display additional text information, proceed as follows;

- 👉 Press the **i** **3** information button.
- ✓ Additional text information labels appear on the display.
- 👉 Press the **i** **3** information button continuously to highlight the desired label.
- or -
- 👉 Press the appropriate button **6** located below the label that you wish to select.
- ✓ The text information related to the selected label appears on the display.
- If additional text information is not available, "No Info" appears on the display.

Station memory

The radio has a total of 36 station memory locations for any combination of radio stations on both wavebands (FM, AM).

- The station memory locations are selected via the appropriate buttons **6** located below the radio station frequency labels that appear on the display.

Storing favourite radio stations

Six favourite stations are available on each of six separate pages of favourites. Each page can contain any combination of FM or AM radio stations.

By pressing the **FAV** **2** (favourites) button continuously, each of the six separate pages of favourites can be viewed and new stations stored on any of the 36 memory locations.

To store a favourite radio station, proceed as follows;

- 👉 Select waveband and station.
- 👉 Press the **FAV** **2** (favourites) button until the page where you wish to store the selected station is displayed.
- ✓ Six radio station frequency labels appear on the display.
- 👉 Press and hold the appropriate button **6** located below the label on which the selected station is to be stored.
- ✓ A beep sounds and the selected station appears on the display.
- ✓ The selected station plays.
- Repeat the above steps for as many favourite stations as you wish to store, up to a maximum of 36 memory locations.

Changing number of favourites pages

The number of favourites pages can be set up using the **MENU** 4 button, up to a maximum of six separate pages of favourites.

To change the number of favourites pages, proceed as follows;

- 👉 Press the **MENU** 4 button until the radio set-up menu appears.
- ✓ The FAV 1, FAV 2, FAV 3, FAV 4, FAV 5 and FAV 6 labels appear on the display.
- 👉 Press the appropriate button 6 located below the label that you wish to select.
- ✓ The selection is applied.
- Choosing the FAV 6 label will allow up to a maximum of 36 station memory locations to be stored.

👉 Press the **FAV** 2 (favourites) button to return to the original main radio display, showing the radio station frequency labels.

- ✓ Six radio station frequency labels appear on the display.
- Alternatively, allow the screen to time out and the selection made will be applied.
- The process for storing favourite stations for the chosen number of favourites pages can be begun. See "Storing favourite radio stations".

Tuning into a stored radio station

To select a stored favourite radio station, proceed as follows;

- 👉 Press the **FAV** 2 (favourites) button until the page where the favourite radio station frequency label you wish to select appears on the display.
- ✓ Six radio station frequency labels appear on the display.
- 👉 Press the appropriate button 6 located below the label you wish to select.
- ✓ The station selected is displayed.
- ✓ The selected station plays.

Radio messages

The following messages may appear on the display if a problem occurs and the radio does not operate correctly:

- Calibration Error,
- Locked.

Calibration error

The Infotainment system has been calibrated during vehicle production. If this message appears on the display, the system has not been calibrated correctly and must be returned to your retailer for service. We recommend that you consult an Opel Service Partner.

Locked

If this message appears on the display, the electronic theft-deterrent feature has locked up the radio. Take the vehicle to your retailer for service. We recommend that you consult an Opel Service Partner.

CD/MP3 player

This device plays standard commercial CDs with a diameter of 12 cm. You can also play CDs with a diameter of 8 cm with an adapter.


- ⚠ Contoured CDs (Shape CDs) are not suitable for playing.
- ⚠ Do not insert DVDs into the CD drive.
- ⚠ Do not add labels to a disc, as it could get stuck in the player. If a CD is recorded on a personal computer (PC), only label the disc on the top side using a marker pen.
- ⚠ Do not attempt to play scratched or damaged CDs. Only use CDs in good condition, without a label, loading them one CD at a time.
- ⚠ No liability is accepted for damage to the CD drive caused by the use of unsuitable CDs or from attempting to insert more than one CD into the slot at a time.

- Audio CDs are being manufactured with mechanisms to protect them from unauthorised reproduction. However, these measures do not comply with the audio CD specification (Red Book) according to which all appliances for playing audio CDs have been and are being developed. Your Infotainment system can play back CDs with the types of copy protection known at the time the player is sold. However, this is not a guarantee that it will be able to play back CDs with new variants of the copy protection mechanisms in the future.


You can also play CD-Rs and CD-RWs with MP3 music files and uncompressed CD audio files (with ".CDA" file extension) on the Infotainment system.

- While playing a CD-R or CD-RW, the sound quality may be reduced due to disc quality, the method of recording, the quality of the music that has been recorded, and the way the disc has been handled. There may be an increase in skipping, difficulty in finding tracks, and/or difficulty in loading and ejecting. If these problems occur, check the bottom surface of the disc. If the surface of the disc is damaged, e.g. cracked, broken, or scratched, the disc will not play properly.

Switch on the Infotainment system

- 🔊 Press the  knob.
- ✓ The Infotainment system switches on.
- ✓ The most recent audio source plays.

Playing a CD (single-CD player)

- 🔊 Insert the CD (label side up) part of the way into the CD slot .
- ✓ The device pulls the CD in automatically.
- The movement of the CD must not be hindered or aided.
- ✓ The "CD" symbol appears on the display.
- ✓ As soon as the first track starts to play, the track number appears on the display.

Playing a CD (six-disc CD player ✱)

Inserting one CD

To insert one CD into the six-disc CD player, proceed as follows;

- 👉 Press and release the **LOAD 1** button.
 - ✓ A message appears after a few seconds asking you to insert the disc.
- 👉 Insert the CD (label side up) part of the way into the CD slot **19**.
 - ✓ The device pulls the CD in automatically.
 - The movement of the CD must not be hindered or aided.
 - ✓ The “CD” symbol appears on the display.
 - ✓ As soon as the first track starts to play, the track number appears on the display.
 - If a CD is in the player when the ignition or the Infotainment system is turned off, it remains in the player. When the ignition or the Infotainment system is turned on again, the CD begins playing from where it last stopped, if it was the last selected audio source.

Inserting multiple CDs

To insert multiple CDs into the six-disc CD player, proceed as follows;

- 👉 Press and hold the **LOAD 1** button for approx. two seconds.
 - ✓ A beep sounds and “Load All Discs” appears on the display.
- 👉 Follow the on-screen instructions for inserting multiple discs, inserting the CDs label side up part of the way into the CD slot **19**.
 - ✓ The device pulls the CDs in automatically.
 - The movement of the CD must not be hindered or aided.
- 👉 Press the **LOAD 1** button a gain to cancel loading of more CDs.
 - ✓ The “CD” symbol appears on the display.
 - ✓ As soon as the first track starts to play, the track number appears on the display.
 - If a CD is in the player when the ignition or the Infotainment system is turned off, it remains in the player. When the ignition or the Infotainment system is turned on again, the CD begins playing from where it last stopped, if it was the last selected audio source.

CD mode

If the Infotainment system is in radio mode and you wish to play a CD, proceed as follows;



- ✓ The Infotainment system is in radio mode.
 - ✓ A CD is already inserted in the single-CD or six-disc CD player ✱.
 - 👉 Press the **CD/AUX 11** button.
 - ✓ The “CD” symbol appears on the display.
 - ✓ As soon as the first track starts to play, the track number appears on the display.
 - By pressing the **CD/AUX 11** button again, the Infotainment system searches for an auxiliary input device, such as a portable audio player. See “Using the Auxiliary Input Jack” on page 96.
- To switch back to radio mode while a CD is playing, press the **BAND 18** button.
- The CD remains in the CD slot, ready for future listening.

Track selection



For audio CDs, the track is selected within the CD.

For MP3-CDs, the track is selected within the album selected.

If you wish to select a track while a CD/MP3-CD is playing, proceed as follows:



-  Turn the  **8** tune knob; clockwise to search forwards or anticlockwise to search backwards, until the required track is selected.
- ✓ The track starts to play and the track number appears on the display.

Tracks can also be selected using the **SEEK ▷ 16** and **SEEK ◁ 17** buttons, as follows:

-  Press the **SEEK ▷ 16** button.
 - ✓ The next track begins to play.
 - or -
-  Press the **SEEK ◁ 17** button.
 - ✓ The current track begins from the start, if more than 10 seconds have elapsed.
- If the **SEEK ▷ 16** or **SEEK ◁ 17** button is pressed continuously or pressed multiple times, the player continues moving forwards or backwards through the tracks on the disc.

Fast forward/backwards search

To find a specific section of a track, proceed as follows:

- ✓ You are listening to a track.
-  Press and hold the **FWD 13** or **REV 14** button.
- ✓ Playback is advanced/reversed quickly within the track.
- ✓ The sound is reduced during fast forward/backwards searching.
-  Release the **FWD 13** or **REV 14** button when the desired section has been reached.
- ✓ The track starts to play again at the normal volume when either button has been released.
- ✓ The elapsed track time appears on the display.

MP3-CD playback selecting next/previous folder with MP3-CDs

If your MP3-CD contains several albums, you can select the album you want as follows:

- ✓ You are listening to an MP3-CD.
- ✓ The folder labels with < and > next to a folder icon appear on the display.
- ☞ Press the appropriate button **6** located below the folder label you wish to select.
- ✓ By selecting the < folder label, the Infotainment system goes back to the first track in the previous folder.
- ✓ By selecting the > folder label, the Infotainment system goes to the first track in the next folder.
- ✓ When the first track in the previous/next folder starts to play, and the relevant track information (album name, track name or artist name) appears on the display.
- All the folders which do not contain MP3 files are automatically skipped.

Switching between compressed and uncompressed audio files with MP3-CDs*

The Infotainment system can play discs containing both uncompressed CD audio files (with “.CDA” file extension) and compressed audio files (MP3 files).


By default, the system reads and plays only the uncompressed audio files and ignores the MP3 files.

To switch between uncompressed and compressed files, proceed as follows;

- ☞ Press the **CAT 9** category button.
- ✓ The Infotainment system will only read and play the previously ignored files.

MP3-CD music navigator

Use the music navigator feature to play MP3 files on the disc in order by artist or by album, as follows;

- ✓ You are listening to an MP3-CD.
- ☞ Press the appropriate button **6** located below the music navigator label  on the display.
- ✓ The Infotainment system scans the disc to sort the files by artist and album ID3 tag information.
- It can take several minutes to scan the disc depending on the number of MP3 files recorded on the disc. The radio may begin to play while the Infotainment system is scanning the disc in the background.
- ✓ When the scan is finished, the disc begins playing again and the system defaults to playing MP3 files in order by artist.
- ✓ The current artist playing is shown on the second line of the display between the arrows.
- ✓ Once all songs by that artist are played, the Infotainment system moves to the next artist in alphabetical order on the disc and begins playing MP3 files by that artist.

If you wish to listen to MP3 files by another artist, proceed as follows;

- ✎ Press the appropriate button **6** located below either arrow label on the display.
- ✓ The disc goes to the next/previous artist in alphabetical order.
- ✎ Press the appropriate button **6** located below either arrow button until the desired artist appears on the display.
- ✓ Files by the selected artist are played.

To change from playback by artist to playback by album, proceed as follows;

- ✎ Press the appropriate button **6** located below the 'Sort By' label on the display.
- ✎ From the sort screen, press the appropriate button **6** located below the album label on the display.
- ✎ Press the appropriate button **6** located below the 'Back' label to return to the main music navigator screen.
- ✓ The album name appears on the display - on the second line between the arrows - and tracks from the current album begin to play.
- Once all tracks from that album are played, the Infotainment system moves to the next album in alphabetical order on the disc and begins playing MP3 files from that album.

To exit music navigator mode, press the appropriate button **6** located below the 'Back' label to return to normal MP3 playback.

Random mode

If you use this function, the CD/MP3 player will play back the tracks of the current disc in random order.

Single CD

To play the tracks from a single CD in random order, proceed as follows;

- ✎ Press the **CD/AUX 11** button to enter CD mode.
- or -
- ✎ Insert the CD (label side up) part of the way into the CD slot **19**.
- ✓ The device pulls the CDs in automatically.
- The movement of the CD must not be hindered or aided.
- ✓ An 'RDM' label appears on the display.
- ✎ Press the appropriate button **6** located below the RDM label until "Random Current Disc" appears on the display.
- ✓ The tracks of the current disc are played in random, rather than sequential order.
- Switch off random play by pressing the appropriate button **6** located below the RDM label again.

Multiple CDs *

To play the tracks from all discs loaded in the six-disc CD player in random order, proceed as follows;

- ☞ Press the **CD/AUX 11** button to enter CD mode - or - press and hold the **LOAD 1** button for approx. two seconds.
- ✓ A beep sounds and "Load All Discs" appears on the display.
- ☞ Follow the on-screen instructions for inserting multiple discs, inserting the CDs label side up part of the way into the CD slot **19**.
- ✓ The device pulls the CDs in automatically.
- The movement of the CD must not be hindered or aided.
- ☞ Press the **LOAD 1** button again to cancel loading of more CDs.
- ✓ An 'RDM' label appears on the display.
- ☞ Press the appropriate button **6** located below the RDM label until "Randomize All Discs" appears on the display.
- ✓ The tracks of all discs loaded in the six-disc CD player are played in random, rather than sequential order.
- Switch off random play by pressing the appropriate button **6** located below the RDM label again.

Changing the display type displaying additional MP3-CD text information

Depending on the kind of disc (MP3-CD with or without ID3 tags), a choice of additional text information related to the current MP3-CD can be displayed, e.g. Song, Artist and CAT (category).

To display additional text information, proceed as follows;

- ☞ Press the **i 3** information button.
 - ✓ Additional text information labels appear on the display.
 - ☞ Press the **i 3** information button continuously to highlight the desired label.
 - or -
 - ☞ Press the appropriate button **6** located below the label that you wish to select.
 - ✓ The text information related to the selected label appears on the display.
 - If additional text information is not available, "No Info" appears on the display.
- See "Switching between compressed and uncompressed audio files" on page 93 for further information on categories.

Ejecting CDs

To eject the CD that is currently playing, proceed as follows;

- ☞ Press the **EJECT 10** button.
- ✓ A beep sounds and "Ejecting Disc" appears on the display.
- ✓ Once the disc is ejected, "Remove Disc" appears on the display.
- ☞ Remove the disc from the player.
- If the disc is not removed, after several seconds it is automatically retracted and begins to play.
- or -
- ☞ With the six-disc CD player *, press and hold the **EJECT 10** button for two seconds.
- ✓ All discs are ejected.
- ☞ Remove the discs from the six-disc CD player.
- If the discs are not removed, after several seconds they are automatically retracted.

CD messages

The message 'CHECK DISC' appears on the display if a problem occurs and the CD player does not operate correctly.

If this message appears or if the CD is ejected automatically, it could be for one of the following reasons:


- The CD is dirty, scratched, wet, or upside down.
- The air is very humid.
If so, wait approx. one hour and try again.
- There may have been a problem while burning the CD.
- The label may be caught in the CD player.
- It is very hot.
When the temperature returns to normal, the CD should play.
- You are driving on a very rough road.
When the road surface becomes smoother, the CD should play.


If the CD is not playing correctly, for any other reason, try a known good CD.


If any error occurs repeatedly or if an error cannot be corrected, we recommend that you consult an Opel Service Partner.


If the radio displays an error message, write it down and provide it to your retailer when reporting the problem.

Using the auxiliary input jack





Your Infotainment system has an auxiliary input jack  located on the lower right side of the Entertainment Head Unit (EHU).


This is not an audio output;
Do not plug headphones into the auxiliary input jack .


You can however, connect an external audio device such as a laptop computer*, MP3 player *, CD changer*, or cassette player *, to the auxiliary input jack  for use as another audio source.

To use a portable audio player, connect a 3.5 mm phone plug to the auxiliary input jack .

When a device is connected, to begin playing audio from the device through the vehicle's speakers, proceed as follows;

- ✓ You are listening to a CD/MP3.
-  Press the **CD/AUX**  button.
- ✓ Audio from the external audio device connected starts to play.
- If a portable audio player is not connected, "No Input Device Found" appears on the display.
- If the volume of the connected portable audio player does not go as loud or soft as you wish using the   knob (see page 81), you may need to make additional volume adjustments on the portable audio player itself.

To switch back to the CD/MP3 you were playing, press the **CD/AUX**  button again.



To switch to radio mode while a portable audio device is playing, press the **BAND**  button.

- The portable audio device continues to play, so you may wish to stop it or turn it off.

Troubleshooting

If your Infotainment system does not function as you would expect, please read these Operating Instructions carefully and go through the following checklist before contacting Customer Services.

If you cannot find a solution to the problem, we recommend that you consult an Opel Service Partner.

Error message / symptom	Possible cause / remedy
General	
Display is dark.	Vehicle's battery is weak (if operated without the engine running); See page 159.
Display is difficult to read.	Instrument illumination is set incorrectly; See page 76.
Infotainment system cannot be switched on either with the  knob or with the ignition key.	Infotainment system fuse or vehicle fusebox is defective.
Incorrect time on the display	Set time as specified on page 82.
Audio	
Audio playback volume constantly decreases and cannot be adjusted.	Infotainment system is overheating. Internal temperature regulator is acting to protect the Infotainment system. Recommendation: switch the Infotainment system off.
Stored station cannot be selected with the appropriate button  .	No reception for station currently.
Stored station not stored with station name.	Broadcasting organisation occasionally sends additional information. Try to store it again when the station name appears on the display. Poor reception when storing (frequency is displayed). Broadcasting organisation is not transmitting RDS information (frequency is displayed).
"CHECK DISC" appears on the display.	After loading a CD: CD incorrectly inserted. CD label may be caught in the player. Incompatible audio CD inserted (DVD etc.). CD scratched or otherwise damaged. Insert an undamaged, compatible CD with the printed side upwards. During CD playback: Temperature of Infotainment system too high. Wait until the temperature of the unit has returned to normal. Air is too humid. Wait for conditions to improve. Road surface is uneven. When road surface becomes smoother, CD should play again.
"Calibration Error" appears on the display	Infotainment system has not been calibrated correctly. Return vehicle to your retailer for service.
"Locked" appears on the display.	Electronic theft-deterrent feature has locked up the Infotainment system. Return vehicle to your retailer for service.
An ejected CD that has not been accepted is retracted again by the unit when the ignition/unit is switched off	No error. Remove the CD before switching off the ignition/ Infotainment system.

General advice

During normal radio reception, you may experience frequency interference and static if items such as mobile phone chargers, vehicle convenience accessories, and external electronic devices are plugged into the accessory power socket.

If there is interference or static, unplug the item from the accessory power outlet.

FM reception

Despite a high degree of technical perfection, reception in vehicle radio sets is different from that in home radio sets and some interference may occur, even with FM-RDS stations.

Tall buildings or hills can interfere with FM signals, causing sound to fade in and out.

FM stereo will give the best sound, but FM signals will reach only a approx. 16 to 65 km (10 to 40 miles).

AM reception

The range for most AM stations is greater than for FM, especially at night. The longer range can cause station frequencies to interfere with each other. For better radio reception, most AM radio stations will boost the power levels during the day, and then reduce these levels during the night.

Static can also occur when events such as storms interfere with radio reception. When this happens, try reducing the treble on your Infotainment system.

Handling CDs

Handle CDs carefully. Avoid leaving fingerprints on the CDs when changing them. Replace CDs in their cases immediately after removing them, to stop them from getting damaged, dusty and dirty.

Dirt and liquids on CDs may make the Infotainment system's CD player lens dirty and result in malfunctions.

Do not expose CDs to heat or direct sunlight.

The CD player scans the bottom surface of the disc. If the surface of a CD is damaged, e.g. cracked, broken or scratched, the CD will not play properly or not at all.

If the surface of a CD is soiled, take a soft, lint-free cloth or dampen a clean, soft cloth in a mild, neutral detergent solution mixed with water, and clean it. Make sure the wiping process starts from the centre, going out towards the edge of the disc.

Do not touch the bottom side of a CD while handling it; this could damage the surface. Pick up CDs by grasping the outer edges or the edge of the hole and the outer edge.

Care and maintenance

Your Infotainment system has been developed and manufactured with great care and it should also be treated with care.

Observing the recommendations listed below will prevent your warranty from expiring prematurely and ensure that you will be able to enjoy your product for many years.

Note the following when using your Infotainment system:

- Never try to open the Infotainment system. Incorrect handling can damage the Infotainment system.
- Do not use aggressive chemicals, cleaning liquids or agents to clean the Infotainment system. Use a soft cloth moistened with a mild soap solution to clean your Infotainment system.
- Do not attempt to clean the CD player using CD lens cleaners. The lens of the CD optics may become contaminated with lubricants from the CD lens cleaner.

- Do not paint or colour the Infotainment system. Paint can make moving parts sticky and stop them functioning correctly.
- Do not store combustible liquids, gases or explosives in the same room as the Infotainment system, its parts or accessories.
- The Infotainment system should only be serviced by experts. Incorrect installation or servicing of the Infotainment system can have dangerous consequences and result in the warranty becoming void.

Fixed mast antenna

Check occasionally to make sure the mast is still fixed tightly to the vehicle. If tightening is required, tighten by hand.

Glossary

Automatic station search

Station search via the seek buttons.

Balance

Volume distribution between the left and right speakers.

Bass

Low-frequency sounds.

Equalizer (EQ)

Preset equalization settings for bass, midrange and treble tones.

Fade

Volume distribution between the front and rear speakers.

ID3 tag

Code in an MP3 file which can include the following data:

- Track title,
- Artist name,
- Track number and playing time,
- Album name.

This information can be stored in the MP3 file with a PC.

Manual station search

Station search via the tune knob.

MP3

CD audio data compression method developed by the Fraunhofer Institute.

Compression allows reduction of the data to a small percentage of the original volume without audible losses in sound quality.

If low bit rates are used to convert the audio data into MP3, smaller files are possible but sound quality is reduced.

Music navigator

To play MP3 files on a disc in order by artist or by album.

Random mode

CD/MP3 tracks on a single CD or from multiple CDs in the six-disc CD player* are played in a random order.

RDS (Radio Data System)

RDS is a service provided by the radio broadcasters which makes it much easier to find an FM station and helps to ensure reception is free of interference.

RDS stations are identified by the name of the station on the display instead of the frequency.

RDS stations transmit information which is automatically evaluated by the RDS radio if RDS is activated.

Speed Compensated Volume (SCV)

To compensate for ambient and rolling noise, the Infotainment system volume adjusts to the speed of the vehicle.

Seek and scan

Search and brief playback of stations with a strong signal via the seek buttons.

Treble

High-frequency sounds.

Radio reception

Car radio reception differs from domestic radio reception:

As the vehicle antenna is relatively near the ground, the broadcasting companies cannot guarantee the same quality of reception as obtained with a domestic radio using an overhead antenna.

- Changes in distance from the transmitter,
 - Multi-path reception due to reflection and
 - Shadowing
- may cause static, noise, distortion or loss of reception altogether.

Mobile telephones and radio equipment (CB) *

The Opel installation instructions and the operating guidelines provided by the telephone manufacturer must be observed when fitting and operating a mobile telephone. Failure to do so could invalidate the vehicle's operating permit (EU Directive 95/54/EG).

Prerequisites for fault-free operation:

- Professionally installed exterior antenna to obtain the maximum range possible,
- Maximum transmission power 10 Watts,
- Installation of the telephone in a suitable spot (see information on page 49).

Obtain advice on predetermined installation locations for the external antenna and equipment holder and ways of using devices with transmission power of more than 10 Watts.

- Operation of a handsfree attachment with no outside antenna, using the mobile telephone standards GSM 900/1800/1900 and UMTS, may take place only if the maximum transmission power of the mobile telephone does not exceed 2 W, in the case of GSM 900, and otherwise 1 W. The operating instructions of the manufacturer of the telephone and handsfree attachment must be noted in all cases.

For reasons of safety, we recommend that you do not use the phone while driving. Even use of a hands-free set can be a distraction while driving. Be sure to observe any country-specific regulations.

Warning

When used in the vehicle interior, mobile telephones and radio equipment (CB) with integrated antenna may cause malfunctions in the vehicle electronics.

Mobile telephones and radio equipment (CB) should only be used with an antenna fitted on the vehicle exterior.

Climate control

Heating, ventilation and air conditioning system	102
Air vents	102
Heated rear window	103
Heating and ventilation system	104
Air conditioning system	107
Air intake	109
Note	109
Maintenance	109



Heating, ventilation and air conditioning system

Ventilation, heating and cooling are combined into one unit that is designed to provide comfort regardless of the season, weather or outside temperature.

When cooling is activated, the air is cooled and dried.



The heating unit heats the air as required in all operating modes depending on the position of the temperature rotary switch. The air supply can be adjusted to suit requirements by means of the fan.

Air conditioning system – see page 107.



Air vents

Pleasant ventilation of the interior is controlled by the position of the temperature rotary switch.

To increase the air supply, switch the fan to a higher setting and set the air distribution rotary switch to  or .

Centre air vents

Direct the flow of air by tilting and swivelling the slats.



S 14051

Side air vents


Open vent: rotate vertical adjuster wheel upwards.

Direct the flow of air by tilting and swivelling the slats.

Close vent: rotate vertical adjuster wheel downwards.


Additional air vents

Below the windscreen and door windows and in the foot well.



S 13944


Heated rear window

With the ignition on, the rear window heating is switched on by pressing button .

Control indicator in button illuminates: rear window heating.

Control indicator does not illuminate: rear window heating is switched off.

Heating works with the engine running and is switched off automatically after approx. 15 minutes.

If button  is pressed again after switching off automatically, rear window heating will continue for approx. 8 minutes and switch off again.

Turn rear window heating off as soon as rear vision is clear.

Warning

Do not turn on rear window heating when the soft top has been stowed in the luggage compartment.



S 14053

Heating and ventilation system

Left-hand rotary switch: Temperature

Turn right = Warm
Turn left = Cold



S 14054

Centre rotary switch: air flow

Four fan speeds:

0 = Off
4 = Maximum air flow

The rate of air flow is determined by the fan. The fan should therefore also be switched on during a journey.



S 14052

Right-hand rotary switch: Air distribution




- To head area via adjustable centre and side air vents
- To head area via adjustable centre and side air vents and to foot well
- To foot well
- To the windscreen, door windows and to foot well
- To the windscreen and door windows

Intermediate settings are possible.

Open the side air vents when the rotary switch is set to or .




Ventilation

- For maximum ventilation in the head area: move air distribution rotary switch to , open side air vents and move slats of centre air vents to an upright position – see page 102.
- Set the temperature to the desired setting.
- Set the fan to the desired setting.
- For ventilation to foot well: set air distribution rotary switch to .
- For simultaneous ventilation to the head area and the foot well: set air distribution rotary switch to .



Heating

The amount of heat is dependent on the coolant temperature and is thus not fully attained until the engine is warm.

For rapid warming of the passenger compartment:


- Set air distribution rotary switch to the desired position, preferably position  - see page 104.
- Turn the temperature rotary switch clockwise as far as it will go.
- Select fan setting **3**.
- Open side air vents.

The comfort and general well-being of the vehicle occupants are to a large extent dependent on a suitable ventilation and heating setting.

On order to achieve temperature stratification with the pleasant effect of "cool head and warm feet", turn the air distribution rotary switch to  or  and move the temperature rotary switch to any position (in the mid-range with temperature stratification).



Heating the foot well

- Set air distribution rotary switch to .
- Temperature rotary switch in right zone.
- Switch on fan.








Demisting and defrosting windows

⚠ Warning

Failure to follow the instructions can lead to window fogging or icing and therefore accidents due to lack of visibility.

To clear window fogging or icing, e.g. in damp weather, because of wet clothing or due to low outside temperatures:

- Cooling  on - see page 107.
- Move air distribution rotary switch to  or .
- Turn the temperature rotary switch clockwise as far as it will go (warm).

- Set fan to **3** or **4**.
 - Switch on heated rear window .
 - Open side air vents as required and direct them towards door windows.
- For simultaneous warming of the foot well, set a air distribution rotary switch to .

Air conditioning system

As well as the effect of the heating and cooling system, the air conditioning system also cools and dries the inflowing air.

If no cooling or drying is required, switch the cooling system off to save fuel.

At low outside temperatures, the cooling unit switches off automatically.



Cooling ☼

Operate only with the engine running and the fan on:

On = Press ☼

Off = Press ☼ again

Control indicator in button.

If the fan is off, the control indicator will flash three times then go out. Air conditioning is not available with the fan off.






Air re-circulation system ↻



The air re-circulation button ↻ is used to set the ventilation system to re-circulation mode (control indicator illuminates in button).

If fumes or unpleasant odours penetrate the passenger compartment from outside, temporarily switch on air re-circulation system.

To increase the cooling power at high outside temperatures, temporarily switch on air re-circulation system.





The air re-circulation system minimises the entry of outside air. The humidity increases, and the windows can mist up. The quality of the passenger compartment air deteriorates which may cause the vehicle occupants to feel drowsy.

Air distribution to ,  or : air re-circulation system is automatically switched off, to speed up window demisting and avoid fogging. The control indicator in the button goes out.

If air distribution rotary switch is turned back to positions  or , the air re-circulation system is switched back on and the control indicator illuminates in the button.



Convenience settings




- Set cooling  as desired.
- Air re-circulation system  off.
- Set air distribution rotary switch to  or .
- Set temperature rotary switch to desired position.
- Switch on fan at desired speed.
- Open or align air vents as required.


Temperature rotary switch in centre of adjustment range: warmer air will flow into the foot well and cooler air into the upper zone, with warmer air coming from the side air vents and cooler air from the centre air vents.



Maximum cooling

Briefly open the window so that the heated air can dissipate quickly.

- Cooling  on.
- Activate air re-circulation system .
- Set air distribution rotary switch to .
- Turn the temperature rotary switch anti-clockwise as far as it will go (cold).
- Set fan to 4.
- Open side air vents.



Air intake

The air intakes in front of the windscreen in the engine compartment must be kept clear to allow air intake. Remove any leaves, dirt or snow.

Note

If the windscreen mists up during damp weather, temporarily set the system as described under "Demisting and defrosting the windows" - see page 106.

Cooling functions most efficiently when the windows are closed. If the passenger compartment has heated up considerably after a long period in direct sunlight, briefly open the windows so that the hot air can escape quickly.

When cooling (air conditioning compressor) is switched on condensation forms, which is expelled from the underside of the vehicle.

At least one air vent must be open while cooling (air conditioning compressor) is on, in order to prevent the evaporator from icing up due to lack of air movement.

At low outside temperatures the cooling unit switches off automatically.

Maintenance

In order to ensure continuously efficient performance, the air conditioning compressor must be operated for a few minutes once a month, irrespective of the weather and time of year. Air conditioning compressor operation is not possible when outside temperatures are low.

In the event of a fault, consult a workshop.

Driving and operation

Driving hints	110
Saving fuel, protecting the environment	112
Fuels, refuelling	114
Catalytic converter, exhaust gases...	116
Drive control systems	118
Brake system	122
ABS (®)	124
Wheels, tyres	125

Driving hints

The first 1000 km (600 miles)

Drive your vehicle at various speeds.

Do not use full throttle. Never allow the engine to labour at low revs.

Make good use of all gears. Depress the accelerator pedal a maximum of around three quarters of the available pedal travel in all gears.

Do not drive faster than three quarters of maximum speed.

Do not brake unnecessarily hard for the first 200 km (120 miles).

Never coast with engine not running

Many units will not function in this situation (e.g. brake servo unit, power steering). Driving in this manner is a danger to yourself and others.

Brake servo unit

When the engine is not running, the brake servo unit is no longer effective once the brake pedal has been depressed once or twice. Braking effect is not reduced, but significantly greater force is required for braking.

Power steering

If the power steering fails or when being towed with the engine switched off, the vehicle can still be steered, but considerably more force is required.

Driving in mountainous terrain

The cooling fan is electrically operated. Its cooling power is therefore independent of the engine speed.

Since a considerable amount of heat is generated at high engine speeds and less at lower speeds, do not shift down when climbing hills while the vehicle is still coping with the gradient in the higher gear.

Driving with a roof load

Not permitted.

Switching off the engine

When you switch off the engine, fans in the engine compartment may continue running for a while, to cool the engine.

If the engine temperature is very high, e.g. after driving in mountainous terrain, allow the engine to idle for approx. 2 minutes, in order to prevent heat accumulation.

Vehicles with turbocharged engine:

After running at high engine speeds or high engine loads, operate the engine briefly at a low load or run in neutral for approx. 30 seconds before switching off, in order to protect the turbocharger.

Save energy – more kilometres/miles

Please observe the running-in hints on the previous page and the tips for saving energy on the following pages.

Good, technically correct and economical driving ensures maximum durability and performance for your vehicle.

Overrun

The fuel supply is automatically shut off during overrun, e.g. when the vehicle is being driven down long gradients or when braking. To enable the overrun cut-off to take effect, do not accelerate during overrun and do not declutch. To prevent damage to the catalytic converter, overrun cut-off is temporarily deactivated when the catalytic converter temperature is high.

Vehicles with turbocharged engine:

Flow-generated noises may be audible if the accelerator is released quickly, on account of air flow in the turbocharger.

Engine speed

Drive in a low engine speed range for each gear as much as possible.

Warming up

Run engine warm, do not warm up in idle. Do not apply full throttle until the operating temperature has been reached.

Correct gear selection

Transmission in neutral and without revving in the lower gears. Stop-and-go traffic and driving at a speed too high for the selected gear increases wear and fuel consumption.

Change down!

When decreasing speed, shift down into the next lowest gear. Do not slip the clutch with a high-revving engine. This is especially important when hill climbing.

Clutch operation

Always depress the clutch pedal hard to the floor to prevent shifting difficulties and transmission damage.

When driving, do not use the pedal as a foot rest; this will cause substantial clutch wear.

Cooling fan

The cooling fan is controlled via a thermostat and therefore only runs if necessary.

Pedals

Do not place any objects in the foot well which could slip under the pedals and inhibit the pedal travel.

To ensure the pedal travel is uninhibited, there must be no unrestrained mats in the area of the pedals.

Battery care

When driving slowly or when the vehicle is stationary, e.g. in slow urban traffic, stop-and-go traffic or traffic jams, turn off all unnecessary electrical loads where possible (e.g. heated rear window).

Saving fuel, protecting the environment

Trend-setting technology

When developing and manufacturing your vehicle, Opel used environment-friendly and primarily recyclable materials. The production methods used to make your vehicle are likewise environmentally-compatible.

Recycling of production wastes keeps the circulation of material closed. Reduction of energy and water requirements also helps to conserve natural resources.

The advanced design makes it easier to dismantle the vehicle at the end of its service life and separate materials for recycling.

Materials such as asbestos and cadmium are not used. The refrigerant in the air conditioning system is CFC-free.

New painting techniques employ water as a solvent.

End-of-life vehicle recovery

Information on end-of-life vehicle recovery centres and the recycling of end-of-life vehicles is available at www.opel.com.

Drive in an energy and environment-conscious way

- High fuel consumption, noise levels and exhaust emissions are often caused by a driving style that is not energy and environment-conscious.
- You should therefore drive with energy in mind: "more kilometres/miles with less fuel".

Reduce the noise level and exhaust emissions by adopting an environment-conscious driving style. This is extremely worthwhile and improves the quality of life.

Fuel consumption depends to a great extent on your own personal driving style. The following hints are intended to help you consume fuel at a rate that is as close as possible to the specified levels – see page 177.

Check your vehicle's fuel consumption every time you refuel. This facilitates early detection of any irregularities causing increased fuel consumption.

Warming up

- Full throttle and warming up at idle speed increase wear, fuel consumption, exhaust emissions, the amount of pollutant in the exhaust and the amount of noise.
- Drive off as soon as possible after starting.

Uniform speed

- Hectic driving significantly increases fuel consumption, the exhaust emissions, the proportion of pollutant in the exhaust gases and the noise level.
- Do not accelerate and brake unnecessarily. Drive at uniform speed.

Avoid frequent starting-off and stopping, e.g. at traffic lights, in short distance traffic and in queues of traffic, by means of clever planning. Select roads with good traffic flow.

Idling

- The engine also consumes fuel when idling.
- If you have to wait for more than 1 minute, it is worthwhile switching off the engine. Five minutes of idling corresponds to approx. 1 kilometre (0.6 miles) of driving.

Overrun

- The fuel supply is automatically shut off during overrun, e.g. when the vehicle is being driven down long gradients or when braking – see page 111.
- To enable the overrun cut-off to take effect and save fuel, during overrun do not accelerate and do not declutch.

Correct gear selection

- High revs increase engine wear and fuel consumption.
- Do not race your engine. Avoid driving at high engine speeds.

Driving with an eye on the tachometer saves fuel. If possible, drive at low revs in each gear and at a constant speed. Drive in top gear as much as possible, shift up as soon as possible and do not shift down until the engine is no longer running truly.

High speed

- The faster the speed, the higher the fuel consumption and the noise level. Driving at full throttle uses up a great deal of fuel and generates excessive noise and high emission levels.
- Slightly releasing the accelerator pedal results in distinct fuel savings with no major loss of speed.

Drive at no more than around three quarters of maximum speed and you will use up to 50% less fuel, without losing a great deal of time.

Tyre pressure

- Inadequate tyre pressure, leading to higher road resistance, costs money in two ways: more fuel and increased tyre wear.
- Regular checks (every 14 days) pay off.

Electrical loads

- The power consumption of electrical equipment increases fuel consumption.
- Switch off additional consumers (e.g. air conditioning, heated rear window) when they are no longer required.

Repair and maintenance

- Improper repairs or adjustment and maintenance work can increase fuel consumption. Do not carry out work on the engine yourself.

You may infringe environmental laws out of ignorance by not disposing of materials properly.

Appropriate parts might not be recycled.

Contact with some of the materials involved may pose a health hazard.

- We recommend that repair and maintenance be entrusted to your Opel Service Partner.

Extreme driving conditions

- Driving up steep gradients, cornering, driving on poor roads and winter driving all increase fuel consumption. Fuel consumption increases dramatically in urban traffic and at winter temperatures, especially on short trips when the engine operating temperature is not reached.
- Follow the hints given above to keep consumption to a minimum under such conditions.

Fuels, refuelling

Fuel consumption

Fuel consumption is determined under specific driving conditions – see page 177.

Special equipment increases the weight of the vehicle. As a result, they can increase fuel consumption and reduce the specified maximum speed.

For the first few thousand kilometres/miles, friction between the engine and transmission components is higher. This increases fuel consumption.

Fuel for petrol engines

Normal commercial high-quality fuels with a maximum ethanol content of 5% in accordance with DIN EN 228 are suitable (Catalytic converter - see page 116. Octane numbers - see page 175). The quality thereof has considerable effect on performance, running and service life of the engine. The additives mixed with the fuel are extremely important. For this reason you must only refuel with high-quality fuels containing additives.

Fuels with ethanol content of greater than 5% do not comply with DIN EN 228 and must not be used unless the vehicle has been specifically developed and approved for these fuels.

Fuel with too low an octane number can cause pinking. Opel cannot be held liable for resulting damage.


Petrol with a higher octane number can always be used.

The ignition timing adjusts automatically to the grade of fuel used (octane number) – see page 175.

Use of petrol with an octane rating of 95 or higher will ensure economical driving.

Fuel filler cap

If replacing the fuel filler cap, be sure to use the original fuel filler cap for your model, to ensure full functionality.



S 14086

Refuelling


Warning

Care must be taken when handling fuel.

Before refuelling, switch off the engine and where applicable any auxiliary heating with combustion chambers. Switch off mobile phones.

Warning

Fuel is flammable and explosive. Avoid naked flames or sparks when handling fuel or just in its vicinity. Do not smoke. This also applies where fuel is perceptible only from its characteristic odour. If fuel odours occur in the vehicle itself, have the cause eliminated immediately by a workshop.



S 14087

Fuel filler neck at left rear side of vehicle.

Open the tank flap.

The fuel filler cap is locked and unlocked using the key provided. Turn key in lock cylinder clockwise to unlock cap.

Unscrew the fuel filler cap by turning it anti-clockwise, and remove.

The fuel tank has a limiting system which prevents overfilling of the tank.


Correct filling depends to a large extent on proper operation of the fuel dispensing pump:

1. Fully insert the pump nozzle and switch it on.
2. At automatic switch off, the specified tank capacity is reached. Leave the filler nozzle in place until the flow stops.

Place fuel filler cap in position and turn it clockwise until tight and turn key in lock cylinder anti-clockwise to lock cap.

Close tank flap.

Wipe off any overflowing fuel immediately.



Catalytic converter, exhaust gases

Catalytic converter for petrol engines
Leaded fuel will damage the catalytic converter and parts of the electronic system, thereby rendering them inoperative.

High quality fuels other than those listed on pages 114 and 175 (e.g. LRP¹⁾) could damage the catalytic converter.



Damage to the catalytic converter or the vehicle may result if the following points are not observed:

- Consult a workshop as quickly as possible in the event of misfiring, irregular engine running following a cold start, a significant loss of engine power or other unusual malfunctions which may indicate a fault in the ignition system. If necessary, driving may be continued for a short time at a low speed and with a low engine speed.

Irregular engine running and lack of power when the Electronic Stability Program (ESP) kicks in are for operational reasons and can be ignored – see page 119.

- If unburned fuel enters the catalytic converter, this may result in overheating and irreparable damage to the catalytic converter.

You should therefore avoid unnecessarily long use of the starter when starting-off, running the tank dry (an irregular fuel supply will lead to overheating) and starting the engine by pushing or towing.

- If the emission control indicator  flashes, slow down until the flashing stops and the control indicator is steady. Consult a workshop immediately. Emission control indicator  – see page 117.

¹⁾ LRP = Lead Replacement Petrol.



Controlling exhaust emissions

The combination of design measures – mainly in the area of the fuel injection system and ignition systems, and the catalytic converter – has minimised the proportion of harmful substances in the exhaust gases, such as carbon monoxide (CO), hydrocarbons (CH) and nitrous oxides (NO_x).



Control indicator for exhaust

Illuminates when the ignition is switched on and during the start attempt. Goes out shortly after the engine starts running.

If it illuminates while the engine is running, there is a fault in the emission control system. The permitted emission values may be exceeded. Consult a workshop immediately.

Flashing with the engine running indicates a fault that may damage the catalytic converter. You can continue to drive without causing damage by slowing down until the flashing stops and the control indicator is steady. Consult a workshop immediately.

Exhaust gases

Warning

Engine exhaust gases contain poisonous carbon monoxide, which is colourless and odourless and could be fatal if inhaled.

If exhaust gases penetrate the vehicle interior, open the windows and consult a workshop immediately.

During the first drive, smoke may develop because of wax and oil evaporating on the exhaust system. Park the vehicle in the open for a while after the first drive and avoid inhaling the fumes.

Maintenance

Have all maintenance work carried out at the intervals specified by Opel. We recommend that you entrust this work to your Opel Service Partner, who has proper equipment and trained personnel available. Electronic testing systems permit rapid diagnosis and remedy of faults. This way you can be certain that all components of the vehicle's electrical, injection and ignition systems operate correctly, that your vehicle has a low level of pollutant emission and that the catalytic converter system will have a long service life.

You are thereby making an important contribution towards keeping the air clean and compliance with emissions legislation.

The Service work includes testing and adjusting the fuel injection system and the ignition system. For this reason, have all Service work carried out at the intervals specified by Opel (see chapter "Service, Maintenance" on page 165).


Drive control systems


Electronic Stability Program (ESP), Electronic Stability Control (ESC)

Electronic Stability Control (ESC) is a component part of the Electronic Stability Program (ESP).

ESP improves driving stability when necessary in any driving situation, regardless of the type of road surface or tyre grip. It also prevents the drive wheels from spinning.

The system monitors vehicle movements. As soon as the vehicle starts to swerve (understeers/oversteers) engine output is reduced (the sound of the engine changes) and individual wheels are specifically braked. This considerably improves the driving stability of the vehicle on snow and ice and on wet or slippery road surfaces.

ESP is ready for operation as soon as the ignition is switched on and control indicator  goes out.

The ESP control process is displayed by the flashing of .

The vehicle is now in a critical situation; ESP allows you to keep control of the vehicle and reminds you to match your speed to the road conditions.

Warning

Do not let this special safety feature tempt you into taking risks when driving.

Traffic safety can only be achieved by adopting a responsible driving style.



Control indicator

Illuminates for a few seconds when the ignition is switched on. The system is ready for operation when the control indicator goes out.

Flashing during driving:

This shows the system has come into action. The engine output may be reduced (the sound of the engine changes) and the vehicle may be braked automatically to a small degree.

The driver information centre also shows "ESC ACTIVE" and/or "LOW TRACTION" when the system has come into action. See page 69.

"ESC" appears in some warning messages. ESC is a component part of the Electronic Stability Program (ESP), improving driving stability.

Illuminates while driving:

The system is switched off or a fault is present. Continued driving is possible. The driving stability can however deteriorate depending on road surface conditions.


The driver information centre shows "ESC OFF", "SERVICE ESC" or "SERVICE TRACTION" if a system fault occurs. See pages 69, 70.


The driver information centre shows "TRACTION OFF" and/or "ESC OFF" if the system has been switched off. See pages 69, 70.

Reactivate ESP or have the cause of the fault remedied by a workshop. The system's integrated self-diagnostics allow faults to be quickly remedied.




Switching off:

The traction control aspect of ESP can be switched off by pressing button  once. ESP can also be switched off altogether by pressing and holding the button for more than 10 seconds.

When traction control and/or ESP have been deactivated, control indicator  illuminates in the instrument panel.

The driver information centre shows "TRACTION OFF" if the button is pressed once, and also "ESC OFF" if the system has been switched off altogether. See pages 69, 70.

Traction control and ESP are switched on again by pressing button  again (control indicator goes out immediately) or the next time the ignition is switched on.

Warning

When the traction control aspect of ESP is switched off, it is possible to lose traction.

Do not attempt to shift gears while the rear wheels are spinning, to prevent damage to the transmission. Failure to follow these instructions can cause injuries or put lives at risk.




Competitive mode

Competitive mode allows the driver to have full control of the rear wheels while ESP continues to assist in maintaining the driving stability of the vehicle by braking the front wheels as necessary.

To activate:


Press button  twice within 5 seconds.

Control indicator  illuminates in the instrument panel. The traction control aspect of ESP is deactivated for high performance driving.

The driver information centre shows "COMPETITIVE MODE". See page 69.

Adjust your driving accordingly.

To deactivate:

Briefly press button  again or switch off the ignition.

Warning


When competitive mode is engaged, it is possible to lose traction.

Do not attempt to shift while the rear wheels are spinning, to prevent damage to the transmission. Failure to follow these instructions can cause injuries or put lives at risk.

Cruise control

The cruise control can store and maintain speeds above approx. 30 km/h (20 mph). Deviations from the stored speeds may occur when driving uphill or downhill.

For safety reasons, cruise control cannot be activated until the brake pedal has been operated once.

Cruise control is operated with buttons , **+ RES**, and **- SET** on the left side of the steering wheel.

Do not use cruise control if it is not advisable to maintain a constant speed (e.g. in situations presenting a danger to yourself and other road users, in heavy traffic or on winding, slippery or greasy roads).


When cruise control is active, reaction times may be increased due to the different position of the feet.

Warning

The driver is always responsible for maintaining an appropriate speed if cruise control is on. Failure to follow instructions can cause injuries or put lives at risk.



To activate:

Press button  to turn cruise control on. The control indicator in the button will illuminate.



Accelerate to the desired speed, press the **- SET** button and release it: the current speed is stored and maintained.

The accelerator pedal can be released after setting cruise control speed.

Vehicle speed can be increased temporarily for overtaking purposes, by depressing the accelerator pedal. When the accelerator pedal is released, the previously stored speed is resumed.

"CRUISE ENGAGED" appears in the driver information centre with cruise control active.

Check control warning messages - see page 68.

Increase speed:

With cruise control active, hold down button + **RES** or briefly press it repeatedly: speed is increased continuously or in steps of 1.6 km/h (1 mph) without using the accelerator pedal.

When button + **RES** is released, the current speed is stored and maintained.

Alternatively, use the accelerator pedal to increase vehicle speed, press button - **SET** and release it, then release the accelerator pedal.

When button - **SET** and the accelerator pedal are released, the current speed is stored and maintained.


Decrease speed:

With cruise control active, hold down button - **SET** or briefly press it repeatedly: speed is reduced continuously or in steps of 1.6 km/h (1 mph).

When button - **SET** is released, the current speed is stored and maintained.

To deactivate:

Switch off cruise control when not needed, to avoid accidental activation.

Press button : cruise control is switched off, the control indicator in the button goes out and the vehicle slowly decelerates. To continue driving, depress the accelerator pedal in the usual manner.


For reasons of safety, cruise control deactivates under certain driving conditions. For example:

- if the vehicle's speed drops below approx. 30 km/h (20 mph) or
- if the brake pedal is depressed or
- if the clutch pedal is depressed or
- if the Electronic Stability Program (ESP) comes into action, to improve driving stability and limit wheel spin.

Deactivating cruise control does not switch off the system.

Resuming the stored speed:

Briefly press button + **RES** at a speed above 30 km/h (20 mph): speed selected before cruise control was deactivated is resumed.

The value of the stored speed is deleted when cruise control has been switched off by pressing button , and when the ignition is turned off.

Brake system

The effectiveness of the brakes is an important factor for traffic safety.


To improve effectiveness, do not brake unnecessarily hard for the first 200 km (120 miles) after new brake pads have been fitted.

Brake pad wear must not exceed a specified limit. Regular maintenance as detailed in the chapter "Service, Maintenance" on page 165 is therefore of the utmost importance for traffic safety.


Have worn brake pads replaced by a workshop. Pads which have been tested and approved ensure optimum brake performance.

Brake pads that have worn to their minimum thickness generate a grinding noise. Continued driving is possible.

Have the brake pads replaced as soon as possible by a workshop.

 **Warning**

Disregard of these instructions may lead to injuries or endanger lives.



Brake assist

Powerful application of the brake pedal automatically applies maximum braking force amplification to achieve the shortest possible braking distance under full braking (brake assist).

Maintain steady pressure on the brake pedal for as long as full-on braking is to continue. When the brake pedal is released, the maximum brake force amplification is taken away.

Foot brake

The foot brake comprises two independent brake circuits.


If a brake circuit fails, the vehicle can still be braked using the other brake circuit. If this occurs, however, the brake pedal must be depressed quite far using considerable force before braking effect occurs. The distance required for braking will be greater. Consult a workshop before continuing your journey.


To ensure the full pedal travel can be utilized, especially in case of a fault in one of the brake circuits, there must be no unrestrained mats in the vicinity of the pedals – see page 111.

When the engine is not running, the assistance of the brake servo unit ends once the brake pedal has been depressed once or twice. Braking effect is not reduced, but braking requires significantly greater force.

Check the brake lamps before starting out on a journey.

Just before starting any journey, check effectiveness of brake system at low speeds and without obstructing moving traffic, particularly if brakes are wet, e.g. after washing the vehicle.

The brake/clutch fluid level should be checked regularly. If the brake/clutch fluid level is too low and the hand brake is not applied, control indicator  illuminates in the instrument panel – see page 56.



Hand brake

Always apply hand brake firmly. On slopes, apply the hand brake as firmly as possible.

The mechanical hand brake affects the rear wheel brakes. They automatically engage when the lever is pulled.

To release the hand brake, lift handle slightly, press release button and lower handle all the way down.

To reduce the operating forces of the hand brake, depress the foot brake at the same time.



Control indicator (ⓘ) for brake system

Illuminates when the ignition is switched on if the hand brake is applied or if the brake/clutch fluid level is too low.

Flashes at speeds over 8 km/h (5 mph) if hand brake is applied. Release hand brake before continuing journey, to avoid overheating and damaging the brake system. See also page 70.

Brake and clutch fluid – see page 156.

Warning

If the control indicator illuminates when the hand brake is not applied: Stop. Interrupt your journey immediately. Consult a workshop.

ABS (Ⓢ)

The ABS (Anti-lock Brake System) continuously monitors the brake system and prevents the wheels from locking, independently of the type of road surface and the tyre grip.

It starts to regulate the braking pressure as soon as a wheel shows a tendency to lock. The vehicle remains steerable, even in the event of very heavy braking, for instance on bends or when swerving to avoid an obstacle. Even in the case of full-on braking, the ABS makes it possible to drive round an obstacle without releasing the brakes.


ABS control is made apparent through a pulse in the brake pedal and the noise of the regulation process.

Warning

For optimum braking, keep the brake pedal fully depressed throughout the braking process, despite the fact that the pedal is pulsating. Do not reduce the pressure on the pedal.

Do not let this special safety feature tempt you into taking risks when driving.

Traffic safety can only be achieved by adopting a responsible driving style.



Control indicator for ABS

Illuminates for a few seconds after the ignition is switched on. The system is ready for operation when the control indicator goes out.

If the control indicator does not go out after a few seconds, or if it illuminates while driving, there is a fault in the ABS. The brake system remains operational without ABS regulation.

Self-check

Each time the ignition is switched on and the engine is started, after setting off at a speed of about 3 km/h (2 mph), the system performs a self-check which may be audible.

Fault

Warning

If there is a fault in ABS, the wheels may be subject to locking due to braking that is heavier than normal. This may cause the vehicle to swerve. The advantages of ABS are no longer operational.

You can continue driving, provided you drive with care and anticipation.

Have the cause of the fault remedied by a workshop. The system's integrated self-diagnostics allows faults to be quickly remedied.

Wheels, tyres

See page 179 for suitable tyres and restrictions.

Factory-fitted tyres are matched to the chassis and offer optimum driving comfort and safety.

Changing tyre/wheel type

Before changing to tyres or wheels of a different size, seek advice as regards technical possibilities. Seek the assistance of a workshop.

If tyres of a different size than those fitted at the factory are used, the electronic speedometer may require reprogramming to ensure that the correct speed is displayed.

Warning

Use of unsuitable tyres or wheels may lead to accidents and render the vehicle unroadworthy.

Fitting new tyres

Please fit tyres in pairs. Sets would be even better. Replace tyres with:

- the same size,
- the same design,
- the same make,
- the same tread pattern on one axle.

Fit directional tyres such that they roll in the direction of travel. The rolling direction is indicated by a symbol (e.g. an arrow) on the sidewall.

Tyres fitted opposing the rolling direction (e.g. when a tyre is changed) should be refitted as soon as possible. This is the only way to obtain full benefit from the design properties of the tyre.

Observe legal requirements when disposing of tyres.


Some brands of tyres have a beaded edge for alloy wheels to protect against damage. If a wheel trim is used on steel wheels with beaded-edge tyres, the following procedure must be followed:

- Wheel trims and tyres that are approved for the respective vehicle and comply with all of the relevant wheel and tyre combination requirements must be used.
- If the wheel trims and tyres used are not approved, the tyres must not have a beaded edge.

⚠ Warning	
Use of unsuitable tyres or wheel trims could lead to sudden pressure loss and thereby accidents.	

Tyre pressure


Check tyre pressures when cold, at least every 14 days and prior to any long journey.



S 14735

Tyre pressures – see page 180 and the tyre and loading information label on the B-pillar, visible with the driver's door open. Have tyre and loading information label replaced after changing to a different tyre size.

Do not reduce tyre pressure when the tyres are warm. Otherwise the pressure may drop below the permissible minimum when the tyres cool down.



After having checked the tyre pressures, tighten the valve caps.

Incorrect tyre pressures will impair safety, vehicle handling, comfort and fuel economy and will increase tyre wear.

If the pressure is too low, this can result in considerable tyre warm-up and internal damage, leading to tread separation and even to tyre blow-out at high speeds.

Hidden tyre damage is not eliminated by adjusting tyre pressure.

⚠ Warning

Incorrect tyre pressure can lead to tyre rupture.



Tyre condition, wheel condition


Drive over edges slowly and at right angles if possible. Driving over sharp edges can cause concealed damage to tyres and wheels that only becomes noticeable later.

Do not trap tyres when parking.

Check tyres regularly for damage (foreign bodies, punctures, cuts, cracks, bulges in sidewalls). Check wheels for damage. In the event of damage or abnormal wear, consult a workshop.

⚠ Warning

Damage may lead to tyre blow-out.



Tread depth

Check tread depth at regular intervals.

If there is more wear at the front than the rear, swap round front wheels and rear wheels.

Correct the tyre pressure.

Tyres should be replaced for safety reasons if tread depth drops below 2-3 mm (4 mm for winter tyres).



The legally permissible minimum tread depth (1.6 mm) has been reached when the tread has worn down as far as one of the wear indicators (TWI¹⁾). A number of wear indicators are spaced at equal intervals around the tyre within the tread. Their position is indicated by markings on the tyre sidewall.

General information

- The danger of aquaplaning is greater if the tyres are worn.
- Tyres age, even if they are used only very little or not at all.
- Never fit used tyres the previous history and use of which you do not know.
- So as not to impair brake cooling, use only wheel trims approved for use on your vehicle.

Tyre designations

Meanings:

e.g. **245/45 R 18 100 W**

- 245** = Tyre width in mm
- 45** = Aspect ratio (tyre height to tyre width) in %
- R** = Belt type: Radial
- 18** = Rim diameter in inches
- 100** = Load index
e.g.: 100 corresponds to 800 kg
- W** = Speed code

Speed code letters:

- Q** Up to 160 km/h (100 mph)
- S** Up to 180 km/h (112 mph)
- T** Up to 190 km/h (118 mph)
- H** Up to 210 km/h (130 mph)
- V** Up to 240 km/h (150 mph)
- W** Up to 270 km/h (168 mph)

¹⁾ **TWI** = Tread **W**ear **I**ndicator.

Winter tyres ❄️

For notes on fitting new tyres – see page 126.

See page 179 for restrictions.

Winter tyres improve safety at temperatures below 7 °C and should therefore be fitted on all the wheels.

The design of summer tyres means they have limited qualities for winter driving.

If the maximum permissible speed for the winter tyres is less than that of the vehicle, a notice indicating the maximum permissible speed for the tyres must be affixed within the driver's field of vision¹⁾.

Wheel trims

If the wheel trims and tyres used are not approved, make sure that the tyres do not have a beaded edge – see page 126.



17217T

Tyre chains ❄️

Restrictions and further information - see page 179.

Tyre chains are only permitted on the driven wheels (rear axle). They must be fitted to the tyres symmetrically in order to achieve a concentric fit.

Always use fine-linked chains that add no more than 11 mm to the tyre tread and the inboard sides (including chain lock).

Wheel trim on steel wheels could come into contact with parts of the chain and be damaged. Remove the wheel trim.

Tyre chains may only be used at speeds up to 50 km/h (30 mph) or up to the tyre chain manufacturer's recommended maximum speed, whichever is lower.

When travelling on roads that are free of snow, they may be used for brief periods only since they are subject to rapid wear on a hard road and may snap.

Avoid sharp turns, bumps and holes and do not lock the wheels when braking, to avoid damaging the tyre chains.

Re-tighten the chains after driving for approx. 1 km (0.6 miles). If, at any time you hear or suspect that the chains are contacting the vehicle, stop and re-tighten the chains.

Always read the instructions supplied with the tyre chains.

Correct the tyre pressure before starting-off. See page 180.


¹⁾ Varies from country to country on account of national regulations.

Self-help, vehicle care

Bonnet release	130
Starting	131
Starting the engine with jump leads *	132
Towing	134
First-aid kit ☹️* , warning triangle ⚠️*	135
Vehicle tools	135
Puncture	135
Tyre repair kit	136
Electrical system	141
Fuses and the most important circuits they protect	143
Bulb replacement	146
Inspection system	151
Opel genuine parts and accessories .	152
A note on safety	152
Checking and topping up fluids	152
Windscreen wipers	157
Windscreen washer system	158
Battery	159
Protection of electronic components	159
Vehicle decommissioning	160
Vehicle recommissioning	160
Vehicle care	161

⚠️ Warning

Disregard of these instructions may lead to injuries or endanger life. Vehicle passengers should be informed accordingly.




Bonnet release

To open the bonnet, pull the release lever located on the driver's side below the instrument panel.

The bonnet will then be unlatched and will open partially. Return release lever to its original position.

Do not pull release lever while the vehicle is moving.



To open completely, lift bonnet upwards from the edge nearest the windscreen. Air pressurised support rods will hold the bonnet open.

When the bonnet is opened, leaves, dirt or snow can obstruct the air intake. Remove any leaves, dirt or snow. Air intake – see page 109.

Never drive with bonnet open.

To close bonnet, lower it gradually before pushing it firmly into its catch.

Check that the bonnet is latched in position before driving, by pulling at its rear edge. If it is not engaged, repeat closing procedure.

Warning

To avoid causing damage to the doors and the bonnet, ensure the driver's door and the passenger's door are both closed correctly before closing the bonnet.

Starting

Do not start with quick charger

This prevents damage to electronic components.


Warning

If the vehicle battery requires charging while still in the vehicle, ensure there is adequate ventilation in and around the battery compartment to prevent risk of explosion.

Do not start by pushing or towing

Because your vehicle is fitted with a catalytic converter, it must not be started by pushing or towing – see page 116.

The vehicle can only be started using jump leads – see following page.




Starting the engine with jump leads *

A vehicle with a discharged battery can be started using jump leads, the battery of another vehicle and your vehicle's jump start terminals - see page 133. Attempts to start the vehicle should be made at intervals of 1 minute and should not last longer than 15 seconds.

Warning

This must be done with extreme care. Any deviation from the following instructions could lead to personal injury or damage resulting from battery explosion, as well as to damage to the electrical systems in both vehicles.

- Never expose the battery to naked flames or sparks.
- A discharged battery can freeze at temperatures of 0 °C. Defrost the frozen battery in a warm room before connecting jump leads.
- Do not allow battery fluid to come into contact with eyes, skin, fabrics or painted surfaces. The fluid contains sulphuric acid which can cause injuries and damage in the event of direct contact.
- Wear eye protection and protective clothing when handling a battery.
- Use auxiliary battery with same voltage (12 volts). Its capacity (Ah) must not be considerably less than that of the discharged battery. Voltage and capacity information can be found on the batteries.
- Use jump leads with insulated terminals and a cross section of at least 16 mm².
- Do not disconnect the discharged battery from the vehicle.
- Switch off all unnecessary electrical consumers.
- Do not lean over the battery during jump starting.
- Do not allow the terminals of one lead to touch those of the other lead.
- The vehicles should not touch while jump starting.
- Apply hand brake. Transmission in neutral.




S 14092

Jump start terminals

In the event of a discharged battery, the jump start terminals located in the engine compartment enable the vehicle to be started without the need to access the battery.


The positive jump start terminal is identified by a "+" sign on the red insulating cover, located next to the engine compartment fuse box.

Open the red insulating cover to access the positive "+" terminal connector. Ensure the red insulating cover is latched back into position when not in use.



S 14093

The negative jump start terminal is identified by a "GND (-)" sign on a ground bracket, located below the engine beauty cover.



S 14094

Connect the leads in the order shown in the illustration:

1. Connect one end of the first jump lead to the positive terminal 1 of the battery providing the jump start (identified by "+" sign on battery case or terminal).
2. Connect the other end of this lead to the positive jump start terminal 2 of the vehicle with the discharged battery ("+" sign).
3. Connect the first end of the other jump lead to the negative terminal 3 of the battery providing the jump start ("- sign).
4. Connect the other end of the second jump lead 4 to the negative jump start terminal ground bracket, identified by "GND (-)".

- Do not connect leads to negative terminal of discharged battery!
- Route the leads so that they cannot catch on rotating parts in the engine compartment.
- Start the engine of the vehicle providing the jump start.
- After 5 minutes, start the other engine. Start attempts should be made for no longer than 15 seconds at an interval of 1 minute.
- After the start, allow both engines to idle for 3 minutes with the leads connected.
- In order to avoid excess voltage in the electrical system, before removing a lead, switch on an electrical consumer (e.g. lamps, heated rear window) in the vehicle receiving the jump start.
- Reverse above sequence exactly when removing leads.



Towing

Towing the vehicle

Screw the front towing eye (stowed in a bag in the luggage compartment) fully into the front towing point.

Attach a tow rope * - or better still, a tow rod * - to the towing eye, never to the bumper or front suspension units.

Warning

Never lift the vehicle using the towing eye!

Place the gear shift lever in neutral. Switch on the ignition to release the steering column lock and to permit operation of the brake lamps, horn and windscreen wipers.

Drive off slowly and avoid jerky movements. Impermissible tractive forces could damage the vehicles.

Warning

More brake pedal pressure is necessary when braking since the brake servo unit is operative only when the engine is running.

Considerably greater steering force is necessary since the power steering unit is operative only when the engine is running.

To prevent the entry of exhaust gases from the towing vehicle, switch on the air recirculation system and close the windows.

Seek the assistance of a workshop.

Towing service


Entrust your vehicle only to the towing service of your choice and obtain an estimate on towing costs before employing any towing service. In this way you avoid unnecessary costs and possible insurance problems during claim processing.

First-aid kit ☹️ *, warning triangle ⚠️ *

Your first-aid kit and warning triangle can be accommodated in the luggage compartment.

Vehicle tools

The front towing eye should be kept in the bag provided when not in use and stowed in the luggage compartment.



S 14173

Puncture

In order to minimise vehicle weight, your vehicle is not fitted with a jack or a spare wheel.

It is recommended that wheel changing and jacking of the vehicle are only carried out by a workshop.

However, if the vehicle needs to be lifted in an emergency, suitable jacking points are located on the vehicle underbody.

⚠️ Warning

When raising the vehicle on a workshop hoist, proper lift pads must be used to avoid causing damage to the vehicle. Contact a workshop.

Tyre repair kit

Minor damage to the tyre tread, e.g. from foreign bodies, can be temporarily repaired using the tyre repair kit.


Do not remove foreign bodies from the tyres. Damaged areas bigger than 4 mm and damage at the tyre rim cannot be repaired using the tyre repair kit.

Warning

Driving with tyre pressure that is too low can cause invisible damage to the tyres. This damage cannot be remedied using the tyre repair kit. Park vehicle and contact a workshop.

The tyre repair kit can be used to seal small punctures with a liquid sealant. Use of the sealant does not constitute a permanent repair but is designed as an emergency measure, to allow the vehicle to be driven while awaiting tyre replacement.

The tyre repair kit can also be used to inflate the tyres to the correct tyre pressure (see page 180) without using the sealant.



S 14063

For important information – see page 140.

If you have a flat tyre:

- Park on a level, firm and non-slippery surface.
- Switch on hazard warning lamps, apply hand brake, engage reverse gear and switch off engine.
- Correctly set up the warning triangle ❄. Warning triangle – see page 135.

Never use the liquid sealant on more than one tyre at a time.

The tyre repair kit is located in a stowage compartment on the driver's side at the rear of the luggage compartment.

Remove the strap from the tyre repair kit by pressing the tabs on either side of the buckle and remove the tyre repair kit from its foam container.



S 14064

1. Place the tyre repair kit on level ground and unwrap the sealant filling hose from the compressor unit.




S 14065

2. Remove accessory plug from the unit by pulling out the top part of the wrapped cord first, followed by the bottom part. Disconnect the accessory plug.



S 14066

3. Unscrew dust cap from defective tyre and screw sealant filling hose to valve.
4. Ensure the compressor on/off switch is in position **O** (off).



S 14067

5. Open cover of accessory socket and insert accessory plug of tyre repair kit.
6. Start the engine (see page 17). The engine must be running while using the air compressor.



S 14070

7. Switch compressor on/off switch to position I (on).
8. All of the sealant is pumped into the tyre and the tyre is inflated.

Sealant may leak from the puncture hole until the vehicle has been driven and the hole sealed.

Do not run the compressor for more than 10 minutes, see "Important information" on page 140.



S 14071

9. Check the compressor pressure gauge. If there is no reading, the sealant filling hose to valve connection may be faulty. Re-check the connection.
10. Inflate the tyre to the correct pressure - see page 180.

As the pressure gauge reading is slightly high while the compressor is on, switch compressor off to gain an accurate pressure reading.


If the prescribed tyre pressure is not obtained within 10 minutes, the tyre is too badly damaged. Switch off engine and compressor, remove accessory plug and unscrew sealant filling hose before contacting a workshop.

11. When the correct tyre pressure has been reached, switch compressor on/off switch to position O (off).
12. Switch engine off and unplug the accessory plug from the accessory socket.
13. Disconnect sealant filling hose from tyre valve and replace the dust cap.

Exercise caution when removing tyre repair kit components, as they may still be hot after use.

Wrap sealant filling hose around compressor unit in its original location. Stow accessory plug in compressor unit by wrapping the cord, reconnecting the accessory plug, then pushing in the bottom part of the wrapped cord followed by the top part into the compressor unit.

Peel off the sticker containing the maximum permitted speed that is affixed to the sealant bottle, and attach it within the driver's field of view. For sticker – see page 137, Fig. S14066.

14. Place the tyre repair kit in its foam container and wrap the strap around it. Snap the buckle into place and tighten the strap as necessary.
15. Remove any excess sealant using a cloth. Stow tyre repair kit in luggage compartment in its original location.
16. Collapse warning triangle  and stow in luggage compartment – see page 135.



17. Continue driving immediately so that sealant is evenly distributed throughout the tyre.
After driving approx. 10 km (6 miles) (but no more than 10 minutes), stop and check tyre pressure, using the compressor:
Unlck air compressor hose from underside of compressor unit by pulling the lever up (see illustration). Detach the hose from the sealant bottle and pull out the hose.
Push air compressor hose directly on to tyre valve and push lever down to secure in place.

18. Check the compressor pressure gauge. As long as the tyre pressure has not dropped more than 0.7 bar below the correct tyre pressure, it may be adjusted to the prescribed value. Repeat the procedure until there is no more loss of pressure.
If the tyre pressure has dropped more than 0.7 bar below the correct tyre pressure, the vehicle must not be driven. Contact a workshop.
19. Stow tyre repair kit in luggage compartment.

Important

 **Warning**

Do not drive faster than 90 km/h (55 mph).

Have the repaired tyre replaced as soon as possible.

Do not drive with more than one temporarily repaired tyre.

Steering and handling may be affected. Take bends slowly.

Only stow the tyre repair kit in the luggage compartment.

The driving characteristics of the repaired tyre is severely affected, therefore have this tyre replaced without delay by a workshop.

If unusual noise is heard or the compressor becomes hot, turn compressor off for at least 30 minutes.

The built-in safety valve opens at a pressure of 7 bar.

Protect compressor from moisture and rain.

Pay attention to storage information and best before date on sealant bottle. Its sealing capability is not guaranteed after this time.

The sealant bottle can only be used once. Replace used sealant bottle.

The compressor and sealant can be used from approx. -30 °C.

Dispose of used tyre repair kits in accordance with the applicable laws.

Consumers must not be connected to the accessory socket at the same time when the tyre repair kit is being used.


Electrical system

⚠ Warning

Electronic ignition systems use a very high voltage. Do not touch the ignition system; danger to life.

Fuses

The vehicle has two fuse boxes: one behind a cover on the right-hand side of the passenger compartment and another in the engine compartment.




S 14096

It is advisable to carry a complete set of fuses in the vehicle.

Store spare fuses on the underside of the engine compartment fuse box cover.

Opening the cover – see page 144.

Before replacing a fuse, turn off the respective switch and the ignition.



17259 T

A blown fuse can be recognised by its melted wire. Do not install a new fuse until the cause of the fault has been remedied.




Different types of fuse are used.

Fuse colour	Fuse rating
Grey	2 A
Brownish yellow	5 A
Red	10 A
Blue	15 A
Yellow	20 A
Transparent	25 A
Orange	40 A



17260 T

Fuse colour	Fuse rating
Blue	20 A
Pink	30 A
Green	40 A
Red	50 A
Yellow	60 A



18469 T

Place the fuse extractor on the various types of fuse from the top or side, and withdraw fuse.

Only install fuses of the specified rating. Each fuse has its rating written on it, in addition the fuses are colour coded.




Fuses and the most important circuits they protect

Fuse box in passenger compartment

The fuse box is located at the end of the passenger's foot well, below the instrument panel.

Pull floor carpet from the top to access fuse box cover.




To open, pull cover from the left-hand side to detach from Velcro pads and remove cover.

Do not store any objects behind the cover.

Spare fuses, fuse extractor - see pages 141, 142.

Some functions are protected by several fuses.

No.	Circuit	Rating
1	-	
2	-	
3	-	
4	-	
5	Amplifier	20 A
6	Instrument panel cluster	10 A
7	Ignition switch, electronic immobiliser	2 A
8	Brake lamp	10 A
9	Climate control, electronic immobiliser	10 A
10	-	
11	Spare	20 A
12	Airbags	10 A
13	Spare	10 A
14	Windscreen wipers	10 A



S 14122



S 14109

No.	Circuit	Rating
15	Climate control, seat occupancy recognition, clutch switch, crank relay, instrument panel cluster	10 A
16	Electric windows	30 A
17	-	
18	-	
19	Steering wheel controls	2 A
20	Spare	15 A
21	Spare	20 A

No.	Circuit	Rating
22	-	
23	Radio	15 A
24	Sensing and Diagnostic Module	10 A
25	Engine Control Module, Transmission Control Module	10 A
26	Door locks	15 A
27	Interior lamps	10 A
28	Steering wheel control illumination	2 A


Fuse box in engine compartment

Warning

Turn off engine before opening engine compartment fuse box; risk of injury – see page 152.

To open the cover, press locking tabs at each end of the fuse box inwards. Lift the cover upwards to remove.

Do not store any objects behind the cover.



S 14126

Some functions are protected by several fuses.

No.	Circuit	Rating
1	-	
2	Body Control Module	50 A
3	Body Control Module 2	40 A
4	Crank	30 A
5	Body Control Module 3	30 A
6	-	
7	Heated rear window	20 A
8	Cooling fan	60 A

No.	Circuit	Rating
9	Fuel pump	15 A
10	-	
11	Luggage compartment	5 A
12	Luggage compartment	25 A
13	-	
14	Electric exterior mirrors	5 A
15	Spare	10 A
16	-	

No.	Circuit	Rating
17	Air conditioning	10 A
18	Data link connector	15 A
19	Spare	20 A
20	-	
21	Outlet	20 A
22	-	
23	Emissions	10 A
24	Vacuum pump	20 A
25	-	
26	Electric seat	20 A
27	-	
28	Engine Control Module, transmission	15 A
29	Engine Control Module	20 A
30	Turbo, Cam phaser	10 A
31	-	
32	Reversing lamp	10 A
33	Ignition coils	15 A
34	ABS	10 A
35	Fog lamps	15 A

No.	Circuit	Rating
36	Horn	15 A
37	Remote central locking	10 A
38	Driver's side high beam	10 A
39	Windscreen wipers	25 A
40	ABS	10 A
41	ABS	20 A
42	Passenger's side high beam	10 A
43	Passenger's side low beam	10 A
44	Driver's side low beam	10 A
45	Instrument panel ignition	20 A
46	Canister vent	10 A
47	Parking lamps	15 A

Bulb replacement

Warning

To avoid causing damage to the doors and the bonnet, ensure the driver's door and the passenger's door are both closed correctly before closing the bonnet.

Halogen bulbs contain pressurised gas. Take special care when disposing of halogen bulbs. Never touch the glass with bare fingers; risk of injury.

Before replacing a bulb, switch ignition off and turn off relevant light switch.

Only hold new bulb at base! Do not touch the bulb glass with bare hands, otherwise fingerprints on the glass evaporate. Residue builds up on the reflector, eventually resulting in a dull reflector. Inadvertently stained bulbs may be cleaned with a clean non-fluffy cloth, using alcohol or white spirits.


Replacement bulb must be in accordance with information on base of defective bulb. Do not exceed wattage specified on base of bulb.

Replace cracked or damaged bulbs as dirt can get inside, coating the inside of the bulb and reducing light output.

If the headlamps are damaged, the light may not be sufficiently diffused and can blind oncoming drivers. Vehicle vibration can also cause incorrect headlamp aiming.

Headlamp aiming


We recommend that headlamp aiming be carried out by a workshop, who will have special equipment.



S 14123

Headlamp system


Headlamps with separate systems for low beam 1 (outer bulbs) and high beam 2 (inner bulbs).



S 14136

Low beam

1. Open bonnet and remove 3 screws from headlamp protective cover.
2. Rotate bulb socket anti-clockwise and pull it out of headlamp assembly.
3. Detach plug connector from bulb socket.
4. Remove bulb from bulb socket and insert new bulb, without touching the glass.
5. Attach plug connector to bulb socket, push bulb socket into headlamp assembly and rotate bulb socket clockwise.
6. Replace headlamp protective cover, replace 3 screws to hold cover in place and close bonnet.



S 14138


High beam

1. Open bonnet and remove headlamp protective cover.
2. Rotate bulb socket anti-clockwise and pull it out of headlamp assembly.
3. Detach plug connector from bulb socket.
4. Remove bulb from bulb socket and insert new bulb, without touching the glass.
5. Attach plug connector to bulb socket, push bulb socket into headlamp assembly and rotate bulb socket clockwise.
6. Replace headlamp protective cover and close bonnet.




Parking lamps

1. Open bonnet.
2. Rotate bulb socket anti-clockwise and pull it out of headlamp assembly.
3. Detach plug connector from bulb socket.
4. Remove bulb from bulb socket and insert new bulb, without touching the glass.
5. Attach plug connector to bulb socket, push bulb socket into headlamp assembly and rotate bulb socket clockwise.
6. Close bonnet.




Front turn signals, front fog lamps

1. Open bonnet.
2. Reach through aperture between front panelling and bonnet and locate bulb assembly.
3. Rotate bulb socket anti-clockwise and pull out bulb assembly.




4. Detach plug connector from bulb socket.
5. Remove bulb from bulb socket and insert new bulb, without touching the glass.
6. Attach plug connector to bulb socket, push bulb assembly into original position and rotate bulb socket clockwise.
7. Close bonnet.




Rear brake, tail, turn signal lamps

1. Open luggage compartment
2. Remove 2 bolts holding the bulb assembly to the vehicle body.



3. Pull bulb assembly away from vehicle body and detach plug connector from bulb assembly.
4. Rotate bulb socket anti-clockwise and remove from bulb assembly.
5. Remove bulb from bulb socket and insert new bulb, without touching the glass.
6. Replace bulb socket in bulb assembly and rotate bulb socket clockwise.
7. Replace bulb assembly into original position and replace 2 bolts to hold bulb assembly to the vehicle body.
8. Close luggage compartment.



Reversing lamp, fog tail lamp


1. Reach behind, up and under rear panelling and locate bulb socket.
2. Rotate bulb socket anti-clockwise and remove from lamp assembly.
3. Remove bulb from bulb socket and insert new bulb, without touching the glass.
4. Install bulb socket by lining up the tabs in the lamp assembly and rotate bulb socket clockwise.



S 14150

License plate lamps

1. Remove 2 screws holding license plate lamp to fascia.
2. Rotate and pull license plate lamp forwards through fascia opening.
3. Rotate bulb socket anti-clockwise.
4. Remove bulb from bulb socket and insert new bulb, without touching the glass.
5. Rotate bulb socket clockwise and replace license plate lamp into original position.
6. Replace 2 screws to hold license plate lamp to fascia.



S 14151

Luggage compartment lamp

1. Open luggage compartment and prise out bulb housing.
2. Detach plug connector from bulb housing.
3. Remove bulb from bulb socket and insert new bulb, without touching the glass.
4. Attach plug connector to bulb housing, push bulb housing into original position and close luggage compartment.


Centre high-mounted stop lamp, side repeater lamps, courtesy lamps, instrument illumination

We recommend having bulb replacements carried out by a workshop.

Inspection system

In order to guarantee economical and safe vehicle operation and to maintain the value of your vehicle, it is of vital importance that all maintenance work is carried out at the proper intervals as specified by Opel (see chapter "Service, Maintenance" on page 165). Time or mileage/kilometre intervals - whichever is reached first - determine when your vehicle is due for its next Service.

Have the Service work that is due carried out within one week or 500 km (300 miles). Have this work carried out by a repairer in accordance with Opel's recommendations, using Opel genuine parts and accessories.



The engine oil life monitor lets you know when to change the engine oil. Based on driving conditions, the time or kilometre/mileage interval at which an engine oil change will be indicated can vary considerably.

For the system to work properly, it must be reset every time the engine oil is changed. Seek the assistance of a workshop.

When the system has calculated that engine oil life has been diminished, "CHANGE OIL SOON" appears in the driver information centre - see page 69. Engine power may be decreased. Change engine oil immediately.

Further information on Service and the Service Plan can be found in the chapter "Service, Maintenance" on page 165.

Have maintenance work, as well as repairs to the bodywork and equipment, carried out by a professional. We recommend your Opel Service Partner, who is familiar with Opel vehicles and in possession of the necessary special tools and the latest service instructions from Opel. It is particularly advisable to use an Opel Service Partner during the warranty period, to avoid invalidation of warranty claims. See the chapter "Service, Maintenance" on page 165 for further information.


Separate anti-corrosion service

Have the work performed at the intervals specified in the chapter "Service, Maintenance" on page 165.

Opel genuine parts and accessories

We recommend that you use "Opel genuine parts and accessories" and conversion parts released expressly for your vehicle type. These parts have undergone special tests to establish their reliability, safety and specific suitability for Opel vehicles. Despite continuous market monitoring, we cannot assess or guarantee these attributes for other products, even if they have been granted approval by the relevant authorities or in some other form.

"Opel genuine parts and accessories" and approved conversion parts can be obtained from your Opel Service Partner, who can provide comprehensive advice about permitted technical changes and ensure that the part is installed correctly.



17304 T


A note on safety

To avoid injury from moving parts and cables conducting ignition voltage, only carry out engine compartment checks (e.g. checking brake/clutch fluid or engine oil level) when the ignition is switched off.

Warning

The cooling fan is controlled by a thermostatic switch and can therefore start unexpectedly, even if the ignition is switched off. Risk of injury.

Electronic ignition systems use a very high voltage. Do not touch the ignition system; danger to life.



S 14120

Never carry out any repairs or adjustment and maintenance work on the vehicle yourself. This especially applies to the engine, chassis and safety parts. You may, out of ignorance, infringe the provisions of the law and, by not performing the work properly, you may endanger yourself and other road users.

Checking and topping up fluids

The engine oil dipstick handle and the information on the caps for topping up coolant and brake/clutch fluid are yellow, for ease of identification.

Engine oil

Information on engine oils is available in the chapter "Service, Maintenance" on page 165.


Engine oil level and consumption

Every engine consumes engine oil for technical reasons. The engine oil consumption cannot be assessed until a fairly long distance has been driven, and may be above the specified value when the vehicle is first being driven (run-in period). Frequent driving at high revs increases engine oil consumption.

Warning

Do not allow the engine oil level to drop below the minimum level!

Before embarking on a long journey, it is advisable to check the engine oil level.




Engine oil level check, topping up engine oil

The engine oil level must be checked with the vehicle on a level surface and with the engine (which must be at operating temperature) switched off. Wait at least 5 minutes before checking the level to allow the normal engine oil accumulation in the engine to flow into the oil pan.

To check the engine oil level, insert wiped oil gauge (dipstick) into dipstick tube as far as it will go. Top engine oil up if the level has dropped into the range of the top-up mark **MIN**.

The engine oil level must not exceed the upper mark **MAX** on the dipstick. Excess engine oil must be drained off or extracted. If the engine oil level is above the **MAX** mark there is a risk of damage to the engine or the catalytic converter.

Capacity between **MIN** and **MAX** marks – see page 182.



Top up with the same brand of engine oil that was used during the previous engine oil change, following the instructions in the chapter "Service, Maintenance" on page 165.

To close, position the cap and screw it into place.

Capacities – see page 182.

Engine oil change, engine oil filter change

Perform change in accordance with the chapter "Service, Maintenance" on page 165.

Engine oil changes are to be carried out depending on time or kilometre/mileage intervals, or when the engine oil life monitor indicates that engine oil life has been diminished, since engine oil loses its lubrication properties not only through engine operation but also through ageing.

We recommend using an original Opel engine oil filter.

Warning

Empty engine oil cans must not be placed in the domestic refuse. We recommend that you entrust engine oil and engine oil filter changes to a workshop who is familiar with the legal requirements concerning the disposal of used engine oil and filters, and can thus help protect the environment and your health.

Remember to reset the engine oil life monitor whenever the engine oil is changed. Seek the assistance of a workshop.

Coolant


During operation the system is pressurized. The temperature may therefore rise to over 100 °C.

The glycol-based coolant provides excellent corrosion protection for the heating and cooling systems as well as antifreeze protection down to -28 °C. It remains in the cooling system throughout the year and need not be changed.

Use of certain antifreezes can lead to engine damage. We therefore recommend the use of antifreezes that have been approved.

Warning

Antifreeze is a danger to health; it must therefore be kept in the original container and out of the reach of children.




Antifreeze and corrosion protection

Before the start of the cold weather season, have the coolant checked for correct concentration.

The amount of antifreeze must provide protection up to approx. -28°C . If the antifreeze concentration is too low, this reduces protection from freezing and corrosion. Top up antifreeze if necessary.

If coolant loss is topped up with water, have concentration checked and add anti-freeze if necessary.



Coolant level

Hardly any losses occur since the cooling system is sealed and it is thus rarely necessary to top up the coolant.

The coolant should be just above the arrow marked **COLD FILL** in the expansion tank with a cold cooling system. The coolant level can be read from the outside of the expansion tank.

Warning

Allow engine to cool down before removing coolant filler cap. Remove filler cap carefully so that pressure can escape slowly, otherwise there is a risk of scalding.

When the engine is at operating temperature the coolant level rises. It falls again when the system cools. If it falls below the **COLD FILL** mark when the system is cold, top up to the mark.

Top up an antifreeze. If no antifreeze is available, top up with clean tap water. If tap water is unavailable, distilled water can be used.


After topping up with drinking water or distilled water, check the antifreeze level and add antifreeze if required. Have the cause of the coolant loss rectified by a workshop.

Too low a coolant level can cause engine damage.

To close, position the cap and screw it into place.

Coolant temperature

During operation the system is pressurized. The temperature may therefore rise to over 100 °C.

Control indicator  illuminates in the instrument panel when coolant temperature is too high. Check coolant level immediately:

■ Coolant level low:

Top up coolant. Pay attention to the instructions given under "Antifreeze and corrosion protection" and "Coolant level". Have the cause of coolant loss remedied by a workshop.

■ Coolant level OK:

Have the cause of increased coolant temperature remedied. Contact a workshop.



Brake and clutch fluid

Brake and clutch fluid level

Warning

Brake/clutch fluid is poisonous and corrosive. Do not allow it to contact eyes, skin, fabrics or painted surfaces. Direct contact may cause injuries and damage.

The fluid level in the container must be neither higher than the **MAX** mark nor lower than the **MIN** mark.

Use of certain brake/clutch fluids can lead to damage or reduced braking effect. We therefore recommend that you use only high performance brake/clutch fluid approved.

When topping up, ensure maximum cleanliness, as contamination of the brake/clutch fluid can lead to function problems in the braking system.


After correcting the brake/clutch fluid level, have the cause of brake/clutch fluid loss remedied by a workshop.

Brake/clutch fluid change

Brake/clutch fluid is hygroscopic, i.e. it absorbs water. If the brakes become hot, such as when driving on long downhill stretches, vapour bubbles can occur in the water, which can have an extremely adverse effect on braking power (depending on the proportion of water).

The fluid change intervals specified in the chapter "Service, Maintenance" on page 165 must therefore be observed.

⚠ Warning
We recommend that you have brake/clutch fluid changed by a workshop who is familiar with the requirements of the law as regards disposal of brake/clutch fluid and can thus help to protect the environment and your health.

**Power steering fluid**

The power steering fluid does not require any additional maintenance than that detailed in the chapter "Service, Maintenance" on page 165.

If the fluid in the reservoir falls below the **HOT** mark on the dipstick, consult a workshop.

Windscreen wipers

Clear vision is essential for safe driving.

Perform regular checks on the windscreen wipers to ensure they are operating correctly. We recommend wiper blade replacement at least once a year.

If the windscreen is dirty, operate the windscreen washer system before switching on the windscreen wipers. This will avoid wiper blade wear.

Do not switch on the windscreen wipers if the windscreen is iced up, as this could damage the wiper blades or the wiper system.


If the wipers become frozen on to the glass, we recommend that they be released with the aid of Opel De-icer Spray.

Smearing wiper blades can be cleaned with a soft cloth and Opel Cleaning Solvent and Antifreeze.

Wiper blades whose lips have become hardened, cracked or covered with silicone must be replaced. This may be necessary as a result of the effects of ice, thawing salt or heat, or the incorrect use of cleaning agents.


Switch off the windscreen wipers in car washes – see pages 15, 161.

Windscreen wiper care – see page 163.



17788 J

To replace wiper blade, lift wiper arm away from windscreen. Move release lever and detach wiper blade.



S 14115

Windscreen washer system

The fluid reservoir filler neck for the windscreen washer system is located in the engine compartment.

Capacities – see page 182.

Fill only with clean water to prevent the nozzles from clogging. To improve cleaning efficiency, we recommend that you add a little Opel Cleaning Solvent and Antifreeze.

The windscreen washer system will not freeze in winter:

Freeze protection down to	Mixture - Opel Cleaning Solvent And Antifreeze : Water
- 5 °C	1 : 3
- 10 °C	1 : 2
- 20 °C	1 : 1
- 30 °C	2 : 1

When closing the container, press the lid firmly over the beaded edge all the way round.



173201

Battery

The battery is maintenance-free.

⚠ Warning

Have battery changes carried out by a workshop who knows the laws concerning the disposal of used batteries and therefore protects the environment and your health.

Retrofitted electrical or electronic accessories can place an additional load on the battery or even discharge the battery. Consult a workshop regarding technical possibilities, such as fitting a more powerful battery.

Laying up the vehicle for more than 4 weeks can lead to battery discharge, which may reduce the service life of the battery. Disconnect battery from on-board power supply by detaching negative terminal.

Ensure that the ignition is switched off before connecting battery. Then perform the following actions:

- Set date and time in the radio display – see section “Infotainment system ✱” on page 78.

In order to prevent the battery from discharging, some consumers such as the courtesy lamps automatically switch off after approx. 20 minutes.

Protection of electronic components

In order to prevent faults in electronic components in the electrical system, never connect or disconnect battery with the engine running or the ignition switched on. Never start engine with battery disconnected, e.g. when starting using jump leads.

To avoid damaging the vehicle, do not make any modifications to the electrical system, e.g. connecting additional consumers or tampering with electronic control units (chip tuning).

⚠ Warning

Electronic ignition systems use a very high voltage. Do not touch the ignition system; danger to life.

Disconnecting/connecting the battery from/to the electrical system

Disconnect the battery from the vehicle electrical system before charging: First detach the negative and then the positive lead. Do not reverse the polarity of the battery, i.e. do not confuse the terminals for the positive and negative leads. When connecting, start with the positive lead and then connect the negative lead.

Vehicle decommissioning

Observe national regulations.

If the vehicle is decommissioned for several months, the following work must be carried out by a workshop in order to prevent damage.

- Wash and preserve the vehicle – see page 161.
- Check preservation in engine compartment and on underbody and make good where necessary.
- Clean and preserve rubber seals on bonnet and doors.
- Change engine oil – see page 154.
- Check antifreeze and corrosion protection – see page 155.
- Check the coolant level, top up with antifreeze if necessary – see page 155.
- Empty windscreen washer system.
- Increase tyre pressures to value specified for full load – see page 180.

Vehicle storage

- Park vehicle in a dry, well ventilated place. Engage first or reverse gear. Use chocks or the like to prevent the vehicle from rolling.
- Do not apply hand brake.
- Disconnect battery by disengaging negative terminal from vehicle electrical system – see page 159.

Vehicle recommissioning

Observe national regulations.

Perform the following work before recommissioning the vehicle:

- Connect battery – see page 159.
 - Check tyre pressures and correct if necessary – see page 180.
 - Fill up windscreen washer system – see page 72.
 - Check engine oil level – see page 153.
 - Check the coolant level; top up with antifreeze if necessary – see page 155.
- Fit the license plate if necessary.

Vehicle care

When caring for your vehicle, observe all national environmental regulations, particularly when washing it.

Regular, thorough care helps to improve the appearance of your vehicle and maintain its value over the years. It is also a prerequisite for warranty claims for any paint or corrosion damage. The following pages contain tips for vehicle care which, if used properly, will help combat the unavoidable damaging effects of the environment.

Vehicle care aids *

Vehicle wash:

- Wash brush,
- Car Shampoo,
- Sponges,
- Wheel Cleaners,
- Engine Cleaners,
- Glass Cleaners,
- Insect Removal Sponge,
- Chamôis Leather.

Vehicle care:

- Paintwork Cleaner,
- Paintwork Polish,
- Cream Polish,
- Metallic Paintwork Wax,
- Hard Wax,
- Touch-Up Applicator,
- Aerosol and Touch-Up Paint,
- Lock Cylinder Grease,
- Wheel Preserver,
- Alloy Wheel Preserver
- Tar Removal Spray,
- Insect Remover,
- Window Cleaner,
- Cleaning Solvent and Antifreeze,
- Silicone Oil for Rubber Seals.

Interior care:

- Interior/Upholstery Cleaner.

Washing

The paintwork of your vehicle is exposed to environmental influences, e.g. continuous changes in weather conditions, industrial waste gases and dust or thawing salts, so wash and wax your vehicle regularly.

Bird droppings, dead insects, resin, pollen and the like should be cleaned off immediately, as they contain aggressive constituents which can cause paint damage.

If using a car wash, comply with the pertinent instructions of the car wash manufacturer. The windscreen wipers must be switched off – see pages 15, 71. Remove antenna by unscrewing anti-clockwise.

If you wash your vehicle by hand, make sure that the insides of the wings are also thoroughly rinsed out.

Clean edges and folds on opened doors and flaps as well as the areas they cover.

Thoroughly rinse off and leather-off the vehicle. Rinse leather frequently. Use separate leathers for paint and window surfaces: remnants of wax on the windows will impair vision.

Observe national regulations.

Soft top care

Particular care should be taken when washing the fabric soft top. Carefully vacuum the soft top before washing, to remove excess dust and dirt particles. Wash in shade with a sponge (a chamois leather will leave lint, while a brush may abrade the threads) and use an Opel Car Shampoo and lukewarm water solution.

Wash the entire top uniformly to avoid rings or spots. Rinse with plenty of clean water.

Remove surface water with a sponge and allow to air dry. Be sure to allow the soft top to dry completely before stowing, as prolonged stowage of a wet or damp soft top will cause rotting of the fabric.

- Remove bird droppings from the soft top immediately.
- Do not use aggressive cleaning agents or stain removers.
- Do not direct water jets on to the edges of the soft top.
- Do not use sharp-edged objects to remove snow and ice from the soft top.

Whilst the soft top is weatherproof, it cannot be guaranteed to be fully waterproof if the vehicle is washed in an automatic car wash. It is therefore recommended that the vehicle is hand-washed and that automatic car washes are avoided.

Exterior storage

Due to the soft top design being weatherproof and not water tight in all conditions, extended periods of rainfall may result in some water collection in the passenger compartment. Therefore, it is recommended that the vehicle is not stored outside without a suitable protective covering such as a shower cover (available from your Opel Service Partner).

Waxing

Wax your vehicle regularly, in particular after it has been washed using shampoo and at the latest when water no longer forms beads on the paintwork, otherwise the paintwork will dry out.

Never let things deteriorate this far. Waxing prevents harmful chemical action.

Also wax edges and folds on opened doors and flaps as well as the areas they cover.

Polishing

Polishing is necessary only if the paint has become dull or if solid deposits have become attached to it.

Paintwork polish with silicone forms a protective film, making waxing unnecessary.

Plastic body parts must not be treated with preservation and polishing agents.

Use Metallic Paintwork Wax on vehicles with a metallic-effect paint finish.

Wheels

Use a pH-neutral wheel cleaning agent to clean the wheels.

Wheels are painted and can be treated with the same agents as the body. For alloy wheels, we recommend the use of Alloy Wheel Preserver.

Paintwork damage

Repair small areas of paint damage such as stone impacts, scratches etc. immediately using a Touch-Up Applicator or Aerosol and Touch-Up Paint before rust can form. If rust has already formed, have the cause rectified by a workshop. Please also pay attention to surfaces and edges beneath the vehicle where rust may have formed unnoticed for some time.

Tar spots

Do not use hard objects to remove spots of tar – use Tar Removal Spray. Do not use Tar Removal Spray on the covers of headlamps or other exterior lamps.

Exterior lamps

Headlamp and other protective lamp covers are made of plastic. If they require additional cleaning after the vehicle has been washed, clean them with Car Shampoo. Do not use any abrasive or caustic agents, do not use an ice scraper, and do not clean them dry.

Plastic and rubber parts

For additional cleaning of plastic and rubber parts, use Interior/Upholstery Cleaner. Do not use any other agent, and in particular do not use solvents or petrol.

Do not use high-pressure jet cleaners.

Wheels and tyres

Do not use high-pressure jet cleaners on wheels and tyres.

Interior and upholstery

Clean the vehicle interior, including the instrument panel fascia, using Interior/Upholstery Cleaner.

The instrument panel should only be cleaned using a soft damp cloth.

Clean fabric upholstery with a vacuum cleaner and brush. To remove stains, use Interior/Upholstery Cleaner that is suitable for both fabrics and vinyl.

Do not use cleaning agents such as acetone, carbon tetrachloride, paint thinner, paint remover, nail varnish remover, washing powder or bleach to clean fabrics, carpets, the instrument panel or leather trim ✱ in the vehicle interior. Petrol is also unsuitable.

Open Velcro fasteners on clothing could damage seat upholstery. Make sure that Velcro fasteners are closed.

Seat belts

Always keep seat belts clean and dry.

Clean only with lukewarm water or Interior/Upholstery Cleaner.

Windows

When cleaning the heated rear window, make sure that the heating element on the inside of the window is not damaged.

Use a soft lint-free cloth or chamois leather in conjunction with Window Cleaner and Insect Remover.

Opel Cleaning Solvent and Antifreeze is suitable for de-icing windows.

For mechanical removal of ice, use a commercially available sharp-edged ice scraper. Press the scraper firmly against the glass so that no dirt can get under it and scratch the glass.

Windscreen wiper blades

Wax such as the wax used in car washes can cause smearing on the windscreen when the windscreen wipers are switched on.

Smearing wiper blades can be cleaned with a soft cloth and Opel Cleaning Solvent and Antifreeze, and replaced if necessary – see page 157.

Locks

The locks are lubricated with a high-grade lock cylinder grease at the factory. Opel Lock Cylinder Grease prevents the locks from freezing up. Only use de-icing agents in emergencies, as they have a degreasing effect and will impair the function of the locks. After using a de-icing agent, have the locks re-greased by a workshop.

Engine compartment

Areas of the engine compartment that are painted in the same colour as the vehicle must be looked after like any other painted surface.

It is advisable to wash the engine compartment before and after winter and preserve it with wax. Cover alternator and brake/clutch fluid reservoir with plastic sheets before washing the engine.

When washing the engine with a steam-jet cleaner, do not direct the steam-jet at components of the Anti-lock Brake System (ABS), air conditioning system, climate control system or the belt drive and its components.

Protective wax that has been applied is also removed during the engine wash. For this reason, have the engine, brake system components in the engine compartment, axle components with steering, body parts and cavities thoroughly preserved by a workshop using protective wax.

An engine wash can be performed in the spring in order to remove dirt that has adhered to the engine compartment, which may also have a high salt content. Check protective wax layer and make good if necessary.

Do not use high-pressure jet cleaners.

Underbody

Your vehicle has a durable protective coating in the wheel arches (including the longitudinal members), which provides permanent protection and needs no special maintenance.

On vehicles which are washed frequently in automatic car washes with underbody washing facility, the protective coating may be impaired by dirt-dissolving additives, so check the underbody after washing and have it waxed if necessary. Before the start of the cold weather season, check the coating and, if necessary, have it restored to perfect condition.

Caution – commercially available bitumen/rubber materials can damage the coating. We recommend that you have underbody work carried out by a workshop, who knows the prescribed materials and has experience in the use thereof.

The underbody should be washed following the end of the cold weather season to remove any dirt adhering to the underbody since this may also contain salt. Check protective wax coating and, if necessary, have it restored to perfect condition.

Service, maintenance

European service schedule	166
International service schedule.....	168
Additional servicing.	170
Recommended fluids, and lubricants	170

European service intervals

Main Service

Due every 30,000 km (20,000 miles) or 1 year, whichever occurs first.

International service intervals

Interim Service

Due every 15,000 km (10,000 miles).

Main Service

Due every 30,000 km (20,000 miles) or 1 year, whichever occurs first.

Engine oil life monitor - see pages 63, 69, 151.

Confirmations

Confirmation of Service is recorded in the spaces provided in the Service and Warranty Booklet. The date and kilometre/mileage reading is completed with the stamp and signature of the Servicing Workshop.

Make sure that the Service and Warranty Booklet is completed correctly as continuous proof of service is essential if any warranty or goodwill claims are to be met, and is also a benefit when you come to sell the vehicle.

Service plan

The European service schedule is valid for the following countries:

Andorra, Austria, Belgium, Cyprus, Czech Republic, Denmark, Estonia, Finland, France, Germany, Greece, Greenland, Hungary, Iceland, Ireland, Italy, Latvia, Lithuania, Luxembourg, Malta, The Netherlands, Norway, Poland, Portugal, Slovakia, Slovenia, Spain, Sweden, Switzerland, United Kingdom.

For all remaining countries the International service schedule applies.

European service schedule

(Opel GT - Z 20 NHH)

Service operations	by year ¹⁾	1	2	3	4	5	6
	km (x 1000) ¹⁾	30	60	90	120	150	180
	miles (x 1000) ¹⁾	20	40	60	80	100	120
Controls, lighting, signalling equipment and airbags: visual check steering lock and ignition lock: check		x	x	x	x	x	x
Remote control batteries: replace		Every 2 years					
Windscreen wipers, windscreen washer system: check, correct		x	x	x	x	x	x
Coolant level and antifreeze: check, correct Hoses: check for tightness and secure seating		x	x	x	x	x	x
Brake fluid level: check, correct		x		x		x	
Battery terminals: check for secure connections and battery eye		x	x	x	x	x	x
Pollen filter: replace			x		x		x
● More often for when dust, sand or pollen is in the air		Agreement with customer					
Air cleaner element: replace		Every 4 years/60 000 km/40 000 miles					
⊕ Spark plugs: replace		Every 4 years/60 000 km/40 000 miles					
Ribbed V-belt: visual check			x		x		x
⊕ Replace		Every 10 years/150 000 km/100 000 miles					
Power steering system: check for leaks. Fluid level: check, correct		x	x	x	x	x	x
Engine oil and oil filter: replace ²⁾		x	x	x	x	x	x
Parking brake: check and adjust Wheel mounting and suspension front and rear, brake lines, brake pressure hoses, fuel lines and exhaust system: visual check			x		x		x

¹⁾ Whichever occurs first.

²⁾ Engine oil life monitor may indicate an earlier engine oil and oil filter change is necessary. See pages 63, 69, 151.

⊕ Additional operations.

● Under extreme operating conditions and if required by country-specific conditions, the intervals are reduced.

Service operations	by year ¹⁾					
	1	2	3	4	5	6
	km (x 1000) ¹⁾	60	90	120	150	180
	30	60	90	120	150	180
	miles (x 1000) ¹⁾	40	60	80	100	120
Corrosion protection: check and record in Service and Warranty Booklet	Annually					
Front and rear wheel brakes: check visually		x		x		x
●⊕ Annual service check if annual mileage exceeds 20 000 km	Annually					
Engine, transmission, A/C compressor: check for leaks	x	x	x	x	x	x
Steering system boots, track rods, final drive: visual check	x	x	x	x	x	x
Track rod end and supporting ball joint: check	x	x	x	x	x	x
⊕ Brake and clutch fluid: change	Every 2 years					
Wheel fastening: loosen and tighten to torque Tyre condition and pressures: check, correct	x	x	x	x	x	x
⊕ Annual service check if annual mileage exceeds 20 000 km	Annually					
First aid kit, tyre repair kit and lashing eyes: visual check	Every 2 years					
Headlamp aiming: check, adjust		x		x		x
Door hinges, door stop, lock cylinder, lock striker, bonnet catch, tailgate hinges and check links: lubricate		x		x		x
●⊕ Folding roof: lubricate (in dusty conditions)	x	x	x	x	x	x
Test drive, final check Service interval display and oil life monitor: reset - if applicable	x	x	x	x	x	x

¹⁾ Whichever occurs first.

⊕ Additional operations.

● Under extreme operating conditions and if required by country-specific conditions, the intervals are reduced.

International service schedule

(Opel GT - Z 20 NHH)

Service operations	by year ¹⁾					
	15 km (x 1000) ¹⁾ 10 miles (x 1000) ¹⁾	30 20	45 30	60 40	75 50	90 60
Controls, lighting, signalling equipment and airbags: visual check steering lock and ignition lock: check	x	x	x	x	x	x
Remote control batteries: replace	Every 2 years					
Windscreen wipers, windscreen washer system: check, correct	x	x	x	x	x	x
Coolant level and antifreeze: check, correct Hoses: check for tightness and secure seating	Annually					
Brake fluid level: check, correct		x				x
Battery terminals: check for secure connections and battery eye	Annually					
Pollen filter: replace	Every 2 years/60 000 km/40 000 miles					
● More often for when dust, sand or pollen is in the air	Annually/15 000 km/10 000 miles					
Air cleaner element: replace	Every 4 years/60 000 km/40 000 miles					
● More often for when dust or sand is in the air	Annually/15 000 km/10 000 miles					
⊕ Spark plugs: replace	Every 4 years/60 000 km/40 000 miles					
Ribbed V-belt: visual check	Every 2 years/60 000 km/40 000 miles					
⊕ Replace	Every 10 years/150 000 km/100 000 miles					
Power steering system: check for leaks. Fluid level: check, correct	Annually					
Engine oil and oil filter: replace ²⁾	x	x	x	x	x	x
Parking brake: check and adjust Wheel mounting and suspension front and rear, brake lines, brake pressure hoses, fuel lines and exhaust system: visual check	Every 2 years/60 000 km/40 000 miles					

¹⁾ Whichever occurs first.²⁾ Engine oil life monitor may indicate an earlier engine oil and oil filter change is necessary. See pages 63, 69, 151.

⊕ Additional operations.

● Under extreme operating conditions and if required by country-specific conditions, the intervals are reduced.

Service operations	by year ¹⁾					
	15	30	45	60	75	90
	km (x 1000) ¹⁾					
	miles (x 1000) ¹⁾					
Corrosion protection: check and record in Service and Warranty Booklet	Annually					
Front and rear wheel brakes: check visually	Every 2 years/60 000 km/40 000 miles					
●⊕ Annual service check if annual mileage exceeds 20 000 km	Annually					
Engine, transmission, A/C compressor: check for leaks	Annually					
Steering system boots, track rods, final drive: visual check	Annually					
Track rod end and supporting ball joint: check	Annually					
⊕ Brake and clutch fluid: change	Every 2 years					
Wheel fastening: loosen and tighten to torque Tyre condition and pressures: check, correct	Every 2 years/60 000 km/40 000 miles					
⊕ Annual service check if annual mileage exceeds 20 000 km	Annually					
First aid kit, tyre repair kit and lashing eyes: visual check	Every 2 years					
Headlamp aiming: check, adjust	Every 2 years/60 000 km/40 000 miles					
Door hinges, door stop, lock cylinder, lock striker, bonnet catch, tailgate hinges and check links: lubricate	Every 2 years/60 000 km/40 000 miles					
●⊕ Folding roof: lubricate (in dusty conditions)	Annually					
Test drive, final check	x	x	x	x	x	x
Service interval display and oil life monitor: reset - if applicable						

¹⁾ Whichever occurs first.

⊕ Additional operations.

● Under extreme operating conditions and if required by country-specific conditions, the intervals are reduced.

Additional servicing

Additional operations ⊕

Additional work is work that is not required every service but can be performed in conjunction with a regular service.

Time allowances for such work are not included in the scope of regular services and will be charged for additionally. It is more economic if these operations are performed as part of a scheduled service than having them performed separately.

Severe operating conditions ●

Operating conditions are classified as severe when one or more of the following occurs frequently:

- cold starts,
- stop and go,
- trailer/caravan towing,
- gradients and/or high altitudes,
- poor road surfaces,
- sand and dust,
- extreme temperature fluctuations.

Police vehicles, taxis and driving school vehicles are also classified as operating under severe conditions.

Under severe operating conditions, it may be necessary to have certain scheduled service work done more frequently than the scheduled intervals.

For example, if fuel is used that does not comply with required standards, the fuel filter may need more frequent draining or replacement and it may also be necessary to change other components more often (e.g. spark plugs).

It is recommended to seek technical advice on the servicing requirements dependent on the specific operating conditions of your vehicle.

Recommended fluids, and lubricants

Only use products that have been tested and approved. Damage resulting from the use of non-approved materials will not be covered by the warranty.

Warning

Operating materials are hazardous and must be handled with the appropriate level of care. If consumed, seek medical attention immediately. Do not inhale fumes and avoid skin contact. Keep out of reach of children. Do not allow operating materials to contaminate the sewage system, surface water, ground water or soil. Dispose of empty containers properly. Always bear in mind that operating materials are hazardous to your health.

Checking and topping up fluids

see page 152.

Engine oil

Engine oil is identified by its quality and also its viscosity. Quality is more important than viscosity when selecting which engine oil to use.

Engine oil quality

European specifications

GM-LL-A-025: Petrol engines

GM	General Motors Europe
LL	Longlife
A	Engine oil quality specification
025	Validity index

Opel engine oil meets classification GM-LL-A-025 and is therefore suitable for petrol engines.

International specifications

ACEA-A3: Petrol engines

The above specification is valid only if the service interval is reduced to that shown for the international service schedule - see page 165.

Topping up engine oil

Oils of different manufacturers and brands can be mixed as long as you comply with the specified engine oil criteria (quality and viscosity).

Not every engine oil available on the market meets the quality requirements, always check the required specification and rating is marked on the container.

If engine oil of the required quality is not available, a maximum of 1 litre of ACEA A3/B4 or A3/B3 grade may be used (only once between each oil change). The viscosity should be of the correct rating.


Use of ACEA A1/B1 and A5/B5 engine oil is expressly forbidden, since they can cause long-term engine damage under certain operating conditions.

Engine oil additives

The use of engine oil additives could cause damage and invalidate the warranty.

Engine oil viscosity

SAE 0W-30, 0W-40, 5W-30 or 5W-40



S 17639

The SAE viscosity rating defines the ability of an oil to flow. When cold, oil is more viscous than when hot.

Multigrade oil is indicated by two figures. The first figure, followed by a W, indicates low temperature viscosity and the second figure the high temperature viscosity.

Coolant and antifreeze

Use antifreeze of recommended specification: silicate-free LLC (Long Life Coolant).

The system is factory-filled with coolant designed for frost protection down to approx. -28 °C. This concentration should be maintained all year-round.

Coolant additives intended to give additional corrosion protection or seal against minor leaks can cause function problems. Liability for consequences resulting from the use of coolant additives will be rejected.

Brake and clutch fluid

Only use DOT3 or DOT4 brake fluid.

Warning

Brake fluid is poisonous!

Over time, brake fluid absorbs moisture which will reduce braking effectiveness. The brake fluid should therefore be replaced at the specified interval.

Brake fluid should be stored in a sealed container to avoid water absorption.


Ensure it does not become contaminated with fluids containing mineral oil (oil, petrol, cleaner) as this can damage the seals and sleeves of the brake system.

Warning

Due to its corrosive nature, it must not come in contact with the paintwork. Flush any escaped brake fluid with plenty of water.

Technical data

Vehicle documents, identification plate.....	172
Vehicle identification data.....	173
Coolant, oils, brake/clutch fluid.....	174
Engine data.....	175
Performance.....	176
Fuel consumption, CO ₂ emissions.....	177
Weights, payload and roof load.....	178
Tyres.....	179
Electrical system.....	181
Capacities.....	182
Dimensions.....	183



Vehicle documents, identification plate

The technical data is determined in accordance with European Community standards. We reserve the right to make modifications. Specifications in the vehicle documents always have priority over those given in this manual.

The vehicle identification number (VIN) is stamped on a plate and is affixed to the instrument panel on the driver's side, visible through the windscreen.




Information on visible VIN plate:

1. Country of origin
2. Manufacturer
3. Make
4. Carline/Series
5. Body style
6. Restraint system
7. Engine type
8. Check digit
9. Model year
10. Plant location
11. Plant sequence number



S 14712

Engine identification: etched into the engine oil filter housing on the cylinder block.




S 14713

The VIN and axle loading information label is located on the B-pillar, visible with the driver's door open.

Information on label:

1. Manufacturer
2. Type approval number
3. Vehicle identification number
4. Gross vehicle weight rating
5. Permissible gross train weight
6. Maximum permissible front axle load
7. Maximum permissible rear axle load



S 14735

Vehicle identification data

The tyre and loading information label is located on the B-pillar, visible with the driver's door open. See page 126.

Information on label:

- Specified occupant seating positions
- Maximum vehicle capacity weight
- Vehicle identification number (VIN)
- Tyre pressure, front and rear
- Original equipment tyre size



§ 14171

The service parts identification label is located in the glove compartment.

Information on label:

- Vehicle option code
- Vehicle identification number (VIN)
- Engineering model number
(vehicle division, line and body style)
- Interior trim level and decor
- Exterior (paint colour) WA number
- Paint technology
- Special order paint colours and numbers

Coolant, oils, brake/clutch fluid

Use approved fluids only.

Use of unsuitable fluids could cause serious damage to the vehicle.

Engine oils

Information on engine oils is available on page 170.

Engine data

Sales designation	2.0 Turbo
Engine stamp	LNf
Engine identifier code	Z 20 NHH
Number of cylinders	4
Bore dia. (mm)	86
Stroke (mm)	86
Piston displacement (cm ³)	1998
Engine power (kW) at rpm	194 5300
Torque (Nm) at rpm	353 2500-5000
Compression ratio	9.2 : 1
Fuel type ¹⁾	Petrol
Octane requirement (RON) ²⁾³⁾ unleaded or unleaded	95 (S) 98 (SP)
Max. permissible engine speed, continuous (rpm) approx.	6300
Oil consumption (l/1000 km)	0.6

¹⁾ Standard high-quality fuels, unleaded DIN EN 228.

²⁾ Standard high-quality fuels: S = Super (Premium), SP = Super Plus (Premium Plus); value printed in bold: recommended fuel.

³⁾ Knock control system automatically adjusts ignition timing according to type of fuel used (octane number).

176 Technical data

Performance

(approx. km/h / mph)

Engine¹⁾

Z 20 NHH

Maximum speed²⁾

Manual transmission

229/142

¹⁾ Sales designation – see page 175.

²⁾ The maximum speed indicated is achievable at kerb weight. Optional equipment could reduce the specified maximum speed of the vehicle.

Fuel consumption, CO₂ emissions

Directive 80/1268/EEC (last changed by 2004/3/EG) has applied for the measurement of fuel consumption since 1996.

The directive is oriented to a actual driving practices: Urban driving is rated at approx. $\frac{1}{3}$ and off-road driving with approx. $\frac{2}{3}$ (urban and extra-urban consumption). Cold starts and acceleration phases are also taken into consideration.

The specification of CO₂ emission is also a constituent of the directive.

The figures given must not be taken as a guarantee for the actual fuel consumption of a particular vehicle.

All values are based on the EU base model with standard equipment.

The calculation of fuel consumption as specified by directive 2004/3/EG takes account of the vehicle's kerb weight, ascertained in accordance with these regulations. Optional extras may result in slightly higher fuel consumption and CO₂ emission levels than those quoted.

To convert l/100 km into mpg, divide 282 by number of litres/100 km.

Saving fuel, protecting the environment – see page 112.

Fuel consumption (approx. l/100 km), CO₂ emission (approx. g/km)

Engine ¹⁾	Z 20 NHH
Manual transmission	
urban	13.0
extra-urban	6.9
total	9.2
CO ₂	218

¹⁾ Sales designation – see page 175.

Tyres

Restrictions

Tyres of size 245/45 R 18 may only be used.

Goodyear Eagle F1 GS-2 P 245/45 R 18 96 W and Bridgestone Potenza RE050A 245/45 R 18 100 W are recommended for this vehicle. These tyres have undergone special tests to establish their reliability, safety and specific suitability for Opel vehicles.

Not all tyres available on the market currently meet the structural requirements. Seek the assistance of a workshop concerning suitable tyre makes.

Despite continuous market monitoring, we are unable to assess these attributes for other tyres, even if they have been granted approval by the relevant authorities or in some other form.

Further information – see page 125.

Winter tyres ❄

Tyres of size 245/45 R 18 are permitted for use as winter tyres.

Use only specified winter tyres released for your vehicle. Seek the assistance of a workshop.

Further information – see page 129.

Tyre chains ❄

Restrictions

Tyre chains may be used on the rear wheels only.

We recommend the use of Opel-tested fine-mesh tyre chains that add no more than 11 mm to the tyre tread and the inboard sides (including chain lock).

Further information – see page 129.

Wheels

Wheel bolt tightening torque: 140 Nm.

Tyre pressure in kPa/bar

The specified tyre pressures are valid for cold tyres. The increased tyre pressure resulting from extensive driving must not be reduced. The tyre pressures specified in the following table apply to both summer and winter tyres.

Further information – see pages 125 to 129.

Engine ¹⁾	Tyres	Tyre pressure with full load	
		Front	Rear
Z 20 NHH	245/45 R 18	200/2.0	200/2.0

¹⁾ Sales designation – see page 175.

Electrical system

Battery	Voltage	12 Volt
	Amp hours	60 Ah
Battery for remote control		CR 20 32

182 Technical data

Capacities

(approx. litres)

Engine ¹⁾	Z 20 NHH
Engine coolant	9.0
Fuel tank (nominal content)	52.0
Engine oil with filter change between MIN and MAX on dipstick	4.7 1.0
Washer fluid reservoir for windscreen washer system	4.5

¹⁾ Sales designation – see page 175.

Dimensions

Overall length (mm)	4100
Overall width (mm)	1813
Overall width including exterior mirrors (mm)	1846
Overall height with soft top raised (mm)	1276
Wheelbase (mm)	2415
Track width (mm):	
Front	1543
Rear	1561
Turning circle diameter, kerb to kerb (m)	10.5

Index

A

ABS (Anti-lock Brake System)	124
Accessories	152
Accessory socket	54
Air conditioning system	107
Air intake	109
Air re-circulation system	107
Air vents	102
Airbags	39, 45
Alternator	58
Antenna	101, 161
Antifreeze	154, 155, 171
Antifreeze protection	154, 158
Anti-knock quality of fuel	114
Octane number	175
Anti-theft protection	9, 17
Aqua planing	128
Ashtrays	53
Auto light control	73
Automatic locking	25
Automatic unlocking	25

B

Battery	111, 159, 181
Interruption of power supply	23
Battery discharge protection	77
Before starting-off	16
Belt force limiters	40
Belt tensioners	41
Bonnet	130
Brake assist	123
Brake fluid	171
Brakes	
ABS	124
Brake assist	123
Brake fluid	156
Brake lamps	149
Brake servo unit	110
Control indicator	56
Foot brake	123
Hand brake	124
Bulb replacement	146
Bulbs	146

C

Capacities	182
Car dimensions	183
Car Pass	21
Care	161
Catalytic converter	116, 118, 131
Central locking system	6, 24
Centre high-mounted stop lamp	150
Bulb replacement	150
Changing the battery	
Remote control	23, 181
Changing tyre/wheel type	125
Changing wheels	135
Chassis number	
see vehicle identification number	172
Check control	20, 68
Child restraint systems	44
Cigarette lighter	53, 77
Climate control	102
Clutch fluid	156
Clutch operation	111
CO ₂ emissions	177
Cold start	111
Competitive mode	20, 120
Console box	51

Control indicators	12, 55
ABS (Anti-lock Brake System)	55, 125
Airbag systems	47, 57
Alternator	58
Belt tensioners	41, 57
Brake system	56, 124
Clutch system	56
Coolant temperature	57, 156
Driver's seat belt	57
Engine oil pressure	57
ESC (Electronic	
Stability Control)	58, 119
ESP (Electronic	
Stability Program)	58, 119
Exhaust	56, 117
Fog tail lamp	55, 75
Front fog lamps	58, 75
High beam	56
Immobiliser	22, 58
Luggage compartment open	55
Passenger's seat belt	43
Seat occupancy recognition	48
Turn signals	56
Coolant	154, 171
Coolant level	155
Coolant temperature	156
Cooling	107
Corrosion protection	151, 163, 171
Courtesy lamps	76
Bulb replacement	150
Cruise control	121

D

Dashboard - see Instrument panel	10
Data	21, 172
Decommissioning	160
Delayed locking	24, 66
Demisting and defrosting	16, 106
Dimensions	183
Display	59
Display instruments	58
Door locks	6, 26, 164
Drive control systems	118
Driver information centre	19, 59
Driver's seat belt warning device	43, 57
Driving abroad	114
Headlamps	77
Driving hints	110

E

Economical driving	112
Electric windows	30
Electrical system	141, 159, 160, 181
Electronic components	160
Electronic immobiliser	21
Electronic Stability Control (ESC)	118
Electronic Stability Program (ESP)	118
Emergency luggage compartment release handle	27
Engine code	173, 175
Engine oil	153, 170
Additives	171
Topping up	170
Viscosity	171
Engine oil change	154
Engine oil level and consumption	153
Engine oil life monitor	63, 151
Engine oil pressure	57
Engine speed	111
Engine wash	164
Entry lighting	76
Environmental protection	154, 161
ESC (Electronic Stability Control)	118
ESP (Electronic Stability Program)	118
Exhaust control indicator	117
Exhaust gases	117
Exhaust system	116
Exterior mirrors	8, 29

F

Fan	104, 152
Filling station	
Capacities	182
Engine oil level	153
Fuel	114, 175
Opening the bonnet	130
Tyre pressure	113, 180
Vehicle data	173
Windscreen washer system	158
First-aid kit	53, 135
Flat tyre	135, 136
Fog tail lamp	13, 75
Bulb replacement	149
Folding backrests	39
Foot brake	123
Front fog lamps	13, 75
Bulb replacement	148
Fuel	114, 175
Fuel consumption	112, 114, 177
Fuel filler cap	114
Fuel gauge	59
Fuel level	59
Fuse extractor	142
Fuses	143

G

Gears	16
Generator - see Alternator	58
Glove compartment	51
Gross vehicle weight	178

H

Halogen headlamp system	146
Hand brake	17, 124
Hazard warning lamps	14, 75
Head restraints	38
Headlamp aiming	146
Headlamp flash	13, 74
Headlamp switch	13, 73
Headlamps	13
Bulb replacement	146
Driving abroad	77
Reversing lamp	75
Warning device	71
Heated rear window	15, 103
Heating	102, 105
Height adjustment	
Seat	7, 38
Steering wheel	9
High beam	13, 73, 74
Bulb replacement	147
Control indicator	56
High-pressure jet cleaners	163, 164
Horn	14

I

Identification plate	172
Ignition switch	9
Ignition system	152, 159
Immobiliser	21
Indicators	14, 74
Bulb replacement	148, 149
Information display	19, 60
Infotainment system	78
Inspection system	151
Instrument illumination	76
Bulb replacement	150
Instrument panel	10
Instruments	55
Interior and upholstery	163
Interior mirror	8, 29

J

Jacking the vehicle	135
Jump leads	132
Jump start terminals	133

K

Keys	21
Ignition lock	9
Locking doors	24
Remove	17
Starting the engine	9, 17

L

Language selection	67
Leather trim	163
License plate	160
License plate lamps	150
Bulb replacement	150
Lighting	13, 73
Driving abroad	77
Loading	50, 178
Locking doors	6, 24
Locks	164
Low beam	13, 73
Bulb replacement	147
Lubricants	152, 153, 174
Luggage compartment	6, 26
Closing	28
Lighting	77
Loading	50, 178
Opening	26, 27
Release button	27
Luggage compartment lamp Bulb replacement	150

M

Maintenance	99
Air conditioning	109
Antifreeze protection	155
Brake fluid	156
Brakes	122
Catalytic converter	118
Clutch fluid	156
Engine oil	153
Fuel consumption	113
Tyre pressure	126
Tyres	127, 128
Windscreen wipers	157
Manual transmission - see Transmission	16
Mirrors	8, 29
Misted windows	16, 106
Mobile telephone	101

N

Neutral, transmission	16
-----------------------------	----

O

Octane numbers	114, 175
Odometer	60
Oil	170
Additives	171
Topping up	170
Viscosity	171
Oil change	154
Oil level and consumption	153
Oil life monitor	63, 151
Oil pressure	57
Oils	153
Opel genuine parts and accessories	152
Opel Service	165
Operating temperature	111
Outside temperature	60
Overrun	111

P

Paintwork damage	35, 163
Panic alarm	28
Parking	17
Parking lamps	13, 73
Bulb replacement	148
Parking the vehicle	17
Parts	152
Passenger's airbag	45
Passenger's seat belt warning device ...	43
Pedals	111
Performance	176
Personalisation mode	64
Petrol	114, 175, 177
Pinking	114
Power outlets	53
Power steering	110
Fluid	157
Protection of electronic components ...	159
Pushing, towing	131

R

Radio	86, 101
Radio equipment (CB)	101
Radio reception	101
Reading lamps	76
Rear lamp cluster	73
Bulb replacement	149
Rear window heating	15, 103
Recommissioning	160
Refuelling	114
Fuel filler cap	114, 115
Remote control	22
Battery changing	23
Central locking system	6, 24
Luggage compartment	6, 26
Panic alarm	28
Steering wheel	19
Vehicle locator	28
Replacement keys	21
Reversing lamp	75
Bulb replacement	149
Running-in	110
Brakes	122

S

Safeguard against unauthorised use	9, 18
Safety	152
Saving energy	112
Seat adjustment	7, 37
Seat belts	8, 40, 42, 163
Driver's seat belt warning device	43
Passenger's seat belt warning device	43
Seat occupancy recognition	48
Seat position	38
Seats	7, 37
Self-diagnosis	41, 47, 119, 125
Self-help	130
Remote control	23
Service intervals	165, 166
Additional operations	170
Interim service	165
Main service	165
Severe operating conditions	170
Service work	151
Side repeater lamps	
Bulb replacement	150
Signal system	14, 74
Silencer, see Exhaust system	116
Soft top	31
Lowering	31
Raising	33
Soft top care	162
Spare fuses	141
Spare keys	21

Speed	112, 113
Fuel consumption	112
Speedometer	59
Starting the engine	9, 17, 21, 131
Self-help	131
Steam jet cleaners	163, 164
Steering column lock	9, 17
Steering wheel adjustment	9
Steering wheel remote control	19, 79, 81
Storage	50
Stowage compartments	51
Sun visors	36

T

Tachometer	58
Tail lamps	73
Bulb replacement	149
Tank	114
Fuel gauge	59
Technical data	172
Telephone - see Mobile telephone	101
Temperature regulation	104
The first 1000 km	110
Tightening torque	179
Tools	135
Towing service	134
Towing the vehicle	134
Traction control	119
Transmission, manual	16
Tread depth	127
Trip odometer	61
Turn signals	14, 74
Bulb replacement	45, 148, 149
Tyre chains	129, 179
Tyre condition	127
Tyre pressure	126, 180
Tyre repair kit	136

U

- Units of measurement65
- Unleaded fuel 114, 116, 175
- Used oil 154

V

- Vehicle care 161
- Vehicle decommissioning 160
- Vehicle dimensions 183
- Vehicle identification number 172
- Vehicle keys - see Keys21
- Vehicle locator28
- Vehicle recommissioning 160
- Vehicle storage 160
- Vehicle tools 135
- Ventilation102, 105

W

- Warning buzzers 71
- Warning messages20, 60, 68
- Warning triangle 53, 135
- Washer bottle, windscreen washer system 158
- Weights 178
- Welcome light function 67
- Wheels 125, 179
- Wheels, tyres 125
- Windows
 - Demisting and defrosting 16, 106
- Windscreen washer system15, 72, 158
 - Antifreeze protection 158
 - Capacities 182
 - Washer bottle 158
- Windscreen wipers 15, 71, 157
- Winter operation
 - Battery 111
 - Coolant, antifreeze 155
 - Fuel consumption 113
 - Heating 102, 105
 - Locks 164
 - Tyre chains129, 179
 - Window demisting and defrosting 16, 106
 - Windscreen washer system, antifreeze protection 158
- Winter tyres 129, 179