
GALLOPER II

GALLOPER II

OWNER'S MANUAL

FOREWORD

Thank you for choosing Hyundai. We are pleased to welcome you to the growing number of discriminating people who drive Hyundai vehicles. The advanced engineering and high-quality construction of each Hyundai is something of which we're very proud.

Your Owner's Manual will introduce you to the features and operation of your car. It is suggested that you read it carefully since the information it contains can contribute greatly to the satisfaction you receive from your new car.

The manufacturer also recommends that all service and maintenance on your car be performed by an authorized Hyundai dealer. Hyundai dealers are prepared to provide high-quality service, maintenance and other assistance that may be required.

Hyundai reserves the right to make changes in design and specifications and/or to make additions or improvements in its products without obligation to install them on products previously manufactured. It is an absolute requirement for the driver to strictly observe all laws and regulations concerning vehicles.

This manual has been written in compliance with such laws and regulations, but some of the contents may become contradictory with later amendment of the laws and regulations.

HYUNDAI MOTOR COMPANY


NOTE: Because future owners will also need the information included in this manual, if you sell this Hyundai, please leave the manual in the vehicle for their use. Thank you.

Copyright 1992 HYUNDAI MOTOR COMPANY. All rights reserved. The material in this publication may not be reproduced in any form without written permission from HYUNDAI MOTOR COMPANY.

Table of contents


▪ Instruments and controls	2
▪ Safety precautions and driving tips	5
▪ Instruments.....	17
▪ Switches.....	27
▪ Key-locking and unlocking.....	35
▪ Interior equipment.....	41
▪ For pleasant driving	61
▪ Starting and driving	93
▪ Vehicle care	109
▪ During cold weather.....	115
▪ Do it yourself	119
▪ Emergency measures	133
▪ Things you should know	151
▪ Service data	153

Instruments and controls (without airbag)



* Indication of applicability:
Optional equipment marked with an asterisk may differ according to the country it is sold in or the sales classification; refer to the sales catalogue.

Instruments and controls (with airbag)*



Indication of optional items

Optional equipment marked with an asterisk may differ according to the country it is sold in or the sales classification. Refer to the sales catalogue.

MEMO

Safety precautions and driving tips

- Ignition switch
 - Carrying children
 - Seat and seat belt
 - Loading
 - Automatic transmission*
 - Brake system
 - Anti-lock brake system*
 - Parking
 - Power steering system
 - Turbocharger (diesel-powered vehicles)
 - Catalytic converter
(gasoline-powered vehicles)
 - Economical driving
 - Fuel usage (gasoline-powered vehicles)
 - Limited slip differential*
-
-
-

Ignition switch



(1) If the key is accidentally removed while driving, the steering wheel will lock, making it impossible to control the vehicle.




- (2) If the engine is stopped while driving, the brake servo mechanism will cease to function so the braking efficiency will deteriorate.



- (3) If the engine is stopped while driving power steering system will fail function and it will require more manual power to operate the steering wheel.

Carrying children




- (1) Never leave a child in the vehicle unattended.
- (2) If a child is seated alone in the rear seat, use the child protection system.



-
- (1) Be careful of children's fingers when operating electric windows

Seat and seat belt



- (1) Never adjust the driver's seat while the vehicle is in motion.
Adjusting the seat while driving could cause the driver to lose control of the vehicle.
- (2) Do not pile luggage or cargo high on the seatbacks for your safety.
- (3) For technical reasons, the second seat and minivan should not be folded down to make a bed while the vehicle is being driven.

- (4) To protect you and your passengers in the event of an accident, it is most important that the seat belts be worn correctly when you drive.
- (5) The seat belt will provide maximum protection for its wearer. The shoulder belt should be placed in its most upright position. When the seatback is reclined there is greater risk that the passenger will slide under the belt, especially in a forward impact accident, and may be injured by the belt or by striking the inside head panel or seatbacks.

Loading

Loading should not be to the point at which the Maximum Gross Vehicle weight, Maximum Front Axle Weight or Maximum Rear Axle Weight is exceeded.

Please attention to the following in order to maintain good driving characteristics:

- (1) Secure loaded goods properly to keep them from breaking or flying off when the vehicle makes a sudden stop or turn.
- (2) Always close the truck door securely when driving to keep exhaust gases from entering the vehicle.
- (3) Center loads can be stowed as closely as possible. Place big items to the side of rear well unless a vehicle might.
- (4) Be cautious to keep loads from bouncing or shifting toward the rear window to avoid damage to rear window bolt nuts.

Automatic transmission*




- (1) Before shifting a gear with the engine running and the vehicle stationary, fully depress the brake pedal to prevent the vehicle from creeping.
→ Since the vehicle will begin to move as soon as the gear is engaged, especially when the engine speed is around fast idle or the air conditioner is operating, the brakes should be released only when you are ready to drive away.
- (2) Depress the brake pedal with the right foot at all times. Using left foot could cause driver moment delay in sudden maneuver in case of an emergency.

- (3) To prevent sudden acceleration, never race the engine when shifting from the 'P' or 'N'.
- (4) Operate the accelerator pedal while the vehicle that is resting on the brake pedal will affect braking efficiency and may cause premature wear of brake pads.
Do not race the engine with brake pedal pressed. This can damage the transmission.

Brake system

All the parts of the brake system are important to safety. Have the vehicle serviced by a GM/GPEF dealer at regular intervals according to the service standards.



- The service brake is divided into two brake circuits so that when one brake circuit fails, the other is available to stop the vehicle. If this occurs, however, the brake pedal must be depressed further than usual; slow driving as soon as possible and have the brake system serviced at the nearest SAAB-SCANDIA dealer.

- Do not leave any objects or place a mark that might surround the brake pedal, doing so could prevent the full pedal stroke; this would be necessary in an emergency. Make sure that the pedal can be operated freely at all times.

- If the vehicle is equipped with a brake warning lamp, the lamp will light up if the brake fluid level is abnormally low.


- If the vehicle is equipped with a brake booster, the main housing becomes hot after the brake pedal is depressed once or twice while the engine is off. This occurs, the brake will require greater force than usual.

This is especially important when the vehicle is being towed. On diesel powered vehicles, the brake booster will no longer function if the V belt is broken. In this case, use engine braking (downshifting) to reduce the speed of the vehicle and then depress the brake pedal with more force than usual to stop the vehicle in a safe place.

- Check the brake system while driving at a low speed immediately after starting the engine, that it works normally. A film of water can form on the roads, thus preventing normal functioning. After driving in heavy rain or through large puddles, or after the vehicle is washed, if necessary, repeatedly tap the brake pedal lightly while driving or dry out the brakes.



00-00005



0000-000

- It is important to take advantage of the braking power of the engine by shifting to a lower gear while driving on steep downhill roads in order to prevent the brakes from overheating.

- With new brake pads or linings, if possible, avoid applying the master cylinder during the first 200km(124 miles) of driving.

- 8. Operating conditions and driving habits**
will affect the need of the guide strings.
In some cases, therefore, it may be necessary to have the assistance of the guide
strings provided by a GM ABS. This is an
optional component that comes at the
Service Factory, especially, at additional
charge. This option is especially to
people who drive mostly in the city or
ice and snow areas, as well as in areas
where there is some traffic, e.g., in S.

Anti-lock brake system*

(ABS)

When the brakes are applied on a moving
vehicle, excessive braking on the wheel
can cause the wheel to lock. On the road surface
material, where the vehicle skids, the friction force
between the braking force will be reduced and the
braking distance increased, and the vehicle
can run sideways and get into a spin with the driver losing control.
The ABS prevents the wheels from locking
during braking. It is maintaining directional
stability, ensuring controllability and providing
optimum braking force.

Driving hints



- (1) Even with the ABS, the steering wheel
must be turned during a hard braking (when
the ABS is active), otherwise sharply from
when the brakes are not being applied.
Be sure to operate the steering wheel
carefully.
- (2) Although the braking distance for ve-
hicles equipped with an ABS is generally
shorter than for those without, i.e.,
caution thus drive even with very
slipping on the road condition and other factors.
Maintain the same distance from
the vehicle in front as you do for a ve-
hicle not equipped with an ABS.

- (3) Also, because the braking distance on
gravel or snowy roads may be longer
than for a vehicle not equipped with an
ABS, these roads should be driven at
reduced speeds.

CAUTION

Even the ABS can not prevent the natural
laws of physics from acting on the
vehicle. It can not for instance avoid acci-
dents that maybe resulting from exces-
sive speed in turns, following another
vehicle too closely or aquaplaning. It
should remain driver's task with safety
precautions to judge speeds and brake
applications correctly in such conditions.

Parking



- (1) When parking, fully engage the parking brake, and then set the gearshift lever in 1st or reverse for vehicles with manual transmission and set the safety lever to 'L' position for vehicles with automatic transmission. Set the transfer shift lever to any position except 'N'; this is recommended. For additional safety, that wheel chocks also be used on a hill.
- (2) Do not keep the engine running for a long time in an enclosed or poorly ventilated place. Carbon monoxide gas is odorless and extremely poisonous and dangerous.
- (3) Because the exhaust system produces high temperatures, avoid parking in a place where there are inflammable objects such as dry grass, bags, etc.
- (4) Remove the key from the ignition switch when leaving the vehicle.

Power steering system



When the engine is stopped, the power steering system will not function and it will require more manual power to operate the steering wheel. Keep this in mind in particular when towing the vehicle. Never turn off the engine while driving. Periodically check the power steering fluid level.

Turbocharger

(diesel-powered vehicles)

If your vehicle is equipped with a turbocharger, do not stop the engine immediately after operating the vehicle at high speeds. Allow the engine to idle for about 30 seconds to 60 seconds or more to give the turbocharger's compressor time to cool down.


Driving out of mud

If one rear wheel gets stuck in the mud and starts spinning, try using the following method to drive the vehicle out of the mud:



1. Set the transfer shift lever to either '4H' or '4L' and use four-wheel drive to free the vehicle out of the mud.
2. If it is still not possible to extract the vehicle, pull the parking brake lever slightly to just barely engage the brake (be sure not to engage it all the way) and try driving again. Depress the accelerator gradually and don't forget to release the parking brake once the vehicle is out of the mud.

Catalytic converter (if installed) (gasoline-powered vehicles)




In normal use, there are no particular care requirements regarding handling except for the use of lead-free gasoline. Exhaust gas purification systems equipped with the catalytic converter are extremely effective in reducing noxious gases. The catalytic converter is situated in the exhaust gas system. Because it is a highly concentrated source of heat, the following points should be given attention to prevent safety

- Do not park the vehicle near flammable materials.
- Do not apply an undercut to the catalytic converter.

The catalytic converter reaches very high temperatures, and overheating may result in damage. One should be aware of the following points to prevent overheating from occurring due to faulty functioning of the catalytic converter:

- Do not turn off the engine with a warm engine.
- Never start the engine by starting the vehicle with the battery if weak or even the electrical system to start the engine.
- If engine trouble such as backfiring and misfire occurs during engine operation, please refer to the section "Fault diagnosis" of the manual. If the trouble continues, please contact your nearest GM or GM OPEL dealer for inspection.

Economical driving



For efficient driving, there are some basic requirements that have to be met. The prerequisite for low fuel consumption is a properly adjusted engine. In order to achieve longer life of the vehicle and to meet economic operation, have the vehicle maintained by a GELLOPER dealer at regular intervals in accordance with the service schedule. Fuel economy and cost savings at parking are highly influenced by personal driving habits as well as the car's operating conditions. The following points should be observed to prevent unnecessary wear of brakes, tyres and engine as well as to reduce environmental pollution.

(1) Starting


Any rapid acceleration and sudden starts, such as when starting from standstill, will result in more fuel consumption.

(2) Starting

Start only at an appropriate vehicle speed and engine rev. Always use the highest gear possible. When driving at high speed over long distances, fuel economy can suddenly poor and cause fuel loss. The transmission gears should be set to 24". In addition, for vehicles equipped with rear-wheel drive, the free-wheeling pins should be unlocked.

(3) Cruising

Fast and start-and-stop driving increases the average fuel consumption. Therefore, drive smoothly whenever possible. When driving on congested roads, avoid use of a low gear at high engine rpm.



(4) Idling

The vehicle consumes fuel even when idling. Avoid extended idling whenever possible.

(5) Speed

The higher the vehicle speed the more fuel is burned. Avoid driving at high speeds. Even a slight release of the accelerator pedal will save a significant amount of fuel.

(6) Tyre inflation pressure

Check the tyre inflation pressure strongly, as incorrect, low tire inflation pressures increase road resistance and fuel consumption. In addition, low tyre pressures adversely affect tire wear and driving control.

(7) Load

Do not drive with unnecessary articles in the luggage compartment. Especially during city driving where frequent starting and stopping is necessary, the increased weight of the vehicle will greatly affect fuel consumption. Also avoid driving with unnecessary luggage, etc., etc. In fact, the increased air resistance will cause more fuel consumption.


(8) Cold engine starting

Starting of a cold engine consumes extra fuel. Unnecessary fuel consumption is also caused by keeping a hot engine running. After the engine is started, begin driving soon.

**Fuel usage
(gasoline-powered vehicles)**

Unleaded gasoline only must be used in vehicles equipped with catalytic converter.

Limited-slip differential*



If the engine is started while one of the rear wheels is raised on a jack, the vehicle will move forward. Do not start the engine while the vehicle is raised on a jack. If, during four-wheel drive operation, two wheels on the same side of the vehicle rapidly spin and skid, become stuck in mud, snow etc., it may be possible to move the vehicle by depressing the accelerator pedal; however, in this condition the vehicle may immediately stop at high speeds and the limited-slip differential might be damaged.

CAUTION


All vehicles equipped with limited-slip differential must use specific rear differential oil.

MEMO


Instruments

Speedometer
Odometer
Tripmeter and reset button
Tachometer
Fuel gauge
Water temperature gauge
Thermometer*
Inclinometer*
Altimeter*
Indication and warning lamps


<TYPE 1>




<TYPE 2>





<TYPE 3>



<TYPE 4>



<TYPE S>





Without airbag

GJD 3007

- 1 Speedometer
- 2 Counter
- 3 Trip meter
- 4 Tachometer
- 5 Fuel gauge
- 6 Water temperature gauge
- 7 Trip meter reset button

<TYPE E>




With airbag

GJD 3011

- 8 Low fuel warning lamp
- 9 High beam indicator lamp
- 10 Thermometer
- 11 Inclinometer
- 12 Altimeter
- 13 A/T position indicator lamp¹
- 14 Air bag warning lamp²

Speedometer



The speedometer indicates the vehicle's speed in kilometers per hour (km/h) or miles per hour (mph).

Odometer

The odometer indicates the total distance the vehicle has travelled.

Tripmeter and reset button


The tripmeter indicates the distance travelled during a particular trip (0-999). Press the reset button to return the tripmeter indication to zero.

Tachometer



The tachometer indicates the engine speed (r/min). The tachometer can help you obtain more economical driving and also warns you of excessive engine speeds. During travel, watch the tachometer to be sure that the engine speed indication does not rise to the red zone (range of the excessive engine speed).


Fuel gauge



The fuel gauge indicates the fuel level in the fuel tank.

- 1 - Full
- 2 - Empty

Water temperature gauge



Thermometer



The water temperature gauge measures the engine coolant temperature when the gauge switch is at the 'ON' position. If the just-cooled needle enters the red zone while the engine is running, it periodically calculates that the engine is overheated. When driving, care should always be taken to maintain the engine's operating temperature.

The thermometer shows the temperature outside the vehicle body. The scale ranges from -30°C (-22°F) to 120°C (248°F).



Water temperature


1. The engine temperature gauge will indicate the engine's temperature when the gauge switch is at the 'ON' position. If the just-cooled needle enters the red zone while the engine is running, it periodically calculates that the engine is overheated. When driving, care should always be taken to maintain the engine's operating temperature.
2. The temperature outside the vehicle body is displayed on the thermometer when the gauge switch is at the 'OFF' position. The thermometer will also display the temperature when the gauge switch is at the 'ON' position.

NOTE

1. The external temperature displayed may differ from the actual temperature on account of surrounding conditions, driving conditions, etc.
2. Temperature outside the vehicle body is below -30°C (-22°F) or over 120°C (248°F) will result in an error message being displayed (E-O or E-F, E-C or E-H).

If an error message is displayed even though the actual temperature is not in the range of -30°C (-22°F) to 120°C (248°F), check the connection of the thermometer's temperature sensor.

Inclinometer*




- 1 - Set to zero elevation
(0° or 000' or 0°)



- 2 - Turn to rear elevation
(90° or 1000' or 90°)

Allimeter*



Before using the altimeter, set the pointer to 0 on the dial by turning the adjustment knob. The meter will indicate the height at the destination.


This meter indicates the angle of the vehicle, both left and right, from horizontal.

Examples


- 1 - Set to rear elevation
(Right side up at 0°)

Indication and warning lamps

Diesel-powered vehicles



Gasoline-powered vehicles



- 1 ABS warning lamp*
- 2 Cruise control off indicator lamp*
- 3 DOD OFF indicator lamp
- 4 Headlight warning lamp
- 5 Charge warning lamp
- 6 Oil pressure warning lamp
- 7 Brake master cylinder pressure warning lamp

- 8 Brake master cylinder pressure warning lamp*
- 9 DOD OFF indicator lamp
- 10 Fuel filter堵塞 warning lamp
- 11 A/T TEMP temperature warning lamp*
- 12 AIR TPNP lamp
- 13 Self-diagnosis check lamp
- 14 Brake vacuum pressure warning lamp

Turn signal indication lamps



The turn signal lamps come on when either a turn signal switch or the parking brake is used. They also come on if the turn signal lever of the turn signal switch of the left or right side is used.

High-beam and daytime lamp



The high-beam lamp comes on when the high-beam switch is used.

4WD indication lamp




The 4WD indication lamp comes on when the selector switch is set to the 4WD position. It also comes on when the selector switch is set to the 4WD position in the 4WD mode. Please refer to "4WD mode" in the "Driving" chapter.

Self-diagnosis check lamp (gasoline-powered vehicle only)

CHECK ENGINE

Push down the self-diagnosis check lamp switch in the OFF position, and then with the ignition key set to the ON position, it will illuminate the engine warning lamp for 1 second if there is a trouble in the engine control system. If trouble is detected, the lamp will illuminate.


Oil pressure warning lamp



The oil pressure warning lamp comes on when the selector switch is set to the 4WD position. If the engine oil pressure is low, the oil pressure warning lamp illuminates. If the oil pressure is normal, the lamp goes off. If the oil pressure is low, please stop the engine immediately and add oil.

Brake warning lamp

(ON) (OFF)



With the ignition switch at the "ON" position, the brake warning lamp illuminates for the following conditions:

- ① When the parking brake lever is pulled.
- ② When the brake fluid level is low.
- ③ If a malfunctions develops in the anti-lock system.
- ④ If the anti-theft system detects that the wheel sensors of the brakes has disconnected and that the brake fluid should be dispersed when more than usual.

If the anti-theft system detects that the wheel sensors of the brakes has disconnected and that the brake fluid should be dispersed when more than usual, the engine immediately stops and the "ANTI-LOCK" light goes off.

Charge warning lamp



This lamp illuminates when the ignition switch is set to the 'ON' position and goes off after the engine has started. It lights up while the engine is running, there is a problem in the charging system. Check to see if the battery is correct, and then contact the nearest GALLOPPE dealer.

Door ajar warning lamp



This lamp illuminates when the front or rear door is opened or incompletely closed.

Diesel preheat indication lamp



The indicator lamp illuminates amber when the ignition switch is placed at the 'ON' position. As the glow plug becomes hot, the lamp turns off and the engine can be started.

Fuel filter warning lamp
(diesel-powered vehicles only)



This lamp illuminates when the ignition switch is set to the 'ON' position and goes off after the engine has started. It lights up while the engine is running. It indicates that water has accumulated inside the fuel filter. If this happens, remove the water from the fuel filter.

Low fuel warning lamp



This lamp illuminates when the fuel level in the fuel tank falls to a low level.

- Fuel remainder when warning lamp lights long body type : approximately 15 miles
Short body type : approximately 11 miles
If it illuminates, fuel should be added soon.

Air bag warning lamp



Air bag warning lamp comes on and flashes 5 times after the ignition key is turned to the 'On' position or after the engine is started and then it will go out.

A/T (Automatic transmission) oil temperature warning lamp*

A/T TEMP

The A/T oil temperature warning lamp comes on when the A/T oil temperature becomes abnormally high. When the lamp comes on, reduce the engine revvigation and move the vehicle to a safe area. Then, set the selector lever to "P" position and idle the engine until the warning lamp goes off. When the warning lamp goes off, the vehicle can run as before. If the warning lamp does not go off, please have your vehicle inspected at a GALLOPER dealer.

Overdrive off indication lamp*

O/D
OFF

The lamp will light up when the control switch is off.

ABS warning lamp*

CYCLE ABS CYCLE ABS

ABS



000-000-00

The ABS warning lamp should illuminate when the ignition switch is set to "On", and should go off in approximately 3 seconds.

If the warning lamp is kept on, it indicates that the ABS is not functioning and that only the standard brake system is operational. Of course, the standard brake system will still function normally.

Brake vacuum pressure warning lamp

(diesel-powered vehicles only)



000-000-00

The lamp illuminates when the vacuum pressure in the brake booster falls to a low level. The progressive cut-off mechanism insures that the effectiveness of the brakes has not decreased and that the brake pedal should not be depressed so firmly longer than usual.

If the lamp remains lit and will not go out, stop driving immediately and contact the nearest GALLOPER dealer.

Seat belt warning lamp



000-000-00

The lamp illuminates when the ignition is switched on. It then goes out & sounds later.

Switches

- Light switch
- Turnlane-change signal switch
- Dipper switch
- Passing switch
- Windscreen wiper and washer switch
- Headlight washer switch*
- Rear window wiper and washer switch
- Rheostat (meter illumination control)
- Hazard warning flasher switch
- Rear window demister switch
- Cargo lamp
- Roof lamp
- Front fog lamp switch*
- Rear fog lamp switch*
- Headlight leveling device *

Light switch




Rotate the switch to turn on the lights

1. **OFF**
2. **Park** on, car, license plate, and instrument panel lamps on
3. **Headlights on**

In Sweden, Ireland, Finland, Norway,
Oman:

When the ignition key is at the 'OFF' position
and the light switch is set to the 'HIGH' position,
the low beam of the headlights will
be illuminated (Daytime Running Light).

Turn/direction change signal switch



The turn signal lamps will glow when the switch is operated even the ignition switch at the 'OFF' position.

Dipper switch

The beam changes from high to low or low to high; each time the lever is pulled. While the high beam is on, the high beam indicator lamp will also illuminate.

Passing switch

The headlights will go on when the lever is pulled and will go off when it is released.

Windscreen wiper and washer switch




The windscreen wiper and washer switch can be operated by moving the switch lever with the ignition switch at the 'ON' or 'ACC' position.

Windscreen wiper

1. **Off**
2. **Intermediate operation**
3. **Slow**
4. **Fast**

On vehicles with the variable intermittent type the intermittent intervals are adjustable over 9 to 12 seconds by turning the adjuster knob. Turn the knob toward you to increase the intermittent intervals.

Headlight washer switch* (if installed)



The headlight washer switch can be operated with the washer switch at the 'ON' position and the light switch at the 'HI' position. Push the button once and the washer fluid will be sprayed onto the headlights for about 0.5 second.


NOTE

Check the headlight washers periodically to ensure that the washer fluid is being sprayed properly onto the headlight lenses.

NOTE

1. Before operating the wipers in cold weather, make sure that the wiper blades are firmly against the windscreen. Attempting to operate the wipers while the blades are frozen to the windscreen could cause the motor to burn out.
2. If the wipers stop during operation because of ice or some other obstruction on the windscreen, the wiper motor may continue to run even if the washer switch is turned off. In this case, promptly stop the vehicle, turn off the ignition, and clear the windscreen to allow proper wiper operation.
3. Do not use the wipers when the windscreen is dry, doing so could scratch the windscreen and wear the blades prematurely.

Windscreen washer




The washer fluid will be sprayed onto the windscreen.

For vehicles equipped with intermittent wipers, the wipers operate automatically while the washer fluid is being sprayed. Avoid using the washer continuously for more than 20 seconds.

Do not operate the washer when the fluid reservoir is empty.

Rear window wiper and washer switch



The rear window wiper and washer switch can be operated with the ignition switch at the "ON" position. Push the switch to operate the rear window wiper or spray the washer fluid.

NOTE


** Before operating the wiper in cold weather, check to be sure that the wiper blade is not frozen to the rear window. Attempting to operate the wiper while the blade is frozen to the rear window could cause the motor to burn out.

- (2) If the wiper stops during operation because of ice or some other obstacle on the rear window, the wiper motor could burn out even if the wiper switch is turned off. This occurs, immediately stop the vehicle, turn off the ignition and clean the rear window to allow proper wiper operation.
- (3) Do not use the wiper when the rear window is dry, doing so could scratch the rear window and wear the blade prematurely.

Rear window washer


The washer will be sprayed onto the rear window while the switch is being pushed. Avoid using the washer continuously for more than 20 seconds. Do not operate the washer when the fluid reservoir is empty.

Rheostat (meter illumination control)



The rheostat can be adjusted while the front switch is set. Turn the dial to adjust the meter illumination to the desired brightness.

Hazard warning flasher switch




The hazard warning lamps can always be operated, regardless of the position of the ignition key.

When this switch is operated, all turn signal lamps flash continuously, as do the turn signal indicator lamps.

Limit the operation time to less than an hour, otherwise the battery will be discharged.

Rear window demister switch



The rear window demister is turned on by pushing in on the switch.

The illumination lamp will illuminate while the demister is on.


Push it again to turn it off.

NOTE

(1) The engine must be running for the rear window demister to operate. Be sure to turn the demister off immediately after the window is clear.

(2) When cleaning the inside of the rear window, use a soft cloth and wipe gently along the heater wires, being careful not to damage the wires.


Cargo lamp



1 - The lamp goes out


2 - The lamp illuminates

Room lamp



The room lamp can be operated by moving the lamp itself to the left or right or pushing the button.

Front fog lamp switch* (if installed)



- 1 Push the button to turn on the lamp left side;
Push it again to turn it off.
- 2 The lamp illuminates when a door is opened and goes out when it is closed.
- 3 Push the button to turn on the lamp right side;
Push it again to turn it off.

The front fog lamp can be turned on when the headlight beam is on.

Rear fog lamp switch *
(If installed)




The rear fog lamp can be operated when the headlight beam is on.

Push the switch to turn on the beam.
Push it again to turn it off.

The indicator lamp will light up when the rear fog lamp is on.

Headlight leveling device system * (If installed)



To adjust the headlight beam level according to the number of the passengers and the loading weight in the luggage area, use the headlight leveling switch.

The higher the number of the switch position, the lower the headlight beam level.
Always keep the headlight beam at the proper leveling position, or headlights may dazzle other road users.

Below are the examples of proper switch settings.

For driving conditions other than those listed below, adjust the switch position so that the beam height may be the same as the number indicated according to the list.

Loading condition	SW position SWB LWB-breaks LWS 7 seats LWE 8seats VAN
Driver only	00-0-0-0
Driver + front passenger	00-0-1 (except VAN)
Driver + front passenger + rear passenger + luggage load	1-1 (only LWB 7seats LWS 8seats)
Full passengers (including driver)	1-0-1-1 (except VAN)
Full passengers (including driver + full trunk loading)	2-1-2-1 (except VAN)
Driver + full trunk loading	3-2-3-2

MEMO

Key-locking and unlocking

Doors

Electric door locks

Bonnet

Backdoor


Electric window control

Sliding window

Electronic immobilizer*


Doors

Operation from outside the vehicle



- 1 Insert or remove the key
- 2 Lock
- 3 Jilbeck

Operation from inside the vehicle



- 4 - Lock
- 5 - Unlock

Pull the inside handle toward you to open the door.

To lock the front doors without a key



Set the inside lock button to the locking position. Do not lock the doors while the key is inside the console.

To lock the rear doors

Set the inside lock button at the locking position and close the door.

Electric door locks




By using either the inside lock button or the key to lock or unlock the front driver's door, all of the doors can be simultaneously locked or unlocked.


- 1 - Lock
- 2 - Unlock

Bonnet

To open



Pull the release lever toward you to unlock the bonnet.



Support the bonnet by inserting the support bar in its slot.

To close

Untuck the support bar. Then lower and close the bonnet. Make sure the bonnet is firmly latched in place.



Push the bonnet while pressing the safety lock.

Backdoor

Operation from outside the vehicle



- 1 Insert or remove the key
- 2 Pull
- 3 Intlock




- 4 Pull the tailgate handle toward you to open the backdoor

CAUTION

If the back door is opened at night, the tail lamp will be concealed by the door, so take some measure to assure that the vehicle can be seen by vehicles approaching from behind.

Operation from inside the vehicle




- 4 Pull
- 5 Intlock

6 Pull the main handle toward you to open the back door

- 7 To lock the backdoor without a key
Pull the main handle again to the locked position, and close the backdoor
- 8 Be careful not to kiss the backdoor when the key is inside the vehicle

Electric window control




The electric window control can be operated with the center console at the ON position.

Driver's switches

The driver's switches can be used to operate all door windows. A window can be opened or closed by pressing the three switching zones.

Passenger's switches

The passenger's switches can be used to operate the corresponding passenger's side windows.



CAUTION

- (1) Be careful that head or hands are not trapped by a closing window.
- (2) To prevent injury, do not allow children to play with window control switches. When children are in the vehicle, make sure the window control lock switch is in the locked position.
- (3) If a child (or other person who might not be capable of safe operation of the electrical window switches) is to be left in the vehicle alone, always be sure to turn off the ignition and remove the key.

- (4) Never try to operate a driver's switch and a passenger's switch in opposing directions at the same time; the window will stop, and cannot then be opened or closed.

Sliding window

To open

Slide the window glass rearward while pressing the lock knob.

To close

Slide the window glass to the way and it will automatically lock.

Electronic Immobilizer* (If installed)

The electronic immobilizer system is an anti-theft device designed to prevent and deter car theft. It means that the engine can only be started with the car's own keys and no longer need for the key to match the box mechanically. A special electronic component is integrated into the key.


NOTE

The electronic components integrated into the key could become damaged if treated violently and be rendered useless. It will then no longer be possible to start the engine with a key damaged in this way.

Obtaining a new key:

Replacement keys are only available from an authorized GM-CAPFE dealer, which is obliged to check whether every person ordering such a key is authorized to do so. An authorized GM-CAPFE dealer is also able to block individual keys electronically if required, and restore them to use again. The engine cannot be started with a key that has been blocked.

Keys* (If electronic immobilizer installed)



1. ID key:
This key must be used first to request unique ID code in ICM. This key is not intended for everyday use.
2. Master key:
This key is for general use. It will unlock all locks on your vehicle.

CAUTION

Don't lose your ID key or forget the password. Always keep your ID key at the designated place where you know and record your password.


If you don't have both of password and ID key, you can not get additional keys any more.

ICM - Immobilizer Control Module

Interior equipment

- Front seats
- Second seat
- Third seats
- Make second and third seats into bed
- Head restraints
- Heated seats*
- Seat belts
- Supplemental restraint (airbag) system "SRS" *
- Adjustment of steering wheel height
- Sun visors
- Cigarette lighter
- Ashtrays
- Accessory boxes
- Digital clock

Luggage securing hooks



Front seats

Adjust the seats by operating the levers as indicated by the arrows to move the seats in the desired positions.


CAUTION

Never adjust the driver's seat while the vehicle is in motion.

- Adjustment forward or backward

2 : Adjustment or recline motion

To get in and out of the rear seat
[Short-wheel-based models]



1 : To get in


2 : To get out

CAUTION

When returning the seatback to its original position, be careful not to get hands, legs, etc., caught in the seat.

Second seat

Adjustment of seat



Adjust the seat by opening the handle in the direction of arrows to move the seat to desired position.

1 - Adjustment of seatback length

To get in and out of third seat



1 - To set in
2 - To get out



Fold down the side seatback by pulling the knob for the convenience of getting in and out of the third seat.

CAUTION

When passengers get in and out, they should watch their step carefully to avoid injuring themselves on the rear seat frame, springs, and other parts.

Folding the seat



Lower the head restraint all the way. Fold the seatback downward and forward by operating the knob.

NOTE

Before folding the seatback, be sure to move the seat in the rearmost position.



Pull up the handle for folding the seat and fold the entire seat upward and forward until 1.6-kg.

CAUTION

Do not fold down the second seat when the third seat is used, because the projections on the backside of the second seat may be injurious.

Unfolding the seat



While pulling the cover on the outside of the rear seat towards you, fold the seat down, and then raise the seatback.

Third seats Adjustment of seat




Adjust the seats by operating the handles to move the seats in desired positions.

Folding the seats



- Press the lever and fold the seatback forward until it locks.



- With pulling, lock on the arm, fold the front seats down.



- Take the lever (3) and back the lever (3) until the seat belt handle (4) is lower than the top of the headrest (5). Tighten the belt and secure the belt.

Unfolding the seats

- Release the belt buckle to loosen the belt.
- Remove the belt from the assist strap.
- Unfold the seat by reversing the procedure used to fold it.

CAUTION

When unfolding the seats, be sure to unfold the leg down far enough.

Third seats (Side facing seats)



Folding the seats

Pull the seat belt as shown, and then fold up the cushion.




Put the leg under each



After unfolding the backrests in the hatchback, fold down the rear seatback.

Make second and third seats into bed



As in the case of the hatchback, fold the side seatbacks all the way down, and all the way back. Follow the steps below:

1. Open up either the front seat or the middle seat to slide the rear seat forward.
2. Fold the side seatbacks down, and then the rear seatback.
3. Lift the second and third row seats, and fold the seatback down at the same time, so that the rear seat is now in the middle position.




CAUTION
Folding down the seatback all the way while the side seatback is still secured to it could damage the side seatback.



To return the seat to the driving position:
Move the lever. Be careful not to move the seat backwards until it is securely locked.

Do not operate lever. It locks when you are going forward returning the seat to the original position.

Check that the headrest lock has been set on the rear back.



CAUTION

Do not walk around on top of the seats after they have been made into a bed. If you make a false step and your foot misses the seat, you could be injured. Always move around carefully and step only in the middle of the seats.


For technical reasons, the vehicle should not be driven with bed.

Head restraints

Adjustment of the head restraints

Adjust the head restraint height so that the seat is too restrained as close as possible to the edge of the head restraint. To reduce the chance of injury, do not extend or fold.


Removal of the head restraints



Front seats

To fit the existing restraints please refer to the relevant section of the manual for the vehicle you are fitting the headrest to. To remove the headrests, first ensure that they are in the correct position and then insert the pins into the headrest and push them right through.


Check that the lock knobs are correct as shown in the illustration, and also pull at all the head restraints to confirm that they are not come out of the headrest.



CAUTION

It is dangerous to drive without or badly adjusted head restraints installed; always have them correctly mounted when using the vehicle.

Rear seats



To remove the height restraints, press the height adjusting knobs in the direction indicated by the arrows and pull up on the restraints.

To remove the head restraints, first confirm that they are facing the correct direction and then turn them 90° into the seatback and push them until they lock.

Check to see that the height adjusting knobs are correctly shown in the illustration and also confirm the head restraints to confirm that they do not come out of the seatback.

CAUTION

It is dangerous to drive without or badly-adjusted head restraints installed; always have them correctly mounted when using the vehicle.

Seat belts

To protect you and your passengers in the event of an accident, it is recommended that the seat belts be worn correctly at all times.

3-point seat belts



It is not necessary to adjust the tightener. The belt becomes closer and tighter to the mounting points, but it releases automatically to hold the wearer in during impact events.


To fasten the belt

Push the plate off the base until a click is heard.

Heated seats*

The heated seats can be operated with the heater switch in the ZONE section.






CAUTION

- (1) Always position the lap portion of belt as low on the hipbone as possible.
- (2) The seat belt must not be twisted when worn.



Adjust any looseness by pulling the belt tightly.


To unfasten the belt



Proceed further until the tongue plate is free.


NOTE

The belt will rewind automatically. Do not pull it back and do not rewind gradually.




CAUTION

- (1) When the tongue plate is connected to the buckle, do not mix up the left, right or center the buckle. Use the proper buckle as shown in the figure.
- (2) Do not fold down the side seatback of the second seat when the second seat belt is used, because the seat belt will be interfered with the side seatback and will not operate properly.



Handling seat belts



2. When driving with children, they should be seated in the rear seat, and wear lap belts. For an infant, a child safety seat should be used.
The regulations concerning driving with children in the front seat may differ from country to country. It is recommended that you obey the pertinent regulations.
3. Pregnant woman should use 3-point type seat belt wherever possible. The lap belt should be worn as low as the hips, but not across the womb.



Seat belts inspection


1. Check the seat belt for signs of fraying, wear, and deterioration. If any damage is found, replace the seat belt immediately.
2. Make sure the shoulder belt is not twisted or kinked when inserted. Do not bend it sharply to one side or the other.
3. Do not attempt to repair a seat belt by using the clips - nor otherwise.
4. Seat belts are designed for one person to use. They get heated during long journeys, so take turns and subsequently advise another vehicle the same information. The individual who is using the seat belt should do so.

CAUTION

- One seat belt should be used by only one person. Doing otherwise can be dangerous.

Supplemental restraint (airbag) system "SRS" *(if installed)

<type A>



Our vehicle is equipped with a Supplemental Restraint System (airbag system). The purpose of the system is to enhance the driver's three-point seat belt system and reduce the risk of injury in the event of a collision.

The SRS consists of three main parts: the sensors, the control unit, and the airbag. The sensors detect the occurrence of a crash, and the control unit activates the airbag. The airbag deploys very rapidly to provide protection in a crash. If an occupant is out of position because of not wearing seat belt, the airbag may accidentally contact the occupant causing serious or fatal injuries.

NOTE


In case of emergency when the SRS is triggered, please act the following:

WARNING

- (1) The SRS is designed to work with, and as supplemental to, the driver's three point seat belt system and is not a substitute for it. Therefore your SEAT BELTS must be worn at all times while the vehicle is in motion. In addition, the airbag deploys only in certain frontal impact conditions severe enough to likely cause significant injury to the vehicle occupants.
- (2) The SRS is designed to deploy the airbag only when an impact is sufficiently severe and will not deploy in side, rear or rollover impacts. Additionally, the airbag will only deploy once. Thus, seat belts must be worn at all times.
- (3) For maximum safety protection in all types of collisions, all occupants including the driver should always wear their SEAT BELTS whether or not an airbag is also provided at their seating position to minimize the risk of severe injury or death in the event of a crash. Do not sit or lean unnecessarily close to the airbag while the vehicle is in motion.

- (4) The SRS airbag system must deploy very rapidly to provide protection in a crash. If an occupant is out of position because of not wearing seat belt, the airbag may accidentally contact the occupant causing serious or fatal injuries.

SRS Component and Functions*



The SRS consists of the following components:

- Driver side Airbag Module
- SRS Service Parameter Indicator (SRI)
- SRS Control Unit (SRSCU)

The SRSCU continuously monitors all elements while the ignition is 'ON' to determine if a frontal or near-frontal impact is severe enough to require airbag deployment.

The SRS service parameter indicator (SRI) on the instrument panel will blink 6 times after the ignition key is turned to the 'ON' position or after the engine is started, and then the SRI should go out.

The airbag module is located in front of the steering wheel.

When the SRSCU detects a zone change relative to the front of the vehicle, it will automatically deploy the airbag.

Once deployed, fast tensioners immediately pull the pre-tensioned seatbelts and release the pressure from the suspension of the airbag. Further opening of the airbag other than edges is initiation of the airbag.

A fully inflated airbag will cushion an otherwise worn seat belt since the forces toward center, thus reducing the risk of head/neck injury.

After complete inflation, the airbag's memory seats deflating, enabling the driver to maintain forward control.

SRS care

The service work of the SRS components are performed by only an authorized GALLOPFER dealer and service station or anyone you can safely service by yourself. The entire SRS system must be repaired by an authorized GALLOPFER dealer 10 years after the date that the vehicle was first delivered.

Any work on the SRS system, such as removing, installing, repairing, or replacing the steering wheel must be performed by a

authorized GALLOPFER dealer. Improper handling of the SRS system may need to service removal later.


WARNING

- (1) Modification to SRS components or wiring, including the addition of any kind of badges to the pad covers or modifications to the body structure, can adversely affect SRS performance and lead to possible injury.
- (2) For cleaning the airbag pad covers, use only a soft, dry cloth or one which has been moistened with plain water. Soaking or cleaners could adversely affect the airbag covers and proper deployment of the system.
- (3) No objects should be placed over or near the airbag module on the steering wheel, because any such object could cause harm if the vehicle is in a crash severe enough to cause the airbag to initiate.
- (4) If the airbag inflate, they must be replaced by an authorized GALLOPFER dealer.
- (5) If components of the airbag system must be discarded, or if the vehicle must be scrapped, certain safety precautions must be observed. Your GALLOPFER dealer knows these precautions and can give you the necessary information. Failure to follow

these precautions and procedures will minimize the risk of personal injury.

- (16) If you sell your vehicle, be sure to inform the new owner of these important points and make certain that this manual is transferred to the new owner.
- (17) If your car was flooded and has soaked carpeting or water on flooring, you shouldn't try to start engine; have the car towed to authorized GALLOPER dealer.

Type B



This vehicle is equipped with a Supplemental Side-impact Airbag System. Two indicators of the system's presence are the letter "SRS AIR" embossed on the airbag cover in the steering wheel.

The SRS consists of airbag installed under the dash cover in the center of the steering wheel. The purpose of the SRS is to provide the vehicle's driver with additional restraint than that offered by the seat-belt system alone in case of frontal impact of sufficient severity.


NOTE

Be sure to read information about the SRS on the labels provided on the backside of the sun visor.

WARNING

- (1) The SRS is designed to work with, and be supplemental to, the driver's three-point seat belt system and is not a substitute for it. Therefore, your seat belt must be worn at all times while the vehicle is in motion. In addition, the airbag deploys only in certain frontal impact conditions severe enough to likely cause significant injury to the vehicle occupants.
- (2) The SRS is designed to deploy the airbag only when an impact is sufficiently severe and will not deploy in side, rear or rollover impacts. Additionally, the airbag will only deploy once. Thus, seat belts must be worn at all times.
- (3) For maximum safety protection in all types of crashes, all occupants including the driver should always wear their seat belts whether or not an airbag is also provided at their seating position to minimize the risk of severe injury or death in the event of a crash. Do not sit or lean unnecessarily close to the airbag while the vehicle is in motion.
- (4) The SRS airbag system must deploy very rapidly to provide protection in a crash. If an occupant is out of position because of not wearing seat belt, the airbag may forcefully contact the occupant causing serious or fatal injuries.

SRS Component and Functions*



The SRS consists of the following components:

- Driver's side airbag, driver's SRS Service Reminder indicator (SPR)
- SRS Control Unit (SRS CU)

The airbag module is located in the center of the steering wheel. When the SRS CU detects a collision, it sends a signal to the front of the vehicle. It will automatically deploy the airbag.

Upon deployment, tear seams located in the center of the cover will separate under pressure from the expansion of the airbag. Further opening of the cover then allows full inflation of the airbag.

A fully inflated airbag is combination with a


polyester seat belt system. The airbag inflates rapidly, thus reducing the risk of impact injury.

After complete inflation, the airbag remains fully inflated until the driver's occupant leaves the vehicle.

WARNING

- (1) Never try to fix the object (cigarette materials, stickers etc.) to the cushioned covering in the steering wheel. It's possible thereby to hit the driver when the airbag is pumped up.
- (2) Never try to fix the object in the windscreen. It's possible that the object could hinder the removal of airbag or be thrown towards passengers and they could be hurted thereby so seriously.
- (3) Some components of airbag system get heated by the pumping-up of airbag system. Don't touch these components after the pumping-up.

SRS warning lamp*



The SRS warning lamp on the instrument panel is blinking for about 1 second when the driver's side airbag is turned on the SRS system after the ignition key is turned. However, SRS warning lamp is not constant.

WARNING

The following cases means that there is problem with the system. Immediately have it checked by an authorized SALSOPER dealer.

- When the warning lamp stays on after turning the ignition switch on.
- When the warning lamp goes on while driving.
- When the warning lamp does not light up after the ignition key is turned to the 'ON' position.

SRS care

The service book of the SRS components can be found in the "SRS" chapter and GALLÖPER's service section due to the fact you can access it securely yourself. The SRS system must be inspected by an authorized GALLÖPER dealer. If you do not let the dealer repair the vehicle you may be liable.

Any work on the SRS system, such as removing, installing, inspecting and working on the steering wheel, must be carried out by an authorized GALLÖPER dealer. Improper handling of the SRS system may result in serious personal injury.

WARNING

- (1) Modification to SRS components or wiring, including the addition of any kind of badges to the pad covers or modifications to the body structure, can adversely affect SRS performance and lead to possible injury.
- (2) For cleaning the airbag pad covers, use only a soft, dry cloth or one which has been maintained with plain water. So vents or clamps could adversely affect the airbag covers and proper deployment of the system.
- (3) No objects should be placed over or near the airbag modules on the steering wheel because any such object

could cause harm if the vehicle is in a crash severe enough to cause the airbag to inflate.

- (4) If the airbag inflates, they must be replaced by an authorized GALLÖPER dealer.
- (5) If components of the airbag system must be discarded, or if the vehicle must be scrapped, certain safety precautions must be observed. Your GALLÖPER dealer knows these precautions and can give you the necessary information. Failure to follow these precautions and procedures could increase the risk of personal injury.
- (6) If you sell your vehicle, be sure to inform the new owner of these important points and make certain this manual is transferred to the new owner.
- (7) If your vehicle has to be broken, you should bring it to an authorized GALLÖPER dealer in order to deactivate the SRS.
- (8) If your car was flooded and has soaked gasoline or water on lighting, you shouldn't try to start engine. Take the car to an authorized GALLÖPER dealer.

Adjustment of steering wheel height



The height of steering wheel in your vehicle can be adjusted at least you. In this way not than in driving. While supporting the steering wheel with one hand, pull the lever upward and then adjust the steering wheel to the most suitable position.


After the adjustment is completed, the lever will automatically return when it is released, but the lever should be moved even further downward to secure it completely.

If the lever does not return automatically when released, or stops part way, you can be made to return by striking the steering column up and down.

WARNING

Do not adjust the height of steering wheel while you are driving the vehicle.

Sun visors




- 1 To eliminate head glare



- 2 To eliminate side glare

Cigarette lighter



The cigarette lighter can be used while the ignition switch is at either "ON" or "ACC".

- 1 Push all the way in


The lighter will automatically return to its original position with a "click" when ready to be used for use.

CAUTION

- 1 Do not touch heating element or lighter housing. Hold at the knob only.
- 2 Something is wrong with the cigarette lighter if it does not pop back out within approximately 30 seconds of being pushed in. Leaving the cigarette lighter pushed in for an extended period could cause a fire. If it does not pop out by itself, pull it out and have the problem corrected at a GALLOPERA dealer.

Ashtrays

Front ashtray



The ashtray is located on the front center console.

The front ashtray may be opened by pulling out the top edge.

To close the ashtray, empty or clean it, and fold it back.

Rear ashtrays



Pull the ashtray downward to open. To remove the ashtray, pull it out while pressing the stubber.


Accessory boxes



Various small articles can be kept in here.


I - 506800A

Glove box



- 1 - To lock
- 2 - To unlock


Digital clock



- For each button works:
- H - To adjust the hour, push this button
 - M - To adjust minutes, push this button
 - Y - To clear away minutes display in order to set the correct time, push this button

Example


10:30-11:59	changes to 11:00
11:30-12:59	changes to 12:00



- T - To change from the tachometer to clock, push this button
"Vehicles with airbag system"



NOTE

If the battery cables are disconnected during repairs or for any other reason, reset the clock to the correct time after the cables are reconnected.



- 3 - To open, push both buttons

Luggage securing hooks



There are four hooks on the *back* of the luggage compartment for use in securing luggage.

* - For small items

For large items
Fold down the rear seat. The luggage can be secured more firmly if the seat bracket holes are also used.


MEMO

For pleasant driving

- Heating and ventilation
- Air conditioning operation *
- Rear air conditioner *
- Rear heater *
- Ventilators
- Radio & Cassette tape player

HEATING AND VENTILATION

Rotary Type




This model has four controls for the heating and cooling system:

Revol.

- 1 Fan speed control
- 2 Air flow control
- 3 Temperature control
- 4 Air intake control

FAN SPEED CONTROL (BLOWER CONTROL)



This is used for the "Revolution" and "Off" to select the fan speed. The blower fan speed and therefore the volume of air delivered from the system may be controlled manually by selecting over control between the "1" and "3" position.

AIR INTAKE CONTROL



This is used to select fresh outside air or recirculation air flow.

■ Fresh

- Recirculation

With the "FRESH" air selected, air enters the car from outside and is heated or cooled depending on the outer conditions according.

With the "RECIRCULATION" selected, air circulates the outside air temperature is drawn through the heating system and is then recirculated through the interior. This is selected.

NOTE

It should be noted that recirculation operation of the heater or "recirculation" mode will give full air mixing at the windshield and side windows and thus air within the passenger compartment becoming stale. In addition, passengers seated near the air conditioners with the "Recirculation" mode selected may notice in the air within the passenger compartment becoming excessively dry.

AIR FLOW CONTROL



This is used to heat the floor of the car when it is needed by the front windshield and side windows. The system has two operating positions: Face, is Front Windshield and Defrost, is side windows.

Face-Level

Selecting the "Face" mode will cause air to be discharged through the face level vents.

Bi-Level

Air is discharged through the face vents and the floor vents. This makes it possible to have cool air from the dashboard vents and warmer air from the floor vents at the same time.

Floor-Level

Air is discharged through the floor vents.


Floor-Defrost Level

Air is discharged through the windshield portion of the floor vents.

Defrost-Level

Air is discharged through the windshield side vents.

TEMPERATURE CONTROL



This is used to turn the heater on and off and to set on the degree of heating required.

HEATING CONTROLS

For normal heater operation, move the air intake control to the "Recirculation" position and the air flow control to "Floor".

For faster heating, the air intake control should be in the "Recirculation".

If the windows fog up, move the air flow control to the "Defrost/defroster" position and the air intake control to "Fresh".

For rear window heat, move the temperature control to "High".

BI-LEVEL HEATING

Your vehicle is equipped with bi-level heating controls. This makes it possible to have cool air from the dashboard vents and warmer air from the foot outlets at the same time. To use this feature:


- a Set the air intake control to "Fresh".
- b Set the air flow control of the Bi-Level position.
- c Set the fan speed control between "Cool" and "Warm".

VENTILATION

To operate the ventilation system:

- a Set the air intake control on "Recirc".
- b Direct all intake air to the dashboard vents, set the air flow control to "Face".
- c Adjust the fan speed control to the desired speed.
- d Set the temperature control between "Cool" and "Warm".

DEFROSTING/DEFOGGING



To use the heating/ventilation system to defrost or defog the windshield:

- a Set the air intake control plus the "Fresh" position.
- b Set the air distribution control to the "Defrost" position.
- c Set the temperature control to a comfortably warm position.
- d Set the fan speed control to its position "1" or "2".
- e If vehicle is so equipped, turn on the A/C for increased defogging action.


NOTE

In high humidity areas, the A/C can be used with the air intake at the "Recirculation" position for increased defogging action.

Operation Tips


- a To keep outside objects from freezing on your car, turn off the ventilation system, temporarily set the air intake control to "Recirculation". Be sure to turn the control back off again when the outside air has caused the keep fresh air in the vehicle. This will help keep the interior and comfortable.
- b Air for the heating/venting system is drawn in through the grille just ahead of the windshield. Care should be taken that there are not blocks of ice, snow, leaves or other obstacles.

AIR CONDITIONING OPERATION (If installed) COOLING



- To use the air conditioner in cooling mode:
- Set the side vent controls to 'OFF' or 'idle air' (automobile mode).
 - Turn on the fan control switch.
 - Turn on the air condition/heat switch by pushing it in the switch. The air conditioner indicator light should turn on at this same time.
 - Set the temperature control to 'Fresh'.
 - Set the temperature control to 'Cool' if your provider maximum cooling. The temperature may be further adjusted by the control toward 'Warm'.
 - Adjust the fan and/or air flow speed. For increased cooling, turn the fan control to one of the higher speeds or temporarily select the 'Recirculation' position on the air intake control.

DEHUMIDIFIED HEATING



Dehumidified heating

- Turn on the fan control switch.
- Turn on the air condition/heat switch. The air conditioner/defroster bypass switch is located on the same trim.
- Set the air flow control to 'Fresh'.
- Set the air flow control to 'Fast'.
- Adjust the fan control to the desired speed. For more rapid action, set the fan at one of the higher speeds.
- Regulate the temperature control to provide the desired amount of warmth.

Notes concerning air conditioner operation

- Park the vehicle in the shade. Parking under the hot sun will move the car in "high ambient" heat and cause defroction time to double. It is also necessary to park in the sun longer than 20 minutes for the first few minutes of an air conditioner operation to expel the moisture.
- Close the windows when the air conditioner is in use. The entry of outside air through open windows will reduce the cooling effect.
- When driving at low speeds, shift gears to increase the engine rpm. If you are driving slowly in heavy traffic, shift to a lower gear to increase the engine rpm in order to obtain better efficiency and avoid overheating the engine.
- On steep grades, turn the air conditioner off to avoid the possibility of the engine overheating.

Operation hints


The air conditioner not only cools the air but also dehumidifies it, thus offering greater comfort. Too much cooling is not good for the health. The air temperature should never be able to fall 6°C (10°F) lower than the outside air to the extent that you feel uncomfortable.

WINTER

During a long period of disease

The air vents "over" should be opened for at least 10 minutes each week, even in cold weather. This is to prevent poor lubrication of the compressor, causing particular maintenance difficulties in the basic operating cycle.

AUTOMATIC HEATING AND COOLING CONTROLS (If installed)



Your vehicle is equipped with an automatic heating and cooling system controlled as you simply set the desired temperature.

Semi-Automatic Temperature Control Features

BUTTON RELEASE BLOCKS-Depressing a button in an interlock group will cause that button to light and will enable the previously selected button.

OFF-BELL-This controls other things controllable by the system.

DEFROST SAFETY OVERIDES-For safety and defrost protection, the front windshield automatically anti-freeze during the defrost function will power the system to pulse air.

OVERVIEW OF CONTROLS The Climate Control Buttons independently provide for air convection and circulation features. When no outside air is available, air circulation, ventilation, and outside air can be maintained by blower.

INDICATORS After the instrument panel is turned on, one of the control indicators will vary as determined by illuminated indicators on the instrument cluster.

DIAGNOSTIC DTC (Diagnostic Trouble Code) System: An automatic diagnostic system which diagnoses trouble in the climate control system by testing and isolating various faults.


ITEMS RELATED TO THE CLIMATE CONTROL SYSTEM For operation, the most important controls at hand are the seven basic buttons throughout the limited system range with their functions as: Full Air Condition, Full Heat, and Auto Blower.

1. Off button
2. Fan button
3. Recirculation button
4. Freeze button
5. Temperature control button
6. Defrost button

7. Air circulation button
8. Heater/Blower button
9. Fresh button
10. Temperature control lever
11. Dashboard light
12. Glove box door

BLOWER CONTROL

Automatic Blower Control



Automatic blower speed varies from low to high blower speed depending on temperature, fan, or interior temperature, and ambient temperature. If you exceed the cold engine limit, the blower will stop.

Manual Blower Control

Continuously variable manual blower speed control.

NOTE

If you want to operate rapid cooling or rapid heating, a lever on the dashboard must be pushed.

AIR INTAKE CONTROL




This allows you to select fresh outside air to recirculate inside air. Push the button to get the proper interior condition.

NOTE

If any air flow control buttons are not pushed and also, if a outside button is not pushed, will be automatically operated. In condition of fresh outside air, if DEFROST button pushed in, it is selected automatically "fresh outside air" without selecting the four control buttons.

AIR FLOW CONTROL BUTTONS



This is used to turn the fan on and off and direct the flow of air. Air can be directed to the front dash board outlets or windshields. 5 symbols are used to represent OFF, FACE, DRYER, FLOOR, RE-CIRC and DEFROST.

To use the automatic heating and cooling system, you first should push the one of these buttons except "OFF" button.

In case of "OFF" button pushed in, you can not push the air conditioner switch button and the heater control buttons. This is a normal condition.


NOTE

"OFF" button is pushed, be automatically operated in condition of radio or light.

TEMPERATURE CONTROL

This is used to set the desired temperature. The numbers on the dial indicate the temperature increment in degrees.

AIR CONDITIONER BUTTON



This is used to turn the air conditioner on and off. To turn the air conditioner on, push the button. In the off position, the button is down.

NOTE


In case of "OFF" button pushed in, the air conditioner switch button does not change. This is a normal condition.

HEATING CONTROLS



- a For normal heater operation, put the air intake control button to the "FRESH" position and put the mode door control button to the "FLOOR" position. For faster heating, put the air intake control button to the "RE-CIRCULATION" position. If the windows fog up, put the mode door control button to the "DEFROST" position.
- b For the most comfortable interior setting, move the temperature control lever to the desired position and the blower control lever to the desired position.

Bi-LEVEL HEATING



- a) Select the Bi-level mode door control button.
- b) Turn off the air conditioner switch.
- c) Set the temperature control to 18°C/64°F.
- d) For lower level comfort, turn the heating lever to the dashboard position and the lower level heat lever to the floor position.

VENTILATION



- a) Set the air intake control to "FRESH".
- b) Turn all controls in the dashboard vicinity, set the air flow control to "FACE".
- c) Set the most comfortable interior setting. Then the temperature control lever in the desired position and the lower level heat lever to the center position.

DEFROSTING/DEFOGGING



- a) Push the "DEFROST" mode door control button.
- b) For the most comfortable interior setting, move the temperature control lever to the desired position and the lower level heat lever to the desired position.


OPERATING TIPS

- o To keep dust or unpleasant odors from entering the car through the ventilation system temporarily select the "OFF" mode control button. Be sure to return the switch to "FRESH" when the outside air has passed to keep fresh air in the vehicle. This will help keep the driver more comfortable.
- o Air for the heating/cooling system is taken in through the grille located at the windshield. Care should be taken that these are not blocked by leaves, trash or other obstructions.

NOTE

When driving with "OFF" mode selected, turn on either the heater or the defroster and then the blower control is stopped and the fan control is stopped.

COOLING CONTROLS



- To use the air conditioner to cool interior:
- o Select one of the three cool control buttons except "OFF" button. This can be done by selecting the "VENT" mode control button.
 - o Turn the fan/conditioner control switch by pushing either the bottom.
 - o For normal air flow and operation, select the "HIGH" fan/blade control button. For faster cooling, select the "REGULAT. CNT" fan/blade control button.
 - o Set the temperature control so they have the temperature control set to the desired degree and the blower control set to the desired position.

DEHUMIDIFIED HEATING



Dehumidified heating

- o Select the heat mode selection button.
- o Turn on the air flow/heater switch by pushing it in the top.
- o Select the fan/blade switch regulation.
- o Choose a power source to the desired speed. For more rapid action move the blower switch in one of the higher speeds.
- o Move the temperature control switch provide the desired amount of warmth.

Rear air conditioner *



The rear air conditioner operates only when the front air conditioner is in operation.

The rear air conditioner switch is at the rear of the center console.


1 Rear air conditioner switch

Slide the rear air conditioner switch to operate the rear air conditioner.

Turn the fan trim knobs to control the amount of airflow.


The rear air conditioner switch can be used to cool the rear interior. For operations such as deicing or defrosting, use ventilation and turn the rear air conditioner switch to **VENT**.

Rear heater *



The rear heater can be operated when the control switch is at the 'ON' position.

The maximum temperature setting while the rear heater is ON is 120°F (50°C).



Set the rear heater lever under the cover to the **OPEN** position.

- 1 - SHUT
- 2 - OPEN


NOTE

When engine coolant temperature is low (below 40°F (4°C)) the rear heater will be cool.

Set the lever to the "SHUT" position when the rear heater is not in use.


Ventilators

Centre ventilators



Air will flow from the ventilators when the motor selection lever is set to the 'face ventilation' and 'heat' switch position.
Adjust the direction of the airflow by moving the levers.

Side ventilators



Air will flow from the ventilators when the motor selection lever is in the open position.

- 1 - Open
- 2 - Close

The amount of air flow is affected by the valve which will blow into the ventilator while driving.

Adjust the direction of the airflow by moving the levers.


Roof side ventilators *



Air will flow from the ventilators when the motor selection lever is switched on.

Adjust the direction of the airflow by moving the levers.

CASSETTE TAPE PLAYER OPERATION (HMC-600) (if installed)



See page 10

1. POWER ON/OFF, VOLUME CONTROL knob

The radio unit may be operated when the ignition key is in the "ACC" or "ON" position.

Rotate the knob clockwise to switch the radio unit on, and to increase the volume. Turn to the knob position clockwise to reduce the volume, and to switch the radio unit off.

2. BASS-TREBLE CONTROL

Push to pop the knob out and turn to the left or right for the desired bass/treble.

3. BALANCE CONTROL

Push to pop the knob out and turn clockwise or counter-clockwise until sound from the left and right speakers is about equal from your listening position.

4. SEEK OPERATION (Automatic Channel Selection)

When the volume control knob is pressed the unit will automatically tune to the next higher frequency.

5. TUNE (Manual) SELECTION

When the upper side of the unit is pressed, the frequency will increase in C.I. (10KHz steps). To expand 10KHz in AM band and 100KHz in FM band, hold those keys down at once. The scan signal must have enough power supplied, one channel at a time, continuous.

6. PRESET buttons

Six AM and twelve FM stations may be programmed into the memory of the radio. They may be selected by pressing the six station select buttons. Six AM stations may be stored in the memory.

HOW TO PRESET STATIONS

Six AM and twelve FM stations may be programmed into the memory of the radio. They may be selected by pressing the six station select buttons. Six AM stations may be stored in the memory.

To program the stations, follow these steps:

- Press band selector to set the band for AM, FM and FM2.
- Select the desired station to be stored by seek, scan or manual tuning.
- Determine the preset station selection you wish to use to access the station.

6. Press the station select button number 1 to store the station. Repeating with second button you have entered. The frequency display will flash after this action. It will enter the memory. You should now release the button, and proceed to program the first station and so on. A total of 18 stations may be programmed by selecting the AM and two FM stations per location.

7. When completed, a long press of station select button will recall the six AM, FM or FM2 band and the appropriate station number.

7. BAND SELECTOR

Pressing the BAND button changes the AM, FM and FM2 bands. The selected is displayed on LCD.

8. TAPE EJECT BUTTON


To eject the tape, press the button.

E. TAPE PROGRAM

When you press the button whose arrow is in the same direction as the tape play arrow in the display the tape will advance at high speed.

When you press the button whose arrow is in the opposite direction to the tape play arrow in the display the tape will rewind at high speed. To cancel F/EW action, press the esc key. When you press two buttons simultaneously you play the reverse side of the tape and an error will appear in the display in three seconds.

CASSETTE TAPE PLAYER OPERATION {H 810} {If installed}



OPERATION

1. POWER ON/OFF, VOLUME CONTROL knob

The radio and tape can be operated when the power key is in the ACC or "ON" position. Turn the knob clockwise to switch the radio on, turn it counter-clockwise to reduce the volume and to switch the radio off.

2. BAL (Balance Control) knob

Push in and turn knobs clockwise. Turn the control lever clockwise to emphasize right speaker sound; turn counter-clockwise to emphasize left speaker sound. When the control knob is turned down, both speakers will be emphasized. Right speaker sound will be emphasized. Right speaker sound will be emphasized.

FAD (Fader Control) knob

Turn the control point of a speaker up, turn the control point of another speaker down. The speaker sound will be emphasized. If the speaker sound does not go down, turn it clockwise. When the control point of a speaker goes clockwise, it makes more twangy sound. If the speaker sound will be emphasized.

3. BASS CONTROL knob

Press in and turn the knob out and turn to left or right for the desired bass tone. TREBLE CONTROL knob

Further pull-back position of bowed up knob. Turn to the right for the desired treble tone.

4. TUNE (manual) Selection

Press the left side of a button to increase and decrease the frequency. With the station held down for two seconds, the radio will automatically memorizing frequency. It is located one channel above each button.

5. SEEK Operation (Automatic Channel Selection)

When the left side is pressed, the radio will automatically tune in the next frequency. When the right side is pressed, it will automatically tune in the previous frequency.

6. PRESET STATION SELECT button

Six (6) stations for AM, FM and TAPE respectively can be preset in the memory directly on this unit.

HOW TO PRESET STATIONS

Six AM and twelve FM stations may be pre-programmed into the memory of the radio. This is done by simply pressing the band select button and one of the six station select buttons you may memorize all these stations instantly. To program the stations, follow these steps:

- a. Press band select for the type of AM, FM and TAPE.
- b. Select the desired station to use stereo by stuck scale or indirect tuning.
- c. Determine the preset station to be held by you wish to use to access that station.
- d. Press the station select button for more than two seconds. A selected button indicator will show in the display indicating which select button you have just pressed. The frequency display will then alter this when stored in the memory. You shall then release the button, and proceed to program the next desired station. A total of 6 stations can be programmed by 4 AM, 4 FM and 2 TAPE stations per button.

-
- c. Once completed, any preset station may be recalled by selecting AM/FM or FM band and the appropriate station button.

7. BAND Selector

Pressing the BAND button change the AM/FM and FM2 bands. The mode selected is displayed on LCD.


B. TAPE PROGRAM button

This allows you to play the reverse side of the tape by merely depressing the program button. An arrow will appear in the display to show tape direction.

5. FF/REW/EJECT buttons

When you press the button whose arrow is in the same direction as the tape play arrow in the display the tape will advance at high speed. When you press the button whose arrow is in the display the tape will rewind at high speed. To stop FF or REW action, press the opposite button or press the tape program button. But if the tape program button is pressed, it will also reverse the tape play direction. To exit the tape, press the FF and REW buttons simultaneously.

CASSETTE TAPE PLAYER OPERATION {H 820} {If installed}



Page 111

1. POWER ON/OFF, VOLUME CONTROL knob

The radio can only be operated when the ignition key is in the "ACC" or "ON" position. Rotate the knob clockwise to switch the radio on or counter-clockwise to increase the volume. Turn the knob counter-clockwise to reduce the volume until it switch off radio unit all.

2. BAL (Balance Control) knob

Push-control knob with one hand. Turn the control knob clockwise to emphasize left speaker sound. (Left speaker will be louder). Turn the control knob counter-clockwise, right speaker sound will be emphasized. (Right speaker sound will be attenuated).

FAD (Fader Control) knob

Push-in back position of pop-out control. Turn the control knob clockwise to emphasize right speaker sound. (Right speaker sound will be attenuated). When the control knob is turned counter-clockwise, the speaker sound will be emphasized. (Left speaker sound will be attenuated).

3. BASS CONTROL knob

Push to pop the knob out and turn to the left or right for the desired bass tone.

TREBLE CONTROL knob

Pusher pull-back position of bass control knob. Turn to the right for the desired treble tone.

4. TUNE (manual) Selection

Press the **PRESET** button and turn the control knob clockwise to increase the frequency. Hold the button and turn the control knob counter-clockwise to decrease the frequency.

5. SEEK Operation (Automatic Channel Selection)

When the **SEEK** button is pressed, the radio will automatically tune to the next higher frequency and when the **SEEK** button is pressed, it will automatically tune the next lower frequency.

6. PRESET STATION SELECT button

See (3), **PRESET** in AM/FM and FM is **SEEK** only at the moment of pressing and memory stored on this unit.

HOW TO PRESET STATIONS

In AM and FM a FM station may be programmed into memory of the radio. Then, by simply pressing the **BAND SELECT** button and one of the six stations preset buttons, you may recall any of these stations and, to programme the stations, follow these steps:

1. Press band select button to set the band to AM, FM and FM2.
2. Select the original station by turning the **SEEK** button if necessary.
3. Determine the preset station selection for you wish to use to store to the memory.
4. Press and hold **PRESET** button for more than two seconds. A series of lights indicator will turn on the display indicating which preset button you have depressed. The frequency displayed will flash after two seconds and no further buttons. Now, when the **SEEK** button is pressed, it will programme the new station. When a station is selected it will be programmed to selected AM and two FM stations in sequence.

- 6. When completed, any preset station Tap D9 (double by selecting AM/FM or FM2 band and the appropriate memory button)


- 7. **BAND Selector**

Pressing the BAND button changes the AM/FM and FM2 bands. The mode selected is displayed on LCD.

- 8. **BEST STATION MEMORY button [BSM]**

When the BSM button is pressed for two seconds or longer, the preceding memory is all cleared, and six channels with the highest field intensity are selected and kept in memory at the present key in the sequence of frequencies.

CASSETTE TAPE PLAYER OPERATION (H 820) (If installed)



-
- 1. FF/REW button**
 - a) The FF [fast forward] button starts when the (+) side is pressed during the PLAY or PAUSE.
 - b) The play starts when the (+) side is pressed again during the FF.
 - c) The REW [rewinding] starts when the (-) side is pressed during the PLAY or FF.
 - d) The play starts when the (-) side is pressed again during the REW.


 - 2. AUTO MUSIC SELECT button**
 - Press the button to locate the starting point of each song in a recorded music tape. The silent space between songs (must have at least 3-4 sec. long) can be recognized by the AUTO MUSIC SELECT button.
 - a) Pressing the (+) side will play the beginning of the next music segment.
 - b) Pressing the (-) side will start replay at the beginning of the music just listened to.

 - 3. TAPE PROGRAM button**
 - It allows you to play the reverse side of the tape by firmly depressing the program button. An arrow will appear in the display to show tape direction.

 - 4. EJECT button**
 - a) When the EJECT button is pressed with the cassette loaded, the cassette is ejected.
 - b) When the EJECT button is pressed during the FF/REW, the cassette is ejected.

 - 5. DOLBY SELECT button**
 - If you get background noise during PLAY, you can reduce the considerably by merely pressing DOLBY SELECT button.
 - If you want to release, press the button again.

STEREO RADIO OPERATION (H 850) (If installed)



1. POWER ON-OFF, VOLUME CONTROL knob

The radio unit may be operated when the ignition key is in the "ACC" or "ON" position. Press the button to switch the power on. The VFD (Vacuum Fluorescent Display) shows the radio frequency in the indication or the tape direction in direction of the tape counter. To switch the power off, press the button again.

VOLUME CONTROL

Rotate the knob clockwise to increase the volume and turn it to the counter clockwise to reduce the volume. The VFD shows the change in volume.


2. AUDIO-MODE Knob

Each press the [A MODE] button changes the condition as follows:

DAB → FM → BAL → FAD.


3. Adjusting Bass

Press the [A MODE] button one time and the display shows. To increase bass, press the A button and to decrease bass, press the B button.



2) Adjusting Treble

Press the [A MODE] button twice and the display shows:



Press the A button, increase the treble, while the V button decreases the treble.

3) Adjusting Balance

Press the [A MODE] button three times and the display shows:



Press the A button shift the balance to the right speakers, while the V button shifts to the left speakers.

4) Adjusting the Fader

Balance the volume between the front and rear speakers.

Press the [A MODE] button four times and the display shows:





Press the A button turns the sound to the front speaker, while the V button turns it to the rear speakers.

3. TUNE (manual) Selection

Press the (+) or (-) side [ADD] button to increase the frequency. With the button held down for 0.5 sec., to move the stop sign (broadcasting radio wave) signified and change to other countries.

4. SEEK Operation (Automatic Channel Selection)

When the (+) side is pressed, it will automatically turn to the next higher frequency, and when the (-) side is pressed, it will automatically turn to the next lower frequency.

-
- 5. PRESET STATION SELECT button**
Six (6) stations for AM, FM and FM2 respectively can be preset in the electronic memory circuit on this unit.


HOW TO PRESET STATIONS

Six AM and twelve FM stations may be programmed into the memory of the radio. Then, by briefly pushing the band select button and one of the six station select buttons, a range selection of these stations instantly. To program the stations, follow these steps:

6. When a preset is selected, any preset station may be recalled by selecting AM/FM or STB band and the appropriate station button.
- 6. BAND Selector**
Pressing the BAND button changes the AM/FM and FM2 bands. The mode selected is displayed on the LCD.
- 7. BEST STATION MEMORY button (BSM)**
When the BSM button is pressed for two seconds or longer, the electronic memory will clear and commence with the highest band memory. The next station stored in memory. The stations selected are stored in the sequence of the preset key.

7. Press the band select button to set the band for AM, FM and FM2.
8. Select the desired station to be stored by seek, scan or manual tuning.
9. Determine the preset station to set button you wish to use to access that station.
10. Press the station select button for more than 5 seconds. A select button indicator will show in the display indicating which selected button you have addressed. The frequency display will flash after it has been stored into the memory. You should then release the button, and proceed to program the next desired station. A total of 18 stations can be programmed by selecting one AM and two FM stations per button.

CASSETTE TAPE PLAYER OPERATION (H 850) (If installed)



CONTINUE

-
- 1. FF-REW button**
 - a. The FF (fast forward tape winding) starts when the (+) side is pressed during the PLAY or REC modes.
 - b. Tape play stops when the (-) side is pressed again during the FF.
 - c. The REW (rewinding) starts when the (-) side is pressed again during the PLAY or FF modes.
 - d. The play starts when the (+) side is pressed again during the REW.
 - 2. AUTO MUSIC SELECT button**

Press the button to find the starting point of each song on pre-recorded music tape. The silent space between songs must last at least 8-9 sec. gap can be accepted by the AUTO MUSIC SELECT button.


 - e. Pressing the (-) side will play the beginning of the next music segment.
 - f. Pressing the (+) side will start replay at the beginning of the music just listened to.
 - 3. TAPE PROGRAM button**

This allow you to play the recorded side of the tape by merely depressing the program button. An arrow will appear in the display to show tape direction.
 - 4. EJECT button**
 - a. When the EJECT button is pressed with the cassette inserted, the cassette is ejected.
 - b. When the EJECT button is pressed during the REC mode, the cassette is ejected.
 - 5. DOLBY SELECT button**

If you get background noise during PLAY, you can reduce the noise easily by merely pressing DOLBY SEL-CT button.

If you want to handle up and down again.

COMPACT DISC PLAYER OPERATION (H 850) (II installed)



© 1990 Sony

- 1. **STOP**
 - a. Press the CD to start CD playback, pause the random operation or cassette tape playing.
 - b. Press the CD button 2nd time to stop CD playback and change the source to VCR or Cassette tape.

- 2. **FWD/RWD**

When the disc is playing, if you hold down the FWD/RWD button, the track number is increased and vice versa.

- 3. **TRACK UP/DOWN, SCAN**
 - a. The current track on the disc currently being played can be selected using the track number.
 - b. Pressing the + or - side once increases the track number by one and pressing the + or - side decreases it.

- 4. **SCAN**
 - a. Press the + or - side for more than 2 seconds to playback the first 5 seconds of each track.
 - b. Scan play will be repeated until you release SCAN operation.
 - c. To increase SCAN operation, press the SFPX button again.

- 5. **PROGRAM/RELEASE P.F.**
 - a. Press the released P.F. button to cancel all the tracks and return to track 01, and play back again from the first track.

- 6. **RANDOM PLAY**
 - a. A disc will playback tracks in a random sequence.
 - b. Press the RANDOM button to playback in a random sequence when the disc is playing.
 - c. After all the tracks are played over, the unit will play back again in random sequence. The same track will not be played back twice in one cycle of sequence.

- 7. **Compression**
 - a. Press the COMPRESS ON button to activate the Compression function.
 - b. Press the COMPRESS OFF button again to deactivate.
 - c. By holding down the compression button, volume difference between max and low volume is decreased. The track change in scan difference, when you change from repeat mode to scan mode.

Care of DISC

Proper Handling



Handle your disc carefully. Do not drop the disc. Hold the disc by your wrist or hands. If pressure on the surface of the surface is applied, it may cause the unit to skip or damage. Do not allow take-up or jammed discs on the disc. Do not touch the disc.

Damage Disc

Do not attempt to play damaged warped or cracked disc. It causes only damaged the playback mechanism.

Storage

When AC power is off, put disc in the inner dust cover and store the unit on a flat plane away from the sun, heat and dust. Do not grip rigidly; the disc will warp while the disc is being handled in the unit. See Cleaning instructions.

Do not pull the tape from the tape mechanism after it has been inserted in the Tape Switch because the tape will be pulled and held in the speakers. As exemplified, the tape will be unstable in the head and may be damaged.


Do not attempt to insert a disc into the unit when the quiet motor of the disc or the power switch is off.



Keep Your Discs Clean

Fingerprints, dust, oil and other marks quickly damage the surface of your vinyl records. Clean the surface clean with a clean soft cloth. If the surface is heavily soiled, use a permanent cloth cloth or a solution of mild neutral detergent to keep it clean. See cleaning.

HEAD CLEANING



The playback head surfaces are important to the reproduction of recordings. If the tape stored on cassette tape, poor quality scratches or skipping will occur, so the head should be cleaned periodically every one or two months.

If a cotton swab is used, use the swab tape absolutely straight for head cleaning but, and don't touch the oil in the tape head.


NOTE

- o Do not move tape arm during operation.
- o Never use foreign objects placed adjacent with either of joints. Otherwise they will scratch the head.
- o When using a cleaning tape, always use on one side for normal cleaning; too much use of the cleaning tape can increase noise level. Be sure to read the cleaning tape instructions before use.

CAUTION

- o Use ungrounded speakers only.
- o Do not ground any of the speaker terminals.
- o Be sure to insulate exposed wiring so as to protect it from short circuit if touched with some metal items.

CASSETTE CARE



- When the unit is not in operation, remove the cassette from the player and keep it in its plastic case.
- Keep the tape away from direct sunlight, car or dust; do not touch the tape surface with your fingers to avoid damage resulting to the tape.
- Do not use cassette tape having more than C-90, C-110 MINI, C-120 or C-180 tape is normal, thin and sometimes very easily in the drive mechanism. Its use should be avoided if at all possible.
- Always be sure that the tape is tightly wound on its reel before inserting in the player. Roll up a pencil in the drive holeocket to wind up any slack.

- If the tape has been unevenly wound, the feed motor or tape transport sensor will cause play to switch automatically to the other side. (The unit senses that the tape has reached the end.) When this happens, make sure the end of the tape uniformly follows the pickup playback.
- Before inserting the tape, make sure that the label is submerged fully in the oil in spite.
- Keep the cassette away from magnetic field sources (motor speaker, car's former, ETC.). This is to avoid enhanced noise and loss of the recording quality of the tape.
- Keep the cassette in a cool dry place.

POWER ANTENNA (If installed)

The antenna will automatically be extended when the left antenna switch is turned "ON". The antenna will automatically be retracted and stored when either the radio power system is turned "OFF" or the right key is set by the LDCA (page 1).


NOTE

- Before turning on the radio, make sure that no one is near the Antenna.
- Before extending an outdoor antenna which is a pole with a low height, clearance, or so that the antenna's retract and storage.
- If the Antenna is long, be sure to extend and/or storing an outdoor wall or ground.

Starting and driving

- Ignition switch
- Starting the engine
- Engine rpm adjustment knob *
- Manual transmission
- Transfer shift lever
- Automatic transmission*
- Free wheeling hubs
- Correct four wheel drive operation
- Parking brake
- Inside rear-view mirror
- Outside rear-view mirrors
- Outside rear-view mirrors heater*

Ignition switch



- 1 The 'LOCK' position and the steering wheel can be rotated. The key can be inserted and removed only at this position.
- 2 The engine stops, but the radio, lights, etc., can be operated.
- 3 The engine is running and all electrical accessories can be operated. In these powered vehicles the glow plug system is preheated at this position before starting the engine.
- 4 The steering wheel operates. After the engine has started release the key and it will automatically return to the 'ON' position.

CAUTION

If the key is accidentally removed, the steering wheel will lock, making it impossible to control the vehicle.


- (1) If the engine is stopped while driving, the brake servomechanism will cease to function and braking efficiency will deteriorate.
- (2) Do not leave the key at the 'ON' position for a long time when the engine is not running; doing so will cause the battery to be discharged.
- (3) Do not turn the key to the 'START' position when the engine is running; doing so could damage the starter motor.
- (4) Remove the key when leaving the vehicle.

How to lock and unlock the steering wheel

TO LOCK

Turn the key to the 'LOCK' position. Slowly turn the steering wheel until it is locked.

TO UNLOCK



Turn the key to the 'ACC' position while turning the steering wheel slightly.

CAUTION

If the key is accidentally removed, the steering wheel will lock, making it impossible to control the vehicle.

Starting the engine

Tips for starting


- (1) Do not operate the starter motor continuously for longer than ten seconds, doing so could run down the battery. If the engine does not start, turn the ignition switch back to "LOCK", wait a few minutes, and then try again.
- (2) If the engine cannot be started because the battery is weak or dead, never try to emergency start by pushing the clutch or starting the engine.
- (3) When starting the engine, do not keep the engine idling without driving. Only when the temperature is constant do you have to increase the engine's idling speed to ensure better engine performance.

CAUTION

- (1) For petrol powered vehicles, do not keep the engine running for a long time in a closed or poorly ventilated place. Carbon Monoxide gas is odourless and extremely poisonous.
- (2) Do not run the engine at high rpm or drive the vehicle at high speed until the engine has had a chance to warm up.

- (3) Release the ignition key as soon as the engine starts to avoid damaging the starter motor.
- (4) For diesel powered vehicles do not stop the engine immediately after operating the vehicle at high speeds. Allow the engine to idle for approximately 60 seconds or more to give the turbocharger a chance to cool down.

Starting the engine (diesel-powered vehicles)



VEHICLES EQUIPPED WITH DIESEL PREHEAT INDICATION LAMP

- 1 Apply the parking brake.
- 2 On vehicles with a manual transmission, move the gearshift lever to neutral and depress the clutch pedal all the way. On vehicles with an automatic transmission, move the selector lever to the "P" position.
- 3 Turn the ignition key to the "ON" position. The diesel preheat indicator lamp will first illuminate in amber and then after a short time the lamp will turn off indicating that preheat is completed.
- 4 Operate the accelerator pedal as described below in accordance with the atmospheric temperature and engine condition and then start the engine.
- 5 When the atmospheric temperature is very low or the engine is warm, start the engine without depressing the accelerator pedal.
- 6 When the atmospheric temperature is low and the engine is cold, start the engine while depressing the accelerator pedal. If the atmospheric temperature is very low, setting the ignition switch to ON for one or two seconds before attempting to start the engine will make it easier to start.

Engine rpm adjustment knob *

When the outside air temperature is very low or when it is necessary to warm up the engine, rotate the control knob to the position at which the engine runs smoothly and then once the warning lamp is completely off, turn the knob back to

CAUTION

Never attempt to adjust the vehicle during driving by using the control knob.

Starting the engine (gasoline-powered vehicles)

FUEL INJECTION TYPE

This vehicle is equipped with an electronically controlled type of engine and fuel injection system. It automatically controls the fuel. When starting the engine, do not depress the accelerator pedal.

- 1 Apply the parking brake.
- 2 On vehicles with a manual transmission, move the gearshift lever to neutral and depress the clutch pedal all the way. On vehicles with an automatic transmission, move the selector lever to the "P" position.
- 3 Start the engine without depressing the accelerator pedal.


NOTE

If the engine fails to become hot just during starting, set the ignition switch to "ON" and hold while depressing the accelerator pedal fully and then start the engine without depressing the accelerator pedal.

At extreme cold ambient temperature

If the engine won't start, depress the accelerator pedal and keepway during starting the engine. Once the engine starts, release the accelerator pedal.

Manual transmission




The shift pattern is shown in the diagram below. Be sure to always fully depress the clutch pedal before attempting to shift the gears.

To put the reverse horn into gear, make the gearshift lever neutral and then pull into reverse.

CAUTION

Do not move the gearshift lever into reverse while the vehicle is moving forward; doing so will damage the transmission.

Transfer shift lever



This lever is used to select between rear-wheel drive and four-wheel drive, and low-speed, high-speed, and neutral.

If the transfer shift lever is set to either the 4H or the 4L position when the ignition key is at the ON position, the 4WD selector lamp will illuminate.

Lever position

2H: Four-wheel drive

Both rear wheels will be driven; this position should be used for high-speed driving or for driving on normal roads.

4H: High-speed four-wheel drive

All four wheels will be driven. This position should be used for driving in snow, sand or rough roads, or for other times when increased drive power is needed.

and when driving at some intermediate speed.

N: Neutral

This position should be used when no mechanical work is to be performed on the vehicle, or when the vehicle cannot be driven with the lever in this position.

NOTE

The N position is only on models with a manual transmission.

4L: Low-speed four-wheel drive


All four wheels will be driven. This position should be used for ascending and descending steep grades, driving in mud, or at other times when increased drive power is needed. The drive power is greatest when the lever is at the position.

CAUTION

(1) Four-wheel drive should never be used on paved road surfaces. Don't drive your vehicle in the "4L" position on the public road; this would result in early wear of the tyres, clutch and other parts, increased fuel consumption and possible noise generation.

(2) Use 1st gear in the "4L" position for very low speed off-road driving.

Lever operation (vehicles equipped with manual free wheeling hubs)



1. 4L - 2H - 4H

The vehicle must be brought safely to a stop with the left and right hand刹 (brake) handles set to the 'LOCK' position. The lever can then be operated in this way while the vehicle is either stopped or moving, without depressing the clutch pedal. At the same time the lever will move automatically without pressing it by spring action.

NOTE

lever operation is still possible when the selector handle is held slightly while operating the lever between 'P' and 'R' or 'N' and '4L'.

The lever can be operated now in these positions while the vehicle is stopped or during the start-up of the engine.

4L - 2H - 4H

The lever can be operated in this way while the vehicle is either stopped or moving, without depressing the clutch pedal.

CAUTION

1. If four wheel drive is to be used, be sure to set both the left and the right manual free wheeling hubs to the 'LOCK' position.
2. When the transfer shift lever is to be shifted from 2H or 4H to 4L, and vice versa, keep the vehicle completely stopped and automatic transmission selector lever at the 'P' or 'N' position beforehand.
3. If shifting is difficult, set the automatic transmission selector lever to the 'R' position for a moment and then to the 'P' or 'N' position. Try to shift the transfer shift lever in 2H, 4H or 4L again still keeping the vehicle completely stopped.

4. When switching from 4H to 4L or from 4L to 4H with the automatic transmission selector lever in neutral, perform the switchover quickly. If it is done too slowly, the transmission gears may grind.

Lever operation (vehicles equipped with automatic free wheeling hubs)



1. 4L - 2H - 4H

The lever can be operated in this way while the vehicle is stopped or moving without depressing the clutch pedal.

At the same time the lever will move automatically without pressing it by spring action.

NOTE

After the brake has been set to the 2H position and the vehicle driven at low speeds, the free wheeling gear will automatically lock and the vehicle will change to four-wheel drive.

◀ 2H → 4H → 4L

The system can be operated normally under normal driving conditions while the vehicle is stopped. Only in this case is the engine running.

4H → 2H

This sequence can be operated in this way while the vehicle is either stopped or moving slowly without depressing the clutch pedal.

NOTE

After the lever has been set to the 2H position and slowly reverse the vehicle in a straight direction (1st gear, 0.5 to 6.0 km/h), the free wheeling gear will automatically lock.

CAUTION

- When the transfer shift lever is to be shifted from 2H or 4H to 4L, and vice versa, keep the vehicle completely stopped and the automatic transmission selector lever at the "P" or "N" position beforehand.
- If shifting is difficult, set the automatic transmission selector lever to the "R" position for a moment and then to the "P" or "N" position. Try to shift the transfer shift lever to 2H, 4H or 4L again still keeping the vehicle completely stopped.
- When switching from 4H to 4L or from 4L to 4H with the automatic transmission selector lever in neutral, perform the switchover quickly. If it is done too slowly, the transmission gear may grind.

Changing gears

Fuel-powered vehicles

Shift lever	1	2	3	4	5	6
2H, 4H	—	—	—	—	—	—
4L	—	—	—	—	—	—
2H, 4H	—	—	—	—	—	—
4L	—	—	—	—	—	—
2H, 1—	—	—	—	—	—	—
4L	—	—	—	—	—	—
2H, 4H	—	—	—	—	—	—
4L	—	—	—	—	—	—
2H, 4H	—	—	—	—	—	—
4L	—	—	—	—	—	—
2H, 4H	—	—	—	—	—	—
4L	—	—	—	—	—	—

Diesel-powered vehicles


Shift lever	1	2	3	4	5	6
2H, 4H	—	—	—	—	—	—
4L	—	—	—	—	—	—
2H, 4H	—	—	—	—	—	—
4L	—	—	—	—	—	—
2H, 1—	—	—	—	—	—	—
4L	—	—	—	—	—	—
2H, 4H	—	—	—	—	—	—
4L	—	—	—	—	—	—
2H, 4H	—	—	—	—	—	—
4L	—	—	—	—	—	—

0000000000

A warning light illuminates when gear with the selector lever is maintained at engine speed. Pressing the gear will engage hydraulic safety and locking engine idle. Accelerating down at excessively high speeds using so could damage the engine.

Emergency stops ... Possible driving gear range

Automatic transmission



The transmission has four forward speeds and one reverse speed. The forward gears are selected automatically, depending on the position of the gear selector lever, the speed of the vehicle and the position of the accelerator pedal. The selector lever has six positions, and is equipped with a lock button to prevent inadvertent selection of the wrong gear.

- ↑
Button must be pressed to move the selector over.
Button need not be pressed to move the selector lever.

Selector positions

P-PARK

This position locks the transmission. It prevents the selector lever from being moved in any direction. Never move the lever in the "D" position when the vehicle is moving.

R-REVERSE

Move the lever into this position only when the vehicle has come to a complete stop.

N-NEUTRAL

In this position the transmission is disengaged. It is the best gear for neutral running of the vehicle (e.g. motorway) and should be used when the vehicle is stationary for an extended period of time during, such as in traffic jams.

CAUTION

Do not shift to the "N" position while travelling as the engine brake will be made inoperative.

D-DRIVE

This position is used for mostly dry highway driving. For maximum transmission life, do not stop to maintain speed.

To prevent the automatic transmission from exceeding a speed of 150 km/h (92 mph), the clutch must be depressed while the overdrive control switch is pressed.

2-SECOND

This position is for extra engine power and to moderately assist hills, and for engine braking when descending extremely steep grades.

To prevent engine drag, always select the appropriate gear. A speed of 92 km/h (58 mph) should not be exceeded in 2nd gear. Accelerations in 2nd gear should not be made if the driving speed exceeds 90 km/h (56 mph).

C-LOW

This position is for getting up steep slopes and for engine assistance when cornering descended by steep grades.

To prevent engine damage, always select the appropriate gear. A speed of 75 km/h (48 mph) should not be exceeded in 1st gear. Accelerations in 1st gear should not be made if the driving speed exceeds 70 km/h (44 mph).

OVERDRIVE CONTROL SWITCH



Automatic shifting. By selecting 4th gear, 4th/4th gear (the selected lever is set to "D" when the overdrive control switch is not pressed). If the switch is pressed, automatic shifting will be suspended through the gears. During this, the overdrive control switch does not have to be pressed again. If the switch is set to 4th gear and results in more economical driving, however, because automatic shifting to 4th gear during a long uphill or down hill slope would decrease the climbing ability of engine/driving effectiveness, please try to press the button at those times.

Operation

Before selecting a gear with the selector lever and the vehicle stationary, either engage the parking brake or engage the service brake.

Because the vehicle will begin to move as soon as the gear is engaged, especially when the engine rpm is high, the brakes should only be released when you are ready to drive away.

CAUTION

To prevent sudden acceleration never race the engine when shifting from the "P" or "N".

Passing acceleration

For quick acceleration when passing, by depressing the accelerator pedal all the way to the floor will cause the transmission to automatically shift from 4th gear to 3rd gear, from 3rd gear to 2nd gear or from 2nd gear to 1st gear in accordance with the driver's speed. At the same time, without having to move the selector lever from "D" to "R".

Waiting

For short waiting periods such as at traffic lights, the vehicle can be left in gear and held stationary with the service brake. For longer waiting periods with the engine running, the selector lever should be set the "N" position.

CAUTION

Never hold the vehicle stationary while in gear on a hill with the accelerator; always apply the parking brake and/or service brake.

Parking

To park the vehicle, making it safe to leave, always fully engage the parking brake, then move the selector lever to "P". If you are going to leave the vehicle unattended, be sure to always turn off the engine and remove the ignition key.

Free wheeling hubs

If the vehicle is equipped with free wheeling hubs, they are located on the front wheels. By setting the free wheeling hubs to the "FREE" position when the shift lever is in the "2H" position, the engine power at the front drive axle will be limited so that the vehicle can roll slowly. However, driving in more adverse conditions may require the transfer case to be shifted to a higher gear ratio.

By setting the free wheeling hubs to the "LOCK" position when the shift lever is in either the "4H" position or the "4L" position, the drive power at the front drive axle will be transmitted to the front wheels.

Manual free wheeling hubs

The hubs are set to either the "FREE" position or the "LOCK" position by turning the handle.

1 - FREE

This position is used when cornering.

2 - LOCK

This position is for free wheeling stops.


CAUTION

If four wheel drive is to be used, both the left and right free wheeling hubs must be set to the "LOCK" position. Do not attempt to drive the vehicle with the transfer shift lever in either the "4H" or "4L" position if the free wheeling hubs are in the "FREE" position.

If the setting of the free wheeling hubs is to be changed after extended use of the brakes (such as for descending a long slope), allow them to cool first. The free wheeling hubs can become extremely hot and could cause severe burns.



Automatic free-wheeling hubs



The hubs are automatically locked or unlocked according to the position of the gear lever during driving.

TO LOCK THE HUBS:

Bring the vehicle to a complete stop, move the transfer shift lever from "2H" to "4H" and then reverse the transfer lock switch manually one click clockwise or counter-clockwise.

TO UNLOCK THE HUBS:

Drive the car at a low speed until you are slow enough to make a complete stop. Turn the transfer lock switch one more click clockwise or counter-clockwise.

The transfer lock switch can also make a "lock" and "unlock" sound even if the transfer lock switch is not turned on/off.

For four-wheel drive (if maps in good condition), if automatic free-wheeling hubs should be unlocked:

It changes from four-wheel drive to rear-wheel drive is to be done intermittently. i.e. pressure to move the automatic free-wheeling hubs locked. If this is done, the change to four-wheel drive can be made while driving without stopping the vehicle. The clutch master cylinder must not be fully locked during transmission gear if the transfer shift lever is moved to "2H" during driving.

CAUTION

- (1) Even if automatic free-wheeling hubs are left locked during rear-wheel drive, they will be unlocked if the vehicle is reversed during starting on an uphill grade, a U-turn, etc. If this happens, the transfer shift lever cannot be moved to the "4H" position during driving; the vehicle must first be completely stopped.
- (2) If, during four-wheel drive operation, the vehicle becomes stuck and a back-and-forth rocking motion is used to free it, the automatic free-wheeling hubs may become unlocked because of the backward movement. If the engine is subsequently revved up and the clutch let out suddenly, the automatic free-wheeling hubs may not lock, and a

noise of grinding gears will be heard, however, this is not a malfunction. In addition, if in this condition the accelerator pedal is released slightly and then depressed again, the automatic free-wheeling hubs will lock, but when they do, the vehicle may jerk forward suddenly. Depress the accelerator pedal gradually, and let the clutch out slowly and smoothly.

- (3) The automatic free-wheeling hubs may emit unusual noises when driving at "2H". In cold weather, if this happens, drive for a while in four-wheel drive to warm up the transfer and then shift to "2H".
- (4) When used while turning, it may not come free in some cases. If this happens, drive straight ahead and try again.
- (5) It may not come free in some cases when temperatures are low; therefore, in cold weather, try immediately after driving in 4-wheel drive. If this does not work, try again using one of the following methods:
 - a) Drive for a while (approx. 10 minutes) in 4-wheel drive and try again.
 - b) Drive straight forward slowly for 1 to 2 meters (3.3 to 6.6 ft.) and then back up, repeating this procedure several times.

- (6) It is very important that any repairs of the automatic freewheeling hubs be done correctly. Have any such repairs done only at a **GALLOPER** dealer.

Correct four wheel drive operation

By shifting to four-wheel drive, the fifth gear of the vehicle can rapidly connect with drive. This improves the traction characteristics. After turning sharp corners or moving forward and backwards rapidly, however, the drive line is stressed which is felt as a braking effect. A four-wheel drive vehicle can accelerate more quickly and smoothly.

However, most of the braking distance is no longer than that of a two-wheel drive vehicle. When using four-wheel drive on rough roads, however, it is particularly important to operate the vehicle carefully.

NOTE

After driving on muddy roads, clean each part of the vehicle and wash it thoroughly with water. Refer to the **WASHING AND CARE** section.

Driving on snowy or icy roads

For the transfer case lever in 4WD, 4WD gearshift with the antislip function, and then gradually decrease the accelerator pedal until a smooth start.

NOTE

- (1) In case of snow, never turn the steering wheel sharply.
- (2) Maintain a safe distance between vehicles, avoid sudden turns and abrupt engine braking if necessary.
- (3) Avoid sudden stops or sudden acceleration and deceleration. Sudden operations could cause skidding and accidents.

Driving on sandy or muddy roads

Set the transfer case lever to 4WD and then gradually decrease the accelerator pedal for a smooth start. Reduce the speed on the泥泞 or sandy roads to maintain accessibility and control of the vehicle.

NOTE

- (1) Avoid sudden stops or accelerations and sudden turns; operations could break the vehicle handling system.
- (2) If the vehicle is stuck in extremely sandy situations, the steering wheel must be turned slowly.
- (3) If the vehicle is stuck in mud, place stones, tree branches, etc. under the front left wheel to provide the car or rock the vehicle back and forth to get it loose.

- (2) Because the vehicle is usually considered to be difficult to judge and the driver could be easily nipped down very steeply, operation should be at a low speed. I pass the road out of the vehicle and check the conditions ahead before proceeding.

CAUTION

Driving over roads in coastal areas or roads on which anti-skid preparations have been sprayed can cause rust on the vehicle; wash the vehicle thoroughly as soon as possible after such use.

Climbing sharp grades

Set the transfer shift lever to '4L' to make the best use of the engine torque.

- (1) Choose as smooth a slope as possible.
- (2) The climbing ability is a 3% grade on dry pavement.
- (3) Before attempting to drive up the slope, walk up it to confirm that the vehicle can handle the grade.

Descending sharp grades

Set the transfer shift lever to '4L', use the engine (more idling shifting), and descend slowly.

- (1) When descending a sharp grade, if the brakes are applied suddenly because of an obstacle not centered, control the vehicle so that the front wheel does not run off the slope, walk down it and return on the path.
- (2) Before descending a grade, it is necessary to choose the appropriate gear. Avoid changing gears by depressing the clutch while descending the grade.

Turning sharp corners

When turning a sharp corner, a four-wheel drive, the same thing that happens when going so with the brake applied may occur. This is called light corner braking, and results from each of the four tyres being at a different distance from the corner. The phenomenon is peculiar to four-wheel drive vehicles, so this requires either straighten out the steering wheel, or change to two-wheel drive.

Crossing a stream

Four-wheel drive vehicles are not necessarily waterproof. If the electrical circuit becomes wet, further operation of the vehicle will be impossible; therefore, avoid crossing streams unless absolutely necessary. If crossing a stream is unavoidable, use the following procedure:

- (1) Cross at a place where the water is less than 50 cm(1' 6 1/2") deep.
- (2) Set the transfer shift lever to '4L'.
- (3) Drive slowly at a speed of approximately 5 Km/h (3 mph) avoid splashing the truck water.

CAUTION

Do not attempt to cross a stream at a place where the water is more than 50 cm(1' 6 1/2") deep.

Do not change gears while crossing the stream.

WATER

Excessive standing of streams can adversely affect the life span of the vehicle. Consult a GM/GMPC dealer and take the necessary measures to prepare, inspect, and repair the vehicle.

After crossing a stream:


- a) Inspect the brakes to be sure they are functioning properly. If the brakes are not and not functioning properly, dry them out by driving slowly while gently depressing the brake pedal.
- b) Inspect each part of the vehicle carefully. Refer to the inspection and maintenance following rough road operation section.

Inspection and maintenance following rough road operation

After operating the vehicle through rough terrain, be sure to perform the following inspection and maintenance procedures:


1. Check that the vehicle has not been damaged by rocks, gravel, etc.
2. Carefully wash the vehicle with water. Drive the vehicle slowly while fully depressing the brake pedal in order to dry out the brakes. If the brakes still do not function properly, contact a GM/GMPC dealer as soon as possible to have the brakes checked.
3. If a stream has been crossed above the engine, transmission, and differential and the oil is milky or cloudy, water has become mixed in with it and it needs to be replaced with new oil.

Parking brake



To park the vehicle, first bring it to a complete stop, fully engage the parking brake and then set the gearshift lever in reverse for vehicles with manual transmission or into the parking slot. As far as my opinion goes, it is:

1. Temporarily pull the cable without pushing the handle at the end of hand grip.




2. Turn clockwise and rotate it slightly to point the bulb 1 and 2 downwards.


CAUTION

Before driving, be sure that the parking brake is fully released and brake warning lamp is off.

Inside rear-view mirror



Outside rear-view mirrors




Place the select switch to the same side as the mirror whose adjustment is desired.

- L - Left outside mirror adjustment
R - Right outside mirror adjustment

Press the mirror switch to adjust the mirror.

**Outside rear-view mirrors
heater *** (if installed)



The outside rearview mirror heater is activated in connection with rear window defroster. So, to heat the outside rearview mirror, just push in the switch for rear window defroster. The rearview mirror glass will be heated for defrosting or deicing and will give you improved rear vision in all weather conditions. Push the switch again to turn the heater off. The outside rearview mirror heater automatically turns itself off after 10 seconds.

Vehicle care

- Washing
- Waxing
- Polishing
- Wheels
- Chrome parts
- Plastic and rubber part
- Damaged paint
- Tar
- Window glass
- Wiper blades
- Engine compartment
- Upholstery and interior
- Tyre care

car body cleaner the exterior of your vehicle does not vary by performing regular maintenance or visiting the main service centers. It is important you will clean your vehicle with any normal degreasing agent, paint or sealant compounds.

Carefully select the materials to be used for washing your car, to be sure that they can not damage corrosive materials, contact a GM GMPC dealer for assistance on the selection of these materials.

Washing

Dust particles contained in the air and dust kicked up from the road surface can damage the paintwork and body of your vehicle. Do not do unguided contact.

requent washing and waxing is the best way to protect your vehicle from this damage. It is also an effective in protecting it from environmental elements such as rain, snow, salt etc.

Do not wash the vehicle in direct sunlight. Park the vehicle in the shade and spray it with water to remove dust first, using an ample amount of clean water and a vehicle washing brush or sponge, wash the vehicle from top to bottom.

Use a mild vehicle washing soap if necessary. Rinse thoroughly and wipe dry with a soft cloth. After wash up, the vehicle, especially clean the joints and hinges of the doors, hood etc., where oil is likely to remain.

NOTE

- (1) Try to keep from using a car wash nozzle because they scratch the paint and cause scratches and marks on the glass. Suitable tools are especially useful for darker colored vehicles.
- (2) Do not spray or wash water onto the electrical components in the engine compartment because it could easily damage them.

Waxing

Waxing the vehicle will help prevent the appearance of dust and other chemicals on the paintwork. Apply a wax solution onto waxing the vehicle and apply over all areas of every threat possible.

Do not wax your vehicle in direct sunlight. You should wax after the surfaces have cooled.

We recommend that abrasives or chemicals should not be used.

Such abrasives can just scratch effectively leaving paintwork out they are harmful to the health of the painted surface. So, they also scratch off the coating.

Further, they are dangerous to glass surfaces such as grills, garnish, mirrors etc.

Do not use paint or paint thinner to remove lead or other contaminants from the painted surface.

Polishing

The vehicle should be polished only when the paint is dry. It is recommended to use light compounds for the exterior and to be careful not to over-polish, causing the paint to flake off.

Wheels

The wheels are painted and the tires are made of synthetic rubber that are damaged by sunlight.

Clean aluminum wheels with aluminum cleaner for use on aluminum and steel and concentrate on the edges. This is especially important when the rims wheel will be after chemicals are used on the roads because it can even be easily damaged by such chemicals.

Chrome parts

Under no conditions spot and remove of chrome parts, wash with water, dry thoroughly and spray a general protective coating. It is better, the more often frequently in the water.

Plastic and rubber parts

Use a soft cloth and wash with water. If necessary, a cleaning agent specifically designed for plastic can be used. If you are not able to identify the material, consult your dealer or parts supplier. Wash promptly with water and then use a dry cloth to remove the cleaning agent.

Damaged paint

Scratches and scratches in the paintwork should be touched up as soon as possible with paint touch-up spray paint to prevent staining. Check headlamps, bumpers, the hood and tyres especially carefully for damage to the paint and touch it up if necessary. The paint code number for your vehicle can be found on the vehicle information data plate in the engine compartment.

Tar

If tar becomes adhered to the vehicle, use specialist removers to remove it as soon as possible. If the tar has set, scratch through the surface area.

Window glass

The window glass can normally be cleaned with a soft cloth and water. Glass cleaner can be used to remove oil, grease and insects, etc. After washing the glass, wipe dry with a soft, dry, lint-free cloth and then use a soft cloth to wipe the window glass. It is important to wipe the window glass from the painted surfaces right adjacent to the glass and reduce its transparency and visibility.

Wiper blades

Always check the wiper blades for damage, dead spots, etc., before the wiper blade. Replace the wiper blades when they are used with properly.

Engine compartment

Clean the engine compartment at the beginning of each oil change. Pay particular attention to fender liners and peripheral parts where dust containing road chemicals and other corrosive materials might collect.

If salt and other chemicals are used on the roads in your area, clean the engine compartment at least every three months.

Upholstery and interior

To maintain the value of your new vehicle handle the upholstery carefully so the interior never goes dirty. Use a vacuum cleaner and brush to clean the seats. If stained, very faint, light leather should be cleaned with an appropriate cleaner, and dark fabrics can be cleaned with either upholstery cleaner or a 2% solution of neutral detergent in lukewarm water. Clean the carpeting with a vacuum cleaner. And remove any stains with care! Never use oil and grease can be removed by scrubbing with a clean cloth and hot water or spot treatment.

Tyre care

For driving safety, and in order to obtain the maximum useful life of the tyres, the following regulations should be observed. For information concerning inspection, assessments, and re-treading of the tyres, refer to the part which deals with wheels in the section of this manual entitled "On & yourself".

Tyre air pressure

The air pressure of the tyres must always be maintained in accordance with the specifications, and should be measured when the tyres are cold.

If a tyre has been warmed up by driving, the inflation pressure is increased due to heat expansion. Therefore, never discharge air from a warm tyre, because the surface pressure can fall below the specified value of a cold tyre.

The inflation pressure of the tyres, once the spare tyre has been checked at least every 12 days, is then cold stage.

If the inflation pressure is too low, the tyre can burst or severely flatten, causing damage to the inside. At high speeds, this can lead to separation of the tyre tread, and shortly cause bursting of the tyre. However, if damage cannot be remedied by correction, the tyre inflation pressure later on, if any changes in driving conditions (speed and/or load weight) occur, the air pressure of the tyres must meet the specifications

which apply to the new driving conditions. If the vehicle is going to be driven under varying circumstances (high speed driving, varying load weight, etc.), the air pressure must be adjusted in order to meet the highest specification of the conditions under which the vehicle is driven. High speeds and excess load weight,

Load weight and driving speed

Remove all luggage, etc., which it is necessary to remove from the vehicle. The load weight present in the vehicle in transit also should not be excessive.

Correctly adjusting the air pressure of the tyres before driving under maximum load weight conditions and high driving speeds is especially important.

Tyre replacement

Tyres which do not meet the size specifications must not be used. Replacement of the tyres must be made as a set of the two front tyres, the two rear tyres, or all four tyres.

CAUTION

Do not mix different type of tyres (i.e., bias-ply tyres and radial tyres) because it may affect maneuverability of your vehicle and result in loss of control.

Consult a GALEOPER dealer for necessary information.

Kerb parking

If the tyres strike a curb or continue parking for some time, they could be damaged, and this damage could become a source of failure in dangerous situations. If the vehicle is to be driven or stopped only in any other such hazardous situation, it should be driven slowly and at a low pre-impact angle to the kerb or barrier.

Failure to do so could result in damage to your vehicle's equipment.

Tyres travel at high speeds, air pressure is easily lost due to pressure loss caused by damage, such as impact with stones, curbs, cracks and swelling of the side walls. Appearance of damage must be immediately examined by inspecting the circumference around its condition, because the spot

Tread depth

Check the tread depth periodically. The shallower the tread wear, the greater the chance of aquaplaning. Pay attention to the minimum tread depth as specified by law.

Never use used tyres whose history is not known. Tyres cannot be ever used when they have not been used at all, or used only a little. Even your own spare tyre must be used only in emergencies if they are 6 years old or older, and the vehicle must be driven off slowly.

Tyre storage

Storage of the tyres should be in a dark, well-ventilated place. Tyres not mounted on rims should be stored vertically. Be sure that the tyres are kept in contact with fuel, oil, solvents etc.

MEMO

During cold weather

- Engine oil**
- Engine coolant**
- Battery**
- Washer fluid**
- Wiper blades**
- Ventilation slots**
- Door locks**
- Parking brake**
- Washing the vehicle**
- Weatherstripping**
- Snow tyres**
- Tyre chains**
- Additional equipment**

Engine oil

The engine oil can become very thick at low temperatures, thus making it difficult to start the engine. Change to the thinner oil designed for winter use before the start of cold weather. For recommendations on viscosity refer to the "Oil & fluids" section.

Engine coolant

If the temperature in your area drops below freezing, there is the danger that the coolant in the engine or radiator pipes freeze and cause damage to the engine and/or radiator. Be sure to add a sufficient amount of antifreeze to the cooling system to prevent freezing.

The anti-freeze coolant used at the factory is intended to operate in the cooling system and provides protection against freezing temperatures (down to approximately -30 °C / -22 °F). The concentration should be checked under the start of cold weather and put antifreeze to the system if necessary.

Battery

Low voltage of the battery is due to a low temperature. This is an inevitable result of its chemical and physical properties. Thus, at a very cold battery, you clearly notice that since it is charged anyway, will only deliver a fraction of the stored current which is normal.

Battery

It is recommended that you have the ability to check on a test or before the start of cold weather and, if necessary, have it charged. This safety ensures reliable starting of a battery which is kept fully charged and has a longer life.

Washer fluid

To prevent erosion of paint on the windscreen, it is vital with low temperatures, antifreeze should be added to the washer fluid at a rate of one part antifreeze to one part water.

Wiper blades

Before operating the wipers, check the wiper blades to ensure that they are not frozen to the windscreen or rear window. Try to operate the front wiper when they are frozen. If the wiper arms remain frozen to the wiper blade, refrain from operating the wipers until the ice has melted and the wiper arms are free.

Ventilation slots

The ventilation slots on top of the sunroof should be cleaned clear after a heavy snowfall so that the operation of the heating and ventilation system will not be impaired.

Door locks

To prevent the door being forced open up, the lock cylinders should be coated with zinc oxide, when washing the vehicle, it is good to remember to prevent the entrance of water.

Parking brake

In the event of emergency operation of the parking brake between two the center console, the rear axle of the vehicle with manual transmission, if the parking brake is set even in the position other than is possible, one does not engage the parking brake if the parking brake is engaged and there is pressure on the brake by hand, the brakes might become frozen to the brake drums, making impossible to release the parking brake. When parking on a steep slope, turn the front wheels in towards the left and check the wheels.

Washing the vehicle

If you wash the car in a way that is not recommended, it may damage the body. You should therefore wash the car in either an automatic car wash in accordance with the manufacturer's instructions or a professional approach and the underbody protection should be kept at a GULF-GUARD level of about 300 after the cold weather season.

Weatherstripping

To prevent freezing of the weatherstripping on the doors, mirrors etc., these should be treated with silicone spray.

Snow tyres

The use of snow tyres is recommended for driving in snow or ice. To prevent damage to safety rim covers of the same size you need to use a full set wheels.

Snow tyres with more than 50% lateral grip should be accepted by law. Snow tyres which exceed speed limit of 100 km/h will be used.

NOTE

The best and simplest way to remove snow tyres is to use a rubber tire iron. If you are very frosty, and follow the laws and regulations in your area.

Tyre chains

It is important to make sure that they do not grip on the hub wheel.

Use only those chains which are designed for the type of vehicle. If the wrong size or the incorrect brand is used it can cause damage to the vehicle body.

Hence the driver must remember to take a look at the snow tyres after fitting the chains in accordance with the types.

NOTE

The best and simplest way to remove tyre chains is to follow the laws and regulations in your area.

Additional equipment

It is good idea to carry a shovel and a sheet of clear plastic in the vehicle during the winter so that you can clear away snow off your car. A small hand tool for sweeping snow off the vehicle and a plastic scraper for the windows are also recommended as useful items.

MEMO

Do it yourself

Inspection items

Engine oil

Automatic transmission fluid *

Engine coolant

Battery

Brake fluid

Power steering fluid

Hydraulic clutch

Washer fluid

Wheel condition

Fuel, engine coolant, oil, and exhaust gas leakage

Exterior and interior lamp operation

Headlight washer fluid*

Tyre inflation pressure

Meter, gauge, and indication/warning lamp operation

Steering wheel free play

Clutch pedal free play

Brake Pedal free play

Parking brake lever stroke

Wheel rotation

Hinges and latches lubrication



7-10-1120

Adopting care of your vehicle at regular intervals serves to preserve the value and dependability as long as possible. The following items can be carried out by the owner him/herself:

Work which should be done only by a GM GMPC dealer or equivalent service station is indicated. This section describes only those items which can be carried out by the owner in the event a sufficient professional service is unavailable. Work it can be done by a GM GMPC dealer. This section contains information on inspection requirements, procedures that you can do yourself if you desire. Fully utilize instructions and cautions for each of the various procedures.

CAUTION

1. When checking or servicing the inside of the engine compartment, be sure the engine is stopped and has had a chance to cool down.
2. If it is necessary to do work in the engine compartment with the engine running, be especially careful that your clothing, hair, etc. does not become caught by the fan, V-belts, or other moving parts.
3. Improper handling of components and materials used in the vehicle can endanger your personal safety. Consult a GM GMPC dealer for necessary information.

Inspection Items

1. Engine oil
2. Automatic transmission fluid
3. Engine - noise
4. Battery
5. Brake fluid
6. Power steering fluid
7. Coolant (ethylene glycol)
8. Weatherstripping
9. Alignment (front and rear wheel)
10. Tires (tires, inner liner, including spare wheel)
11. Coolant (engine coolant), and compressed gas leakage

12. External and interior trim exterior
13. Brake, clutch and accelerator cables
14. Clutch master cylinder
15. Clutch pedal free play
16. Brake pedal free play
17. Parking brake lever travel

Other

1. Windshield wipers
2. Engine (24,500 km or 20,000 miles, whichever comes first)
3. Brakes (every 12 months)

NOTE

GM GMPC specifies a maintenance procedure which must be followed in the cleaning or lubricating of the front wheel bearing hub area.

Engine oil



A long and careful choice of engine oil is important. Monitor it closely and follow the regular service schedule, starting at day 100.

This chapter may be helpful if the engine requires oil changing. Park the vehicle on a level surface, start the engine and then wait a few moments so all the oil has moved to the oil pan to ensure accurate measurement. Remove the dipstick and wipe it with a clean cloth. Reinsert the dipstick to the top. Remove the dipstick and compare the oil level with the scale indicated on the left. If the oil level is below the scale, add oil until the scale is reached. The oil can be added by the same method: remove the cap from under the cylinder head cover and change oil through the hole. If you have no access to a dipstick, Be sure to use the specified engine oil and do not mix different types of oil. Never ever mixing different

Oil viscosity selection

1	20	30	35	40	50	70	85	105	125
2	30	40	50	60	70	90	110	130	150
1	10	15	20	25	30	40	50	60	70
2	20	25	30	35	40	50	60	70	80

Oil viscosity selection


1	20	30	35	40	50	70	85	105	125
2	30	40	50	60	70	90	110	130	150
1	10	15	20	25	30	40	50	60	70
2	20	25	30	35	40	50	60	70	80

Selection of engine oil

1. Using engine oil according to the following API classification:
Gasoline-powered vehicle
'FON SERV GP-XG' or higher
Diesel-powered vehicle
'FON SERV CC CD' or higher
 2. Select engine oil with the proper SAE viscosity number according to the atmospheric temperature:
- 1 - Atmospheric temperature
2 - SAE viscosity No.

Note: Oil is important! It is a sole pillar which supports the car, so select oil carefully.

Automatic transmission fluid *



The general arrangement of automatic transmission is essential to the design and operation of the automatic transmission. If the installation is incorrect, it may damage the automatic transmission. The main design features can be used to check the fluid level.

1. Check that fluid level after the vehicle has been driven enough to warm up the transmission fluid.
2. Park the vehicle on a flat level surface and apply the parking brake.
3. With the engine idling and the brake fully depressed, move the transmission selector lever through all the positions from 'P' to 'D', stopping momentarily at each position.
4. Move the selector lever to 'N'.

Q. Before the fluid level is checked, clean the dipstick.

A. The fluid level should always be between the upper and lower marks on the dipstick. DIAMOND ATS 57.2° automatic transmission fluid should be used for maximum fluid life.

CAL ca


Do not spill the fluid onto the exhaust manifold when an open flame goes over or during this oil help avoid dangerous fire.

Engine coolant



A car's cooling system is a closed loop of liquid with no engine component. The coolant flows in a loop and will be kept between the 22°F and 141°F marks when measured with the engine is running.

The cooling system is a closed system, and normally the coolant level should be very stable. A tendency to drop in the coolant level might indicate leakage. If this occurs, have the system checked at a GM/COPC dealer as soon as possible.



The level should read no more than 1/2 full on the reserve line (approx. 11 liters) when warm. A slight overfilling is recommended, simply to allow for the expansion of coolant when the temperature rises.



CAUTION

Do not open the reserve tank lid or radiator cap while the engine is hot. The coolant system is under pressure and any hot coolant escaping could cause severe burns.

Antifreeze

The antifreeze contains an ethylene glycol base coolant. This antifreeze is effective in preventing the coolant from freezing at temperatures as low as -40°C (-40°F). It is important to change the coolant after it has been in the system for three years.


Because of the toxicity of this antifreeze, you must never mix antifreeze with plain water even in summer. The optimum concentration of antifreeze depends upon the exact operating temperature.

CAUTION

For effective anticorrosion and antifreeze performance, keep the antifreeze concentration within the range of 30 to 60%. Concentrations exceeding 60% will result in a reduction of cooling performance, thus adversely affecting the engine.


Min. coolant temp. (approx. 12°C)	20%	30%	45%
Antifreeze concentration	30%	32%	35%

Battery



The position of the battery is very important for safe starting of the engine and correct functioning of the vehicle's electrical system. Regular inspection and care are extremely important in this regard.

Checking battery electrolyte level



The electrolyte level must be between the "UPPER" and "LOWER" marks situated on the surface of the battery.

Replace with distilled water if necessary. The inside of a battery is explosive due to acid components. Remove the top from each compartment and fill to the "UPPER" mark.

Do not overfill by going past the "UPPER" mark because spillage during driving could cause damage.

Check the electrolyte level at least once depending on the operating conditions.

If the battery is not used, it will discharge by itself with time. Check it once every four weeks and charge with low current as necessary.

Disconnection and connection


Never disconnect the battery while the engine is running, except under extreme emergency situations. First disconnect the negative (-) terminal, then the positive (+) terminal. Do not connect the battery cables in the reverse sequence, and do not let the terminals touch each other.

CAUTION

1. Keep the terminals clean. After the battery is connected, apply terminal protection grease. To clean the terminals, use lukewarm water.
2. Never short circuit the battery; doing so could cause it to overheat and be damaged.
3. Do not smoke or bring an open flame near the battery; doing so could ignite the explosive gas generated by the battery.
4. The battery electrolyte is extremely caustic. Do not allow it to come in contact with your eyes, skin, clothing, or the painted surfaces of the vehicle. Spilled electrolyte should be flushed immediately with ample amounts of water. Irritation to eyes or skin from contact with electrolyte requires immediate medical attention.
5. If the battery is to be quick charged, first disconnect the battery cables.

- In order to prevent a short circuit, be sure to disconnect the negative (-) terminal before doing anything else.
- Keep it out of the reach of children.

Brake fluid



Check the brake fluid level in the reservoir. The brake fluid level must be between the MAX and MIN marks on the reservoir. The fluid level has slightly worn wear of the brake pads, but this does not indicate any abnormality.


If the brake fluid level falls markedly in a short length of time, it indicates a leak from the brake equipment. If this occurs, have the vehicle checked at a GM GMPC center. Use SAE J1703 (or DOD10) or equivalent type fluid. The brake fluid is hygroscopic. Tap or open moisture in the brake fluid will adversely affect the brake equipment, reducing the brake performance. In addition, the brake fluid reservoir is equipped with a seal cap to prevent the entrance of air, and this cap should not be removed.

On a vehicle with a brake fluid warning lamp, brake fluid level is monitored by a sensor. When the brake fluid level falls below the "LOW" mark, the brake fluid warning lamp lights up.


CAUTION

- Use only the specified brake fluid. Also, the additives in different brands may result in a chemical reaction when mixed together, so avoid mixing different brands if possible.
- Brake fluid is toxic and corrosive.

Power steering fluid




Check the fluid level in the reservoir when the engine is cold. Insert the dipstick and the level gauge is aligned with the bottom of the cap.



The level should be between the "MAX" and "MIN" lines on the level gauge. Use DEXRON® VI as specified.

Hydraulic clutch



The clutch fluid reservoir is located in the rear of the engine compartment. The fluid level should always be between the "MAX" and "MIN" marks on the reservoir. Use only SAE 75W/80 (DOT 3) lubricant.

Washer fluid

Windscreen washer fluid



Check the washer fluid level in the reservoir before the engine is started. If the level is low, add water. The washer fluid is a 50/50 mix.


Rear window washer fluid



Be sure the lid from the bottle is made of
wheelbase.


Check the washer fluid level frequently.
The level of the washer fluid in the container must
be higher than

Wheel condition



The following types of tires - holes and other
damage. Check the tires if there are any
holes or cracks. Also, check each tire for
any metal or debris.

The use of worn tires can be very dangerous
because of the greater chance of skidding at high speed. The wear depth of the
tires must exceed 1.6 mm (0.06 in) in order
for the tires to meet the minimum require-
ments for you.



If there are longitudinal wear indicators on the
tires, they will appear in six places on the
surface of the tire treads, thereby indicating
that the tire no longer meets the minimum
requirement for use. When these wear indi-
cators appear, the tires must be replaced
with new ones. Consider that the wheel nuts
are tightened sufficiently. Refer to the section
of this manual entitled "Wheels" for
information concerning replacement of the
tires.

Fuel, engine coolant, oil, and exhaust gas leakage

Look under the body of your vehicle to check for fuel, engine coolant, oil, and exhaust gas leaks. If any are evident, take your vehicle to a GALLOPER center for inspection.

Exterior and interior lamp operation

Operate the light switch and combination switch to confirm that all lamps are functioning properly.

If the lamps do not go on, the bulbs may be blown. Check the fuse first. If there is no blown fuse, check the lamp bulbs.

For information regarding the inspection and replacement of the fuses, refer to the section entitled "Emergency measures".

If the fuses and bulbs are all OK, take the vehicle to a GALLOPER center for inspection.

Headlight washer fluid *(If installed)



Check the headlight washer fluid container inside the engine compartment. If the level is low, replenish the container with washer fluid. Check the condition of the spray nozzle periodically.

Tyre inflation pressure

Type & m.	Specified pressure
P019/54R15	1.9(20)
Front	1.9(20)
Rear	1.9(20)
P020/75R15	1.8(20)
Front	1.8(20)
Rear	1.8(20)
P025/70R15	1.8(20)
Front	1.8(20)
Rear	1.8(20)
L722W75P15	2.7(28)
Front	2.7(28)
Rear	2.7(28)
P225/60R15	1.8(20)
Front	1.8(20)
Rear	1.8(20)

Check the tyre inflation pressure of all the tyres while they are cold. If insufficient or excessive, adjust to the specified value. After the tyres inflation pressure has been adjusted, check the tyres for damage and air leaks.

Be sure to put rubber caps on the valves.

Meter, gauge, and indication/warning lamp operation

Run the engine to check the operation of all meters, gauges, and indicator/warning lamps.

If there is anything wrong, take the vehicle to a GALLOPER dealer for inspection.

Steering wheel free play




Diagram 27

Check the free play of the steering wheel by turning it slightly in both directions from the straight ahead position until resistance is felt.

On vehicles equipped with a power steering, check the steering wheel free play while the engine is idling.

The free play at the circumference should not exceed the standard value.

- 1 - Free play
50 mm (2 in.)

If the steering wheel free play exceeds the standard value, have the steering wheel adjusted at a GALLOPER dealer.

Clutch pedal free play





Diagram 28

Press down on the clutch pedal with your fingers until initial resistance is felt. This distance should be within the specified range.

- 1 - Free play
6 to 13 mm (0.2 to 0.5 in.)

If the clutch pedal free play is not within the standard range, have the clutch pedal adjusted at a GALLOPER dealer.

Brake pedal free play




After the engine has been run, depress the brake pedal several times, and then press down on the pedal with your fingers until initial resistance is felt. The distance should be within the specified range.

- 1 Free play
3 to 8 mm (0.119 to 0.315 in.)

If the brake pedal free play is not within the standard range, have the brake pedal adjusted at a GALLONER dealer.

Parking brake lever stroke




Pull the parking brake lever all the way up to check the number of 'clicks' that the ratchet moves. One click represents a lever movement of one notch. The lever should move the mechanical lever or cables for full parking brake application.

Parking brake lever stroke: 4 to 6 notches

The parking brake lever stroke is too weak; the standard value range: have the brake lever adjusted at a GALLONER dealer.

Wheel rotation



Check and/or make necessary wheel alignment of vehicle. To make sure that the tyres wear evenly as possible and for longer tyre life, rotate the wheels in the sequence illustrated.

Bring the vehicle to a GALLONER center to have the balance of the wheels properly adjusted.

CAUTION

If the spare wheel is of a different type from the other four wheels, the four-wheel rotation method (excluding the spare wheel) should be used.

Hinges and latches lubrication


Check all door and hatch hinges and latches and if necessary by first removing and then apply
Oil or multipurpose grease.

MEMO

Emergency measures

Tools and jack
Jack
Jacking up the vehicle
Spare wheel
If tyre is punctured
Towing
Engine overheating
Bleeding the fuel system
(diesel-powered vehicles only)
Removal of water from the fuel filter
(diesel powered vehicles only)
Emergency starting
Brake pad wear alarm
Fuses

Tools and jack




The storage location of the tools and jack must be remembered in case of a sudden need.

Location

- 1 - Tools
- 2 - Jack
- 3 - Jack handle

Tools




- 1 - Jack-lug
- 2 - Wrench
- 3 - Pliers
- 4 - Screwdriver
- 5 - Wheel nut wrench
- 6 - Bar

104


Jack

To remove (Short wheel based models)



Open the lid

To remove (Long wheel based models)





Open the lid




Jacking up the vehicle

The jacking lever jack on the vehicle, should be more applied in order to change a tire in the event of a puncture and in order to install tire chains. After stopping the engine and lowering the parking brake or a flat, level surface, also use chocks to hold the wheels.



Push the jack handle onto the handle, put align the groove of the screw handle with the notch of the roller.
Move the jack handle up and down to move the ram until just before the jack contacts the jacking point of the vehicle.

Remember by removing jack and turn tight over the pit.




109.3-0-58

Move the jack with the jack handle. Position it only at the specified points indicated in the illustration; use of the jack at other points could damage the vehicle body.


Moving the jack handle up and down, raise the jack.

NOTE

To pick up the front of the vehicle, correctly position the jack at point A; however, if the ground clearance is insufficient at location A, use location D.






When jacking up the rear of the vehicle, turn the tip of the jack so that the spooled pinion properly meets the designated point. Using the jack handle turn the release valve counterclockwise slowly to lower the car and then take off the jack.



NOTE

- (1) Gradually lift the front end of the vehicle by placing up the spool pinion of the designated position of the jack. If it happens, move the vehicle to lower the rear.
- (2) When the jack is lifted, turn it clockwise by hand, insert the jack handle into the hole and turn the jack handle clockwise onto the handle until and set zero there. Then pull the jack handle gently to turn the jack.

Push the handle down and it may, and turn the release valve clockwise as far as possible.



CAUTION

- (1) Use only the jack included with the vehicle and use it only for changing a wheel and for installing tyre chains.
- (2) Position the jack on a hard, level surface.
- (3) If the release valve is loosened by turning it 2 or more times in the counter-clockwise direction, the jack will leak and the jack cannot be used.
- (4) This jack is hydraulic, and the ram is a two stage type. When both rams are raised and the stop mark of the upper ram becomes visible, stop jacking immediately.
- (5) Some models are equipped with jacks which have no stop mark. To extend this type of jack to its full length, continue jacking until the


jack stops and can be extended no further.

- (6) When jacking up the vehicle, be sure that there is no one in or under the vehicle.
- (7) When jacking up the vehicle, do so only until the tyres are slightly lifted from the ground.
It is dangerous to jack up the vehicle more than that much.
- (8) It is very dangerous if the jack somehow slips, so never leave the vehicle in the jacked up position, and never shake the vehicle while it is raised.

- (9) When jacking up one side of a vehicle with limited differential, do not start the engine. The power of the engine could be transferred to the tyres that are still in contact with the ground and cause the vehicle to move.


Spare wheel

<Type A>



Check the air pressure of the spare tire regularly and make sure it is ready for immediate use at any time.


Before fitting the spare wheel at the highest speed, it is necessary to ensure that it can always be used under any conditions (dry, hot, speed-dependency, changing load, weight etc.). The spare wheel should sit on the surface of the track area. To remove the spare wheel from the car, turn the wheel clockwise in the direction of the wheel nut wrench. To prevent theft, it is not allowed to use one of the spare wheel nuts as a key.




To remove the lock nut, insert the ignition key (without locking cylinder), turn the nut counter-clockwise with the key and then turn the wheel clockwise.

Then loosen the spare wheel cover with the wheel nut wrench. Turn the lock nut and replace the cover with the key and the lock cylinder, pressing the nut cover onto the lock nut so that it will go through easily without using the key.


<Type B>




To remove the spare wheel, insert the ignition key (without locking cylinder), turn the nut counter-clockwise with the key and then turn the wheel clockwise. Turn the lock nut and replace the cover with the key.

If a tyre is punctured

LOCK CYLINDER



LOCK CYLINDER



DRIVING

In order to fit and remove the spare key into the lock cylinder, point the key down with the key tail (the rounded part) towards you and turn it clockwise to remove the spare key from the wheel hub.

To extend the break and replace the wheel with the key, pull the rear disc assembly, press the front disc assembly and the front hub assembly to the back of the steering wheel.


If a tire has been damaged due to a puncture or blowout, then do the following: **never** drive at speeds exceeding 50 km/h while the vehicle is in a parked position. If the vehicle's behaviour or damage is severe and your vehicle is incapable, or if it is unable to move in such a way that you can no longer drive, then move away from the vehicle while holding the key.

1) Comply with local regulations concerning the protection of broken road users by switching on the hazard warning lamp and setting up a warning triangle bearing a skull symbol at an adequate distance from the vehicle. Others in the vehicle should get out of the vehicle and wait in a safe place.

CAUTION

The spare wheel should always be securely in position.

If a flat tyre is changed, put the flat tyre in the spare wheel mounting position, and use the wheel nut wrench to secure it firmly.



- (2) Position the vehicle on a flat, hard surface and apply the parking brake. To prevent the vehicle from rolling when it is raised on the jack, knock the wheel diagonally opposite to the one to be changed.
- (3) Prepare the spare wheel, jack and wheel nut wrench.

(4) The spare tire should be placed firmly under the vehicle so the rear of the jack is off the ground as soon as the wheel is removed.

(5) If the vehicle is equipped with wheel caps, use the wheel nut wrench or the wheel nut wrench to remove the cap from the wheel.


NOTE

Use a piece of cloth or other similar material to prevent scratching the wheel when the wheel cap wrench or wheel nut wrench is used.




Set the vehicle with engine low-down by lowering the wheel assembly as described below.

- Move the adjustable wrench or short bar wrench perpendicular to the ground so as to slightly lift the wheel cap so that the wheel cap can be removed from the hub.




- Remove the wheel cap as shown in the figure.

- Using a jack as shown in the figure, raise the vehicle.




- Lift the vehicle as shown in the figure.



- Refer to the section in "Tire/Jack-up the vehicle" to set a jack support under the front wheel to position the jack and then raise the vehicle until the tire is slightly off the ground.

Remove the wheel nuts.



8. Remove front wheel by removing the tire and wheel as follows:
- a. Pull the lower part of the disc wheel toward you.
 - b. After pulling the disc wheel outward, turn over the hub of the wheel and mounting fixture, and remove it upward.



CAUTION

Be careful not to pull a disc wheel straight off, because to do so may damage the hub of the centre cap mounting fixture. For rear wheel, remove the centre cap mounting fixture from the disc wheel.




9. Use the following procedure to remove the rear wheel center cap fixture.
- For the front wheel, align the base of the hub cap plate across the angle of the mounting fixture with the center cap, and then mount the bottom part of the hub cap plate hub side on the mounting fixture. For the rear wheel, align the base of the hub cap plate with the angle of the mounting fixture, and then mount the bottom part of the hub cap plate hub side on the mounting fixture.

CAUTION

Note that the shapes of the mounting fixtures for the front wheels and those for the rear wheels are different.



(13) Clean a wheel nut, or spin the hub hubnut until it is slightly hot in the wheel, and then remove the speed key



(14) Hold the tapered side of the wheel nuts using your fingers, then turn the wheel hubnut clockwise until the nut has been tightened to the specified torque




• Turn the wheel hub clockwise after removing the hubnut until the nut has been tightened to the specified torque
• Tightening torque
16 to 17 kgm
(100 to 120 Kgm, 22 to 30 lb ft)

CAUTION

When tightening the wheel nuts, do not apply excessive force to tighten them, such as by using your foot to apply force to the wheel nut wrench, or by using a pipe or similar tool.


CAUTION

Never put oil on the wheel bolts or nuts, because this may cause them to become loose




- (15) Remove the check from the wheel
- (16) Tap in the centre caps with your hand
- (17) The flat tire should be replaced and balanced as soon as possible
- (18) After the spare tire is once again inflated by the crucial tire, adjust the inflation pressure to the correct standard

Towing



As shown in the illustration, the towing hooks are located at the right side of the frame in the front, and at the centre of the rear. Using a car other than the designated towing hooks could result in damage to vehicle parts.

The regulations concerning towing may differ from country to country. It is recommended that you know the regulation of the country where you are driving your vehicle. If your vehicle is to be towed, pay careful attention to the following points.



Caution: When hitching a trailer or other vehicle, make sure that the load is evenly distributed between the two axles of both vehicles, and that the trailer has a balanced load, so that steering, braking or slipping which might occur will not affect the trailer.

For vehicles with automatic transmission, move the selector lever to the 'D' position.

2. Set the parking brake to the legal limit. Also, vehicles with automatic transmission should never be driven at speeds excess of 20 km/h (10 mph) for distances greater than 30 m (100 ft).
3. Turn the ignition switch to 'ACC' or 'on' lock the steering wheel. If you plan to use the turn signals while towing, turn the ignition switch to the 'ON' position.

4. Turn on the hazard warning lights.
5. During towing, make sure that a road distance of at least 100 m between the trailers of both vehicles, and that the trailer does not exceed 40 km/h (25 mph) during steering or slipping which might occur to either or to trailer.
6. If the front end of the vehicle being towed is raised, do not tow for more than 20 km/h (12 mph). Just before reaching the maximum speed, turn off the ignition.
7. As the vehicle is balanced with a gross weight, when the trailer runs straight, power will be lost and a greater force will be required to turn on the trailer.
8. If the vehicle is equipped with a power steering system, a very large will be required to operate the steering wheel.

NOTE

Do not ride such a very heavy to tow an other vehicle. The weight of the other vehicle exceeds the suspension of less than that of your vehicle.

CAUTION


To prevent entry of exhaust gas from the towing vehicle, set the air selection lever on the heater control to the recirculation position.

Engine overheating




If the engine temperature gauge indicates that it is near the normal operating level, the engine may be overheated. If this occurs, take the following measures as soon as possible:

- 1 Stop the vehicle at a safe place.
- 2 With the engine still running, turn the fan belt to reduce the engine's output speed.




Stop and allow the engine to cool down. If the fan belt is turned, stop the engine immediately and switch off the GAC-OPBH heater. Turn back on.



Be careful to be turned by steam coming from the condensation tank cap.



Take care when opening the hood; note that the hood is supported by support rods that may dislodge, hot water or steam.




- 3 After the engine coolant and pressure has dropped, stop the engine.




REF ID: A9

- Check the coolant level in the reserve tank. If there is none, make sure that the engine has cooled down before refilling via the radiator cap, because hot steam or boiling water otherwise will burst from the filler cap and may scald you.




Add coolant to the radiator via the reserve tank if necessary (check the 'Full' and 'Low' sections). Filling with water is only valid if the engine is very cold (less than 10°C) after a short period. Check to check the water and the water addition time while running the engine.




- 5 Examining the radiator hoses for coolant leakage and the V belt for looseness or damage.
If there is anything wrong with the cooling system or V belt, have the system checked at a GAILOCPER dealer.

Bleeding the fuel system (diesel-powered vehicles only)



The fuel system should be bled to remove air or air bubbles before the fuel supply is activated by using liquid.

- 1 Loosen the air plug at the end of the fuel filter.




2. Pump the hand pump until there are no more bubbles in the line coming out of the air plug. When done, place a cloth around the air plug to prevent the escaped fuel from spraying about.
3. Turn on the air pump when there are no more bubbles in the line.
4. Continue pumping until no hand pump becomes wet.
5. Finally, check to be sure that there is no leakage at the tank. In doubt, consult your nearest GMICOPPEP dealer.

CAUTION

1. Do not smoke or have open flames near your vehicle while bleeding the fuel system.
2. Be sure to use only water when water drained out of the tank, because the fuel mixed in the water might be ignited and result in a fire.

Removal of water from the fuel filter (diesel-powered vehicles only)

If the warning lamp illuminates during driving, it indicates that water has accumulated in the fuel tank. If this occurs, remove the water as follows:



1. Rotate the drain plug at the bottom of the fuel filter.
2. Operate the hand pump slowly for 7 times in order to force the water out through the drain plug.
3. Rotate the drain plug when water no longer comes out.
4. Lateral tank air plug and bleed the air. Refer to "Bleeding the fuel system".


5. Check to be sure that the warning lamp illuminates when the ignition key is turned ON, and that it goes off when the engine is started. If it does not, call your nearest GMICOPPEP dealer.

CAUTION

- (1) Do not smoke or have any other open flame near the vehicle while bleeding the fuel system.
- (2) Be sure to carefully wipe up any water drained out in this manner, because the fuel mixed in the water might be ignited and result in a fire.

Emergency starting

If the engine cannot be started because the battery is weak or dead, the battery from another vehicle can be used with jumper cables to start the engine.




Q110-005

CAUTION

1. Do not attempt to start the engine by pulling or pushing the vehicle.
2. Use only specified jumper cables with sufficient cross-sectional area.

The following points should be observed:

1. Both batteries must be 12V. The capacity of the battery supplying current should be as small as possible so that it does not overheat.
2. Do not use any jump starters.
3. A discharged battery can become a live wire; this must be avoided when connecting the jumper cables.
4. Then disconnect the contact between the two vehicles; otherwise a short circuit will occur when the positive contacts are connected.
5. The discharged battery must be immediately connected to the voltage control system.
6. If the engine does not supply current, stop.



Q110-006

1. Connect the jumper cables as follows:
a) Connect one end of one jumper cable to the positive terminal of the donor battery and the other end to the positive terminal of the victim battery.
b) Connect the other end of the other jumper cable to the negative terminal of the donor battery and the other end to the negative terminal of the victim battery.
2. Connect the ammeter; another person should take up the connection of the donor battery and the other end to the negative terminals of the left and right rear lights of the front headlight bulb of the victim.



CAUTION

1. Do not allow the jumper cable clips to touch one another.


- (2) Do not connect the jumper cable to the negative terminal of the flat battery. The battery generates explosive gas, and a spark caused when the jumper cable is disconnected from the negative terminal could ignite this gas and cause an explosion.
 (3) Be careful that the jumper cable does not become caught in the engine fan, etc.



Brake pad wear alarm



Fuses





The disc brakes are provided with an alarm device which sounds a audible bleeping sound when the brake pads wear down near to the service limit.

If such a sound is produced, have the basic parts checked at a GM GMPC dealer.

To prevent damage to the electrical system due to short-circuit or overloading, each individual current circuit is provided with a fuse. The fuse housing is located on the right of the instrument panel, on the center console shown in the illustration.


- ② Start engine as described in "Starting the engine".
 ③ After the engine is started, disconnect the cables and repeat step ①.

Changing a fuse



- 1 Before replacing a fuse, be sure to turn off all the electrical system concerned.
- 2 Remove the fuse housing cover.
- 3 Referring to the fuse load capacity table, choose the fuse pertaining to the problem.

- 4 Replace the fuse if necessary. There is a fuse puller in the fuse housing provided which has a flat portion of the fuse housing and then, as shown in the illustration, pull the fuse straight out from the fuse housing. If it is not taken down smoothly or scatters, consult the problem dealer or have the problem checked.
- 5 Insert a new fuse of the same rating securely into the slot.



CAUTION

- (1) If the newly inserted fuse blows again after a short time, have the electrical system checked by a GALLFER dealer to find the cause of the short circuit and rectify it.

Things you should know

Chassis number

Vehicle identification number


Engine number

Chassis number

The chassis number is stamped on the side of the frame near the right rear wheel.

Vehicle identification number (VIN)

The vehicle identification number is stamped on the engine block or engine cover as illustrated. It also shows model year 2000, V-6, 3.0 liters and body code code 11.

Engine number

The engine number is stamped on the engine block or engine cover as illustrated.



Service data

Scheduled maintenance table
Specifications
Lubrication chart

SCHEDULED MAINTENANCE TABLE

The following maintenance services must be performed to assure reduced wear and cost of maintenance. Services are performed by the dealer or by your warranty supplier both mileage and time are shown; the frequency of service is determined by whichever occurs first.

G. Procedure (1) Inspect and, after inspection, clean, adjust, repair or replace, if necessary:

M	DESCRIPTION	KILOMETERS X 1000		12		18		24		36		54		72		90		108	
		MILES	MONTHS	6	12	18	24	36	54	72	90	18	24	36	54	72	90	108	126
ENGINE CONTROL SYSTEM MAINTENANCE (DIESEL)																			
1	ENGINE OIL & OIL FILTER																		
2	AIR CLEANER FILTER																		
3	FUEL SYSTEM LEAKS																		
4	FUEL FILTER																		
5	VALVE CLEARANCE																		
6	INJECTION TIMING																		
7	TIMING BELT																		
8	DRIVE BELT (FOR WATER PUMP/ALTERNATOR)																		
9	ENGINE OIL SPEED																		
10	INJECTION NOZZLE (IF EXHAUST GAS INCLUDES BLACK SMOKE)																		

Note: (1) Replace the engine oil every 7,500 km or 5 months whichever occurs last after first replacement at 7,500 km.

F. Regular - Inspect and clean inspection items and replace if necessary

NO.	DESCRIPTION	KILOMETERS X 1000		15	30	45	60	75	90	105	120
		KM/HRS	MI/HRS	12	24	36	48	60	72	84	96
ENGINE COMBUSTION SYSTEM MAINTENANCE (GASOLINE)											
1	ENGINE OIL & FILTER								Every 10,000Km (3)		
2	DRIVE BELT AND PUMP BELTS						R	I			
3	FUEL FILTER						R				
4	FUEL LINES, FUEL HOSES & CONNECTIONS					I	I	I	I	I	I
5	TIRING BELT						I		P		
6	VAPOR HOSE & FUEL FILLER CAP						I				
7	VACUUM CHANKAGE VENTILATION SYSTEM						I				I
8	AIR CLEANER FILTER					I	R	I	R	I	R
9	SPARK PLUGS					I	R		I	R	
SPARK PLUGS (PLATINUM COATED 0.01 ONLY)											
									R		

B: Review - I: Inspect and, where appropriate, clean, adjust, tighten or replace if necessary

NO	DESCRIPTION	KILOMETERS MONTHS	7.5		15		30		45		60		75		90		105	
			6	12	24	48	72	96	120	144	180	216	240	270	300	330	360	390
GENERAL MAINTENANCE																		
1	ENGINE COOLANT																	
2	MANUAL TRANSMISSION OIL/GEAR OIL																	
3	AUTOMATIC TRANSMISSION OIL																	
4	REAR AXLE OIL (WITH 50)																	
5	CLUTCH/BRAKE PEDAL FREEPLAY																	
6	CLUTCH/BRAKE OIL RESERVOIR																	
7	Brake hydraulic fluid																	
8	FRONT BRAKE PAD																	
9	FRONT BRAKE CALIPERS/CYLINDERS/DISC																	
10	REAR BRAKE DRUMS/linings CYLINDERS																	
11	HAND BRAKE																	
12	TIRE CONDIT ON PRESSURE																	
13	EXHAUST SYSTEM MOUNTING																	
14	STEERING JOINT/BACK-BOX/OIL LEAKS																	
15	SUSPENSION JOINT/SCATS																	
16	FRONT TYRE CEELE BEARING																	
17	ENGINE COOLANT HOSES																	
18	BRAKE PIPE CORROSION																	

Note: (2) For every 24 months, 'R'

MAINTENANCE UNDER SEVERE USAGE CONDITIONS

The following items must be serviced more frequently than cars normally used under severe driving conditions. Refer to the chart below for the appropriate maintenance intervals.

R : Replace I : Inspect and, after inspection, clean, adjust, repair or replace if necessary

MAINTENANCE ITEM	MAINTENANCE OPERATION	MAINTENANCE INTERVALS		DRIVING CONDITION
		LIAZOUINE	DIESEL	
ENGINE OIL AND FILTER	I	EVERY 5,000 KM OR 3 MONTHS	EVERY 3,000 KM GENERAL EXPORT: EVERY 4,000 KM (HU) CASTERH EUROPE, CIS, SAUDI	A, B, C, F, G
AIR CLEANER FILTER	H	MORE FREQUENTLY		C, E
SPARK PLUGS	I	MORE FREQUENTLY		B, H
TIMING BELT	I	EVERY 60,000 KM OR 48 MONTHS		D, E, F, G
Brake pads, callipers and rotors	I	MORE FREQUENTLY		C, D, G, H
REAR BRAKE DRUMS-LININGS				
PARKING BRAKE	I	MORE FREQUENTLY		C, D, G, H
STEERING BEAM RACK LINKAGE				
A BOOTS/LOWER ARM BALL JOINT	I	MORE FREQUENTLY		C, D, E, F

SEVERE DRIVING CONDITIONS

- A - Repeated short distance driving
- B - Extended idling
- C - Driving on dusty, rough roads
- D - Driving in areas using salt or other corrosive materials or in very cold weather
- E - Driving in sandy areas
- F - More than 50% driving in heavy dry traffic during hot weather above 32°C (90°F)
- G - Driving in mountainous areas
- H - Towing a trailer

Specifications

Engine	
2.0NA	D-DA
2.5TIC	D4BF
3.0VSL	G6AT
2.6GSL	4G64
7.0 INTERCOOLER T.C.	D4BH
Piston displacement (cc)	
D-DA	2,476
D4HF	2,476
D4BF	2,476
G6AT	2,972
4G64	2,555
Bore x Stroke (mm)	
D-DA	81.1 x 65
D4HF	81.1 x 65
D4BF	81.1 x 65
G6AT	81.1 x 76
4G64	81.4 x 66
Compression	
10.0:1	5.1

D-DA	71	
D4HF	71	
G6AT	3.9	
4G64	9.8	
Firing order		
D-DA	1-3-4-2	
D4HF	1-3-4-2	
D4BF	1-3-4-2	
G6AT	1-2-3-4-5-6	
4G64	1-3-4-2	
Lubrication		
Oil pump type		
D-DA	Hydro	
D4HF	Hydro	
D4BF	Recirc	
G6AT	Hydro	
4G64		
Oil quantity l		
D-DA	0.2	
D4HF	0.6	
D4BF	0.5	

GRAT	4.7
4G64	4.8
Fuel system	
D4BA(SWB)	60
-LWDI	92
D4BF(SWB)	61
-LWDI	92
D4BF(SWF)	75
(SWB)	97
GEAT(SWB)	75
(SWB)	97
4G64(LWDI)	92
Clutch	
Type	
D4BA	Dry single-disc
D4BF	Dry multi-disc
D4BF	Dry single-disc
GEAT	Dry single-disc
4G64	Dry single-disc

Oil pressure type	
D4BA	Oil pressure type
D4BF	Oil pressure type
D4BF	Oil pressure type
GEAT	Oil pressure type
4G64	Oil pressure type
Transmission	
Type	
1+5 speed	
D4BA	Synchronous transmission
D4BF	Synchronous transmission
D4BF	Synchronous transmission
GRAT	Synchronous transmission
4G64	Synchronous transmission
Reverse	
D4BA	Constant-mesh transmission
D4BF	Constant-mesh transmission
D4BF	Constant-mesh transmission
GEAT	Constant-mesh transmission
4G64	Constant-mesh transmission

Reducer ratio	
1.51	
D4SA	4.200
D4SF	3.987
D4BH	3.918
G8AT	3.918
4G64	3.961
2.00	
D15A	2.355
D4BF	2.136
D4BH	2.281
G8AT	2.281
4G64	2.136
3.00	
D4SA	1.505
D4SF	1.380
D4BH	1.305
G8AT	1.305
4G64	1.380
2.00	
D15A,D15F,D4BH,G8AT,4G64	1.000
5.00	
D15A	0.807
D4BF	0.866

	1.000	0.929
G8AT	0.929	
4G64	0.906	
D4BH	1.142	
D4SF	1.578	
D4BH	3.826	
G8AT	3.925	
4G64	3.378	
0.900		
D4SF,D4BH,4G64	0.2	
G8AT,4G64	0.7	
Automotive transmission		
3.000L	10.101	
1.51	2.526	2.626
2nd	1.483	1.483
3rd	1.000	1.000
4th	0.730	0.586
Reverse	2.702	2.702

Transfer		Brake	
Type	Constant-mesh transmission	Type	Disc
Gear ratio		Front	Front
H	1.00	Rear	Vacuum
L	1.92	Brake fluid	DOT 3
Suspension		Electrical system	
Front		Battery capacity (A·h)	
Camber	1.30	2.5 DSL NA,T/C,TCI	68 or 100 (calc. zero)
Caster	2.55°	3.0GSL, 2.6GSL	66
Toe-in	6.0-9.0 mm	Alternator capacity (A)	
Rear		2.5 DSL NA,T/C,TCI	68 or 75 (W0A85)
Camber	0	3.0GSL, 2.6GSL	75 or 90 (W0A85)
Toe-in	3 mm	Start. motor capacity (Kw)	
Steering system		2.5 DSL NA,T/C,TCI	2.0 or 2.2
Steering gear type		3.0GSL, 2.6GSL	1.2
Power steering	Vehicle load & m. type	Ignition type	Compressed air type Spark ignition type
Angle		2.5 DSL NA,T/C,TCI	
Inside	22.30	3.0GSL, 2.6GSL	
Outside	26.00		

Lubrication chart

Items	GL & Grease Standard	Grade
Engine oil	Select engine oil of the proper SAE viscosity number according to the atmospheric temperature.	3.0 GSI 2.7 3.5 GSI 6.5 2.6 GSI 4.5
Automatic transmission	DIAMOND ATF SP-2	1.7
Manual transmission and transfer oil	Hypoid gear oil API GL-4, or higher SAE viscosity SAE 75w/95w	Transmission oil 2.0 GSI 2.7 2.5 GSI (KA TCI) 2.2 2.0 GSI (TCI) 2.7 2.6 GSI 2.0 Transfer oil 2.2
Brake fluid & clutch fluid	SAC J1703/DOT 3	As required
Power steering fluid	ATF Dexron II A ATF SP	As required
Differential gear oil	Hypoid gear oil API GL 5 or higher SAE viscosity SAE 80w/90 (for conventional type) MITSUBISHI genuine Gear oil part No. 8149630E or CASTROL HYPOY LS (for limited slip differential type)	Front 1.1 Rear No.6 1.6 No.7 2.3

غالفوبدر