


**DAIHATSU**  
**TYPE CB**  
**ENGINE**

[CB-23, CB-61 & CB-80]

**DAIHATSU MOTOR CO., LTD.**  
**NO.9173-GE**



# WORKSHOP MANUAL



[CB-23, CB-61 & CB-80]

## FOREWORD

This workshop manual contains essential information regarding the construction, operation, adjustment procedure and servicing method of the Type CB-23, CB-61 and CB-80 engines which are mounted on the DAIHATSU CHARADE.

The contents and specifications in this manual may be partly revised without advance notice and without incurring any obligation to us.

**Published in June, 1987**

DAIHATSU MOTOR CO., LTD.

WM-30070



## SECTION INDEX

NAME	SECTION
GENERAL INFORMATION	<b>1</b>
THE ENGINE PROPER	<b>2</b>
ENGINE TUNE-UP	<b>3</b>
IN-VEHICLE SERVICE	<b>4</b>
ENGINE MECHANICALS	<b>5</b>
FUEL SYSTEM	<b>6</b>
LUBRICATION SYSTEM	<b>7</b>
COOLING SYSTEM	<b>8</b>
TURBOCHARGER SYSTEM	<b>9</b>
ENGINE ELECTRICAL SYSTEM	<b>10</b>
INTAKE SYSTEM	<b>11</b>
EXHAUST EMISSION CONTROL SYSTEM	<b>12</b>
APPENDIX	<b>13</b>



**DAIHATSU**  
**TYPE CB**  
**ENGINE**

[CB-23, CB-61 & CB-80]

## **SECTION 1**

# **GENERAL INFORMATION**

<b>HOW TO USE THIS WORKSHOP MANUAL</b> .....	1-2
<b>INSTRUCTIONS ON SERVICE OPERATIONS</b> .....	1-3
<b>JACKING POINTS AND SUPPORTING POINTS</b>	
<b>OF SAFETY STANDS</b> .....	1-5
<b>SUPPORTING POINTS OF TWO-POST LIFT</b> .....	1-5
<b>LOCATION OF ENGINE TYPE AND</b>	
<b>ENGINE NUMBER</b> .....	1-6
<b>ENGINE TYPE EMBOSSED POSITION</b> .....	1-6
<b>ENGINE NUMBER STAMPED POSITION</b> .....	1-6
<b>ABBREVIATION CODES</b> .....	1-7
<b>MAIN SPECIFICATIONS</b> .....	1-9

WV-1-001

## GENERAL INFORMATION

### HOW TO USE THIS WORKSHOP MANUAL

#### [Articles To Be Prepared]

As regards general tools (those tools which are normally provided in a service shop), jacks and other standard equipment, they are omitted in this workshop manual.


As for those Special Service Tools (SSTs) which are necessary for the service operations, they are posted collectively in the tables under SECTION 11 APPENDIX. Hence, please prepare them prior to the service operation.

In respect to instruments, lubricants and so forth, be sure to use those designated by Daihatsu.


WA-01002

#### [Composition]

1. The component diagram is provided in the beginning of each section. Refer to this component diagram whenever you want to assure the shape or the part name of each part during the installation operation or the removal operation.
2. In principle, each section is arranged in the following order. However, it should be noted that the composition for the in-vehicle operation differs from this order.



However, instances where the removal or the installation is comparatively easy or no SST or the like is required, the arrangement is made as follows:



3. With regard to the tightening torque specifications, they are indicated in the Engine Components and Tightening Torque under SECTION 3-10. In addition, they are shown in the tables under SECTION 11 SERVICE SPECIFICATIONS.

However, as for those items where no specific tightening torque is mentioned, perform the operation referring to the Tightening Torque for Main Components under SECTION 00.

WA-01003

#### [Numerals]

As regards those numerals which are posted under "Inspection" and under sections other than SECTION 11 SERVICE SPECIFICATIONS, those numerals from the specified values to the allowable limits are posted. As for those numerals which are posted under SECTION 11 SERVICE SPECIFICATIONS, those numerals concerning the specified values and allowable limits are indicated separately.

WA-01004

#### [NOTE]

1. "NOTES" posted in the main text clearly show those items which need particular attention or prohibited items which must be avoided during the service operation.
2. Prior to the operation, make certain to take any necessary precautionary measures so as to prevent personal injury during the removal/installation of parts.

WA-01005



**INSTRUCTIONS ON SERVICE OPERATIONS**

1. Make sure that only the specified bolts and nuts are used. Also, where specified, be sure to employ a torque wrench to tighten bolts or nuts to specifications.
2. When tightening or slackening bolts, be sure to progressively tighten or slacken them over several stages, slightly at a time. This caution must be observed to prevent the tightened parts from being distorted or damaged.
3. Use only genuine parts for every replacement operation.
4. For increased working efficiency and improved accuracy, utilize SSTs (Special Service Tools) effectively.
5. When both front and rear sections of the vehicle or only the rear section thereof is jacked up, make certain to place chocks at the wheels correctly in order to assure safe operations.
6. When the vehicle is jacked up, make sure to support the vehicle with safety stands positioned at the specified jacking points.
7. Before any repair work is made on the electrical system or the engine is removed or installed, first be sure to disconnect the negative (-) terminal of the battery.
8. Disassembly
  - (1) When complicated parts are disassembled, put stamped marks or trace marks on suitable non-functional sections of the parts in order that the said parts may be easily assembled in the correct original positions.
  - (2) Replacements of the cylinder block or crankshaft, etc. should be carried out after the engine assembly has been removed from the vehicle.
9. Checks to be performed during disassembly  
Each time a part is removed, check conditions under which the part has been assembled. Also, check to see if the part exhibits any evidence of distortion, breakage, wear or scores, etc.
10. Arrangement of disassembled parts  
Put disassembled parts in a good order. Moreover, divide disassembled parts into two groups: those parts to be replaced and those parts which can be reused.
11. Washing disassembled parts  
As for those parts which can be reused, thoroughly clean or wash them. (except grease sealed bearing)
12. Inspection  
Those parts which are to be reused must be carefully inspected or measured, as required.
13. Those operations specified under 'Inspection' are performed, in principle, in combination with the checks and repairs. It is, therefore, necessary to replace any part which does not conform to the specifications. However, in cases where otherwise specified in the main text, be sure to follow the given instructions.
14. Assembly of parts  
Those satisfactory parts only should be assembled in accordance with the prescribed standards (e.g. specified adjustment values, tightening torque and so forth).  
Furthermore, seal packing or grease should be applied, as required.  
Furthermore, in respect to packings, gaskets, oil seals and similar items, be certain to install new parts.
15. Adjustments and checking of service operations  
Service operations must be carried out correctly by means of gauges or testers, if the use of these instruments is required.
16. Never smoke during the service operation. Also, be sure not to allow any fire to be brought near the working bay.
17. Under no circumstances should your hand touch with the front side and back sides, the installation surfaces of each bearing insert. Also, be very careful not to scratch the surfaces. Do not wipe off the bearing surfaces with a cloth. Be certain to blow off them, using compressed air.  
Protect your eyes with safety glasses during this cleaning.

## GENERAL INFORMATION

---

18. The warming-up state of the engine means a state in which the temperature of the cooling water reaches at least 75 - 85°C (167 - 185 F) and the temperature of the engine oil reaches at least 65°C (149 F).

These temperatures can be judged by observing a point where the cooling fan motor ceases its rotation.

**NOTE:**


When the idle speed is checked on Type CB-80 engine, special warming-up procedure is required. Hence, be sure to refer to the section under "Checking Idle Speed."

WA-31006

## JACKING POINTS AND SUPPORTING POINTS OF SAFETY STANDS

### • Jacking point

- Front side     Engine mounting center member (Place the jack below the member, exercising care of the exhaust pipe )  
 Rear side     Center of rear floor cross member



### • Supporting points of safety stands

- Four supporting points are located at the right and left sides. (The supporting points have been strengthened by spot-welding reinforcements. Never support the vehicle at points other than the specified points.)




Fig. 1-1

WP-01007

## SUPPORTING POINTS OF TWO-POST LIFT

- Align the supporting pads of a two-post lift with the supporting points of safety stands, as indicated in the figure above.




Fig. 1-2

WP-01008

## GENERAL INFORMATION

### LOCATION OF ENGINE TYPE AND ENGINE NUMBER

#### ENGINE TYPE EMBOSSED POSITION

The engine type is embossed on the power train side of the cylinder block.

#### ENGINE NUMBER STAMPED POSITION

##### 1. CB-23 and CB-61

The engine serial number is stamped on the cylinder head at the front end section.

For the Australian specifications, the engine number is stamped also at the side of the embossed engine type.




Fig. 1-3

MF-01009

##### 2. CB-80

The engine serial number is stamped on the cylinder head at the rear end section.




Fig. 1-4

WH01013

## BBREVIATION CODES

The abbreviation codes that appear in this workshop manual stand for the following, respectively.

Abbreviation code	Original word	Meaning
RH	Right Hand	Refers to right side
LH	Left Hand	Refers to left side
FR	FRONT	Refers to front side.
RR	REAR	Refers to rear side
STD	Standard	When referring to automotive parts, "standard" represents those parts which have been installed originally by the manufacturer and which have standard dimensions.
O/S	Over Size	In instances where fitting becomes too loose due to wear resulting from use for a long period of time or due to frequent removal/installation operations, a fitting part (e.g. piston) is replaced with a part having larger dimensions. The other mating part may be put into use again. "Over sized" parts denote those parts having larger dimensions compared with standard parts.
U/S	Under Size	In the same manner as with the "oversized" parts, a fitting part (e.g. bush and bearing) is replaced with a part having smaller bore dimensions. The other mating part may be put into use again. "Under sized" parts denote those parts having smaller dimensions compared with standard parts.
ATDC	After Top Dead Center	Refers to position of piston in cylinder where piston is near but has passed over the top of the stroke
B.TDC	Before Top Dead Center	Refers to position of piston in cylinder where piston is near but has not reached the top of the stroke
IN	Intake	Refers to intake system
EX	Exhaust	Refers to Exhaust system.
PR	Pry Rating	Represents strength of lines. The larger the pry rating number, the stronger the line strength.
SAE	Society of Automotive Engineers	For example, automotive oils are designated as SAE so and so number. These designation numbers have been set forth by the Society of Automotive Engineers in the United States of America (SAE). The larger the SAE number, the higher the oil viscosity. Conversely, the smaller the SAE number, the lower the oil viscosity.
API	American Petroleum Institute	The standards set forth by the American Petroleum Institute (abbreviated as API Classification) have been employed to evaluate and classify properties of various oils. Engine oils for gasoline engines are classified as SD, SE and so on, whereas engine oils for diesel engines are classified as CC, CD and so on.
SST	Special Service Tool	Refers to a tool designed for a special purpose.
T	Torque	Refers to tightening torque.
S.A	Sub-Assembly	Refers to a component comprising more than two single parts which are welded, stacked, or sludded to each other to form a single component.
Asy	Assembly	Refers to an assembled component comprising more than two single parts or sub-assembly parts.
W	With	Denotes that the following part is attached.
L	Less	Denotes that the following part is not attached.
MT	Manual Transmission	Refers to manual type transmission.
AT	Automatic Transmission	Refers to automatic transmission.
T.C	Turbo Charger	
WG	Waste Gate	Refers to exhaust by-pass.
AC	Air Cleaner	

## GENERAL INFORMATION

### List of Abbreviated Component Names of Exhaust Emission Control System

The table below shows abbreviated component names of the exhaust emission control system. The components of the exhaust emission control system are described in this manual in their abbreviated forms.

	Abbreviation	Component name
1	BvSV	B meta Vacuum Switching Valve
2	CO	Choke Operer
3	DP	Dashpot
4	VTV	Vacuum Transmitting Valve
5	VS	Vacuum Switch
6	AD	Advance
7	T.P	Throttle Positioner
8	TVSV	Thermostatic Vacuum Switching Valve
9	EGF	Exhaust Gas Recirculation

WV-07312

## AIN SPECIFICATIONS

Item		Engine type	CG-20	CG-41	CG-80
Type			Perfor. 4-cycle	Perfor. 4-cycle	Perfor. 4-cycle
Mounting location			Front	Front	Front
Cylinder No. and arrangement			3-cylinder in-line mounted horizontally	3-cylinder in-line mounted horizontally	3-cylinder in-line mounted horizontally
Combustion chamber type			Multi-sphere type	Multi-sphere type	Perfor. type
Valve mechanism			Ball-driven overhead camshaft	Ball-driven overhead camshaft	Ball-driven (DOHC)
Bore x stroke		mm (inch)	75 x 73 (2.99 x 2.87)	75 x 73 (2.91 x 2.87)	75 x 73 (2.95 x 2.87)
Compression ratio			9.5	9.0	7.8
Compression pressure		kg/cm <sup>2</sup> (lb/in <sup>2</sup> )	12.6 (180) (17.7 (254))	10.0 (140) (13.0 (185))	10.3 (140) (14.0 (200))
Maximum output	SAE net	kW/rpm	General specifications 32.5/500	50.5/500	74.6/500
	EEC	kW/rpm	Australian specifications 38.5/500	50.5/500	—
	EEC DIN	kW/rpm	ECE & EEC specifications 36.5/500	50.5/500	74.6/500
Maximum torque	SAE net	Nm/rpm	General specifications 75.5/2300	105.3/2300	130.0/2300
	EEC	Nm/rpm	Australian specifications 75.5/2300	105.3/2300	—
	EEC DIN	Nm/rpm	ECE & EEC specifications 75.5/2300	106.0/500	130.0/500
Engine dimensions (Length x width x height)		mm (inch)	566 x 536 x 536 (22.28 x 20.87 x 20.94)	563 x 520 x 502 (22.17 x 20.47 x 19.69)	576 x 573 x 524 (22.68 x 22.55 x 20.67)
Service engine weight		kg (lb)	92 (202.9)	96 (212)	135 (297.7)
Number of piston rings	Compression ring		2	2	2
	Oil ring		1	—	—
Valve timing	Intake	Open	1° BTDC	1° BTDC	2° BTDC
		Close	51° ABDC	49° ABDC	51° ABDC
	Exhaust	Open	51° ODC	49° BDC	45° BDC
		Close	10° ATDC	11° ATDC	11° ATDC
Valve clearance	mm (inch)				
Idle speed	rpm				
Blow-by gas recirculating system			Closed type	Closed type	Closed type
Lubricating method			Fully-pressurized feed method	Fully-pressurized feed method	Fully-pressurized feed method
Oil Pump type			Trochoid type	Trochoid type	Trochoid type
Oil filter type			Ful-flow filter type / filter paper type	Ful-flow filter type / filter paper type	Ful-flow filter type / filter paper type
Lubricating System	Capacity of capacity	Whole	3.2	3.2	3.3
		When only oil is changed	2.7	2.7	2.7
		When oil and oil filter are changed	3.0	3.3	3.1
Oil cooler type			Water-cooled type (only for tropical spec.)	Water-cooled type	Water-cooled type
Supercharger type			—	Turbocharger	Turbocharger

USA and Norwegian specifications

WM 01013

# GENERAL INFORMATION

Item		Engine type	C8-23	C8-41	C8-50	
Cooling System	Cooling method		Water cooled, electromagnetic type	Water cooled, electromagnetic type	Water cooled, electromagnetic type	
	Radiator type		Conjugate type mesh radiator	Conjugate type forced circulation	Conjugate type forced circulation	
	Coolant capacity	Manual transmission	3.5 (Including 0.6 for reserve tank)	3.9 (Including 0.5 for reserve tank)	4.0 (Including 0.6 for reserve tank)	
		Automatic transmission	3.9 (Including 0.6 for reserve tank)	—	—	
	Water pump type		Centrifugal type, V-belt-drive type	Centrifugal type, V-belt-drive type	Centrifugal type, V-belt-drive type	
	Thermostat type		Wax pellet type	Wax pellet type	Wax pellet type	
Air Filter	Type		1st paper type	Filter paper type	Filter paper type	
	Number		1	1	1	
Fuel System	Fuel tank	Capacity	37	40	40	
		Location	Mounted underneath rear seat floor	Mounted underneath rear seat floor	Mounted underneath rear seat floor	
	Fuel pipe material		Rubber and steel type	Steel tube	Steel tube	
	Fuel pump type		Gear-type	Electromotor type	Electromotor type	
	Fuel filter type		Filter paper type	Filter paper type	Filter paper type	
	Carburetor	Manufacturer		Aitar Kagyo	Aitar Kagyo	—
		Type		Two-barrel type	Two-barrel type	—
		Throttle valve diameter	mm (inch)	28 (1.10), 25 (1.26)	28 (1.10), 22 (1.26)	—
		Venturi diameter	mm (inch)	18 (0.71), 25 (1.00)	18 (0.71), 28 (1.10)	—
	Choke valve type		Manual type, butterfly-shaped valve	Manual type, butterfly-shaped valve	—	
	Fuel injection device		—	—	Electronic type	
	Injection pump	Type		—	—	
		Injection timing		—	—	
		Punger diameter	mm (inch)	—	—	
		Cam lift	mm (inch)	—	—	
Type of self-aligner			—	—		
Injection nozzle or injector	Type of nozzle orainer		—	With cushion rubber type		
	Nozzle type		—	Electronic controlled throttle type		
	Injection pressure	kg/cm <sup>2</sup> (Psi)	—	—	2.53 (116.4)*	
Engine electrical system	Ignition system	Voltage	12 (Negative ground)	12 (Negative ground)	12 (Negative ground)	
		Type	Battery ignition type	Battery ignition type	Battery ignition type	
		Ignition timing	ATDC 5°±2 (timing)	ATDC 10°±2 (timing)	ATDC 10°±2 (timing)	
		Firing order	1-2-3	1-2-3	1-2-3	
	Circuit	Switcher type		Conventional type	Conventional type	Full transistorized type
		Breaker type		Contact-point type	Contact-point type	—
		Reference timing advance mechanism	Cam type	0°-750 rpm, 10.5°-2.500 rpm	0°-750 rpm, 13.5°-2.000 rpm	Electronic timing advance
			Vacuum type	0°-100 mmHg, 11°-220 mmHg	0°-60 mmHg, 10°-450 mmHg	Electronic timing advance

\*Punger stroke: 1.87 ± 0.02 mm (0.073 ± 0.0012 inch)

WJ-C1014



# GENERAL INFORMATION

		Engine type				CB-23				CB-21				CB-20			
		Manufacturer		DENSO	NGK	BOSCH	DAIICHI	DENSO	NGK	BOSCH	DAIICHI	DENSO					
Ignition system	Spark plug	Type		For ECE & EEC	A16FRJ	SFR4	SFR2	AF20	PR10	AF20	PR10	AF20	PR10	AF20	PR10	AF20	PR10
		Type		Except for ECE & EEC	A16R	SFR4	SFR2	AF20	PR10	AF20	PR10	AF20	PR10	AF20	PR10	AF20	PR10
		Thread		M14 x 1.25				M14 x 1.25				M14 x 1.25					
		Spark plug gap (mm/inch)		0.7-0.8 (0.028-0.031)	0.7-0.8 (0.028-0.031)	0.7-0.8 (0.028-0.031)	0.7-0.8 (0.028-0.031)	0.7-0.8 (0.028-0.031)	0.7-0.8 (0.028-0.031)	0.7-0.8 (0.028-0.031)	0.7-0.8 (0.028-0.031)	0.7-0.8 (0.028-0.031)	0.7-0.8 (0.028-0.031)	0.7-0.8 (0.028-0.031)	0.7-0.8 (0.028-0.031)	0.7-0.8 (0.028-0.031)	0.7-0.8 (0.028-0.031)
Side plug	Type	-															
	Voltage-current	V/A															
Engine electrical system	Battery	General specifications		34B17L *1)55B24L				34B17L *1)55B24L				34B17L *1)55B24L					
		Type		ECE & EEC specifications				55B24L				55B24L					
		Australian specifications		34B17L				34B17L				-					
	Capacity	General specifications		27 (5-PR) *1)36 (5-PR)				27 (5-PR) *1)36 (5-PR)				27 (5-PR) *1)36 (5-PR)					
		ECE & EEC specifications		36 (5-PR)				36 (5-PR)				36 (5-PR)					
		Australian specifications		27 (5-PR)				27 (5-PR)				-					
Alternator	Type	3-Phase alternating current commutating type				3-Phase alternating current non-commutating type				3-Phase alternating current commutating type							
	Output	V/A		12-45 *1)12-50				12-45				12-50					
Starter	Regulator type	Contact-pointless type				Contact-pointless type				Contact-pointless type							
	Type	Wagner engaging type				Wagner engaging type				Wagner engaging type							
Ratio noise suppressing device	Output	V/A		12-20.7 *1)12-20.8 *1)12-10				2-0.6 *1)2-1.0				12-0.6 *1)12-1.0					
	Type		Resistive cord				Resistive cord				Resistive cord						

- \*1)Option
- \*General & Australian specifications mounted with manual transmission
- \*ECE & EEC specifications mounted with manual transmission
- \*Vehicles mounted with automatic transmission
- \*Norwegian specifications with automatic transmission mounted inside

ATA-01214



**DAIHATSU**  
**TYPE CB**  
**ENGINE**

[CB-23, CB-61 & CB-80]

## **SECTION 2**

# **THE ENGINE PROPER**

<b>ENGINE SECTIONAL VIEWS .....</b>	<b>2- 2</b>
CB-23 .....	2- 2
CB-61 .....	2- 4
CB-80 .....	2- 6
<b>ENGINE COMPONENTS AND</b>	
<b>TIGHTENING TORQUE .....</b>	<b>2- 8</b>
CB-23 and CB-61 .....	2- 8
CB-80 .....	2- 9
<b>MAIN SERVICE SPECIFICATIONS .....</b>	<b>2-10</b>

WM-32001

ENGINE SECTIONAL VIEWS

CB-23




Fig. 2-1




Fig. 2-2

WM-02003




Fig. 2-3




Fig. 2-4




Fig. 2-5






Fig. 2-6

# ENGINE COMPONENTS AND TIGHTENING TORQUE

CB-23 and CB-61




Fig. 2-7




Fig. 2-8

# THE ENGINE PROPER

## MAIN SERVICE SPECIFICATIONS

Item		Specified value			Remarks
		CB-23	CB-6*	CB-6C	
Engine rpm	rpm	1975 ± 50 ~ 1950 ± 50	1900 ± 50	650 ± 50	
Oil temperature	General specifications				
	Oil & seal specifications	25 ~ 13	65 ~ 15	15 ~ 15	
Compression pressure	Specified value	12.0 (20.1) ~ 13.0 (23.5)	12.0 (20.1) ~ 13.0 (23.5)	12.5 (20.1) ~ 13.0 (23.5)	
	Allowable limit	10.5 (18.9) ~ 14.5 (26.5)	10.5 (18.9) ~ 14.5 (26.5)	10.5 (18.9) ~ 14.5 (26.5)	
	Diff. range between cylinders	Within 0.5 (0.9)	Within 0.5 (0.9)	Within 0.5 (0.9)	
Valve clear. (mm)	Inn.	0.20 (0.0079)	0.25 (0.0098)	0.21 (0.0083)	
	Out.	0.20 (0.0079)	0.25 (0.0098)	0.22 (0.0087)	
Lubrication system	Tank capacity	3.3	3.3	3.0	
	Oil level (oil level)	2.7	2.7	2.7	
	Oil pan capacity (oil level)	1.7	1.7	1.7	
Foot step	mm (inch)	72 (2.83)	22 (0.87)	—	Measured to 1 mm (1/32 inch) of turn.
Radiator cap gasket opening pressure	Specified value	0.75 ~ 1.05 (10.7 ~ 14.9)	0.75 ~ 1.05 (10.7 ~ 14.9)	0.75 ~ 1.05 (10.7 ~ 14.9)	
	Allowable limit	0.6 (8.5)	0.6 (8.5)	0.6 (8.5)	
Radiator leak test pressure	kg/cm <sup>2</sup> (psi)	1.2 (17)	1.2 (17)	1.2 (17)	
Alber deflection	mm/kg (in./lb)	5.7 (0.10) ~ 20.0 (39.3) (1)	5.7 (0.10) ~ 20.0 (39.3) (1)	19.0 (0.36) ~ 20.0 (39.3) (1)	
Cooling water capacity	Total capacity (AT)	3.5 (3.9)	3.3	4.0	including 0.5 liter (reserve tank)
	Reserve tank capacity	0.0	0.5	0.5	
Anti-freezing capacity	-10°C (23°F)	0.66 (AT) ~ 0.75 (AT) (0.14)	0.75 (0.14)	0.77 (0.14)	1 liter (0.26 gallon) for reserve tank
	-20°C (32°F)	1.00 (AT) ~ 1.14 (AT) (0.21)	1.14 (0.21)	1.14 (0.21)	
	-30°C (50°F)	1.44 (AT) ~ 1.54 (AT) (0.30)	1.54 (0.30)	1.68 (0.33)	
Dist. belt	Dist. angle	59° ~ 60°	58° ~ 65°	—	
	Free jaw interference	0.4 ~ 0.3 (0.015 ~ 0.022)	0.4 ~ 0.3 (0.015 ~ 0.020)	—	
Spark plug	Year make:	DENSO NGK BOSCH CHAMPION DENSO NGK BOSCH CHAMPION DENSO NGK			
	for CB-23 & CB-6	AWD-16R AWD-16R AWD-16R AWD-16R AWD-16R AWD-16R AWD-16R AWD-16R AWD-16R AWD-16R			
	for CB-6C & CB-6C	AWD-16R AWD-16R AWD-16R AWD-16R AWD-16R AWD-16R AWD-16R AWD-16R AWD-16R AWD-16R			
Spark plug gap (mm/inch)	0.7 ± 0.05 (0.028 ± 0.002)	0.7 ± 0.05 (0.028 ± 0.002)	0.7 ± 0.05 (0.028 ± 0.002)	0.7 ± 0.05 (0.028 ± 0.002)	0.6 ± 0.05 (0.024 ± 0.002)
Ignition timing	Manual transmission	BTDC 21° ± 2° 550 ± 50 rpm	BTDC 10° ± 2° 800 ± 50 rpm	BTDC 13° 350 ± 50 rpm	
	Automatic transmission	BTDC 9° ± 2° 550 ± 50 rpm	—	—	

\*2000 cc (121 cu in) for heavy duty specification with CB-23 and CB-6 only.

2M-C26

**DAIHATSU**  
**TYPE CB**  
**ENGINE**

[CB-23, CB-61 & CB-80]



**SECTION 3**  
**ENGINE TUNE-UP**

ENGINE TUNE-UP PROCEDURE .....	3- 2
ENGINE TUNE-UP [CB-23 and CB-61] .....	3- 6
ENGINE TUNE-UP [CB-80] .....	3-19

WV-C201

# ENGINE TUNE-UP

## ENGINE TUNE-UP PROCEDURE

**NOTE:**

The operation enclosed by heavy lines is described in the main text.

Checking cooling water level and engine oil level:

Specified value:  
Cooling water capacity:  
(including reserve tank capacity of 0.6 liter)

Item	Engine type		
	CB-23	CB-61	CB-80
Manual transmission	3.8	3.9	4.0
Automatic transmission	3.8	—	—

Specified value  
Engine oil capacity:

Item	Engine type		
	CB-23	CB-61	CB-80
When only one is changed	2.7	2.7	2.7
When oil and oil filter are changed	3.0	3.0	3.1

Specified value:  
Radiator cap opening pressure:  
0.75 - 1.05 kg/cm<sup>2</sup> (1.7 - 2.3 psi)

Checking battery electrolyte level and specific gravity

Specified value:  
Battery electrolyte specific gravity:  
(at electrolyte temperature of 20°C)  
1.27 to 1.29 (34B-17L)

**[NOTE]**

The vehicles mounted with a maintenance-free battery should be checked by a battery checker.

Checking and cleaning air cleaner

Checking and adjusting spark plugs

Spark Plug Specifications

Engine type	CB-23				CB-61				CB-80	
	MANUFACTURER	MODEL	NGK	ESKO	DAIHATSU	EMCO	NGK	ESKO	DAIHATSU	DENSO
ECE & EEC	WAFR4	SPR4H	SPR4	WAF4C	WAF4C	WAFR4	SPR4	WAF4C	WAF4C	WAFR4
Excludes: ECE & EEC	WAFR4	SPR4H	SPR4	WAF4C	WAF4C	WAFR4	SPR4	WAF4C	WAF4C	WAFR4
Spark plug gap (mm/inch)	0.7 - 0.8 (0.028 - 0.031)		0.8 - 0.85 (0.031 - 0.033)	0.7 - 0.8 (0.028 - 0.031)		0.7 - 0.8 (0.028 - 0.031)	0.7 - 0.8 (0.028 - 0.031)		0.9 - 1.0 (0.035 - 0.039)	

Checking resistive cords

... Specified value.

Item	Engine type		
	CB-23	CB-61	CB-80
Cord No. 1	6.8 - 10.0	6.8 - 10.0	9.2 - 4.3
Cord No. 2	5.1 - 12.1	5.1 - 12.1	4.6 - 7.0
Cord No. 3	8.1 - 12.1	5.1 - 12.1	7.0 - 10.3
Center cord	8.1 - 9.2	5.1 - 9.2	5.1 - 7.7

kΩ

Checking and adjusting V-belt for deflection

... Specified deflection:  
Cooling water capacity  
(including reserve tank capacity of 0.6 liter)

Item	Engine type		
	CB-23	CB-61	CB-80
V-belt deflection	3.1-10 (0.10-0.35-22.5)	4.7-15 (0.20-0.25-22)	7.5-25.5 (0.30-0.25-17.0)

mm/kg (inch/lb)

Checking cylinder head and manifolds for tightening condition

... Specified value:  
Cylinder head tightening torque & Manifold tightening torque

Item	Engine type		
	CB-23	CB-61	CB-80
Cylinder head tightening torque	5.5 - 6.5 (40 - 47)	5.5 - 6.5 (40 - 47)	5.0 - 7.0 (43 - 51)
Exhaust manifold tightening torque	1.0 - 1.0 (7 - 12)	1.0 - 1.6 (7 - 12)	4.0 - 5.0 (29 - 36)
Intake manifold tightening torque	1.0 - 1.6 (7 - 12)	1.0 - 1.6 (7 - 12)	1.7 - 2.5 (12.9 - 18)

kg-m (ft.-lb)

Warming-up engine  
(Cooling water temperature: 75 to 80°C)

Checking valve clearances

... Specified clearance:  
(Clearance between cam and rocker arm)

Item	Engine type		
	CB-23	CB-61	CB-80
IN (When hot)	0.20 (0.0079)	0.25 (0.0098)	0.27 (0.0101)
EX (When hot)	0.20 (0.0079)	0.25 (0.0098)	0.32 (0.0126)

mm (inch)

**[NOTE]**

"HOT" denotes a period during which the engine block temperature is above 80°C (176°F) after the vehicle has been warmed up completely.

# ENGINE TUNE-UP

Checking compression pressure

Item	Engine type	kg/cm <sup>2</sup> (psi)		
		CB-23	CB-61	CB-80
Specified value (350 rpm)		2.5 (177.8)	2.0 (170.7)	10.5 (300 rpm) (148.1 - 300 rpm)
Minimum requirement (350 rpm)				8.5 (300 rpm) (121 - 300 rpm)
Difference between cylinders				

Checking and adjusting distributor  
(Except CB-80)

Specified value:

Item	Engine type	CB-23		CB-61	
		mm (inch)	mm (inch)	mm (inch)	mm (inch)
Heel gap		0.4 - 0.5 (0.016 - 0.020)	0.4 - 0.5 (0.016 - 0.020)		
Dwell angle	°	55 - 65	55 - 65		

Checking and adjusting ignition timing

Specified value:

Item	Engine type	CB-23	CB-61	CB-80
		Ignition timing	BTDC 10° ± 2° (avg)	BTDC 10° ± 2° (avg)

Checking id'le speed

Specified value:

[NOTE]

Make sure that no additional electrical load such as headlamps is applied to the engine

Item	Engine type	rpm		
		CB-23	CB-61	CB-80
Manual transmission		800 ± 50 (1000 = 50)	800 ± 50 (1000 = 50)	950 ± 50
Automatic transmission		850 ± 50 (1000 = 50)	—	—

( ) Swedish and Norwegian specifications

GM-0006



Measuring CO concentration

Specified value:

Item	Engine type	CB-23	CB-51	CB-80
CO concentration		1 ± 0.5%	1 ± 0.5%	1 ± 0.5%

NOTE: For Swiss specifications, be sure to put off the EGR operation.

Not conformed to specifications

4. Adjusting idling speed

Checking and adjusting fast idle speed

(Except CB-80)

Specified speed:

Item	Engine type	CB-23	CB-51
Engine speed (rpm)		2000 ± 200	2600 ± 200

NOTE: Put the choke button out as far as it will go and depress the accelerator pedal once or twice.

Checking and adjusting idlespot

Specified speed:

Item	Engine type	CB-23	CB-51	CB-80
General specifications		1000 ± 50	1600 ± 50	1600 ± 100
Swiss & Australian specifications		1200 ± 50	1300 ± 50	1600 ± 100
Australian & West German specifications		1200 ± 50	1300 ± 50	1600 ± 100

Checking choke opener for operation

(Except CB-80)

AM-01003

## ENGINE TUNE-UP

---

### ENGINE TUNE-UP [CB-23 and CB-61]

#### Connecting Method of Instruments and Handling Instructions

1. Engine tachometer
  - (1) In the case of a tachometer in which the pick-up is made from the primary circuit and there is no 3-cylinder range, carry out the measurement using the 6-cylinder range. And multiply the reading by 2. This product is the actual rotational speed of the 3-cylinder engine.
  - (2) In the case of a tachometer in which the pulses flowing through the resistive cord of the cylinder No. 1 are sensed, the reading can be read directly regardless of the number of cylinders.
2. The power supply for the tachometer, timing light and other instruments should be connected to the battery terminal.
3. Never disconnect the battery terminals while the engine is running.  
(Failure to observe this caution will cause abnormal pulses to apply to the transistors, even leading to damage of the transistors and other electronic meters, etc.)
4. Care must be exercised to ensure that no water gets to each electric part during the cleaning.
5. Make sure that the CO meter is adjusted and calibrated accurately before it is put into use.
  - (1) Warming-up
  - (2) Zero-point adjustment
  - (3) Span adjustment

MM-02005

**Checking engine oil level**

After the engine has warmed up, stop the engine. A few minutes later, check the engine oil level using a level gauge.

Ensure that the oil level is between the full level and the low level.

**Engine Oil Capacity**

Item \ Engine type	CB-23	CB-6*
Full level	2.7	2.7
Low level	1.7	1.7

**NOTE:**

When the engine oil level is below the specified level, replenish the specified oil to the full level.

(When the engine oil level is below the specified level, check to see if oil leakage exists.)

**2. Checking cooling water level**

Check the cooling water level at the reserve tank. Ensure that the cooling water level is between the full level and the low level.

**NOTE:**

When the cooling water level is below the specified level, replenish the reserve tank with water to the full level.

If the cooling water level is below the low level, remove the radiator cap and check the radiator cooling water for correct level.

If the cooling water level is always below the specified level, check the radiator cap and water leakage, using a radiator cap tester.

**CAUTION:**

Never open the radiator cap when the engine is running or when the cooling water is still hot.

**Cooling water capacity**

CB-23	Manual transmission-equipped vehicle.	3.5 ℓ (Including 0.5 ℓ for reserve tank)
	Automatic transmission-equipped vehicle.	3.9 ℓ (Including 0.6 ℓ for reserve tank)
CB-81	3.9 ℓ (Including 0.6 ℓ for reserve tank)	

WM03009




Fig. 3-1

WM03007



Fig. 3-2

WM03008

## ENGINE TUNE-UP

### 3. Checking air cleaner element

- (1) Visually inspect to see if the air cleaner element is restricted, abnormally dirty or damaged.

**NOTE:**

Replace the air cleaner element, as required.

- (2) Clean the element with compressed air.  
Blow compressed air from the inside or up side of the air cleaner element.




Fig. 3-3

WM-09110




Fig. 3-4

WM-09111

### 4. Checking spark plugs

- (1) Visually inspect the spark plugs for damage or cracks.

**NOTE:**

Replace the spark plug, as required.

- (2) Clean the spark plugs.  
(3) Check and adjust the spark plug gaps.



Fig. 3-5

WM-09112

### Specified Spark Plug Gap

Engine type	CB-23					CB-61			
	DENSO	NGK	BOSCH	CHAMPION	CFRGO	NGK	BOSCH	CHAMPION	
EOE & EEC specifications	W16EXR-U	BR3EAL	BR3EY	AR5DC	RN-11YC	W16EXR-U W20EXR-U	BR3EY BR3EY	WR3DC WR7DC	RN-11YC RN-11YC
Except EOE & EEC specifications	W16EX-U	BR3EAL	BR3EY	WR3DC (X,Y)	RN-11YC	W16EX-U W20EX-U	BR3EY BR3EY	WR3DC (X,Y) WR7DC (X,Y)	RN-11YC RN-11YC
Spark plug gap (mm/inch)	0.7 ± 0.03 (0.028 ± 0.001)	0.7 ± 0.03 (0.028 ± 0.001)	0.7 ± 0.03 (0.028 ± 0.001)	0.7 ± 0.03 (0.028 ± 0.001)	0.7 ± 0.03 (0.028 ± 0.001)	0.7 ± 0.03 (0.028 ± 0.001)	0.7 ± 0.03 (0.028 ± 0.001)	0.7 ± 0.03 (0.028 ± 0.001)	0.7 ± 0.03 (0.028 ± 0.001)

WM-09113

**Checking V-belt**

(1) Visually inspect to see if the V-belt exhibits damage, cracks or wear.

NOTE:

Replace the V-belt, as required.

(2) Measure the amount of belt deflection:

Specified Deflection of V-Belt:  
 5 - 7 mm (0.20 - 0.28 inch)  
 [With a force of 8 kg (17.64 lb) Applied]




Fig. 3-6

AW-02017

**6. Checking valve clearances**

Warm up the engine.

Cooling water temperature: 75 - 85°C (167 - 185 °F)

Check and adjust the valve clearances.

Specified Valve Clearance:  
 CB-23: 0.20 ± 0.05 mm (0.0079 ± 0.002 inch)  
 CB-61: 0.25 ± 0.05 mm (0.0098 ± 0.002 inch)  
 Both for Intake and Exhaust Valves




Fig. 3-7

AW-02015

NOTE:

Carry out the check and adjustment of valve clearances, with the piston of the No.1 cylinder set to the end of the compression stroke or to the tops of the intake and exhaust strokes, respectively. See the table at the right for the adjustable valves for the respective positions of the No.1 piston.

Crank angle	Cylinder	
	2	3
When No.1 piston is set to end of compression stroke	IN ○	EX ○
When No.1 piston is set to tops of intake and exhaust strokes respectively	IN ○	EX ○

AW-02016

**7. Checking compression pressure**

kg/cm<sup>2</sup> (psi) at 350 rpm

CB-23	10.5 - <del>12.5</del> (149.4 - <del>175.3</del> )
CB-61	10.5 - <del>12.0</del> (149.4 - <del>172.4</del> )

NOTE:

The compression pressure check should be performed with all spark plugs removed. Also, be sure to keep both the throttle valve and choke valve fully opened during the check.

The measurement of compression pressure should be performed for a short period of time. Moreover, care must be exercised to ensure that the measurement time for each cylinder becomes equal.

If the specified pressure is not met, check to see if the cylinder-to-piston clearance conforms to the specification. Also check the piston rings for wear.




Fig. 3-8

AW-02018

AW-02013

## ENGINE TUNE-UP

### 8. Checking contact points

(1) Check to see if the contact points exhibit the trace of burning.

(2) Check and adjust the gap of the contact points.

**Specified Heel Gap:**

0.4 - 0.5 mm (0.016 - 0.020 inch)

[Referential Information]

**Specified Contact Point Gap:**

0.4 - 0.5 mm (0.016 - 0.020 inch)

**Specified Dwell Angle:** 58° - 66°




Fig. 3-9

WA-03019

### 9. Checking ignition timing

(1) Disconnect the vacuum hose from the vacuum advancer. Plug the disconnected vacuum hose.

Using a timing light, check the ignition timing while idling the engine.

**Specified Ignition Timing:**

Manual transmission

BTDC 5° ± 2°/800 ± 50 rpm

Automatic transmission

BTDC 5° ± 2°/850 ± 50 rpm

Daylight system-equipped vehicle

BTDC 5° ± 2°/1,000 ± 50 rpm




Fig. 3-10

WA-03020

#### NOTE:

Upon completion of the ignition timing check, be certain to install the clutch housing cover on the inspection window.

### 10. Adjustment

(1) The ignition timing can be adjusted by slackening the retaining bolt of the distributor flange and then by turning the distributor body.

#### NOTE:

When the distributor body is turned counterclockwise, the ignition timing is advanced. Conversely, when the distributor body is turned clockwise, the ignition timing is retarded.




Fig. 3-11

WA-03021

(2) After the adjustment has been completed, reconnect the auxiliary vacuum hose to the vacuum advancer. Ensure that the engine revolution speed rises about 50 to 100 rpm. Also ensure that the engine is emitting a normal sound.

WA-03022

- (3) Securely tighten the retaining bolt of the distributor. Care must be exercised to ensure that the distributor body does not turn during this tightening operation.

Specified Tightening Torque:

1.5 - 2.2 kg-m (10.8 - 15.9 ft-lb)

WV4922

### 11. Checking ignition advance

- (1) Disconnect the vacuum hose and plug the disconnected hose. Accelerate the engine repeatedly. Using a timing light, check to see whether the governor ignition advance is taking place.

#### NOTE:

Prior to starting this test, disconnect the vacuum hose. Make sure to plug the disconnected hose.

- (2) Apply a negative pressure to the vacuum advancer by means of a MilyVac or by sucking the hose.

Ensure that the ignition mark moves in the ignition advance direction.

- (3) Reconnect the vacuum hose in the original position.



Fig. 3-12

WV4924





Fig. 3-13

WV4925

## ENGINE TUNE-UP

### 12. Checking idle speed



W4-03026

#### (1) Precaution

The following notes must be observed before or during the idle speed adjustment.

- ① Warm up the engine thoroughly.
- ② Do not perform the engine idling speed adjustment while the fan motor is functioning.
- ③ Never apply extra loads such as the headlights, rear window defogger or the lke during the adjustment of the engine idle speed. (On the day light-equipped vehicle, keep the headlights glowing.)
- ④ Be sure to install the air cleaner element in place.
- ⑤ Be sure to disconnect the HIC (Hot Idle Compensator) hose and plug the disconnected hose.
- ⑥ Ensure that the choke valve opens fully.
- ⑦ Ensure that the exhaust system exhibits no gas leakage.
- ⑧ Ensure that the intake system exhibits no air leakage.
- ⑨ The idle limit cap can be removed by cutting it off with pliers or the like. (Except the ECE & EEC, Australian, GCC, Singapore specifications) After the adjustment has been completed, be sure to install a new cap. Make sure that it can rotate freely.
- ⑩ The shape of the idle limit cap for the ECE & EEC, Australian, GCC, Singapore specifications differs from that of other specifications. Use the following SST to adjust the cap.  
SST: 09243-00020
- ⑪ On those vehicles whose air cleaner is equipped with a vacuum motor, disconnect the vacuum motor hose and plug the disconnected hose.

W4-03027

#### (2) Initial check and adjustment

- ① Warm up the engine, until the cooling water temperature becomes 75°C - 85°C (167 - 185°F) (As for a guide for this temperature, you may use a point when the fan motor stops running. The idling should not be adjusted while the fan motor is operating.)
- ② Warm up the CO meter.
- ③ If the engine is equipped with a plastic idle limit cap, remove it.
- ④ Ensure that the choke valve opens fully.

#### (3) Test equipment installation

Install an engine tachometer to the engine.

W4-03028



(4) Check and adjustment of idle speed

• **Manual transmission-equipped vehicle**

- ① Back off the idling adjusting screw the specified turns from the fully closed position.  
Specified backing-off turn:  
CB-23 4¾ turns  
CB-61 7 turns
- ② Start the engine. Turn the throttle adjusting screw until the engine runs at 850 rpm.
- ③ Screw in the idle adjusting screw until the engine runs at 800 rpm.  
Specified Idling Speed: 800 ± 50 rpm

• **Automatic transmission-equipped vehicle**

- ① Back off the idle adjusting screw about 4¾ turns from the fully-closed position.
- ② Start the engine. Turn the throttle adjusting screw until the engine runs at 850 rpm.
- ③ Screw in the idle adjusting screw until the engine runs at 850 rpm.  
Specified Idling Speed: 850 ± 50 rpm  
(For Day-Light Relay-equipped vehicle: 1000 ± 50 rpm)

NOTE:

On those engines for ECE & EEC Australian, GCC and Singapore specifications, screw in the idle adjusting screw, using a SST (09243-00020).

WA-13/17




Fig. 3-14

WA-02029

• **Except AS (secondary air suction) system-equipped vehicle**

- (As for the AS system-equipped vehicle, see the next section.)
- ④ Measure the CO concentration.

Specified CO concentration:

General specifications:	5 - 6 %
ECE & EEC specifications:	2.5 - 1.5 %

- ⑤ If the CO concentration does not conform to the specified values, turn the idle adjusting screw. If the engine rotates roughly, check to see if the CO concentration or engine revolution speed drops excessively. Set these values to higher points within the allowable ranges.

WA-13/22




Fig. 3-15

WA-03011

## ENGINE TUNE-UP

### • AS (secondary air suction) system-equipped vehicle

(Australian, and West German specifications)

#### ④ Measure the CO concentration.

- (1) Disconnect the hose between the air cleaner and the air suction valve. Plug the disconnected hose.
- (2) Leave the engine idling for about 10 minutes.
- (3) Check the CO concentration.

Specified CO Concentration:

Not to exceed 1.0 %

- ⑤ If the measured concentration does not conform to the specified value, perform the idle adjustment described below.

#### (5) Idle limit cap installation

Inst. the idle limit cap in the original position. (This applies to those engines equipped with a plastic idle limit cap.)

#### (6) Idle adjustment

- ① Back off the idle adjusting screw the specified turns from the fully-closed state.

Specified Value:

CB-23: About 5 1/4 Turns

CB-61: About 7 Turns

- ② Turn the throttle adjusting screw to set the idling to the specified speed.

Specified idling speed:

Manual Transmission: 800 ± 50 rpm

Automatic Transmission: 850 ± 50 rpm

- ③ Remove the air suction valve.




Fig. 3-16

WA-03033




Fig. 3-17

WA-03034




Fig. 3-18

WA-03035




Fig. 3-19

WA-03036




Fig. 3-20

WA-03037

- ④ Insert the sampling pipe into the air suction pipe. Plug the gap between the air suction pipe and the sampling pipe using heat-resistant tape or the like.




Fig. 3-21

NM-0326

- ⑤ Measure the CO concentration.  
Specified CO Concentration:  
Swiss specifications:  
Not to exceed  $1.5 \pm 0.5$  %  
Australian specifications:  
Not to exceed  $1.0 \pm 0.5$  %  
West German specifications:  
Not to exceed  $1.5 \pm 0.5$  %




Fig. 3-22

NM-0329

- ⑥ If the idling speed does not conform to the specified value, adjust the idle speed by the throttle adjusting screw.




Fig. 3-23

NM-0304

- ⑦ At this time, if the engine rotates roughly, recheck the CO concentration and check to see if the engine rotational speed is too low. Set the CO concentration to 0.5 to 1.5%.




Fig. 3-24

NM-0304

- ⑧ Reinstall the AS valve in the original position.




Fig. 3-25

NM-0304

## ENGINE TUNE-UP

- ⑨ Ensure that the CO concentration decreases.




Fig. 3-25

WM 02943

- ⑩ Ensure that the engine revolution speed is within the specified idle speed.

Specified idle speed:

Manual transmission-equipped vehicle:

800 ± 50 rpm

Automatic transmission-equipped vehicle:

850 ± 50 rpm

### 13. Checking fast idle speed

#### Check

- (1) Warm up the engine.  
(Temperature of coolant 75 - 85°C)
- (2) Stop the engine and pull the choke button out as far as it will go. Depress the accelerator pedal once or twice. Restart the engine.
- (3) After starting the engine, ensure that the choke opener is functioning and that the fast idle adjusting lever rests on the second stage of the fast idle cam.
- (4) Check the engine revolution speed.

Specified Fast Idling Speed:

CB-23: 1800 - 2200 rpm

CB-61: 2400 - 2800 rpm

- (5) Ensure that the engine returns to its idling speed, when the choke button is pushed back to the original position.

#### NOTE-

The operations described in the steps (3) and (4) should be carried out for a short period of time.

#### Adjustment

The fast idling speed can be adjusted by turning the fast idle adjusting screw.




Fig. 3-27

WM 02945




Fig. 3-28

WM 03046

**Checking dashpot****(Dashpot-equipped vehicle only)****(1) Touch revolution speed check**

- ① Start the engine. Disconnect the vacuum hose ① from the diaphragm pipe ②.
- ② Open the throttle so that the throttle touch arm ③ may be held separated from the diaphragm shaft ④.
- ③ Plug the diaphragm pipe by finger.
- ④ Release the throttle valve. Measure the engine revolution speed at a time when the throttle touch arm begins to contact the diaphragm shaft. If this engine speed falls within the following range, it indicates that the system is functioning properly.  
Touch Revolution Speed: 1200 - 1400 rpm




Fig. 3-29

WM-0367

**(2) Adjustment**

- ① Turn the adjusting screw ① so that the specified revolution speed is obtained.
- ② Upon completion of the adjustment, reconnect the vacuum hose. Ensure that the engine revolution speed drops to the idle speed.




Fig. 3-30

WM-0368

**(3) Dashpot function check**

- ① Keep the engine revolution speed at 2500 rpm for a short period of time. Then, release the throttle valve.
- ② Measure the time required for the engine to drop its engine revolution speed from the touch revolution speed to the idle revolution speed.  
Specified Time Required: 0.5 - 5.0 seconds

- (4) If the measured time does not conform to the specified value, check the dashpot for air tightness. Also check the VTV and replace them as required.

**15. Checking choke opener****(Choke opener-equipped vehicle only)**

While the engine is idling, disconnect the vacuum hose connected to the choke opener. If the link functions in the way as described in the table below, it represents that the choke opener is functioning properly.

Cooling water temperature	When hose is reconnected, link moves
- - - - - 29°C or above	(Negative pressure is applied)

If the link will not move, check the BVSV, TVSV or choke opener. Replace them, as required.




Fig. 3-31

WM-0369

## REFERENTIAL INFORMATION


**Simple Checking Method of Valve Timing**

The valve timing can be checked easily at a time when the piston of the No.1 cylinder is set to the top dead center at the end of the compression stroke for the purpose of checking and adjusting valve clearances. The following is the procedure for this simple checking method of valve timing.

**Checking Procedure**

- 1 Turn the crankshaft until the ignition mark on the flywheel is aligned with the ignition mark of the No.1 cylinder.
- 2 When the operation described in the step 1 has been made, check to see whether the check mark on the timing belt cover is lined up with the timing mark on the camshaft pulley, as indicated in the illustration at the right.

When these marks are aligned to each other, the valve timing is correct.



## ENGINE TUNE-UP [CB-80]

### CONNECTING METHOD OF INSTRUMENTS AND HANDLING INSTRUCTIONS

1. Engine tachometer
  - (1) In the case of a tachometer in which the pick-up is made from the primary circuit and there is no 3-cylinder range, carry out the measurement using the 6-cylinder range. And multiply the reading by 2. This product is the actual revolutionary speed of the 3-cylinder engine.
  - (2) In the case of a tachometer in which the pulses flowing through the resistive cord of the cylinder No.1 are sensed, the reading can be read directly regardless of the number of cylinders.
2. The power supply for the tachometer, timing light and other instruments should be connected to the battery terminal.
3. Never disconnect the battery terminals while the engine is running.  
(Failure to observe this caution will cause abnormal pulses to apply to the transistors, even leading to damage of the transistors and other electronic meters, etc.)
4. Care must be exercised to ensure that no water gets to each electric part during the cleaning.
5. Make sure that the CO meter is adjusted and calibrated accurately before it is put into use.
  - (1) Warming-up
  - (2) Zero-point adjustment
  - (3) Span adjustment

W74-02051

## ENGINE TUNE-UP

### 1. Checking engine oil level

After the engine has warmed up, stop the engine. A few minutes later, check the engine oil level using a level gauge.

Ensure that the oil level is between the full level and the low level.

Engine Oil Capacity:

Full level 2.7

Low level 1.7

#### NOTE:

When the engine oil level is below the specified level, replenish the specified oil to the full level.

(When the engine oil level is below the specified level, check to see if oil leakage exists.)




Fig. 3-32

WVA-0336

### 2. Checking cooling water level

Check the cooling water level at the reserve tank. Ensure that the cooling water level is between the full level and the low level.

#### NOTE:

When the cooling water level is below the specified level, replenish the reserve tank with water to the full level.

If the cooling water level is below the low level, remove the radiator cap and check the radiator cooling water for correct level.

If the cooling water level is always below the specified level, check the radiator cap and water leakage, using a radiator cap tester.




Fig. 3-33

WVA-0336

#### CAUTION:

Never open the radiator cap when the engine is running or when the cooling water is still hot.

Cooling water capacity: 4.0 l

(Including 0.6 l for reserve tank)

### 3. Checking air cleaner element

(1) Visually inspect to see if the air cleaner element is restricted, abnormally dirty or damaged.

#### NOTE:

Replace the air cleaner element, as required.




Fig. 3-34

WVA-0336

(2) Clean the element with compressed air.

Blow compressed air from the upper of the air cleaner element.




Fig. 3-35

WVA-0336



**Checking spark plugs**

(1) Visually inspect the spark plugs for damage or cracks

**NOTE:**

Replace the spark plug, as required.

(2) Clean the spark plugs.

(3) Check and adjustment of the spark plug gaps.

**Specified Spark Plug Gap:**

0.9 - 1.0 mm (0.035 - 0.039 inch)

(4) If the spark plug is burnt excessively, replace it with a replacement plug.



Fig. 3-36

WM-03058

Manufacturer:	DENSO	
ECE & EEC specifications	W22ETR-L	W20FTR-L
except ECE & EEC specifications	W22ET-L	W20ET-L

WM-03057

**5. Checking V-belt**

(1) Visually inspect to see if the V-belt exhibits damage, cracks or wear.

**NOTE:**

Replace the V-belt, as required.

(2) Measure the amount of belt deflection.

**Specified Deflection of V-Belt**

7.5 - 8.5 (0.3 - 0.35 inch)

[With a force of 8 kg (18 lb) Applied]




Fig. 3-37

WM-03059

**6. Checking valve clearances**

(1) Warm up the engine.

Cooling water temperature: 75 - 85°C (167 - 185°F)

(2) Check the valve clearances.

**Specified Valve Clearance:**

Intake valve:

0.27 ± 0.05 mm (0.0106 ± 0.002 inch)

Exhaust valve:

0.32 ± 0.05 mm (0.0126 ± 0.002 inch)

Carry out the checking of valve clearances with the piston of the No. 1 cylinder set to the end of the compression stroke or to the tops of the intake and exhaust strokes, respectively. See the table at the right for the adjustable valves for the respective positions of the No. 1 piston.




Fig. 3-38

WM-03060

Crank angle	Cylinder : 1   2   3		
	When No. 1 piston is set to end of compression stroke	IN : C	
When No. 1 piston is set to tops of intake and exhaust strokes respectively	IN	C	EX : O

WM-03061

## ENGINE TUNE-UP

(3) If the valve clearances do not conform to the specified values, replace the adjusting shims, following the procedure given below.

- ① Turn the crankshaft so that the cam lobe of the cylinder to be adjusted assumes nearly the upright position of the valve.

### NOTE:

When the valve clearances are adjusted, make sure that the piston of the cylinder to be adjusted is not at its top dead center.

(If the SST is used when the piston is at its top dead center, the valves may interfere with the piston, thus damaging the valves and piston.)

- ② Set the cut-out section of each lifter to a position indicated in the figure.  
SST: 09248-87703-000

- ③ Insert the SST into between the camshaft and the valve lifter, as shown in the figure.  
In this way, push down the two lifters.

- ④ Using a mini-sized nose pier or the like, raise the adjusting shim through the cut-out section of the lifter.

- ⑤ Select a suitable shim.  
Thickness of shim to be selected =  
Thickness of removed shim + measured valve clearance - specified valve clearance

### [Reference]

Adjusting shim is available in 41 different kinds within range from 2.500 to 3.300 mm in increments of 0.02 mm.




Fig. 3-39

WA-0326




Fig. 3-40

WA-0362




Fig. 3-41

WA-0363




Fig. 3-42

WA-0364

WA-0365

- ⑥ Place the selected shim in the lifter.  
The shim should be placed in such a direction that the surface marked by inerasable ink faces toward the lifter side.

- ⑦ Remove the SST.  
⑧ Ensure that the valve clearances have been adjusted within the specifications.

**NOTE:**

See the section under "Checking valve clearances."

- ⑨ Install the cylinder head cover.

WM-C3058

**7. Checking Ignition timing**

- (1) Warm up the engine.  
(2) Short the terminal T.  
Read the culputted diagnosis code. If any abnormality is detected, perform the trouble shooting. (See the "Trouble Shooting for Type CB-80 Engine Control System.")

- (3) Adjust the idle speed to  $950 \pm 50$  rpm by means of the idle adjusting screw of the throttle body.

- (4) While the engine is idling, check the ignition timing, using a timing light. Ensure that the ignition timing is correct, using the ignition timing mark on the flywheel and the indicator.

**Reference**

Ignition timing:  $10^\circ \pm 2^\circ$  BTDC/950=50 rpm




Fig. 3-43

WM-C3059




Fig. 3-44

WM-C3060




Fig. 3-45

WM-C3061




Fig. 3-46

WM-C3062




Fig. 3-47

WM-C3071

## ENGINE TUNE-UP

### (5) Adjustment

If the ignition mark fails to align with the indicator, slacken the attaching bolts of the distributor. Adjust the ignition timing by turning the distributor body.

#### NOTE:

When the distributor body is turned counterclockwise, the ignition timing is advanced. Conversely, when the distributor body is turned clockwise, the ignition timing is retarded.

### (6) Securely tighten the attaching bolts of the distributor.

#### NOTE:

Care must be exercised to ensure that the distributor body will not turn during this tightening operation.

Tightening Torque: 1.5 - 2.2 kg-m (11 - 16 ft-lb)

### (7) Detach the short pin at the terminal 7.




Fig. 3-48

WM-03072




Fig. 3-49

WM-03073

## 8. Checking idle speed

#### NOTE:

The following notes must be observed before or during the idle speed adjustment.

- ① Warm up the engine thoroughly. (Warm up the engine for about another 15 minutes after the cooling fan has started its operation.)
- ② Do not perform the engine idle speed adjustment while the fan motor is functioning.
- ③ Never apply extra loads such as the headlamps or the like during the adjustment of the engine idle speed. (As for the day-light-equipped vehicles, disconnect the day-light relay connector.)
- ④ Be sure to install the air cleaner element in place.
- ⑤ Ensure that the exhaust system exhibits no gas leakage.
- ⑥ Ensure that the intake system exhibits no air leakage.

WM-03074

### (1) Check and adjustment of idle speed

- ① Install a tachometer and a CO meter.
- ② Turn the bypass screw of the throttle body so that the engine idle speed becomes  $950 \pm 50$  rpm. (When the bypass screw is turned clockwise, the idle speed drops. Conversely, when the bypass screw is turned counterclockwise, the idle speed rises.)

Specified Idle Speed:  $950 \pm 50$  rpm




Fig. 3-50

WM-03075

- ③ Measure the CO concentration, as follows:  
 Adjust the A/F adjuster screw so that the CO concentration becomes  $1 \pm 0.5\%$   
 Specified CO Concentration: 0.5 - 1.5 %

After completion of the adjustment, check to see if the engine idle speed conforms to the specifications. If the idle speed fails to conform to the specifications, repeat the operations ② and ③.

**NOTE:**

Under no circumstances should the adjustment of the A/F adjuster be performed without a CO meter.

(This engine is equipped with the diagnosis function. Therefore, if the A/F adjuster should be adjusted without a CO meter, it may cause an erroneous diagnosis code.)

**9. Checking dashpot****(1) Checking of touch revolution speed**

- ① Warm up the engine.
- ② Disconnect the vacuum hose from the diaphragm pipe.
- ③ Raise the engine revolution speed to about 2500 rpm. Plug the disconnected diaphragm pipe by your finger.

- ④ Release the throttle valve. Measure the engine revolution speed at a time when the throttle touch arm begins to contact the diaphragm shaft.  
 Specified Touch Revolution Speed:  
 $1600 \pm 100$  rpm

If this engine speed drops within the following duration of time, it indicates that the system is functioning properly.

Specified Time: 0.5 - 5 Seconds

**(2) Adjustment of touch revolution speed**

- ① Stop the engine. Slacken the lock nut of the dashpot adjusting screw.
- ② Start the engine.
- ③ Keep the engine revolution speed at about 2500 rpm. Plug the diaphragm pipe of the dashpot by finger.
- ④ Release the throttle valve. Adjust the dashpot adjusting screw so that the touch revolution speed may become the specified value.




Fig. 3-51

WV-0306




Fig. 3-52

WV-0307




Fig. 3-53

WV-0308




Fig. 3-54

WV-0309

## ENGINE TUNE-UP

- ⑤ Stop the engine. Tighten the lock nut of the adjusting screw.
- ⑥ Start the engine. Check the dashpot touch revolution speed.
- ⑦ If the touch revolution speed fails to conform to the specifications, repeat the adjusting procedure above.
- ⑧ Connect the hose.

### (3) Dashpot function check

- ① Keep the engine revolution speed at 3000 rpm for a short period of time. Then, release the throttle valve.
- ② Measure the time required for the engine to drop its engine revolution speed from the touch revolution speed to the idle revolution speed.  
Specified Time Required: 0.5 - 5.0 seconds




Fig. 3-55

WM 02983




Fig. 3-56

WM 43302

**DAIHATSU**  
**TYPE CB**  
**ENGINE**

[CB-23, CB-61 & CB-80]

**4**

## **SECTION 4**

### **IN-VEHICLE SERVICE**

INSTRUCTIONS ON SERVICE OPERATIONS ...	4- 2
TIMING BELT & WATER PUMP .....	4- 2
CRANKSHAFT OIL SEAL .....	4- 7
CAMSHAFT [CB-23 & CB-61 ENGINES] .....	4- 8
CAMSHAFT [CB-80 ENGINE] .....	4 - 9
CAMSHAFT OIL SEAL	
[CB-23 & CB-61 ENGINES] .....	4-10
CYLINDER HEAD GASKET	
[CB-23 & CB-61 ENGINES] .....	4-11
CYLINDER HEAD GASKET [CB-80 ENGINE] .....	4-12
INJECTOR [CB-80 ENGINE] .....	4-12
OIL PUMP .....	4-13

WV 24331

**INSTRUCTIONS ON SERVICE OPERATIONS**

1. This section only describes the removal/installation procedure for those parts which can be removed/installed while the engine is still mounted on the vehicle. As for the overhaul or inspection for the removed parts, see the section under "Engine Overhaul."
2. With regard to those operations for the timing belt, camshaft, crankshaft, oil seal, camshaft oil seal and cylinder head gasket, previous to the operations, make sure to set the piston No.1 to the top dead center under the compression stroke.

**NOTE:**

The top dead center under the compression stroke of the cylinder No.1 can be confirmed by removing the oil filler cap and observing the top mark of the camshaft.

**TIMING BELT & WATER PUMP**

**REMOVAL**

1. Drain engine coolant.
2. Remove the air cleaner and nose. (CB-61 & CB-80 engines only)
3. Remove the engine mounting bracket. Prior to this operation, support the oil pan with a jack.

**NOTE:**

Be very careful not to deform the oil pan. Extreme care must be exercised not to damage the oil drain plug. The deformation of the oil pan will cause engine seizure.

4. Remove the V-belt
5. Remove the water pump pulley
6. Remove the crankshaft pulley.  
When the crankshaft pulley is slackened, lock the ring gear, using a screwdriver or the like (On Type CB-80 engine, the space is very limited for this operation. Hence, it is advisable to use a screwdriver whose end is bent at a right angle for this operation.)

7. Remove the bracket (surge tank & cylinder head cover). (CB-80 engine only)
8. Remove the resistive cords. (CB-80 engine only)
9. Remove the cylinder head cover. (CB-80 engine only)
10. Remove the timing belt upper cover.
11. Remove the timing belt lower cover.
12. Remove the timing belt tensioner.

Before the timing belt tensioner is removed, align the punch marks of the crankshaft and camshaft timing belt pulleys with the indicator marks, respectively. (This setting the piston No.1 to the top dead center under the compression stroke)

WM-04002




Fig. 4-1

WM-04003




Fig. 4-2

WM-04004

(CB-23 & CB-61 engines)




Fig. 4-3

WM-04005






Fig. 4-4

WM-2408

- ③ Remove the crankshaft timing belt pulley flange.
- ④ Remove the timing belt.

Prior to the timing belt removal, put a mark which shows the normal rotating direction at the back surface of the timing belt, using chalk or the like.

**NOTE:**

- ① When removing the timing belt, never use a tool such as a screwdriver.
- ② Make sure not to bend the belt sharply to form a small radius. Such practice will cut the belt cord.
- ③ Never permit oils or water to get to the belt, for such matter would shorten the life of the belt.




Fig. 4-5

WM-04007

- ⑤ Remove the water pump

WM 34015

**INSTALLATION**

- 1. Install the water pump

**NOTE:**

Be sure to replace the gasket with a new one.

- 2. Installation of timing belt tensioner

(1) With the timing belt tensioner set to the lowest position, temporarily tighten the attaching bolt (two attaching bolts in case of CB-80 engine) of the timing belt tensioner.

(This tightening must be made to such an extent that the tensioner can not be moved when the tensioner spring is attached.)

(CB-23 & CB-61 engines)




Fig. 4-6

WM 34029

## IN-VEHICLE SERVICE

- (2) Install the tension spring. Ensure that the tension spring are positively hooked at its both ends and will not be detached.

### 3 Install the timing belt.

#### NOTE:

- ① Make sure not to bend the belt sharply to form a small radius. Such practice will cut the belt cord.
- ② Never permit oils or water to get to the belt, for such matter would shorten the life of the belt.
- ③ When installing the belt, never try to pry the belt with a screwdriver or the like.
- ④ When turning the engine with the belt installed, the rotation should be made at the crankshaft side.
- ⑤ If the belt is reused, install the belt in such a way that the belt is turned in the same direction as indicated by the arrow mark which was put at the belt's back surface during the belt removal.

- (1) Ensure that the mating marks of the crankshaft and camshaft timing belt pulleys are aligned with the indicator marks respectively.

(CB-60 engine)




Fig. 4-7

WM-346-2

(CB-60 engine)




Fig. 4-8

WM-347-1

(CB-23 & CB-61 engines)




Fig. 4-9

WM-348-2

(CB-80 Engine only)

- (2) Install the timing belt in such a way that the part number of the timing belt can be seen properly, as viewed toward the cylinder head side, and comes between the timing marks of the camshaft pulley. Also, make sure that the three mating marks at the back surface of the belt are aligned with the mating marks on the camshaft and crankshaft timing belt pulleys, respectively. Ensure that the belt is not slackened, especially at the tension side (exhaust side) of the belt.

**NOTE:**

If the three mating marks at the back surface of the belt are erased, the belt should be installed in such a way that the belt is not slackened at the tension side (exhaust side).

- (3) Ensure that the mating marks of the timing belt pulleys are aligned with the mating marks of the belt, respectively.
- (4) Slacken the attaching bolts of the tensioner which were tightened temporarily in the previous step. Ensure that the timing belt tension is provided by the tension spring.

- (5) Turn the crankshaft slightly in the normal rotating direction (clockwise), thus applying tension to the timing belt between the intake camshaft timing belt pulley and the exhaust camshaft timing belt pulley and between the exhaust camshaft timing belt pulley and the crankshaft timing belt pulley.

(6) Tighten the timing belt tensioner temporarily.

- (7) Turn the crankshaft about two turns in the normal rotating direction until the mating mark on the cylinder head is aligned with the recessed timing mark on the camshaft.

**NOTE:**

Never make a reverse turn, even if it is the slightest one, during this operation.




Fig. 4-10

WA-340-3




Fig. 4-11

WA-340-4




Fig. 4-12

WA-340-5

WA-340-6

## IN-VEHICLE SERVICE

- (8) Ensure that the tension spring force is being applied to the tensioner, by slackening the bolts of the timing belt tensioner.

WM-04017

- (9) Tighten the bolts of the timing belt tensioner.

### Tightening Torque

(CB-23 & CB-61 engines)

1.9 - 3.1 kg-m (14 - 22 ft-lb)

(CB-80 engine)

M10 bolt: 3.0 - 4.5 kg-m (22 - 33 ft-lb)

M6 bolt: 0.6 - 0.9 kg-m (5 - 7 ft-lb)




Fig. 4-13

WM-04018

- (10) Align the ignition timing marks at the flywheel by turning the crankshaft one turn.

Push the belt between the camshaft timing belt pulleys with a force of 3 kg (6.6 lb). Check to see if the deflection meets the specification.

Specified Deflection: About 5 mm (0.197 inch)

(with a force of 3 kg (6.6 lb) applied)




Fig. 4-14

WM-04019

4. Install the crankshaft timing belt pulley flange.

### NOTE:

Be sure to install the crankshaft timing belt pulley flange in the correct direction.




Fig. 4-15

AV Co.

5. Install the cylinder head cover (CB-23 & CB-61 engines)  
6. Install the resistive cords (CB-23 & CB-61 engines)  
7. Install the air cleaner assembly (CB-23 engine only)  
8. Install the intake pipe (CB-61 engine only)  
9. Install the surge tank (CB-61 engine only)  
10. Install the timing belt lower cover  
11. Install the timing belt upper cover

WM-04020

12. Install the crankshaft pulley.

When the crankshaft pulley is tightened, lock the ring gear, using a screwdriver or the like (On Type CB-80 engine, the space is very limited for this operation. Hence it is advisable to use a screwdriver whose end is bent at a right angle for this operation.)

Tightening Torque: 9.0 - 10.0 kg-m (65 - 72 ft-lb)




Fig. 4-16

WM-04021

- install the cylinder head cover. (CB-80 engine only)
- 14. Install the bracket (surge tank & cylinder head cover) (CB-80 engine only)
- 15. Install the water pump pulley.
- 16. Install the V-belt.
- 17. Install the engine mounting bracket. Remove the jack supporting the oil pan
- 18. Install the air cleaner and hose. (CB-61 & CB-80 engines only)
- 19. Fill cooling water.

WM-04020

## CRANKSHAFT OIL SEAL

### REMOVAL

1. After the operations up to the timing belt removal in the section under "Removal of Timing Belt & Water Pump" have been completed, proceed to this operation of "Crankshaft Oil Seal Removal."

2. Remove the crankshaft timing belt pulley.

#### NOTE

If any difficulty should be encountered in removing the crankshaft timing belt pulley, screw-in bolts into the threaded holes provided in the side of the pulley.

3. Remove the crankshaft timing belt pulley flange
4. Remove the woodruff key.
5. Removal of crankshaft oil seal

Remove the oil seal, using the following SST.

SST: 09223-87702-000

- (1) With the oil seal remover & replacer ① placed against the oil seal, drive a drift into the oil seal so as to make a hole.
- (2) Thread a tapping screw into the thus-produced hole in the oil seal.
- (3) Screw the puller ④ so as to remove the oil seal.



Fig. 4-17

WM-04020




Fig. 4-18

WM-04024

### INSTALLATION

1. Install the new crankshaft oil seal.  
SST: 09223-87702-000

- (1) Apply engine oil to the lip section of the oil seal.
- (2) Place the oil seal remover & replacer ① against the oil seal.
- (3) Place the crankshaft attaching bolt ② against the remover & replacer ①. Then, proceed to install the oil seal into position by turning the crankshaft attaching bolt ②




Fig. 4-19

WM-04026

## IN-VEHICLE SERVICE

2. Install the woodruff key.
3. Install the crankshaft timing belt pulley flange.

### NOTE:

Ensure that the flanges are installed only in the correct direction.

4. Perform the timing belt tensioner installation and the following operations described in the section under "Installation of Timing Belt & Water Pump." As for the contents of these operations, see the section under "Timing Belt & Water Pump."




Fig. 4-20

WV-9126

## CAMSHAFT (CB-23 & CB-61 Engines)

### REMOVAL

1. After the operations up to the timing belt removal in the section under "Removal of Timing Belt & Water Pump" have been completed, proceed to this operation of "Camshaft Removal."
2. Remove the surge tank. (CB-61 engine only)
3. Remove the intake pipe. (CB-61 engine only)
4. Remove the air cleaner assembly. (CB-23 engine only)
5. Remove the resistive cords.
6. Remove the cylinder head cover.
7. Remove the distributor and distributor housing.
8. Remove the camshaft timing belt pulley.

### NOTE:

During the timing belt pulley removal, the rotation of the camshaft can be prevented by inserting a screwdriver through the opening of the pulley.




Fig. 4-21

WV-9427

9. Loosen the attaching screws of the valve rocker arm.
10. Remove the camshaft.

### INSTALLATION

Reverse the removal procedure to install the camshaft.

WV-9428

## AMSHAFT (CB-80 Engine)

### REMOVAL

1. After the operations up to the timing belt removal in the section under "Removal of Timing Belt & Water Pump" have been completed, proceed to this operation of "Camshaft Removal."
2. Remove the camshaft timing belt pulley.  
**NOTE:**  
 The rotation of the camshaft can be prevented by securing the hexagon section on the cylinder No.1.  
 Do not remove the camshaft timing belt pulley by utilizing the tension of the timing belt.
3. Remove the distributor.
4. Remove the camshaft bearing caps.
5. Remove oil seal from camshaft.
6. Remove the camshafts.




Fig. 4-22

SM4-11029

### INSTALLATION

1. Install the camshafts.
2. Installation of camshaft bearing caps  
 Install each camshaft bearing cap as indicated in the right figure, according to the embossed number and arrow at the back side of the camshaft bearing cap.  
 Tightening Torque: 1.15 - 1.45 kg-m (8.3 - 10.5 ft-lb)




Fig. 4-23

SM4-11030

3. Install the new camshaft oil seal, using SST  
 SST: 09618-87301-000




Fig. 4-24

SM4-11031

4. Installation of distributor
  - (1) Remove the distributor cap. Tilt the rotor, as indicated in the right figure.
  - (2) While turning the rotor, push and install the distributor into the groove provided in the camshaft to drive the distributor.

#### NOTE:

Since the distributor is eccentric with the groove provided in the camshaft, the installation can be performed in one direction. Therefore, never install the distributor forcibly. Failure to observe this note will lead to distributor damage.




Fig. 4-25

SM4-11032

## IN-VEHICLE SERVICE

5. Install the camshaft timing belt pulley.

### NOTE:

The rotation of the camshaft can be prevented by securing the hexagon section on the cylinder No.1.

Tightening Torque: 3.0 - 4.5 kg-m (22 - 33 ft-lb)

6. Perform the timing belt installation and the following operations described in the section under "Installation of Timing Belt & Water Pump." As for the contents of these operations, see the section under "Timing Belt & Water Pump."

## CAMSHAFT OIL SEAL (CB-23 & CB-61 Engines)

### REMOVAL

1. After the operations up to the cylinder head cover removal in the section under "Removal of timing belt & water pump" have been completed, proceed to this operation of "Camshaft Oil Seal Removal."

2. Remove the camshaft timing belt pulley.

### NOTE:

During the timing belt pulley removal, the rotation of the camshaft can be prevented by inserting a screwdriver through the opening of the pulley.

3. Removal of camshaft oil seal

(1) Make a hole on the oil seal, using the following SST.

SST: 09223-87702-000

(2) Screw in the SST into the hole

SST: 09223-87702-000

(3) Pry off the oil seal with a screwdriver or the like.

### NOTE:

Be careful not to damage the camshaft and cylinder head.




Fig. 4-26

WV-24022




Fig. 4-27

WV-24031




Fig. 4-28

WV-24034




Fig. 4-29

WV-24035




Fig. 4-30

WV-24038



**STALLATION**

1. Installation of camshaft oil seal  
 With the SST placed against the oil seal, drive the oil seal into position.  
 SST: 09508-12010-000  
**NOTE:**  
 Be sure to use a new oil seal




Fig. 4-31

WM-0407

2. Install the camshaft timing pulley  
 Tightening Torque: 3.0 - 4.5 kg-m (22 - 33 ft-lb)




Fig. 4-32

WM-0408

3. Perform the timing belt tensioner installation and the following operations described in the section under "Installation of Timing Belt & Water Pump." As for the contents of these operations, see the section under "Timing Belt & Water Pump."

WM-0409

**CYLINDER HEAD GASKET (CB-23 & CB-61 Engines)**

**MOVAL**

1. After the operations up to the cylinder head cover removal in the section under "Camshaft Removal" have been completed, proceed to this operation of "Cylinder Head Gasket Removal."
2. Drain engine oil

WM-0410

3. Disconnect the exhaust pipe.
4. Remove the EGR pipe. (Specific area only)
5. Disconnect the hoses.
6. Remove the cylinder head assembly
7. Remove the cylinder head gasket

**INSTALLATION**

Reverse the removal procedure to install the cylinder head gasket.

**NOTE:**  
 Be sure to use a new gasket oil seal.




Fig. 4-33

WM-0405

### CYLINDER HEAD GASKET (CB-80 Engine)

#### REMOVAL

1. After the operations up to the distributor removal in the section under "Camshaft Removal" have been completed, proceed to this operation of "Cylinder Head Gasket Removal."
2. Remove the surge tank cover.
3. Remove the hoses.
4. Remove the connectors.
5. Remove the surge tank stay.
6. Disconnect the exhaust pipe.
7. Remove the intake pipe.
8. Remove the cylinder head assembly.
9. Remove the cylinder head gasket.

#### INSTALLATION

Reverse the removal procedure to install the cylinder head gasket.

W11-34037

### INJECTOR (CB-80 Engine)

#### REMOVAL

1. Remove the surge tank cover.
2. Remove the bracket (surge tank ⊗ cylinder head cover).
3. Remove the intake pipe.
4. Remove the hoses.

#### Union (for cold start injector)

The fuel line system is retained under a highly pressurized state. When the union is removed, place a cloth underneath. Be sure to slowly remove the union so as to prevent the fuel from splashing.

5. Remove the connectors.
6. Remove the surge tank.
7. Remove the delivery pipe.
8. Remove the insulator.
9. Remove the injector.

#### INSTALLATION

Reverse the removal procedure to install the injector.

#### NOTE:

Be sure to use new gaskets.

W11-34035




Fig. 4-34

W11-34048

## OIL PUMP

### REMOVAL

1. Remove the exhaust pipe.
2. Remove the bracket (transmission ⊗ exhaust pipe).
3. Remove the engine mounting rear bracket No.2.
4. Remove the engine mounting rear bracket No.1.
5. Remove the engine lower mounting member.
6. Remove the stiffener plate.
7. Remove the oil pan.
8. Remove the oil pan gasket.
9. Remove the oil pump drive shaft sprocket.
10. Remove the oil jet. (CB-80 engine only)
11. Remove the oil pump.




Fig. 4-35

WM-04630

### INSTALLATION

1. Install the oil pump.

**NOTE.**

Be sure to use new "O" ring.

2. Install the oil jet. (CB-80 engine only)
3. Install the oil pump drive shaft sprocket.

**NOTE.**

Be sure to install the oil pump drive shaft sprocket with the side having the "CB OUTSIDE" stamp facing to the outside.




Fig. 4-36

WM-04631

4. Install the oil pan gasket.

- ⓐ Apply the sealer to the cylinder block, following the procedure indicated in the illustration at the right.

Sealer to be Used: **Silicon Bond**




Fig. 4-37

WM-04632

- ⓑ Apply the sealer to the oil pan gasket and the oil pan side, following the procedure indicated in the illustration at the right. Place the oil pan gasket on the cylinder block.




Fig. 4-38

WM-04633

## IN-VEHICLE SERVICE

### 5. Install the oil pan

Tighten the stud bolt sections temporarily. Then, tighten the oil pan attaching bolts in the sequence as shown in the illustration at the right.

**Tightening Torque:** 0.4 - 0.7 Kg-m (2.9 - 5.1 ft-lb)

The numerals in ( ) in the illustration at the right denote the temporal tightening sequence for the stud bolts.




Fig. 4-39

879-0004

### 6. Install the stiffener plate.

### 7. Install the engine lower mounting member.

### 8. Install the engine mounting rear bracket No. 1.

### 9. Install the engine mounting rear bracket No. 2.

### 10. Install the bracket (transmission (3) exhaust pipe).

### 11. Install the exhaust pipe.

879-0004

**DAIHATSU**  
**TYPE CB**  
**ENGINE**

[CB-23, CB-61 & CB-80]

**E**

## **SECTION 5**

# **ENGINE MECHANICALS**

<b>REMOVAL AND INSTALLATION OF ENGINE ...</b>	<b>5- 2</b>
<b>INTAKE AND EXHAUST SYSTEM .....</b>	<b>5-14</b>
CB-23 AND CB-61 ENGINES .....	5-14
CB-80 ENGINE .....	5-19
<b>TIMING BELT .....</b>	<b>5-24</b>
CB-23 AND CB-61 ENGINES .....	5-24
CB-80 ENGINE .....	5-30
<b>CYLINDER HEAD .....</b>	<b>5-39</b>
CB-23 AND CB-61 ENGINES .....	5-39
CB-80 ENGINE .....	5-55
<b>CYLINDER BLOCK .....</b>	<b>5-69</b>

WM-03001

## ENGINE MECHANICALS

# REMOVAL AND INSTALLATION OF ENGINE

### REMOVAL

1. Drain the engine oil and cooling water.




Fig. 5-1

WM-05002

2. Remove the engine hood.

#### NOTE:

This operation must be performed by at least two persons. Since the engine hood is quite heavy, be very careful not to scratch the body and hood.

WM-05003

3. Disconnect the negative  $\ominus$  terminal of the battery. Detach the hold-down clamp and remove the battery.
4. Remove the battery carrier stay.




Fig. 5-2

WM-05004

5. Remove the intercooler assembly. (CB-80 engine only)




Fig. 5-3

WM-05005

6. Remove the radiator.
7. Remove the air cleaner assembly.
8. Remove the blow-by hose. (CB-6<sup>+</sup> engine only)




Fig. 5-4

WM-05006

Disconnect the speedometer cable.



Fig. 5-5 WVA-2327

10 Disconnect the clutch cable.



Fig. 5-6 AW-2328

11 Disconnect the accelerator cable assembly.




Fig. 5-7 WVA-2329

12 Disconnect the brake booster hose.

13 Disconnect the heater hose.




Fig. 5-8 AW-2327

14 Disconnect the hose of the turbocharger waste gate valve.  
(CB-20 engine only)




Fig. 5-9 WVA-23211

## ENGINE MECHANICALS

### 15. Disconnect the fuel pipe.

- 1) Disconnect the fuel hose between the fuel filter and the delivery pipe. (CB-80 engine only)

SST: 09258-00030-000

#### NOTE:

Even when the engine is stopped, a fuel pressure of about 2.55 kg/cm<sup>2</sup> (36.3 psi) is applied to the fuel line. Hence, be sure to prevent the fuel from splashing, using a cloth or the like.

- 2) Disconnect the fuel return hose between the delivery pipe and the fuel tank. (CB-80 engine only)

#### NOTE:

When disconnecting the hose, be sure to prevent the fuel from splashing, using a cloth.




Fig. 5-10

WM-05012




Fig. 5-11

WM-05013

### 16. Disconnect the wire harness connector.

#### NOTE:

- ① The following explanation and illustrations for disconnecting the wire harness connector pertains to Type CB-80 engine. For Type CB-23 and CB-61 engines, refer to the following sections before starting the operation.
- ② Care must be exercised as to the removal method of the connector. Some connectors can be removed by pulling the lock section, while others can be removed by pushing the lock section.

#### [CB-23]

While the engine proper is still mounted on the vehicle, disconnect each connector of the switches and sensors. Make sure that the wire harnesses are left at the vehicle side when the engine proper is removed.

WM-05014

#### [CB-61]

Disconnect the connector between the cowl wire harness and the engine wire harness, as indicated in the right figure. After the engine has been removed, disconnect each connector of the switches and sensors at the engine proper.

#### NOTE:

When removing the engine, perform final check to ensure that all connectors have been disconnected.




Fig. 5-12

WM-05015



Disconnect the distributor-related harness couplers.  
(CB-60 engine only)

- 1) Injector time switch
- 2) Water temperature sensor
- 3) Fan motor switch
- 4) Thermostat sender unit
- 5) Distributor connector
- 6) Ignition coil resistive cord



Fig. 5-13

7-4-05016

18. Disconnect the surge tank-related harness couplers  
(CB-80 engine only)

- 1) Cold start injector
- 2) Coupler of each injector




Fig. 5-14

7-4-05017

19. Disconnect the transmission-related harness couplers  
(CB-80 engine only)

- 1) Starter harness
- 2) Transmission earth
- 3) Backup lamp harness

20. Remove the surge tank cover (CB-80 engine only)



Fig. 5-15

7-4-05018

21. Disconnect the engine-related harness couplers (CB-80 engine only)

- 1) Throttle sensor
- 2) Pressure sensor
- 3) Variable resistor
- 4) Intake air temperature sensor
- 5) Earth
- 6) Oil pressure switch
- 7) Alternator connector




Fig. 5-16

7-4-05019

## ENGINE MECHANICALS

22. Jack up the vehicle. Support the vehicle with safety stands. Remove the wheels.

**NOTE:**

For the supporting points, see the section under "GENERAL INFORMATION."

23. Drain the transmission oil.

WM-05020

24. Disconnect the shift & selector shaft subassembly




Fig. 5-17

WM-05021

25. Disconnect the exhaust front pipe. Remove it from the manifold




Fig. 5-18

WM-05022

26. Remove the stabilizer bar.




Fig. 5-19

WM-05023

27. Remove the lower suspension brace. (CB-61 and CB-80 engines only)

28. Disconnect the suspension lower arm subassembly




Fig. 5-20

WM-05024

1. Remove the front drive shaft.  
SST: 09648-87201-000

NOTE:

① On Type CB-23 and CB-61 engines, no stopper is provided at the inside of the inboard of the drive shaft. It is, therefore, necessary to support the inboard joint section by hands during the removal.

② On Type CB-80 engine, remove the front drive shaft by inserting a crowbar into between the projected section of the drive bearing shaft and the drive shaft. Care must be exercised not to deform the dust cover of the drive shaft during the removal.




Fig. 5-21

AM-05225




Fig. 5-22

AM-05226

30. Disconnection of engine mounting lower left bracket  
Remove the bolts at the transmission side only.




Fig. 5-23

AM-05227

31. Disconnection of engine mounting rear No.1 bracket  
Remove the bolt attaching the engine lower mounting member subassembly to the engine mounting rear No.1 bracket.

AM-05228

32. Sling the engine, using the following SST.  
SST: 09090-04810-000 (Engine sling device)




Fig. 5-24

AM-05229

## ENGINE MECHANICALS

### 33 Removal of engine assembly

- ① Remove the engine mounting front stopper.
  - ② Remove the engine mounting front insulator.
  - ③ Remove the engine by lifting it, using the following SST
- SST: 09090-04810-000 (Engine sling device)

#### NOTE:

When removing the engine, perform final check to ensure that all removal parts have been removed.




Fig. 5-25

WV-C5311

- 34 Remove the starter assembly from the transmission.
- 35 Remove the transmission assembly from the engine assembly.




Fig. 5-26

WV-C5311

### 36. Install the engine assembly to the following SSTs.

- SSTs: 09219-87701-000  
09219-87202-000

WV-C5312

**STALLATION**

1. Remove the engine assembly from the SSTs.
2. Install the transmission assembly to the engine assembly  
Tightening Torque: 5.0 - 7.0 kg-m (36 - 51 ft-lb)
3. Install the starter assembly to the transmission




Fig. 5-27

NM-0273

4. Installation of engine assembly:
  - ① Sling the engine, using the following SST  
SST: 09090-04810-000 (Engine sling device)
  - ② Install the engine mounting front insulator.  
Tightening Torque: 7.5 - 10.5 kg-m (54 - 76 ft-lb)
  - ③ Install the engine mounting front stopper  
Tightening Torque: 7.5 - 10.5 kg-m (54 - 76 ft-lb)




Fig. 5-28

NM-0284

5. Install the engine mounting rear No.1 bracket.  
Tightening Torque: 7.5 - 10.5 kg-m (54 - 76 ft-lb)




Fig. 5-29

NM-0305

6. Install the engine mounting lower left bracket.  
Tightening Torque: 3.0 - 4.5 kg-m (22 - 33 ft-lb)
7. Remove the SST (engine sling device) from the engine assembly.




Fig. 5-30

NM-0306

## ENGINE MECHANICALS

8. Install the front drive shaft.

**NOTE:**

Install the front drive shaft to the differential case slowly, being very careful not to damage the lip section of the oil seal.




Fig. 5-31

AW-00027

9. Install the suspension lower arm subassembly.

Tightening Torque: 7.5 - 10.5 kg-m (54 - 76 ft-lb)

10. Install the lower suspension brace. (CB-67 and CB-80 engines only)

Tightening Torque: 4.0 - 5.5 kg-m (29 - 40 ft-lb)




Fig. 5-32

AW-00028

11. Installation of stabilizer bar

- ① Tightening the suspension lower arm subassembly.

Tightening Torque: 7.5 - 11.0 kg-m (54 - 80 ft-lb)

- ② Tightening the stabilizer bracket.

Tightening Torque: 4.0 - 6.0 kg-m (29 - 43 ft-lb)




Fig. 5-33

AW-00029

12. Install the exhaust front pipe

Tightening Torque: 3.0 - 5.0 kg-m (22 - 36 ft-lb)




Fig. 5-34

AW-00030

13. Install the shift & selector shaft subassembly

Tightening Torque: 1.0 - 1.6 kg-m (7 - 12 ft-lb)

**NOTE:**

After completion of the installation, make sure that the shift & selector shaft subassembly can be shifted smoothly into each position. Also, be sure that it can be returned smoothly in the selecting direction.




Fig. 5-35

AW-00031

Fill the transmission fluid.

Lubricant viscosity recommendation:

SAE 80W (oil equivalent to API classification GL-4)

Oil level	Transmission 4-speed manual transmission	5-speed manual transmission
Oil level flush with Filter plug	About 2.0 litres	About 2.2 litres
Oil level 5 mm below Filter plug	About 1.9 litres	About 2.1 litres

15. Tighten the wheels temporarily. Remove the safety stands.  
Tighten the wheels securely.  
Tightening Torque: 9.0 - 12.0 kg-m (65 - 87 ft-lb)

16. Connect the harness connectors for the parts given below:

- 1) Alternator connector
- 2) Oil pressure switch
- 3) Earth
- 4) Intake air temperature sensor
- 5) Variable resistor
- 6) Pressure sensor
- 7) Throttle sensor
- 8) Backup lamp harness
- 9) Transmission earth
- 10) Starter harness
- 11) Coupler of each injector
- 12) Cold start injector
- 13) Ignition coil resistive cord
- 14) Distributor connector
- 15) Thermostat sender unit
- 16) Fan motor switch
- 17) Water temperature sensor
- 18) Injector time switch

17. Install the hose of the turbocharger waste gate valve.  
(CB-80 engine only)
18. Install the fuel pipe.
19. Install the heater hose.
20. Install the brake booster hose.




Fig. 5-36

WM-05647




Fig. 5-37

WM-05645

WM-05041




Fig. 5-38

WM-05042

## ENGINE MECHANICALS

21. Connect the accelerator cable.




Fig. 5-39

AW-03046

22. Connect the clutch cable

**NOTE:**

Apply MP grease to the point where the clutch release lever is attached to the clutch cable.

23. Connect the speedometer cable




Fig. 5-40

AW-05047

24. Install the air cleaner assembly

25. Install the blow-by nose. (CB-61 engine only)

26. Install the radiator.

27. Install the intercooler assembly

28. Install the battery carrier stay

29. Install the positive (+) terminal of the battery.

30. Install the negative (-) terminal of the battery

31. Install the hold-down clamp of the battery




Fig. 5-41

AW-05048

32. Install the engine hood

**NOTE:**

Apply rust preventive oil to the bolt tightening sections.

(Reference)

Rust Preventive Oil

3M make

Rust Fighter-I (Aerosol Type)




Fig. 5-42

AW-05049

33. Fill the engine oil

API Classification CB23 SC-SF

CB61 and CB80 SD-SF

Lubrication oil capacity: 2.7 liter

Classification: API SC, SD, SE or SF




Fig. 5-43

AW-02050

		CB-23	CB-61	CB-80
Engine oil capacity	litre	3.2	3.2	3.2



Fill the radiator tank and reserve tank with cooling water.

**NOTE:**

- ① After completion of the operation, make sure that no leakage exists.
- ② Put the coolant, as required.




Fig. 5-44

(WA-2555)

**Amount of coolant (When undiluted coolant with 98% concentration is used:)**

(With heater)


Atmosphere temperature		Concentration	Radiator (litre)	Reserve tank (litre)
-10°C	Petrol engine (Type CB-23 engine) : Manual transmission	23%	0.66	0.14
	: Automatic transmission		0.76	0.14
	Petrol turbo engine (Type CB-61 engine)		0.75	0.14
	Petrol turbo engine (Type CB-80 engine)		0.77	0.14
	Diesel engine (Type CL-11 engine)		0.62	0.14
	Diesel turbo engine (Type CL-61 engine)		0.55	0.14
-20°C	Petrol engine (Type CB-23 engine) : Manual transmission	35%	1.00	0.21
	: Automatic transmission		1.14	0.21
	Petrol turbo engine (Type CB-61 engine)		1.14	0.21
	Petrol turbo engine (Type CB-80 engine)		1.17	0.21
	Diesel engine (Type CL-11 engine)		1.25	0.21
	Diesel turbo engine (Type CL-61 engine)		1.29	0.21
-35°C	Petrol engine (Type CB-23 engine) : Manual transmission	50%	1.44	0.30
	: Automatic transmission		1.64	0.30
	Petrol turbo engine (Type CB-61 engine)		1.64	0.30
	Petrol turbo engine (Type CB-80 engine)		1.68	0.30
	Diesel engine (Type CL-11 engine)		1.73	0.30
	Diesel turbo engine (Type CL-61 engine)		1.84	0.30

(WA-2555)

INTAKE AND EXHAUST SYSTEM

CB-23 AND CB-61 ENGINES

COMPONENTS OF INTAKE AND EXHAUST SYSTEM



- ① Hoses
- ② Fuel pump (CB-23 engine only)
- ③ Carburetor Ay
- ④ EGR pipe (Specific area only)
- ⑤ Intake manifold Ay
- ⑥ Intake manifold-to-cylinder head gasket
- ⑦ Exhaust manifold heat insulator No. 1
- ⑧ Turbocharger oil inlet (CB-61 engine only)
- ⑨ Air suction pipe (Specific area only)
- ⑩ Exhaust manifold case (CB-61 engine only)
- ⑪ Turbocharger-to-exhaust manifold gasket (CB-61 engine only)
- ⑫ Turbocharger oil outlet pipe S/A (CB-61 engine only)
- ⑬ Turbocharger Ay (CB-61 engine only)
- ⑭ Turbocharger-to-exhaust manifold gasket (CB-61 engine only)
- ⑮ Exhaust manifold Ay
- ⑯ Exhaust manifold-to-cylinder head gasket

Fig. 5-45

**REMOVAL**

- 1 Remove the surge tank assembly. (CB-61 engine only)
- 2 Remove the intake pipe. (CB-61 engine only)

**NOTE:**

After the intake pipe has been removed, plug the opening with adhesive tape so that no dust, etc. may get into the turbocharger turbine.

- 3 Remove the hoses.

**NOTE:**

When removing the vacuum hoses, put a tag on each removed hose so that the hoses may be installed correctly in the original position.

- 4 Remove the carburetor assembly
- 5 Remove the fuel pump assembly. (On Type CB-61 engine, remove the bracket.)

- 6 Remove the EGR pipe. (Swiss specifications only)
- 7 Remove the intake manifold assembly

- 8 Remove the exhaust manifold heat insulator No.1.
- 9 Remove the turbocharger oil inlet. (CB-61 engine only)
- 10 Remove the air suction pipe. (West German, Australian and Swiss specifications only)




Fig. 5-46

WM-35054



Fig. 5-47

WM-35054



Fig. 5-48

WM-35054




Fig. 5-49

WM-35054




Fig. 5-50

WM-35054

## ENGINE MECHANICALS

11. Remove the exhaust manifold case (CB-61 engine only)




Fig. 5-51

WM-2552

12. Remove the turbocharger or outlet pipe subassembly. (CB-61 engine only)




Fig. 5-52

WM-2553

13. Remove the turbocharger assembly (CB-61 engine only)

**NOTE:**

For the handling instructions on the removed turbocharger assembly, see page 9-3.




Fig. 5-53

WM-2554

14. Remove the exhaust manifold.

15. Remove the exhaust manifold-to-cylinder head gasket.




Fig. 5-54

WM-2555

### INSPECTION

Check the cylinder head attaching surface of the intake manifold for distortion. Measure the distortion on the diagonal lines.

Allowable Limit (both intake and exhaust manifolds):

0.1 mm (0.0039 inch)

If the distortion exceeds the allowable limit, correct the surface by grinding it. However, this grinding amount should be limited to 0.3 mm (0.012 inch).




Fig. 5-55

WM-2556

- Check the EGR valve. (See the section under "Exhaust Emission Control System" (page 12-28).)
3. Check the BVSV and TVSV. (See the section under "Exhaust Emission Control System" (page 12-23).)
  4. Check the turbocharger. (See the section under "Turbocharger Check" (page 9-4).)
  5. Check the carburetor. (See the section under "Carburetor Check" (page 6-5).)

VIN 03064

## INSTALLATION

1. Install the exhaust manifold-to-cylinder head gasket.
2. Install the exhaust manifold.  
Tightening Torque: 1.0 - 1.6 kg-m (7 - 12 ft-lb)
3. Install the turbocharger-to-exhaust manifold gasket.  
(CB-61 engine only)

### NOTE:

This gasket is a nonreusable part.

4. Install the turbocharger assembly. (CB-61 engine only)

### NOTE:

For the handling instructions on the turbocharger assembly, see page 9-3.

Tightening Torque: 2.5 - 3.3 kg-m (18 - 24 ft-lb)

5. Install the turbocharger oil outlet pipe subassembly.

6. Install the exhaust manifold case. (CB-61 engine only)  
Tightening Torque: 3.0 - 4.0 kg-m (22 - 29 ft-lb)
7. Install the air suction pipe.  
(West German, Australian and Swiss specifications only.)




Fig. 5-56

VIN-6075




Fig. 5-57

VIN 03066




Fig. 5-58

VIN 03067




Fig. 5-59

VIN 03068

## ENGINE MECHANICALS

8. Install the turbocharger oil inlet. (CB-61 engine only)




Fig. 5-60

W4-33260

9. Install the exhaust manifold heat insulator No. 1.
10. Install the intake manifold-to-cylinder head gasket.
11. Install the intake manifold.

Tightening Torque: 1.0 - 1.6 kg-m (7 - 12 ft-lb)

**NOTE:**

This gasket is a nonreusable part.




Fig. 5-61

W4-33261

12. Install the EGR pipe. (Swiss specifications only)
13. Install the carburetor assembly.
14. Install the fuel pump assembly. (On Type CB-61 engine, install the bracket.)

**NOTE:**

This gasket is a nonreusable part.




Fig. 5-62

W4-33262

15. Install the hoses.

**NOTE:**

Be sure to install the hoses correctly in accordance with the tags put during the removal.



Fig. 5-63

W4-33263

16. Install the intake pipe. (CB-61 engine only)
17. Install the surge tank assembly. (CB-61 engine only)





Fig. 5-64

W4-33264

### 3-80 ENGINE COMPONENTS OF INTAKE AND EXHAUST SYSTEM



(1)

T : Tightening torque  
Unit: kg-m  
\* : Non-reusable part

- (1) Hoses
- (2) Throttle body
- (3) Fuel pipe (Cold start injector)
- (4) Air surge tank
- (5) Fuel delivery pipe
- (6) Fuel delivery pipe insulator
- (7) Fuel injector Ay
- (8) Intake manifold
- (9) Intake manifold-to-cylinder head gasket
- (10) Turbocharger oil inlet pipe S/A
- (11) Exhaust manifold case
- (12) Turbocharger-to-exhaust manifold gasket
- (13) Turbocharger oil outlet pipe S/A
- (14) Turbocharger Ay
- (15) Turbocharger-to-exhaust manifold gasket
- (16) Exhaust manifold Ay
- (17) Exhaust manifold-to-cylinder head gasket

Fig. 5-65

WV-05074

## ENGINE MECHANICALS

### REMOVAL

1. Remove the hoses.

**NOTE:**

When removing the vacuum hoses, put a tag on each removed hose so that the hoses may be installed correctly in the original position.

2. Remove the surge tank cover.
3. Remove the fuel pipe for cold start injector use.

**NOTE:**

When removing the pipe, the fuel will be discharged. Hence, be sure to get a cloth ready to receive the fuel!

4. Remove the throttle body.

5. Remove the air surge tank assembly.
6. Remove the fuel delivery pipe.
7. Remove the fuel delivery pipe insulator.

8. Remove the intake manifold.




Fig. 5-66

WM-0975




Fig. 5-67

WM-0975




Fig. 5-68

WM-0977




Fig. 5-69

WM-0978




Fig. 5-70

WM-0979



Remove the turbocharger oil inlet pipe subassembly.

10. Remove the exhaust manifold case




Fig. 5-71

AV-250106

11. Remove the turbocharger oil outlet pipe subassembly




Fig. 5-72

AV-25009

12. Remove the turbocharger assembly

**NOTE:**

For the handling instructions on the removed turbocharger assembly, see page 9-3.




Fig. 5-73

AV-25022

13. Remove the exhaust manifold

Remove the exhaust manifold-to-cylinder head gasket.




Fig. 5-74

AV-25022

## INSPECTION

1. Check the surge tank and cylinder head attaching surfaces of the intake manifold for distortion. Measure the distortion on the diagonal lines.

**Allowable Limit:** 0.1 mm (0.0039 inch)

If the distortion exceeds the allowable limit, correct the surface by grinding it. However, this grinding amount should be limited to 0.3 mm (0.012 inch).




Fig. 5-75

AV-25024

## ENGINE MECHANICALS

2. Check the turbocharger. (See the section under "Turbocharger Check" (page 9-4).)

WM-05085

### INSTALLATION

1. Install the exhaust manifold-to-cylinder head gasket.

**NOTE:**

When installing a new gasket, install it with the projected section facing toward the manifold side.

2. Install the exhaust manifold.

**Tightening Torque:** 4.0 - 5.0 kg-m (29 - 36 ft-lb)




Fig. 5-76

WM-05086

3. Install the turbocharger assembly.

**NOTE:**

For handling instructions on the turbocharger assembly prior to its assembly, see page 9-3.

**Tightening Torque:** 2.5 - 3.3 kg-m (18 - 24 ft-lb)




Fig. 5-77

WM-05087

4. Install the turbocharger oil outlet pipe subassembly.




Fig. 5-78

WM-05088

5. Install the exhaust manifold case.

**Tightening Torque:** 2.5 - 3.3 kg-m (18 - 24 ft-lb)

6. Install the turbocharger oil inlet pipe subassembly.




Fig. 5-79

WM-05089

Install the intake manifold.

Tightening Torque: 1.7 - 2.5 kg-m (12 - 18 ft-lb)

**NOTE:**

The gasket is a nonreusable part.




Fig. 5-80

WA-65061

8. Install the fuel delivery pipe insulator
9. Install the fuel injector.

AM-3803\*

10. Install the fuel delivery pipe

11. Install the air surge tank assembly.

Tightening Torque: 3.5 - 4.5 kg-m (25 - 32 ft-lb)




Fig. 5-81

WA-65062

12. Install the throttle body

1. Install the fuel pipe (for cold start injector use)




Fig. 5-82

WA-65063

14. Install the hoses

**NOTE:**

Be sure to install the hoses correctly according to the tags which were put during the removal.





Fig. 5-83

WA-65064

**TIMING BELT**

**CB-23 AND CB-61 ENGINES  
COMPONENTS OF TIMING BELT**



- ① V-belt
- ② Water pump pulley
- ③ Crank shaft pulley
- ④ Timing belt upper cover
- ⑤ Timing belt lower cover
- ⑥ Crankshaft timing belt pulley flange
- ⑦ Timing belt tensioner
- ⑧ Timing belt
- ⑨ Crankshaft timing belt pulley
- ⑩ Crankshaft timing belt pulley

Fig. 5-84

**REMOVAL**

1. Remove the V-belt.
  2. Remove the water pump pulley.
  3. Remove the crankshaft pulley.
- When slackening the attaching bolt of the crankshaft pulley, use the following SST to prevent the ring gear from turning.

SST: 09210-87701-000

4. Remove the timing belt upper cover.
  5. Remove the timing belt lower cover.
  6. Remove the crankshaft timing belt pulley flange.
  7. Remove the timing belt tensioner subassembly.
- When removing the timing belt tensioner subassembly, set the piston No. 1 to the top dead center under the compression stroke.  
(Before removing the timing belt tensioner, align the punch marks of the crankshaft and camshaft timing belt pulleys with the indicators, respectively.)

**NOTE:**

After the timing belt tensioner has been removed, under no circumstances should the camshaft or the crankshaft be rotated. If they should be rotated, the piston will interfere with the valves, resulting in damage to these parts.

8. Remove the timing belt.
- Prior to the timing belt removal, put a mark which shows the normal rotating direction at the back surface of the timing belt, using chalk or the like.

**NOTE:**

While removing the timing belt, make sure not to bend the belt sharply to form a small radius.  
When removing the timing belt, never use a screwdriver or the like.

9. Remove the crankshaft timing belt pulley, as follows:  
Screw in M8 bolts. Remove the crankshaft timing belt pulley together with the bolts.




Fig. 5-85

471-05024




Fig. 5-86

471-05091




Fig. 5-87

471-05106



Fig. 5-88

471-05099

## ENGINE MECHANICALS

10 Remove the camshaft timing belt pulley.

During the timing belt pulley removal, the rotation of the camshaft can be prevented by inserting a screwdriver through the opening of the pulley.




Fig. 5-39


WJW-3100

## INSPECTION


1. Checking of timing belt

Check each section of the timing belt. Replace the belt which exhibits the following damage

- (1) Cracks at rubber portion of back surface
- (2) Cracks at tooth bottom and peeling off and cracks at canvas



- (3) Wear at canvas and tooth missing
- (4) Abnormal wear at side surface of belt



Replace the belt in the following cases, even if no external damage is observed

- (1) Case where the timing belt has been continuously exposed to water owing to water leakage of the water pump, etc
- (2) Case where the rubber may have swollen because of a large amount of oil stuck on the timing belt
- (3) Case where most likely excessive force has been applied to the timing belt due to a camshaft seizure

www.94131

**Checking of timing belt tensioner**

Turn the tensioner. Check the bearing for a lock condition and abnormal noise. Also check the belt contact surface for damage.




Fig. 5-90

WA-05109

**3. Checking of timing belt pulley****Wear limit of timing belt pulley**

mm (inches)

Crankshaft timing belt pulley	53.2 (2.134)
Camshaft timing belt pulley	113.8 (4.477)

If the wear exceeds the wear limit, replace the timing belt pulley.




Fig. 5-91

WA-05109

**4. Checking of crankshaft timing belt pulley flange**

Check the crankshaft timing belt pulley flange for deformation or damage.

WA-05109

## ENGINE MECHANICALS

### INSTALLATION

1. Install the camshaft timing belt pulley.  
To prevent the rotation of the camshaft, apply a metal rod to the rib section of the cylinder head.  
(Be sure not to turn the camshaft while the timing belt pulley is being installed.)




Fig. 5-92

44-02126

2. Install the crankshaft timing belt pulley.
3. Install the timing belt tensioner subassembly.  
Temporarily attach the timing belt tensioner.  
The setting bolt of the timing belt tensioner should be backed off about half a turn from the completely tightened position.  
Install the tension spring bracket and tension spring.




Fig. 5-93

44-02126

4. Install the timing belt.

#### NOTE:

- ① Make sure not to bend the belt sharply to form a small radius. Such practice will cut the belt cord.
- ② Never permit oils, greases or water to get to the belt.
- ③ When installing the belt, never try to pry the timing belt with a screwdriver or the like.
- ④ When turning the engine with the belt installed, the rotation should be made at the crankshaft side.
- ⑤ If the belt is reused, install the belt in such a way that the belt is turned in the same direction as indicated by the arrow mark which was put at the belt's back surface during the belt removal.

44-02127

- (1) Ensure that the punch marks of the crankshaft and camshaft timing belt pulleys are aligned with the indicator marks, respectively.
- (2) Ensure that two mating marks at the back surface of the belt are aligned with the punch marks of the camshaft and crankshaft timing belt pulleys, respectively. Also, be certain that the belt is not slackened.




Fig. 5-94

44-02126



- 3) Turn the crankshaft two turns in the normal rotating direction (clockwise) until the piston No. 1 comes between the point 30° before the top dead center and the top dead center.

**NOTE:**

Never make a reverse rotation when turning the crankshaft.

- (4) Tighten the attaching bolt of the timing belt tensioner.

**NOTE:**

Do not push the tensioner by your finger, etc. during this operation.

Tightening Torque: 2.0 - 3.0 kg-m (14 - 22 ft-lb)




Fig. 5-95

79-25112




Fig. 5-96

79-25113

- (5) Turn the crankshaft, until the piston No. 1 comes at the top dead center under the compression stroke.
- (6) Ensure that the punch marks of the crankshaft and camshaft timing belt pulley are aligned with the indicators, respectively.
- At this time, however, the two mating marks at the back surface of the timing belt are not aligned with the punch marks, respectively.

79-25114

5. Install the crankshaft timing belt pulley flange.  
The crankshaft timing belt pulley flange should be installed only in the correct direction.




Fig. 5-97

79-25115

6. Install the timing belt lower cover.  
7. Install the timing belt upper cover.  
8. Install the crankshaft pulley.  
9. Install the water pump pulley.  
10. Install the V-belt.





Fig. 5-98

79-25116

# ENGINE MECHANICALS

## CB-80 ENGINE COMPONENTS OF TIMING BELT



- |                           |  |
|---------------------------|--|
| ① V-belt                  | ⑪ Timing belt tensioner S/A                        |
| ② Water pump pulley       | ⑫ Timing belt idler S/A No.1                       |
| ③ Crankshaft pulley       | ⑬ Timing belt idler S/A No.2                       |
| ④ Resistive cords         | ⑭ Crankshaft timing belt pulley flange             |
| ⑤ Oil filter cap          | ⑮ Timing belt                                      |
| ⑥ Surge tank cover        | ⑯ Crankshaft timing belt pulley                    |
| ⑦ Surge tank bracket      | ⑰ Crankshaft timing belt pulley (Intake & exhaust) |
| ⑧ Cylinder head cover     |  |
| ⑨ Timing belt upper cover |  |
| ⑩ Timing belt lower cover |  |

Fig. 5-95

AM-2114

## REMOVAL

1. Remove the V-belt.
2. Remove the water pump pulley.
3. Remove the crankshaft pulley.  
When removing the attaching bolt of the crankshaft pulley, use the following SST to prevent the ring gear from turning.

SST: 09201-87701-000

4. Remove the resistive cord.
5. Remove the oil filler cap.
6. Remove the surge tank cover.
7. Remove the surge tank bracket.
8. Remove the cylinder head cover.
9. Remove the timing belt upper cover.
10. Remove the timing belt lower cover.
11. Remove the timing belt tensioner subassembly.  
When removing the timing belt tensioner subassembly, set the piston No.1 to the top dead center under the compression stroke.  
(Before removing the timing belt tensioner, align the punch marks of the crankshaft and camshaft timing belt pulleys with the indicators, respectively.)

## NOTE:

After the timing belt tensioner has been removed, under no circumstances should the camshaft or the crankshaft timing belt pulley be rotated. If they should be rotated, the piston will interfere with the valves, resulting in damage to these parts.

12. Remove the timing belt idler subassembly No.1.
13. Remove the timing belt idler subassembly No.2. Remove it, using a 10 mm hexagon wrench.

14. Remove the crankshaft timing belt pulley flange.
15. Remove the timing belt.  
Prior to the timing belt removal, put a mark which shows the normal rotating direction at the back surface of the timing belt using chalk or the like.

## NOTE:

- ① While removing the timing belt, make sure not to bend the belt sharply to form a small radius. Moreover, never use a screwdriver or the like.
- ② Never allow oils and water to get to the timing belt.




Fig. 5-100

WA05116




Fig. 5-101

WA05116




Fig. 5-102

WA05117




Fig. 5-103

WA05118

## ENGINE MECHANICALS

16. Remove the crankshaft timing belt pulley, as follows.  
Screw in M6 bolts. Remove the crankshaft timing belt pulley together with the bolts.




Fig. 5-104

WJ-01114

17. Remove the camshaft timing belt pulley (intake & exhaust).

When removing the attaching bolt of the camshaft timing belt pulley, prevent the rotation of the camshaft by holding the hexagonal section (width across flats: 23 mm) of the cylinder No. 1 with a spanner or the like.








Fig. 5-105

WJ-01115

**INSPECTION****1. Checking of timing belt**

Check each section of the timing belt. Replace the belt which exhibits the following damage.

**(1) Cracks at rubber portion of back surface****(2) Cracks at tooth bottom and peeling off and cracks at canvas****(3) Wear at canvas and tooth missing****(4) Abnormal wear at side surface of belt**

Replace the belt in the following cases, even if no external damage is observed.

- (1) Case where the timing belt has been continuously exposed to water owing to water leakage of the water pump, etc.
- (2) Case where the rubber may have swollen because of a large amount of oil stuck on the timing belt.
- (3) Case where most likely excessive force has been applied to the timing belt due to a camshaft seizure.

4M-0512

**2. Checking of timing belt tensioner**

Turn the tensioner. Check the bearing for a lock condition and abnormal noise. Also check the belt contact surface for damage.




Fig. 5-106

4M-0512

**3. Checking of timing belt idler subassemblies No.1 and No.2**

Check the timing belt idler subassemblies No.1 and No.2 in the same way as with the timing belt tensioner.

4M-05123

## ENGINE MECHANICALS

4. Checking of timing belt pulley  
(1) Check the timing belt pulley for wear

mm (inch)

	Minimum limit
Camshaft timing belt pulley	110.6 (4.354)
Crankshaft timing belt pulley	54.6 (2.149)

If wear of the timing belt pulley exceeds the minimum limit above, replace the timing belt pulley

- (2) Check the belt contact surface of the timing belt pulley for scratches, etc.




Fig. 5-107

AM-05-24

5. Checking of crankshaft timing belt pulley flange  
Check the crankshaft timing belt pulley flange for deformation or damage




Fig. 5-108

AM-05-25

## INSTALLATION

1. Installation of camshaft timing belt pulley
  - (1) Install the camshaft timing belt pulley to the camshaft with the "F" mark facing toward your side.
  - (2) Install the washer plate of the timing belt pulley in such a way that the washer plate's locating pin for camshaft positioning use is aligned with the groove of the timing belt pulley and the hole at the end surface of the camshaft.
  - (3) Tighten the attaching bolt.
 

Tightening Torque: 3.0 - 4.5 kg-m (22 - 33 ft-lb)




Fig. 5-109

WM-05-26

Installation of crankshaft timing belt pulley flange  
 Install the crankshaft timing belt pulley flange with its hemmed portion at the periphery facing the cylinder block side.

3. Installation of crankshaft timing belt pulley  
 With the "F" mark at the end surface of the crankshaft timing belt pulley facing toward your side, insert the pulley into the crankshaft, aligning with the key groove.




Fig. 5-110

WM-05-27




Fig. 5-111

WM-05-28

4. Installation of timing belt idler subassembly No.1  
 When installing the idler subassembly No. 1, bring the right side of the locating bracket into contact with the balance shaft gear cover. Namely, set the bracket in such a way that a clearance is provided between the left side of the bracket and the balance gear cover.  
 Tightening Torque: 3.0 - 4.5 kg-m (22 - 33 ft-lb)




Fig. 5-112

WM-05-29

5. Installation of timing belt idler subassembly No.2  
 Install the timing belt idler subassembly No. 2, using a 10 mm hexagon wrench.  
 Tightening Torque: 4.0 - 5.0 kg-m (29 - 36 ft-lb)




Fig. 5-113

WM-05-30

## ENGINE MECHANICALS

### 6. Installation of timing belt tensioner

- (1) With the timing belt tensioner set to the lowest position, temporarily tighten the two attaching bolts of the timing belt tensioner.

(This tightening must be made to such an extent that the tensioner can not be moved when the tension spring is attached.)

- (2) Install the tension spring. Ensure that the tension spring are positively hooked at its both ends and will not be detached.




Fig. 5-114

WM-2133

### 7. Install the timing belt.

#### NOTE:

- ① Make sure not to bend the belt sharply to form a small radius. Such practice will cut the belt cord. (Never try to pry the timing belt with a screwdriver or the like.)
- ② Never permit oils or water to get to the belt.
- ③ When turning the engine with the belt installed, the rotation should be made at the crankshaft side.
- ④ If the belt is reused, install the belt in such a way that the belt is turned in the same direction indicated by the arrow mark which was put at the belt's back surface during the belt removal.

WM-2133

- (1) Ensure that the recessed marks of the crankshaft and camshaft timing belt pulleys are aligned with the indicator marks, respectively.




Fig. 5-115

WM-2133

- (2) Install the timing belt in such a way that the part number of the timing belt can be seen properly, as viewed toward the cylinder head side, and comes between the timing marks of the camshaft pulley. Also make sure that the three mating marks at the back surface of the belt are aligned with the recessed marks on the camshaft and crankshaft timing belt pulleys, respectively. Ensure that the belt is not slackened, especially at the tension side (exhaust side) of the belt.




Fig. 5-116

WM-2133



- (3) Ensure that the mating marks on the belt are aligned with those of the timing belt pulleys, respectively.
- (4) Slacken the attaching bolts of the tensioner which were tightened temporarily in the previous step. Ensure that the timing belt tension is provided by the tension spring.




Fig. 5-117

WM-08116

- (5) Turn the crankshaft slightly in the normal rotating direction (clockwise) thus applying tension to the timing belt between the intake camshaft timing belt pulley and the exhaust camshaft timing belt pulley and between the exhaust camshaft timing belt pulley and the crankshaft timing belt pulley.




Fig. 5-118

WM-08116

- (6) Turn the crankshaft about two turns in the normal rotating direction, until the mating mark on the cylinder head is aligned with the recessed timing mark on the camshaft.

**NOTE:**

Never make a reverse turn, even if it is the slightest one, during this operation.

WM-08117

- (7) Ensure that the tension spring force is being applied to the tensioner, by slackening the bolts of the timing belt tensioner.

- (8) Tighten the bolts of the timing belt tensioner.

**Tightening Torque:**

M10 bolt 3.0 - 4.5 kg-m (22 - 33 ft-lb)

M6 bolt 0.6 - 0.9 kg-m (4.5 - 6.5 ft-lb)




Fig. 5-119

WM-08119

- (9) Push the belt between the camshaft timing belt pulleys by hand. Ensure that the deflection meets the specification.

**Specified Deflection:** About 5 mm (0.197 inch)

(with a force of 3 kg (6.6 lb) applied)




Fig. 5-120

WM-08120

## ENGINE MECHANICALS

### NOTE:

Be sure to tighten the timing belt tensioner with the bolts, until it no longer can be moved.

8. Installation of crankshaft timing belt pulley flange  
Install the crankshaft timing belt pulley flange with its beveled portion at the periphery facing the outside.




Fig. 5-121

AV-C5-09

9. Install the timing belt lower cover.
10. Install the timing belt upper cover.
11. Install the cylinder head cover.
12. Install the surge tank bracket.
13. Install the surge tank cover.
14. Install the oil filler cap.
15. Install the resistive cords.
16. Install the crankshaft pulley.

Tightening Torque: 9.0 - 10.0 kg-m (65 - 72 ft-lb)

### NOTE:

When tightening the crankshaft pulley, use the following SST so as not to apply any excessive force to the timing belt.

SST: 09210-87701-000




Fig. 5-122

AV-C5-10


17. Install the water pump pulley.
18. Install the V-belt.
19. SST removal.

Remove the engine assembly from the following SSTs.

SST: 09219-87202-000

AV-C5-11

## CYLINDER HEAD

CB-23 AND CB-61 ENGINES  
COMPONENTS OF CYLINDER HEAD

\* : Non-reusable parts

- ① Spark plug
- ② Cylinder head cover
- ③ Cylinder head fly
- ④ Distributor
- ⑤ Distributor housing
- ⑥ Wave washer
- ⑦ Valve rocker shaft,  
valve rocker arm  
Compression spring (Valve rocker shaft)

- ⑧ Camshaft
- ⑨ O I seal
- ⑩ Valve spring retainer lock
- ⑪ Valve spring retainer
- ⑫ Compression spring (for valve)
- ⑬ Valve
- ⑭ Valve spring seat
- ⑮ Valve stem oil seal

Fig. 5-123

AM-02142

## ENGINE MECHANICALS

### REMOVAL

1. Remove the spark plugs.
2. Remove the cylinder head cover.
3. Remove the distributor.
4. Remove the distributor housing.
5. Remove the wave washer.
6. Remove the cylinder head assembly.

(1) Loosen the cylinder head bolts gradually over two or three stages, following the specified numerical sequence.

(2) Remove the cylinder head. Attach the cylinder head to the SST. Fit the SST in a vise securely.  
SST: 09219-87703-000

#### NOTE:

Be very careful not to scratch the gasket surface of the cylinder head.

7. Removal of valve rocker shafts, valve rocker arms and compression springs (for shafts).

Loosen all adjusting screws of the valve rocker arm. Pull out the valve rocker shaft, using the following SST.  
SST: 09204-87701-000

#### NOTE:

Perform this operation while holding the compression spring by hand so as to prevent it from jumping out. Arrange the removed parts in order so that their installation positions may be known readily.

8. Removal of camshaft

Put out the camshaft toward the rear side of the cylinder head.

Utmost care must be exercised not to damage the camshaft bearing bores of the cylinder head during this operation.

9. Removal of oil seal

Remove the oil seal, using a screwdriver or the like.

#### NOTE:

The oil seal is a nonreusable part.




Fig. 5-124

AW-0147




Fig. 5-125

AW-0148




Fig. 5-126

AW-0149




Fig. 5-127

AW-0150




Fig. 5-128

AW-0151

- 10. Removal of valve spring retainer locks  
 Insert the valve rocker shaft. Compress the valve spring with the SST. Remove the spring retainer locks.  
 SST: 09202-87702-000




Fig. 5-129

WM-C5-118

**NOTE:**

As for those parts 11 through 14 given below, group the parts by the kinds of valves or cylinders so that the installation positions of the parts may be known readily.

- 11. Remove the valve spring retainers.
- 12. Remove the compression springs.
- 13. Remove the valves.
- 14. Remove the valve stem oil seals
- 15. Remove the valve spring seats.

**NOTE:**

Wash the removed parts with a cleaning solvent and blow them by compressed air.  
 Do not use a cloth or the like to wipe the parts.  
 Remove the cylinder head from the SST.

WM-C5-119

**INSPECTION**

- 1. Checking of cylinder head
  - (1) Check the cylinder head for cracks, damage and distortion  
 If the cylinder head exhibits cracks or damage, replace it, as required.  
 Check the cylinder head for distortion on the following three surfaces.
  - ① Distortion of cylinder block gasket surface  
 Maximum Limit: 0.10 mm (0.039 inch)




Fig. 5-130

WM-C5-120

CB-61 and CB-80 engines:

If the distortion of the cylinder block gasket surface exceeds the maximum limit, replace the cylinder head.

CB-23 engine:

If the distortion of the cylinder block gasket surface exceeds the maximum limit, correct the surface, making sure not to exceed the height limit of 125.7 mm (4.949 inches).

## ENGINE MECHANICALS

- ② Distortion of intake manifold attaching surface  
Maximum Limit: 0.1 mm (0.039 inch)
- ③ Distortion of exhaust manifold attaching surface  
Maximum Limit: 0.1 mm (0.039 inch)

C3-23 and C8-61 engines:

If the distortion of the intake manifold or exhaust manifold attaching surface exceeds the maximum limit, correct the surface, making sure not to exceed the width limit of 159.4 mm (6.29 inches).

### (2) Checking valve seats

Apply a thin film of red lead to the valve seat. Let the valve drop by its own weight onto the valve seat two or three times. Take out the valve. Measure the width of the contact surface of the valve seat.

Specified Value: 1.0 - 1.8 mm (0.039 - 0.071 inch)

### NOTE:

If the valve-to-valve seat contact surface does not conform to the specifications or the contact surface exhibits roughness, correct the cylinder head or replace it, as required.

### (3) Refacing valve seats

Reface the valves, using a valve seat cutter.

### NOTE:

If the valve guide bush is worn, first replace it. Then, proceed to the valve seat refacing.

#### • Refacing procedure for intake valve seats

- ① Recondition the roughness on the valve-to-valve seat contact surface, using a 45-degree cutter.
- ② Using a 30-degree cutter, cut the valve seat in such a way that the circumference of the surface refaced by the 45-degree cutter may become  $35 \pm 0.1$  mm ( $1.38 \pm 0.004$  inches).
- ③ Using a 70-degree cutter, cut the valve seat in such a way that the width of the surface refaced by the 45-degree cutter may become 1.4 mm (0.055 inches).




Fig. 5-131

WM-25109




Fig. 5-132

WM-25110




Fig. 5-133

WM-25111




Fig. 5-134

WM-25112




Fig. 5-135

WM-25113

- ④ Using the 45-degree cutter, remove burrs produced during the refacing by the 30-degree and 70 degree cutters.

● **Refacing procedure for exhaust valve seats**

- ① Recreate the roughness on the valve-to-valve seat contact surface using a 45-degree cutter
- ② Using a 20-degree cutter, cut the valve seat in such a way that the circumference of the surface refaced by the 45-degree cutter may become 32 mm (1.26 inches)
- ③ Using a 60-degree cutter, cut the valve seat in such a way that the width of the surface refaced by the 45-degree cutter may become 1.4 mm (0.055 inches)
- ④ Using the 45-degree cutter, remove burrs produced during the refacing by the 20-degree and 60-degree cutters




Fig. 5-136

474-05-136




Fig. 5-137

474-05-136




Fig. 5-138

474-05-137




Fig. 5-139

474-05-138




Fig. 5-140

474-05-139

## ENGINE MECHANICALS

### (4) Checking of valve recession

After the valve seat has been refaced, install the new valve. Measure the distance between the cylinder attaching surface of the cylinder head (attaching surface of the cylinder head gasket) and the uppermost section of the valve. Ensure that the distance does not exceed the following maximum limit.

**Maximum Limit:**

Intake valve 1.866 mm (0.0743 inch)

Exhaust valve 2.807 mm (0.1105 inch)

### NOTE:

If the recession exceeds the maximum limit, replace the cylinder head.




Fig. 5-141

WM-05150

## 2. Checking of valves

### (1) Checking valve stems

Visually inspect the valve stem for seizure or damage. If the valve exhibits damage, replace it together with the valve guide bush as a set.




Fig. 5-142

AM-05161

### (2) Checking valve stem end

① Check the valve stem end for abnormal wear.




Fig. 5-143

AM-05162

② If the valve stem exhibits abnormal wear, correct the stem end with a valve refacer.

However, make sure that the valve has the minimum valve overall length of 100.85 mm (3.97 inches).

**Minimum Valve Overall Length:**

100.85 mm (3.97 inches)




Fig. 5-144

WM-05163



(3) Checking of valve heads

- ① Check the valve-to-valve seat contact surface for roughness or damage. Remove any carbon deposit from the valve head.

- ② If the valve-to-valve seat contact surface exhibits any damage, grind the surface with a valve refacer

Valve Face Angle: 45.5°

- ③ After the valve head has been ground, measure the stock thickness of the valve head.

**Minimum Limit**

Intake valve	0.8 mm (0.031 inch)
Exhaust valve	1.0 mm (0.039 inch)

**NOTE:**

If the stock thickness of the valve head is less than the limit, replace it with a new one.

When replacing the valve with new one be sure to check the oil clearance with the valve guide bush.

3 Checking of valve guide bush-to-valve stem oil clearance

(1) Measuring oil clearance

Measure the valve guide bush-to-valve stem oil clearance

Oil clearance = Inner diameter of valve guide bush – Outer diameter of valve stem

Specified Value: Intake valve: 0.040 - 0.090 mm (0.0016 - 0.0035 inch)

Exhaust valve: 0.045 - 0.100 mm (0.0018 - 0.0039 inch)

**NOTE:**

If the measured oil clearance exceeds the specified value, replace the valve guide bush together with the valve as a set.




Fig. 5-145

AW-05'64




Fig. 5-146

AW-05'65




Fig. 5-147

AW-05'66

## ENGINE MECHANICALS

- ① Measurement of inner diameter of valve guide bush  
Perform the measurement at six points.




Fig. 5-148

WM-25168

- ② Measurement of outer diameter of valve stem  
Perform the measurement at six points.




Fig. 5-149

WM-26169

### (2) Replacing valve guide bush

#### NOTE:

When replacing the valve guide bush, replace also the valve as a set. However, if the bushes with rings (replacement part) have been already installed as valve guide bushes, replace the cylinder head.

WM-26170

#### • Exhaust side

- ① Break the valve guide bush, using a brass bar




Fig. 5-150

WM-25171

- ② Drive out the valve guide bush toward the combustion chamber side, using the following SST.

SST: 09201-87201-000




Fig. 5-151

WM-25172

- ③ Drive a new valve guide bush into position, until the snap ring contacts the cylinder head, using the following SST.

SST: 09201-87201-000

**NOTE:**

After the valve guide bush has been driven into position, remove any burr or the like, using an adjustable reamer. At this time, make sure that the specified oil clearance is assured between the valve guide bush and the valve stem.

• **Intake side**

- ① Drive out the valve guide bush from the combustion chamber side, using the following SST

SST: 09201-87201-000

- ② Drive a new valve guide bush into position, until the snap ring contacts the cylinder head, using the following SST.

SST: 09201-87201-000

**NOTE:**

After the valve guide bush has been driven into position, remove any burr or the like, using an adjustable reamer. At this time, make sure that the specified oil clearance is assured between the valve guide bush and the valve stem.

4. Checking of valve springs

- (1) Check the valve spring for squareness, using a square

Maximum limit: 1.5 mm (0.059 inch)

- (2) Using a spring tester, measure the free length. Also, measure the spring tension with the spring compressed to the specified installed length

Minimum free length: 42.0 mm (1.654 inch)

Spring tension:

Minimum limit/installation height

22.7 kg/34.9 mm (56.7 lb/1.374 inch)




Fig. 5-152

AWJ-05-13




Fig. 5-153

AWJ-05-14




Fig. 5-154

AWJ-05-15




Fig. 5-155

AWJ-05-16




Fig. 5-156

AWJ-05-17

## ENGINE MECHANICALS

5. Checking of valve rocker arms and valve rocker shafts  
(1) Check the rocker arms and rocker shafts for cracks and damage.




Fig. 5-157

WJ4-02172

- (2) Measure the oil clearance.

Oil clearance = Inner diameter of valve rocker arm -  
Outer diameter of valve rocker shaft  
Specified Value: Oil clearance 0.016 - 0.09 mm  
(0.00063 - 0.00350 inch)

### NOTE:

The oil clearance should be established by measuring the following two values. The inner diameter of each valve rocker arm and the outer diameter of the valve rocker arm installation section of the valve rocker shaft.




Fig. 5-158

WJ4-03172

If the oil clearance does not meet the specifications, replace the parts with new ones, as required, referring to the specified values of the inner diameter of the valve rocker arm and the outer diameter of the valve rocker shaft.

Inner diameter of valve rocker arm (new one)  
16.000 - 16.018 mm (0.6300 - 0.6306 inch)  
Outer diameter of valve rocker shaft (new one)  
15.958 - 15.984 mm (0.6283 - 0.6293 inch)

### [Reference]

Oil clearance at the time when the valve rocker shaft and valve rocker arm have been replaced by new ones:  
0.016 - 0.060 mm (0.0006 - 0.0024 inch)

WJ4-02

## Checking of camshaft

## (1) Checking distributor drive gear

Check the distributor drive gear for cracks and abnormal wear.

## NOTE:

If the distributor drive gear exhibits any abnormal wear, check the distributor driven gear, too.

## (2) Checking camshaft for runout

Support the camshaft at its both ends with V-shaped blocks. Set a dial gauge to the mid-point of the center journal section of the camshaft. Turn the camshaft one turn, making sure that the camshaft will not move in the axial direction. Take a reading on the dial gauge during the turning. Calculate the maximum runout, i.e. the difference between the maximum and minimum readings.

Maximum runout: 0.03 mm (0.0012 inch)

## (3) Checking cam lobe height:

Minimum limit	mm (inches)
CB-23	33.6 (1.367)
CB-51	39.6 (1.567)

If the measured height is less than the minimum limit, replace the camshaft.




Fig. 5-159

V-160-11




Fig. 5-160

V-160-12




Fig. 5-161

V-160-13

## (4) Checking oil clearance

- ① Measure the outer diameters of the journal sections of the camshaft.
- ② Measure the inner diameters of the bearing bores of the cylinder head at three points of front, center and rear sections. This bore measurement for each section should be conducted in two directions, 90 degrees apart from each other.




Fig. 5-162

MM-02-94

## Oil clearance

Front	0.04 - 0.14 mm (0.0016 - 0.0055 inch)
Center	0.08 - 0.18 mm (0.0035 - 0.0075 inch)
Rear	0.06 - 0.16 mm (0.0024 - 0.0063 inch)

If the oil clearance exceeds the specified value, replace the parts, as required, so that the oil clearance may meet the specifications, referring to the following specified dimensions of the camshaft journal sections and the camshaft bearing bores of the cylinder head.

MM-05-95

## Specified Dimensions

	Front	Center	Rear
Outer diameter of camshaft journal section	31.960 - 31.960 mm (1.2583 - 1.2591 inches)	47.385 - 47.410 mm (1.8655 - 1.8663 inches)	48.415 - 48.440 mm (1.9061 - 1.9071 inches)
Inner diameter of camshaft bearing bore of cylinder head	32.020 - 32.045 mm (1.2605 - 1.2618 inches)	47.500 - 47.525 mm (1.8701 - 1.8711 inches)	48.500 - 48.525 mm (1.9094 - 1.9104 inches)

MM-05-95

## 7. Checking of wave washer

Check the wave washer for flattened condition or damage.




Fig. 5-163

MM-05-95

## 8. Hand lapping of valves

- (1) After all checks have been completed, carry out hand lapping of the valves before assembling them.
- (2) Apply a thin film of abrasive compound to the valve and valve seat. Perform the lapping with a valve lapper.
- (3) After completion of the lapping, wash the valves and cylinder head, using a cleaning solvent. Blow them with compressed air.




Fig. 5-164

MM-05-95

**INSTALLATION**

Install the cylinder head to the SST\* (09219-87703-000).

1. Install the valve spring seats.
2. Installation of valve stem oil seals  
Apply engine oil to a new valve stem oil seal. Then, insert it into the valve guide bush using the following SST.  
SST: 09201-87703-000




Fig. 5-165

WV-07-89

3. Installation of valves  
Apply engine oil to the valve stem. Insert it into the valve guide bush from the combustion chamber side, being very careful not to damage the valve stem oil seal.  
NOTE:  
Once the valve has been inserted, never pull it out from position. If the valve should be pulled out, replace the valve stem oil seal with a new one.

WV-08-93

4. Install the compression springs (for the valves)
5. Install the valve spring retainers
6. Installation of valve spring retainer locks  
Insert the valve rocker shaft into position, install the valve spring retainer lock, using the following SST.  
SST: 09201-87702-000




Fig. 5-166

WV-05-91

After the valve spring retainer lock has been installed, lightly tap the valve retainer using a plastic hammer. In this way, ensure that the valve spring retainer lock is installed securely.

**NOTE:**

During this check, care must be exercised to ensure that the valve spring retainer or lock retainer may not be jumped out.




Fig. 5-167

WV-06-92

7. Installation of oil seals  
Install a new oil seal to the cylinder head using the following SST.  
SST: 09515-87202-000

After the oil seal has been installed, apply engine oil to the oil seal lip section.




Fig. 5-168

WV-06-92

## ENGINE MECHANICALS

### 8. Installation of camshaft

- (1) Apply engine oil to the camshaft bearing bores of the cylinder head.
- (2) Apply engine oil to the camshaft journal sections.
- (3) Assemble the camshaft to the cylinder head, being very careful not to damage the camshaft bearing bores of the cylinder head.




Fig. 5-169

WM-05-97

### 9. Installation of valve rocker shafts, valve rocker arms and compression springs (for valve rocker shafts)

Apply oil to the valve rocker shafts, valve rocker arms, compression springs and valve rocker shaft attaching nodes of the cylinder head. Then, install these parts.



Fig. 5-170

WM-05-97

#### NOTE:

The length of the valve rocker shaft differs between the exhaust side and the intake side.




Fig. 5-171

WM-05-97

### 10. Installation of wave washer

Apply engine oil to the wave washer. Assemble it to the cylinder head.




Fig. 5-172

WM-05-97

### 11. Installation of distributor housing

Tighten the distributor housing to the specified torque.  
Tightening Torque: 0.4 - 0.7 kg-m (2.9 - 5.1 ft-lb)

#### NOTE:

Be sure to use a new O-ring.

WM-05-98



**Adjustment of valve clearances**

After the distributor housing has been installed, adjust the valve clearances.

**Exhaust valve** — 0.15 mm (0.006 inch)

**Intake valve** — 0.15 mm (0.006 inch)

- (1) Turn the camshaft, until the camshaft woodruff key comes at the exact top position. Then, adjust the clearances of the intake and exhaust valves of the cylinder No.1, the exhaust valve of the cylinder No.2 and the intake valve of the cylinder No.3.
- (2) Turn the camshaft, until the camshaft woodruff key comes at the exact bottom position. Then, adjust the clearances of the intake valve of the cylinder No.2 and the exhaust valve of the cylinder No.3.
- (3) After the valve clearances have been adjusted, turn the camshaft, until the camshaft woodruff key comes at the top position.

**NOTE:**

After the engine assembly has been mounted on the vehicle, warm up the engine fully. Readjust the valve clearances to the specifications for hot operation.




Fig. 5-173

WM-05126




Fig. 5-174

WM-05200

**Reference**

Camshaft position	No. of cylinder		
	1	2	3
Camshaft woodruff key position: exact top	Intake valve	○	○
	Exhaust valve	○	○
Camshaft woodruff key position: exact bottom	Intake valve	○	
	Exhaust valve		○

**13. Installation of cylinder head assembly**

- (1) Remove the cylinder head from the SST.
- (2) Install a new cylinder head gasket on the cylinders.
- (3) Check to see if oil or water, etc. is present in the attaching holes of the cylinder head bolts at the cylinder block side. Remove any oil or water which is present by blowing compressed air.
- (4) Turn the camshaft key, until the camshaft woodruff key comes at the exact top position.

**NOTE:**

At this time, make sure that the crankshaft comes at the top dead center under the compression stroke of the cylinder No.1.

- (5) Install the cylinder head onto the cylinder head gasket surface, being very careful not to scratch the gasket.

WM-05201

## ENGINE MECHANICALS

- (6) Insert the cylinder head bolts into position. Tighten the bolts to the specified torque in the sequence indicated in the right figure.

**Tightening Torque:** 5.5 - 6.5 kg-m (40 - 47 ft-lb)




Fig. 5-175

W4-02201

### 7A. Installation of distributor

- (1) Ensure that the cylinder No 1 is at the top dead center under the compression stroke or that the camshaft woodruff key comes at the exact top position.




Fig. 5-176

W4-02211

- (2) Determine the position of the distributor shaft by aligning the punch mark at the end of the distributor with the recessed mark, as shown in the right figure.

#### NOTE:

Fill about 30 cc of engine oil in the distributor housing.




Fig. 5-177

W4-02201

- (3) Insert the distributor proper into the distributor housing in such a way that the split line of the distributor proper may be aligned with the embossed line of the distributor housing.




Fig. 5-178

W4-02201

- (4) Tighten the attaching bolts of the distributor temporarily.

#### NOTE:

Tighten the attaching bolts securely after the engine assembly has been mounted on the vehicle and the engine tune-up has been performed.





Fig. 5-179

W4-02201

## B-80 ENGINE COMPONENTS OF CYLINDER HEAD



\* : Non-reusable parts

- ① Distributor Assy
- ② Cylinder head Assy
- ③ Cylinder head gasket
- ④ Camshaft bearing cap
- ⑤ Oil seal
- ⑥ Camshaft
- ⑦ Shim

- ⑧ Valve lifter
- ⑨ Valve spring retainer lock
- ⑩ Valve spring retainer
- ⑪ Compression spring
- ⑫ Valve
- ⑬ Valve stem oil seal
- ⑭ Valve spring seat

Fig. 5-180

WM-35002

## ENGINE MECHANICALS

### REMOVAL

1. Remove the distributor assembly.
2. Remove the cylinder head assembly.
  - (1) Loosen the cylinder head bolts gradually over two or three stages, following the sequence indicated in the right figure. Then, pull out the cylinder head bolts.

- (2) Remove the cylinder head. Attach the cylinder head to the SST. Fit the SST in a vise securely.  
SST: 09219-87703-000

#### NOTE:

Be very careful not to scratch the gasket surface of the cylinder head.

3. Remove the cylinder head gasket.

4. Remove the camshaft bearing caps.

- (1) Turn the camshaft about 30 degrees counterclockwise so that the tappet may be brought under a non-compressed state.

- (2) Pull out the camshaft bearing cap bolts.

#### NOTE:

Be sure to alternately slacken the camshaft bearing cap bolts over two or three stages.

5. Remove the oil seal.

6. Remove the camshaft.

7. Remove the shims.

#### NOTE:

Arrange the removed shims in order so that their installation positions may be known readily.

8. Remove the valve lifters.

#### NOTE:

Arrange the removed valve lifters in order so that their installation positions may be known readily.

9. Removal of valve spring retainer locks.

Remove the valve spring retainer lock using the following SSTs.

SST: 09202-87002-0A0

09202-87002-000




Fig. 5-181

W4-0204




Fig. 5-182

W4-0210




Fig. 5-183

W4-0211




Fig. 5-184

W4-0213

- Remove the valve spring retainers
11. Remove the compression springs.
  12. Remove the valves.
  13. Remove the valve stem oil seals
  14. Remove the valve spring seats
  15. Remove the cylinder head from the SST.

**NOTE:**

Wash the removed parts with a cleaning solvent and blow them by compressed air.  
(Do not use a cloth or the like to wipe the parts.)

WM-0214

**INSPECTION**

1. Checking of cylinder head
  - (1) Check the cylinder head for cracks, damage and distortion.  
If the cylinder head exhibits cracks or damage, replace it, as required.  
Check the cylinder head for distortion on the following three surfaces.
    - ① Distortion of cylinder block gasket surface  
Maximum Limit: 0.10 mm (0.039 inch)
    - ② Distortion of intake manifold attaching surface  
Maximum Limit: 0.10 mm (0.039 inch)
    - ③ Distortion of exhaust manifold attaching surface  
Maximum Limit: 0.10 mm (0.039 inch)




Fig. 5-125

WM-0215

**NOTE:**

If the distortion exceeds the maximum limit, replace the cylinder head.

- (2) Checking valve seats
 

Apply a thin film of red lead to the valve seat. Let the valve drop by its own weight onto the valve seat two or three times. Take out the valve. Measure the width of the contact surface of the valve seat.

Specified Value: 1.2 - 1.6 mm (0.047 - 0.063 inch)

**NOTE:**

If the valve-to-valve seat contact surface does not conform to the specifications or the contact surface exhibits roughness, correct the cylinder head or replace it, as required.




Fig. 5-126

WM-0216

## (3) Refacing valve seats

Reface the valves, using a valve seat cutter.

### NOTE:

If the valve guide bush is worn, first replace it. Then, proceed to the valve seat refacing.

WM-05217

### • Refacing procedure for intake valve seats

- ① Recondition the roughness on the valve-to-valve seat contact surface, using a 45-degree cutter




Fig. 5-187

WM-05219

- ② Using a 30-degree cutter, cut the valve seat in such a way that the circumference of the surface refaced by the 45-degree cutter may become  $29 \pm 0.1$  mm ( $1.14 \pm 0.004$  inches).




Fig. 5-188

WM-05219

- ③ Using a 70-degree cutter, cut the valve seat in such a way that the width of the surface refaced by the 45-degree cutter may become  $1.4 \pm 0.2$  mm ( $0.055 \pm 0.008$  inches)




Fig. 5-189

WM-05219

- ④ Using the 45-degree cutter, remove burrs produced during the refacing by the 30-degree and 70-degree cutters




Fig. 5-190

WM-05221

◆ Refacing procedure for exhaust valve seats

- ① Recondition the roughness on the valve-to-valve seat contact surface using a 45-degree cutter.




Fig. 5-191

WJ-0522

- ② Using a 20-degree cutter, cut the valve seat in such a way that the circumference of the surface refaced by the 45-degree cutter may become  $25.0 \pm 0.1$  mm ( $0.98 \pm 0.004$  inches).




Fig. 5-192

WJ-0523

- ③ Using a 70-degree cutter, cut the valve seat in such a way that the width of the surface refaced by the 45-degree cutter may become  $1.4 \pm 0.2$  mm ( $0.055 \pm 0.008$  inches).




Fig. 5-193

WJ-0524

- ④ Using the 45-degree cutter, remove burrs produced during the refacing by the 20-degree and 70-degree cutters.




Fig. 5-194

WJ-0525

## ENGINE MECHANICALS

### (4) Checking of valve seat recession

After completion of the valve seat refacing, using a micrometer, measure the clearance between the upper end of the valve seat surface refaced by the 45 degree cutter and the cylinder head gasket surface.

#### Maximum Limit

Intake valve: 4.23 mm (0.1665 inch)

Exhaust valve: 5.30 mm (0.2087 inch)

#### NOTE:

If the recession exceeds the maximum limit, replace the cylinder head.




Fig. 5-135

WV 05235

## 2. Checking of valves

### (\*) Checking valve stems

Visually inspect the valve stem for seizure or damage. If the valve exhibits damage, replace it together with the valve guide bush as a set.




Fig. 5-136

WV 05237

### (2) Checking valve stem end

- ① Check the valve stem end for abnormal wear or damage




Fig. 5-137

WV 05238

- ② If the valve stem exhibits abnormal wear, correct the stem end with a valve refacer

However, make sure that the valve has the following minimum valve overall length given below

#### Minimum Valve Overall Length:

Intake valve: 106.4 mm (4.189 inches)

Exhaust valve: 106.6 mm (4.197 inches)




Fig. 5-138

WV 05239



(3) Checking of valve heads

- ① Check the valve-to-valve seat contact surface for roughness or damage.




Fig. 5-199

WM-05230

- ② If the valve-to-valve seat contact surface exhibits any damage, grind the surface with a valve refacer.

Valve Face Angle: 45.5°




Fig. 5-200

WM-05231

- ③ After the valve head has been ground, measure the stock thickness of the valve head.

Minimum Limit Intake valve 0.7 mm (0.028 inch)

Exhaust valve 0.8 mm (0.031 inch)

NOTE:

If the stock thickness of the valve head is less than the limit, replace it with a new one.

When replacing the valve head, be sure to check the oil clearance with the valve guide bush




Fig. 5-201

WM-05232

3 Checking of valve guide bush-to-valve stem oil clearance

(1) Measuring oil clearance

Measure the valve guide bush-to-valve stem oil clearance

Oil clearance = Inner diameter of valve guide bush - Outer diameter of valve stem

Specified Value: Intake valve: 0.025 - 0.08 mm (0.0009 - 0.0031 inch)

Exhaust valve: 0.030 - 0.09 mm (0.0012 - 0.0035 inch)

WM-05233

- ① Measurement of inner diameter of valve guide bush  
Perform the measurement at six points.




Fig. 5-202

WM-05234

- ② Measurement of outer diameter of valve stem  
Perform the measurement at six points.




Fig. 5-203

WV-C05215

- (2) Replacing valve guide bush if necessary  
**NOTE.**

When replacing the valve guide bush, replace also the valve as a set. However, if the intake valve guide bushes with rings (replacement part) have been already installed as valve guide bushes, replace the cylinder head

WV-C05236

◆ **Exhaust side**

- ① Drive out valve guide bush from the combustion chamber side, using the SST

SST: 09201-87201-000




Fig. 5-204

WV-C05237

- ② Measure the inner diameter of the installation hole of the valve guide bush of the cylinder head.

Specified Inner Diameter:

11.05 mm dia. (0.45 inch dia.)

**NOTE**

If the measured value exceeds the specified value, replace the cylinder head.




Fig. 5-205

WV-C05238

- ⑤ Drive a new valve guide bush into position, until the snap ring contacts the cylinder head, using the following SST

SST: 09201-87201-000

**NOTE.**

After the valve guide bush has been driven into position, remove any burr or the like, using an adjustable reamer. At this time, make sure that the specified oil clearance is assured between the valve guide bush and the valve stem.




Fig. 5-206

WV-C05240

• **Intake side**

- ① Drive out the valve guide bush from the combustion chamber side, using the following SST.

SST: 09201-87201-000

- ② Drive a new valve guide bush into position, until the snap ring contacts the cylinder head, using the following SST.

SST: 09201-87201-000

**NOTE:**

After the valve guide bush has been driven into position, remove any burr or the like, using an adjustable reamer. At this time, make sure that the specified oil clearance is assured between the valve guide bush and the valve stem.

4. **Checking of valve springs**

- (1) Check the valve spring for squareness, using a square.

Maximum limit: 1.6 mm (0.063 inch)

- (2) Using a spring tester measure the free length. Also, measure the spring tension with the spring compressed to the specified installed length.

Minimum free length: 44.5 mm (1.75 inches)

Spring tension:

Minimum limit/installation height

34.4 kg/27.67 mm (75.9 lb/1.09 inches)

5. **Checking of valve lifters and shims**

- (1) Check the valve lifter shim surfaces for wear or damage.

**NOTE:**

If the valve lifter exhibits wear or damage, replace it with a shim of the same size as the original valve lifter shim. (The shim size is stamped on the valve lifter shim.)

- (2) **Checking valve lifters**

Check the valve lifters for seizure or damage.




Fig. 5-207

WM-7621




Fig. 5-208

WM-6524




Fig. 5-209

WM-05610




Fig. 5-210

WM-05610




Fig. 5-211

WM-05610

## ENGINE MECHANICALS

### 6. Checking of valve lifter-to-cylinder head oil clearance

WM-05246

- (1) Measure the inner diameter of the valve lifter hole of the cylinder head.




Fig. 5-212

WM-05247

- (2) Measure the outer diameter of the valve lifter. This measurement should be conducted in two directions, 90 degrees apart, from each other.




Fig. 5-213

WM-05248

Oil clearance: 0.015 - 0.07 mm (0.0006 - 0.0028 inch)

If the oil clearance exceeds the specified value, replace the valve lifter with a new one and/or cylinder head, as required, referring to the following specified dimensions of new valve lifters.

**Outer diameter of valve lifter (New part)**

29.975 - 29.985 mm (1.1801 - 1.1805 inches)

WM-05249

### 7. Checking of camshaft

- (1) Checking camshaft for runout

Support the camshaft at its both ends with V-shaped blocks. Set a dial gauge to each of the camshaft journal sections No.2, No.3, No.6 and No.7. Turn the camshaft one turn, making sure that the camshaft will not move in the axial direction. Take a reading on the dial gauge during the turning. Calculate the maximum runout, i.e. the difference between the maximum and minimum readings.

Maximum runout: 0.03 mm (0.0012 inch)




Fig. 5-214

WM-05250

- (2) Checking cam lobe height

Measure the cam lobe height.

Minimum limit: Intake valve 39.4 mm (1.55 inches)

Exhaust valve 39.0 mm (1.53 inches)

If the measured height is less than the minimum limit, replace the camshaft.




Fig. 5-215

WM-05251

## (3) Checking oil clearance

With the bearing cap tightened to the specified torque, measure the oil clearance, using the plastigage.

**Tightening Torque:**  $1.3 \pm 0.15$  kg-m ( $9.4 \pm 1.1$  ft-lb)

**Oil Clearance:**

0.025 - 0.16 mm (0.0010 - 0.0063 inch)




Fig. 5-216

WM-05222

## (4) Checking thrust clearance

After the bearing caps have been tightened to the specified torque, check the thrust clearance.

**Maximum limit:** 0.20 mm (0.0078 inch)




Fig. 5-217

WM-05222

## 8 Hand lapping of valves

After all checks have been completed, carry out hand lapping of the valves before assembling them.

Apply a thin film of abrasive compound to the valve and valve seat. Perform the lapping with a valve lapper.

After completion of the lapping, wash the valves and cylinder head, using a cleaning solvent. Blow them with compressed air.

WM-05254

## INSTALLATION

Install the cylinder head to the SST (09219-87703-000).

Install the valve spring seats

## 1 Installation of valve stem oil seals

Apply engine oil to a new valve stem oil seal. Then, insert it into the valve guide bush by your hands.




Fig. 5-218

WM-05256

## 3 Installation of valves

Apply engine oil to the valve stem. Insert it into the valve guide bush from the combustion chamber side, being very careful not to damage the valve stem oil seal.

**NOTE:**

(1) Be sure to install the valves, valve springs and valve retainers into the original position to which they were installed before the disassembly. (This does not apply to the replaced parts.)

(2) Once the valve has been inserted, never pull it out from position. If the valve should be pulled out, replace the valve stem oil seal with a new one.




Fig. 5-219

WM-05256

## ENGINE MECHANICALS

4. Installation of compression springs  
Assemble the compression spring with the white-painted side facing the cylinder head




Fig. 5-220

AW-C5257

5. Install the valve spring retainers.
6. Installation of valve spring retainer locks using the following SSTs.

SST: 09202-87002-0A0

09202-87002-000




Fig. 5-221

AW-C5258

After the valve spring retainer lock has been installed, lightly tap the valve retainer, using a plastic hammer. In this way, ensure that the valve spring retainer lock is installed securely.

### NOTE.

During this check, care must be exercised to ensure that the valve spring retainer or lock retainer may not be jumped out.




Fig. 5-222

AW-C5259

7. Installation of valve lifters  
Apply engine oil to the cylinder head valve lifter hole and valve lifter. Then, insert the valve lifter into position.

### NOTE.

Make sure that the valve lifter can be rotated lightly.




Fig. 5-223

AW-C5260

8. Installation of shims  
Install the shims in the same number as installed before the disassembly. The shim should be installed with the size-indicated side facing toward the lifter.

Face side where in-sizable mark is stamped toward lifter.




Fig. 5-224

AW-C5261

Installation of camshafts

- (1) Apply engine oil to the camshaft bearing bores of the cylinder head.
- (2) Apply engine oil to the camshaft journal sections where the oil seals have been assembled. Then, install the camshaft to the cylinder head.
- (3) For identification purpose, the camshaft for exhaust valve use has a groove for driving the distributor, as indicated in the right figure.

NOTE:

Set each camshaft to the initial position. Namely, set each of the camshafts to a state where the camshaft pushes no valve lifter.




Fig. 5-225

WA-02253




Fig. 5-226

WA-02264

10. Installation of camshaft bearing caps

Apply engine oil to the inside of each camshaft bearing cap. Then, evenly tighten the camshaft bearing caps to the specified torque.

Tightening Torque: 1.15 - 1.45 kg-m (8.3 - 10.5 ft-lb)

NOTE:

- ① Make sure that the oil seal may not tilt during the bearing cap installation.
- ② Be sure to install each camshaft bearing cap correctly, according to the embossed number and arrow at the back side of the cap.




Fig. 5-227

WA-05268

Installation of oil seals

Apply engine oil to each new oil seal. Then, press it into position, using the following SST.

SST: 09618-87301-000




Fig. 5-228

WA-05262

12. Installation of cylinder head gasket

Install a new cylinder head gasket.

WA-05266

## ENGINE MECHANICALS

### 13. Installation of cylinder head assembly

Tighten the bolts over two stages, following the sequence indicated in the right figure.

Tightening Torque:

First tightening 4.0 - 4.5 kg-m (29 - 33 ft-lb)

Second tightening 6.0 - 7.0 kg-m (43 - 51 ft-lb)

NOTE:

- ① Be very careful not to scratch the cylinder head and gasket during the installation.
- ② Make sure that no water or oil remains in the attaching holes of the cylinder head bolts.

### 14. Installation of distributor assembly

(1) Remove the distributor cap, lift the rotor, as indicated in the right figure.

(2) While turning the rotor, push and insert the distributor assembly into the groove for driving the distributor.

NOTE:

Apply about 40 cc of engine oil between the camshaft journal sections. Also, apply about 10 cc of engine oil to the distributor dog chamber (at the rear end of the camshaft for exhaust valves).




Fig. 5-229

AV-22287




Fig. 5-230

AV-05265


### 15. Remove the cylinder head from the SS\*

AV-05250



**CYLINDER BLOCK**

(CB-23, CB-61 & CB-80 ENGINES)  
COMPONENTS OF CYLINDER BLOCK



\* : Non-reusable parts

- |  |                                   |
|--|-----------------------------------|
| ① Alternator Ay                              | ⑩ Oil pump sprocket               |
| ② Oil cleaner element                        | ⑪ Balance shaft                   |
| ③ Oil cooler Ay (CB-61 & CB-80 engines only) | ⑫ Connecting rod cap              |
| ④ Oil filler bracket                         | ⑬ Connecting rod bearing          |
| ⑤ Water inlet pipe                           | ⑭ Connecting rod with piston      |
| ⑥ Water inlet                                | ⑮ Flywheel                        |
| ⑦ Dust seal                                  | ⑯ Rear end plate                  |
| ⑧ Water pump Ay                              | ⑰ Oil seal retainer with oil seal |
| ⑨ Dust seal                                  | ⑱ Gasket                          |
| ⑫ Oil pan                                    | ⑲ Balance shaft rear cover        |
| ⑬ Balance shaft gear cover                   | ⑳ Balance shaft rear cover gasket |
| ⑭ Oil seal                                   | ㉑ Crankshaft bearing cap          |
| ⑮ Gasket                                     | ㉒ Crankshaft bearing (lower)      |
| ⑯ Oil pump drive sprocket & drive chain      | ㉓ Crankshaft                      |
| ⑰ Oil nozzle (CB-80 engine only)             | ㉔ Thrust washer                   |
| ⑱ Oil pump outlet pipe with oil pump         | ㉕ Crankshaft bearing (upper)      |
| ⑲ Balance weight                             | ㉖ Cylinder block                  |

Fig. 5-231

AM-05270

## ENGINE MECHANICALS

### REMOVAL

1. Remove the alternator assembly.
2. Remove the oil cleaner element.
3. Remove the oil cooler assembly. (CB-61 & CB-80 engines only)
4. Remove the oil filter bracket.
5. Remove the water inlet pipe.
6. Remove the dust seal.
7. Remove the water pump assembly.
8. Remove the dust seal.
9. Remove the oil pan and oil pan gasket.
10. Remove the balance shaft gear cover.
11. Remove the crankshaft oil seal.
12. Remove the gasket.
13. Remove the balance weight.
14. Remove the oil pump drive sprocket and drive chain.
15. Remove the oil nozzle. (CB-80 engine only)
16. Remove the oil pump and oil pump outlet pipe.
17. Removal of balance shaft:

WM-050-1

- (1) Align the stamped mark on the crank shaft gear with the stamped mark on the balance shaft drive gear.




Fig. 5-232

WM-05072

- (2) Remove the hexagon socket head cap bolt, using a (5 mm) hexagon wrench key.  
Pull out the balance shaft toward the front side of the cylinder block.




Fig. 5-233

WM-05213

### 18. Removal of connecting rod bearing cap

- (1) Turn the crankshaft, until the connecting rod bearing cap to be removed comes at the oil pan side.
- (2) Slacken the connecting rod bearing cap nuts evenly over two or three stages. Then, remove the connecting rod bearing cap nuts.

#### NOTE:

Use the following SST to prevent the crankshaft from turning.




Fig. 5-234

WM-05214

SST: 09210-87701-000

(3) Remove the connecting rod bearing cap.

**NOTE:**

- ① Arrange the removed connecting rod bearing caps in order so that their installation positions may be known readily.
- ② Never touch the surface of the bearing by hands.
- ③ Be very careful not to scratch the crankshaft by the connecting rod bolts.

19. Removal of connecting rod bearings

Remove the connecting rod bearing, as follows. Push the connecting rod bearing at the side without the turning-preventive tang by your finger so that the opposite end may float. Thus, take out the bearing. Do not touch the front surface and the back surface of the bearing by your finger during the removal.

**NOTE:**

- ① Arrange the removed connecting rod bearings in order so that their installation positions may be known readily.
- ② Be very careful not to scratch the front surface or back surface of the bearings.
- ③ Never touch the front surface or back surface of the bearings by hands.

20. Removal of connecting rod with piston

- (1) If the upper part of the cylinder block exhibits carbon deposits, forming ridges, remove them with a ridge reamer or the like.
- (2) Draw the connecting rod with the piston to the cylinder head side.

**NOTE:**

- ① Be very careful not to scratch the cylinder wall surfaces, crankshaft journals and connecting rod.
- ② Arrange the removed connecting rods with the pistons in order so that their installation positions may be known readily.

21. Removal of flywheel

- (1) Slacken the attaching bolts of the flywheel evenly over two or three stages. Then, remove the bolts.
- (2) Remove the flywheel.

**NOTE:**

Care must be exercised as to its handling because the flywheel is heavy.




Fig. 5-235

4M-C5273




Fig. 5-236

4M-C5273




Fig. 5-237

4M-C5277




Fig. 5-238

4M-C5275

## ENGINE MECHANICALS

22. Remove the rear end plate.
23. Remove the oil seal retainer with the oil seal.
24. Remove the gasket.
25. Remove the balance shaft rear cover.
26. Remove the balance shaft rear cover gasket.
27. Removal of crankshaft bearing caps.

- (1) Slacken the crankshaft bearing cap bolts evenly over two or three stages. Then, remove the bolts.
- (2) Remove the crankshaft bearing caps.




Fig. 5-239

WM 0202 '9

28. Removal of crankshaft bearing (lower).

Remove the connecting rod bearing, as follows: Push the connecting rod bearing at the side without the turning-preventive tang by your finger so that the opposite end may float. Thus, take out the bearing. Do not touch the front surface or the back surface of the bearing by your finger during the removal.

### NOTE

Arrange the removed bearings in order so that their installation positions may be known readily.




Fig. 5-240

WM 0202 '9

29. Removal of crankshaft.

Remove the crankshaft by lifting it vertically so that no scratch may be made to the crankshaft journals and the crankshaft may not interfere with the cylinder block.




Fig. 5-241

WM 0202 '9

30. Remove the thrust washers.

The thrust washers are provided at both sides of the bearing No. 3.




Fig. 5-242

WM 0202 '9

31. Removal of crankshaft bearing (lower).

Remove the connecting rod bearing, as follows: Push the connecting rod bearing at the side without the turning-preventive tang by your finger so that the opposite end may float. Thus, take out the bearing. Do not touch the front surface or the back surface of the bearing by your finger during the removal.

### NOTE:

- ① Arrange the removed bearings in order so that their installation positions may be known readily.
- ② Clean the disassembled parts with a cleaning solvent. Blow them by compressed air. This note does not apply to the rubber parts.



Fig. 5-243

WM 0202 '9

Remove the cylinder block from the SST.

WV-05234

**INSPECTION**

1. Cracking of cylinder block
  - (1) Check the cylinder block for damage or cracks.
  - (2) Check the cylinder head gasket surface for distortion.

**NOTE:**

Perform the measurement in six directions.

Maximum distortion limit: 0.1 mm (0.0039 inch)

**[CB-23 engine only]**

If the distortion exceeds the maximum distortion limit, recondition the surface. However, this reconditioning should not be performed beyond the grinding limit of 0.3 mm (0.012 inch).

Furthermore, make sure that the width between the cylinder head gasket contact surface and the oil pan attaching surface is at least 200.55 mm (7.896 inches).

- (3) Measure the cylinder bore diameters
 

Measure the bore diameter of each cylinder. The measurement should be made at six points.

- ① Ensure that the difference between the maximum and minimum bore diameters of each cylinder is within 0.1 mm (0.039 inch).

**NOTE:**

The measurement results should be recorded.

- ② If the difference between the maximum and minimum values exceeds the specified value (0.1 mm or 0.039 inch), perform boring and honing for the cylinder.

**Specified cylinder bore diameter after honing**

When repair standard piston is used	76.00 - 76.03 mm (2.992 - 2.993 inches)
When O/S 0.25 pistons are used	76.25 - 76.28 mm (3.002 - 3.003 inches)
When O/S 0.50 pistons are used	76.50 - 76.53 mm (3.012 - 3.013 inches)




Fig. 5-244

WM-3E285




Fig. 5-245

WV-05236




Fig. 5-246

WV-05237




Fig. 5-247

WV-05238

## ENGINE MECHANICALS

- ③ After the cylinder block has been cleaned and checked, calculate the cylinder-to-piston clearance. At this calculation, use the minimum measurement value as the cylinder bore diameter of each cylinder.

Cylinder-to-piston clearance:

0.03 - 0.12 mm (0.0012 - 0.0047 inch)

### NOTE:

If the calculated clearance exceeds the specified value, perform boring and honing, referring to the specifications in ②. However, if the oversize pistons have been installed and the cylinder-to-piston clearance has exceeded the specified value, replace the cylinder block and pistons.

## 2. Checking of piston and piston rings

- (1) Remove the piston rings No.1 and No.2, using a commercially-available piston ring expander or the like.

### NOTE:

- ① Arrange the removed piston rings in order so that their installation positions may be known readily.
- ② Do not expand the piston ring unnecessarily beyond the required extent.

- (2) Remove the oil ring by hand.

### NOTE:

- ① Arrange the removed oil rings in order so that their installation positions may be known readily.
- ② Do not expand the oil ring unnecessarily beyond the required extent.
- (3) Disassemble the piston pin from the piston, using the following SST.

SST: 09221-25018-000

- ① Assemble the spring to the main body of the SST.
- ② Attach the smaller bar on the spring. While pushing the lever into the body, install the fitting piece to the main body with the surface having a cut-out section facing upward. Then, secure it with the attaching screw.
- ③ Place the piston on the fitting piece, aligning the cut-out sections.
- ④ Install the longer lever into the piston hole.
- ⑤ Press off the piston pin, using a press.

### NOTE:

Arrange the disassembled pistons and piston pins in order so that their installation positions may be known readily.




Fig. 5-248

GM-6293




Fig. 5-249

GM-6293




Fig. 5-250

GM-6292

(4) Cleaning of pistons

- ① Remove the carbon deposits from the piston top, using a gasket scraper or the like.
- ② Clean the piston ring groove with a broken piston ring or a groove cleaning tool.
- ③ Clean the piston with a soft brush and a cleaning solvent.

NOTE:

Be very careful not to scratch the piston.




Fig. 5-251

WZK11097

(5) Check the pistons for cracks, damage or seizure

(6) Checking piston ring side clearance

Check the piston ring side clearance over the entire periphery of each groove using a feeler gauge or a thickness gauge.

The maximum value in the measurement is regarded as the side clearance.




Fig. 5-252

WZK11097

Side clearance mm (inch)

	CB-23 & CB-61 engines	CB-80 engine
Compression ring No.1	0.03 - 0.12 (0.0012 - 0.0047)	0.05 - 0.12 (0.0002 - 0.0047)
Compression ring No.2	0.02 - 0.12 (0.0008 - 0.0047)	0.02 - 0.12 (0.0008 - 0.0047)

If the measured side clearance exceeds the specified value, measure the piston ring thickness with a micrometer. To make the side clearance meet the specifications, replace the piston ring of the piston, or both of them, referring to the piston ring standard thicknesses given below.

Piston ring standard thickness mm (inch)

	CB-23 & CB-61 engines	CB-80 engine
Compression ring No.1	1.47 (0.058)	1.47 (0.058)
Compression ring No.2		

WZK11097

(7) Check the oil ring for damage

NOTE:

If any of the ring No.1, ring No.2 and oil ring is defective, replace all of them as a set for one cylinder.

WZK11097

## ENGINE MECHANICALS

### (8) Measuring outer diameter of piston

Measure the outer diameter of the piston at the specified measuring point from the lower end of the piston.

#### Measuring points of piston outer diameter (mm (inch))

	Measuring point
CB-23 & CB-61 engines	15 (0.6) from lower end
CB-80 engine	10 (0.4) from lower end




Fig. 5-253

AW-05297

#### NOTE:

The measurement results should be recorded.

(The measurement results become necessary when the cylinder-to-piston clearance is calculated.)

### (9) Checking piston pin oil clearance

- ① Measure the diameter of the piston pin hole.
  - ② Measure the outer diameter of the piston pin.
  - ③ Measure the piston-to-piston pin oil clearance.
- Allowable limit: 0.03 mm (0.0018 inch)

#### NOTE:

If the oil clearance exceeds the specified value, replace the piston and piston pin as a set.




Fig. 5-254

AW-05298

### (10) Checking piston ring end gap

After the cylinder has been checked or reconditioned, insert the piston ring into the cylinder bore down to a point about 110 mm (4.3 inches) measured from the cylinder head gasket attaching surface. Then measure the piston ring end gap.

#### NOTE:

Apply engine oil to the piston ring before inserting it.

#### End gap

[CB-23 & CB-61 engines]

Compression ring No.1

0.20 - 0.70 mm (0.079 - 0.028 inch)

Compression ring No.2

0.20 - 0.70 mm (0.079 - 0.028 inch)

Oil ring 0.20 - 1.10 mm (0.079 - 0.043 inch)

[CB-80 engine]

Compression ring No.1

0.35 - 0.70 mm (0.014 - 0.028 inch)

Compression ring No.2

0.28 - 0.70 mm (0.011 - 0.028 inch)

Oil ring 0.20 - 1.10 mm (0.008 - 0.043 inch)

If the end gap exceeds the specified limit, replace piston ring as a set.




Fig. 5-255

AW-05299



Checking connecting rod

- (1) Check the connecting rod for damage or cracks.
- (2) Check the connecting rod for bend or twist.  
 Maximum bend limit: 0.05 mm (0.0020 inch)  
 Maximum twist limit: 0.05 mm (0.0020 inch)




Fig. 5-256

WM 02501

- (3) Measure the oil clearance at the big end
- ① Install the bearing to the connecting rod and bearing cap




Fig. 5-257

WM 02501

- ② Install the plastigage on the crankpin journal. Tighten the bearing cap to the specified torque

**Tightening Torque:**

kg-m (ft-lb)

CB-23 & CB-61 engines	2.5 ± 0.4 (18 ± 3)
CB-80 engine	4.7 ± 0.5 (34 ± 7)




Fig. 5-258

WM 02502

- ③ Remove the bearing cap. Measure the oil clearance.  
**Oil clearance**  
 [CB-23 & CB-61 engines]  
 0.020 - 0.070 mm (0.00079 - 0.00280 inch)  
 [CB-80 engine]  
 0.024 - 0.070 mm (0.00094 - 0.00280 inch)



Fig. 5-259

WM 02502

If the oil clearance exceeds the specified value, grind or replace the crankshaft so that the oil clearance may meet the specifications, referring to the dimensions of the crankpin journal given below.

Bearing size	Crankpin journal diameter		
	Engine type		
	CB-23	CB-61	CB-80
Repair standard	39.956 - 39.992 (1.573 - 1.574)	39.958 - 39.992 (1.573 - 1.574)	42.962 - 42.992 (1.691 - 1.692)
U/S 0.25	39.734 - 39.742 (1.564 - 1.565)	—	42.738 - 42.747 (1.682 - 1.683)
U/S 0.50	39.484 - 39.492 (1.554 - 1.555)	—	42.488 - 42.492 (1.672 - 1.673)

**NOTE:**

- ① When grinding the crankpin journal, finish each crankpin journal should be finished so that its radius at the corner becomes 0.25 mm.
- ② On Type CB-61 engine, no undersize bearing is available.

(MM) (IN)

- ④ Checking connecting rod thrust clearance  
Measure the thrust clearance between the connecting rod and the crankshaft, using a thickness gauge.

**Thrust clearance**
**[CB-23 Engine]**

0.15 - 0.38 mm (0.0059 - 0.0150 inch)

**[CB-61 Engine]**

0.15 - 0.38 mm (0.0059 - 0.0150 inch)

**[CB-80 Engine]**

0.15 - 0.45 mm (0.0059 - 0.0177 inch)




Fig. 5-260

(MM) (IN)

**NOTE:**


The thrust clearance should be measured while the connecting rod being pushed against either side of the crankshaft in the axial direction. Measure the clearance at the opposite side.

- ⑤ If the clearance exceeds the specified value, replace the connecting rod or the crankshaft, or both of them, referring to the width of the big end of the connecting rod in the thrust direction and the side width of the crankpin journal.

mm (inch)

	Width of big end of connecting rod in thrust direction	Side width of crankpin
CB-23	21.80 - 21.85 (0.858 - 0.860)	22.00 - 22.13 (0.866 - 0.871)
CB-61	21.80 - 21.85 (0.858 - 0.860)	22.00 - 22.13 (0.866 - 0.871)
CB-80	24.80 - 24.85 (0.976 - 0.978)	25.0 - 25.2 (0.984 - 0.992)

Reference



WVCE306

4. Checking of crankshaft:

(1) Checking crankshaft for runout

① Measure the crankshaft runout at the main bearing journal No.3.

Maximum runout limit: 0.05 mm (0.0024 inch)

NOTE:

Be very careful not to scratch the crankshaft journals.

(2) Checking crankshaft for wear

Check the crankshaft main bearing journals and crankpin journals for evidence of seizure or scratches.

(3) Checking crankshaft main bearing journals and crankpin journals

Measure the outer diameter at four points of each of the main bearing journals and crankpin journals. This measurement should be conducted over the entire periphery of each journal, avoiding the oil holes provided on the journals.

Calculate the difference between the maximum value and minimum value for each measurement of the main bearing journals and crankpin journals

Out-of-roundness and taper limit:  
0.01 mm (0.0004 inch)

NOTE:

① The measurement results should be recorded.

② Be careful not to scratch the crankshaft.




Fig. 5-261

WVCE307




Fig. 5-262

WVCE308

## ENGINE MECHANICALS

(2) Checking main bearing journal oil clearance

- ① Install the bearings in the cylinder block and main bearing caps. Do not touch the front surface or the back surface of the bearings and also the bearing installation surfaces of the cylinder block and bearing cap during the check.

NOTE:

Care must be exercised not to mistake the installation position of the upper bearing for that of the lower bearing.

Upper bearing (cylinder block side) .... A groove is provided.

Lower bearing (bearing cap side) ..... No groove is provided.

41102519

② Install the crankshaft in the cylinder block.

NOTE:

- ① Be careful not to scratch the crankshaft and bearing.
- ② Do not apply engine oil to the crankshaft and bearings.




Fig. 5-263

41102519

③ Install the plastigage

④ Tighten the bearing cap to the specified torque.

### Tightening Torque:

kg-m (7-1b)

CB-25 & CB-21 engines	5.4 - 6.5 (10 - 16)
CB-30 engine	6.4 - 7.6 (16 - 55)




Fig. 5-264

41102519

⑤ Remove the bearing cap. Take the reading of the oil clearance.

Main bearing journal oil clearance:

0.020 - 0.070 mm (0.0008 - 0.0028 inch)




Fig. 5-265

41102519

- ⑥ If the oil clearance exceeds the specified value, grind or replace the crankshaft so that the oil clearance may meet the specifications, referring to the diameters of the main bearing journals given below.

mm (inch)

Bearing size	Main bearing journal diameter		
	Engine type		
	CB-23	CB-61	CB-80
Repair standard	47.958 - 47.992 (1.852 - 1.853)	47.958 - 47.992 (1.852 - 1.853)	47.962 - 47.992 (1.888 - 1.889)
U.S. 0.25	47.724 - 47.742 (1.6420 - 1.6431)	—	—
U.S. 0.50	47.484 - 47.492 (1.633 - 1.634)	—	—

NOTE:

- ① When grinding the main bearing journal, finish each main bearing journal so that its radius at the corner becomes 0.25 mm. (CB-23 engine only)
- ② On Type CB-61 and CB-80 engines, no undersize bearing is available.

WM-0210

(5) Checking crankshaft thrust clearance

- ① Install the bearings in the cylinder block and main bearing caps. Do not touch the front surface or the back surface of the bearings and also the bearing installation surfaces of the cylinder block and bearing cap during the check.




Fig. 5-266

WM-0210

- ② Install the thrust washers in the cylinder block.

NOTE:

Do not apply oil to the thrust washers.

- ③ Place the crank shaft to the cylinder block.




Fig. 5-267

WM-0210

- ④ Measure the thrust clearance using a dial gauge.

Thrust Clearance:

0.02 - 0.30 mm (0.00079 - 0.01180 inch)

NOTE:

The measurement results should be recorded.




Fig. 5-268

WM-0210

## ENGINE MECHANICALS

- ⑤ Remove the parts which have been assembled to the cylinder block.
- ⑥ If the thrust clearance exceeds the specified value, determine which thrust washers should be used or whether the crankshaft should be replaced, based on the following calculation.

Measured thrust clearance: A

Sum of thicknesses of thrust washers at right and left sides: B

Specified thrust clearance: C

Required thrust washer thickness: D

$$\{(A - B) - C\} \pm 2 = D$$

Based on the thus-calculated value D, select a suitable thrust washer from among those in the table below.

Thrust washer size	Thrust washer thickness	Remarks
Standard	1.940 - 1.990 (0.0764 - 0.0783)	To be used when the maximum value of D is 1.990 or less.
O/S 0.125	2.065 - 2.115 (0.0813 - 0.0833)	To be used when the maximum value of D exceeds 1.990.
O/S 0.25	2.190 - 2.240 (0.0862 - 0.0882)	To be used when maximum value of D exceeds 2.115.

VM-CSE-5

### [Example]

Measured thrust clearance: A = 0.53 mm

Sum of thicknesses of thrust washers at right and left sides: B = 3.80 mm

Specified thrust clearance: C = 0.02 to 0.30

Required thrust washer thickness: D = ?

$$D = \{(0.53 + 3.80) - C\} \pm 2$$

$$= 2.015 \text{ to } 2.115$$

In this case, use a O/S 0.125 mm thrust washer.

However, if the minimum value of D exceeds 2.240 mm (0.0882 inch), replace the crankshaft and thrust washer in a set.

### [Reference]

Such determination can also be made by measuring the width of the thrust bearing contact surface of the crankshaft.

mm (inch)

	Measurement value ②
Standard	23.000 - 23.130 (0.905 - 0.911)
O/S 0.125	23.125 - 23.255 (0.910 - 0.916)
O/S 0.25	23.25 - 23.38 (0.915 - 0.920)
Replace crankshaft.	23.38 (0.920) or more




Fig. 5-269

VM-CSE-7




Fig. 5-270

VM-CSE-9

Checking of balance shaft and gear

(1) Check the balance shaft and gear for damage, abnormal wear, cracks or seizure.

NOTE:

As for the disassembling procedure for the balance shaft and gear, see the sections (2) - (5) onward.




Fig. 5-271

WV-0522

(2) Checking thrust clearance

(1) Attach the balance shaft to the cylinder block. Tighten the hexagon socket head cap bolt, using a hexagon wrench key (5 mm)

Tightening Torque: 1.25 ± 0.25 kg-m (9 ± 1.8 ft-lb)

NOTE:

Be sure to apply oil to the balance shaft bearing section.




Fig. 5-272

WV-0522

(2) With a dial gauge attached at the forward end of the balance shaft at the balance shaft gear side, measure the thrust clearance of the balance shaft.

Thrust clearance:

0.03 - 0.20 mm (0.0012 - 0.0079 inch)

(3) If the thrust clearance exceeds the specified value, replace the thrust washer with a new one. Then, measure the thrust clearance again.

Thrust clearance:

0.03 - 0.20 mm (0.0012 - 0.0079 inch)




Fig. 5-273

WV-0523

NOTE:

As for the disassembling procedure for the balance gear and balance shaft, see section (5) onward.

(4) If the thrust clearance still exceeds the specified value even after the new thrust washer has been assembled, replace the balance shaft with a new one.

NOTE:

As for the disassembling procedure for the balance gear and balance shaft, see section (5) onward.

WV-0524

## ENGINE MECHANICALS

- ⑤ Disassembling balance shaft and balance shaft gear  
Remove the balance shaft gear from the balance shaft, using the following SSTs.

SST: 09214-87701-000  
09253-87202-000




Fig. 5-274

WMI-0028

- ⑥ Assembling balance shaft and balance shaft gear  
Attach the thrust plate to the balance shaft. Press the balance shaft gear into position, using a press in combination with the following SSTs.

SST: 09214-87701-000  
09253-87201-000  
09506-87303-000




Fig. 5-275

WMI-0028

(3) Checking balance shaft for oil clearance

- ① Measure the outer diameters of the front and rear bearing journals of the balance shaft.

The measurement should be performed at the mid-point of each of the front and rear journals, in the two directions, 90 degrees apart from each other. The maximum value in the measurement is regarded as the outer diameter.



Fig. 5-276

WMI-0028

- ② Measure the inner diameters of the bearing bores of the balance shaft.

The measurement should be performed at the mid-point of each of the front and rear bearing bores, in the two directions, 90 degrees apart from each other. The maximum value in the measurement is regarded as the inner diameter.



Fig. 5-277

WMI-0028



- ③ Calculate the oil clearance.  
Oil clearance: 0.25 - 0.1 mm (0.0098 - 0.0039 inch)
- ④ If the oil clearance exceeds the specified value, replace the balance shaft bearing and/or grind or replace the balance shaft so that the oil clearance may meet the specifications, referring to the diameters of the balance shaft bearing given below.

**Balance shaft bearing sets**

mm (inch)

Balance shaft bearing	Balance shaft bearing inner diameter:	
	Front	Rear
Repair standard	44.925 - 44.975 (1.769 - 1.771)	33.925 - 33.975 (1.336 - 1.338)
US 0.5	44.425 - 44.475 (1.749 - 1.751)	33.425 - 33.475 (1.316 - 1.318)

WJ-05-09

- ⑤ Pull out the balance shaft bearing, using the following SST.  
SST: 09215-87701-000




Fig. 5-278

WJ-05-09

- ⑥ Install the balance shaft bearing, using the following SST.  
SST: 09215-87701-000




Fig. 5-279

WJ-05-09

**NOTE:**

- ① Be sure to install the bearing in the correct direction. Also, align the oil hole of the cylinder block with that of the bearing during the installation.
- ② After the bearing has been pressed into position, make sure that no burr or the like exists at the bearing bore. If the bearing exhibits any burr or the like, remove such harmful burrs, using an adjustable reamer.



Fig. 5-280

WJ-05-02

## ENGINE MECHANICALS

### 6. Checking of crankshaft balance shaft drive gear

(1) Check the crankshaft balance shaft drive gear for damage or wear. Replace it, as required

WM-05333

(2) Remove the crankshaft balance shaft drive gear from the crankshaft, using the following SST.

SST: 09253-87202-000




Fig. 5-281

WM-05334

(3) Install the crankshaft balance shaft drive gear to the crankshaft, using the following SSTs

SST: 09506-87303-000

09253-87202-000




Fig. 5-282

WM-05335

#### NOTE:

Make sure that the key groove at the crankshaft side and the woodruff key exhibit no damage. The assembling should be made by aligning the woodruff key at the crankshaft with the key groove of the crankshaft balance shaft drive gear.

### 7. Checking of flywheel

(1) Checking flywheel for runout

① Tighten the flywheel to the specified torque.

Tightening Torque	kg-m (ft-lb)
CB-23 & CB-61 engines	4.0 - 5.0 (29 - 36)
CB-80 engine	6.0 - 7.0 (43 - 51)

#### NOTE:

Prior to the check, be sure that the crankshaft bearings have been tightened to the specified torque.

② Check the flywheel for runout with a dial gauge.

Runout limit of flywheel: 0.1 mm (0.0039 inch)

If the measured runout exceeds the limit, replace the flywheel.

(2) Ensure that the ring gear and clutch disc contact surface exhibit no wear or damage

WM-05336

### 8. Checking of other parts

(1) Check the other parts for damage or cracks, etc. Replace the parts, as required.

(2) As for the oil pump check, see the section under "Unit Inspection" (page 7-3 to 7-5)

(3) As for the water pump check, see the section under "Unit Inspection"

WM-05

## STALLATION

### CAUTION

1. Clean all parts thoroughly.
2. Apply new engine oil to the sliding and rotating parts before assembling.
3. Replace all gaskets and "O" rings.
4. Use liquid packing as required to prevent water leakage and oil leakage.
5. Use the proper attaching bolts, nuts and washers. Tighten the nuts and bolts to the specified torque. Be very careful not to overtighten the studs installed to aluminum alloy parts.
6. When marks have been put during the disassembly, perform the reassembly in accordance with these marks. Confirm that the pistons and other parts are assembled correctly, meeting the specified clearance.

WM-09132

1. Install the cylinder block to the following SSTs.

SSTs: 09219-87202-000

09219-87701-000

2. Installation of crankshaft upper bearings

(1) Install the crankshaft upper bearings to the bearing sections of the cylinder block. Do not touch the front surface or back surface of the bearing and also the bearing installation surfaces of the cylinder block during the installation.

(2) Apply engine oil to the surfaces of the installed bearings.

#### NOTE:

Wipe off any oil on the back surface of each crankshaft bearing.

3. Assembly of crankshaft

Apply engine oil to the crankshaft main bearing journals. Then, assemble the crankshaft in the cylinder block.

#### NOTE:

Be very careful not to scratch each of the crankshaft journals during the assembly.




Fig. 5-283

WM-06375




Fig. 5-284

WM-05340




Fig. 5-285

WM-05341

## ENGINE MECHANICALS

### 4. Assembly of thrust washers

Apply engine oil to the thrust washers. With the side having the oil groove facing toward the crankshaft, insert each washer between the cylinder block and the crankshaft.

#### NOTE:

The insertion position is the crankshaft main bearing journal No.3 at the upper side.

WM-05142

### 5. Installation of crankshaft lower bearings and crankshaft bearing caps

(1) Assemble the crankshaft lower bearing to each crankshaft bearing cap

(2) Liberally apply engine oil to each bearing surface. Then, install the bearing caps in the cylinder block.

#### NOTE:

- ① Be careful not to scratch each journal of the crankshaft.
- ② Install the bearing caps in such a way that the arrow mark provided on each bearing cap faces toward the front side of the engine.

(3) Tighten the crankshaft bearing caps to the specified torque in the sequence indicated in the right figure

#### NOTE:

- ① After the bearing caps have been tightened temporarily, make sure that the crankshaft can be turned lightly. Then, each time the bearing cap is further tightened, make sure that the crankshaft still can be turned lightly.
- ② On Type CB-80 engine, the bracket oil nozzle No.1 and No.2 are tightened in common at the bearing caps No.1 and No.3.

#### Temporal Tightening Torque

kg-m (ft-lb)

CB-23 & CB-61 engines	2.5 - 3.5 (18 - 25)
CB-80 engine	5.0 - 5.5 (36 - 40)

#### Final Tightening Torque

kg-m (ft-lb)

CB-23 & CB-61 engines	5.4 - 6.6 (39 - 48)
CB-80 engine	6.4 - 7.6 (46 - 55)




Fig. 5-285

WM-053-13




Fig. 5-287

WM-053-14




Fig. 5-288

WM-053-15

Install the balance shaft rear cover gasket.

**NOTE:**

The gasket is a nonreusable part.

7. Install the balance shaft rear cover.

WM-05348

8. Install the oil seal retainer gasket.

**NOTE:**

The gasket is a nonreusable part.

9. Installation of oil seal retainer with oil seal

- (1) Drive a new oil seal into position, using the following SST.

SST: 09515-87301-000

- (2) Apply engine oil to the rear oil seal contact section of the crankshaft and the lip section of the oil seal. Then, install the oil seal retainer in the cylinder block.




Fig. 5-289

WM-CE1-7




Fig. 5-290

WM-CE1-8

10. Install the rear end plate.

Installation of flywheel

- (1) Attach the flywheel to the crankshaft rear end.

- (2) Tighten the bolts evenly over about two stages in the sequence indicated in the right figure.

**Tightening Torque**

kg-m (ft-lb)

CB-23 & CB-6 <sup>+</sup> engines	4.0 - 5.0 (29 - 36)
CB-80 engine	6.0 - 7.0 (43 - 51)




Fig. 5-291

WM-CE1-9

## ENGINE MECHANICALS

### 12. Assembly of connecting rod with lower bearing and piston

- (1) Assemble the connecting rod and piston, using the following SST.

SST: 09221-25018-000

WM-02350

- ① Insert the spring into the main body
- ② Insert the larger bar into the main body
- ③ Install the fitting piece to the main body, with the side having a cut-out section facing upward
- ④ Install the piston on the main body, aligning with the cut-out section of the fitting piece

**NOTE:**

Apply engine oil to the piston pin hole.

- ⑤ Insert the piston pin into the piston pin hole.

**NOTE:**

Apply engine oil to the piston pin.

- ⑥ Insert the smaller bar into the piston pin.
- ⑦ Insert the small end of the connecting rod into the piston pin hole.

**NOTE:**

Align the front mark of the piston with the front mark of the connecting rod.

- ⑧ Press the piston pin by pressing the smaller bar mounted on the piston pin.




Fig. 5-292

WM-02351




Fig. 5-293

WM-02352

### (2) Assembling oil ring in piston

- ① Fit the expander spacer to the oil ring groove

**NOTE:**

Install the expander spacer in such a way that spacer ends may not coincide with the front mark.




Fig. 5-294

WM-02353

- ② Assemble the upper rail

**NOTE:**

- Be careful not to scratch the piston by the end of the rail.
- Set the rail in such a way that the ends of the rail are deviated to the left 90 degrees from that of the expander spacer.




Fig. 5-295

WM-02354

③ Assemble the lower rail

**NOTE:**

- Utmost care must be exercised not to scratch the piston by the end of the rail.
- Set the rail in such a way that the ends of the rail are deviated to the right 90 degrees from that of the expander spacer.




Fig. 5-296

MM-0323

(3) Assemble the compression rings No.1 and No.2 in such a way that each end of the compression rings is 120 degrees apart from the end of the expander spacer of the oil ring in opposite directions from each other. In this way, make sure that no ends come in the same angle on the circumference of the piston.

**NOTE:**

Utmost care must be exercised not to scratch the piston by the end of the ring.




Fig. 5-297

MM-0326

(4) Install the connecting rod upper bearing. Do not touch the upper bearing installation surface of the connecting rod and also the front surface or the back surface of the upper bearing during the installation.




Fig. 5-298

MM-0327

(5) Apply engine oil to the side wall of the piston, piston rings and piston pin.

**NOTE:**

Make sure that the ends of each ring does not move during this operation.

(6) Apply engine oil to the cylinder wall, surface of the connecting rod upper bearing and crankpin journal.

MM-0328

(7) Compress the piston rings, using a piston ring compressor. Then, assemble the piston into the cylinder bore.

SST: 09217-87701-000

**NOTE:**

- ① Be sure to install the piston in the correct direction, referring to the position of the front mark.
- ② Make sure that the ends of each ring does not move during the installation.
- ③ Care must be exercised to ensure that the crankshaft journal is not scratched by the connecting rod.




Fig. 5-299

MM-0331

## ENGINE MECHANICALS

### 13. Assembling connecting rod bearing cap with lower bearing

(1) Install the connecting rod lower bearing to the connecting rod bearing cap. Do not touch the lower bearing installation surface of the connecting rod bearing cap and also the front surface or the back surface of the lower bearing during the assembly.

(2) Apply engine oil to the bearing surface.

(3) Install the connecting rod bearing cap with the front mark facing toward the front side of the engine.

#### Tightening Torque

kg-m (ft-lb)

CB-23 & CB-61 engines	2.1 - 2.9 (1.5 - 2.1)
CB-8U engine	4.2 - 5.2 (30 - 38)

#### NOTE:

① When tightening the connecting rod bearing cap, use the following SST to prevent the crankshaft from turning.

SST: 09210-87701-000




Fig. 5-300

WM-05302




Fig. 5-301

WM-05301




Fig. 5-302

WM-05302

### 14. Assembling Balance Shaft

(1) Apply engine oil to the balance shaft bearing of the cylinder block

(2) Apply engine oil to the balance shaft bearing journals and thrust washer sections.




Fig. 5-303

WM-05303



- (3) Turn the crankshaft until the stamped mark of the balance shaft drive gear of the crankshaft is aligned with the stamped mark of the balance shaft gear. Then, insert the balance shaft into position.

**NOTE:**

When the balance shaft is inserted, be careful not to damage the balance shaft bearing.

- (4) Install the thrust washer to the cylinder block by tightening the hexagon bolts.

**NOTE:**

Use a hexagon wrench key whose width across flats is 5 mm.

15. Install the oil pump drive sprocket to the balance shaft.

16. Install the balance weight to the balance shaft. Insert the washer and tighten the bolt.

**NOTE:**

When tightening the bolt, prevent the crankshaft from turning, using the following SST at the flywheel side.

SST: 09210-87701-000

17. Installation of oil pump with oil pump outlet pipe

- (1) Replace the "O" ring of the oil pump outlet pipe with a new one. Insert the oil pump outlet pipe into the oil pump, being careful not to damage the "O" ring.
- (2) Mount the oil pump with the oil pump outlet pipe on the cylinder block.
- (3) Insert the oil pump outlet pipe into the cylinder block, being careful not to damage the "O" ring.
- (4) Install the bolts to each bolt hole temporarily.




Fig. 5-304

AW-03363




Fig. 5-305

AW-03363



Fig. 5-306

AW-03363




Fig. 5-307

AW-03363




Fig. 5-308

AW-03363

## ENGINE MECHANICALS

- (5) Tighten the attaching bolts of the oil pump outlet pipe. Ensure that no excessive force is applied to the connecting section with the oil pump.
- (6) Tighten the attaching bolts of the oil pump  
Tightening Torque: 1.5 - 2.2 kg-m (11 - 16 ft-lb)




Fig. 5-309

AM-05373

18. Install the oil nozzle. (CB-80 engine only)  
Tightening Torque: 3.0 - 3.5 kg-m (22 - 25 ft-lb)

### NOTE:

The oil jet can be distorted very easily. Hence, be very careful in handling the oil nozzle assembly so that the assembly may not be damaged.




Fig. 5-310

AM-05374

19. Installation of oil pump drive sprocket and oil pump drive chain assembly

- (1) Install the oil pump drive chain to the oil pump sprocket at the balance shaft side.
- (2) With the side having the stamped mark "CB OUTSIDE" facing toward the front side of the engine, install the oil pump drive sprocket to the oil pump with the drive chain installed in place. Then, tighten the attaching nut.




Fig. 5-311

AM-05375

20. Installation of balance shaft gear cover.

- (1) Drive a new oil seal into position, using the following SST.  
SST: 09515-87202-000




Fig. 5-312

AM-05376

- (2) Install the balance shaft gear cover.  
 Tightening Torque: 1.0 - 1.6 kg·m (7.2 - 11.5 ft·lb)




Fig. 5-313

474-051.6

21 Installation of oil pan

- (1) Apply silicon bond to the cylinder block at the points indicated in the right figure.  
 Sealer to be Used: Silicon Bond




Fig. 5-314

474-051.7

- (2) Apply Silicon Bond to the new oil pan gasket at the points indicated in the right figure.  
 Sealer to be Used: Silicon Bond




Fig. 5-315

474-051.7

- (3) Install the oil pan gasket applied with silicon bond to the cylinder block, aligning with the stud bolts at the cylinder block.  
 (4) Install the oil pan, aligning with the stud bolts at the cylinder block.  
 (5) Tighten the oil pan bolts and nuts in the sequence indicated in the right figure.  
 Tightening Torque: 0.4 - 0.7 kg·m (2.9 - 5.1 ft·lb)




Fig. 5-316

474-051.7

NOTE:

The numerals in ( ) in the right figure denote the sequence of the temporal tightening for the stud bolts.

22 Installation of dust seal (lower)

- (1) Unlock the SST. Turn over the cylinder block.  
 (2) Install the dust seal on the balance shaft gear cover.




Fig. 5-317

474-051.7

## ENGINE MECHANICALS

23. Install the water pump assembly.

24. Install the dust seal (upper).

**NOTE:**

Be certain that the dust seal is installed in the specified position.

25. Install the water inlet with a new gasket interposed.

26. Installation of water inlet pipe

(1) Replace the "O" ring of the water inlet pipe with a new one.

(2) Insert the water inlet pipe into the water inlet.

(3) Tighten the attaching bolts of the water inlet pipe.

27. Install the oil filter bracket.

28. Install the oil cooler assembly, aligning the mating mark of the oil cooler assembly with the mating mark of the oil filter bracket.

Tightening Torque: 3.0 - 4.0 kg-m (22 - 29 ft-lb)

29. Install the oil cleaner element to the oil cooler.

**NOTE:**

Prior to the installation, coat the "O" ring of the oil element with a thin film of engine oil. The tightening must be performed by hands. Never use a tool for this purpose.

30. Install the alternator assembly to the cylinder block temporarily.




Fig. 5-318

99-0030




Fig. 5-319

99-0038




Fig. 5-320

99-0038

**DAIHATSU**  
**TYPE CB**  
**ENGINE**

[CB-23, CB-61 & CB-80]

**SECTION 6**  
**FUEL SYSTEM**

CARBURETOR .....	6- 2
FUEL LINE [CB-23 Engine] .....	6- 9
FUEL LINE [CB-61 Engine] .....	6-11
FUEL PUMP [CB-61 Engine] .....	6-13
FUEL PUMP [CB-80 Engine] .....	6-14
FUEL TANK .....	6-15

6A5-0001

# FUEL SYSTEM

## CARBURETOR

### COMPONENTS OF CARBURETOR [CB-23 & CB-61 Engines]




Fig. 5-1

WM-05002

ARBURETOR SCHEMATIC DIAGRAM [CB-23 Engine]




Fig. 6-2

W476002

# FUEL SYSTEM

## CARBURETOR SCHEMATIC DIAGRAM [CB-61 Engine]




Fig. 8-3

70A-06004



**SPECTION**

**NOTE:**

- (1) Before inspecting the parts, wash them thoroughly in gasoline.  
Using compressed air, blow all dirt and other foreign matter from the jets and similar parts, and from the fuel passages and apertures in the body.
- (2) Never clean the jets or orifices with wire or drill. This could enlarge the openings and result in excessive fuel consumption.

**Body**

- (1) Check the body for cracks. Check each hole for distortion.
- (2) Check the small venturi for restriction.
- (3) Check the large venturi for looseness or excessive wear.

**Air Horn**

- (1) Check the air horn for distortion or damage.
- (2) Check each passage of the air horn for restriction.
- (3) Check the choke valve for proper function.

**Floaf**

Check to see if any gasoline ingress is present. Also, check the lever pin hole for wear.

**Needle Valve and Seat**

Check for the contact surfaces.




Fig. 6-4

WM-59005




Fig. 6-5

WM-08206




Fig. 6-6

WM-08107




Fig. 6-7

WM-06324




Fig. 6-8

WM-08009

## FUEL SYSTEM

### Jets

Check the holes, threads and screw driver grooves for signs of damage.




Fig. 6-9

WM-06010

### Idle Adjusting Screw

Check the tapered section or threads for damage




Fig. 6-10

WM-06011

### Power Valve

Ensure that no leak is seen when your breath is blown through lower part.

Check for smooth operation




Fig. 6-11

WM-06012

### Solenoid Valve

Check the solenoid valve connecting wire to the battery positive (+) terminal for proper operation by grounding the body. The needle valve should be pulled in.




Fig. 6-12

WM-06013

### Diaphragm

Connect a hose to the diaphragm and suck the hose. The diaphragm should move. If not, replace the diaphragm.




Fig. 6-13

WM-06014

**Thermostatic Valve**

Lightly blow into the thermostatic valve through the (A) side. If there is no air continuity, it indicates a satisfactory operation.

**UNIT CHECK**

**NOTE:**

When the carburetor has been disassembled, be certain to install new seals and gaskets during the reassembly.

1. Float Level Check and Adjustment

(1) Detach the clip that has been attached on the needle valve. Reinstall the needle valve. Carry out the float level check and adjustment.

(2) Float ascent position check and adjustment

① Invert the air horn and allow the float to hang down by its own weight.

Measure the minimum gap between the projected section of the float and the air horn.

Specified Gap: 8.0 mm (0.315 inch)

② If the gap does not conform to the specification, bend the section A in order that the specified gap may be obtained.

When the float is at the ascent position, the minimum gap between the projected section of the float and the air horn should be measured as shown in the right figure.

When the float's right end is higher than the float's left end, the left end of the projected section will be measuring point. Conversely, when the float's right end is lower than the float's left end, the right end of the projected section will be measuring point. Adjustment is made by bending the section A.




Fig. 6-14 WMI-06213




Fig. 6-15 WMI-06216




Fig. 6-16 WMI-06217




Fig. 6-17 WMI-06218

## FUEL SYSTEM

### (3) Float descent position check and adjustment

- ① Raise the float and measure the tip clearance

**Specified Clearance:** 1.6 mm (0.063 inch)

- ② If the clearance does not conform to the specification, bend the section B in order that the specified clearance may be obtained




Fig. 6-18

WV-0603

### 2. Secondary diaphragm check (CB-61)

Disconnect the vacuum hose at the diaphragm side.

Connect the turbo charger pressure gauge and apply a positive pressure of 0.2 kg/cm<sup>2</sup> (2.9 psi). If the link moves, it indicates that the secondary diaphragm is functioning normally.




Fig. 6-19

WV-0602

### 3. Checking of jet operation

(1) With the white-colored (or orange-colored) port plugged, connect a MityVac to the orange-colored (or white-colored) port. Apply a negative pressure of 500 mmHg. If the pointer is steady, it indicates a normal operation.

(2) Replace the white-colored (or orange-colored) port. Measure the time required for the negative pressure to drop from 400 mmHg to 200 mmHg.

**Time Required for Dropping:** About one second





Fig. 6-20

WV-0601

FUEL LINE

COMPONENTS OF FUEL LINE [CB-23 Engine]



- ① Fuel filter
- ② Fuel hose (Filter to Pump)
- ③ Fuel hose (For return)
- ④ Fuel pump
- ⑤ Fuel hose (Pump to carburetor)
- ⑥ Hose
- ⑦ Push rod

Fig. 6-21

WM-06C34

## FUEL SYSTEM

### INSPECTION

1. Check the fuel pump for proper check valve operation.  
(1) Ensure that air continuity exists when blown from the section (A).

**NOTE:**

Never attempt to suck the section

2. Ensure that no air continuity exists when blown from the section (B).

**NOTE:**

Never attempt to suck the section.

3. Measure the overall length of the push rod.

**Length:**

STD 31.6 - 31.8 mm (1.244 - 1.252 inches)

Limit 31.1 mm (1.224 inches)

4. Check the fuel pump drive cam for wear.

- (1) Insert a good push rod into the distributor housing.
- (2) Turn the crankshaft two turns (i.e. turn the camshaft one turn). Measure the maximum amount as well as the minimum amount of protrusion between the distributor housing's edge and the tip-end the push rod.

- (3) If the amount of protrusion is less than limit, replace the fuel pump drive cam.

**Maximum amount of protrusion:**

STD 10.5 - 11.5 mm (0.4134 - 0.4528 inch)

Limit 10.0 mm (0.3937 inch)

**Minimum amount of protrusion:**

STD 8.5 - 9.5 mm (0.3346 - 0.3740 inch)

Limit 8.0 mm (0.3150 inch)

Stroke: 2.0 mm (0.0787 inch)




Fig. 6-22

vml-062125




Fig. 6-23

vml-062125




Fig. 6-24

vml-062125




Fig. 6-25

vml-062125





Fig. 6-26

vml-062125

COMPONENTS OF FUEL LINE [CB-61 Engine]



- ① Fuel filter
- ② Fuel pressure control valve
- ③ Fuel hose (Valve to carburetor)
- ④ Fuel hose (Valve to tank)
- ⑤ Fuel pipe No. 1
- ⑥ Fuel hose (Carburetor to filter)

Fig. 6-27

411-06304

## FUEL SYSTEM

### IN-VEHICLE INSPECTION [CB-61 Engine]

1. If any work related to the fuel system has been performed, it is mandatory to make sure that the fuel system exhibits no leakage under a condition where the fuel pressure is applied.
2. Remove the fuel tank cap so that the tank internal pressure may be released.
3. Disconnect the fuel hose connecting the fuel filter to the carburetor and the fuel hose connecting the carburetor to the pressure control valve. These fuel hoses should be disconnected at the carburetor side.

#### NOTE:

When the fuel hoses are disconnected, make certain that the engine is already cool. Also, be sure to plug the fuel hoses, using cloth or the like.

4. Connect a fuel pressure gauge.  
Fuel pressure gauge:  
SST: 09268-87701-000  
Fuel pressure gauge attachment:  
SST: 09263-87701-000
5. Disconnect the connector from the magnetic switch of the starter. (This step is taken to prevent the starter rotation.)
6. Turn the engine switch to the "ST" position.
7. Measure the fuel pressure under this setting.  
Specified Fuel Pressure:  
0.25 to 0.35 kg/cm<sup>2</sup> (3.6 to 5.0 psi)
8. Disconnect the vacuum hose between the pressure control valve and the 4-way joint. Then, connect the turbocharger pressure gauge.
9. Apply a positive pressure of 0.5 kg/cm<sup>2</sup> (7.1 psi) and measure the fuel pressure under this setting.  
Specified Fuel Pressure:  
0.75 to 0.85 kg/cm<sup>2</sup> (10.7 to 12.1 psi)

### EMERGENCY FUEL STOP SYSTEM

#### IN-VEHICLE INSPECTION [CB-61 Engine]

1. Start the engine.
2. Disconnect the noise filter connector for the tachometer. If the fuel pump stops its operation, it indicates that the emergency fuel stop system is functioning normally.




Fig. 6-28

WV-0803




Fig. 6-29

WV-0804




Fig. 6-30

WV-0804





Fig. 6-31

WV-0804



## JEL PUMP

## COMPONENTS OF FUEL LINE [CB-61 Engine]




- ① Fuel pump A<sub>y</sub>
- ② Cushion rubber
- ③ Fuel pump cover
- ④ Fuel pump filter
- ⑤ Gasket
- ⑥ Bracket S/A

Fig. 6-32

WM00046

# FUEL SYSTEM

## COMPONENTS OF FUEL LINE [CB-80 Engine]



- ① Fuel pump Ay
- ② Fuel pump gasket
- ③ Fuel pump cover
- ④ Cushion rubber
- ⑤ Bracket S/A

Fig. 6-33

2/11/00/27

## JEL TANK

### REMOVAL

- 1 Jack up the vehicle and support it with safety stands.
- 2 Drain the fuel from the fuel tank by removing the drain plug. (After the fuel tank has been drained, install the drain plug in the original position.)

3. Disconnection of connectors of fuel sender gauge and fuel pump
  - (1) Remove the rear seat.
  - (2) Detach the rear quarter trim at the right side. (3-door model.)
  - (3) Remove the rear scuff plate at the right/rear side. (5-door model.)
  - (4) Disconnect the connector. Take out the connector together with the grommet.




Fig. 6-34

AW-0609

- 4 Removal of fuel tank subinlet hose and breather hose

#### 3-door model

- (1) Detach the clamp. Disconnect the fuel tank subinlet hose.
- (2) Detach the clamp. Disconnect the breather hose.

#### 5-door model

- (1) Detach the clamp. Disconnect the fuel tank subinlet hose.
- (2) Remove the clip and hose at both sides of the breather hose.
- (3) Remove the attaching bolt of the breather pipe. Remove the breather pipe.




Fig. 6-35

AW-0609




Fig. 6-36

AW-0609

- 5 Removal of fuel hoses

- (1) Disconnect the main fuel hose.
- (2) Disconnect the return fuel hose.
- (3) Disconnect the fuel hose for emission control use.




Fig. 6-37

AW-0609




Fig. 6-38

WM 06052




Fig. 6-39

WM 06053

6. Removal of fuel tank assembly
  - (1) Support the fuel tank with a jack.
  - (2) Remove the four attaching bolts of the fuel tank.
  - (3) Take out the fuel tank assembly from the vehicle.




Fig. 6-40

WM 06054




Fig. 6-41

WM 06055

7. Remove the fuel hose and pipe.
8. Remove the coupler and five screws. Remove the fuel sender gauge assembly.
9. Remove the fuel pump assembly with bracket by removing the eight screws.




Fig. 6-42

WM 06056

**INSPECTION**

- 1 Check to see if the fuel pump filter exhibits restriction
- 2 Apply the battery voltage to the fuel pump. Check to see if the fuel pump functions smoothly

[Reference]

**Fuel pump specifications**

Item	Unit	CS-61	CB-80
Delivery output	l/h	Not less than 60	Not less than 60

WA-09-67

**INSTALLATION**

- 1 Install the fuel pump assembly with bracket and the fuel sender gauge assembly.
- 2 Install the fuel hose and pipe.
- 3 Install the fuel tank assembly with the four bolts.

**NOTE:**

Prior to the installation of the fuel tank assembly, be sure to route the fuel gauge-related harness through the inside.

- 4 Installation of fuel hoses
  - (1) Connect the main fuel hose
  - (2) Connect the return fuel hose
  - (3) Connect the fuel hose for emission control use




Fig. 6-43

WA-09-68




Fig. 6-44

WA-09-69




Fig. 6-45

WA-09-70

## FUEL SYSTEM

5. Install the fuel tank subinlet hose and breather hose.

### 3-door model

- (1) Connect the breather hose. Secure it with the clip.
- (2) Connect the fuel tank subinlet hose. Secure it with the clamp.




Fig. 6-46

AM-0005

### 5-door model

- (1) Connect the fuel tank subinlet hose. Secure it with the clamp.
- (2) Connect the hoses to both ends of the breather pipe. Secure them with the clips.
- (3) Install the breather pipe with one bolt.




Fig. 6-47

AM-0002

6. Installation of fuel sender gauge and fuel pump connectors

- (1) Connect the connectors and install the grommet.
- (2) Attach the rear quarter trim at the right side (3-door model)
- (3) Attach the scuff plate at the right/rear side. (5-door model.)
- (4) Install the rear seat




Fig. 6-48

AM-0003

**DAIHATSU**  
**TYPE CB**  
**ENGINE**

[CB-23, CB-61 & CB-80]

**SECTION 7**  
**LUBRICATION SYSTEM**

<b>OIL PUMP</b> .....	7-2
COMPONENTS OF OIL PUMP .....	7-2
INSPECTION .....	7-3
ASSEMBLY .....	7-4
<b>OIL COOLER</b> .....	7-7
COMPONENTS OF OIL COOLER (CB-61) .....	7-7
COMPONENTS OF OIL COOLER (CB-80) .....	7-8
INSTALLATION .....	7-9
INSPECTION .....	7-9

WM-07001

# LUBRICATION SYSTEM

## OIL PUMP

### COMPONENTS OF OIL PUMP




Fig. 7-1

WM-07002



**INSPECTION**

1. Oil pump drive shaft sprocket Check for cracks and damage




Fig. 7-2

WM-07004

2. Oil pump chain Check for damage.




Fig. 7-3

WM-07005

3. Measurement of shaft clearance

**Specified Clearance:** 0.045 - 0.085 mm  
(0.0018 - 0.0033 inch)  
**Limit:** 0.10 mm (0.0039 inch)




Fig. 7-4

WM-07006

4. Measurement of t.p. clearance

**Specified Clearance:** 0.15 mm (0.0059 inch) or less  
**Limit:** 0.25 mm (0.0098 inch)




Fig. 7-5

WM-07007

5. Side clearance

**Specified Clearance:** 0.03 - 0.09 mm  
(0.0012 - 0.0035 inch)  
**Limit:** 0.20 mm (0.0079 inch)




Fig. 7-6

WM-07008

## LUBRICATION SYSTEM

6. Body clearance  
Specified Clearance: 0.10 - 0.16 mm  
(0.0039 - 0.0063 inch)  
Limit: 0.30 mm (0.0118 inch)

7. Relief valve  
Check the oil passage and sliding surface for damage.

### ASSEMBLY

1. Assemble the relief valve in the numerical order shown in the figure.

2. Oil pump rotor set  
Assemble the rotor in such a way that the punched marks point toward the same direction (facing toward you).  
**NOTE.**  
Coat each sliding part with engine oil.

3. Oil pump cover and body  
Tightening Torque: 0.4 - 0.7 kg-m (2.9 - 5.1 ft-lb)




Fig. 7-7

WM-31039



Fig. 7-8

WM-31039




Fig. 7-9

WM-31039




Fig. 7-10

WM-31039




Fig. 7-11

WM-31039

Strainer

**NOTE:**

Replace the gasket with new one.

Tightening Torque: 0.4 - 0.7 kg-m (2.9 - 5.1 ft-lb)




Fig. 7-12

6M-173-4

**Oil Pump Operation Check**

5. After assembling, immerse the oil pump strainer into clean engine oil. Turn the sprocket counterclockwise. The oil should be discharged from the oil pump outlet pipe.




Fig. 7-13

6M-173-5

6. Block the outlet port with your finger and perform the same test. Ensure that the oil pump shaft becomes harder to turn until it cannot be turned any longer.




Fig. 7-14

6M-173-6

7. Attach the oil pump assembly onto the cylinder block. Install the oil pump outlet pipe subassembly.

**NOTE:**

Apply engine oil to the "O" ring sections provided at both ends of the oil pump outlet pipe subassembly.

9. Install the oil pump drive shaft sprocket.

10. Inspection

Check the deflection of oil pump chain. Measure the deflection when the center of the chain between the sprockets is pushed.

Deflection Limit: 7.0 mm (0.275 inch)




Fig. 7-15

6M-173-7

## LUBRICATION SYSTEM

- 11 Install the oil nozzle assembly. (CB-80 engine only)

**NOTE:**

The oil nozzle assembly can be distorted very easily. Hence, care must be exercised to ensure that the oil nozzle assembly is interferred with no other parts.

Tightening Torque: 3.0 - 3.5 kg-m (22 - 25 ft-lb)





Fig. 7-16

WUJ37018

## OIL COOLER

## COMPONENTS OF OIL COOLER [CB-61]



★: Non-reusable parts


- ① Oil filter element
- ② Oil cooler set bolt
- ③ Oil cooler hose
- ④ Oil cooler hose

- ⑤ Oil cooler
- ⑥ Oil filter bracket
- ⑦ Gasket

Fig. 7-17

# LUBRICATION SYSTEM

## COMPONENTS OF OIL COOLER [CB-80]



★: Non-reusable parts

- ① Oil filter element
- ② Oil cooler set bolt
- ③ Oil filter bracket
- ④ Oil cooler
- ⑤ Oil cooler hose
- ⑥ Turbo oil outlet pipe

- ⑦ Turbo oil inlet pipe
- ⑧ "O" ring
- ⑨ Oil filter bracket
- ⑩ "O" ring
- ⑪ Gasket
- ⑫ Gasket

Fig. 7-18

www.37020

**INSTALLATION****Oil Cooler Assembly**

- (1) Make sure that the oil filter bracket is fitted with the "O" ring.  
Install the oil cooler pin into the pin hole provided in the oil filter bracket.
- (2) Align the projected section of the oil filter bracket with the arrow-headed mark of the oil cooler.
- (3) Install the oil cooler set bolt.

Tightening Torque: 3.0 - 4.0 kg-m (22 - 29 ft-lb)

**NOTE:**

Inasmuch as the gap between the oil cooler and the set bolt is very narrow, difficulty may be encountered in installing the set bolt. In such case, the application of a small amount of engine oil to the set bolt may facilitate the installation of the said bolt.

**NOTE:**

Be sure to replace the gasket with a new one




Fig. 7-19

WM-37521

**INSPECTION**

After the oil filter and cooler have been installed, start the engine. Make sure that the oil filter and oil cooler exhibit no oil leakage or water leakage.

WM-37522





**DAIHATSU**  
**TYPE CB**  
**ENGINE**

[CB-23, CB-61 & CB-80]

**SECTION 8**  
**COOLING SYSTEM**

**8**

<b>RADIATOR</b> .....	8-2
IN-VEHICLE INSPECTION .....	8-2
<b>RADIATOR CAP</b> .....	8-2
INSPECTION .....	8-2
<b>THERMOSTAT</b> .....	8-3
INSPECTION .....	8-3
<b>RADIATOR THERMO CONTROL SWITCH</b> .....	8-4
IN-VEHICLE INSPECTION .....	8-4
UNIT INSPECTION .....	8-4
<b>WATER PUMP</b> .....	8-5
COMPONENTS OF WATER PUMP .....	8-5
DISASSEMBLY .....	8-5
INSPECTION .....	8-6
ASSEMBLY .....	8-6

WM-08031

## COOLING SYSTEM

### RADIATOR

#### IN-VEHICLE INSPECTION

Check the cooling system following the procedure given below. Retighten or replace any part which exhibits defects.

- (1) Detach the radiator cap and fill the cooling system with cooling water. Install a cap tester.
- (2) Apply a pressure of 1.2 kg/cm<sup>2</sup> (17 psi) to the cooling system by means of the cap tester. Proceed to check the following items listed below:
  - ① Radiator leakage
  - ② Water pump leakage
  - ③ Leakage at hose connections
  - ④ Excessive hose bulge

#### NOTE:

Care must be exercised to ensure that the neck filler section of the radiator is not distorted while the cap tester is removed or installed, or during the test.

- (3) Checking of neck filler section (water filling port)

- ① Distorted or dented seal surface
- ② Distorted edge section

#### NOTE:

If the neck filler section is distorted, the radiator cap can not be seated on the neck filler section closely, resulting in a decrease in the water level.

### RADIATOR CAP INSPECTION

- (1) Check the following parts. Replace any part which exhibits defects:
  - ① Cranked or distorted seal packing
  - ② Distorted or dented valve or valve seat
  - ③ Water scale accumulation between valve and valve seat

#### NOTE:

Remove any water scale accumulation which is found between the valve and the valve seat.




Fig. 8-1

4V-08212




Fig. 8-2

4V-08303




Fig. 8-3

4V-08304

) Check the pressure sealing and vacuum relief valve operation:

Valve Opening Pressure Limit:	kg/cm <sup>2</sup> (psi)
CB-23	0.6 (8.5)
CB-61	0.6 (8.5)
CB-80	0.6 (8.5)

Standard Valve:	kg/cm <sup>2</sup> (psi)
CB-23	0.75 - 1.05
CB-61	0.75 - 1.05
CB-80	0.75 - 1.05




Fig. 8-4

7W-0036

## THERMOSTAT INSPECTION

(1) Immerse the thermostat in water, and check the valve opening temperature by heating the water gradually.

(2) Replace the thermostat if the valve remains open at normal temperature or is not very tight when fully closed.

Specifications	Valve opening temperature (°C)	Valve total lift (mm)
Except ECE & EEC Specifications	80.5 - 83.5	5 mm or more at 95 °C
ECE & EEC Specifications	80.5 - 89.5	5 mm or more at 100 °C

### CAUTION:

As for Type CB-80 engine, install the thermostat in such a way that the jiggle pin may come at the upper side of the cylinder head. Failure to observe this caution may cause overheat or seizure of the engine.




Fig. 8-5

7W-0006




Fig. 8-6

7W-0007

## COOLING SYSTEM

### RADIATOR THERMO CONTROL SWITCH IN-VEHICLE INSPECTION

- (1) Turn ON the ignition switch.
- (2) Disconnect the radiator thermo control switch terminal and ground it directly to the body.  
Confirm that the fan motor can turn.

### UNIT INSPECTION

- (1) Connect a circuit tester to the radiator thermo control switch.  
Under this setting, change the water temperature. Observe the behavior of the circuit tester's pointer. If the pointer of the tester behaves as follows, it represents that the radiator thermo control switch is functioning normally.

- (2) Radiator thermo control switch characteristics

① General and Australian specifications

When the cooling temperature reaches  $92 \pm 2^{\circ}\text{C}$ , the radiator thermo control switch starts to operate. When the cooling water temperature begins to drop, the radiator thermo control switch continues to function until the cooling water temperature drops to  $87 \pm 2^{\circ}\text{C}$ .

② ECE & EEC Specifications

When the cooling temperature reaches  $98 \pm 2^{\circ}\text{C}$ , the radiator thermo control switch starts to operate. When the cooling water temperature begins to drop, the radiator thermo control switch continues to function until the cooling water temperature drops to  $93 \pm 2^{\circ}\text{C}$ .

### Fan Motor

Connection of fan motor to battery

[Connect the positive  $\oplus$  terminal of the motor to the positive  $\oplus$  terminal of the battery.]

[Connect the negative  $\ominus$  terminal of the motor to the negative  $\ominus$  terminal of the battery.]




Fig. 8-7

WM-38005




Fig. 8-8

WM-38009




Fig. 8-9

WM-38013




Fig. 8-10

WM-38017




Fig. 8-11

WM-38023

# WATER PUMP

## COMPONENTS OF WATER PUMP




Fig. 8-12

WM 38113

### DISASSEMBLY

1. Press off the water pump pulley, using the following SSTs.

SST: 09253-87202-000

SST: 09238-87201-000




Fig. 8-13

WM 38114

2. Remove the water pump bearing, using the following SST.

SST: 09237-87201-000




Fig. 8-14

WM 38115

3. Remove the rotor and seal set from the water pump bearing using the following SST.

SST: 09238-87201-000




Fig. 8-15

WM 38116

## COOLING SYSTEM

### INSPECTION

1. Check the water pump rotor and water pump seal set for evidence of damage or wear.  
Replace any parts that show defects.
2. Inspect on the water pump bearing for damage, abnormal sound or improper rotation.  
Replace the bearing that exhibits defects.
3. Check the water inlet pipe "O" ring for deterioration or damage. Replace the "O" ring that indicates defects.

### ASSEMBLY

1. Press the bearing into water pump rotor, using the following SST.  
SST: 09237-87201-000
2. Press the water pump set with the rotor into position, using the following SSTs.  
SST: 09238-87201-000  
SST: 09238-87701-000
3. Press the water pump rotor into position using the following SST.  
SST: 09238-87201-000




Fig. 8-15

WW-C8017




Fig. 8-17

WW-C8018




Fig. 8-18

WW-C8019




Fig. 8-19

WW-C8020




Fig. 8-20

WW-C8021

Press the water pump bearing set into the water pump pulley seat, using the following SSTs.

SST: 09238-87201-000

SST: 09254-87201-000

5. After assembling, make sure the rotor rotates smoothly with the water pump seat in the installed condition.




Fig. 8-21

4M-07023




Fig. 8-22

4M-08623





**DAIHATSU**  
**TYPE CB**  
**ENGINE**

[CB-23, CB-61 & CB-80]

## **SECTION 9**

# **TURBOCHARGER SYSTEM**

<b>TURBOCHARGER</b> .....	<b>9-2</b>
COMPONENTS OF TURBO CHARGER	
[CB-61 & CB-81 Engines] .....	<b>9-2</b>
INSPECTION ON TURBOCHARGED RELATED	
OPERATION .....	<b>9-3</b>
INSPECTION .....	<b>9-4</b>
IN-VEHICLE INSPECTION .....	<b>9-4</b>
<b>TROUBLE SHOOTING</b> .....	<b>9-6</b>

WM 39001


## TURBOCHARGER SYSTEM

### TURBOCHARGER

#### COMPONENTS OF TURBOCHARGER [CB-61 & CB-80 Engines]

**NOTE:**

The removal of the turbocharger should be performed only after the temperature of the turbocharger has dropped sufficiently.



- ① Turbo oil inlet pipe
- ② Exhaust manifold heat insulator No. 1
- ③ Exhaust manifold heat insulator No. 2
- ④ Air cleaner nose

- ⑤ Turbo oil outlet pipe
- ⑥ Exhaust front pipe
- ⑦ Exhaust manifold case
- ⑧ Turbocharger

Fig. 9-1

W74-39002

## INSTRUCTIONS ON TURBOCHARGER-RELATED OPERATIONS

1. The turbocharger is a precision component whose assembly requires special attention and equipment. Hence, never try to disassemble it.
2. When turbocharger is removed or installed:
  - (1) When the turbocharger has been removed, special care must be exercised as to the removed turbocharger.
  - (2) When the turbocharger is removed and installed, the oil inlet and outlet ports of the turbocharger and its inlet and outlet ports of intake air and exhaust gases should be plugged using adhesive tape, etc. in order that no dust or foreign particle may enter into the turbocharger.
  - (3) When the intake system, exhaust system or lubrication system is disassembled, make sure that no dust or foreign particle be permitted to enter into the turbocharger. Furthermore, ensure that the tightening torque specifications are strictly observed during the installation of the turbocharger so that the turbocharger may exhibit no leakage.
  - (4) When the engine is started after the turbocharger has been replaced, be sure to run the engine idly for at least 10 seconds. If the engine revolution speed is increased too sharply, the bearings of the turbocharger may be damaged. Also, make sure that no oil is leaking from the oil pipe.

3. Never try to lift the turbocharger by holding the waste gate valve rod or the similar parts.




Fig. 9-2

WV-09003



Fig. 9-3

WV-09004




Fig. 9-4

WV-09005

## TURBOCHARGER SYSTEM

4. Be very careful not to drop the turbocharger, for it is a precision component.
5. Never try to wipe off the residual oil completely from the bearing.  
(Here, the residual oil refers to such a degree of sticking oil which appears after the normal flowing.)
6. Be sure not to touch the turbocharger immediately after the engine operation or during the engine operation.  
(Failure to observe this caution may incur a burn.)
7. Do not run the engine with the intake pipe, intake hose, or exhaust manifold case, etc. disconnected.  
(This notice is important to prevent the ingress of any foreign matter.)



Fig. 9-5

WV-0305

## INSPECTION

### Checking of Lubrication System

1. Remove the union bolt for turbocharger lubrication use. Check to see if the orifice is restricted. If the orifice exhibits any restriction, clean the orifice using compressed air.

#### NOTE

1. Be sure to replace the union bolt washer with a new part.
2. Apply engine oil to the union bolt during the assembly.




Fig. 9-6

WV-0307

### Checking of Turbocharger

1. Check the blades of the turbine and compressor for any evidence of damage.
2. When the blades are turned by your finger, ensure that the turbine and compressor rotate smoothly.
3. Make sure that neither the turbine side nor the compressor side exhibits oil leakage.




Fig. 9-7

WV-0308

## IN-VEHICLE INSPECTION

### Checking of Operation of Waste Gate Valve

1. Disconnect the waste gate actuator hose at the actuator side.
2. Connect a Turbocharger pressure gauge and apply a pressure of  $0.65 \text{ kg/cm}^2$  (9.2 psi) (CB-61-80). Ensure that the rod and link are functioning properly.

Turbocharger pressure gauge:

SST (0992-87703-000)

When the pressure is released, ensure that the rod and link return to the original position without any binding.

3. Check to see if the hose exhibits cracks or damage.

#### NOTE:

If any pressure in excess of  $0.7 \text{ kg/cm}^2$  (10.0 psi) is applied to the waste gate actuator, there is a possibility that the diaphragm may be damaged.




Fig. 9-8

WV-0309

## Checking of Supercharging Pressure of Turbocharger (Running Test)

### NOTE:

This running test should be carried out in a test site where the acceleration running with the secondary valve fully opened and the transmission placed in the second gear may be performed safely. Moreover, conduct this running test with two persons riding on the test vehicle.

WA-090-3

### 1. (CB-61 Engine)

Disconnect the surge tank hose. Connect a three-way joint and turbocharger pressure gauge. Place the pressure gauge in the vehicle interior.

Turbocharger pressure gauge.

SST [09992-87703-000]

### (CB-80 Engine)

Disconnect the vacuum hose of the VSV (for controlling the supercharging pressure). Attach a three-way joint between the VSV and the vacuum switch (turbo indicator). Measure the supercharging pressure, using a pressure gauge.

Turbocharger pressure gauge:

SST [09992-87703-000]




Fig. 9-9

WA-090-3

2. After warming-up the engine, perform a full acceleration running test with the transmission placed in the second gear until the engine revolution speed reaches 4000 rpm.
3. Check the pressure at the time when the engine revolution speed reaches 4000 rpm.
  - Specified Pressure: **CB-61 Engine** 0.4 - 0.6 kg/cm<sup>2</sup> (5.7 - 8.5 psi)
  - CB-80 Engine** 0.6 kg/cm<sup>2</sup> (8.5 psi) or more

If the pressure fails to conform to the specification, replace the turbocharger assembly.

### NOTE:

Be sure not to perform the adjustment or disassembly of the turbocharger.

WA-090-3


# TURBOCHARGER SYSTEM

## TROUBLE SHOOTING (CB-61)

### NOTE:


1. Prior to starting the trouble shooting, make sure that the engine has been tuned-up properly and the idling adjustment has been performed to the specification.
2. Also, ensure that the engine is warmed up thoroughly.

### 1. Engine fails to deliver sufficient engine output.




WM1-09013

**Knocking or hunting occurs when engine runs at 3000 to 4000 rpm with throttle valve opened fully and with transmission place in second gear.**



AWC0014

**3. Engine emits whitish exhaust gas or oil is emitted from tail pipe.**



AWC0015





# DAIHATSU TYPE CB ENGINE

[CB-23, CB-61 & CB-80]


## SECTION 10 ENGINE ELECTRICAL SYSTEM

<b>DISTRIBUTOR</b> .....	<b>10- 2</b>
COMPONENTS OF DISTRIBUTOR	
[CB-23 & CB-61 Engines] .....	10- 2
DISASSEMBLY [CB-23 & CB-61 Engines] .....	10- 3
INSPECTION [CB-23 & CB-61 Engines] .....	10- 4
INSPECTION [CB-80 Engine] .....	10- 5
ASSEMBLY [CB-23 & CB-61] .....	10- 5
<b>IGNITION SYSTEM</b> .....	<b>10- 7</b>
COMPONENTS OF IGNITION SYSTEM .....	10- 7
INSPECTION [CB-23 & CB-61 Engines] .....	10- 8
<b>STARTER</b> .....	<b>10-10</b>
COMPONENTS OF STARTER	
[CB-23 M/T, CB-61 Engine & CB-80 Engine	
with General Specification] .....	10-10
[CB-23 Engine A/T & CB-80 Engine	
with ECE & EEC Specification] .....	10-11
PERFORMANCE TEST .....	10-12
DISASSEMBLY	
[CB-23 Engine M/T and CB-61 & CB-80 Engines] ....	10-14
DISASSEMBLY [CB-23 Engine A/T] .....	10-15
INSPECTION .....	10-16
ASSEMBLY	
[CB-23 Engine M/T and CB-61 & CB-80 Engines] ....	10-19
ASSEMBLY [CB-23 Engine A/T] .....	10-21
<b>ALTERNATOR</b> .....	<b>10-23</b>
COMPONENTS OF ALTERNATOR .....	10-23
DISASSEMBLY .....	10-24
INSPECTION .....	10-24
ASSEMBLY .....	10-25
IN-VEHICLE INSPECTION .....	10-26

WMI-0501

DISTRIBUTOR

COMPONENTS OF DISTRIBUTOR [CB-23 & CB-61 Engines]



- ① Water-proof cover
- ② Distributor can
- ③ Distributor rotor
- ④ Dust-proof distributor cover
- ⑤ Breaker points kit
- ⑥ Wire
- ⑦ Stationary plate
- ⑧ Washer

- ⑨ Vacuum advancer
- ⑩ Condenser
- ⑪ Screw and washer
- ⑫ Governor spring
- ⑬ Distributor cam
- ⑭ Snap washer
- ⑮ Governor weight
- ⑯ Governor shaft

- ⑰ Governor spring
- ⑱ Snap washer
- ⑲ Governor weight
- ⑳ Distributor cap spring
- ㉑ O-ring
- ㉒ Plate washer
- ㉓ Spiral gear

Fig. 10-1

**SASSEMBLY [CB-23 & CB-61 Engine]**

1. Remove the distributor cap.
2. Remove the rotor, cover and backing
3. Remove the terminal nut, lead wire condenser, insulators and terminal.




Fig. 10-2

WV-10003

4. Remove the two screws and breaker points




Fig. 10-3

WV-10004

5. Remove the vacuum advance
  - (1) Remove the condenser mounting screw and condenser from the distributor housing
  - (2) Remove the E-ring. Turn and pull out the vacuum advancer




Fig. 10-4

WV-10005

6. Remove the breaker plate.
  - (1) Remove the two screws, ground wire and plate washers.
  - (2) Pull out the breaker plate. Remove the governor springs.




Fig. 10-5

WV-10006

7. Remove the cam.
  - (1) Pry out the grease stopper.
  - (2) Remove the screw at the top of the governor shaft.
  - (3) Pull out the cam and governor weights.




Fig. 10-6

WV-10007

## ENGINE ELECTRICAL SYSTEM

### INSPECTION [CB-23 & CB-61 Engine]

1. Cap  
Check the cap for cracks, rust, dirty or corroded terminal.  
Check the central section for wear.
  
2. Rotor  
Check the rotor for cracks, burnt state, dirt or corrosion.
  
3. Breaker plate  
Turn the breaker plate. Ensure that it has a slight drag.  
If strong resistance or sticking is felt, replace the breaker plate.
  
4. Governor  
Temporarily install the cam with governor to the governor shaft. Ensure that they fit correctly.  
Replace the cam with governor or the housing kit, as required.
  
5. Breaker points  
Check the breaker points for wear or damage.
  
6. Governor shaft and housing  
Check for wear, sticking or damage. Replace the housing kit, as required.




Fig. 10-7

WVA-10035




Fig. 10-8

WVA-10036




Fig. 10-9

WVA-10010




Fig. 10-10

WVA-10011




Fig. 10-11

WVA-10012

**INSPECTION [CB-80 Engine]**

Measure the resistance between the terminals specified in the right figure.

Specified Value

Resistance between Terminals ① and ②:  
140 - 180 Ω

Resistance between Terminals ③ and ④:  
140 - 180 Ω

**Cap**

Check the cap for cracks, rust, dirty or corroded terminal.  
Check the contact section for wear.

**ASSEMBLY [CB-23 & CB-61]**

1. Install the cam with governor weights.
  - (1) Install the screw.
  - (2) Pack the high-temperature grease into the shaft.
  - (3) Push on the grease stopper by your finger.
  - (4) Install the cam with governor weights.
  - (5) Install the governor spring.
  
2. Install the breaker plate.
  - (1) Fit the four clips on the governor plate into the housing slots.
  - (2) Install one end of the lead wire and two plate washers with screws.




Fig. 10-12

WM-10213




Fig. 10-13

WM-10214




Fig. 10-14

WM-10214




Fig. 10-15

WM-10215




Fig. 10-16

WM-10216

## ENGINE ELECTRICAL SYSTEM

3. Install the vacuum advancer.
  - (1) Insert the advancer into the distributor and position the lever hole over the plate pin.
  - (2) Install the E-ring on the pin.
  - (3) Install the screw with the condenser to the distributor body.




Fig. 10-17

94-10017

4. Install and adjust the breaker point.
  - (1) Clean the contact surfaces of the points with a piece of cloth saturated in solvent.
  - (2) Loosely install the breaker points and one end of the lead wire with two screws.
  - (3) Using a feeler gauge set the heel gap and tighten the two screws.  
Heel gap: 0.45 mm (0.0177 inch)




Fig. 10-18

94-10018

5. Install the lead wire and terminal.  
Insert the terminal with breaker points wire. Install the insulators, lead wire, condenser and terminal nut.
6. Install the rotor.
7. Install the distributor cap and packing.





Fig. 10-19

94-10019

## IGNITION SYSTEM

## COMPONENTS OF IGNITION SYSTEM



- ① Resistor bracket  
 ② Resistor  
 ③ Ignition coil  
 ④ Coil resistive cord  
 ⑤ Spark plug resistive cord No. 2

- ⑥ Spark plug resistive cord No. 1  
 ⑦ Spark plug resistive cord No. 1  
 ⑧ Spark plug  
 ⑨ Clamp  
 ⑩ Clamp

Fig. 10-20

WM 10020

## ENGINE ELECTRICAL SYSTEM

### INSPECTION [CB-23 & CB-61 Engine]

#### 1. Ignition coil

##### (1) Primary coil resistance measurement:

Measure the resistance between the positive (+) terminal and the negative (-) terminal.

Resistance: 0.9 - 1.1  $\Omega$




Fig. 10-21

WM-10022

##### (2) Secondary coil resistance measurement:

Measure the resistance between the positive (+) terminal and the high tension terminal.

Resistance: 20.7 - 25.3 k $\Omega$




Fig. 10-22

WM-10022

##### (3) Insulator resistance measurement:

Measure the resistance between the positive (+) terminal and the coil case.

Resistance: Infinity




Fig. 10-23

WM-10023

##### (4) Resistor resistance measurement:

Resistance: 1.53 - 1.87  $\Omega$




Fig. 10-24

WM-10023

#### High tension cord check

##### 1. Carefully remove the high tension cord holding the rubber boot

NOTE:

Pulling out or bending the cord may damage the inner conductor.




Fig. 10-25

WM-10023



Measure the resistance of each high tension cord

### Resistance:

	CB-23 engine	CB-61 engine	CB-80 engine
Cord No 1	6.8 - 10.0	6.6 - 10.0	3.2 - 4.9
Cord No 2	8.1 - 12.1	8.1 - 12.1	4.6 - 7.0
Cord No.3	8.1 - 12.1	8.1 - 12.1	7.0 - 10.3
Central cord	6.1 - 9.2	6.1 - 9.2	5.1 - 7.7

### Spark plugs

- Remove the spark plug.
- Clean and check the spark plug.
  - Clean the spark plug with a plug cleaner or wire brush.
  - Inspect the spark plug to see if any damage is present at the electrode wire, thread or insulator
- Adjust the electrode gap  
Carefully bend the outer electrode to obtain the correct electrode gap.




Fig. 10-26

4-10-14631




Fig. 10-27

4-10-16331




Fig. 10-28

4-10-16331

### Spark Plug Specifications

Type type	CB-23					CB-61				CB-80	
	DFNSD	NGK	BOSCH	CHAMPION	DFNSD	NGK	BOSCH	CHAMPION	GENSO		
Manufacturer	DFNSD	NGK	BOSCH	CHAMPION	DFNSD	NGK	BOSCH	CHAMPION	GENSO		
ECG & SCL Specifications	W16EX-U	BP6EA	WR6DC	N111YC	W16EX-U W20EX-U	BP6EY	WR6DC	N111YC	W20EX-L	W22EX-L	
Except ECG & SCL Specifications	W16EX-U	BP6EA-L	WR6DC	N111YC	W16EX-U W20EX-L	BP6EY	WR6DC-X	N111YC	W20EX-L	W22EX-L	
Spark plug gap (mm) (inch)	0.7 - 0.8 (0.028 - 0.031)	0.8 - 0.9 (0.031 - 0.035)	0.7 - 0.8 (0.028 - 0.031)	0.7 - 0.8 (0.028 - 0.031)	0.7 - 0.8 (0.028 - 0.031)	0.8 - 0.9 (0.031 - 0.035)	0.7 - 0.8 (0.028 - 0.031)	0.7 - 0.8 (0.028 - 0.031)	0.8 - 1.0 (0.031 - 0.039)		


- Install the spark plugs.

4-10-15031

STARTER

COMPONENTS OF STARTER


[CB-23 M/T, CB-61 Engine & CB-80 Engine with General Specification]



- |                         |                        |
|-------------------------|------------------------|
| ① Screw                 | ⑩ Lock plate           |
| ② Starter drive housing | ⑪ Spring               |
| ③ Stop collar           | ⑫ Cover                |
| ④ Snap ring             | ⑬ Dust protector       |
| ⑤ Snap ring             | ⑭ Commutator end frame |
| ⑥ Magnetic switch       | ⑮ Bush                 |
| ⑦ Starter clutch        | ⑯ Bush holder          |
| ⑧ Armature              | ⑰ Field frame          |
| ⑨ Bearing cover         |                        |

Fig. 10-29

[CB-23 Engine AT & CB-80 Engine with ECE & EEC Specification]



- ① Bearing
- ② Armature
- ③ Bearing
- ④ Starter yoke
- ⑤ Spring brush
- ⑥ Brush holder
- ⑦ Drive housing
- ⑧ Magnetic starter switch

- ⑨ Spring
- ⑩ Ball
- ⑪ Starter clutch
- ⑫ Idle gear
- ⑬ Roller
- ⑭ Rear pin
- ⑮ Starter drive housing

Fig. 10-30

## ENGINE ELECTRICAL SYSTEM

### PERFORMANCE TEST

#### CAUTION:

Each of the following tests must be performed within three to five seconds to avoid burning out the coil.

WM-10236

1. Perform the pull-in test
  - (1) Disconnect the field coil lead from the terminal C.
  - (2) Connect the battery to the magnetic switch as shown in the right figure. Ensure that the pinion moves outward.  
If the pinion does not move, replace the magnetic switch.




Fig. 10-31

WM-10237




Fig. 10-32

WM-10238

2. Perform the hold-in test:  
While still connected above and with the pinion out, disconnect the negative lead from the terminal C. Ensure that the pinion remains out. If the pinion returns inward, replace the magnetic switch.




Fig. 10-33

WM-10239




Fig. 10-34

WM-10240

Check the pinion return.

Disconnect the negative lead from the switch body. Ensure that pinion returns inward. If the pinion does not return, replace the magnetic switch.

- 4 Perform the no-load performance (CB-23 Engine M/T and CB-61 & CB-80 Engines)

- (1) Connect the tie d coil lead to the terminal C. Make sure that the lead is not grounded.
- (2) Connect the battery and ammeter to the starter as shown in Fig. 10-40
- (3) Ensure that the starter rotates smoothly and steadily with the pinion moving out.
- (4) Ensure that the ammeter registers the specified current.

**Specified Current: Less Than 50 A at 11 V**

- 5 Perform the no-load performance (CB-23 Engine A/T)

- (1) Connect the battery and ammeter to the starter as shown in the right figure
- (2) Ensure that the starter rotates smoothly and steadily with the pinion moving out. Ensure that the ammeter registers the specified current.

**Specified Current: Less Than 90 A at 11.5 V**

- 6 Check the pinion clearance (Except CB-23 Engine A/T)

- (1) Connect the battery to the magnetic switch as shown in Fig. 10-42

(CB-23 Engine M/T and CB-61 & CB-80 Engines)




Fig. 10-35

AV-10042

(CB-23 Engine A/T)




Fig. 10-36

AV-10042




Fig. 10-37

AV-10042




Fig. 10-38

AV-10042




Fig. 10-39

AV-10042

## ENGINE ELECTRICAL SYSTEM

- (2) Move the pinion gear toward the armature to remove any play. Measure the clearance between the pinion end and the stop collar

Specified Clearance: 0.1 - 4.0 mm  
(0.004 - 0.157 inch)




Fig. 10-40

WM-10045

### DISASSEMBLY

#### [CB-23 Engine M/T and CB-61 & CB-80 Engines]

1. Remove the magnetic switch.
  - (1) Remove the nut. Disconnect the lead wire from the magnetic switch terminal.
  - (2) Loosen the two nuts holding the magnetic switch to the switch housing. Lift the magnetic switch up and out to unhook the plunger from the drive lever.




Fig. 10-41

WM-10047

2. Remove the end frame.
  - (1) Remove the bearing cover.
  - (2) Using a feeler gauge, check the armature shaft thrust clearance between the lock plate and the end frame.  
Thrust clearance: 0.05 - 0.60 mm  
(0.0020 - 0.0236 inch)




Fig. 10-42

WM-10049

- (3) Remove the lock plate, spring and rubber.
  - (4) Remove the two through bolts and pull out the commutator end frame.




Fig. 10-43

WM-10049

3. Remove the brushes and brush holder.
  - (1) Using a piece of steel wire, separate the brush springs. Remove the brushes from the brush holder.
  - (2) Pull the brush holder off the armature.



Fig. 10-44

WM-10050

- Remove the field frame from the drive housing.  
Pull them apart by hands.
5. Remove the armature.
- (1) Remove the drive lever from the drive housing.
  - (2) Pull the armature from the drive housing.




Fig. 10-45

WM-10031

6. Remove the starter clutch.
- (1) Detach the stop collar, using a screwdriver.
  - (2) Pry off the snap ring, using a screwdriver.
  - (3) Remove the collar from the shaft.




Fig. 10-46

WM-10032

- (4) If any difficulty is encountered in pulling out the pinion, smoothen the shaft with an oil stone.
- (5) Remove the starter clutch.




Fig. 10-47

WM-10033

**DISASSEMBLY [CB-23 Engine A/T]**

Remove the field frame with armature from the magnetic switch.

- (1) Disconnect the lead wire from the magnetic switch terminal.
  - (2) Remove the two through bolts. Pull out the field frame with the armature from the magnetic switch.
  - (3) Remove the left seal.
2. Remove the starter housing from the magnetic switch assembly.  
Remove the two screws and remove the starter housing with the idler gear and clutch assembly.




Fig. 10-48

WM-10034




Fig. 10-49

WM-10035

## ENGINE ELECTRICAL SYSTEM

3. Remove the clutch assembly and idler gear from the starter housing
4. Remove the steel ball and spring  
Using a magnetic finger, remove the spring and steel ball from the clutch shaft hole.




Fig. 10-50

WMA-10019E

5. Remove the brushes and brush holder
  - (1) Remove the endcover from the field frame
  - (2) Separate the brush springs, using a screwdriver or a steel wire. Remove the brushes from the brush holder.
  - (3) Pull the brush holder off the field frame.
6. Remove the armature from the field frame.



Fig. 10-51

WMA-10057

## INSPECTION

### Armature Coil

1. Ensure that the commutator is not grounded.  
Using an ohmmeter, ensure that no continuity exists between the commutator and the armature coil core. If continuity exists, replace the armature.
2. Check the commutator for open circuit.  
Using an ohmmeter, ensure that continuity exists between the segments of the commutator. If no continuity exists between any segments, replace the armature.




Fig. 10-52

WMA-10059




Fig. 10-53

WMA-10059

### Field Coil

1. Check the field coil for open circuit.  
Using an ohmmeter, ensure that continuity exists between the lead wire and the field coil brush lead. If no continuity exists, replace the field coil.




Fig. 10-54

WMA-10060

(CB-23 Engine M/T and  
CB-61 & CB-80 Engines)



2. Ensure that the field coil is not grounded. Using an ohmmeter ensure that no continuity exists between the field coil end and the field frame. If continuity exists, replace the field coil.

**Brush Holder**

1. Check the brush holder for insulation. Using an ohmmeter, ensure that no continuity exists between the positive and negative brush holders. If continuity exists, repair or replace the brush holder.

**Starter Clutch**

Inspect the pinion gear and spline teeth. inspect the pinion gear and spline teeth for wear or damage. If damaged, replace the starter clutch. Also, inspect the flywheel ring gear for wear or damage.

2. Check the clutch. Rotate the pinion clockwise. Ensure that the pinion is locked. Then, rotate the pinion counterclockwise. Ensure that the pinion rotates freely.

**Bearings**

1. Inspect the bearings. Turn each bearing by hands while applying a force to the bearing. If any resistance or binding is felt, replace the bearing.

(CB-23 Engine A/T)




Fig. 10-55

WM-10051




Fig. 10-56

WM-10052



Fig. 10-57

WM-10053




Fig. 10-58

WM-10054



Fig. 10-59

WM-10055

## ENGINE ELECTRICAL SYSTEM

2. Replace the bearings, as required
  - (1) Remove the bearing from the armature shaft, using the following SST
  - (2) Remove the other bearing from the opposite side  
SST: 09286-46011
  - (3) Tape the front bearing onto the shaft using the following SST.  
SST: 09285-76010
  - (4) Install the rear bearing onto the shaft using a press.

### Magnetic Switch

#### [CB-23 Engine MT and CB-61 & CB-80 Engines]

1. Check the plunger.

Push in the plunger and release it. Ensure that it returns quickly to its original position.
2. Perform the pull-in coil open circuit test.

Using an ohmmeter, ensure that continuity exists between the terminal 50 and the terminal C.  
If no continuity exists, replace the magnetic switch.
3. Perform the hold-in coil open circuit test.

Using an ohmmeter, ensure that continuity exists between the terminal 50 and the switch body.  
If no continuity exists, replace the magnetic switch.




Fig. 10-60

WM-10060




Fig. 10-61

WM-10061




Fig. 10-62

WM-10062




Fig. 10-63

WM-10063




Fig. 10-64

WM-10064

**Magnetic Switch [CB-23 Engine A/T]**

1. Perform the pull-in coil open circuit test.  
Using an ohmmeter, ensure that continuity exists between the terminal 50 and the terminal C.  
If no continuity exists, replace the magnetic switch.
  
2. Perform the hold-in coil open circuit test.  
Using an ohmmeter, ensure that continuity exists between the terminal 50 and the switch body.  
If no continuity exists, replace the magnetic switch.




Fig. 10-65

WM-10071




Fig. 10-66

WM-10073

**ASSEMBLY [CB-23 Engine M/T and CB-61 & CB-80 Engines]**

**NOTE:**

Use high-temperature grease to lubricate the bearings and sliding parts when assembling the starter.

WM-10075

1. Assemble the starter clutch to the armature
  - (1) Place a new stop collar on the armature
  - (2) Drive in the snap ring with a 14 mm (0.5 inch) socket wrench or the like. Then, fit it into the shaft groove.
  
- (3) Using a vise, compress the snap ring. Make sure that the snap ring fits correctly.




Fig. 10-67

WM-10074




Fig. 10-68

WM-10075

## ENGINE ELECTRICAL SYSTEM

- (4) Using a screwdriver, tap the pinion to slide the stop collar onto the snap ring.




Fig. 10-69

WM-0076

2. Assemble the drive housing, drive lever and field frame to the armature.

- (1) Apply grease to the drive lever and drive housing bushing.
- (2) Install the drive lever to the drive housing.
- (3) Install the field frame on the armature.




Fig. 10-70

WM-0077

3. Install the brush holder and brushes.

- (1) Place the brush holder over the armature shaft.
- (2) Using a piece of steel wire, hold the brush spring back and install the brush in the brush holder. Install the four brushes.

4. Install the end frame.

- (1) Apply grease to the end frame bushing.
- (2) Install the end frame on the armature shaft and secure with two through bolts.



Fig. 10-71

WM-0078

5. Install the bearing cover.

- (1) Install the rubber, spring and lock plate.
- (2) Using a feeler gauge, measure the armature thrust clearance between the lock plate and the end frame.  
Thrust clearance: 0.05 - 0.60 mm  
(0.0020 - 0.0236 inch)

- (3) Install the bearing cover with the two screws.



Fig. 10-72

WM-0079

6. Install the magnetic switch.

- Hook the magnetic switch stud underneath the drive lever spring. Install the two nuts.




Fig. 10-73

WM-0080

**ASSEMBLY [CB-23 Engine A/T]****NOTE.**

Use high-temperature type grease to lubricate the bearings and gears when assembling the starter.

- Place the armature into the field frame.  
Apply grease to the armature bearings and insert the armature into the field frame.

WVA-10081

- Install the brush holder and brushes.
  - While the brush spring is held back by means of a screwdriver, install the brush into the brush holder. Thus, install the four brushes.

**NOTE:**

Make sure that the positive lead wires are not grounded.

- Install the end cover to the field frame.

- Install the steel ball into the clutch shaft hole.  
Apply grease to the ball and spring, and insert them into the clutch shaft hole.

- Install the gear and clutch assembly.
  - Apply grease to the gear and clutch assembly.
  - Place the clutch assembly, idle gear and bearing in the starter housing.

- Install the starter housing.  
Place the starter housing on the magnetic switch and install the two screws.




Fig. 10-74

WVA-10082




Fig. 10-75

WVA-10083




Fig. 10-76

WVA-10084




Fig. 10-77

WVA-10085

## ENGINE ELECTRICAL SYSTEM

6. Install the field frame with armature in the magnetic switch.
- (1) Place the felt seal on the armature shaft
  - (2) Align the protrusion of the field frame with the magnetic switch.




Fig. 10-78

MM-C056

- (3) Install the two through bolts
- (4) Connect the coil lead to the terminal on the magnetic switch.





Fig. 10-79

MS-10267

ALTERNATOR

COMPONENTS OF ALTERNATOR



- ① Pulley lock nut
- ② Alternator pulley
- ③ Spacer collar
- ④ Drive end frame A<sub>y</sub>
- ⑤ Stud bolt
- ⑥ Bearing
- ⑦ Retainer plate
- ⑧ Bush
- ⑨ Alternator rotor A<sub>y</sub>
- ⑩ Bearing

- ⑪ Bearing cover
- ⑫ Rear end frame
- ⑬ Rectifier
- ⑭ Terminal insulator
- ⑮ IC regulator
- ⑯ Brush
- ⑰ Spring
- ⑱ Brush holder A<sub>y</sub>
- ⑲ Rear end cover

Fig. 10-80

NM-1008

## ENGINE ELECTRICAL SYSTEM

### DISASSEMBLY

1. Remove the nut and terminal B insulator.
2. Remove the three bolts and rear end cover.
3. Remove the two screws of the brush holder assembly. Also, remove the three screws of the IC regulator assembly.
4. Remove the brush holder assembly and regulator assembly.




Fig. 10-81

WM-10089




Fig. 10-82

WM-10090




Fig. 10-83

WM-10091




Fig. 10-84

WM-10092

### INSPECTION

1. IC Regulator Diode  
Ensure that continuity exists between the terminal B and the terminal F.  
F → B Continuity exists  
B → F No continuity exists




Fig. 10-85

WM-10093



**Brush**

Measure the exposed brush length

**Exposed length**

Specified value: 10.5 mm (0.413 inch)

Limit: 4.5 mm (0.177 inch)




Fig. 10-86

www.ticpe.com

**3 Rectifier**

Ensure that continuity exists between the terminal B and the rectifier terminal.

F → Rectifier Continuity exists

Rectifier → B No continuity exists.




Fig. 10-87

www.ticpe.com

**4 Stator**

Measure the resistance between the terminals, using an ohmmeter

Resistance: Less than 1 Ω




Fig. 10-88

www.ticpe.com

**5 Rotor**

Measure the resistance between the slip rings, using an ohmmeter.

Resistance: 2.9 Ω




Fig. 10-89

www.ticpe.com

**ASSEMBLY**

1 Install the brush holder assembly together with the IC regulator into the body from the side direction.

**NOTE:**

Be very careful not to distort the holder cover during the installation.

Install the brush holder, using the five screws. Also, install the IC regulator into position.




Fig. 10-90

www.ticpe.com

## ENGINE ELECTRICAL SYSTEM

3. Install the rear end cover.




Fig. 10-91

AW-10689

4. Install the terminal B insulator and nut.




Fig. 10-92

AW-10700

### IN-VEHICLE INSPECTION

#### 1. No-Load Performance Test

- (1) Connect the probes to the battery. Connect the DC 200 A probe to the alternator terminal B wire harness.
- (2) Run the engine at 2000 rpm.  
Regulating Voltage: 13.9 - 15.1 (25°C)  
Current: Less than 10 A




Fig. 10-93

AW-10701

#### 2. Load Performance Test

- (1) Run the engine at 2000 rpm
- (2) Turn on the headlamps and blower fan.  
Regulated Voltage: 13.9 - 15.1 V  
Current: More than 30 A




Fig. 10-94

AW-10702

**DAIHATSU**  
**TYPE CB**  
**ENGINE**

[CB-23, CB-61 & CB-80]

**SECTION 11**  
**INTAKE SYSTEM**


AIR CLEANER .....	11-2
SURGE TANK [CB-61 Engine] .....	11-6
INTERCOOLER [CB-80 Engine] .....	11-7

WMI-11007

## INTAKE SYSTEM

### AIR CLEANER

#### COMPONENTS OF AIR CLEANER [CB-23 Engine]




- ① Air cleaner cap
- ② Gasket
- ③ Air cleaner filter element
- ④ Grommet
- ⑤ Air cleaner case
- ⑥ Hot air intake duct
- ⑦ Air cleaner hose No. 1
- ⑧ Clamp

Fig. 11-1

WM-11002

[CB-61 &amp; CB-80 Engines]



- ① Air cleaner cap
- ② Air cleaner filter element
- ③ Air cleaner hose No. 1
- ④ Air cleaner case

Fig. 11-2

WM-11-003

## INTAKE SYSTEM

### INSPECTION

1. Check the air cleaner cap and case for deformation or damage. Replace or repair any defective parts.
2. Check the air cleaner element. If it is excessively dirty, clogged or damaged, clean or replace the element.

Element cleaning intervals: 10,000 km (6,000 mile)

Element replacement intervals:

40,000 km (24,000 mile)

#### NOTE:

If the vehicle is operated in dusty area, the cleaning or replacement of the element must be made at earlier time than the intervals above.




Fig. 11-3

WM-11074




Fig. 11-4

WM-11075

### Cool Air/Hot Air Switching Adjustment System Check [CB-23 Engine]

1. Check the vacuum motor  
Ensure that the air control valve opens fully when a negative pressure of  $-180$  mmHg is applied by means of a MityVac.  
If the air control valve is malfunctioning, replace the air cleaner case.
2. Check the hoses and connections  
Visually inspect the hoses and connections for cracks, leakage or damage.




Fig. 11-5

WM-11076

## Checking of operation of temperature sensing valve

- (1) Detach the air cleaner cap
- (2) Cool the temperature sensing valve by cold air
- (3) Ensure that the air control valve opens fully under this setting




Fig. 11-6

WM-11007

- (4) Install the air cleaner cap
  - (5) Start the engine. Run the engine at the idling speed.
  - (6) When the temperature inside the air cleaner case rises above about 30°C, ensure that the air control valve is opened fully.
- If the air control valve fails to open fully despite the temperature rise, replace the air cleaner case.




Fig. 11-7

WM-11008

## INTAKE SYSTEM

### SURGE TANK

#### COMPONENTS OF SURGE TANK [CB-61 Engine]




Fig. 11-8

WM-1-009

#### INSPECTION

1. Check to see if the surge tank exhibits any sign of cracks or damage.
2. Disconnect the relief valve hose and blow your breath into the surge tank. There should be no air continuity.

#### 3. Turbocharger Indicator Lamp

##### Inspection:





Fig. 11-9

WM-1-010





Fig. 11-10

WM-1-011



INTERCOOLER

COMPONENTS OF INTERCOOLER [CB-80 Engine]



- ① Inlet cool air No. 1
- ② Inlet cool air No. 2
- ③ Intercooler: S/A
- ④ Bracket
- ⑤ Hose
- ⑥ Hose
- ⑦ Intake pipe
- ⑧ Hose

Fig. 11-11

## INTAKE SYSTEM

### INSPECTION

1. Check the core section of the intercooler for restriction.
2. Check the core section of the intercooler for damage.




Fig. 11-12

WM 1103

3. Check the intercooler for air leakage.  
Tightly seal the intake and discharge ports of the intercooler using sealing tape or the like. Submerge the intercooler into the water in a water tank. This water should be heated in advance up to about 50°C.  
Check to see if the intercooler exhibits air leakage.  
Replace the intercooler if it exhibits air leakage.



Fig. 11-13

WM 1103

# DAIHATSU TYPE CB ENGINE

[CB-23, CB-61 & CB-80]

## SECTION 12 EMISSION CONTROL SYSTEM

<b>LIST OF DESTINATIONS</b> .....	12- 2	<b>CHOKE WARNING SYSTEM</b> .....	12-30
<b>SCHEMATIC VIEW OF EMISSION CONTROL SYSTEM</b> .....	12- 3	CHECK .....	12-30
<b>BLOW-BY GAS RECIRCULATION SYSTEM</b> .....	12-20	<b>FUEL CUT SYSTEM DURING DECELERATION</b> .....	12-31
INSPECTION .....	12-22	OPERATING CONDITIONS OF SYSTEM .....	12-31
<b>CHOKE OPENER SYSTEM</b> .....	12-22	SYSTEM CHECK .....	12-32
SYSTEM CHECK .....	12-23	UNIT CHECK .....	12-32
UNIT CHECK .....	12-23	VACUUM SWITCH .....	12-32
<b>LASHPOT SYSTEM</b> .....	12-24	<b>OUTER VENT SYSTEM</b> .....	12-33
SYSTEM CHECK .....	12-25	UNIT CHECK .....	12-34
UNIT CHECK .....	12-25	<b>IGNITION TIMING CONTROL SYSTEM</b>	
<b>FUEL EVAPORATIVE EMISSION CONTROL SYSTEM</b> .....	12-25	CHECK [CB-23 Engine] .....	12-35
CHARCOAL CANISTER .....	12-26	MAIN SIDE .....	12-35
INSPECTION .....	12-26	SUB SIDE .....	12-35
<b>MAIN AIR BLEED</b> .....	12-26	UNIT CHECK .....	12-36
OPERATION CHECK OF VCV .....	12-27	<b>IGNITION TIMING CONTROL SYSTEM</b>	
<b>SECONDARY AIR SUCTION SYSTEM (AS SYSTEM)</b> .....	12-27	CHECK [CB-61 Engine] .....	12-37
CHECKING OF SECONDARY AIR SUCTION SYSTEM .....	12-27	IGNITION TIMING CONTROL SYSTEM CHECK .....	12-37
A.R SUCTION FILTER ELEMENT .....	12-28	UNIT CHECK .....	12-38
<b>EGR (EXHAUST GAS RECIRCULATING) SYSTEM</b> .....	12-28	CHECK AND ADJUSTMENT OF IGNITION TIMING .....	12-38
EGR SYSTEM CHECK .....	12-28		
UNIT INSPECTION .....	12-29		

# EMISSION CONTROL SYSTEM

## LIST OF DESTINATIONS

Engine type Destination Transmission type	Blow-by gas recirculating system	Choke warning	Ignition timing control system	Choke control	Dashpot	Control system	Fuel during decelera- tion	Second- ary air injection	Carburetor	Manifold heater	Exhaust gas recircu- lating system	Fuel injector or emission control system
General specifications Manual transmission	○	—	○	—	—	—	—	—	—	—	—	—
General specifications Automatic transmission	○	—	○	—	—	—	—	—	—	—	—	—
Australian specifications Manual transmission	○	○	○	○	○	○	○	○	○	—	—	○
Australian specifications Automatic transmission	○	○	○	○	○	○	○	○	○	—	—	○
ECE & EEC specifications Manual transmission	○	○	○	○	○	—	—	—	—	—	—	—
ECE & EEC specifications Automatic transmission	○	○	○	○	—	—	—	—	—	—	—	—
Saudi Arabia (GCC) specifications Manual transmission	○	—	○	○	○	—	—	—	—	—	—	—
Saudi Arabia (GCC) specifications Automatic transmission	○	—	○	○	—	—	—	—	—	—	—	—
Singapore specifications Manual transmission	○	—	○	○	○	—	—	—	—	—	—	—
Singapore specifications Automatic transmission	○	—	○	○	—	—	—	—	—	—	—	—
Swedish specifications Manual transmission	○	○	○	○	○	—	—	—	—	—	—	—
Swiss specifications Manual transmission	○	○	○	○	○	—	○	○	○	—	○	—
General specifications Manual transmission	○	—	○	—	—	—	—	—	—	—	—	—
Australian specifications Manual transmission	○	○	○	○	○	○	○	○	○	○	—	○
ECE & EEC specifications Manual transmission	○	○	○	○	○	—	—	—	—	—	—	—
Singapore specifications Manual transmission	○	○	○	○	○	—	—	—	—	—	—	—
Swedish specifications Manual transmission	○	○	○	○	○	—	—	—	—	—	—	—
West German specifications Manual transmission	○	○	○	○	○	—	○	○	○	○	—	—
CE-90 AI specifications Manual transmission	○	○	Electronic timing advance	—	—	—	—	—	—	—	—	○
CL-1 AI specifications Manual transmission	○	—	—	—	—	—	—	—	—	—	—	—
CL-6 AI specifications Manual transmission	○	—	—	—	—	—	—	—	—	—	—	—

WM-12002

## SCHEMATIC VIEW OF EMISSION CONTROL SYSTEMS

General Specifications with CB-23 Engine and Manual Transmission




Fig. 12-1

WM-12003

# EMISSION CONTROL SYSTEM

## General Specifications with CB-23 Engine and Automatic Transmission




Fig. 12-2

WM-12004

Australian Specifications with CB-23 Engine and Automatic Transmission





Fig. 12-3

# EMISSION CONTROL SYSTEM

## Australian Specifications with CB-23 Engine and Manual Transmission





Fig. 13-4



E & EEC Specifications with CB-23 Engine and Manual Transmission





Fig. 12-5

# EMISSION CONTROL SYSTEM

## ECE & EEC Specifications with CB-23 Engine and Automatic Transmission





Fig. 12-6

MM-2008

Udi Arabian (GCC) Specifications with CB-23 Engine and Manual Transmission




Fig. 12-7

# EMISSION CONTROL SYSTEM

Saudi Arabian Specifications with CB-23 Engine and Automatic Transmission




Fig. 12-8

WM-12310

igapore Specifications with CB-23 Engine and Manual Transmission





Fig. 12-9

# EMISSION CONTROL SYSTEM

Singapore Specifications with CB-23 Engine and Automatic Transmission




Fig. 12-10

WV-1201-2

vehish Specifications with CB-23 Engine and Manual Transmission





Fig. 12-11

# EMISSION CONTROL SYSTEM

## Swiss Specifications with CB-23 Engine and Manual Transmission




Fig. 12-12



General Specifications with CB-61 Engine





Fig. 12-13

# EMISSION CONTROL SYSTEM

## Australian Specifications with CB-61 Engine





Fig. 12-14

ECE & EEC and Singapore Specifications with CB-61 Engine




Fig. 12-16

# EMISSION CONTROL SYSTEM

## Swedish Specifications with CB-61 Engine




Fig. 12-16

WM-12018

ast German Specifications with CB-61 Engine





Fig. 12-17

## BLOW-BY GAS RECIRCULATION SYSTEM

### Blow-by Gas Recirculating System (CB-23 Engine)




Fig. 12-18

ATA-2083

### Blow-by Gas Recirculating System (CB-80 Engine)




Fig. 12-19

ATA-12021

Low-by Gas Recirculating System (CB-61 Engine)




Fig. 12-20

## EMISSION CONTROL SYSTEM

### INSPECTION

#### Ventilation hose (1)

1. Ensure that the ventilation hoses exhibit no cracks, damage, or restriction
2. Ensure that the baffle plate of the cylinder head cover exhibits no restriction
3. Remove the oil filler cap. Lightly blow into the hose through the ventilation hose. If air continuity exists, it represents a normal operation.

#### Ventilation hose (2)

1. Disconnect the ventilation hose from the carburetor's insulator
2. Ensure that the hose exhibits no cracks
3. Damage or restriction
4. Remove the oil filter cap. Strongly blow from the carburetor side. If air passes through, it represents a normal operation.




Fig. 12-21

WMI-10023




Fig. 12-22

WMI-10024

## CHOKE OPENER SYSTEM




Fig. 12-23

WMI-10025




Fig. 12-24

WMI-10025



**SYSTEM CHECK**

While the engine is running at the id'e speed, disconnect the vacuum hose connected to the choke opener. If the link shows the following behaviors described in the table below, it represents a satisfactory operation.

Cooling water temperature	When hose is connected
10°C or below	Link will not move (No vacuum is applied to hose )
20°C or above	Link moves (Vacuum is applied to hose )




Fig. 12-25

WM-12007

**UNIT CHECK**

1. With a MityVac connected, apply a vacuum of 220 mm Hg to the choke opener. If the link is pulled, it represents a normal operation. Next, release the vacuum. If the link returns quickly, it indicates a normal function.




Fig. 12-26

WM-12208

2. BSVV OR TVSV




Fig. 12-27

WM-12020

## EMISSION CONTROL SYSTEM

Gradually heat the BVSV or TVSV. Then, cool it gradually. Check the valve for air continuity during the check.

Test water temperature	Port		
	K	L	J
10°C (50°F) or below	○	○	○
30°C (86°F) or above	○	○	○

○—○ mark denote that vent continuity exists.

Test water temperature	Port				
	N	M	L	S	R
0°C (32°F) or below	○	○	○	○	○
14°C (57°F) or above	○	○	○	○	○
40°C (104°F) or above	○	○	○	○	○
66°C (151°F) or above	○	○	○	○	○

○—○ mark denote that vent continuity exists.

## DASHPOT SYSTEM




Fig. 12-28

WM-2130




Fig. 12-29

WM-127




Fig. 12-30

WM-2137

**STEM CHECK**

1. Hold the engine revolution speed at 2500 rpm for a short period of time. Then, release the throttle.
2. While the engine revolution speed drops, measure the time required for the engine speed to drop from 1500 rpm to 1000 rpm.

If the required time falls within the range given below, the dashpot system is functioning properly.

Specified Time: 2.0 - 4.0 seconds




Fig. 12-31

WM-1203

**UNIT CHECK**

**Dashpot**

With a MityVac connected, apply a vacuum of 220 mm Hg to the dashpot. If the shaft is pulled out, it represents a normal operation.

Next, release the vacuum. If the shaft returns quickly, it rates a normal function.




Fig. 12-32

WM-1203A

**FUEL EVAPORATIVE EMISSION CONTROL SYSTEM**




Fig. 12-33

WM-1203E

## EMISSION CONTROL SYSTEM

### CHARCOAL CANISTER

#### CAUTION:

1. Handle the charcoal canister with utmost care, for most likely it has absorbed gasoline.
2. Never attempt to disassemble the charcoal canister. The charcoal canister has been so constructed that it is integral with the check valve.

WM-12025

### INSPECTION

Check the charcoal canister for continuity between ports, as follows:

1. When you blow your breath into the canister through the port A (TO CARB) there should be no continuity. Also, when you blow your breath strongly into the canister through the port B (TO TANK) there should be continuity.
2. While blowing breath strongly into the canister through the port C, perform the continuity check of the check valves located at the ports A and B, following the procedure given below:
  - (1) When the port A is plugged with finger, air should emit from the port B.
  - (2) When the port B is plugged with finger, air should emit from the port A.




Fig. 12-34

WM-13027

### MAIN AIR BLEED

In order to maintain proper air-to-fuel ratio during heavy load operation, a VCV has been provided at the main air bleed No. 2.

When the turbocharging pressure exceeds  $0.28 \text{ kg/cm}^2$  ( $+210 \text{ mmHg}$ ) the VCV closes.

As a result, the air ceases flowing from the surge tank to the main air bleed No. 2.

#### VCV Specifications

Valve closing pressure	$0.28 \text{ kg/cm}^2$ ( $+210 \text{ mmHg}$ ) $3.92 \text{ psi}$ ( $+210 \text{ mmHg}$ )
------------------------	--





Fig. 12-35

WM-12025

#### VCV Characteristics



WM-12029

## OPERATION CHECK OF VCV

1. If air continuity exists when you blow your breath from the side of A or B port, the VCV is satisfactory.
2. Plug the port A side and connect a turbocharger pressure gauge to the port B side. Then apply a positive pressure of  $0.5 \text{ kg/cm}^2$  ( $7.11 \text{ lb/inch}^2$ ) and release the port A. If the pointer is stable at this time, the VCV is satisfactory.
3. Release the port A to reduce the positive pressure gradually. If the pointer suddenly drops from a pressure of about  $0.25 \text{ kg/cm}^2$  ( $3.56 \text{ lb/inch}^2$ ), it means that the VCV is functioning properly.




Fig. 12-36

WM-12043

## SECONDARY AIR SUCTION SYSTEM (AS SYSTEM)




Fig. 12-37

WM-12041

## CHECKING OF SECONDARY AIR SUCTION SYSTEM

1. Disconnect the hose between the air suction valve and the air cleaner.
2. Start the engine. If you can hear a pumping sound and the pumping sound ceases when you plug the hose with your hand, it indicates satisfactory operation.

## NOTE:

Ensure that no exhaust gas blows back.

3. Make sure that the AS filter exhibits no restriction, contamination or damage.
4. Check air continuity of the air suction valve, as follows.
  - (1) Air continuity should exist when the section A is lightly blown.
  - (2) No air continuity should exist even when the section B is strongly blown.




Fig. 12-38

WM-12042





Fig. 12-39

WM-12043


## EMISSION CONTROL SYSTEM

### AIR SUCTION FILTER ELEMENT

- Replace the air suction filter element.  
Replacement intervals: Two years or 40,000 km running, whichever comes first



### EGR (EXHAUST GAS RECIRCULATING) SYSTEM




### EGR SYSTEM CHECK

When engine is cold:

(Temperature of cooling water is above 29°C):

- 1 Connect a vacuum gauge between the modulator valve and the EGR valve
- 2 Start the engine. If the pointer of the vacuum gauge registers between zero and a negative pressure of 100 mm Hg when the engine is idling or even when the engine revolution speed exceeds 3000 rpm, it indicates that the EGR system is functioning properly



**ter engine is warmed-up:****(Temperature of cooling water is above 46.5°C):**

1. Connect a vacuum gauge between the modulator valve and the EGR valve.
2. If the pointer of the vacuum gauge registers zero when the engine is started, it shows satisfactory operation.
3. Raise the engine revolution speed to approximately 3500 rpm. If the pointer of the vacuum gauge rises to around 150 mmHg, it indicates that the EGR system is functioning properly.
4. Connect a MityVac to the EGR valve.
5. Apply a negative pressure of 130 mmHg to the EGR valve; if the engine becomes roughly idling or stalls, it indicates that the EGR system is functioning properly.

**UNIT INSPECTION**

## 1. EGR valve

## (1) Air-tightness check

Apply a negative pressure of 400 mmHg to the diaphragm chamber using a MityVac. If the pointer is steady, it indicates that the EGR valve is satisfactory.

## (2) Air-continuity check

If air continuity exists between the port A and the port B when a negative pressure of 190 mmHg or more is applied to the diaphragm chamber using a MityVac and if no air continuity exists between the port A and the port B when a negative pressure of 140 mmHg or less is applied to the diaphragm chamber, it indicates that the EGR valve is satisfactory.

## 2. Modulator

Plug either the port Q or the port P by your finger. Using a MityVac, apply a negative pressure to the remaining port. If the pointer returns to zero gradually, it indicates that the modulator is functioning properly.




Fig. 12-43

474-2247




Fig. 12-44

474-2249




Fig. 12-45

474-2250




Fig. 12-46

474-2252

## EMISSION CONTROL SYSTEM

### 3 Check valve

If air continuity exists when your breath is blown from the port A and no air continuity exists when your breath is blown from the port B, it shows that the check valve is satisfactory.




Fig. 12-47

WA-12061

## CHOKE WARNING SYSTEM




Fig. 12-48

WA-12052

## CHECK

### Choke Warning Lamp and Choke Switch

Disconnect connector.

Ground connector at harness side.

Turn ON engine switch and pull choke switch.

Choke warning lamp should go on




Fig. 12-49

WA-1207



**Water Thermo Switch**

Disconnect connector

Disconnect connector

Ensure that no continuity exists between water thermo switch terminal and earth

Ensure that continuity exists between water thermo switch terminal and earth when water temperature exceeds 70°C (158°F) after engine started




Fig. 12-50

AW-1204

**FUEL CUT SYSTEM DURING DECELERATION**





Fig. 12-51

AW-1205

When the intake manifold negative pressure exceeds the specified pressure, the vacuum switch is turned OFF and the fuel supply is cut.

**OPERATING CONDITIONS OF SYSTEM**

Operation Characteristic of Fuel Cut System During Deceleration



AW-1205B

## EMISSION CONTROL SYSTEM

### SYSTEM CHECK

1. Connect a MityVac to the port S (CB23: Darkblue side, CB61: Skyblue side) of the vacuum switch. Plug the disconnected hose.  
SST: 09258-00030-000
2. Set the engine revolution speed to 2000 rpm by means of the throttle adjusting screw.
3. Apply a negative pressure of at least 675 mmHg to the vacuum switch. If the engine revolution speed drops, it means that the system is functioning properly.
4. Open the port S of the vacuum switch to the atmosphere. If the engine revolution speed rises, it means that the system is functioning properly.




Fig. 12-52

WVA-12657

### UNIT CHECK

#### Solenoid Valve

1. Turn ON the engine switch.
2. Repeat the connection/disconnection of the solenoid valve connector. If you can hear a clicking sound or feel the operation with your hand placed on the solenoid valve, the solenoid valve is satisfactory.




Fig. 12-53

WVA-10659

### VACUUM SWITCH

#### Continuity Check

600 mmHg or less

Between terminals: Continuity must exist.

675 mmHg or more

Between terminals: No continuity must exist.




Fig. 12-54

WVA-20059

## UTER VENT SYSTEM




Fig. 12-55

WM-12051

This outer vent system has been adopted on all vehicles having Australian specifications. The system contributes to the reduction of HC emission.

Fuel evaporative emission which is emitted from the float chamber is sucked by means of the charcoal canister while the engine is stopped.

With the engine switch turned OFF, the outer vent opens the passage. As for the BvSV it opens when the ambient temperature is above 60°C (140°F).

Furthermore, this system has made it easier to restart the engine when the engine is hot.

WM-12051

## EMISSION CONTROL SYSTEM

### UNIT CHECK

#### BVSV

To check air continuity, blow your breath into the BVSV from the hose at the carburetor side.

Ambient Temperature

Below 40 °C ..... No air continuity exists.

Above 60 °C ..... Air continuity exists.




Fig. 12-56

WM-1205

#### Outer Vent Valve

With the engine switch turned ON, disconnect the hose of the BVSV at the carburetor. Blow your breath into the hose from the BVSV side. If no air continuity exists during the test above, but air continuity exists when the engine switch is turned OFF, it indicates a satisfactory operation.

Specified Value

Resistance between Terminals: 36 - 38  $\Omega$

#### CAUTION:

Never attempt to suck the hose during the BVSV and outer vent valve checks, for most likely evaporative gasoline may remain in the nose.



Fig. 12-57

WM-1205

#### Charcoal Canister

Check the charcoal canister for continuity between ports, as follows:

1. Plug the port ① by your finger.
2. When you blow your breath into the canister through the port ②, there should be no air continuity. Also, when you blow your breath strongly into the canister through the port ③, there should be air continuity.
3. While blowing your breath strongly into the canister through the port ②, perform continuity check of the check valve provided at the ports ④ and ⑤, following the procedure given below:
  - (1) When the port ④ is plugged by your finger, air should be discharged from the port ⑤.
  - (2) When the port ⑤ is plugged by your finger, air should be discharged from the port ④.
4. When you blow your breath strongly into the canister through the port ③, air should be discharged from the the port ⑥.




Fig. 12-58

WM-1205

## IGNITION TIMING CONTROL SYSTEM CHECK [CB-23 Engine]




Fig. 12-59

WA-12066

**MAIN SIDE**

Connect a vacuum gauge between the main side of the distributor and the carburetor.

1. If the pointer of the vacuum gauge registers 150 mmHg or less during the idling, it means that the system is functioning properly.
2. Increase the engine speed gradually. If the negative pressure in proportion to the throttle opening is registered, it means that the system is functioning properly.




Fig. 12-60

WA-12066

**SUB SIDE**

1. Connect a vacuum gauge between the sub side of the distributor and the four-way joint.
2. If the vacuum gauge registers the manifold negative pressure (450 mmHg or more) during the idling operation, it means that the system is functioning properly.
3. Increase the engine speed gradually. If the negative pressure in proportion to the throttle opening is registered, it means that the system is functioning properly.




Fig. 12-61

WA-12067

## EMISSION CONTROL SYSTEM

### UNIT CHECK

#### Vacuum Controller

##### 1. Operation Check

- (1) Connect a MityVac to the main chamber or the sub chamber.
- (2) If the breaker plate is sucked with the negative pressure applied, it means that the unit is satisfactory.
- (3) If the breaker plate returns quickly with the negative pressure set to zero, it means that the unit is satisfactory.

##### 2. Diaphragm Air-Tightness Check

If the pointer is stable when a negative pressure of 500 mmHg is applied, the unit is satisfactory.




Fig. 12-62

AM-1008

#### Ignition timing check

1. Disconnect the vacuum hose at the sub side of the distributor. Then, plug the hose

SST: 09258-00030-000

2. Check the ignition timing while the engine is idling, using a timing light.

**Initial Ignition Timing: Manual transmission**

$5^{\circ} \pm 2^{\circ}$ /BTDC 800  $\pm$  50 rpm

Manual transmission

$5^{\circ} \pm 2^{\circ}$ /BTDC 850  $\pm$  50 rpm

Automatic transmission




Fig. 12-63

AM-1008

## IGNITION TIMING CONTROL SYSTEM [CB-61 Engine]




Fig. 12-64

WM-12073

## IGNITION TIMING CONTROL SYSTEM CHECK

1. Connect a vacuum gauge between the vacuum controller of the distributor and the carburetor.
2. If the pointer of the vacuum gauge registers between  $-250$  mmHg and  $-350$  mmHg during the idling, it means that the system is functioning properly.
3. Increase the engine speed gradually. If the negative pressure in proportion to the throttle opening is registered, it means that the system is functioning properly.
4. Disconnect the hose of the vacuum controller and connect the turbocharger pressure gauge into place. Apply a positive pressure up to  $0.5$  kg/cm<sup>2</sup>. If the ignition timing is retarded, it means that the system is functioning properly.




Fig. 12-65

WM-12073

## EMISSION CONTROL SYSTEM

### UNIT CHECK

1. Connect a MityVac or turbocharger pressure gauge to the vacuum controller and apply a negative pressure or positive pressure. If the breaker plate rotates, it means that the unit is functioning properly.
2. If the pointer is stable when a negative pressure of -500 mmHg is applied, it means that the air-tightness is satisfactory.




Fig. 12-66

WA-12072

### CHECK AND ADJUSTMENT OF IGNITION TIMING


1. Disconnect the vacuum hose of the vacuum controller of the distributor. Then, plug the hose  
SST: 09258-00030-000

2. Check the ignition timing during the idling operation, using a timing light.

Initial Ignition Timing:

Ignition timing

$10^{\circ} \pm 2^{\circ}$ /BTDC 800  $\pm$  50 rpm



WA-12073



**DAIHATSU**  
**TYPE CB**  
**ENGINE**

[CB-23, CB-61 & CB-80]

**SECTION 13**  
**APPENDIX**

SST (Special Service Tools) .....	13- 2
SERVICE SPECIFICATIONS .....	13- 5
TIGHTENING TORQUE SPECIFICATIONS FOR MAIN PARTS .....	13-10

472 13001

# APPENDIX

## SST (Special Service Tools)







































Illustration	Tool No.	Tool Name
	09219-87202-000	Engine overhaul stand
	09219-87701-000	Engine overhaul attachment
	09210-87701-000	Flywheel holder
	09515-87202-000	Rear axle bearing inner replacer
	09219-87703-000	Cylinder head holder
	09202-87702-000	Valve spring replacer
	09231-87201-000	Valve guide remover & replacer
	09090-04810-000	Engine sling device
	09618-87301-000	Transmission bearing replacer
	09221-25018-000	Piston pin remover & replacer
	09217-87001-000	Piston replacing guide
	09253-87202-000	Water pump bearing anvil
	09214-87701-000	Balance shaft gear anvil

Illustration	Tool No.	Tool Name
	09215-87701-000	Balance shaft gear bearing remover & replacer
	09506-87303-000	Differential drive pinion front bearing con. replacer
	09608-87301-000	Axle hub & pinion bearing tool set
	09223-87702-000	Oil seal remover & replacer
	09204-87701-000	Valve rocker shaft puller
	09201-87703-000	Valve stem oil seal replacer
	09992-87704-000	Turbocharger pressure gauge
	09248-87703-000	Valve clearance tool
	09842-87704-000	EFI computer check subharness
	09842-30040-000	EFI inspection wire D
	09842-30050-000	EFI inspection wire A
	09258-30030-000	Hose plug set
	09243-00020-000	Idle adjusting wrench

# APPENDIX

Illustration	Tool No.	Tool Name
	09268-87701-000	Fuel pressure gauge
	09286-46011-000	Injection camshaft bearing cone puller
	09285-76010-000	Injection camshaft bearing cone replacer
	09238-87201-000	Water pump bearing remover & replacer
	09237-87201-000	Water pump seal set remover & replacer
	09236-87701-000	Water pump rotor puller
	09254-87201-000	Water pump bearing receiver
	09608-12010-000	Front hub & drive pinion bearing replacer set
	09860-11011-000	Carburetor driver set
	09202-87002-CA0	Valve corler attachment NOTE: Can be used as a set with 09202-87002-000
	09202-87002-000	Valve corler remover & replacer
	09648-87201-000	Drive shaft replacer

vw-13004

## SERVICE SPECIFICATIONS

## CYLINDER HEAD

Item	CB-23 & CB-31 engines		CB-30 engine		Remarks
	Specified value	Allowable limit	Specified value	Allowable limit	
Cylinder head lower gasket surface distortion (mm/inch)	—	0.10 (0.0039)	—	0.10 (0.0039)	On CB-23 engine only recondition can be made, provided that head height limit of 15.7 mm (0.619 inches) is observed.
Manifold gasket surface distortion (mm/inch)	—	0.10 (0.0039)	—	0.10 (0.0039)	Recondition can be made, provided that grinding limit of 0.3 mm (0.012 inch) is not exceeded.
Valve seat	Intake	IN 0.13 (0.0051 - 0.0071)	—	0.2 - 0.6 (0.047 - 0.063)	—
	Exhaust	EX 0.5 (0.039 - 0.071)	—	0.2 - 0.6 (0.047 - 0.063)	—
Seal angle	IN 0°45'30" EX 2°45'30"	—	2°45'30"	—	—
Valve seat recession allowable (mm/inch)	—	IN 0.06 (0.0024) EX 0.007 (0.0005)	—	IN 0.20 (0.0079) EX 0.30 (0.0097)	If limit is exceeded, replace the cylinder head.
Clearance with valve lifter (mm/inch)	—	—	0.015 - 0.046 (0.0006 - 0.0018)	0.01 (0.002)	If limit is exceeded, replace.

NM-13005

## VALVE GUIDE BUSH

Item	CB-23 & CB-31 engines		CB-30 engine		Remarks	
	Specified value	Allowable limit	Specified value	Allowable limit		
Bush bore diameter (mm/inch)	Intake	7.000 - 7.015 (0.2755 - 0.2762)	—	6.010 - 6.025 (0.2366 - 0.2372)	—	
	Exhaust	7.000 - 7.015 (0.2755 - 0.2762)	—	6.010 - 6.025 (0.2366 - 0.2372)	—	
Valve stem-to-bush clearance (mm/inch)	Intake	0.040 - 0.075 (0.00157 - 0.00295)	0.09 (0.00354)	0.025 - 0.060 (0.00099 - 0.00236)	0.08 (0.0031)	If clearance exceeds limit, replace valve guide bush and valve as a set.
	Exhaust	0.040 - 0.075 (0.00157 - 0.00295)	0.10 (0.0039)	0.030 - 0.065 (0.0012 - 0.00256)	0.09 (0.0035)	—

NM-13005

## APPENDIX

### VALVES

Item	CB-23 & CB-61 engines		CB-80 engine		Remarks
	Specified value	Allowable limit	Specified value	Allowable limit	
Seat width mm (inch)	Intake 1.0 - 1.5 (0.039 - 0.070)	—	1.2 - 1.6 (0.047 - 0.063)	—	
	Exhaust 0 - 1.5 (0.000 - 0.070)	—	1.2 - 1.6 (0.047 - 0.063)	—	
Overall length mm (inch)	Intake 101.65 (4.0019)	100.65 (3.970)	107.0 (4.2122)	106.2 (4.1811)	Recondition can be made provided that grinding limit of 0.0 mm (0.001 inch) is not exceeded.
	Exhaust 101.65 (4.0119)	100.65 (3.970)	107.2 (4.2204)	106.4 (4.1890)	
Valve stem outer diameter mm (inch)	Intake 6.945 - 6.960 (0.2734 - 0.2740)	—	6.970 - 6.985 (0.2750 - 0.2756)	—	
	Exhaust 6.940 - 6.955 (0.2732 - 0.2736)	—	6.960 - 6.980 (0.2736 - 0.2751)	—	
Valve head stock thickness mm (inch)	Intake —	0.8 (0.031)	—	0.7 (0.028)	If thickness becomes less than limit, replace valve.
	Exhaust —	1.0 (0.039)	—	0.8 (0.031)	

WM-13007

### VALVE SPRING

Item	CB-23 & CB-61 engines		CB-80 engine		Remarks
	Specified value	Allowable limit	Specified value	Allowable limit	
Out-of-squareness (under free state) mm (inch)	—	1.5 (0.059)	—	1.5 (0.059)	If limit is exceeded, replace.
Free length mm (inch)	43.2 (1.705)	42.7 (1.681)	45.9 (1.807)	44.5 (1.752)	If length becomes less than limit, replace.
Spring tension as installed kg/mm (lb/inch)	26.7 (24.9 156.7) (1.374)	22.7 (24.5 150.1) (1.374)	40.4 (27.67 189.1) (1.09)	34.4 (27.67 175.2) (1.09)	If tension drops below limit, replace.

WM-13008

### VALVE ROCKER SHAFT & ROCKER ARM [CB-23 & CB-61 Engines]

Item	CB-23 & CB-61 engines		Remarks
	Specified value	Allowable limit	
Rocker arm bore diameter mm (inch)	16.000 - 16.016 (0.629 - 0.630)	16.06 (0.632)	If bore exceeds limit, replace.
Rocker shaft outer diameter mm (inch)	15.958 - 15.984 (0.628 - 0.629)	15.93 (0.627)	If outer diameter becomes less than limit, replace.
Shaft-to-arm clearance mm (inch)	0.016 - 0.060 (0.0006 - 0.0024)	0.09 (0.0035)	If clearance exceeds limit, replace.

WM-13009

## CYLINDER BLOCK

Item	CB-23 & CB-61 engines		CB-80 engine		Remarks	
	Specified value	Allowable limit	Specified value	Allowable limit		
Top gasket surface distortion mm (inch)		1.1 (0.039)		0.1 (0.039)	On CB-23 engine only, replacement can be made provided that block height limit of 200.50 mm (7.896 inches) is assured.	
Cylinder bore	Cylinder-to-rod clearance mm (inch)	0.025 - 0.055 (0.0014 - 0.0022)	0.12 (0.0047)	0.045 - 0.065 (0.0018 - 0.0026)	0.12 (0.0047)	If limit is exceeded, recondition.
	Out-of-roundness, taper mm (inch)	—	0.1 (0.039)	—	0.1 (0.039)	If limit is exceeded, recondition.

WMI-10010

## PISTON, PISTON PIN &amp; PISTON RINGS

Item	CB-23 & CB-61 engines		CB-80 engine		Remarks		
	Specified value	Allowable limit	Specified value	Allowable limit			
Piston-to-cylinder clearance mm (inch)	0.025 - 0.055 (0.0014 - 0.0022)	0.12 (0.0047)	0.045 - 0.065 (0.0018 - 0.0026)	0.12 (0.0047)	If limit is exceeded, recondition.		
Piston ring	End gap mm (inch)	Compression No. 1	0.20 - 0.40 (0.0073 - 0.0157)	0.7 (0.0276)	0.35 - 0.45 (0.0138 - 0.0177)	0.7 (0.0276)	If limit is exceeded, replace rings as a set.
		Compressor No. 2	0.20 - 0.35 (0.0078 - 0.0136)	0.7 (0.0276)	0.25 - 0.40 (0.0110 - 0.0157)	0.7 (0.0276)	
		Oiling	0.20 - 0.30 (0.0079 - 0.0115)	1.1 (0.0433)	0.20 - 0.70 (0.0079 - 0.0276)	1.1 (0.0433)	
Piston ring	Side Clearance mm (inch)	Compression No. 1	0.03 - 0.07 (0.0012 - 0.0028)	0.12 (0.0047)	0.05 - 0.09 (0.0020 - 0.0035)	0.12 (0.0047)	If limit is exceeded, replace.
		Compressor No. 2	0.02 - 0.05 (0.0012 - 0.0024)	0.12 (0.0047)	0.02 - 0.06 (0.0008 - 0.0024)	0.12 (0.0047)	
		Oiling (reference)	0.01 - 0.03 (0.0004 - 0.0012)	—	0.01 - 0.03 (0.0004 - 0.0012)	—	
Piston-to-piston pin oil clearance mm (inch)	—	0.030 (0.0012)	—	0.030 (0.0012)	If clearance exceeds limit, replace piston and piston pin as a set.		

WMI-10011

## CONNECTING ROD

Item	CB-23 & CB-61 engines		CB-80 engine		Remarks
	Specified value	Allowable limit	Specified value	Allowable limit	
Bearing oil clearance mm (inch)	0.020 - 0.044 (0.0008 - 0.0017)	0.07 (0.0028)	0.024 - 0.048 (0.0009 - 0.0019)	0.07 (0.0028)	
Big end thrust clearance mm (inch)	(CB-23) 0.15 - 0.25 0.0059 - 0.0099; (CB-61) 0.15 - 0.30 0.0059 - 0.0130	(CB-23) 0.30 (0.0118); (CB-61) 0.33 (0.0149)	0.15 - 0.40 (0.0059 - 0.0157)	0.45 (0.0177)	
Allowable limit of connecting rod	Bend	—	0.05 (0.002)	0.05 (0.002)	If limit is exceeded, replace.
	Twist	—	0.05 (0.002)	0.05 (0.002)	

WMI-10012

## APPENDIX

### CRANKSHAFT

Item	mm (inch)	CB-23 & CB-51 engines		CB-60 engine		Remarks
		Specified value	Allowable limit	Specified value	Allowable limit	
Crankshaft runout	mm (inch)	—	0.05 (0.002)	—	0.05 (0.002)	If runout exceeds limit, replace
Out-of-roundness of main bearing and crankpin journals	mm (inch)	—	0.01 (0.0004)	—	0.01 (0.0004)	If out-of-roundness exceeds limit, machine
Main bearing cumulative diameter	mm (inch)	41.975 - 42.000 (1.6522 - 1.6535)	—	41.975 - 42.000 (1.6522 - 1.6535)	—	
Crankpin journal outer diameter	mm (inch)	39.975 - 40.000 (1.5739 - 1.5748)	—	42.975 - 43.000 (1.6920 - 1.6929)	—	
Main bearing journal clearance	mm (inch)	0.020 - 0.044 (0.00079 - 0.00173)	0.01 (0.00079)	0.020 - 0.044 (0.00079 - 0.00173)	0.01 (0.00079)	If limit is exceeded, crankpin and/or bearing must be reconditioned
Thrust clearance	mm (inch)	0.001 - 0.022 (0.000079 - 0.00087)	0.00 (0.000079)	0.002 - 0.021 (0.000079 - 0.00087)	0.00 (0.000079)	If clearance exceeds limit, replace thrust washer as required

49A-1014

### BALANCE SHAFT

Item	mm (inch)	CB-23 & CB-51 engines		CB-60 engine		Remarks
		Specified value	Allowable limit	Specified value	Allowable limit	
Thrust clearance	mm (inch)	0.03 - 0.13 (0.0012 - 0.0051)	0.20 (0.0079)	0.03 - 0.13 (0.0012 - 0.0051)	0.20 (0.0079)	If clearance exceeds limit, replace thrust washer
Bearing bore diameter	Front bearing	45.000 - 45.025 (1.7717 - 1.773)	—	45.000 - 45.025 (1.7717 - 1.773)	—	
	Rear bearing	34.000 - 34.025 (1.3389 - 1.340)	—	34.000 - 34.025 (1.3389 - 1.340)	—	
Shaft outer diameter	Front section	34.959 - 34.975 (1.3717 - 1.3711)	—	44.959 - 44.975 (1.7700 - 1.7711)	—	
	Rear section	33.959 - 33.975 (1.3357 - 1.335)	—	33.959 - 33.975 (1.3357 - 1.336)	—	
Oil clearance	mm (inch)	0.025 - 0.066 (0.0010 - 0.0026)	0.1 (0.0039)	0.025 - 0.066 (0.0010 - 0.0026)	0.1 (0.0039)	If clearance exceeds limit, replace bearing

49A-1014

### FLYWHEEL

Item	mm (inch)	CB-23 & CB-51 engines		CB-60 engine		Remarks
		Specified value	Allowable limit	Specified value	Allowable limit	
Flywheel runout limit	mm (inch)	—	0.10 (0.0039)	—	0.10 (0.0039)	If runout exceeds limit, replace flywheel

49A-1015



## NIFOLD

Item	CB-23 & CB-61 engines		CB-80 engine		Remarks
	Specified value	Allowable limit	Specified value	Allowable limit	
Gasket surface warpage mm (inch)	Intake side	—	0.10 (0.0039)	—	If warpage exceeds limit recondition can be made provided that grinding limit of 0.3 mm (0.012 inch) is not exceeded.
	Exhaust side	—	0.10 (0.0039)	—	

WA-1015

## CAMSHAFT

Item	CB-23 & CB-61 engines		CB-80 engine		Remarks
	Specified value	Allowable limit	Specified value	Allowable limit	
Cam lobe height mm (inch)	Intake side [CB-23] 39.087 - 40.187 (1.574 - 1.582) [CB-61] 39.937 - 40.137 (1.572 - 1.580)	39.8 (1.567)	39.55 - 39.65 (1.567 - 1.561)	39.4 (1.551)	If lobe height becomes less than limit, replace camshaft.
	Exhaust side [CB-23] 39.087 - 40.187 (1.574 - 1.582) [CB-61] 39.937 - 40.137 (1.572 - 1.580)	39.8 (1.567)	39.15 - 39.25 (1.541 - 1.545)	39.0 (1.535)	
Fucul mm (inch)	—	0.03 (0.0012)	—	0.03 (0.0012)	If runout exceeds limit, replace camshaft.
Oil clearance mm (inch)	Front section	0.04 - 0.09 (0.0016 - 0.0035)	0.14 (0.0055)	—	If clearance exceeds limit, replace camshaft or cylinder head.
	Center section	0.09 - 0.14 (0.0035 - 0.0055)	0.19 (0.0075)	—	
	Rear section	0.06 - 0.11 (0.0024 - 0.0043)	0.16 (0.0063)	—	
	No. 1 - No. 2	—	—	0.025 - 0.066 (0.0010 - 0.0026)	
Clearance in axial direction mm (inch)	—	—	—	0.20 (0.0079)	If clearance exceeds limit, replace camshaft.

WA-1017

## TIMING BELT PULLEY

Item	CB-23 & CB-61 engines		CB-80 engine		Remarks
	Specified value	Allowable limit	Specified value	Allowable limit	
Camshaft timing pulley outer diameter mm (inch)	119.98 - 120.40 (4.7169 - 4.7401)	119.8 (4.7165)	119.837 - 119.757 (4.7166 - 4.7168)	119.6 (4.7342)	If diameter becomes less than limit, replace pulley.
Crankshaft timing pulley outer diameter mm (inch)	59.28 (2.3331)	59.2 (2.3307)	54.651 - 54.751 (2.1516 - 2.1555)	54.6 (2.1496)	

WA-1018

## APPENDIX









### TIGHTENING TORQUE SPECIFICATIONS FOR MAIN COMPONENTS

1. When you want to find out suitable tightening torque for a bolt, first determine the strength division of the said bolt, using the table below. Then, locate suitable tightening torque in the tightening torque table described in the following pages.
2. As for the tightening torque for a nut, find out suitable tightening torque in the same way as with Paragraph 1 above, based on the mating bolt.
3. Tightening torque specifications posted in the workshop manual are standard values for steel fasteners. It is therefore, necessary to modify these tightening torque specifications when you tighten fasteners made of materials other than steel. This rule also applies to such instances where bolts are undergoing heat or other stress, such as vibratory loads and so forth.

WM-13019





#### METHOD TO IDENTIFY STRENGTH DIVISION OF BOLTS

##### 1. Identification Method by Checking Bolts Themselves

	Configuration and how to determine strength division	Strength division		Configuration and how to determine strength division	Strength division	
Hexagon bolt	 Bolt having an embossed or stamped figure at its head section	4 = 4T 5 = 5T 6 = 6T 7 = 7T	Welded bolt		4T	
	 No mark	4T			No mark	4T
	 Bolt having two embossed lines at its head section	5T 6T	Stud bolt		Bolt having about 2 mm deep recess at one end or both ends	6T
	 Bolt having three embossed lines at its head section	7T				

WM-13017

##### 2. Identification Method by Part Numbers

<p><b>Hexagon Bolt</b></p> <p>Part number example 9 1 1 1 1 - 4 0 6 2 0</p> <p>  </p> <p>  </p>	<p><b>Stud Bolt</b></p> <p>Part number example 9 2 1 3 2 - 4 0 6 2 2</p> <p>  </p> <p>  </p>
---	---

WM-13021

T. Tightening Torque Table for General Standard Bolts

Category	Nominal diameter	Pitch	Standard tightening torque		
			kg-m (ft-lb)		
			Standard torque	Tightening range	
4T (Bolt having a mark of "4" at its head section) Example of part number (91000 - 400000)	6	1	0.47 ( 3.4)	0.4 - 0.7	2.9 - 5.1
	8	1.25	1.11 ( 8.0)	1.0 - 1.5	7.2 - 11.6
	10	1.25	2.25 (16.3)	1.9 - 3.1	14 - 22.5
	10	1.5	2.14 (15.5)	1.8 - 3.0	12 - 22
	12	1.25 (ISO)	4.40 (31.8)	3.5 - 5.5	25 - 40
	12	1.5	3.89 (28.1)	3.5 - 5.5	25 - 40
	12	1.75	3.74 (27.1)	3.0 - 5.0	22 - 36
	12	1.5	5.08 (36.7)	4.5 - 7.0	33 - 51
	14	1.5	5.33 (45.2)	5.0 - 8.0	36 - 56
	14	2	5.52 (42.9)	4.7 - 7.7	34 - 56
5T (Bolt having a mark of "5" at its head section) Example of part number (91000 - 500000)	6	1	0.71 ( 5.1)	0.6 - 0.9	4.3 - 6.5
	8	1.25	1.66 (12.0)	1.5 - 2.2	11 - 16
	10	1.25	3.37 (24.4)	3.0 - 4.5	22 - 33
	10	1.5	3.20 (23.1)	2.7 - 4.2	19.5 - 30.5
	12	1.25 (ISO)	5.84 (42.2)	5.0 - 7.0	36 - 51
	12	1.5	5.84 (42.2)	5.0 - 7.0	36 - 51
	12	1.75	5.60 (40.5)	4.6 - 6.6	34 - 45
	12	1.5	7.63 (55.2)	6.5 - 9.0	47 - 65
	14	1.5	9.50 (68.7)	7.5 - 11.0	54 - 79.5
	14	2	8.90 (64.4)	7.0 - 10.5	51 - 76
6T (Bolt having a mark of "6" at its head section) Example of part number (91000 - 600000)	6	1	0.71 ( 5.1)	0.6 - 0.9	4.3 - 6.5
	8	1.25	1.66 (12.0)	1.5 - 2.2	11 - 16
	10	1.25	3.37 (24.4)	3.0 - 4.5	22 - 33
	10	1.5	3.20 (23.1)	2.7 - 4.2	19.5 - 30.5
	12	1.25 (ISO)	5.84 (42.2)	5.0 - 7.0	36 - 51
	12	1.5	5.84 (42.2)	5.0 - 7.0	36 - 51
7T (Bolt having a mark of "7" at its head section) Example of part number (91000 - 700000)	8	1	0.95 ( 6.87)	0.8 - 1.2	5.3 - 8.7
	8	1.25	2.20 (15.9)	2.0 - 3.0	14.5 - 22
	10	1.25	4.50 (32.5)	4.0 - 5.5	29 - 40
	10	1.5	4.30 (31.1)	3.7 - 5.2	27 - 38
	12	1.25 (ISO)	7.78 (56.3)	7.0 - 9.0	51 - 65
	12	1.5	7.78 (56.3)	7.0 - 9.0	51 - 65
	12	1.75	7.48 (54.1)	6.0 - 8.5	43 - 61.5
	12	1.5	10.17 (73.6)	8.0 - 12.0	56 - 86
	14	1.5	12.67 (91.6)	10.0 - 15.0	72 - 108
	14	2	11.66 (85.8)	9.5 - 14.0	69 - 101
16	1.5	19.15 (138.5)	16.0 - 23.0	108 - 166	
	2	18.11 (131.0)	14.9 - 22.0	108 - 159	

www.ks29

**APPENDIX**

Unit: kg-m (ft.)

Tightening component	Tightening torque	
	CB-23 & CB-61 engines	CB-80 engine
Cylinder block x Cylinder head	5.5 - 6.5 (40 - 47 )	6.0 - 7.0 (43 - 51 )
Cylinder block x Crankshaft bearing cap	5.4 - 6.6 (40 - 48 )	6.4 - 7.6 (46 - 55 )
Spark plug x Cylinder head	1.5 - 2.2 (11 - 16 )	1.5 - 2.2 (11 - 16 )
Flywheel x Crankshaft	4.0 - 5.0 (29 - 36 )	6.0 - 7.0 (43 - 51 )
Crankshaft pulley x Crankshaft	9.0 - 10.0 (65 - 72 )	9.0 - 10.0 (65 - 72 )
Connecting rod x Connecting rod cap	2.1 - 2.9 (15 - 21 )	4.2 - 5.2 (30 - 38 )
Balance shaft (nut) plate x Cylinder block	1.0 - 1.5 (7 - 11 )	1.0 - 1.5 (7 - 11 )
Cylinder head cover x Cylinder head	0.8 - 1.2 (6 - 9 )	0.3 - 0.5 (2 - 4 )
Fuel pipe x Carburetor	1.5 - 2.0 (11 - 14 )	—
Oil pan drain plug x Oil pan	2.5 - 3.5 (18 - 25 )	2.5 - 3.5 (18 - 25 )
Fuel pump drive cam x Camshaft (CB-23 engine only)	1.0 - 1.5 (7 - 11 )	—
Timing belt cover x Balance shaft gear cover	0.2 - 0.4 (1.4 - 3.0)	0.2 - 0.4 (1.4 - 3.0)
Fuel pipe x Fuel pump (CB-23 engine only)	1.5 - 2.2 (11 - 16 )	—
Oil cooler x Oil filter bracket	3.0 - 4.0 (22 - 29 )	3.0 - 4.0 (22 - 29 )
Camshaft bearing cap x Cylinder head	—	1.15 - 1.45 (8.3 - 10.5)
Camshaft timing belt pulley x Camshaft	3.0 - 4.5 (22 - 32 )	3.0 - 4.5 (22 - 32 )
Timing belt idler No.2 x Cylinder head	—	4.0 - 5.0 (29 - 36 )
Cylinder block x Oil pan	0.4 - 0.7 (3.0 - 5.0)	0.4 - 0.7 (3.0 - 5.0)
Valve adjusting screw x Lock nut	1.3 - 1.8 (9 - 13 )	—
Exhaust manifold case No.1 x Exhaust manifold case No.2	2.0 - 3.0 (14 - 22 )	2.0 - 3.0 (14 - 22 )
Turbocharger x Exhaust manifold	2.5 - 3.3 (18 - 24 )	2.5 - 3.3 (18 - 24 )
Turbocharger x Exhaust manifold case No.1	3.0 - 4.0 (22 - 29 )	2.5 - 3.3 (18 - 24 )
Turbo oil inlet pipe S/A x Turbocharger	1.0 - 1.6 (7 - 12 )	1.0 - 1.6 (7 - 12 )
Cylinder head x Exhaust manifold	1.0 - 1.6 (7 - 12 )	4.0 - 5.0 (29 - 36 )
Cylinder head x Intake manifold	1.0 - 1.6 (7 - 12 )	1.7 - 2.5 (12 - 18 )
Intake manifold x Surge tank	—	3.5 - 4.5 (25 - 33 )
Oil nozzle Ay x Oil pump Ay	—	3.0 - 3.5 (22 - 25 )
Carburetor x Surge tank stud bolt (CB-61 engine only)	0.8 - 1.2 (6 - 9 )	—
Carburetor x Surge tank cap nut (CB-61 engine only)	0.8 - 1.0 (6 - 7 )	—

4V-13323

## APPENDIX

Unit: kg-m (ft-lb)

Tightening component	Tightening torque	
	CB-23 & CB-61 engines	CB-80 engine
EGR pipe No.1 x EGR valve (Swiss specifications only)	4.8 - 7.2 (35 - 52)	—
EGR pipe No.2 x EGR valve (Swiss specifications only)	3.6 - 5.4 (26 - 39)	—
EGR pipe No.2 x Intake manifold	4.4 - 6.6 (32 - 48)	—
Fuel pipe No.2 x Delivery pipe	—	1.2 - 1.8 (9 - 13)
Fuel pipe No.2 x SAGE link	—	1.2 - 1.8 (9 - 13)
Fuel hose No.1 x Delivery pipe	—	3.5 - 4.5 (25 - 33)
Heat insulator No.2 x Exhaust manifold base No.2	—	1.5 - 2.2 (11 - 16)
Engine mounting rear right bracket x Cylinder block	4.5 - 6.5 (33 - 47)	4.5 - 6.5 (33 - 47)
Engine lower mounting member S/A x Cylinder block	5.0 - 7.0 (36 - 51)	5.0 - 7.0 (36 - 51)
Engine lower member S/A x Engine mounting front stopper	7.5 - 10.5 (54 - 76)	7.5 - 10.5 (54 - 76)
Engine mounting upper right insulator x Engine mounting front bracket	4.0 - 5.5 (29 - 40)	4.0 - 5.5 (29 - 40)
Engine mounting upper right insulator x Body	7.5 - 10.5 (54 - 76)	7.5 - 10.5 (54 - 76)
Engine mounting lower left bracket x Engine mounting over left	7.5 - 10.5 (54 - 76)	7.5 - 10.5 (54 - 76)

100-11024

