

**THIS MANUAL COVERS ALL MODELS OF 1991 TO 1993 164 VEHICLES WITH THE EXCEPTION OF 28 EARLY PRODUCTION ELECTRICAL CIRCUITS ON 1991 MODELS PRODUCED BEFORE JULY 1, 1990.**

**FOR THOSE 28 ELECTRICAL CIRCUITS ON VEHICLES PRODUCED BEFORE JULY 1, 1990, SEE "EARLY PRODUCTION" WIRING DIAGRAMS AND ELECTRICAL DIAGNOSIS MANUAL.**

## **WIRING DIAGRAMS AND ELECTRICAL DIAGNOSIS MANUAL**

---

# **1991-1993**

**164 ALL MODELS**

**50 STATE  
AND  
CANADA VERSIONS**



**ALFA ROMEO DISTRIBUTORS  
OF  
NORTH AMERICA**

## FOREWORD

The following manuals provide all electrical and electronic information for 1991 164 vehicles produced for the USA and Canada:

-for vehicles produced before July 90=PA4596B (VOLUME 1), and  
PA4596C (VOLUME 2);

-for vehicles produced after 1 July 90=PA4596B (VOLUME 1) only.

This manuals will supply service technicians the information necessary to provide timely and precise repairs.

This manuals contain wiring diagrams, functional descriptions, connector drawings, and "ghost" illustration designed to help locate components on the vehicle being repaired.

Troubleshooting procedures are located at the end of each subject section that provide a specific series of test steps to enabled even an unfamiliar technician to quickly repair almost any electrical problem.

Information detailing basic electrical testing techniques and cautions can be found in the introduction chapter. This should be read before using this manual.

For information not covered in this manual, refer to the appropriate chapter of the designated SERVICE MANUAL.

All information contained in this manual refers to the latest data available at the time of print. Alfa Romeo reserves the right to make changes in design, or additions to, or improvements in its products at any time without notice.

Any of the above mentioned changes will be covered in an updated issue of this manual.

*Alfa Romeo* 



## TABLE OF CONTENTS

INTRODUCTION .....	VII
GENERAL PRECAUTIONS AND ACCIDENT PREVENTION WARNINGS .....	VII
ABBREVIATIONS.....	VII
HOW TO USE THIS MANUAL .....	VIII
WIRING DIAGRAMS .....	X
WIRES IDENTIFICATION .....	XI
ELECTRIC COMPONENTS.....	XII
OPERATIONAL DESCRIPTIONS .....	XV

## ELECTRICAL SYSTEM SUBJECT LIST

In order to ease the consultation, the subjects contained in this publication are enclosed in alphabetic order as follows:

SUBJECT	PAGE NUMBER
— ABS brake system .....	1
— Air Bag .....	19
— Air conditioning system.....	47
— Alarm - - electronic anti-theft system .....	89
— Buzzer .....	109
— Cigarette lighters - - front and rear.....	121
— Controlled damping suspensions (S only) .....	133
— Cruise control .....	165
— Defogger - - rear window, front windshield, external mirrors .....	185
— ECU - - power supply relay .....	201
— FAN - - automatic transmission oil cooler .....	209
— FAN - - radiator cooling and A/C condenser.....	217
— Foglamps - - front and rear (for USA version only).....	227

SUBJECT	PAGE NUMBER
— Fuel door - - electric opening .....	245
— Fuse box .....	257
— Grounds .....	265
— Instrument panel - - Alfa Romeo Control ECU Interface .....	291
— Instrument panel - - indicator circuits .....	301
— Instrument panel - - internal wiring .....	337
— Lamps - - brake .....	341
— Lamps - - door opening indicator .....	363
— Lamps - - ground illumination, door open, trunk lighting .....	385
— Lamps - - low beam and high beam (for USA version only) .....	413
— Lamps - - miscellaneous dome .....	433
— Lamps - - position, side marker license plate illumination (for USA version only) .....	495
— Lamps - - reverse and gear selector illumination .....	521
— Lamps - - turn signal and hazard warning .....	533
— Locks - - power door .....	565
— Mirrors - external power .....	583
— Motronic ML4.1 .....	595
— Power distribution .....	631
— Radio .....	639
— Seats - - heater .....	659
— Seats - - power adjustable .....	677
— Sensors - - brake fluid level, windshield washer fluid level, parking brake warning lights .....	709
— Sensors - - brake pad wear, engine coolant level, maximum coolant temperature .....	729
— Sensors - - engine oil minimum level, engine oil minimum pressure, automatic transmission maximum temperature, test pushbutton .....	747
— Starting and charging .....	765
— Sun roof .....	777
— Switch - - neutral safety (automatic transmission only) .....	785
— Telephone .....	793
— Trunk - - electric opening .....	803
— Windows - - electric opening .....	813
— Wipers and horns - - windshield wipers/washers, head lamp washers, horns .....	837

Moreover, the complete key to electrical components is reported at the end of this manual at page 951.

---

**ELECTRICAL SYSTEM SUBJECT LIST  
FOR CANADA VERSION ONLY**

SUBJECT	PAGE NUMBER
— Foglamps - - front and rear .....	861
— Lamps - - low beam and high beam .....	885
— Lamps - - position, side marker, license plate illumination .....	913

Moreover, the complete key to electrical components is reported at the end of this manual at page 951.

## INTRODUCTION

This manual contains necessary information about the theory of operation of the vehicle's electrical systems to help the operator in troubleshooting these systems. For a better understanding, a wiring diagram and a separate operational description is provided for each electrical sub-system (ignition-injection, low/high beam lamps, anti-theft, etc.). In addition, a troubleshooting table is provided for each sub-system, in which the most likely failures and relevant corrective actions are presented.

## GENERAL PRECAUTIONS AND ACCIDENT-PREVENTION WARNINGS

Before attempting any activity on the electrical system, adopt the following precautions.

- Wear-off rings and wrist watch.
- Disconnect one battery lead if any electrical component has to be removed.
- If any component needs replacement, use only genuine Alfa Romeo spare parts.

When acting on vehicle's electrical system, never pull abruptly wires connected to connectors to prevent interruption of cables. Disconnect all electronic control units before performing arc welding on vehicle.

### Short circuit warning

Although the electric system is only 12V, the high battery capacity could cause very high currents in the case of a short circuit, and subsequent sparks or electric arcs that could burn the operator or start fires.

### High voltage warning

The electronic ignition system generates greater than 20,000V and could be fatal to people suffering from heart diseases or using a pacemaker.

Proceed with caution when acting on, or in the proximity of the ignition system.

### Fire hazard warning

Never smoke when recharging the battery or when working on the vehicle to prevent accidental fires.

### High temperatures warning

If it is necessary to work on vehicle components that operate at high temperatures (halogen lamps), or in the engine compartment for inspections or replacement of parts, avoid direct contact with hot components. If not otherwise stated, turn off the relevant electrical systems and/or shut down the engine and wait until cool.

### Air Bag warnings

The vehicle is provided with an inflatable Air Bag safety device; always observe the following precautions:

- Always fasten seat belts. The system must inflate quickly to help protect the driver, and the inflation force could cause further injuries if the driver is too close to (or against) the steering wheel when the air bag inflates.
- Do not place any object on the steering wheel surface that could be projected by the inflation charge and cause severe injuries.
- The system has been designed to be actuated only once; after actuation, the system must be replaced.
- When working on any electrical system in the air bag deployment zone (driver's seat area), disconnect the battery and remove the air bag module from the steering wheel. You may then reconnect the battery and proceed with electrical diagnosis. (See air bag section for air bag module removal and air bag warning code reset instructions).
- Never allow children to sit in the driver's seat even when the vehicle is stopped; accidental actuation of the air bag system could cause them severe injuries.

## ABBREVIATIONS

The following abbreviations have been used throughout this manual:

- ABS Anti-lock Brake System
- L.H Left hand
- R.H Right hand
- N.C. Normally Closed
- N.O. Normally Open

**HOW TO USE THIS MANUAL**

All information concerning each electrical system has been grouped in single subsections all structured in the same way.

The information contained in each subsection is presented in the following order:

- Wiring diagram (on first reverse page of section - see sample page A).

- General information, operational description and troubleshooting table, (in diagrams featuring more than one fault) (on right hand page facing the wiring diagram - see sample page B).


- List of electrical connectors used in the subject circuit (see sample page C).

- Schematic diagram of circuit (on page facing connectors list - see sample page D).

**WIRING DIAGRAMS**

**OPERATIONAL DESCRIPTION**

**A** CIGARETTE LIGHTERS - FRONT AND REAR



**B** CIGARETTE LIGHTERS - FRONT AND REAR

**GENERAL**

The car is provided with two cigar lighters respectively located inside the front and rear ashtrays. The cigar lighters are illuminated when the parking lights are turned on. To activate the lighters, push the center of the lighter; after a few seconds the lighter will pop out, ready for use. The system is protected by three fuses in the fuse box, G1, as follows:

- F1 fuse (15A) FRONT LIGHTER
- F13 fuse (10A) REAR LIGHTER
- F2 fuse (7.5A) FRONT AND REAR LIGHTER INDICATOR LAMPS

**OPERATIONAL DESCRIPTION**

12V from the battery is applied to one of the two terminals of front lighter O6 through the fuse F1. The rear lighter O7 is energized through the fuse F13 only when the ignition key is set to "Run". Both O6 and O7 lighters are provided with an indicator light which is actuated by the parking lights control unit M41 when the parking lamps are turned on. The circuit of the indicator lights is protected by the fuse F2. The second terminal of the front and rear lighters is connected respectively to the ground points G174 and G182 by means of jumpers. Pressing the center of the lighter which is intended for use, connects to ground the respective jumper, thus allowing warming of the lighter.

**TROUBLESHOOTING TABLE**

FAULT TYPE	FAULT COMPONENT					
	F1	F13	F2	O6	O7	M41
FRONT LIGHTER NONOPERATIVE	•			•		
REAR LIGHTER NONOPERATIVE		•			•	
LIGHTER ILLUMINATION NONOPERATIVE	•		•			•



- Test-type troubleshooting procedures (on subsequent pages).

When the wiring diagram is laid down on two pages, a blank page is inserted so that the relevant description (generality) will be on a right-hand page. This is also applied to the text: should a subject end on a right-hand page, a blank page is added so that the subsequent subject will start on a right-hand page. To make consultation easy, the sub-sections have been arranged in alphabetical order.

The circuit title is indicated at the top of each page. A legend of all the system electrical components is

included at the end of this manual; the components are grouped according to their function and listed in alphabetical order.

Each component reports the reference to the Service Manual, for an easier component location on the vehicle, except for the junctions, for which reference to the vehicle schematic diagram must be made.

**NOTE**


Two wiring diagrams illustrate the printed circuit of the instrument panel and of the fusebox. These wiring diagrams are presented on two pages.

**LIST OF ELECTRICAL CONNECTORS**

C

CIGARETTE LIGHTERS - FRONT AND REAR

184




124

**SCHEMATIC DIAGRAM OF CIRCUIT**

D

CIGARETTE LIGHTERS - FRONT AND REAR



125

## WIRING DIAGRAMS

The wiring diagrams are presented from the functional point of view, to ease identification of any failure that could arise. The wiring diagrams must be read from top to bottom; therefore, the power supply point (start point of circuit) is always located in the upper part of the diagram. For complex wiring diagrams, the diagrams are presented on two sheets; in this case the function flow is from left to right. Power supply is presented on wiring diagrams with four different denominations, depending on positioning of the ignition key:

**HOT AT ALL TIMES:** relevant circuits are continuously powered, even when the key is out of the ignition.

**HOT IN PARKING:** relevant circuits are powered when the ignition key has been turned off and left in the ignition switch.

**HOT IN RUN:** relevant circuits are powered when the ignition key is turned to the RUN position.

**HOT IN START:** relevant circuits are powered when the ignition key is turned to the START position (without mechanical detent); when in this position, activation of the engine starter and momentary de-energization of some circuits to prevent and excessive drainage of battery voltage. Power supply of the various circuits are shown in two power distribution diagrams, also the ignition switch and the electronic control unit power supply relay are illustrated in detail.

The fuse box is never presented in total in the wiring diagrams; complete fuse box wiring diagrams are presented only in the general wiring. Therefore, refer to this diagram if it is necessary to know the actual inner connections of the fuse box.

Each component is identified with an alphanumeric code (e.g. A10); the initial letter identifies the type of component, as indicated below:

- A Starting-charging
- B Manual electric controls
- C Instruments
- D Warning lamps
- E Exterior lights
- F Interior lights
- G Fuse box-connectors-ground connections
- H Switches
- I Relays
- L Transmitters
- M Solenoids- solenoid valves

- N Electronic units, intermittent relays, timers
- O Auxiliary equipment
- P Electric motors
- Q Heat /vent/air conditioning
- R Safety devices
- S Electronic fuel injection
- T Diagnosis

To easily distinguish connectors from components, component codes on wiring diagrams are enclosed in an ellipse, while connector codes are underlined. Components which are part of the subject being treated are always presented in the "OFF" position from a functional point of view, unless otherwise specified. In particular, relays are always represented in a de-energized condition, and switches in N.C. or N.O. condition in relation to their function in the wiring diagram. A dashed line square around a component indicates that component is partially presented in the wiring diagram, and the component is involved and described in several other electric functions. The wiring diagrams also contain references to other diagrams that allow cross referencing the wiring diagrams of the complete vehicle; two type of references can be found:

- Continuous wire: connection between one wiring diagram and another is bridged on a component.
- Dashed wire: connection between one wiring diagram and another is wire-to-wire.

The only exception regarding references to other wiring diagrams concerns the electronic units power supply relay I51. On wiring diagrams where this relay is illustrated, only the wiring diagram of the function being examined is referred to. All systems whose power supply depends on energization of relay I51 are indicated in the relay I51 wiring diagram. All ground points are presented in the lower part of the wiring diagram, except where the complexity of the illustration demands a different solution. Each ground point presented in the wiring diagram is described in a relevant illustration which indicates all circuits connected. Adequate knowledge of all circuits connected to the same ground point facilitates troubleshooting of failures affecting simultaneously all circuits connected to that ground point. Connection of all ground points pertaining to the engine with ground points connected to the vehicle frame is performed by

means of ground straps.

These strips connect the vehicle's frame (front L.H. fender-well) to the engine (gearbox).

Wiring diagrams are presented for both automatic and manual transmission vehicles. In case of differences between the harness of the two versions, the wiring diagram shows with solid lines the circuit relevant to the automatic gear, and with dashed lines the circuit relevant to manual gear. Another type of dashed line has been used to high light specific changes for "S" version (refer to the electric symbols table).

## WIRE IDENTIFICATION

Each wire presented in the wiring diagrams is provided with a code consisting of letters and numbers (e.g. 1 WHT).

The number identifies the size of wire (cross section of wire is 0.5 sq. mm when not indicated). The letters identify the wire color. The color code is abbreviated for ease of presentation. The table below lists conversion values of wire size from metric system to american system, and color codes.

WIRE SIZE CONVERSION TABLE	
METRIC (CROSS SECTION AREA) (SQ. MM.)	AWG (AMERICAN WIRE GAUGE)
0.5	20
0.75	18
1	16
1.5	14
2	14
2.5	12
4	10
6	8
8	8
16	4
20	4
25	2
32	2

WIRE COLOR	
ABBREVIATION	COLOR
BLK	BLACK
WHT	WHITE
LT BLU	LIGHT BLUE
BRN	BROWN
YEL	YELLOW
RED	RED
GRN	GREEN
GRY	GREY
PNK	PINK
ORN	ORANGE
PPL	PURPLE
PNK-BLK	PINK-BLACK
PNK-WHT	PINK-WHITE
GRY-BLK	GREY-BLACK
GRY-RED	GREY-RED
GRY-YEL	GREY-YELLOW
WHT-BLK	WHITE-BLACK
WHT-RED	WHITE-RED
LT BLU-BLK	LIGHT BLUE-BLACK
LT BLU-WHT	LIGHT BLUE-WHITE
LT BLU-RED	LIGHT BLUE-RED
LT BLU-YEL	LIGHT BLUE-YELLOW
YEL-BLK	YELLOW-BLACK
YEL-GRN	YELLOW-GREEN
YEL-RED	YELLOW-RED

(Cont.d)

GRN-BLK	GREEN-BLACK
GRN-WHT	GREEN-WHITE
RED-BLK	RED-BLACK
ORN-BLK	ORANGE-BLACK
ORN-WHT	ORANGE-WHITE
PPL-BLK	PURPLE-BLACK
PPL-WHT	PURPLE-WHITE
BRN-WHT	BROWN-WHITE
HZL	HAZEL (BROWN)
PLM	PLUM
DK GRN	DARK GREEN
BLU	BLUE
LT GRN	LIGHT GREEN
BLU-RED	BLUE-RED

## ELECTRIC COMPONENTS

All the electric components of the vehicle are illustrated by means of symbols. The table below lists all symbols used within the wiring diagrams.

TABLE OF SYMBOL






























SYMBOL	DENOMINATION	SYMBOL	DENOMINATION
	CONNECTOR		BATTERY
	GROUNDING POINT		CIRCUIT BOARD
	REFERENCE TO THE COMPONENT		ELECTROMAGNET
	CRIMPING CONNECTION		INSTRUMENT PANEL
	REFERENCE TO THE CIRCUIT		RELAY/INTERMITTANCE
	FUSE		MOTOR
	LAMP		
	TWO-BEAM LAMP		



TABLE OF SYMBOL

SYMBOL	DENOMINATION	SYMBOL	DENOMINATION	
	RELAYS		SWITCHES	
				
				
		RELAY WITH FUSE		
	SWITCH			
	SPECIFIC DOTTED LINE FOR MODELS WITH MECHANICAL TRANSMISSION			
	SPECIFIC DOTTED LINE FOR MODELS S			

## OPERATIONAL DESCRIPTIONS

The page at the right of each wiring diagram contains a brief introduction and an operational description of the related circuit. The operational description has been realized by analyzing the wiring diagram from top to bottom; the voltage flow is illustrated starting from the battery through the related fuses and inhibitors (switches and/or relays) to the load itself.

If the function is divided into more wiring diagrams (Instrument panel, power adjustable seats, parking/license plate/side marker lamps, etc.), the operational description is preceded by a single general description, but is split into the various sub-functions.

The components are identified in the operational

description using the same alphanumeric code enclosed by the ellipse on the wiring diagram.

Where required, a troubleshooting table is located at the end of the operational description of each wiring diagram. This table lists all the failures that could arise during use of vehicle in the function being examined.

This table also provides a list of components that have possibly failed.

Furthermore, for each possible failure a reference is made to the applicable test procedure among those presented at the end of each section.

The sample table shown below indicates that trouble "A" is probably due to failure of components 1 and 5, and that it can be corrected following instructions give in Test "A".

		COMPONENT				
		1	2	3	4	5
REFERENCE TEST	A	●				●
	B		●	●	●	

## Components and Cables

The second double-size page of each section illustrates all components affected by the wiring, as well as the wiring itself. The table of components lists the connector installed on the component and the corresponding connector on the cable. The connections are illustrated showing the two parts which form the connection (plug and socket).

For each connector or junction only the wires pertaining to the function being examined are illustrated.

As on the wiring diagrams, the wires are identified by the

cross section area and color code; in addition, the alphanumeric code of a component connected to that wire is indicated. A vehicle "silhouette" and routing of cables pertaining to the function being examined is presented on opposite page.

In this way, you can easily locate the components.

Finally, a lens-shaped symbol encloses and highlights the utilities pertaining to the affected wiring diagram (cigar lighter, in the example shown) and the relevant protection fuses.

In any case, the fusebox is indicated any time it is involved in the wiring diagram.

### Troubleshooting Procedure

Troubleshooting tests are presented at the end of each section. These tests are identified by the type of failure that the user of vehicle could experience, and by a

letter (e.g. Test A, Test B).

Priority is given to the most severe failure or to the most used component.

The tests are presented in tabular form on three columns. An example of troubleshooting test is illustrated below.

CIGARETTE LIGHTERS - FRONT AND REAR 184

TYPE OF FAILURE		TEST REFERENCE
FRONT LIGHTER INOPERATIVE	TEST A	
TEST STEPS	RESULTS	REMEDY
<b>A1 FUSE CHECK</b> - Check fuse F21 in fuse box G1 for integrity	(OK) ▶ (X) ▶	Carry-out step A2 Replace fuse F21
<b>A2 VOLTAGE CHECK</b> - Check for presence of 12V between pins 1 and 2 of front lighter O6	(OK) ▶ (X) ▶	Replace lighter O6 Carry-out step A3
<b>A3 VOLTAGE CHECK</b> - Check for presence of 12V between pin 2N of fuse box G1 and ground	(OK) ▶ (X) ▶	Repair wiring between pin 1 of lighter O6 and pin 8P of fuse box G1, and/or between pin 2 of lighter O6 and ground point G17a Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
End of test A		

**TEST STEP:** this column contains in numerical order all steps of the troubleshooting procedure.

Inside the procedure, the steps are titled in relation with the type of test being performed.

Where necessary, the operating conditions required for proper execution of the test are indicated at the beginning of the affected test steps.

The test steps are provided with illustrations if the test procedure could be difficult to understand.

**RESULTS:** this column presents the possible results of test step being examined: the result can be satisfactory (OK) or unsatisfactory (X).

**REMEDY:** this column states if the component has to be replaced or repaired, or gives reference to another test step.

**NOTE**

- Where not otherwise indicated, the checks stated in test steps of the troubleshooting procedure must be performed directly on the pin of the affected component, or on the pin of the connector or terminal board directly connected to that component. An adequate knowledge of the functional flow of the circuit being examined will determine whether a voltage signal is input to, or output from a component. It is therefore advisable to refer to the wiring diagram and operational description prior to performing any troubleshooting procedure.
- Where possible, it is advisable to actuate the component being tested from a remote point in order to simplify and speed up the troubleshooting by isolation of common lines (power supply or ground).

## Troubleshooting Tools

A multimeter providing ohmmeter and voltmeter capabilities is required to perform system troubleshooting. Digital multimeters are very high precision instruments whose readings are significant only if contact between multimeter pins and the component is good and the electrical signal does not happen too quickly.

Set multimeter to  $\Omega$  to measure resistance values; always remove power supply from components before resistance measurement. Remember that:

- Zero  $\Omega$  means electrical continuity; this measure is significant for wires, fuses, etc., but not for measurement of an electric motor, whose impedance must be equal to a determined resistance value to be considered satisfactory.
- Infinite ( $\infty$ ) means interruption, and as a consequence a wire, fuse, motor, etc. is "open".

Set multimeter to V to measure voltage and select correct

scale as dictated by measurement being done.

## Troubleshooting Check


### Voltage test

#### NOTE

When performing tests of the type shown below, it is necessary to establish the power supply conditions stated in the upper section of the wiring diagram.

This test measures voltage in a circuit. Taking measurements at several points (terminals or connectors) along the circuit allows you to isolate the problem.

To take a voltage measurement, connect the negative lead of the voltmeter to the battery's negative terminal or other known good ground. Then connect the positive lead of the voltmeter to the point you want to test. The voltmeter will read the voltage present at that point in the circuit.



**Voltage drop test**


**NOTE**

When performing tests of type shown below, it is necessary to establish the power supply condition stated in the upper section of the wiring diagram.

Wires, connectors and switches (when closed), have been designed to conduct current with a minimum loss of voltage. A voltage drop across any one connector or switch that exceeds 0.2 volts indicates a problem.

To test for voltage drop, connect the voltmeter leads to connectors at either end of the suspected part of the circuit.

The positive lead should be connected to the connector closest to the power source. The voltmeter will show the voltage drop between these two points.




**Continuity test**

To perform a continuity test, first disconnect the car battery. Then adjust the ohmmeter to read zero while holding the ohmmeter leads together.

Connect the ohmmeter leads to connectors or terminals at either end of the suspected part of the circuit.

The ohmmeter will show the resistance across that part of the circuit.





## Short test using voltmeter


## NOTE

When performing tests of type shown below, it is necessary to establish the power supply conditions stated in the upper section of the wiring diagram.

Remove the blown fuse and disconnect the load. Connect the voltmeter leads to the fuse terminals.


The positive lead should be connected to the terminal closest to the power source.

Starting near the fusebox move the wire harness in question back and forth and watch the voltmeter reading. If the voltmeter shows a reading, there is a ground-short in the wiring. Somewhere in the area of the harness being moved, the wire insulation is worn away and the circuit is grounded.



## Short test using ohmmeter

Disconnect the battery. Adjust the ohmmeter to read zero while holding the leads ohmmeter together. Remove the blown fuse and disconnect the load. Connect one lead of the ohmmeter to the fuse terminal that is closest to the load. Connect the other lead to a known good ground. Starting near the fusebox or the pertaining circuit free fuse, move the wire harness back and forth and watch the ohmmeter reading. Low or no resistance indicates a ground-short in the wiring. Infinite resistance indicates no short.



## Components Functional Check

This section contains instructions to perform functional checks of main components indicated on the wiring diagrams.

These instructions must be considered any time it is required to ascertain that components listed below are operating properly.

### NOTE

The contacts of all electric/electronic parts are subject to oxidation, and could cause false measurements that differ from values stated in the following.

It is therefore necessary to check and remove any oxidation before proceeding to a functional check.

If during troubleshooting it is necessary to remove a component to check if it is operational, it is understood that the same component will be properly re-installed if found serviceable, paying attention not to reverse polarity and/or connections.

### Bulbs


The main characteristics of a bulb are the voltage and the power.

The higher the power of bulb, the higher is the current absorbed, and the lower is its resistance; for example a high beam lamp (12V-45W) has a lower resistance than a warning lamp on instrument panel (12V-3W).

To test a bulb, connect ohmmeter pins to the bulb terminals.

If the measured value corresponds to a certain number of  $\Omega$ , the bulb is serviceable; if the measured value is infinite ( $\infty$ ), the bulb filament is broken.

Even if a certain resistance is maintained, a bulb's brilliance could be reduced; replace bulbs if blackened. If a bulb interruption is suspected, it is possible to ascertain if the bulb is serviceable without removing it; connect a 12V power supply to the pins of the bulb connector and check that the bulb illuminates.




### Fuses

A fuse consists of an electric conductor whose cross section is such as to melt and interrupt the circuit in case of an excessive current load.

To ascertain fuse integrity connect ohmmeter pins in parallel to fuse ends.



If multimeter reading is zero  $\Omega$  the fuse is serviceable; the fuse is interrupted if ohmmeter reading is infinite ( $\infty$ ).



### Relays


A relay consists of a coil and a set of electrical contacts. When a voltage is present between the coil terminals, the relay contacts are actuated.

Referring to the following figure, when the relay is energized, pin 30 is connected to pins 87 and 87a.



To ascertain if a relay is operational remove it from the vehicle and energize it using a 12V power supply (the coil has no polarity, and positive power supply can be supplied either to pin 85 or pin 86).

Using a multimeter, check for electric continuity between the contacts as illustrated below with relay energized and de-energized.



**CAUTION:**  
A "stuck contacts" condition could be encountered during a functional check; In this event the coil is interrupted but the contacts do not move and the ohmmeter reading does NOT show any variation (from 0Ω to infinite, or vice versa). Replace relays with this malfunction.

**NOTE**


The vehicle's electrical system includes some relays provided with a fuse. For this type of relay the functional check of the relay is dependant on the integrity of the fuse, which should be replaced if necessary.

### Thermal contacts

The vehicle's electrical system includes thermal contacts whose actuation is determined by temperature.

The thermal contacts are N.O. or N.C. switches that change their status (closed or open circuit) when a pre-determined temperature is reached.

Thermal contacts are illustrated on the wiring diagrams in their normal operating position. Remove the thermal contact from the vehicle's circuit if necessary to check it, and connect an ohmmeter to the thermal contact pins. Bring the thermal contact to the required temperature and note that the ohmmeter reading changes.




### Sensor/switches

The vehicle's electrical system includes sensors that are N.O. or N.C. switches.

These sensors change their status (closed or open circuit) depending on operating conditions.

The sensors are illustrated on the wiring diagrams in normal operating position (for example, the door sensor is illustrated in the door closed position).

To determine if the sensor and/or switch is operational, it is necessary to reverse the operating condition and note that ohmmeter reading changes.



### Electric Motors/Electric Fans/Solenoids

The vehicle's electrical system includes electric motors and/or fans whose energization is controlled by closing of switcheable pushbuttons or switches.

To determine if motor/fan is operational, it is necessary to disconnect it from the vehicle wiring, and connect an ohmmeter between its terminals and check the electric continuity (absence of open circuit) of its winding.



In case of a suspected failure of the component, the functional check can be performed without removing it from vehicle.

To this purpose, connect a 12V power supply between pins of the component's connector, and check that it operates.

Particular care must be taken when checking power rearview mirror motors, since this component consists essentially of two motors (UP-DOWN motor and LEFT-RIGHT motor); check each motor separately.

#### NOTE

In some cases the motor transmits its movement to a mechanical device in one direction or the other depending on the actuating signal. Check these components applying 12V with a certain polarity, and then reversing it. (example: window motor, seat motor, etc)



### Ground points

The ground is intended to be mechanically connected to the battery negative pole.


A point is not connected to ground when it is not firmly mechanically connected to the negative pole; an oxidized terminal or an improperly secured wire do not offer a good ground connection. The check of ground points is

performed by connecting one pin of the ohmmeter to the terminal being checked, and the other to the negative pole of the battery.

Ground connection is satisfactory if the ohmmeter reading is 0  $\Omega$ ; if the ohmmeter reads anything greater than 0.1  $\Omega$  it is necessary to restore proper connection to ground since that terminal is oxidized or not properly secured.




# ABS BRAKE SYSTEM



REFER TO POWER DISTRIBUTION CIRCUIT G56 (SHEET 1 OF 2)

REFER TO POWER DISTRIBUTION CIRCUIT G56 (SHEET 2 OF 2)

REFER TO POWER DISTRIBUTION CIRCUIT G56 (SHEET 1 OF 2)



**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>

## GENERAL

The vehicle is equipped with the anti-lock brake system (ABS). This system modulates the brake pressure to prevent skidding of one or more wheels regardless of road surface and tire conditions.

The system senses the tendency to blocking of one or more wheels by means of sensors located close to the wheels, and monitors skidding.

In this way, the skidding coefficient is continuously maintained within optimal values, thus allowing to stop the vehicle in the shortest possible distance without losing steering control.

The ABS consists mainly of a control unit that processes the signals delivered by four sensors located near each wheel.

The control unit monitors an electro-mechanical device (ABS brake fluid electric pump unit). This device actuates the solenoid valves that meter the flow of fluid to brake calipers.

The ABS includes a self-diagnosis system that continuously monitors the system components.

In case a malfunction is detected, the ABS automatically de-activates, and a warning lamp illuminates on instrument panel.

Automatic de-activation of the ABS does not jeopardize operation of conventional servo brake circuit.

The ABS circuit is protected by ABS SYSTEM FREE FUSE HOLDER G125 (10A).

## OPERATIONAL DESCRIPTION

The battery power (12V) available when ignition key is set to "run" or "start" positions is applied to coil of ABS relay I57, and relay is energized.

When relay I57 is energized, the ABS control unit N27 is powered at pin 1 through free fuse G125; "vehicle running" condition is sensed at pin 15 of control unit N27 through direct connection to alternator A2.

The control unit N27 senses the tip speed of wheels through signals delivered by inductive sensors - pulse emitters (phonic wheels) L28, L29, L30 and L31.











Application of brake pedal is sensed at pin 25 of control unit N27 which delivers input signals to ABS brake fluid electric pump N28.

This unit allows actuation of solenoid valves by means of an electric pump.

The four solenoid valves, one for each wheel, allow metering of brake fluid pressure, and consequent control of braking action. Furthermore, the control unit N27 includes a self-diagnosis system that provides continuous and constant monitoring of proper operation of the ABS components.

When the ignition key is set to "run", the ANTI-LOCK warning lamp illuminates on instrument panel, and extinguishes a few seconds after engine starting if all ABS components are efficient.


The warning lamp remains on after completion of starting phase, or illuminates during run, in case of ABS malfunction; in this event, restore correct operation of the ABS referring to the troubleshooting procedure.

<p>Alternator</p>	<p>A2</p>	<p>Instrument panel</p>	<p>C10 A</p>
			
<p>Fuse box</p>	<p>G1 I</p>	<p>Engine compartment left side ground connection</p>	<p>G53b</p>
			
<p>ABS system connector</p>	<p>G124</p>	<p>ABS system free fuse holder</p>	<p>G125</p>
			
<p>ABS system ground connection</p>	<p>G202</p>	<p>Connector, circuit board to engine utilities wiring</p>	<p>G151</p>
			
<p>Front right sensor connection - ABS</p>	<p>G204</p>	<p>Front left sensor connection - ABS</p>	<p>G205</p>
			

(Cont.d)























<p>Rear right sensor connection - ABS</p>	<p>G206</p>	<p>Rear left sensor connection - ABS</p>	<p>G207</p>
<p>Bar wiring to anti-theft system wiring connector</p>	<p>G241</p>	<p>Electronic control units power supply relay</p>	<p>I51</p>
<p>ABS system electronic relay</p>	<p>I57</p>		
<p>ABS control unit</p>	<p>N27</p>	<p>ABS brake fluid electric pump</p>	<p>N28</p>











## ILLUMINATION ON ANTI-LOCK WARNING LAMP

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
	- Check free fuse <b>G125</b> for integrity	 	Carry out step <b>A2</b>
		 	Replace free fuse <b>G125</b>
<b>A2</b>	<b>R.H. FRONT SENSORS CHECK</b>		
	- Check for presence of a resistance of 600 to 1400 $\Omega$ between pins 21 and 23 of ABS control unit <b>N27</b>	 	Carry-out step <b>A3</b>
		 	Carry-out step <b>A13</b>
<b>A3</b>	<b>L.H. FRONT SENSORS CHECK</b>		
	- Check for presence of a resistance of 600 to 1400 $\Omega$ between pins 4 and 5 of ABS control unit <b>N27</b>	 	Carry-out step <b>A4</b>
		 	Carry-out step <b>A16</b>
<b>A4</b>	<b>R.H. REAR SENSOR CHECK</b>		
	- Check for presence of a resistance of 600 to 1400 $\Omega$ between pins 24 and 26 of ABS control unit <b>N27</b>	 	Carry-out step <b>A5</b>
		 	Carry-out step <b>A19</b>
<b>A5</b>	<b>L.H. REAR SENSOR CHECK</b>		
	- Check for presence of a resistance of 600 to 1400 $\Omega$ between pins 7 and 9 of ABS control unit <b>N27</b>	 	Carry-out step <b>A6</b>
		 	Carry-out step <b>A22</b>

(Cont.d)

ILLUMINATION ON ANTI-LOCK WARNING LAMP	<b>TEST A</b>
--	---------------

TEST STEPS		RESULTS	REMEDY
<b>A6</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 10 of ABS control unit N27		<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; justify-content: space-around; align-items: center; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	<p>Carry-out step A7</p> <p>Repair wiring between pin 10 of control unit N27 and ground point G202</p>
<b>A7</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 20 of ABS control unit N27		<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; justify-content: space-around; align-items: center; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	<p>Carry-out step A8</p> <p>Repair wiring between pin 20 of control unit N27 and ground point G202</p>
<b>A8</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 34 of ABS control unit N27		<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; justify-content: space-around; align-items: center; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	<p>Carry-out step A9</p> <p>Repair wiring between pin 34 of control unit N27 and ground point G202</p>
<b>A9</b>	<b>VOLTAGE CHECK</b>		
- With ignition key set to "run", check for presence of 12V at pin 1 of ABS control unit N27		<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; justify-content: space-around; align-items: center; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	<p>Carry-out step A10</p> <p>Carry-out step A27</p>

(Cont.d)

## ILLUMINATION ON ANTI-LOCK WARNING LAMP









## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A10</b>	<b>VOLTAGE CHECK</b>		
- With engine running check for presence of 13V to 14.5V at pin 15 of ABS control unit N27		OK ►	Carry-out step A11
		<del>OK</del> ►	Carry-out step A32
<b>A11</b>	<b>VOLTAGE CHECK</b>		
- With brake pedal pressed, check for presence of 12V at pin 25 of ABS control unit N27		OK ►	Carry-out step A12
		<del>OK</del> ►	Carry-out step A15
<b>A12</b>	<b>RELAYS CHECK</b>		
- Check proper operation of two relays located on ABS brake fluid electric pump N28		OK ►	Carry-out step A36
		<del>OK</del> ►	Replace defective relay (s)
<b>A13</b>	<b>OPEN CIRCUIT CHECK</b>		
- Check for presence of open circuit between pins 21 and 23 of ABS control unit N27		OK ►	Carry-out step A14
		<del>OK</del> ►	Carry-out step A15 if short circuit is found

(Cont.d)

## ILLUMINATION ON ANTI-LOCK WARNING LAMP

## TEST A









TEST STEPS		RESULTS	REMEDY
<b>A14</b>	<b>CONTINUITY CHECK</b>		
- Disconnect R.H. front sensor <b>L28</b> and check for continuity between pin 21 of ABS control unit <b>N27</b> and <b>G204</b> , and between <b>G204</b> and pin 23 of control unit <b>N27</b>		 ▶  ▶	Replace sensor <b>L28</b>  Repair or replace wires, as required
<b>A15</b>	<b>OPEN CIRCUIT CHECK</b>		
- Disconnect R.H. front sensor <b>L28</b> and check for presence of open circuit between pins 21 and 23 of ABS control unit <b>N27</b> (cable side)		 ▶  ▶	Replace sensor <b>L28</b>  Eliminate short circuit between <b>BRN</b> and <b>GRN</b> wires connecting <b>G204</b> to pins 21 and 23 of control unit <b>N27</b>
<b>A16</b>	<b>OPEN CIRCUIT CHECK</b>		
- Check for presence of open circuit between pins 4 and 5 of ABS control unit <b>N27</b>		 ▶  ▶	Carry-out step <b>A17</b>  Carry-out step <b>A18</b> if short circuit is found
<b>A17</b>	<b>CONTINUITY CHECK</b>		
- Disconnect L.H. front sensor <b>L29</b> and check for continuity between pin 4 of ABS control unit <b>N27</b> and <b>G205</b> , and between <b>G205</b> and pin 5 of control unit <b>N27</b>		 ▶  ▶	Replace sensor <b>L29</b>  Repair or replace wires, as required

(Cont.d)



## ILLUMINATION ON ANTI-LOCK WARNING LAMP









## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A18</b>	<b>OPEN CIRCUIT CHECK</b>		
<ul style="list-style-type: none"> <li>- Disconnect L.H. front sensor <b>L29</b> and check for presence of open circuit between pins 3 and 5 of ABS control unit <b>N27</b> (cable side)</li> </ul>		 	Replace sensor <b>L29</b>  Eliminate short circuit between <b>WHT</b> and <b>BRN</b> wires connecting <b>G205</b> to pins 4 and 5 of control unit <b>N27</b>
<b>A19</b>	<b>OPEN CIRCUIT CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of open circuit between pins 24 and 26 of ABS control unit <b>N27</b></li> </ul>		 	Carry-out step <b>A20</b>  Carry-out step <b>A21</b> if short circuit is found
<b>A20</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>- Disconnect R.H. rear sensor <b>L30</b> and check for presence of continuity between pin 24 of ABS control unit <b>N27</b> and <b>G206</b>, and between <b>G206</b> and pin 26 control unit <b>N27</b></li> </ul>		 	Replace sensor <b>L30</b>  Repair or replace wires, as required
<b>A21</b>	<b>OPEN CIRCUIT CHECK</b>		
<ul style="list-style-type: none"> <li>- Disconnect R.H. rear sensor <b>L30</b> and check for presence of open circuit between pins 24 and 26 of ABS control unit <b>N27</b> (cable side)</li> </ul>		 	Replace sensor <b>L30</b>  Eliminate short circuit between <b>RED</b> and <b>BRN</b> wires connecting <b>G206</b> to pins 24 and 26 of control unit <b>N27</b>

(Cont.d)

## ILLUMINATION ON ANTI-LOCK WARNING LAMP









## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A22</b>	<b>OPEN CIRCUIT CHECK</b>		
	- Check for presence of open circuit between pins 7 and 9 of ABS control unit N27	 ►  ►	Carry-out step A23  Carry-out step A24 if short circuit is found
<b>A23</b>	<b>CONTINUITY CHECK</b>		
	- Disconnect L.H. rear sensor L31 and check for presence of continuity between pin 7 of ABS control unit N27 and G207, and between G207 and pin 9 of control unit N27	 ►  ►	Replace sensor L31  Repair or replace wires, as required
<b>A24</b>	<b>OPEN CIRCUIT CHECK</b>		
	- Disconnect L.H. rear sensor L31 and check for presence of open circuit between pins 7 and 9 of ABS control unit N27 (cable side)	 ►  ►	Replace sensor L31  Eliminate short circuit between YEL and BRN wires connecting G207 to pins 7 and 9 of control unit N27
<b>A25</b>	<b>VOLTAGE CHECK</b>		
	- With ignition key set to "run", check for presence of 12V between pin 87 of relay I57 and ground	 ►  ►	Repair wiring between pin 1 of control unit N27 and pin 87 of relay I57  Carry-out step A26

(Cont.d)

## ILLUMINATION ON ANTI-LOCK WARNING LAMP









## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A26</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 31 of relay I57		 ▶	Carry-out step A27
		 ▶	Repair wiring between pin 31 of relay I57 and ground point G202
<b>A27</b>	<b>VOLTAGE CHECK</b>		
- With ignition key set to "run", check for presence of 12V between pin 15 of relay I57 and ground		 ▶	Carry-out step A28
		 ▶	Carry-out step A30
<b>A28</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 30 of relay I57 and ground		 ▶	Replace relay I57
		 ▶	Carry-out step A29
<b>A29</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin of free fuse G125 (RED wire) and ground		 ▶	Repair wiring between pin 30 of relay I57 and free fuse G125
		 ▶	Failure of the power distribution circuit, refer to relevant circuit of sheet 1 of 2

(Cont.d)

## ILLUMINATION ON ANTI-LOCK WARNING LAMP













## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A30</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run", check for presence of 12V between pin 4 of G124 and ground		 ►  ►	Repair wiring between pin 4 of G124 and pin 15 of relay I57  Carry-out step A31
<b>A31</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run", check for presence of 12V between pin 4 of G241 and ground		 ►  ►	Repair wiring between pin 2 of G241 and pin 4 of G124  Failure of the power distribution circuit, refer to relevant circuit of sheet 2 of 2
<b>A32</b>	<b>VOLTAGE CHECK</b>		
- With engine running, check for presence of 13V to 14.5V at pin 2 of connector G124		 ►  ►	Repair wiring between pin 2 of G194 and pin 15 of control unit N27  Carry-out step A33
<b>A33</b>	<b>VOLTAGE CHECK</b>		
- With engine running, check for presence of 13V to 14.5V at pin 13 of connector G151		 ►  ►	Repair wiring between pin 13 of connector G151 and pin 2 of connector G124  Carry-out step A34

(Cont.d)





## ILLUMINATION ON ANTI-LOCK WARNING LAMP

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A34</b>	<b>VOLTAGE CHECK</b>		
- With engine running, check for presence of 13V to 14.5V at pin D+ of alternator A2		 	Repair wiring between pin D+ of alternator A2 and pin 13 of connector G151
		 	Replace alternator A2
<b>A35</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 3 of connector G124 and ground		 	Repair wiring between pin 3 of connector G124 and pin 25 of control unit N27
		 	Failure of lamps - - brake circuit; refer to the applicable troubleshooting procedure
<b>A36</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 4 and on casing of ABS brake fluid electric pump N28		 	Carry-out step A37
		 	Repair wiring between ground point G53b, pin 4 and casing of brake fluid electric pump N28

(Cont.d)

ILLUMINATION ON ANTI-LOCK WARNING LAMP	<b>TEST A</b>
--	---------------

TEST STEPS	RESULTS	REMEDY
<p><b>A37</b> CONTINUITY CHECK</p> <p>- Check for continuity between:</p> <ul style="list-style-type: none"> <li>• pin 2 of N27 and pin 1 of N28</li> <li>• pin 14 of N27 and pin 9 of N28</li> <li>• pin 18 of N27 and pin 5 of N28</li> <li>• pin 19 of N27 and pin 7 of N28</li> <li>• pin 27 of N27 and pin 6 of N28</li> <li>• pin 28 of N27 and pin 11 of N28</li> <li>• pin 32 of N27 and pin 12 of N28</li> <li>• pin 35 of N27 and pin 3 of N28</li> </ul>	<p style="text-align: center;">   </p> <p style="text-align: center;">   </p>	<p>Replace <b>ABS</b> brake fluid electric pump N28</p> <p>Repair or replace wires, as required</p>

End of test A



# AIR BAG



## GENERAL

The air bag is a safety device, controlled by an electronic control unit, which in case of front impact or impact with reduced angle, inflates instantaneously between steering wheel and driver's body.

After activation, the air bag deflates in a very short time, thus allowing the driver to recover control of the vehicle.

The air bag control system consists of:

- Two front sensors, installed on both sides at forward end of engine compartment.
- An electronic control unit.
- A warning lamp on the instrument panel which indicates failure, if any.

The air bag control unit is equipped with a test connector, which is powered by electronic control units power supply relay I51. The connector allows to perform test by a diagnostic interface.

The air bag control unit stores in its memory all failures occurred during the vehicle operation.

The failures are then reported to operator during troubleshooting procedure.

Any time AIR BAG indicator lamp comes on during run or after the starting phase (some seconds after engine starting), the vehicle should be checked and repaired at an Alfa Romeo authorized service station.

## FUNCTIONAL DESCRIPTION

The electronic control units power supply relay I51 is energized when ignition key is moved to "run" position.

The 12V power supply is connected to air bag control unit R22 either through pin 1B of relay (contact) or directly (pin 2B) with ignition key to "start" position.

In case of a front impact, or impact with reduced angle, the air bag front sensors R20 (R.H. side) and R21 (L.H. side) send an electric signal to air bag control unit R22.

In such a case, the control unit activates an electric signal

between pins 1A and 2A.

The signal is then supplied to air bag capsule R23 on steering wheel.

The air bag module contains a squib, whose detonation generates a shock wave that, in turns, allows the bag to inflate.

The air bag inflates in less than 20 centisec., and deflates in less than 50 centisec.

During starting phase, the air bag control unit performs the system self-diagnosis: during this phase (few seconds), the AIR BAG indicator lamp should illuminate. After the self-diagnosis is completed, the lamp should go off.

Any failure to system is stored in a memory of control unit: the fault codes stored in the memory may be retrieved following the applicable procedure.

## SELF-DIAGNOSIS-SAFETY PRECAUTIONS

During all troubleshooting and maintenance operations on air bag system, the following precautions should be strictly observed:

1. Disconnect battery when performing any duties on steering column and insulate the negative pole.
2. When performing maintenance operations on inflation system, disconnect air bag control unit from module on steering wheel (Connector A).
3. Inflation modules should never be subjected to a temperature above 80°C (176 °F).
4. Inflation modules, impact sensors and control units are unserviceable if dropped from height greater than two (2) feet.
5. Never tap impact sensors with mallet or similar tools.
6. When replacing a sensor, the replacement unit SHOULD be installed with directional arrow oriented.

**CAUTION:**

The impact sensors should be installed flat on chassis guide. Handle sensors with care and secure in correct position. It is important that sensors and chassis mating surfaces are free from dust or other foreign matter.

7. To avoid damage, do not connect control unit to electrical system until its proper installation is checked.
8. To avoid airbag inflation during troubleshooting, never use electrically powered units (e.g. voltmeters, ohmmeters) other than those described in this manual.
9. Do not energize the system until all components are connected: a failure code may appear.
10. Particular care should be taken when handling a new (unexploded) inflation module: the accidental bag inflation may project the module or any other close object.

**WARNING:**

When handling a new inflation module, keep bag and cover away from body: in case of accidental inflation the bag will expand freely, thus reducing possibility of injuries to personnel. For same reason, place unexploded inflation module on workbench (or other surface) with bag and cover upwards.

**WARNING:**

Observe all safety precautions when handling exploded modules. After air bag deployment, the air bag surface may contain deposits of sodium hydroxide, a by-product of gas generated during deployment. Sodium hydroxide is irritating to the skin. Use protective gloves and eyeglasses and wash hands thoroughly with lukewarm water and a mild soap.

**NOTE**

For further information on air bag system, refer to applicable laws (vehicle scrapping).

**SELF-DIAGNOSIS-GENERAL INFORMATION**Code display

Connect pin 6B of air bag control unit R22 to ground. Set ignition key to "run" position for more than 5 sec.

The typical flashing series of AIR BAG warning lamp is the following:

Pause after starting	5.2 ± 0.2 sec.
Lamp on	400 ± 20 msec.
Lamp off	400 ± 20 msec.
Pause between digits	1.2 ± 0.1 sec.
Pause between codes	3.2 ± 0.2 sec.

When starting self-diagnosis, the code 12 appears for 3 times, thus informing operator that troubleshooting procedure is running.

Each failure code consists of two digits, and is displayed three times in sequence before the system shows the subsequent code.

If two or more failure codes are present at the same time, the system displays all codes in numerical order.

At end of each sequence, the system displays again code 12, thus allowing the sequence to be repeated.











Code reset

The code may be reset by operator as follows:

- While AIR BAG warning lamp is flashing (failure code display), disconnect pin 6B of control unit from ground for 3 ± 1 sec.
- Reconnect pin 6B of control unit to ground for 3 ± 1 sec.
- Disconnect pin 6B of control unit from ground definitively.
- Turn off ignition key.


If codes 52, 53 or 54 are stored in memory (e.g. after an impact) or Eprom memory is failed, failure codes cannot be reset in any way. In such a case the AIR BAG warning


lamp on instrument panel is permanently illuminated, even if resetting procedure has been accomplished. The following table contains the troubleshooting for the airbag system where, starting from the flashing error code displayed by the AIR BAG warning lamp, the existing failure can be detected and the faulty components can be identified.

Instrument panel connector <span style="float: right;">(C10) D</span>	Fuse box <span style="float: right;">(G1) D</span>
 <p>GRN (R22, B) 4</p>	 <p>1PPL (R22, B) 3</p>
Fuse box <span style="float: right;">(G1) I</span>	Fuse box <span style="float: right;">(G1) O</span>
 <p>1.5RED (HOT IN RUN) 2 1BRN (I51) 2</p>	 <p>PPL (HOT IN START) 3</p>
Auxiliary fuse box <span style="float: right;">G2</span>	Connector, circuit board to engine compartment left side wiring <span style="float: right;">G150</span>
 <p>1.5PNK (S1) 1PNK (T3)</p>	 <p>1.5RED (S1) 5 1.5RED (HOT AT ALL TIMES) 5</p>
Steering wheel column support ground <span style="float: right;">G174</span>	 <p>1BLK (I51)</p>
Electronic control units power supply relay <span style="float: right;">(I51)</span>	Air Bag right front sensor <span style="float: right;">(R20)</span>
 <p>1BLK (G174) 86 1.5PNK (G2) 87 1PNK (R22, B) 87 1.5RED (G150) 30 1BRN (G1, I)</p>	 <p>RED (R22, C) WHT (R22, C) YEL (R22, C)</p>
Air Bag left front sensor <span style="float: right;">(R21)</span>	 <p>RED (R22, C) WHT (R22, C) YEL (R22, C)</p>

(Cont.d)







### SELF-DIAGNOSIS - TROUBLESHOOTING TABLE

CODE	MALFUNCTION	TEST REFERENCE
14	- Forward L.H. sensor grounded the chassis.	A
15	- Open circuit on forward L.H. sensor.	B
16	- Failure to forward L.H. sensor.	C
24	- Forward R.H. sensor grounded to chassis.	D
25	- Open circuit on forward R.H. sensor.	E
26	- Failure to forward R.H. sensor.	F
31	- Current leakage to battery.	G
32	- Current shorted to battery voltage.	H
33	- Current leakage to ground.	I
34	- Current shorted to ground.	J
35	- Open circuit.	K
36	- Faulty squib.	L
41	- Short to ground/battery-warning lamp.	M
42	- Failure of Air Bag warning lamp.	M
51	- Faulty diagnostic unit.	N
52	- Firing sequence confirmation set.	O
53	- Firing current confirmation set.	O
54	- Squib current has flowed.	O

<b>FORWARD L.H. SENSOR GROUNDED TO CHASSIS</b>	<b>TEST A CODE 14</b>
--	---------------------------

	TEST STEPS	RESULTS	REMEDY
<b>A1</b>	<b>SENSOR INSTALLATION CHECK</b>  - Check that: <ul style="list-style-type: none"> <li>• forward L.H. sensor R21 is properly secured to chassis ground</li> <li>• installation point is clean to assure a good electric contact</li> </ul>	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px;">OK</span> <span style="font-size: 2em;">▶</span> </div> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px; text-decoration: line-through;">OK</span> <span style="font-size: 2em;">▶</span> </div> </div>	Carry-out <b>step A2</b>  Install <b>sensor R21 properly</b>
<b>A2</b>	<b>SENSOR CHECK</b>  - Check proper operation of sensor R21 with an ohmmeter verifying the presence of the values indicated in the following table between sensor pins	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px;">OK</span> <span style="font-size: 2em;">▶</span> </div> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px; text-decoration: line-through;">OK</span> <span style="font-size: 2em;">▶</span> </div> </div>	Carry-out <b>step A3</b>  Replace <b>sensor R21</b>

CONNECT BETWEEN	VALUE (OHM)
<del>RED</del> and ground	Less than 1
<del>RED</del> and WHT	Approx. 10K
RED and YEL	Approx. 10K
WHT and <del>YEL RED</del>	Less than 1

(Cont.d)

## FORWARD L.H. SENSOR GROUNDED TO CHASSIS


TEST A  
CODE 14

TEST STEPS		RESULTS	REMEDY
<b>A3</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of grounding between pin 5 of control unit R22 and ground</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 5 of connector C of control unit R22 and sensor R21</p> <p>Replace control unit R22</p>

End of test A

**OPEN CIRCUIT ON FORWARD L.H. SENSOR**

**TEST B  
CODE 15**

TEST STEPS		RESULTS	REMEDY										
<b>B1</b>	<b>SENSOR INSTALLATION CHECK</b>												
<ul style="list-style-type: none"> <li>- Check that forward L.H. sensor R21 is properly secured to chassis ground; check that installation point is clean to assure a good electric contact</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step B2</p> <p>Install sensor R21 properly</p>										
<b>B2</b>	<b>SENSOR CHECK</b>												
<ul style="list-style-type: none"> <li>- Check proper operation of sensor R21 with an ohmmeter verifying the presence of the values indicated in the following table between sensor pins</li> </ul> <table border="1" data-bbox="127 1308 944 1814"> <thead> <tr> <th>CONNECT BETWEEN</th> <th>VALUE (OHM)</th> </tr> </thead> <tbody> <tr> <td><del>YEL</del> <del>RED</del> and ground</td> <td>Less than 1</td> </tr> <tr> <td><del>YEL</del> <del>RED</del> and WHT</td> <td>Approx. 10K</td> </tr> <tr> <td>RED and YEL</td> <td>Approx. 10K</td> </tr> <tr> <td>WHT and <del>YEL</del> <del>RED</del></td> <td>Less than 1</td> </tr> </tbody> </table> 		CONNECT BETWEEN	VALUE (OHM)	<del>YEL</del> <del>RED</del> and ground	Less than 1	<del>YEL</del> <del>RED</del> and WHT	Approx. 10K	RED and YEL	Approx. 10K	WHT and <del>YEL</del> <del>RED</del>	Less than 1	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step B3</p> <p>Replace sensor R21</p>
CONNECT BETWEEN	VALUE (OHM)												
<del>YEL</del> <del>RED</del> and ground	Less than 1												
<del>YEL</del> <del>RED</del> and WHT	Approx. 10K												
RED and YEL	Approx. 10K												
WHT and <del>YEL</del> <del>RED</del>	Less than 1												

(Cont.d)

OPEN CIRCUIT ON FORWARD L.H. SENSOR

TEST B  
CODE 15

TEST STEPS		RESULTS	REMEDY
<b>B3</b>	<b>CONTINUITY CHECK</b>		
<p>- Check for continuity between:</p> <ul style="list-style-type: none"> <li>• pin 4C of control unit R22 and pin of sensor R21 (YEL wire)</li> <li>• pin 5C of control unit R22 and pin of sensor R21 (RED wire)</li> <li>• pin 6C of control unit R22 and pin of sensor R21 (WHT wire)</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace control unit R22</p> <p>Repair or replace wires, as necessary</p>

End of test B



<b>FAILURE TO FORWARD L.H. SENSOR</b>	<b>TEST C CODE 16</b>
---------------------------------------	---------------------------

	TEST STEPS	RESULTS	REMEDY
<b>C1</b>	<b>SENSOR INSTALLATION CHECK</b>  - Check that forward L.H. sensor <b>R21</b> is properly secured to chassis ground, check that installation point is clean to assure a good electric contact	(OK)      ▶  (OK)      ▶	Carry-out <b>step C2</b>  Install <b>sensor R21</b> properly
<b>C2</b>	<b>SENSOR CHECK</b>  - Check proper operation of sensor <b>R21</b> with an ohmmeter verifying the presence of the values indicated in the following table between sensor pins	(OK)      ▶  (OK)      ▶	Replace <b>control unit R22</b>  Replace <b>sensor R21</b>


CONNECT BETWEEN	VALUE (OHM)
<del>YEL</del> <del>RED</del> and ground	Less than 1
<del>YEL</del> <del>RED</del> and WHT	Approx. 10K
RED and YEL	Approx. 10K
WHT and <del>YEL</del> <del>RED</del>	Less than 1

End of test C

**FORWARD R.H. SENSOR GROUNDED TO CHASSIS**

**TEST D  
CODE 24**

TEST STEPS		RESULTS	REMEDY										
<b>D1</b>	<b>SENSOR INSTALLATION CHECK</b>												
<ul style="list-style-type: none"> <li>- Check that forward R.H. sensor R20 is properly secured to chassis ground, check that installation point is clean to assure a good electrical contact</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step D2</p> <p>Install sensor R20 properly</p>										
<b>D2</b>	<b>SENSOR CHECK</b>												
<ul style="list-style-type: none"> <li>- Check proper operation of sensor R20 with an ohmmeter verifying the presence of the values indicated in the following table between sensor pins</li> </ul> <table border="1" data-bbox="127 1276 950 1782"> <thead> <tr> <th>CONNECT BETWEEN</th> <th>VALUE (OHM)</th> </tr> </thead> <tbody> <tr> <td><del>YEL</del> RED and ground</td> <td>Less than 1</td> </tr> <tr> <td><del>YEL</del> RED and WHT</td> <td>Approx. 10K</td> </tr> <tr> <td>RED and YEL</td> <td>Approx. 10K</td> </tr> <tr> <td>WHT and <del>YEL</del> RED</td> <td>Less than 1</td> </tr> </tbody> </table> 		CONNECT BETWEEN	VALUE (OHM)	<del>YEL</del> RED and ground	Less than 1	<del>YEL</del> RED and WHT	Approx. 10K	RED and YEL	Approx. 10K	WHT and <del>YEL</del> RED	Less than 1	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step D3</p> <p>Replace sensor R20</p>
CONNECT BETWEEN	VALUE (OHM)												
<del>YEL</del> RED and ground	Less than 1												
<del>YEL</del> RED and WHT	Approx. 10K												
RED and YEL	Approx. 10K												
WHT and <del>YEL</del> RED	Less than 1												

(Cont.d)

FORWARD R.H. SENSOR GROUNDED TO CHASSIS

TEST D  
CODE 24

TEST STEPS		RESULTS	REMEDY
D3	GROUNDING CHECK		
- Check for presence of grounding between pin 2C of control unit R22 and chassis ground		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pin 2 of connector C of control unit R22 and sensor R20</p> <p>Replace control unit R22</p>

End of test D

**OPEN CIRCUIT ON FORWARD R.H. SENSOR**



**TEST E  
CODE 25**

TEST STEPS		RESULTS	REMEDY										
<b>E1</b>	<b>SENSOR INSTALLATION CHECK</b>												
<p>- Check that:</p> <ul style="list-style-type: none"> <li>• forward R.H. sensor R20 is properly secured to chassis ground</li> <li>• installation point is clean to assure a good electric contact</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Carry-out step E2</p> <p>Install sensor R21 properly</p>										
<b>E2</b>	<b>SENSOR CHECK</b>												
<p>- Check proper operation of sensor R20 with an ohmmeter verifying the presence of the values indicated in the following table between sensor pins</p> <table border="1" data-bbox="121 1324 944 1843"> <thead> <tr> <th>CONNECT BETWEEN</th> <th>VALUE (OHM)</th> </tr> </thead> <tbody> <tr> <td><del>VEL</del> RED and ground</td> <td>Less than 1</td> </tr> <tr> <td>YEL RED and WHT</td> <td>Approx. 10K</td> </tr> <tr> <td>RED and YEL</td> <td>Approx. 10K</td> </tr> <tr> <td>WHT and <del>YEL</del> RED</td> <td>Less than 1</td> </tr> </tbody> </table> <div data-bbox="421 1856 911 2354" data-label="Diagram"> </div>		CONNECT BETWEEN	VALUE (OHM)	<del>VEL</del> RED and ground	Less than 1	YEL RED and WHT	Approx. 10K	RED and YEL	Approx. 10K	WHT and <del>YEL</del> RED	Less than 1	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Carry-out step E3</p> <p>Replace sensor R20</p>
CONNECT BETWEEN	VALUE (OHM)												
<del>VEL</del> RED and ground	Less than 1												
YEL RED and WHT	Approx. 10K												
RED and YEL	Approx. 10K												
WHT and <del>YEL</del> RED	Less than 1												

(Cont.d)

OPEN CIRCUIT ON FORWARD R.H. SENSOR


TEST E  
CODE 25

TEST STEPS		RESULTS	REMEDY
<b>E3</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for continuity between:               <ul style="list-style-type: none"> <li>• pin 3C of control unit R22 and pin of sensor R20 (YEL wire)</li> <li>• pin 2C of control unit R22 and pin of sensor R20 (RED wire)</li> <li>• pin 1C of control unit R22 and pin of sensor R20 (WHT wire)</li> </ul> </li> </ul>		<p style="text-align: center;">       ►        ►         </p>	<p style="text-align: center;">           Replace control unit  <b>R22</b>             Repair or replace  <b>wires, as necessary</b> </p>

End of test E

**FAILURE TO FORWARD R.H. SENSOR**











**TEST F  
CODE 26**

TEST STEPS		RESULTS	REMEDY										
<b>F1</b>	<b>SENSOR INSTALLATION CHECK</b>												
<p>- Check that:</p> <ul style="list-style-type: none"> <li>• forward R.H. sensor R20 is properly secured to chassis ground</li> <li>• installation point is clean to assure a good electric contact</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step F2</p> <p>Install sensor R21 properly</p>										
<b>F2</b>	<b>SENSOR CHECK</b>												
<p>- Check proper operation of sensor R20 with an ohmmeter verifying the presence of the values indicated in the following table between sensor pins</p> <table border="1" data-bbox="121 1324 944 1830"> <thead> <tr> <th>CONNECT BETWEEN</th> <th>VALUE (OHM)</th> </tr> </thead> <tbody> <tr> <td><del>YEL</del> RED and ground</td> <td>Less than 1</td> </tr> <tr> <td><del>RED</del> YEL and WHT</td> <td>Approx. 10K</td> </tr> <tr> <td>RED and YEL</td> <td>Approx. 10K</td> </tr> <tr> <td>WHT and <del>YEL</del> RED</td> <td>Less than 1</td> </tr> </tbody> </table> 		CONNECT BETWEEN	VALUE (OHM)	<del>YEL</del> RED and ground	Less than 1	<del>RED</del> YEL and WHT	Approx. 10K	RED and YEL	Approx. 10K	WHT and <del>YEL</del> RED	Less than 1	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace control unit R22</p> <p>Replace sensor R20</p>
CONNECT BETWEEN	VALUE (OHM)												
<del>YEL</del> RED and ground	Less than 1												
<del>RED</del> YEL and WHT	Approx. 10K												
RED and YEL	Approx. 10K												
WHT and <del>YEL</del> RED	Less than 1												

End of test F

## CURRENT LEAKAGE TO BATTERY

TEST G  
CODE 31







TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Before carrying-out this test, set ignition key to "parking" position, disconnect connector A of control unit R22 and connect a 4ohms resistor between pins 1 and 2 of above mentioned connector. Reset memory of control unit R22 disconnecting pin 6B from ground for 3 sec., reconnecting it for 3 sec. and disconnecting it definitively.</p>		
<b>G1</b> AIR BAG WARNING LAMP CHECK	 	Carry-out step G2  Carry-out step G3
<ul style="list-style-type: none"> <li>- Set ignition key to "run" position and check that AIR BAG warning lamp illuminates for 5 sec. and then extinguishes definitively</li> </ul>		 
<b>G2</b> AIR BAG WARNING LAMP CHECK	 	
<ul style="list-style-type: none"> <li>- Set ignition key to "parking" position. Restore connections, disconnect connector of air bag capsule R23 on steering wheel and connect a 2 ohms resistor between connector pins (GRY-GRN and LT BLU wires). With ignition key to "run" position, check that warning lamp illuminates for 5 sec. and then extinguishes definitively.</li> </ul>		 
<b>G3</b> AIR BAG WARNING LAMP CHECK	 	
<ul style="list-style-type: none"> <li>- Check that warning lamp illuminates for 5 sec., extinguishes for 1/2 sec. and than illuminates definitively</li> </ul>		

End of test G



## CURRENT SHORTED TO BATTERY VOLTAGE







TEST H  
CODE 32

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Before carrying-out this test, set ignition key to "parking" position, disconnect connector A of control unit R22 and connect a 4ohms resistor between pins 1 and 2 of above mentioned connector. Reset memory of control unit R22 disconnecting pin 6B from ground for 3 sec., reconnecting it for 3 sec. and disconnecting it definitively.</p>			
H1	AIR BAG WARNING LAMP CHECK		
<ul style="list-style-type: none"> <li>- Set ignition key to "run" position and check that AIR BAG warning lamp illuminates for 5 sec. and then extinguishes definitively</li> </ul>		 ►  ►	Carry-out step H2  Carry-out step H3
H2	AIR BAG WARNING LAMP CHECK		
<ul style="list-style-type: none"> <li>- Set ignition key to "parking" position. Restore connections, disconnect connector of air bag capsule R23 on steering wheel and connect a 2 ohms resistor between connector pins (GRY-GRN and LT BLU wires). With ignition key to "run" position, check that warning lamp illuminates for 5 sec. and then extinguishes definitively.</li> </ul>		 ►  ►	Replace module R23  Repair wiring between control unit R22 and capsule R23
H3	AIR BAG WARNING LAMP CHECK		
<ul style="list-style-type: none"> <li>- Check that warning lamp illuminates for 5 sec., extinguishes for 1/2 sec. and than illuminates definitively</li> </ul>		 ►  ►	Repeat memory reset procedure of control unit R22  Replace control unit R22

End of test H

## CURRENT LEAKAGE TO GROUND







TEST I  
CODE 32

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Before carrying-out this test, set ignition key to "parking" position, disconnect connector A of control unit R22 and connect a 4ohms resistor between pins 1 and 2 of above mentioned connector. Reset memory of control unit R22 disconnecting pin 6B from ground for 3 sec., reconnecting it for 3 sec. and disconnecting it definitively.</p>		
I1	AIR BAG WARNING LAMP CHECK	
<ul style="list-style-type: none"> <li>- Set ignition key to "run" position and check that AIR BAG warning lamp illuminates for 5 sec. and then extinguishes definitively</li> </ul>	 	Carry-out <b>step I2</b>  Carry-out <b>step I3</b>
I2	AIR BAG WARNING LAMP CHECK	
<ul style="list-style-type: none"> <li>- Set ignition key to "parking" position. Restore connections, disconnect connector of air bag capsule R23 on steering wheel and connect a 2 ohms resistor between connector pins (GRY-GRN and LT BLU wires). With ignition key to "run" position, check that warning lamp illuminates for 5 sec. and then extinguishes definitively.</li> </ul>	 	Replace <b>module R23</b>  Repair wiring between <b>control unit R22 and capsule R23</b>
I3	AIR BAG WARNING LAMP CHECK	
<ul style="list-style-type: none"> <li>- Check that warning lamp illuminates for 5 sec., extinguishes for 1/2 sec. and than illuminates definitively</li> </ul>	 	Repeat <b>memory reset procedure of control unit R22</b>  Replace <b>control unit R22</b>

End of test I







## CURRENT SHORTED TO GROUND

TEST J  
CODE 34

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Before carrying-out this test, set ignition key to "parking" position, disconnect connector A of control unit R22 and connect a 4ohms resistor between pins 1 and 2 of above mentioned connector. Reset memory of control unit R22 disconnecting pin 6B from ground for 3 sec., reconnecting it for 3 sec. and disconnecting it definitively.</p>			
J1	AIR BAG WARNING LAMP CHECK		
<ul style="list-style-type: none"> <li>- Set ignition key to "run" position and check that AIR BAG warning lamp illuminates for 5 sec. and then extinguishes definitively</li> </ul>		 ►  ►	Carry-out step J2  Carry-out step J3
J2	AIR BAG WARNING LAMP CHECK		
<ul style="list-style-type: none"> <li>- Set ignition key to "parking" position. Restore connections, disconnect connector of air bag capsule R23 on steering wheel and connect a 2 ohms resistor between connector pins (GRY-GRN and LT BLU wires). With ignition key to "run" position, check that warning lamp illuminates for 5 sec. and then extinguishes definitively.</li> </ul>		 ►  ►	Replace module R23  Repair wiring between control unit R22 and capsule R23
J3	AIR BAG WARNING LAMP CHECK		
<ul style="list-style-type: none"> <li>- Check that warning lamp illuminates for 5 sec., extinguishes for 1/2 sec. and than illuminates definitively</li> </ul>		 ►  ►	Repeat memory reset procedure of control unit R22  Replace control unit R22

End of test J

<b>OPEN CIRCUIT</b>	<b>TEST K CODE 35</b>
---------------------	---------------------------

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Before carrying-out this test, set ignition key to "parking" position, disconnect connector A of control unit R22 and connect a 4ohms resistor between pins 1 and 2 of above mentioned connector. Reset memory of control unit R22 disconnecting pin 6B from ground for 3 sec., reconnecting it for 3 sec. and disconnecting it definitively.</p>		
<b>K1</b> AIR BAG WARNING LAMP CHECK <ul style="list-style-type: none"> <li>- Set ignition key to "run" position and check that AIR BAG warning lamp illuminates for 5 sec. and then extinguishes definitively</li> </ul>	 	Carry-out step K2  Carry-out step K3
<b>K2</b> AIR BAG WARNING LAMP CHECK <ul style="list-style-type: none"> <li>- Set ignition key to "parking" position. Restore connections, disconnect connector of air bag capsule R23 on steering wheel and connect a 2 ohms resistor between connector pins (GRY-GRN and LT BLU wires). With ignition key to "run" position, check that warning lamp illuminates for 5 sec. and then extinguishes definitively.</li> </ul>	 	Replace module R23  Repair wiring between control unit R22 and capsule R23
<b>K3</b> AIR BAG WARNING LAMP CHECK <ul style="list-style-type: none"> <li>- Check that warning lamp illuminates for 5 sec., extinguishes for 1/2 sec. and than illuminates definitively</li> </ul>	 	Repeat memory reset procedure of control unit R22  Replace control unit R22

End of test K

<b>FAULTY SQUIB</b>	<b>TEST L CODE 36</b>
---------------------	---------------------------

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Before carrying-out this test, set ignition key to "parking" position, disconnect connector A of control unit R22 and connect a 4ohms resistor between pins 1 and 2 of above mentioned connector. Reset memory of control unit R22 disconnecting pin 6B from ground for 3 sec., reconnecting it for 3 sec. and disconnecting it definitively.</p>		
<b>L1</b> AIR BAG WARNING LAMP CHECK	 ►  ►	Carry-out step L2
- Set ignition key to "run" position and check that AIR BAG warning lamp illuminates for 5 sec. and then extinguishes definitively		Carry-out step L3
<b>L2</b> AIR BAG WARNING LAMP CHECK	 ►  ►	Replace module R23
- Set ignition key to "parking" position. Restore connections, disconnect connector of air bag capsule R23 on steering wheel and connect a 2 ohms resistor between connector pins (GRY-GRN and LT BLU wires). With ignition key to "run" position, check that warning lamp illuminates for 5 sec. and then extinguishes definitively.		Repair wiring between control unit R22 and capsule R23
<b>L3</b> AIR BAG WARNING LAMP CHECK	 ►  ►	Repeat memory reset procedure of control unit R22
- Check that warning lamp illuminates for 5 sec., extinguishes for 1/2 sec. and than illuminates definitively		Replace control unit R22

















End of test L

## FAILURE OF AIR BAG WARNING LAMP

TEST M  
CODE 41-42

TEST STEPS		RESULTS	REMEDY
M1	WARNING LAMP ILLUMINATION CHECK		
	- Set ignition key to "run" position and check that AIR BAG warning lamp on instrument panel illuminates steady	 ►  ►	Carry-out step M2  Carry-out step M3
M2	WARNING LAMP ILLUMINATION CHECK		
	- Remove ignition key and disconnect connector B of air bag control unit R22. Set ignition key to "run" position and check again that warning lamp illuminates	 ►  ►	Repair wiring between pin 4 of connector B of control unit R22 and pin 4D of Instrument panel C10  Replace air bag control unit R22
M3	WARNING LAMP ILLUMINATION CHECK		
	- Remove ignition key then set to "run" position and check for presence of 0V (zero) at pin 4B of control unit R22	 ►  ►	Carry-out step M4  Replace air bag control unit R22
M4	GROUNDING CHECK		
	- Remove ignition key then set to "run" position and check for presence of 0V (zero) at pin 4D of instrument panel C10	 ►  ►	Replace warning lamp on instrument panel C10  Repair wiring between pin 4B of control unit R22 and pin 4D of Instrument panel C10

End of test M

<b>FAULTY DIAGNOSTIC UNIT</b>	<b>TEST N CODE 51</b>
-------------------------------	---------------------------

	TEST STEPS	RESULTS	REMEDY
N1	CONTROL UNIT CHECK		
	<ul style="list-style-type: none"> <li>- Set ignition key to "parking" position, reset failure code by pin 6B of control unit R22 and check that only code 51 remains in memory</li> </ul>	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center; gap: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="font-size: 24px;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="font-size: 24px;">▶</div> </div> </div>	<p>Replace control unit R22</p> <p>Carry-out trouble-shooting procedure of displayed code</p>

End of test N



## AIR BAG SYSTEM ACTIVATED


TEST O  
CODE 52-53-54

TEST STEPS		RESULTS	REMEDY
<b>O1</b>	<b>AIR BAG CHECK</b>		
- Check that after a crash system is activated		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Recover car to Alfa Romeo service station for restoring air bag system</p> <p>Carry-out step O2</p>
<b>O2</b>	<b>CODE CHECK</b>		
- Reset failure code by pin 6B of control unit R22 and check that codes other than 52-53-54 are in memory		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Carry-out troubleshooting procedure of displayed codes</p> <p>Replace control unit R22</p>

End of test O


# AIR CONDITIONING SYSTEM


**BASE AND L ONLY**





**S ONLY**





**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>



## GENERAL

The automatic air conditioning system, whose operation is controlled by an electronic control unit, maintains a constant temperature selected on the display, independently from the environmental and driving conditions.

The air conditioning system can be operated manually or automatically.

In both cases the system is monitored automatically, and is able to reach, very fast, the desired internal conditions. The system includes some sensors that send electric signals, related to measured variables, to the control unit which after an appropriate process, sends to the actuators the command signals needed to keep the internal temperature to the desired value. The system automatically selects and changes air distribution and fan speed according to the internal and external temperature.

The system is provided with a memory that maintains the temperatures and the functions selected before the engine is turned off.

At each subsequent engine start, the previously selected characteristics are already set.

The display, located in the air conditioning lower left section reads the external temperature.

If the car is driven at a speed lower than 19 MPH, the display reads the temperature shown before undergoing this speed.

When the car overcomes the speed of 19 MPH, the display reads again the real external temperature.



### WARNING:

The road pavement temperature may be lower than the air temperature sensed by the sensor, thus during cold season, it is possible to have an icy road while the display reads a temperature greater than 0°C.

Selecting the automatic mode, the system operates automatically and the driver selects only the desired internal temperature.

The time needed to reach the selected temperature depends on several parameters, among them the difference between the internal and external temperatures and

the number of passengers.

It is necessary to wait for some time, always variable, before obtaining the desired internal conditions.

It is advisable not to push the keys to change air distribution or fan speed till the system has reached the normal operation, indicated by a decrease in fan speed.

With high external temperature, to reduce the time for the transient phase until the selected condition is obtained, the system does not allow any external air inlet, and operates under recycle mode. The selection of fan speed or of the air distribution, automatically controlled by the system, can be changed by pressing one of the pushbuttons for the fan speed or air distribution.

Anyway, the temperature control is still accomplished automatically.

To return to the previous operation and to automatic operation, it is necessary to push the AUTO button.

### NOTES


- At low external temperatures, the air conditioning automatically stops.
- To allow the air conditioning to operate at the best conditions, it is advisable to fully close window and sun roof. If the vehicle has been exposed for a long time to sunlight and the interior is very hot, after switching on the air conditioning system, it is necessary to open the windows to recycle internal air.
- To make sure the system is operating correctly, it is advisable to regularly clean the air conditioning condenser.

By the pushbuttons of the air conditioning system it is possible to:


- Switch off conditioner (ECON pushbutton).
- Select the desired temperature ( ▲ and ▼ pushbuttons).
- Manually vary fan speed (pushbuttons 1, 2, 3, 4).
- Switch off the system (OFF pushbutton).
- Select the system automatic mode (AUTO pushbutton).

- Send the air flow where desired.
- Send the air flow toward the windshield for defogging.
- Switch on the rear window defogging.
- Close the external air inlet to obtain an internal air recirculation.

The control unit which monitors the system is equipped with a special self-test program. This program detects any malfunction within the system and shows it on the display used to select the desired temperature.

To start the self-test program, push simultaneously the automatic operation (AUTO) and the air flow toward down buttons (  ).

The self-test program lasts for 20 sec. then it displays the system malfunctions.

Pressing each time the button (  ), the display shows the malfunction according to an appropriate code.

## FUNCTIONAL DESCRIPTION

The air conditioning system is monitored by the automatic control mode check unit **Q21A**.

The control unit **Q21A** is powered on pins 1, 18 and 19 through appropriate protection fuses.

The battery voltage (12V), present also when with the ignition key is set to "park", is connected to:

- **Q21A** unit (pin 18) through fuse **F17+DIRECT FOR Q21A** of the fuse box **G1**.
- **Q21A** unit (pin 1) through fuse **F1+POSITION LAMP FOR Q21A** of the fuse box **G1**.

The voltage (12V) present when the ignition key is set to "run" is connected to:

- **Q21A** (pin 19) unit by means of electronic control units power supply relay **I51**.
- Heater blower relay **Q15** and electro-magnetic coupling control relay **Q22** through fuse **F12 AUTOMATIC AIR CONDITIONING RELAY**.

With position lamps on, the parking lamps control unit **N41** connects to **Q21A** unit pin 2 the voltage (12V) needed to illuminate the serigrafis located on the air conditioning control panel.

This line is protected by fuse **F1+POSITION LAMPS FOR Q21A** of the fuse box **G1**.

Pin 5E of fuse box **G1** connects 12V to **Q21A** unit pin 23, through a rheostat used to change the intensity of the control panel indicator lamps.

**Q21A** unit, through pins 29, 14 and 15, energizes respectively:

- The external rearview mirrors defogging relay **I45** (see rear window defogging circuit).
- The front fog lamps relay **I17** (see fog head and rear lamps circuit).
- The rear fog lamps relay **I25** (see fog head and rear lamps circuit).

**Q21A** unit sends to Motronic control unit **S11**, through the electro-magnetic coupling control relay **Q22** contacts, a signal of air conditioning system activation, to allow the engine idle speed to compensate for the new power request due to air conditioning system operation.

Relay **Q22** is energized by control unit **Q21A** when the coolant fluid pressure is at minimum. If the pressure becomes greater than the maximum value, **Q21A** unit removes power from coupling **Q11**.

The relay **Q22** energizing power is controlled by the anti-frost thermostat **Q26** which removes power in case presence of ice is detected on the evaporating valves.

The speed sensor sends to **Q21A** unit a signal corresponding to car speed so as to disconnect the outside air temperature sensor **Q24** when the speed decreases below 19 MPH. The cabin interior temperature sensor (with motor) **Q33** is powered through the supplementary fuse box **G2** (see electronic control units power relay circuit).

The signals, corresponding to the internal temperature, are sent by the sensor **Q33** to **Q21A** unit pins 3 and 12 and to mixed air temperature sensor **Q25**.

To improve and to keep real the internal temperature sensing, the air is taken from the cabin and blowed on the

sensor by a small fan controlled by **Q21A** unit (pin 32). **Q21A** unit receives from the outside air temperature sensor **Q24** a signal corresponding to the external temperature (pin 12 and 21) and uses this information to adjust the temperature of the air sent to the cabin in accordance to the value selected on the control panel.

To adjust the mixing and distribution of the air within the automatic air conditioning, **Q21A** unit controls the ventilation distribution motor **Q30A** (pins 30, 24, 22, 5) and warm/cool air blend motor **Q30B** (pins 6, 7, 8, 9).

By pin 27 the control unit controls air conditioning unit fan speed control **Q31**.

The command to **Q31** is provided according to external temperature, internal temperature and temperature selected on the display.

12V power reaches **Q31** regulator through heater blower relay **Q15** contacts. This line is protected by fuse **G255** AIR CONDITIONING FAN.

Relay **Q15** is energized by a 12V power line protected by fuse **F12** automatic AIR CONDITIONING RELAY of the fuse box **G1**.

Speed control **Q31**, powered in this way, adjusts the speed of the fan **Q1**, also powered by a contact of **Q15**. **Q21A** unit sends, through pin 26, a speed regulation signal to the heater blower electric fan **Q1** and to the speed control **Q31**.



Pressing the recycle button on the control panel, a signal from **Q21A** unit controls the recycle door position.

In this way it is possible to introduce in the mixing system air taken from the cabin and then cooled and demisted by


the air conditioning circuit. The control signal from control unit on pins 10 and 11 sent to the air recirculation flap control motor **Q27** is able to move door to "recycle" or "external air" positions without intermediate positions.

On the system control panel is located the trunk opening pushbutton; when it is pressed, the unit **Q21A** grounds its output pin 17 activating the corresponding function. For more details see the related circuit.


## SELF-TEST CIRCUIT - GENERAL INFORMATION













The self-test program is activated, with ignition key to position "run", by simultaneous pressing of button AUTO and button , and releasing button AUTO first and button  successively.

The self-test program starts showing bars on the display "desired internal temperature", lasting for 20 sec., and then, if malfunctions are detected, the display will show their quantity.

At this point, press button  for the times corresponding to malfunctions number. Each time the button is pressed, the display shows a code that identifies the type of malfunction and the affected component.


The code is composed of two digits; the first number or letter identifies the faulty component (i.e. number 2 identifies the external air sensor) while the second letter identifies the malfunction type (i.e. C indicates short).

After the self-test, press again button  to proceed with the system operation.

Instrument panel	<b>C10</b> <b>A</b>	Instrument panel	<b>C10</b> <b>C</b>
<p><b>S ONLY</b></p>  <p>GRY • G164 G252c G242 PIN 2</p>		<p><b>S ONLY</b></p>  <p>Pnk-Blk • G151 GRY • G151</p>	
Fuse box	<b>G1</b> <b>A</b>	Fuse box	<b>G1</b> <b>B</b>
 <p>5 WHT • G164 10 YEL-RED • G164 9 GRY-YEL • G164 8 ORN-BLK • G164</p>		 <p>1 GRY-RED • G164</p>	
Fuse box	<b>G1</b> <b>E</b>	Fuse box	<b>G1</b> <b>G</b>
 <p>10 WHT-BLK • G185 8 1PNK • G185</p>		 <p>3 1.5YEL-BLK • N41</p>	
Fuse box	<b>G1</b> <b>N</b>	Fuse box	<b>G1</b> <b>O</b>
 <p>2 4RED • HOT AT ALL TIMES 3 150 PIN 30</p>		 <p>4 25PNK • HOT IN RUN</p>	
Fuse box	<b>G1</b> <b>S</b>	Engine compartment ground connection	<b>G53</b>
 <p>2 B16 PIN U</p>		 <p>2.5BLK • Q11</p>	
Central bulkhead ground	<b>G143</b>	Connector, circuit board to engine compartment left side wiring	<b>G150</b>
 <p>1BLK • Q20 4BLK • Q91 1.5BLK • G150 1BLK • Q15</p>		 <p>1.5BLK • G164 1.5BLK • G143</p>	

(Cont.d)










(Cont.d)

<p>Connector, circuit board to right rear wiring</p>	<p><b>G170</b></p>	<p>Connector, left rear wiring to dome lamp wiring</p>	<p><b>G179</b></p>
<p>Left rear wiring connector - Air conditioning wiring</p>	<p><b>G253</b></p>		
		<p>Air conditioning fan fuse - 40A</p> <p><b>G255</b></p>	
<p>Speedometer sensor</p>	<p><b>L17</b></p>	<p>Parking lamps control unit</p>	<p><b>N41</b></p>
<p>Heater blower electric fan</p>	<p><b>Q1</b></p>	<p>Compressor electro-magnetic coupling</p>	<p><b>Q11</b></p>
<p>Air conditioning electric fan relay</p>	<p><b>Q15</b></p>	<p>Min/max pressure switch (trinary)</p>	<p><b>Q20</b></p>

(Cont.d)




(Cont.d)


<p>Ventilation distribution motor</p>	<p><b>Q30A</b></p>	<p>Warm/cool air blend motor</p>	<p><b>Q30B</b></p>
<p>(A) TO VENTILATION DISTRIBUTION MOTOR</p> 		<p>(B) TO WARM/COOL AIR BLEND MOTOR</p> 	
<p>Air conditioning unit fan speed control</p>	<p><b>Q31</b></p>	<p>Cabin interior temperature sensor (with motor)</p>	<p><b>Q33</b></p>
			



**BASE AND L ONLY**



**S ONLY**









## ON BOARD SELF-TEST - TROUBLESHOOTING TABLE

CODE	MALFUNCTION	TEST REFERENCE
1U	- Open circuit on cabin air temperature sensor.	A
1C	- Cabin air temperature sensor shorted to ground.	B
2U	- Open circuit on external air temperature sensor.	C
2C	- External air sensor shorted to ground.	D
3U	- Open circuit on mixed air temperature sensor.	E
3C	- Mixed air sensor shorted to ground.	F
5U	- Open circuit on air mixing door motor.	G
5C	- Air mixing door motor shorted to ground.	H
6U	- Open circuit on air distribution door motor.	I
6C	- Air distribution door motor shorted to ground.	J
7U	- Condition of open circuit on recirculation door motor.	K
7C	- Recirculation door motor shorted to ground.	L
8U	- Open or short circuit between speed regulator and electric fan.	M
8C	- Faulty speed regulator. - Short between speed regulator and control unit.	N
EU	- Faulty control unit.	Replace control unit Q21A
<b>NOTE:</b> If the air conditioning system is inoperative and no signal appears on the display, carry-out TEST O - AUTOMATIC AIR CONDITIONING INOPERATIVE.		O

**OPEN CIRCUIT ON CABIN INTERIOR TEMPERATURE SENSOR**









**TEST A  
CODE 1U**

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>CONTINUITY CHECK</b>		
	- Check for continuity between pin 3 of control unit Q21A connector and pin 2 of connector G253	 	Carry-out <b>step A2</b>  Repair or replace <b>cables, as required</b>
<b>A2</b>	<b>CONTINUITY CHECK</b>		
	- Check for continuity between pin 2 of connector G253 and pin 8 of connector G179	 	Carry-out <b>step A3</b>  Repair or replace <b>cables, as required</b>
<b>A3</b>	<b>CONTINUITY CHECK</b>		
	- Check for continuity between pin 8 of connector G179 and pin 2 of cabin interior temperature sensor Q33	 	Replace <b>sensor Q33</b>  Repair or replace <b>cables, as required</b>

End of test A

## CABIN INTERIOR TEMPERATURE SENSOR SHORTED TO GROUND

TEST B  
CODE 1C

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>GROUNDING CHECK</b>		
- Check for absence short circuit between pins 3 and 12 of control unit <b>Q21A</b>		 ▶  ▶	Replace control unit <b>Q21A</b>  Carry-out step B2
<b>B2</b>	<b>GROUNDING CHECK</b>		
- Check for absence of short circuit between pins 2 and 3 of connector <b>G253</b>		 ▶  ▶	Repair wiring between pins 2 and 3 of <b>G253</b> and pins 3 and 12 of control unit <b>Q21A</b>  Carry-out step B3
<b>B3</b>	<b>GROUNDING CHECK</b>		
- Check for absence short circuit between pins 8 and 9 of connector <b>G179</b>		 ▶  ▶	Repair wiring between pins 8 and 9 of connector <b>G179</b> and pins 2 and 3 of <b>G253</b>  Carry-out step B4
<b>B4</b>	<b>GROUNDING CHECK</b>		
- Check for absence short circuit exists between pins 2 and 3 of cabin interior temperature sensor <b>Q33</b>		 ▶  ▶	Repair wiring between pins 2 and 3 of sensor <b>Q33</b> pins 8 and 9 of <b>G179</b>  Replace sensor <b>Q33</b>

End of test B









<b>OPEN CIRCUIT OF OUTSIDE AIR TEMPERATURE SENSOR</b>	<b>TEST C CODE 2U</b>
---	---------------------------

TEST STEPS	RESULTS	REMEDY		
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 5%; padding: 5px;"><b>C1</b></td> <td style="padding: 5px;"><b>CONTINUITY CHECK</b></td> </tr> </table> <ul style="list-style-type: none"> <li>- Check for continuity between:                             <ul style="list-style-type: none"> <li>• pin 21 of control unit <b>Q21A</b>, and pin 2 of outside air temperature sensor <b>Q24</b></li> <li>• pin 12 of control unit <b>Q21A</b> and pin 1 of outside air temperature sensor <b>Q24</b></li> </ul> </li> </ul>	<b>C1</b>	<b>CONTINUITY CHECK</b>	<div style="display: flex; flex-direction: column; align-items: center; gap: 20px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div> </div>	<p>Replace <b>sensor Q24</b></p> <p>Repair or replace <b>cables, as required</b></p>
<b>C1</b>	<b>CONTINUITY CHECK</b>			

End of test C

## OUTSIDE AIR TEMPERATURE SENSOR SHORTED TO GROUND

TEST D  
CODE 2C

TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>GROUNDING CHECK</b>		
	- Check for absence of short circuit between pins 12 and 21 of control unit <b>Q21A</b>	 	Replace control unit <b>Q21A</b>
		 	Carry-out step D2
<b>D2</b>	<b>GROUNDING CHECK</b>		
	- Check for absence of short circuit between pins 1 and 2 of outside air temperature sensor <b>Q24</b>	 	Repair wiring between pins 1 and 2 of sensor <b>Q24</b> and pins 12 and 21 of control unit <b>Q21A</b>
		 	Replace sensor <b>Q24</b>

End of test D

**OPEN CIRCUIT ON MIXED ON AIR TEMPERATURE SENSOR**

**TEST E  
CODE 3U**

TEST STEPS		RESULTS	REMEDY
<b>E1</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pin 12 of automatic control mode check unit <b>Q21A</b> connector and pin 3 of connector <b>G253</b>		(OK)      ► ( <del>OK</del> )      ►	Carry-out step <b>E2</b>  Repair or replace cables, as required
<b>E2</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pin 3 of connector <b>G253</b> and mixed air temperature sensor <b>Q25</b> (PPL-BLK wire)		(OK)      ► ( <del>OK</del> )      ►	Carry-out step <b>E3</b>  Repair or replace cables, as required
<b>E3</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between mixed air temperature sensor <b>Q25</b> (PPL-BLK, wire) and pin 9 of connector <b>G179</b>		(OK)      ► ( <del>OK</del> )      ►	Carry-out step <b>E4</b>  Repair or replace cables, as required
<b>E4</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pin 9 of connector <b>G179</b> and pin 3 of cabin interior temperature sensor <b>Q33</b>		(OK)      ► ( <del>OK</del> )      ►	Carry-out step <b>E5</b>  Repair or replace cables, as required

(Cont.d)



OPEN CIRCUIT ON MIXED ON AIR TEMPERATURE SENSOR

TEST E  
CODE 3U

TEST STEPS		RESULTS	REMEDY
E5	CONTINUITY CHECK		
<ul style="list-style-type: none"> <li>- Check for continuity between pin 4 of control unit Q21A connector and mixed air temperature sensor Q25 (PPL-WHT, wire)</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace sensor Q25</p> <p>Repair or replace cables, as required</p>

End of test E

**MIXED AIR TEMPERATURE SENSOR SHORTED TO GROUND**

**TEST F  
CODE 3C**

TEST STEPS		RESULTS	REMEDY
<b>F1</b>	<b>OPEN CIRCUIT CHECK</b>		
	- Check for open circuit between pins 4 and 12 of control unit <b>Q21A</b> connector	(OK)      ▶ (OK)      ▶	Replace control unit <b>Q21A</b>  Carry-out step <b>F2</b>
<b>F2</b>	<b>OPEN CIRCUIT CHECK</b>		
	- Check for open circuit between mixed air temperature sensor <b>Q25</b> terminal and pin 3 of connector <b>G253</b>	(OK)      ▶ (OK)      ▶	Repair connection between pin 3 of connector <b>G253</b> and pin 12 of control unit <b>Q21A</b>  Replace sensor <b>Q25</b>

End of test F

## OPEN CIRCUIT ON AIR BLEND MOTOR

TEST G  
CODE 5U

TEST STEPS		RESULTS	REMEDY
<b>G1</b>	<b>12V CHECK</b>		
<ul style="list-style-type: none"> <li>- With ignition key set to "run", check for presence of 12V on pin 5 of warm/cool air blend motor <b>Q30B</b></li> </ul>		<p style="text-align: center;">(OK)    ▶</p> <p style="text-align: center;"><del>(OK)</del>    ▶</p>	<p>Carry-out step G2</p> <p>Carry-out step G3</p>
<b>G2</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for continuity between pins: <ul style="list-style-type: none"> <li>• 1 of warm/cool air blend motor <b>Q30B</b> and 6 of control unit <b>Q21A</b> connector</li> <li>• 2 of warm/cool air blend motor <b>Q30B</b> and 7 of control unit <b>Q21A</b> connector</li> <li>• 3 of warm/cool air blend motor <b>Q30B</b> and 8 of control unit <b>Q21A</b> connector</li> <li>• 4 of warm/cool air blend motor <b>Q30B</b> and 9 of control unit <b>Q21A</b> connector</li> </ul> </li> </ul>		<p style="text-align: center;">(OK)    ▶</p> <p style="text-align: center;"><del>(OK)</del>    ▶</p>	<p>Replace motor <b>Q30B</b></p> <p>Repair or replace cables, as required</p>
<b>G3</b>	<b>12V CHECK</b>		
<ul style="list-style-type: none"> <li>- With ignition key set to "run", check for presence of 12V on pin 2 of connector <b>G164</b></li> </ul>		<p style="text-align: center;">(OK)    ▶</p> <p style="text-align: center;"><del>(OK)</del>    ▶</p>	<p>Repair connection between pin 2 of <b>G164</b> and pin 5 of motor <b>Q30B</b></p> <p>Malfunction of electronic control units power relay, refer to applicable troubleshooting</p>

End of test G

## AIR BLEND MOTOR SHORTED TO GROUND







TEST H  
CODE 5C

TEST STEPS		RESULTS	REMEDY
H1	OPEN CIRCUIT CHECK		
<p>- Check for open circuit between pins:</p> <ul style="list-style-type: none"> <li>• 6 and 7 of control unit Q21A connector</li> <li>• 6 and 8 of control unit Q21A connector</li> <li>• 6 and 9 of control unit Q21A connector</li> <li>• 7 and 8 of control unit Q21A connector</li> <li>• 7 and 9 of control unit Q21A connector</li> <li>• 8 and 9 of control unit Q21A connector</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace control unit Q21A</p> <p>Carry-out step H2</p>
H2	OPEN CIRCUIT CHECK		
<p>- Check for open circuit between pins:</p> <ul style="list-style-type: none"> <li>• 1 and 2 of air blend motor Q30B connector</li> <li>• 1 and 3 of air blend motor Q30B connector</li> <li>• 1 and 4 of air blend motor Q30B connector</li> <li>• 2 and 3 of air blend motor Q30B connector</li> <li>• 2 and 4 of air blend motor Q30B connector</li> <li>• 3 and 4 of air blend motor Q30B connector</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair or replace cables, as required</p> <p>Replace motor Q30B</p>

End of test H

## OPEN CIRCUIT ON VENTILATION DISTRIBUTION MOTOR

TEST I  
CODE 6U

TEST STEPS		RESULTS	REMEDY
I1	12V CHECK		
<ul style="list-style-type: none"> <li>- With ignition key set to "run", check for presence of 12V on pin 12 of ventilation distribution motor Q30A</li> </ul>		 ►  ►	Carry-out step I2  Carry-out step I3
I2	CONTINUITY CHECK		
<ul style="list-style-type: none"> <li>- Check for continuity between pins:               <ul style="list-style-type: none"> <li>• 8 of pin ventilation distribution motor Q30A and 5 of control unit Q21A</li> <li>• 9 of ventilation distribution motor Q30A and 22 of control unit Q21A</li> <li>• 10 of ventilation distribution motor Q30A and 24 of control unit Q21A</li> <li>• 11 of ventilation distribution motor Q30A and 30 of control unit Q21A</li> </ul> </li> </ul>		 ►  ►	Replace motor Q30A  Repair or replace cables, as required
I3	12V CHECK		
<ul style="list-style-type: none"> <li>- With ignition key set to "run", check for presence of 12V between pin 2 of connector G164 and ground</li> </ul>		 ►  ►	Repair wiring between pin 2 of G164 and pin 12 of motor Q30A  Malfunction of electronic control units power relay, refer to applicable troubleshooting

End of test I

**VENTILATION DISTRIBUTION MOTOR SHORTED TO GROUND**

**TEST J  
CODE 6C**

TEST STEPS		RESULTS	REMEDY
<b>J1</b>	<b>OPEN CIRCUIT CHECK</b>		
<p>- Check for open circuit between pins:</p> <ul style="list-style-type: none"> <li>• 5 and 22 of control unit <b>Q21A</b> connector</li> <li>• 5 and 24 of control unit <b>Q21A</b> connector</li> <li>• 5 and 30 of control unit <b>Q21A</b> connector</li> <li>• 22 and 24 of control unit <b>Q21A</b> connector</li> <li>• 22 and 30 of control unit <b>Q21A</b> connector</li> <li>• 24 and 30 of control unit <b>Q21A</b> connector</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace control unit <b>Q21A</b></p> <p>Carry-out step <b>J2</b></p>
<b>J2</b>	<b>OPEN CIRCUIT CHECK</b>		
<p>- Check for open circuit between pins:</p> <ul style="list-style-type: none"> <li>• 8 and pin 9 of ventilation distribution motor <b>Q30A</b> connector</li> <li>• 8 and 10 of ventilation distribution motor <b>Q30A</b> connector</li> <li>• 8 and 11 of ventilation distribution motor <b>Q30A</b> connector</li> <li>• 9 and 10 of ventilation distribution motor <b>Q30A</b> connector</li> <li>• 9 and 11 of ventilation distribution motor <b>Q30A</b> connector</li> <li>• 10 and 11 of ventilation distribution motor <b>Q30A</b> connector</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair or replace cables, as required</p> <p>Replace motor <b>Q30A</b></p>

End of test J

## OPEN CIRCUIT ON AIR RECIRCULATION FLAP CONTROL MOTOR

TEST K  
CODE 7U

TEST STEPS		RESULTS	REMEDY
<b>K1</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for continuity between pins:               <ul style="list-style-type: none"> <li>• 11 of control unit <b>Q21A</b> connector and pin 1 of air recirculation flap control motor <b>Q27</b></li> <li>• 10 of control unit <b>Q21A</b> connector and pin 2 of air recirculation flap control motor <b>Q27</b></li> </ul> </li> </ul>		<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; margin-right: 10px;">OK</div> <div style="font-size: 2em; margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 2em; margin-right: 10px;">▶</div> </div> </div>	<p>Replace motor <b>Q27</b></p> <p>Repair or replace cables, as required</p>

End of test K









<b>AIR RECIRCULATION FLAP CONTROL MOTOR SHORTED TO GROUND</b>	<b>TEST L CODE 7C</b>
---	---------------------------

	TEST STEPS	RESULTS	REMEDY
L1	OPEN CIRCUIT CHECK		
	<ul style="list-style-type: none"> <li>- Check for open circuit between pins 11 and 10 of control unit Q21A connector</li> </ul>	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div> </div>	<p>Replace control unit Q21A</p> <p>Carry-out step L2</p>
L2	OPEN CIRCUIT CHECK		
	<ul style="list-style-type: none"> <li>- Check for open circuit between pins 1 and 2 of air recirculation flap control motor Q27</li> </ul>	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div> </div>	<p>Replace motor Q27</p> <p>Repair or replace cables, as required</p>

End of test L



**OPEN OR SHORT CIRCUIT BETWEEN SPEED CONTROL AND ELECTRIC FAN**
**TEST M  
CODE 8U**

TEST STEPS		RESULTS	REMEDY
<b>M1</b>	<b>FUSE CHECK</b>		
- Check for integrity of <b>G255</b>		 ►  ►	Carry-out step <b>M2</b>  Replace fuse <b>G255</b>
<b>M2</b>	<b>FUSE CHECKE</b>		
- Check fuse <b>F12</b> in fuse box <b>G1</b> for integrity		 ►  ►	Carry-out step <b>M3</b>  Replace fuse <b>F12</b>
<b>M3</b>	<b>VOLTAGE CHECK</b>		
- With ignition key set to "run", check for presence of 12V between pin 1 of fan speed control <b>Q31</b> and ground		 ►  ►	Carry-out step <b>M4</b>  Carry-out step <b>M7</b>
<b>M4</b>	<b>VOLTAGE CHECK</b>		
- With ignition key set to "run", check for presence of 12V between pin 1 of electric fan <b>Q1</b> and ground		 ►  ►	Carry-out step <b>M5</b>  Carry-out step <b>M7</b>

(Cont.d)

**OPEN OR SHORT CIRCUIT BETWEEN SPEED CONTROL AND ELECTRIC FAN**









**TEST M  
CODE BU**

TEST STEPS		RESULTS	REMEDY
<b>M5</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pins: <ul style="list-style-type: none"> <li>• 4 of fan speed control <b>Q31</b> and ground point <b>G143</b></li> <li>• 3 of fan speed control <b>Q31</b>, and pin 2 of electric fan <b>Q1</b></li> <li>• 3 of fan speed control <b>Q31</b> and pin 26 of control unit <b>Q21A</b> connector</li> <li>• 2 of fan speed control <b>Q31</b> and pin 27 of control unit <b>Q21A</b> connector</li> </ul>		(OK)      ► (OK)      ►	Carry-out step <b>M6</b>  Repair or replace cables, as required
<b>M6</b>	<b>OPEN CIRCUIT CHECK</b>		
- Check for open circuit between pins: <ul style="list-style-type: none"> <li>• 3 of fan speed control <b>Q31</b> and ground</li> <li>• 2 of fan speed control <b>Q31</b> and ground</li> </ul>		(OK)      ► (OK)      ►	Replace fan speed control <b>Q31</b> and/or fan <b>Q1</b>  Repair or replace cables, as required
<b>M7</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 87 of relay <b>Q15</b> and ground		(OK)      ► (OK)      ►	Repair wiring between pin 87 of relay <b>Q15</b> and pin 1 of control <b>Q31</b> , or between pin 87 of relay <b>Q15</b> and pin 1 of fan <b>Q1</b>  Carry-out step <b>M8</b>

(Cont.d)

OPEN OR SHORT CIRCUIT BETWEEN SPEED CONTROL AND ELECTRIC FAN

TEST M  
CODE 8V

TEST STEPS		RESULTS	REMEDY
<b>M8</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 30 of relay Q15 and ground		 	Carry-out step M10  Carry-out step M9
<b>M9</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin of fuse G255 (RED wire) and ground		 	Repair wiring between pin 30 of relay Q15 and fuse G255  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>M10</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 86 of relay Q15 and ground		 	Carry-out step M11  Carry-out step M12
<b>M11</b>	<b>RELAY CHECK</b>		
- Check relay Q15 for proper operation		 	Repair wiring between pin 85 of relay Q15 and ground point G143  Replace relay Q15

(Cont.d)

OPEN OR SHORT CIRCUIT BETWEEN SPEED CONTROL AND ELECTRIC FAN

TEST M  
CODE 8U

TEST STEPS		RESULTS	REMEDY
M12	VOLTAGE CHECK		
- Check for presence of 12V on pins 30 and 86 of electromagnetic coupling control relay Q22		(OK)      ► (OK)      ►	Repair wiring between pin 86 and 30 of relay Q22 and pin 86 of relay Q15  Carry-out step M13
M13	VOLTAGE CHECK		
- With the ignition key set to "run", check for presence of 12V between pin 1 of connector G165 and ground		(OK)      ► (OK)      ►	Repair wiring between pin 1 of G165 and pin 86 and 30 of relay Q22  Carry-out step M14
M14	VOLTAGE CHECK		
- With the ignition key set to "run", check for presence of 12V between pin 40 of fuse box G1 and ground		(OK)      ► (OK)      ►	Repair wiring between pin 1 of G165 and pin 6E of fuse box G1  Failure of the power distribution, circuit, refer to the relevant circuit of sheet 2 of 2









End of test M

**FAULTY SPEED CONTROL OR SHORT BETWEEN SPEED CONTROL AND CONTROL UNIT**
**TEST N  
CODE 8C**

TEST STEPS		RESULTS	REMEDY
<b>N1</b>	<b>OPEN CIRCUIT CHECK</b>		
	- Check for open circuit between pin 27 and ground on control unit <b>Q21A</b>	<del>OK</del> ▶	Replace control unit <b>Q21A</b>
		<del>OK</del> ▶	Carry-out step N2
<b>N2</b>	<b>OPEN CIRCUIT CHECK</b>		
	- Check for open circuit toward ground on pin 2 of fan speed control <b>Q31</b>	OK ▶	Repair wiring between pin 2 of control <b>Q31</b> and pin 27 of control unit <b>Q21A</b>
		<del>OK</del> ▶	Replace fan speed control <b>Q31</b>

**End of test N**

















<b>AUTOMATIC AIR CONDITIONING SYSTEM INOPERATIVE</b>	<b>TEST O</b>
--	---------------

	TEST STEPS	RESULTS	REMEDY
<b>O1</b>	<b>FUSES CHECK</b>		
	- Check for integrity of fuses F12 and F17	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p>Carry-out step O2</p> <p>Replace fuses</p>
<b>O2</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 11 of connector G164 and ground	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p>Carry-out step O4</p> <p>Carry-out step O3</p>
<b>O3</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 2N of fuse box G1 and ground	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p>Repair wiring between pin 11 of G164 and pin 5A of fuse box G1</p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2</p>
<b>O4</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 18 of control unit Q21A and ground	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p>Carry-out step O5</p> <p>Repair wiring between pin 11 of G164 and pin 18 of control unit Q21A</p>

(Cont.d)

## AUTOMATIC AIR CONDITIONING SYSTEM INOPERATIVE

## TEST O

TEST STEPS		RESULTS	REMEDY
<b>05</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 1 of connector <b>G165</b> and ground		 	Carry-out step <b>O7</b>
		 	Carry-out step <b>O6</b>
<b>06</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin 4O of fuse box <b>G1</b> and ground		 	Repair wiring between pin 1 of <b>G165</b> and pin 6E of fuse box <b>G1</b>
		 	Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>07</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 86 of electromagnetic coupling control relay <b>Q22</b> and ground		 	Carry-out step <b>O8</b>
		 	Repair wiring between pin 1 of <b>G165</b> and pin 86 of relay <b>Q22</b>
<b>08</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) on pin 13 of control unit <b>Q21A</b>		 	Carry-out step <b>O10</b>
		 	Carry-out step <b>O9</b>

(Cont.d)

AUTOMATIC AIR CONDITIONING SYSTEM INOPERATIVE	TEST O
---	--------









TEST STEPS		RESULTS	REMEDY
O09	GROUNDING CHECK		
	- Check for presence of 0V (zero) on pin 1 of G164	<div style="display: flex; align-items: center; gap: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between pin 1 of G164 and pin 13 of control unit Q21A
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between pin 1 of G164, pin 4 of G150 and ground point G143
O10	GROUNDING CHECK		
	- Ensure no ice is present on evaporator and check for presence of 0V (zero) on pin 85 of relay Q22	<div style="display: flex; align-items: center; gap: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step O11
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step O17
O11	VOLTAGE CHECK		
	- Check for presence of 12V between pin 30 of relay Q22 and ground	<div style="display: flex; align-items: center; gap: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step O12
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between pins 86 and 30 of relay Q22
O12	VOLTAGE CHECK		
	- Check for presence of 12V between pin 87 of relay Q22 and ground	<div style="display: flex; align-items: center; gap: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step O13
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Replace relay Q22

(Cont.d)











## AUTOMATIC AIR CONDITIONING SYSTEM INOPERATIVE

## TEST O

TEST STEPS		RESULTS	REMEDY
<b>O13</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 10 of connector <b>G164</b> and ground		 ►  ►	Carry-out step <b>O14</b>  Repair wiring between pin 87 of relay <b>Q22</b> and pin 10 of <b>G164</b>
<b>O14</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2 of connector <b>G151</b> and ground		 ►  ►	Carry-out step <b>O15</b>  Repair wiring between pin 10 of <b>G164</b> and pin 2 of <b>G151</b>
<b>O15</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin of compressor electro-magnetic coupling <b>Q11</b> (GRN-BLK wire) and ground		 ►  ►	Carry-out step <b>O16</b>  Repair wiring between pin 2 of <b>G151</b> and coupling <b>Q11</b> (GRN-BLK wire)
<b>O16</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 0V (zero) on coupling <b>Q11</b> (BLK wire)		 ►  ►	Replace coupling <b>Q11</b>  Repair wiring between coupling <b>Q11</b> and ground <b>G174</b> (BLK wire)

(Cont.d)

<b>AUTOMATIC AIR CONDITIONING SYSTEM INOPERATIVE</b>	<b>TEST O</b>
--	---------------

	TEST STEPS	RESULTS	REMEDY
<b>O17</b>	<b>VOLTAGE CHECK</b>		
	- Check, with conditions as stated in test step O8, for presence of 0V (zero) on anti-frost thermostat Q26 (GRY-GRN wire)	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between thermostat Q26 (GRY-GRN wire) and pin 85 of relay Q22
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step O18
<b>O18</b>	<b>GROUNDING CHECK</b>		
	- Check, with conditions as stated in test step O10, for presence of 0V (zero) on thermostat Q26 (GRY-BLK wire)	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Replace thermostat Q26
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step O19
<b>O19</b>	<b>GROUNDING CHECK</b>		
	- With pressure between min. and max. value, check for presence of 0V (zero) on pin 2 of switch Q20 (GRY-BLK wire)	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between thermostat Q26 and pin 2 (GRY-BLK wire) of switch Q20
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step O20
<b>O20</b>	<b>GROUNDING CHECK</b>		
	- With conditions indicated in test step O11, check for presence of 0V (zero) on pin 1 of switch Q20 (GRN wire)	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Replace switch Q20
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step O21

(Cont.d)

## AUTOMATIC AIR CONDITIONING SYSTEM INOPERATIVE

## TEST O

TEST STEPS		RESULTS	REMEDY
<b>O21</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- With conditions indicated in test step O11, check for presence of 0V (zero) on pin 28 control unit Q21A</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pin 1 (GRN wire) of wltch Q20 and pin 28 of control unit Q21A</p> <p>Replace control unit Q21A</p>

End of Test O

# ALARM - - ELECTRONIC ANTI-THEFT SYSTEM



## GENERAL

The vehicle is equipped with a remote control electronic anti-theft system. The remote control also actuates the centralized door lock/unlock system.

The anti-theft system consists of an electronic unit, a siren located in the right side of trunk, and a remote control used to activate/deactivate the system.

The siren is powered by a dedicated battery and is provided with an ON/OFF key.

Activation of the anti-theft system is indicated by flashing of a led on the central console, actuation of the centralized door lock and illumination for a few seconds of the turn signal lamps. Activation of the anti-theft system also locks the engine ignition circuit.

Deactivation of the anti-theft system is indicated by illumination of the turn signal lamps, centralized unlocking of door and switching off of led on the central console. The system is protected by free fuse G258 (15A) ANTI-THEFT SYSTEM.

## OPERATIONAL DESCRIPTION

The 12V power supply line is connected directly to the anti-theft system siren O11, to pins 5 and 12 of the anti-theft control unit N45 through the free fuse G258, and to led D31 on the central console.

Activation of the anti-theft system is obtained by directing the remote control towards the vehicle and pressing the

control push button; the remote control is provided with and indicator light which illuminates any time the control pushbutton is pressed.

The control unit N45 provides the following functions when the anti-theft system is activated:

- Flashing of led D31 (pin 8 of control unit).
- Actuation of centralized door lock (pins 16 and 18).
- Flashing of the four turn signal lamps (pins 1, 3, 15 and 17).
- Engagement of engine ignition circuit lock (pin 2).












When the anti-theft system is activated, opening of doors, engine hood or trunk lid is sensed by the control unit N45, with consequent activation of siren O11. Information about opening of doors, engine hood and trunk lid is transmitted to the control unit by dedicated switches.

When a door is opened, the corresponding switch opens and supplies a "door open" input to pin 3 of control unit N45. When the engine hood or the trunk lid are opened, the corresponding switches H44 and H24 close, and connect to ground pins 10 or 7 of the control unit N45.

With the ignition key inserted, the battery power is supplied to pin 14 of control unit N45, thus allowing inhibition of the receiver to prevent accidental activations.











TROUBLESHOOTING TABLE


FAULT TYPE	FAILED COMPONENT						
	(G258) FUSE	(H24) SWITCH	(H44) SWITCH	(D31) LED	(O11) SYREN	(N45) CONTROL UNIT	REMOTE CONTROL
ANTI-THEFT ACTIVATION/DE-ACTIVATION MODES INOPERATIVE	•					•	•
ANTI-THEFT ACTIVATION MODE INOPERATIVE						•	
SYREN INOPERATIVE		•	•	•	•	•	

<p>Anti-theft system led</p>	<p>D31</p>	<p>Rear cargo lamp</p>	<p>F5</p>
			
<p>Fuse box</p>	<p>G1 I</p>	<p>Central bulkhead ground</p>	<p>G143</p>
			
<p>Trunk right side ground</p>	<p>G186</p>	<p>Connector, right rear wiring to trunk lock wiring</p>	<p>G198</p>
			
<p>Board wiring to anti-theft system wiring connector</p>	<p>G241</p>	<p>Board wiring to anti-theft system wiring connector</p>	<p>G241a</p>
			
		<p>Right rear wiring connector, anti-theft system</p>	<p>G245</p>
			
<p>Anti-theft system wiring connector right rear wiring</p>	<p>G248</p>	<p>Anti-theft system wiring connector - console wiring</p>	<p>G249</p>
			

(Cont.d)



<p>Left rear wiring connector, anti-theft system</p>	<p>G256</p>	<p>Anti-theft system fuse</p>	<p>G258</p>
			
<p>Trunk illumination switch</p>	<p>H24</p>	<p>Trunk illumination switch</p>	<p>H24</p>
<p><b>BASE AND L ONLY</b></p> 		<p><b>S ONLY</b></p> 	
<p>Engine compartment anti-theft system switch</p>	<p>H44</p>	<p>Electronic control units power supply relay</p>	<p>I51</p>
			
<p>Stop lamps switch relay</p>	<p>I59</p>	<p>Trunk opening solenoid</p>	<p>M12</p>
			
<p>Anti-theft control unit</p>	<p>N45</p>	<p>Syren</p>	<p>O11</p>
			



## ANTI-THEFT ACTIVATION/DE-ACTIVATION MODES INOPERATIVE

## TEST A

## TEST STEPS

## RESULTS

## REMEDY

**NOTE:** In case the operation of remote control requires to approach the vehicle excessively, replace the remote control batteries. In any case, replacement of batteries every 12 months is recommended.

## A1 FUSE CHECK

- Check free fuse **G258** for integrity



Carry-out step **A2**



Replace free fuse **G258**

## A2 REMOTE CONTROL BATTERIES CHECK

- Actuate the remote control pushbutton and check that led on remote control illuminates



Carry-out step **A3**



Replace remote control batteries

## A3 CONTROL UNIT CHECK

- Check for presence of 12V between pins 5 and 12 of control unit **N45** and ground



Replace control unit **N45**



Carry-out step **A4**

## A4 VOLTAGE CHECK

- Check for presence of 12V between pin of free fuse **G258** (RED wire) and ground



Carry-out step **A5**



Failure of the power distribution circuit, refer to the relevant circuit of sheet 1 of 2

(Cont.d)

## ANTI-THEFT ACTIVATION/DE-ACTIVATION MODES INOPERATIVE









## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 0V (zero) at pin 9 of control unit N45</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pins 5, 12 of control unit N45 and pin of free fuse G258</p> <p>Repair wiring between pin 9 of control unit N45 and groundpoint G186</p>

End of test A

## ANTI-THEFT ACTIVATION MODE INOPERATIVE









## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>SIMULTANEOUS ILLUMINATION OF TURN SIGNAL LAMPS CHECK</b>		
	- Check that the four turn signal lamps illuminate simultaneously	 	Carry-out step B11  Carry-out step B2
<b>B2</b>	<b>TURN SIGNAL LAMPS CHECK</b>		
	- Check that all the four turn signal lamps remain off	 	Replace control unit N45  Carry-out step B3, B5 or B7 or B9
<b>B3</b>	<b>LEFT FRONT TURN SIGNAL LAMP CHECK</b>		
	- Actuate the multiple switch as required to turn on the left front turn signal lamp, and check the lamp turns on	 	Carry-out step B4  Replace bulb
<b>B4</b>	<b>CONTINUITY CHECK</b>		
	- Check for continuity between pin 1 of control unit N45, pin 1 of connector G241 and pin 1A of fuse box G1	 	Replace control unit N45  Replace or repair wires, as necessary

(Cont.d)

## ANTI-THEFT ACTIVATION MODE INOPERATIVE









## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B5</b>	<b>RIGHT FRONT TURN SIGNAL LAMP CHECK</b>		
- Actuate the multiple switch as required to turn on the right front turn signal lamp, and check the lamp turns on		 	Carry-out step B6  Replace bulb
<b>B6</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pin 13 of control unit N45, pin 3 of connector G241 and pin 2A of fuse box G1		 	Replace control unit N45  Replace or repair wires, as necessary
<b>B7</b>	<b>LEFT REAR TURN SIGNAL LAMP CHECK</b>		
- Actuate the multiple switch as required to turn on the left rear turn signal lamp, and check the lamp turns on		 	Carry-out step B8  Replace bulb
<b>B8</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pin 17 of control unit N45, connector G256 and pins 2A and 2B of tail lamp E26		 	Replace control unit N45  Replace or repair wires, as necessary

(Cont.d)

## ANTI-THEFT ACTIVATION MODE INOPERATIVE









## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B9</b>	<b>RIGHT REAR TURN SIGNAL LAMP CHECK</b>		
- Actuate the multiple switch as required to turn on the right rear turn signal lamp, and check the lamp turns on		 ►  ►	Carry-out step B10  Replace bulb
<b>B10</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pin 15 of control unit N45, connector G245 and pins 2A and 2B of tail lamp E25		 ►  ►	Replace control unit N45  Replace or repair wires, as necessary
<b>B11</b>	<b>DOOR LOCK CHECK</b>		
- Check locking of all the four doors		 ►  ►	Carry-out step B13  Carry-out step B12
<b>B12</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pins 16 and 18 of control unit N45		 ►  ►	Repair wiring between pins 16 and 18 of control unit N45, pins 1 and 2 of connector G249 and pins 2 and 1 of switch B20  Replace control unit N45

(Cont.d)

## ANTI-THEFT ACTIVATION MODE INOPERATIVE

## TEST B







TEST STEPS		RESULTS	REMEDY
<b>B13</b>	<b>LED CHECK</b>		
- Check flashing of led on the central console		 	Carry-out step B16  Carry-out step B14
<b>B14</b>	<b>ELECTRONIC UNIT CHECK</b>		
- Check for presence at pin 8 of control unit N45 of a signal switching from 0V (zero) to open circuit conditions, and vice versa		 	Carry-out step B15  Replace control unit N45
<b>B15</b>	<b>TTL SIGNAL CHECK</b>		
- Check for presence of TTL signal to terminals of led D31		 	Replace led D31  Repair wiring between pin 2 of led D31 (anode) and fuse G258, and between pin1 of led D31 (cathode) and pin 8 control unit N45
<b>B16</b>	<b>ENGINE IGNITION INHIBITION CHECK</b>		
- With anti-theft system activated, check that engine can not be started		 	Carry-out step B19  Carry-out step B17

(Cont.d)



## ANTI-THEFT ACTIVATION MODE INOPERATIVE

## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B17</b>	<b>CONTROL UNIT CHECK</b>		
- With anti-theft system activated, check for presence of 0V (zero) at pin 2 of control unit N45			Repair wiring between pin 2 of control unit N45, pin 2 of connector G241a and pin 86 of relay I10
			Carry-out step B18
<b>B18</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "start" position, check for presence of 12V between pin 14 of control unit N45 and ground			Replace control unit N45
			Carry-out step B19
<b>B19</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "start" position, check for presence of 12V between pin 1 of connector G241a and ground			Repair wiring between pin 1 of G241a and pin 14 of control unit N45
			Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2

End of test B









<b>SYREN INOPERATIVE</b>	<b>TEST C</b>
--------------------------	---------------

TEST STEPS		RESULTS	REMEDY
<b>C1</b>	<b>SYREN CHECK</b>		
- Check syren activation by disconnecting one of the battery terminals		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	<p>Carry-out step C4</p> <p>Carry-out step C2</p>
<b>C2</b>	<b>VOLTAGE CHECK</b>		
- Re-connect battery terminal and, with the ignition key set to "run" or to "start" position, check for presence of 12V between pin 4 of syren O11 and ground		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	<p>Replace syren battery and/or siren O11</p> <p>Carry-out step C3</p>
<b>C3</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" or to "start" position, check for presence of 12V between pin 2 of G241 and ground		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	<p>Repair wiring between pin 2 of connector G241 and pin 4 of syren O11</p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2</p>
<b>C4</b>	<b>SYREN CHECK</b>		
- Check that syren does not activate when the trunk lid, engine hood and doors are opened		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	<p>Carry-out step C5</p> <p>Carry-out step C7</p>

(Cont.d)

SYREN INOPERATIVE

TEST C

TEST STEPS		RESULTS	REMEDY
<b>C5</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pins 1 and 2 of syren O11		 ▶  ▶	Replace syren O11  Carry-out step C6
<b>C6</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 21 control unit N45 and ground		 ▶  ▶	Repair wiring between pin 21 of control unit N45 and pin 2 of syren O11, and between pin 1 of syren O11 and ground point G186  Replace control unit N45
<b>C7</b>	<b>DOOR SYREN ACTIVATION CHECK</b>		
- Check syren activation by opening of either door		 ▶  ▶	Carry-out step C9  Carry-out step C8
<b>C8</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 3 of control unit N45		 ▶  ▶	Replace control unit N45  Repair wiring between pin 3 of control unit N45, pin 4 of connector G241 and pin 8 of connector G170

(Cont.d)

SYREN INOPERATIVE













TEST C

TEST STEPS		RESULTS	REMEDY
<b>C9</b>	<b>HOOD SYREN ACTIVATION CHECK</b>		
	- Check syren activation by opening the engine hood	OK ►	Carry-out step C12
		<del>OK</del> ►	Carry-out step C10
<b>C10</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 10 of control unit N45	OK ►	Replace control unit N45
		<del>OK</del> ►	Carry-out step C11
<b>C11</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 5 of connector G241	OK ►	Repair wiring between pin 5 of connector G241 and pin 10 of control unit N45
		<del>OK</del> ►	Carry-out step C12

(Cont.d)

SYREN INOPERATIVE







TEST C

TEST STEPS		RESULTS	REMEDY
<b>C12</b>	<b>SWITCH CHECK</b>		
	- Check anti-theft system switch H44 in the engine compartment for proper operation	 	Repair wiring between switch H44 (GRY-GRN wire) and pin 5 of connector G241 and between switch H44 (BLK wire) and ground point G143
		 	Replace switch H44
<b>C13</b>	<b>TRUNK LID SYREN ACTIVATION CHECK</b>		
	- Check syren activation by opening the trunk lid	 	Carry-out step C3
		 	Carry-out step C14
<b>C14</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 7 of control unit N45	 	Replace control unit N45
		 	Carry-out step C15

(Cont.d)

SYREN INOPERATIVE

TEST C

TEST STEPS		RESULTS	REMEDY
<b>C15</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at connector <b>G248</b>			Repair wiring between connector <b>G248</b> and pin 7 of control unit <b>N45</b>
			Carry-out step <b>C16</b>
<b>C16</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 5 of connector <b>G198</b>			Repair wiring between connector <b>G198</b> and <b>G248</b>
			Carry-out step <b>C17</b>
<b>C17</b>	<b>SWITCH CHECK</b>		
- Check that trunk illumination switch <b>H24</b> is operational			Repair wiring between switch <b>H24</b> and pin 5 of connector <b>G198</b> , and between switch <b>H24</b> , pin 2 of connector <b>G198</b> and ground point <b>G186</b>
			Replace switch <b>H24</b>


End of test C

**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>

# BUZZER





## GENERAL

The vehicle is equipped with an acoustic warning buzzer which turns on automatically whenever the left front seat belt is not properly fastened, or the ignition key is left in the ignition switch when the door is open.

Automatic activation of the buzzer is controlled by the Alfa Romeo Control unit. The system is protected by the fuse F6 (10A) BUZZER in the auxiliary fuse box G2.

## OPERATIONAL DESCRIPTION

Battery power (12V) is constantly provided to buzzer R24 through the fuse F6 in the auxiliary fuse box G2.

Activation of the buzzer is controlled by the Alfa Romeo Control unit N22.












The safety belt fastened switch R25 on the seat belt anchor is open when the seat belt is fastened; when the seat belt is unfastened, pin 2E of control unit N22 is connected to ground.

Whenever the ignition key is left in the ignition switch after the engine has been turned off, the microswitch B1 closes and connects to ground the pin 12A of the control unit N22.



When pins 2E or 12A of the Alfa Romeo Control unit N22 are connected to ground, the control unit N22 connects to ground the output signal pin 6E, thus actuating the buzzer R24.


### TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT				
	FUSE F6	IGNITION SWITCH B1	SEAT BELT MICROSWITCH R25	BUZZER R24	CONTROL UNIT N22
BUZZER INOPERATIVE (SAFETY BELT NOT FASTENED)	●			●	●
BUZZER INOPERATIVE (IGNITION KEY INSERTED AND DOOR OPEN)	●	●		●	●
BUZZER CONTINUOUSLY ACTUATED			●		●

<p>Ignition switch</p>	<p><b>(B1)</b></p>	<p>Fuse box</p>	<p><b>G1 T</b></p>
 <p>B2 PIN 1 <b>(C)</b> 3          1BLK* G174 2          GRY* 170 1</p>		 <p>4RED* HOT AT ALL TIMES          2.5RED* G2</p>	
<p>Auxiliary fuse box</p>	<p><b>(G2)</b></p>	<p>Steering wheel column support ground</p>	<p><b>G174</b></p>
 <p>2.5RED* G1 <b>(T)</b>          G18 PIN 1          1RED* I26</p>		 <p>1BLK* B1          1BLK* I51</p>	
		<p>Connector circuit board to automatic gear lever wiring</p>	<p><b>G233</b></p>
 <p>BLK* G244 3          1BLK* I51 3          3 F38 PIN 1          3 H16</p>			
<p>Board wiring to aft console wiring two-way connector</p>	<p><b>G244</b></p>	<p>Dome lamp relay</p>	<p><b>I26</b></p>
 <p>BLK* G233 2          LTBLU-WHT* N22 <b>(E)</b> 1          BLK* R25 2          LTBLU-WHT* R25 1</p>		 <p>1RED* G2 85          RED* R24 85</p>	
<p>Electronic control units power supply relay</p>	<p><b>I51</b></p>	<p>Radio relay</p>	<p><b>I70</b></p>
 <p>1BLK* G174 85          1BLK* G233 85</p>		 <p>GRY* N22 <b>(A)</b> 85          GRY* B1 85</p>	
<p>Alfa Romeo control unit</p>	<p><b>(N22 A)</b></p>	<p>Alfa Romeo control unit</p>	<p><b>(N22 E)</b></p>
 <p>GRY* I70 12</p>		 <p>LTBLU-WHT* G244 2          PPL* R24 8</p>	









(Cont.d)

<p>Seat belt unfastened and ignition key inserted buzzer</p>	<p>R24</p>	<p>Safety belt fastened switch</p>	<p>R25</p>
			



## BUZZER INOPERATIVE (SAFETY BELT NOT FASTENED)

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
	- Check fuse <b>F6</b> in auxiliary fuse box <b>G2</b> for integrity	 ►  ►	Carry-out step <b>A2</b>  Replace fuse <b>F6</b>
<b>A2</b>	<b>IGNITION KEY ACTUATED BUZZER CHECK</b>		
	- Start engine, turn off engine and leave the ignition key inserted in the ignition switch the door open; check that buzzer is operational	 ►  ►	Replace safety belt fastened switch <b>R25</b>  Carry-out step <b>A3</b>
<b>A3</b>	<b>CONTROL UNIT CHECK</b>		
	- With seat belt not fastened, or ignition key inserted, and the door open, check for presence of 0V (zero) at pin 6E of Alfa Romeo control unit <b>N22</b>	 ►  ►	Carry-out step <b>A4</b>  Replace control unit <b>N22</b>
<b>A4</b>	<b>BUZZER CHECK</b>		
	- Check for presence of 12V between pins 15 and 31 of buzzer <b>R24</b>	 ►  ►	Replace buzzer <b>R24</b>  Carry-out step <b>A5</b>

(Cont.d)

BUZZER INOPERATIVE (SAFETY BELT NOT FASTENED)

















TEST A

TEST STEPS		RESULTS	REMEDY
A5	VOLTAGE CHECK		
<ul style="list-style-type: none"> <li>- Check for presence of 12V between pin of auxiliary fuse box G2 (RED wire)</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 15 of buzzer R24 and fuse F6, and between pin 31 of buzzer R24 and pin 6E of control unit N22</p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2</p>

End of test A

## BUZZER INOPERATIVE (IGNITION KEY INSERTED AND DOOR OPEN)

## TEST B









TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>FUSE CHECK</b>		
- Check fuse F6 in auxiliary fuse box G2 for integrity		 	Carry-out step B2
		 	Replace fuse F6
<b>B2</b>	<b>SAFETY BELT ACTUATED BUZZER CHECK</b>		
- Start engine, do not fasten safety belt and check that buzzer is operational		 	Replace microswitch in ignition switch B1
		 	Carry-out step B3
<b>B3</b>	<b>CONTROL UNIT CHECK</b>		
- With safety belt not fastened, or ignition key inserted, and the door open, check for presence of 0V (zero) at pin 6E of Alfa Romeo control unit N22		 	Carry-out step B4
		 	Replace control unit N22
<b>B4</b>	<b>BUZZER CHECK</b>		
- Check for presence of 12V between pins 15 and 31 of buzzer R24		 	Replace buzzer R24
		 	Carry-out step A5

End of test B



## BUZZER CONTINUOUSLY ACTUATED







## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C1</b>	<b>GENERAL CHECK</b>		
- Make sure ignition key has been removed from ignition switch <b>B1</b> , and safety belt is properly fastened		 ►  ►	Carry-out step C2  Remove Ignition key from Ignition switch, and/or fasten safety belt properly, and close the door after the engine has been shut off
<b>C2</b>	<b>GROUNDING CHECK</b>		
- With safety belt fastened, check for presence of 0V (zero) at pin 2E of Alfa Romeo control unit N22		 ►  ►	Carry-out step C3  Carry-out step C4
<b>C3</b>	<b>CONTROL UNIT CHECK</b>		
- Check that circuit is open at pin 12A of Alfa Romeo control unit N22		 ►  ►	Replace control unit N22  Replace microswitch in Ignition switch B1
<b>C4</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 2 of safety belt fastened switch R25		 ►  ►	Carry-out step C5  Carry-out step C7

(Cont.d)

## BUZZER CONTINUOUSLY ACTUATED

## TEST C


TEST STEPS		RESULTS	REMEDY
<b>C5</b>	<b>SWITCH CHECK</b>		
- With safety belt fastened check for presence of 0V (zero) at pin 1 of safety belt fastened switch R25		 ►  ►	Carry-out step C6  Replace switch R25
<b>C6</b>	<b>GROUNDING CHECK</b>		
- With safety belt fastened, check for presence of 0V (zero) at pin 1 of connector G244		 ►  ►	Repair wiring between pin 1 of connector G244 and pin 2E of control unit N22  Repair wiring between pin 1 of connector G244 and pin 1 of switch R25
<b>C7</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 2 of connector G244		 ►  ►	Repair wiring between pin 2 of connector G244 and pin 2 of switch R25  Repair wiring between pin 2 of connector G244, pin 3 of connector G233 and ground point G174

End of test C

**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>

# CIGARETTE LIGHTERS - - FRONT AND REAR



## GENERAL

The car is provided with two cigar lighters respectively located inside the front and rear ashtrays.

The cigar lighters are illuminated when the parking lights are turned on.

To actuate the lighters, push the center of the lighter: after a few seconds the lighter will pop out, ready for use.

The system is protected by three fuses in the fuse box G1, as follows:

- F21 fuse (15A) FRONT LIGHTER.
- F13 fuse (10A) REAR LIGHTER.
- F2 fuse (7.5A) FRONT AND REAR LIGHTER INDICATOR LAMPS.

## OPERATIONAL DESCRIPTION

12V from the battery is applied to one of the two terminals of front lighter O6 through the fuse F21.

The rear lighter O7 is energized through the fuse F13 only when the ignition key is set to "run".

Both O6 and O7 lighters are provided with an indicator light which is actuated by the parking lights control unit N41 when the position lamps are turned on.












The circuit of the indicator lights is protected by the fuse F2.


The second terminal of the front and rear lighters is connected respectively to the ground points G174 and G182 by means of jumpers.

Pressing the center of the lighter which is intended for use, connects to ground the respective jumper, this allowing warming of the lighter.

TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT					
	F2 FUSE	F13 FUSE	F21 FUSE	O6 LIGHTER	O7 LIGHTER	N41 CONTROL UNIT
FRONT LIGHTER INOPERATIVE			●	●		
REAR LIGHTER INOPERATIVE		●			●	
LIGHTERS ILLUMINATION INOPERATIVE	●					●







<p>Fuse box</p>  <p>GRY-YEL • G100 1</p>	<p>G1 E</p>	<p>Fuse box</p>  <p>1.5YEL-BLK • N41 3</p>	<p>G1 G</p>
<p>Fuse box</p>  <p>4RED • HOT AT ALL TIMES 2 150 PIN 30 3</p>	<p>G1 N</p>	<p>Fuse box</p>  <p>2.5PNK • HOT IN RUN 4</p>	<p>G1 Q</p>
<p>Fuse box</p>  <p>1RED-BLK • O6 5 1PNK-BLK • G100 6</p>	<p>G1 P</p>	<p>Connector, doors to center console wiring</p> <p>G100</p>  <p>1PNK-BLK • G1 P 13 GRY-YEL • O6 14 GRY-YEL • G1 E 14 1PNK-BLK • O7 13 GRY-YEL • O7 14</p>	
<p>Steering wheel column support ground</p> <p>G174</p>  <p>1BLK • O6</p>			
<p>Center console ground</p> <p>G182</p>  <p>1BLK • O7</p>	<p>Parking lamps control unit</p> <p>N41</p>  <p>1.5YEL-BLK • G1 G 5</p>		
<p>Front cigar lighter</p> <p>O6</p>	<p>Rear cigar lighter</p> <p>O7</p>		
 <p>O4 PIN 4 GRY-YEL • G100 1RED-BLK • G1 P 1 1BLK • G174 2</p>	 <p>GRY-YEL • G100 1PNK-BLK • G100 1 1BLK • G182 2</p>		





## FRONT LIGHTER INOPERATIVE









## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
	- Check fuse F21 in fuse box G1 for integrity	 ►  ►	Carry-out step A2  Replace fuse F21
<b>A2</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pins 1 and 2 of front lighter O6	 ►  ►	Replace lighter O6  Carry-out step A3,
<b>A3</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 2N of fuse box G1 and ground	 ►  ►	Repair wiring between pin 1 of lighter O6 and pin 8P of fuse box G1, and/or between pin 2 of lighter O6 and ground point G174  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2

End of test A

## REAR LIGHTER INOPERATIVE





## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>F13</b> in fuse box <b>G1</b> for integrity		 ►  ►	Carry-out step <b>B2</b>  Replace fuse <b>F13</b>
<b>B2</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pins 1 and 2 of lighter <b>O7</b>		 ►  ►	Replace lighter <b>O7</b>  Carry-out step <b>B3</b>
<b>B3</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 2 of lighter <b>O7</b> with the lighter activated		 ►  ►	Carry-out step <b>B4</b>  Repair wiring between pin 2 of lighter <b>O7</b> and ground point <b>G182</b>
<b>B4</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin 13 of connector <b>G100</b> and ground		 ►  ►	Repair wiring between pin 13 of connector <b>G100</b> and pin 1 of lighter <b>O7</b>  Carry-out step <b>B5</b>

(Cont.d)

REAR LIGHTER INOPERATIVE

TEST B

TEST STEPS		RESULTS	REMEDY
<b>B5</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin 4O of fuse box G1 and ground		   	Repair wiring between pin 6P of fuse box G1 and pin 13 of connector G160  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2

End of test B

## LIGHTERS ILLUMINATION INOPERATIVE









## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C1</b>	<b>FUSE CHECK</b>		
	- Check fuse F2 in fuse box G1 for integrity	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step C2</p> <p>Replace fuse F2</p>
<b>C2</b>	<b>BOTH LIGHTERS ILLUMINATION CIRCUIT CHECK</b>		
	- With the position lamps on, check illumination of both lighters is inoperative	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step C3</p> <p>Carry-out step C5</p>
<b>C3</b>	<b>CONTROL UNIT CHECK</b>		
	- With the position lamps on, check for presence of 12V at pin 6 of parking lights control unit N41	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step C4</p> <p>Failure of the position lamps circuit; refer to the corresponding troubleshooting procedure</p>
<b>C4</b>	<b>CONTINUITY CHECK</b>		
	- Check continuity between pin 3G of fuse box G1 and pin 6 of control unit N41	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring, between pin 14 of connector G100 and pin 1E of fuse box G1</p> <p>Repair or replace wiring as necessary</p>

(Cont.d)

## LIGHTER ILLUMINATION INOPERATIVE

## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C5</b>	<b>FRONT LIGHTER CHECK</b>		
- With the position lamps on, check if illumination of front lighter only is inoperative		 ►  ►	Carry-out step C6  Carry-out step C8
<b>C6</b>	<b>LAMP INSTALLATION CHECK</b>		
- Check that front lighter lamp is properly installed in the lighter and check bulb integrity		 ►  ►	Carry-out step C7  Install the lamp properly and/or replace bulb
<b>C7</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 2 of lighter O6		 ►  ►	Repair wiring between pin 14 of connector G100 and lighter O6 (GRY-YEL wire)  Repair wiring between ground point G174 and pin 2 of lighter O6
<b>C8</b>	<b>LAMP CHECK</b>		
- Check that rear lighter lamp is properly installed in the lighter and check bulb integrity		 ►  ►	Carry-out step C8  Install the lamp properly and/or replace bulb

(Cont.d)

## LIGHTERS ILLUMINATION INOPERATIVE

## TEST C

TEST STEPS		RESULTS	REMEDY
C9	GROUNDING CHECK		
- Check for presence of 0V (zero) at pin 2 of lighter O7		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pin 14 of connector G100 and lighter O7 (GRY-YEL wire)</p> <p>Repair wiring between ground point G182 and pin 2 of lighter O7</p>

End of test C

CONTROLLED DAMPING  
SUSPENSIONS  
(S only)





## GENERAL

The controlled damping suspension system is capable to change the shock absorbers damping at any moment, in real time, on all the four wheels.

This system, electronically monitored, modifies the shock absorbers damping characteristics according to the driving and road pavement conditions.

This feature provides, at any instant, maximum comfort, roadholding power and safety.

The controlled damping suspensions are capable to operate in two different logics: "AUTO" or "SPORT", selected by two pushbuttons located on the center console switchboard.

These two logics operate in accordance with two shock absorber conditions: they may operate with soft or rigid adjustments.

If the "AUTO" function is selected, the electronic system adjusts, the shock absorbers in real time, changing from soft to rigid or viceversa automatically, according to information received by several sensors which read, at any moment, the different driving conditions.

If the "SPORT" function is selected, the shock absorbers adjustment is always set for a sport driving condition, with an increase in roadholding power against comfort.

### System operation - "AUTO" mode

The monitored parameter is the vertical acceleration that is determined by road oscillations, steering angle and rate at which these variations occur, by the exceeding of a fixed value in the brakes hydraulic system pressure and by throttle opening when 1st and 2nd gear are selected. The AUTO logic foresees two operation fields depending on vehicle speed.

1) Till the speed of 4 Km/h (2.5 MPH) the shock absorbers adjustment is rigid to allow manoeuvres without excessive springing on rough roads.

2) The system changes automatically the adjustment from soft to rigid when one of the following conditions is met:

- sudden changes of direction due to obstacles on the road or very sharp turns; these conditions are sensed by the "Steering wheel angle and steering wheel rate of rotation" sensor;

- Bumps and road asperities generating oscillations of the body; these conditions are sensed by the "accelerometer" sensor;
- Vehicle braking with brake system pressure higher than 20 bar (290 psi); this condition is sensed by "braking pressure" sensor;
- Sudden speed-up using 1st and 2nd gear; this condition is sensed by the "engine throttle" sensor and by the "gearbox" sensor for speeds lower than 50 Km/h (31 MPH).

## FUNCTIONAL DESCRIPTION

The damping suspension system is controlled by the relevant control unit N46.

The control unit N46 is supplied at pins 3C (ignition key in "run" position) through fuse F14.

The unit receives information sent by the various sensors thus correlating and processing it according to a logic pre-established by the manufacturer. After processing, the control unit sends control pulses which are directed to the shock absorber solenoid valves M17/18/19/20.

The vehicle's vertical acceleration is measured by the accelerometer N47 which sends ACCH and ACCL signals to pins 4B and 10C of the control unit.

The steering wheel rotation speed is detected by sensor L40 sending STR2, STR1, STR2 signals to pins 1A, 6A, 11A, of the control unit.

The control unit detects the pressure on the brake pedal through pressure switch L41 at pin 6C, whilst the unit measures at pin 2B the gearbox (switch H46) and the accelerator pedal positions (switch H47).

The tachymetric signal, detected by sensor L17 is sent to pin 4A of the control unit.

The selection between AUTO and SPORT operation is carried out by acting on two push-buttons arranged on the relevant panel B67; the selected condition is signalled at pins 12A and 8A of the control unit N46.

## SELF-DIAGNOSIS

With the engine running, the control unit performs a constant self-diagnosis check on the system, the vehicle being either stationary or in motion.












In both cases a red warning light, located on the push-

button panel B67, lights up to signal whatever faulty condition may occur in the system; the system switches automatically to set the shock absorbers in hard position. Said condition is kept until the malfunction is eliminated.

The troubleshooting described in this section is based on

a series of checks, upon lighting up of the warning light, to be carried out on the vehicle.












A test is finally described at the end of the section in case one or more warning lights on the push-button panel do not light up.

<p>Position lights/hazard lights/fuel filler lid pushbutton panel</p> <p style="text-align: right;"><b>B66</b></p> 	<p>Suspension system control panel</p> <p style="text-align: right;"><b>B67</b></p> 
<p>Multiple switch unit</p> <p style="text-align: right;"><b>B68</b> <span style="border: 1px solid black; padding: 2px;">g</span></p> 	<p>Instrument panel</p> <p style="text-align: right;"><b>C10</b> <span style="border: 1px solid black; padding: 2px;">A</span></p> 
<p>Instrument panel</p> <p style="text-align: right;"><b>C10</b> <span style="border: 1px solid black; padding: 2px;">C</span></p> 	<p>Fuse box</p> <p style="text-align: right;"><b>G1</b> <span style="border: 1px solid black; padding: 2px;">D</span></p> 
<p>Fuse box</p> <p style="text-align: right;"><b>G1</b> <span style="border: 1px solid black; padding: 2px;">O</span></p> 	<p>Fuse box</p> <p style="text-align: right;"><b>G1</b> <span style="border: 1px solid black; padding: 2px;">S</span></p> 
<p>Engine compartment ground connection</p> <p style="text-align: right;"><b>G53</b></p> 	<p>Connector, circuit board to engine compartment right side wiring</p> <p style="text-align: right;"><b>G149</b></p> 
<p>Connector, circuit board to engine compartment left side wiring</p> <p style="text-align: right;"><b>G150a</b></p> 	

(Cont.d)

<p>Connector, circuit board to engine utilities wiring</p>	<p><b>G151</b></p>	<p>Steering wheel column support ground</p>	<p><b>G174</b></p>
		<p>Trunk right side ground</p>	<p><b>G186</b></p>
<p>Suspension control system connector</p>	<p><b>G251</b></p>	<p>Connector, terminal board wiring - rear right wiring for suspension control system</p>	<p><b>G252a</b></p>
<p>Connector, terminal board wiring - rear right wiring for suspension control system</p>	<p><b>G252b</b></p>	<p>Connector, terminal board wiring - rear right wiring for suspension control system</p>	
		<p><b>G252c</b></p>	
<p>Gear box switch for suspension control system</p>	<p><b>H46</b></p>		


(Cont. d)

<p>Engine throttle microswitch for suspension system</p>	<p><b>H47</b></p>	<p>Rear window lifts relay</p>	<p><b>I13</b></p>
			
<p>20A suspension control system relay</p>	<p><b>I71</b></p>	<p>Speedometer sensor</p>	<p><b>L17</b></p>
			
<p>Steering wheel rotation angle sensor</p>	<p><b>L40</b></p>	<p>Oil microswitch for suspension control system</p>	<p><b>L41</b></p>
			
<p>Front left shock absorber solenoid valve</p>	<p><b>M18</b></p>	<p>Front right shock absorber solenoid valve</p>	<p><b>M17</b></p>
			
<p>Rear left shock absorber solenoid valve</p>	<p><b>M20</b></p>	<p>Rear right shock absorber solenoid valve</p>	<p><b>M19</b></p>
			
<p>Parking lamps control unit</p>	<p><b>N41</b></p>		

(Cont.d)

<p>Suspension system electronic control unit</p>	<p>Suspension system electronic control unit</p>
<p><b>N46 A</b></p>	<p><b>N46 B</b></p>
<p>Connector, left rear wiring to left rear door wiring</p>	<p>Accelerometer</p>
<p><b>N46 C</b></p> <p><i>SUSPENSION SYSTEM ELECTRONIC CONTROL UNIT</i></p>	<p><b>N47</b></p> <p><b>I5</b></p> <p>Suspension control system diagnosis connector</p>





NOTE Lens M17 valid also for M18, M19, M20

**CHECK OF SHOCK ABSORBER CONTROL RELAY - SOLENOID VALVE - CONTROL UNIT SUPPLY**

**TEST A**









TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
- Check fuse of relay I71 for integrity		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>○ OK</del></div> <div style="font-size: 2em;">▶</div> </div>	<p>Carry-out step A2</p> <p>Replace fuse of relay I71</p>
<b>A2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 30 of relay I71 and ground		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>○ OK</del></div> <div style="font-size: 2em;">▶</div> </div>	<p>Carry-out step A3</p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 1 of 2</p>
<b>A3</b>	<b>RELAY CHECK</b>		
- Check relay I71 for integrity		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>○ OK</del></div> <div style="font-size: 2em;">▶</div> </div>	<p>Carry-out step A4</p> <p>Replace relay I71</p>
<b>A4</b>	<b>SOLENOID VALVE CHECK</b>		
- Check for 3 - 3.3 Ohm resistance at pins of M17, M18, M19, M20, solenoid valves		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>○ OK</del></div> <div style="font-size: 2em;">▶</div> </div>	<p>Carry-out step A5</p> <p>Replace defective solenoid valve</p>

(Cont.d)











CHECK OF SHOCK ABSORBER CONTROL RELAY - SOLENOID VALVE -  
CONTROL UNIT SUPPLY

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>VOLTAGE CHECK</b>		
- With the key set to "run" position, check for presence of 12V between pin 86 of relay I71 and ground		 ►  ►	Carry-out step A6  Repair wiring between pin 86 of relay I71 and pin 2D of fuse box G1, through connector G252b
<b>A6</b>	<b>VOLTAGE CHECK</b>		
- With the key set to "run" position, check for presence of 12V between pin 3C of control unit N46 and ground		 ►  ►	Carry-out step A7  Repair wiring between pin 3C of control unit N46 and pin 86 of relay I71
<b>A7</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V at pins 4C, 6B, 7B, 8B of control unit N46		 ►  ►	Carry-out step A8  Repair wiring between pins 4C, 6B, 7B, 8B of control unit N46 and ground G186
<b>A8</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pin 87 of relay I71 and pin 5B of control unit N46		 ►  ►	Carry-out step A9  Repair or replace cables, as required

(Cont.d)

















<b>CHECK OF SHOCK ABSORBER CONTROL RELAY - SOLENOID VALVE - CONTROL UNIT SUPPLY</b>	<b>TEST A</b>
---	---------------

TEST STEPS		RESULTS	REMEDY
<b>A9</b>	<b>CONTINUITY CHECK</b>		
	- Check for continuity between pin 85 of relay I71 and pin 5C of control unit N46	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p style="margin: 0;">Carry-out step A10</p> <p style="margin: 0;">Repair or replace cables, as required</p>
<b>A10</b>	<b>CONTINUITY CHECK</b>		
	- Check for continuity between pin 87 of relay I71 and crimping connection G251	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p style="margin: 0;">Carry-out step A11</p> <p style="margin: 0;">Repair or replace cables, as required</p>
<b>A11</b>	<b>CONTINUITY CHECK</b>		
	- Check for continuity between crimping connection G251 and connector G252a (red wire)	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p style="margin: 0;">Carry-out step A12</p> <p style="margin: 0;">Repair or replace cables, as required</p>
<b>A12</b>	<b>CONTINUITY CHECK</b>		
	- Check for continuity between connector G252a (red wire) and pin 4 of connector G150a	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p style="margin: 0;">Carry-out step A13</p> <p style="margin: 0;">Repair or replace cables, as required</p>

(Cont.d)

## CHECK OF SHOCK ABSORBER CONTROL RELAY - SOLENOID VALVE - CONTROL UNIT SUPPLY

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A13</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pin 4 of connector <b>G150a</b> and solenoid valve <b>M18</b> (red wire)		 	Carry-out step <b>A14</b>
		 	Repair or replace cables, as required
<b>A14</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between connector <b>G252a</b> (red wire) and pin 5 of connector <b>G149</b>		 	Carry-out step <b>A15</b>
		 	Repair or replace cables, as required
<b>A15</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pin 5 of connector <b>G149</b> and solenoid valve <b>M17</b>		 	Carry-out step <b>A16</b>
		 	Repair or replace cables, as required
<b>A16</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pin10B of control unit <b>N46</b> and connector <b>G252a</b> (GRY-GRN wire)		 	Carry-out step <b>A17</b>
		 	Repair or replace cables, as required

(Cont.d)









<b>CHECK OF SHOCK ABSORBER CONTROL RELAY - SOLENOID VALVE - CONTROL UNIT SUPPLY</b>	<b>TEST A</b>
---	---------------

	TEST STEPS	RESULTS	REMEDY
A17	CONTINUITY CHECK		
	- Check for continuity between connector G252a (GRY - GRN wire) and pin 3 of connector G150a	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="font-size: 24px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 24px;">▶</div> </div> </div>	<p>Carry-out step A18</p> <p>Repair or replace cables, as required</p>
A18	CONTINUITY CHECK		
	- Check for continuity between pin 3 of connector G150a and solenoid valve M18 (GRY-GRN wire)	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="font-size: 24px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 24px;">▶</div> </div> </div>	<p>Carry-out step A19</p> <p>Repair or replace cables, as required</p>
A19	CONTINUITY CHECK		
	- Check for continuity between pin 9B of control unit N46 and connector G252a (GRY-YEL wire)	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="font-size: 24px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 24px;">▶</div> </div> </div>	<p>Carry-out step A20</p> <p>Repair or replace cables, as required</p>
A20	CONTINUITY CHECK		
	- Check for continuity between connector G252a (GRY - GRN wire) and pin 4 of connector G149	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="font-size: 24px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 24px;">▶</div> </div> </div>	<p>Carry-out step A21</p> <p>Repair or replace cables, as required</p>

(Cont.d)

CHECK OF SHOCK ABSORBER CONTROL RELAY - SOLENOID VALVE -  
CONTROL UNIT SUPPLY

## TEST A







TEST STEPS		RESULTS	REMEDY
<b>A21</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pin 4 of connector <b>G149</b> and solenoid valve <b>M17</b>		 ►  ►	Carry-out step <b>A22</b>  Repair or replace cables, as required
<b>A22</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between crimping connection <b>G251</b> and solenoid valve <b>M20</b> (RED wire)		 ►  ►	Carry-out step <b>A23</b>  Repair or replace cables, as required
<b>A23</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between crimping connection <b>G251</b> and solenoid valve <b>M19</b> (RED wire)		 ►  ►	Carry-out step <b>A24</b>  Repair or replace cables, as required
<b>A24</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pin 1C of control unit <b>N46</b> and solenoid valve <b>M20</b> (GRY-WHT wire)		 ►  ►	Carry-out step <b>A25</b>  Repair or replace cables, as required

(Cont.d)



## CHECKING THE ACCELEROMETER

## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>SIGNAL ACCH CHECK</b>		
<ul style="list-style-type: none"> <li>- Detach the accelerometer from the control unit and place it vertically on boot floor, keeping the connector plugged.</li> <li>- Set ignition key to "run".</li> <li>- Apply tester prods to pin 4B of control unit N46 and ground.</li> <li>- Drop a 3/4" steel ball from a 60 cm (1.9686 ft) height on accelerometer center.</li> <li>- Read on tester a variation ranging from 1.1 to 5V (dc).</li> </ul>		 	<p>Carry-out step B2</p> <p>Carry-out step B3</p>
<b>B2</b>	<b>SIGNAL ACCL CHECK</b>		
<ul style="list-style-type: none"> <li>- Apply tester prods to pin 10C of control unit N46 and ground, and repeat test described in step B1.</li> </ul>		 	<p>Carry-out TEST C</p> <p>Carry-out step B3</p>
<b>B3</b>	<b>ACCELEROMETER SUPPLY CHECK</b>		
<ul style="list-style-type: none"> <li>- With the key set to "run" position, check for a voltage higher than 5V between pins A and B of accelerometer N47</li> </ul>		 	<p>Carry-out step B5</p> <p>Carry-out step B4</p>

(Cont.d)

<b>CHECKING THE ACCELEROMETER</b>	<b>TEST B</b>
-----------------------------------	---------------

	TEST STEPS	RESULTS	REMEDY
<b>B4</b>	<b>ACCELEROMETER SUPPLY CHECK</b>		
	<ul style="list-style-type: none"> <li>- With the key set to "run", check for a voltage higher than 5V between pins 1B and 3B of control unit N46</li> </ul>	<div style="display: flex; align-items: center; justify-content: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div>	<p>Restore wiring between pins A and B of accelerometer N47 and pins 1B and 3B of control unit N46</p> <p>Carry-out step B6</p>
<b>B5</b>	<b>CONTINUITY CHECK</b>		
	<ul style="list-style-type: none"> <li>- Check for continuity between:                             <ul style="list-style-type: none"> <li>• pin C of accelerometer N47 and pin 4B of control unit N46</li> <li>• pin D of accelerometer N47 and pin 10C of control unit N46</li> </ul> </li> </ul>	<div style="display: flex; align-items: center; justify-content: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div>	<p>Replace accelerometer N47</p> <p>Repair or replace cables, as required</p>
<b>B6</b>	<b>ACCELEROMETER SUPPLY CHECK</b>		
	<ul style="list-style-type: none"> <li>- Unplug the connector from accelerometer N47. The key being set to "run", check for a voltage higher than 5V between pins A and B of accelerometer N47 connector.</li> </ul>	<div style="display: flex; align-items: center; justify-content: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div>	<p>Replace accelerometer N47</p> <p>Carry out step B7</p>
<b>B7</b>	<b>CONTINUITY CHECK</b>		
	<ul style="list-style-type: none"> <li>- Check for continuity between:                             <ul style="list-style-type: none"> <li>• pin A of accelerometer N47 and pin 1B of control unit N46</li> <li>• pin B of accelerometer N47 and pin 3B of control unit N46</li> </ul> </li> </ul>	<div style="display: flex; align-items: center; justify-content: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center; justify-content: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div>	<p>Replace control unit N46</p> <p>Repair or replace cables, as required</p>

End of test B



CHECKING THE STEERING ANGLE SENSOR









TEST C

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Before testing, check for steering angle sensor correct alignment, has described in <b>Group 21 of SERVICE MANUAL.</b></p>			
<b>C1</b>	<b>SIGNAL STRZ CHECK</b>		
<p>- With ignition key set to "run", perfectly align front wheels and check for 0V at pin 1A of control unit N46. Steer rightwards and leftwards and check for voltage variations</p>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry out step C2</p> <p>Carry-out step C4</p>
<b>C2</b>	<b>SIGNAL STR1 CHECK</b>		
<p>- With ignition key set to "run", perfectly align front wheels and check for a voltage ranging from 3V to 5V at pin 6 of control unit N46. Steer and check a voltage variation from previous value to 0V and viceversa each 18° rotation of steering wheel</p>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry out step C3</p> <p>Carry out step C8</p>
<b>C3</b>	<b>SIGNAL STR2 CHECK</b>		
<p>- With ignition key set to "run", perfectly align front wheels and check for 0V at pin 11A of control unit N46. Steer and check a voltage variation from 0V to 3 - 5V and viceversa each 18° rotation of steering wheel</p>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry out TEST D</p> <p>Carry out step C9</p>
<b>C4</b>	<b>SENSOR SUPPLY CHECK</b>		
<p>- With ignition key set to "run", check for approx. 5V at pins 1 and 2 of sensor L40</p>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry out step C7</p> <p>Carry out step C5</p>

(Cont.d)

## CHECKING THE STEERING ANGLE SENSOR

## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C5</b>	<b>SENSOR SUPPLY CHECK</b>		
- With ignition key set to "run", check for approx. 5V at pins 9A and 7A of control unit N46		 ►	Restore wiring between pins 1 and 2 of sensor L40 and pins 7A and 9A of control unit N46 through connector G252c
		 ►	Carry-out step C6
<b>C6</b>	<b>SENSOR SUPPLY CHECK</b>		
- Unplug connector from sensor L40 and, with ignition key set to "run", check for approx. 5V at pins 2 and 7 of sensor L40 connector		 ►	Replace sensor L40
		 ►	Carry-out step C10
<b>C7</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pin 3 of sensor L40 and pin 1A of control unit N46, through connector G252c		 ►	Replace sensor L40
		 ►	Repair or replace cables, as required
<b>C8</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pin 4 of sensor L40 and pin 6A of control unit N46, through connector G252c		 ►	Replace sensor L40
		 ►	Repair or replace cables, as required

(Cont.d)

## CHECKING THE STEERING ANGLE SENSOR

















## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C9</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for continuity between pin 5 of sensor L40 and pin 11A of control unit N46, through connector G252c</li> </ul>		<p style="text-align: center;">OK      ►</p> <p style="text-align: center;"><del>OK</del>      ►</p>	<p style="text-align: center;">Replace sensor L40</p> <p style="text-align: center;">Repair or replace cables, as required</p>
<b>C10</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for continuity between:             <ul style="list-style-type: none"> <li>• pin 1 of sensor L40 and pin 7A of control unit N46, through connector G252c</li> <li>• pin 2 of sensor L40 and pin 9A of control unit N46, through connector G252c</li> </ul> </li> </ul>		<p style="text-align: center;">OK      ►</p> <p style="text-align: center;"><del>OK</del>      ►</p>	<p style="text-align: center;">Replace control unit N46</p> <p style="text-align: center;">Repair or replace cables, as required</p>

End of test C









**CHECKING THE CONTROL PUSH-BUTTONS OF SHOCK-ABSORBER CONTROL SYSTEM**

**TEST D**

TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>AUTO SIGNAL CHECK</b>		
	- Keeping AUTO pushbutton pressed, check for 0V at pin 8A of control unit N46	 	Carry-out step D2
		 	Carry-out step D3
<b>D2</b>	<b>SPORT SIGNAL CHECK</b>		
	- Keeping SPORT pushbutton pressed, check for 0V at pin 12A of control unit N46	 	Carry-out TEST E
		 	Carry-out step D4
<b>D3</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of ground at pin 6 of pushbutton panel B66	 	Carry-out step D5
		 	Restore connection between pin 6 of pushbutton panel B66 and ground G174
<b>D4</b>	<b>CONTINUITY CHECK</b>		
	- Check for continuity between pin 1 of pushbutton panel B67 and pin 12A of control unit N46	 	Replace pushbutton panel B67
		 	Repair or replace cables, as required

(Cont.d)

<b>CHECKING THE ENGINE THROTTLE MICROSWITCH AND SWITCH ON GEARBOX</b>	<b>TEST E</b>
---	---------------

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Before testing, check for correct opening regulation of engine throttle microswitch as described in <b>Group 21 of SERVICE MANUAL.</b></p>		
<b>E1</b>   CORRECT OPERATION CHECK	 ▶  ▶	Carry-out <b>step E2</b>
- With ignition key set to "parking", check for open circuit at pin 2B of control unit N46		Carry-out <b>step E3</b>
<b>E2</b>   CORRECT OPERATION CHECK	 ▶  ▶	Carry-out <b>TEST F</b>
- Set shift lever to 1st or 2nd speed, press on the accelerator and checks for presence of ground at pin 2B of control unit N46		Carry-out <b>step E3</b>
<b>E3</b>   ENGINE THROTTLE MICROSWITCH CHECK	 ▶  ▶	Carry-out <b>step E4</b>
- Apply multimeter prods to pins of microswitch H47 and check for open circuit presence		Replace microswitch <b>H47</b>
<b>E4</b>   ENGINE THROTTLE MICROSWITCH CHECK	 ▶  ▶	Carry-out <b>step E5</b>
- Press on accelerator pedal and check for presence of shortcircuit on microswitch H47		Replace microswitch <b>H47</b>

(Cont.d)

CHECKING THE CONTROL PUSH-BUTTONS OF SHOCK-ABSORBER  
CONTROL SYSTEM









TEST D

TEST STEPS		RESULTS	REMEDY
D5	CONTINUITY CHECK		
<ul style="list-style-type: none"> <li>- Check for continuity between pin 4 of pushbutton panel B67 and pin BA of control unit N46</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace pushbutton panel B67</p> <p>Repair or replace cables, as required</p>

End of test D

## CHECKING THE ENGINE THROTTLE MICROSWITCH AND SWITCH ON GEARBOX







TEST E

TEST STEPS		RESULTS	REMEDY
<b>E5</b>	<b>MICROSWITCH CHECK ON GEARBOX</b>		
	- Set shift lever to 1st or 2nd speed. Apply multimeter prods to pins of microswitch H46 and check for open circuit presence	 ►  ►	Carry-out step E6  Replace microswitch H46
<b>E6</b>	<b>MICROSWITCH CHECK ON GEARBOX</b>		
	- Set shift lever to 3rd, 4th, 5th or reverse speed. Apply multimeter prods to pins of microswitch H46 and check for presence of a shortcircuit	 ►  ►	Carry-out step E7  Replace microswitch H46
<b>E7</b>	<b>CONTINUITY CHECK</b>		
	- Check for continuity between microswitch H46 (BLK wire) and ground G53	 ►  ►	Carry-out step E8  Repair or replace cables, as required
<b>E8</b>	<b>CONTINUITY CHECK</b>		
	- Check for continuity between microswitch H46 (GRY-BLK wire) and microswitch H47 (GRY-BLK wire)	 ►  ►	Carry-out step E9  Repair or replace cables, as required

(Cont.d)

CHECKING THE ENGINE THROTTLE MICROSWITCH AND SWITCH ON GEARBOX

TEST E









TEST STEPS		RESULTS	REMEDY
<b>E9</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between microswitch H47 (GRN-WHT wire) and pin 4 of connector G151			Carry-out step E10
			Repair or replace cables, as required
<b>E10</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pin 4 of connector G151 and connector G252a (GRN-WHT wire)			Carry-out step E11
			Repair or replace cables, as required
<b>E11</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between connector G252a (GRN-WHT wire) and pin 2B of control unit N46			Carry-out TEST F
			Repair or replace cables, as required

End of test E



## CHECKING OIL MICROSWITCH





TEST F

TEST STEPS		RESULTS	REMEDY
<b>F1</b>	<b>OIL MICROSWITCH CHECK</b>		
	- Apply multimeter prods to microswitch L41 pins and read a resistance of about <del>1200</del> Ohm 2200	 	Carry-out step F2  Replace microswitch L41
<b>F2</b>	<b>OIL MICROSWITCH CHECK</b>		
	- Press on brake pedal and check for presence of short circuit between microswitch L41 pins	 	Carry-out step F3  Replace microswitch L41
<b>F3</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of ground on microswitch L41 (BLK wire)	 	Carry-out step F4  Restore connection between microswitch L41 (BLK wire) and ground G53
<b>F4</b>	<b>CONTINUITY CHECK</b>		
	- Check for continuity between microswitch L41 (YEL wire) and pin 3 of connector G151	 	Carry-out step F5  Repair or replace cables, as required

(Cont.d)

CHECKING OIL MICROSWITCH

TEST F

TEST STEPS		RESULTS	REMEDY
<b>F5</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pin 3 of connector <b>G151</b> and connector <b>G252a</b> (YEL wire)		 ▶  ▶	Carry-out step <b>F6</b>  Repair or replace cables, as required
<b>F6</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between connector <b>G252a</b> (YEL wire) and pin 6C of control unit <b>N46</b>		 ▶  ▶	Carry-out <b>TEST G</b>  Repair or replace cables, as required

End of test F

## CHECKING THE SPEEDOMETER SENSOR













## TEST G

TEST STEPS		RESULTS	REMEDY
<b>G1</b>	<b>SENSOR SUPPLY CHECK</b>		
<ul style="list-style-type: none"> <li>- With ignition key set to "run", check for presence of 12V between pin 3C of instrument panel C10 and ground</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step G2</p> <p>Check Instrument panel C10 supply by carrying out TEST A described in the section INSTRUMENT PANEL</p>
<b>G2</b>	<b>SENSOR SUPPLY CHECK</b>		
<ul style="list-style-type: none"> <li>- With ignition key set to "run", check for presence of 12V between pin 3 of sensor L17 and ground</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step G3</p> <p>Restore wiring between pin 3 of sensor L17, pin 14 of connector G151, and pin 3C of instrument panel C10</p>
<b>G3</b>	<b>SPEEDOMETER SIGNAL CHECK</b>		
<ul style="list-style-type: none"> <li>- Place the vehicle on a lift platform so that the front wheels turn freely.</li> <li>- Start the engine and engage 1st speed. Have engine running at about 2000 rpm.</li> <li>- Check for approx 5V at pin 4C of instrument panel C10</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step G5</p> <p>Carry-out step G4</p>

(Cont.d)

CHECKING THE SPEEDOMETER SENSOR

















TEST G

TEST STEPS		RESULTS	REMEDY
<b>G4</b>	<b>SPEEDOMETER SIGNAL CHECK</b>		
- In the same condition as in step G3, check for presence of approx 5V between pin 2 of sensor L17 and ground		 	Restore wiring among pin 2 of sensor L17, pin 18 of connector G151 and pin 4C of instrument panel C10
		 	Replace sensor L17
<b>G5</b>	<b>SPEEDOMETER SIGNAL CHECK</b>		
- In the same condition as in step G3, check for presence of approx 5V between pin 1A of instrument panel C10 and ground		 	Carry-out step G6
		 	Replace instrument panel C10
<b>G6</b>	<b>SPEEDOMETER SIGNAL CHECK</b>		
- In the same condition as in step G3, check for presence of approx 5V between pin 4A of control unit N46 and ground		 	Replace control unit N46
		 	Restore wiring among pin 4A of control unit N46, connector G252c (BRN-WHT wire) and pin 1A of instrument panel C10

End of test G





## ONE OR MORE WARNING LAMPS INOPERATIVE

## TEST H

TEST STEPS		RESULTS	REMEDY
<b>H1</b>	<b>FUSE CHECK</b>		
	- Check for fuse F14 integrity	   	Carry-out step H2  Replace fuse F14
<b>H2</b>	<b>12V CHECK</b>		
	- Check for presence of 12V between pins 4S of fuse box G1 and ground	   	Carry-out step H4  Carry-out step H3
<b>H3</b>	<b>VOLTAGE CHECK</b>		
	- With the ignition key set to "run" check for presence of 12V between pin 4O of fuse box G1 and ground	   	Replace fuse box G1  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>H4</b>	<b>12V CHECK</b>		
	- Check for presence of 12V between pin 6 of pushbutton panel B67 and ground	   	Carry-out step H5  Restore wiring between pin 6 of pushbutton panel B67 and pin 4S of fuse box G1

(Cont.d)


ONE OR MORE WARNING LAMPS INOPERATIVE	TEST H
---------------------------------------	--------

TEST STEPS		RESULTS	REMEDY
H5	WARNING LAMPS CHECK		
	<ul style="list-style-type: none"> <li>- Check leds of pushbutton panel B67 for integrity</li> </ul>	 	<p>Carry-out step H6</p> <p>Replace defective leds</p>
H6	CONTINUITY CHECK		
	<ul style="list-style-type: none"> <li>- Check for continuity between:                             <ul style="list-style-type: none"> <li>• pin 2 of push-button panel B67 and pin 2A of control unit N46, through connector G252b.</li> <li>• pin 3 of push-button panel B67 and pin 5A of control unit N46, through connector G252b</li> <li>• pin 5 of push-button panel B67 and pin 10A of control unit N46, through connector G252b</li> </ul> </li> </ul>	 	<p>Replace push-button panel B67 or control unit N46</p> <p>Repair or replace cables, as required</p>

End of test H

# CRUISE CONTROL

**BASE AND L ONLY**





## GENERAL (BASE and L only)

The CRUISE CONTROL is an electro-pneumatic device which allows the vehicle to automatically maintain a constant speed, independently from road characteristics. The cruise control system is operated by a switch located near steering wheel. For safety purpose, the system cannot be engaged if the speed is lower than 35 mph. The system is provided with two switches:

- three-position pushbutton switch ON/OFF/RESUME-ACCEL.
- pushbutton switch SET/COAST.

When the switch is set to OFF position, the system is disengaged. To activate the system, move the switch to ON position. When the required speed is reached, depress SET/COAST.

In such operating mode, the vehicle maintains automatically a constant speed, regardless of road and traffic conditions.

The CRUISE CONTROL system will be disengaged if either the brake pedal (vehicles equipped with automatic gear) or clutch pedal (vehicles equipped with manual gear) is depressed. To resume the previously selected speed, it is necessary to move ON/OFF/RESUME-ACCEL switch to RESUME-ACCEL, and then release it.

### NOTE

On vehicles equipped with automatic transmission, the system is automatically disengaged if transmission lever is inadvertently set to N and P positions.

During trip it is possible to increase or reduce the selected speed as for the following procedures:

to increase speed, accelerate until the new required speed is reached, then depress SET/COAST pushbutton, or set switch to RESUME-ACCEL position then release it: the speed increases of 1 mph approximately per each impulse.

If the switch is maintained depressed, the speed increases continuously until switch is released.

To decrease speed, depress SET/COAST pushbutton until the new desired speed reached then release it.

The system is powered when ignition key is in "run" position, and is protected by fuse F14 (7.5A) CRUISE CONTROL in fuse box G1.

## FUNCTIONAL DESCRIPTION

The 12V current is supplied, through fuse F14 in fuse box G1, to cruise control switch B64, which powers the electronic control unit regardless of its position.


The cruise control unit N39 manages cruise control actuator M14 depending on switches position.

The cruise control unit N39 continuously controls the speed by means of speedometer control L17, and consequently manages actuator M14.

If either brake pedal (vehicles equipped with automatic gear) or clutch pedal (vehicles equipped with manual gear) is depressed, the relevant switch H45 opens and cruise control unit N39 disengages the system.

On vehicles equipped with automatic gear, if the gear lever is inadvertently moved to P or N position, the start and reverse gear inhibitor switch H16 closes and cruise control unit N39 disengages the system.

**S ONLY**



## GENERAL (S only)

The CRUISE CONTROL is an electro-pneumatic device which allows the vehicle to automatically maintain a constant speed, independently from road characteristics. The cruise control system is operated by a switch located near steering wheel. For safety purpose, the system cannot be engaged if the speed is lower than 35 mph. The system is provided with two switches:

- three-position pushbutton switch ON/OFF/RESUME-ACCEL.
- pushbutton switch SET/COAST.

When the switch is set to OFF position, the system is disengaged. To activate the system, move the switch to ON position. When the required speed is reached, depress SET/COAST.

In such operating mode, the vehicle maintains automatically a constant speed, regardless of road and traffic conditions.

The CRUISE CONTROL system will be disengaged if either the brake pedal (vehicles equipped with automatic gear) or clutch pedal (vehicles equipped with manual gear) is depressed. To resume the previously selected speed, it is necessary to move ON/OFF/RESUME-ACCEL switch to RESUME-ACCEL, and then release it.

During trip it is possible to increase or reduce the selected

speed as for the following procedures:

to increase speed, accelerate until the new required speed is reached, then depress SET/COAST pushbutton, or set switch to RESUME-ACCEL position then release it: the speed increases of 1 mph approximately per each impulse.

If the switch is maintained depressed, the speed increases continuously until switch is released.

To decrease speed, depress SET/COAST pushbutton until the new desired speed reached then release it.

The system is powered when ignition key is in "run" position, and is protected by fuse F14 (7.5A) CRUISE CONTROL in fuse box G1.

## FUNCTIONAL DESCRIPTION

The 12V current is supplied, through fuse F14 in fuse box G1, to cruise control switch B64, which powers the electronic control unit regardless of its position.










The cruise control unit N39 manages cruise control actuator M14 depending on switches position.

The cruise control unit N39 continuously controls the speed by means of speedometer control L17, and consequently manages actuator M14.









If either brake pedal (vehicles equipped with automatic gear) or clutch pedal (vehicles equipped with manual gear) is depressed, the relevant switch H45 opens and cruise control unit N39 disengages the system.

TROUBLESHOOTING TABLE


FAULT TYPE	FAILED COMPONENT				
	F14 FUSE	B64 SWITCH	L17 SENSOR	M14 ACTUATOR	N39 CONTROL UNIT
SYSTEM INOPERATIVE	●	●			
RES-ACCEL CONTROL INOPERATIVE		●			●
SYSTEM FAILS TO DE-ACTIVATE WHEN BRAKE PEDAL (OR CLUTCH PEDAL ON CARS EQUIPPED WITH MANUAL TRANSMISSION) IS DEPRESSED					●
SET/COAST CONTROL INOPERATIVE		●			●
RELIEF SERVO-VALVE INOPERATIVE				●	●
COMPENSATING SERVO-VALVE INOPERATIVE				●	●
LOSS OF SPEEDOMETER SIGNAL			●		

<p>Cruise control OFF/RESUME switch <span style="float: right;">(B64)</span></p>	<p>Instrument panel <span style="float: right;">(C10) (A)</span></p>
 <p>BRN (N39) 2 BRN (N39) 2 YEL (N39) 4 DKGRN (N39) 3 1 RED (G242)</p>	<p><b>S ONLY</b></p>  <p>GRY (G242) G252 G164 PN 14</p>
<p>Instrument panel <span style="float: right;">(C10) (C)</span></p>	<p><b>S ONLY</b></p>  <p>PNK-BLK (G151) 3 GRY (G151) 4</p>
<p>Fuse box <span style="float: right;">(G1) (Q)</span></p>	<p>Fuse box <span style="float: right;">(G1) (O)</span></p>  <p>2.5PNK (HOT IN RUN) 4</p>
<p>Fuse box <span style="float: right;">(G1) (Q)</span></p>	<p>Connector, circuit board to engine utilities wiring <span style="float: right;">(G151)</span></p>
 <p>1PNK-BLK (G242) 1</p>	<p>Connector, circuit board to engine utilities wiring <span style="float: right;">(G151)</span></p>
<p>Connector, circuit board to engine utilities wiring <span style="float: right;">(G151)</span></p>	<p><b>BASE AND L ONLY</b></p>  <p>1PNK-BLK (L17) 14 1GRY (L17) 18 PNK-BLK (C10) (C) 14 GRY (C10) (C) 18</p>
<p><b>S ONLY</b></p>  <p>1PNK-BLK (L17) 14 1GRY (L17) 18 PNK-BLK (C10) (C) 14 GRY (C10) (C) 18</p>	<p>Steering wheel column support ground <span style="float: right;">(G174)</span></p>
<p><b>BASE AND L ONLY</b></p>  <p>1BLK (151)</p>	<p><b>BASE AND L ONLY</b></p>  <p>1BLK (151)</p>

(Cont.d)


<p>Connector, circuit board to automatic gear lever wiring</p>	<p><b>G233</b></p>	<p>Connector, circuit board to automatic gear lever wiring</p>	<p><b>G233</b></p>
<p><b>BASE AND L ONLY</b></p> 		<p><b>S ONLY</b></p> 	
<p>Board wiring to cruise control wiring connector</p>	<p><b>G242</b></p>	<p>Board wiring to cruise control wiring connector</p>	<p><b>G242</b></p>
<p><b>BASE AND L ONLY</b></p> 		<p><b>S ONLY</b></p> 	
<p>Start inhibitor switch</p>	<p><b>H16</b></p>	<p>Clutch switch for cruise control device</p>	<p><b>H45a</b></p>
			
<p>Brake switch for cruise control device</p>	<p><b>H45b</b></p>	<p>Electronic control units power supply relay</p>	<p><b>I51</b></p>
			

(Cont.d)






**BASE AND L ONLY**





**S ONLY**



# #1 - Cruise Control - Volt Test - ECU Connected - Car Static

**Note:** Probe the wires at the cruise control connector from the back of the connector only, as pictured below. Probing the wires from the front can damage the terminal contacts.

**MEASUREMENTS IN THIS SECTION ARE TAKEN WITH THE ECU CONNECTED - CAR STATIONARY**

Pin 3 - Gray Wire - Speedo Input

Read 5 volts w/key "on".

Record reading \_\_\_\_

Pin 1 - Light Green - ECU Ground

Read 0 volts w/key "off".

Record reading \_\_\_\_

Pin 5 - Brown Wire - Power Feed

Measurement between these two points should read 12 volts / cruise "on".

Record reading \_\_\_\_

Pin 1 - Light Green - ECU Ground

0 volts cruise "off".

Record reading \_\_\_\_

Pin 7 - Brown Wire - Power Feed



Measurement between these two points should read 12 volts / cruise "on".

Record reading \_\_\_\_

Pin 1 - Light Green - ECU Ground

0 volts cruise "off".

Record reading \_\_\_\_



(Cont.d)

## #2 - Cruise Control - Volt Test - ECU Connected - In Motion

**Note:** Probe the wires at the cruise control connector from the back of the connector only, as pictured below. Probing the wires from the front can damage the terminal contacts.

MEASUREMENTS IN THIS SECTION ARE TAKEN WITH THE ECU CONNECTED AND THE CAR IN MOTION - CRUISE ON & SET BUTTON PRESSED

Pin 4 - Plum Wire - Charge Valve

Pin 1 - Light Green - ECU Ground

In motion - cruise "on" - Set button activated - Read a fluctuating signal any where between 0.1 & 12 volts.

Record readings \_\_\_\_\_

Pin 6 - White Wire - Vent Valve

Pin 1 - Light Green - ECU Ground

In motion - cruise "on" - Set button activated - Read a fluctuating signal any where between 9 & 12 volts.



Record readings \_\_\_\_\_

Pin 8 - Pink Wire - Dump Valve

Pin 1 - Light Green - ECU Ground

In motion - cruise "on" - Set button activated - Read 12 volts. In motion - cruise "off" - Read 0 volts.

Record readings here - "on" \_\_\_\_\_ & "off" \_\_\_\_\_



# #3 - Cruise Control - Volt Test - ECU Disconnected - Car Static

**Note:** Probe the wires at the cruise control connector from the back of the connector only, as pictured below. Probing the wires from the front can damage the terminal contacts.

MEASUREMENTS IN THIS SECTION ARE TAKEN WITH THE ECU DISCONNECTED - CAR STATIONARY

Pin 9 - Blue Wire - In Gear Input Sw.

Pin 1 - Light Green - ECU Ground

Auto. Trans. only - Read 12 volts in R, D, 3, 2 or 1 with the key "ON", Cruise "OFF".

Record reading \_\_\_\_\_

Pin 10 - Yellow Wire - Trigger Input

Pin 1 - Light Green - ECU Ground

Cruise switch "on" or "off" - Read 0 Volts

Record reading \_\_\_\_\_

Resume/accel switch "on" or set button pressed -  
Read 12 volts.

Record reading \_\_\_\_\_

Pin 14 - Green Wire - Set Signal

Pin 1 - Light Green - ECU Ground

Cruise "off" - 0 volts.

Record reading \_\_\_\_\_

Cruise "on" - 12 volts.



Record reading \_\_\_\_\_

Cruise "on" / Set Button pressed - 0 volts.

Record reading \_\_\_\_\_

Cruise "on" / Resume/Accel Button pressed - 12 volts.

Record reading \_\_\_\_\_



# #4 - Cruise Control - Ohm Meter Tests - ECU Disconnected

Note: Probe the wires at the cruise control connector from the back of the connector only, as pictured below. Probing the wires from the front can damage the terminal contacts.

MEASUREMENTS IN THIS SECTION ARE TAKEN WITH THE ECU DISCONNECTED  
KEY OFF - USE OHM METER SET TO APPROPRIATE SCALE

Pin 1 - Light Green - ECU Ground

Any Suitable Clean Chassis Ground

Measurement between these two points should read less than 2 Ohms.

Record reading \_\_\_\_\_

Pin 2 - Black Wire - Throttle Feedback

Pin 11 - Tan Wire - Throttle Feedback

Measurement between these two points should indicate approximately 500 Ohms.

Record reading \_\_\_\_\_

Pin 4 - Plum Wire - Charge Valve

Pin 12 - Orange Wire - Valve Common

Measurement between these two points should indicate approximately 50 Ohms.

Record reading \_\_\_\_\_

Pin 6 - White Wire - Vent Valve

Pin 12 - Orange Wire - Valve Common

Measurement between these two points should indicate approximately 50 Ohms.

Record reading \_\_\_\_\_

Pin 8 - Pink Wire - Dump Valve

Pin 1 - Light Green - ECU Ground

Measurement between these two points should indicate approximately 50 Ohms.

Record reading \_\_\_\_\_

Pin 9 - Blue Wire - In Gear Input Sw.

Pin 1 - Light Green - ECU Ground

5 Speed - Open circuit.

Record reading \_\_\_\_\_

Auto. Trans. - Open circuit, in gear and closed circuit in Park or Neutral.



Record reading \_\_\_\_\_

Pin 13 - Purple Wire - Brake / Clutch

Pin 1 - Light Green - ECU Ground

Read less than 2 Ohms pedal(s) not depressed and open circuit when pedal(s) is depressed.


Record reading \_\_\_\_\_



**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>

DEFOGGER - - REAR WINDOW,  
FRONT WINDSHIELD, EXTERNAL  
MIRRORS





## GENERAL

The rear window, the windshield and the external rearview mirrors incorporate an electric conductor that, when energized, heats the surrounding surface with heat produced by the circuit resistance, thus providing defogging of the affected surface.

Defogging of the rear window, windshield and mirrors can be activated manually or automatically.

In the manual mode, defogging is activated by pressing the relevant switch on the air conditioning control panel: the system will remain activated for a period of  $\frac{16}{20}$  minutes.

Subsequent pressure on the switch will re-activate the system for further  $\frac{8}{10}$  minutes only if the previous  $\frac{16}{20}$  minutes period is expired; otherwise, pressure on the switch turns defogging off. Energization of the defogging system is indicated by the illumination of an indicator lamp on the instrument panel.

In the automatic mode, defogging of the rear window, windshield and mirrors activates when the outside ambient temperature decreases below a pre-set value.

The defogging system is protected by fuses, as follows:

- F9 fuse (10A) EXTERNAL REARVIEW MIRRORS/

REAR WINDOW/LAMP in the fuse box G1.

- G201 free fuse (30A) REAR WINDOW DEFOGGING.

## OPERATIONAL DESCRIPTION

The external rearview mirrors defogging relay I45 in the fuse box G1 is connected to the 12V battery power when the ignition key is set to "run".

The relay I45 energizes when the automatic control mode check unit Q21A closes the circuit to ground.

This condition is met by pressing the defogging switch on the air condition switch board, or automatically when the outside ambient temperature decreases below a pre-set value.


12V from the battery are applied to fuse F9 through the relay contacts, and then to the indicator lamp on the instrument panel, to the left and right mirrors defogger O19 and O18, and to the windshield defogger O25.

Furthermore, the 12V power from fuse F9 is supplied to the coil of the rear window defogger relay I2.

Energization of relay I2 supplies electric power to the electrically heated rear window O1 through the free fuse G201 and the relay contacts.

TROUBLESHOOTING TABLE





FAULT TYPE	FAILED COMPONENT								
	F9 FUSE	G201 FUSE	12 RELAY	145 RELAY	01 DEFOGGER	01B DEFOGGER	019 DEFOGGER	025 DEFOGGER	021A CONTROL UNIT
ALL DEFOGGERS INOPERATIVE	●			●					●
REAR WINDOW DEFOGGER INOPERATIVE		●	●		●				
LEFT REARVIEW MIRROR DEFOGGER INOPERATIVE							●		
RIGHT REARVIEW MIRROR DEFOGGER INOPERATIVE						●			
WINDSHIELD DEFOGGER INOPERATIVE								●	




(Cont.d)

<p>Connector, circuit board to left rear wiring</p>	<p><b>G171</b></p>	<p>Steering wheel column support ground</p>	<p><b>G174</b></p>
<p>Trunk left side ground</p>		<p>Connector, left rear wiring to front doors</p>	
<p>Trunk right side ground</p>		<p>Rear window defogging fuse</p>	
<p>Connector, right rear wiring to front door wiring</p>		<p>Rear window defogging relay</p>	









(Cont.d)

<p>Electrically heated rear window</p>	<p>01</p>	<p>Right external rearview mirrors defogger</p>	<p>018</p>
		<p>Left external rearview mirrors defogger</p>	<p>019</p>
<p>Windshield defogger</p>	<p>025</p>	<p>Automatic control mode check unit</p>	<p>Q21A</p>
			









## ALL DEFOGGERS INOPERATIVE

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
- Check fuse F9 in fuse box G1 for integrity		 ►  ►	Carry-out step A2  Replace fuse F9
<b>A2</b>	<b>INDICATOR LAMP ILLUMINATION CHECK</b>		
- With the ignition key set to "run" press defogging switch and check illumination of indicator lamp on the instrument panel		 ►  ►	Carry-out step A5  Carry-out step A3
<b>A3</b>	<b>CONTROL UNIT CHECK</b>		
- Check that pin 29 of control unit Q21A is connected to ground in either of the following conditions: <ul style="list-style-type: none"> <li>• the defogging switch on the air conditioning switch board has been actuated</li> <li>• when the outside temperature is below a certain value</li> </ul>		 ►  ►	Carry-out step A4  Failure of the air conditioning control panel. Refer to the air conditioning system troubleshooting
<b>A4</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 8A of fuse box G1		 ►  ►	Carry-out step A5  Repair wiring between pin 29 of control unit Q21A, pin 6 of connector G164 and pin 8A of fuse box G1

(Cont.d)

ALL DEFOGGER INOPERATIVE	<b>TEST A</b>
--------------------------	---------------

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 2N of fuse box G1 and ground	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around; align-items: center; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p>Carry-out step A6</p> <p>Failure of the power distribution circuit, refer to relevant circuit of sheet 2 of 2</p>
<b>A6</b>	<b>VOLTAGE CHECK</b>		
	- With the ignition key set to "run" check for presence of 12V between pin 4O of fuse box G1 and ground	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around; align-items: center; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p>Carry-out step A7</p> <p>Failure of the power distribution circuit, refer to relevant circuit of sheet 2 of 2</p>
<b>A7</b>	<b>RELAY CHECK</b>		
	- Check relay I45 for proper operation	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around; align-items: center; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p>Repair wiring between pin 15 of connector G171 and connector R of fuse box G1</p> <p>Replace relay I45</p>

End of test A







<b>REAR WINDOW DEFOGGER INOPERATIVE</b>	<b>TEST B</b>
---	---------------

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>FUSE CHECK</b>		
- Check free fuse G201 for integrity		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step B2  Replace fuse G201
<b>B2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin of fuse G201 (RED wire) and ground		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step B3  Failure of the power distribution circuit, refer to relevant circuit of sheet 1 of 2
<b>B3</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" and defogging switch actuated check for presence of 12V at pins 30 and 86 of relay I2		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step B4  Repair or replace wires, as necessary
<b>B4</b>	<b>RELAY CONTROL</b>		
- Check relay I2 for proper operation		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step B5  Replace relay I2

(Cont.d)

REAR WINDOW DEFOGGER INOPERATIVE	<b>TEST B</b>
----------------------------------	---------------

TEST STEPS		RESULTS	REMEDY
<b>B5</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 85 of relay I2	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p>Carry-out <b>step B5</b></p> <p>Repair wiring between <b>pin 85 of relay I2</b> and <b>ground point G185</b></p>
<b>B6</b>	<b>VOLTAGE CHECK</b>		
	- With the ignition key set to "run" and defogging switch actuated check for presence of 12V at terminals of rear window O1	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p>Replace rear window <b>O1</b></p> <p>Repair wiring between <b>pin of rear window O1</b> and <b>ground point G186 (BLK wire)</b>, and between <b>pin of rear window O1</b> and <b>pin 87 of relay I2 (BLK wire)</b></p>

End of test B







## LEFT REARVIEW MIRROR DEFOGGER INOPERATIVE

## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C1</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>With the ignition key set to "run" and the defogging switch actuated check for presence of 12V at connector G180</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step C2</p> <p>Repair wiring between connector G180 and pin 15 of connector G171</p>
<b>C2</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>Check for presence of 0V (zero) at pin 14 of connector G168</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step C3</p> <p>Repair wiring between pin 14 of connector G168 and ground point G174</p>
<b>C3</b>	<b>DEFOGGER CHECK</b>		
<ul style="list-style-type: none"> <li>With the ignition key set to "run" and the defogging switch actuated check for presence of 12V between pins D and E of defogger O19</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace defogger O19</p> <p>Repair wiring between pin D of defogger O19 and connector G180, and between pin E of defogger O19 and pin 14 of connector G168</p>

End of test C

<b>RIGHT REARVIEW MIRROR DEFOGGER INOPERATIVE</b>	<b>TEST D</b>
---	---------------

	TEST STEPS	RESULTS	REMEDY
<b>D1</b>	<b>WINDSHIELD DEFOGGER CHECK</b>		
	- Check if windshield defogger <b>O25</b> is operative	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	<p>Repair wiring between pin 11 of connector <b>G170</b> and <b>G203</b></p> <p>Carry-out <b>step D2</b></p>
<b>D2</b>	<b>VOLTAGE CHECK</b>		
	- With the ignition key set to "run" and the defogging switch actuated check for presence of 12V at connector <b>G203</b>	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	<p>Carry-out <b>step D3</b></p> <p>Repair wiring between windshield defogger <b>O25</b> and connector <b>G203</b></p>
<b>D3</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 14 of connector <b>G166</b>	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	<p>Carry-out <b>step D4</b></p> <p>Repair wiring between ground point <b>G174</b> and pin 14 of connector <b>G166</b></p>

(Cont.d)





## RIGHT REARVIEW MIRROR DEFOGGER INOPERATIVE

## TEST D

TEST STEPS		RESULTS	REMEDY
D4	DEFOGGER CHECK		
<ul style="list-style-type: none"> <li>With the ignition key set to "run" and the defogging switch actuated check for presence of 12V between pins D and E of defogger O18</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace defogger O18</p> <p>Repair wiring between pin D of defogger O18 and connector G203, and between pin E of defogger O18 and pin 14 of connector G166</p>

End of test D

<b>WINDSHIELD DEFOGGER INOPERATIVE</b>	<b>TEST E</b>
--	---------------

TEST STEPS		RESULTS	REMEDY
<b>E1</b>	<b>R.H. MIRROR DEFOGGER CHECK</b>		
	- Check that the right external rearview mirror defogger O18 is inoperative	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	<p>Repair wiring between windshield defogger O25 and pin 11 of connector G170</p> <p>Carry-out step E2</p>
<b>E2</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V at black wire of windshield defogger O25	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	<p>Replace windshield defogger O25</p> <p>Repair wiring between pin of defogger O25 and ground point G185</p>

End of test E

# ECU - - POWER SUPPLY RELAY





## GENERAL

Part of the vehicle's electrical circuits is powered by the battery (12V) through the electronic control units power supply relay I51.

The relay is energized when the ignition key is either in "start" or "run" positions.

Circuits powered by the above mentioned relay are as follows:

- Fuel door - - Electric opening.
- Air bag.
- Instrument panel - - Indicator circuits.
- Instrument panel - - Alfa Romeo control ECU interface
- Sensors - - Brake fluid level.
- Air conditioning system.

The last four of the above mentioned circuits are protected by the fuse F2 (7.5A) KEY - CONTROLLED CURRENTS FOR ELECTRIC CIRCUIT in the auxiliary fuse box G2.

## OPERATIONAL DESCRIPTION

The battery power (12V) available when the ignition key is set to "start" or "run" position energizes the electronic control unit power supply relay I51.







Energization of relay I51 permits energization (12V) of the Air Bag and fuel filler lid opening circuits.


In addition, 12V are simultaneously supplied to the following circuits through the fuse F2 in the auxiliary fuse box G2.

- Instrument panel - - Indicator circuits.
- Instrument panel - - Alfa Romeo control ECU interface
- Sensors - - Brake fluid level circuit.
- Air conditioning system circuit.

















### NOTE

An adequate knowledge of all the circuits powered by the same line will facilitate the troubleshooting when a failure affects all the relevant circuits simultaneously.

<p>Fuse box</p>	<p>G1 I</p>	<p>Auxiliary fuse box</p>	<p>G2</p>
			
<p>Connector, circuit board to engine compartment left side wiring</p>	<p>G150</p>		
			
<p>Steering wheel column support ground</p>	<p>G174</p>	<p>Electronic control units power supply relay</p>	<p>I51</p>
			
<p>Air Bag diagnosis connector</p>	<p>I3</p>		
			







**FAILURE OF ELECTRONIC CONTROL UNITS POWER SUPPLY RELAY  
CIRCUIT**
**TEST A**

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
	- Check fuse F2 in auxiliary fuse box G2 for integrity	 	Carry-out step A2
		 	Replace fuse F2
<b>A2</b>	<b>FUEL FILLER LID OPENING CHECK</b>		
	- Check the fuel filler lid power opening for correct operation	 	Repair wiring between fuse F2 of auxiliary fuse box G2 and pin 87 of relay I51
		 	Carry-out step A3
<b>A3</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 30 of electronic control units power supply relay I51	 	Carry-out step A5
		 	Carry-out step A4
<b>A4</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 5 of connector G150 and ground	 	Repair wiring between pin 30 of relay I51 and pins of connector G150
		 	Failure of the power distribution circuit, refer to the relevant circuit of sheet 1 of 2

(Cont.d)

FAILURE OF ELECTRONIC CONTROL UNITS POWER SUPPLY RELAY  
CIRCUIT

## TEST A


TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 85 of relay I51		 ►  ►	Carry-out step A6  Repair wiring between pin 85 of relay I51 and ground point G174
<b>A6</b>	<b>VOLTAGE CHECK</b>		
- With ignition key set to "run" or "start", check for presence of 12V between pin 86 of relay I51		 ►  ►	Replace relay I51  Failure of the power distribution circuit refer to the relevant circuit of sheet 2 of 2

End of test A

**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>

# FAN - - AUTOMATIC TRANSMISSION OIL COOLER





## GENERAL

The automatic transmission is equipped with an electric fan for the cooling of the oil.

The fan operation is automatic when the oil temperature reaches  $118^{\circ} \pm 4^{\circ} \text{C}$  ( $244.4 \pm 7.2^{\circ} \text{F}$ ).

The circuit is protected by the fuse **F10** (20A) AUTOMATIC TRANSMISSION OIL COOLER in the fuse box **G1**.

## OPERATIONAL DESCRIPTION

When the ignition key is set to "run" 12V from the battery are applied to pin 86 of the automatic transmission oil cooler fan relay **I63** through fuse **F10** in the fuse box **G1**.

The ground section of relay **I63** is then connected to

ground through the oil cooler thermal switch-automatic transmission **L38**










When the oil temperature increases to a pre-determined value about  $118^{\circ}\text{C}$  ( $244.4^{\circ}\text{F}$ ) the thermal contact closes and energizes the oil cooler fan relay **I63**.


When the relay **I63** is energized, 12V from the battery are applied to the fan motor **P34**.

High oil temperature is indicated on the instrument panel by illumination of the relevant indicator lamp.

Illumination of the indicator lamp is controlled by the Alfa Romeo Control unit **N22** when the automatic transmission oil cooler thermal switch contacts close because of high oil temperature.

















Thermal switch **L38** opens the circuit after the oil temperature has decreased below  $110^{\circ}\text{C}$  ( $230^{\circ}\text{F}$ ).

<p>Fuse box</p>	<p>G1 H</p>	<p>Fuse box</p>	<p>G1 O</p>
			
<p>Engine compartment left side ground connector</p>	<p>G53b</p>	<p>Connector, circuit board to engine compartment left side wiring</p>	<p>G150</p>
			
<p>Horn relay</p>	<p>I3</p>		
<p>Low beam lamps relay (left)</p>	<p>I49</p>	<p>Automatic transmission oil cooler fan relay</p>	<p>I63</p>
			
<p>Oil cooler thermal switch-automatic transmission</p>	<p>L38</p>	<p>Oil cooler electric fan motor-automatic transmission</p>	<p>P34</p>
			



## AUTOMATIC TRANSMISSION OIL COOLING FAN INOPERATIVE

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>F10</b> in fuse box <b>G1</b> for integrity		 	Carry-out step <b>A2</b>
		 	Replace fuse <b>F10</b>
<b>A2</b>	<b>FUSE CHECK</b>		
- Check fuse of relay <b>I63</b> for integrity		 	Carry-out step <b>A3</b>
		 	Replace fuse of relay <b>I63</b>
<b>A3</b>	<b>THERMAL CONTACT CHECK</b>		
- Short circuit fan thermal switch <b>L38</b> and verify that cooling fan <b>P34</b> is actuated		 	Replace thermal switch <b>L38</b>
		 	Carry-out step <b>A4</b>
<b>A4</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" and automatic transmission oil overheated (about $118\pm 4^{\circ}\text{C}$ ) ( $244.4\pm 7.2^{\circ}\text{F}$ ) check for presence of 12V between pins 1 and 2 of cooling fan <b>P34</b>		 	Replace cooling fan <b>P34</b>
		 	Carry-out step <b>A5</b>





(Cont.d)

AUTOMATIC TRANSMISSION OIL COOLING FAN INOPERATIVE	<b>TEST A</b>
--	---------------

TEST STEPS	RESULTS	REMEDY
<b>A5</b>   GROUNDING CHECK  - Check for presence of 0V (zero) at pin 2 of cooling fan P34 (BLK wire)	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; text-align: center; line-height: 30px; margin-right: 10px;">OK</div> <div style="font-size: 24px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; text-align: center; line-height: 30px; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 24px;">▶</div> </div> </div>	Carry-out step A6  Repair wiring between ground point G53b and pin 2 of cooling fan P34
<b>A6</b>   RELAY CHECK  - Check automatic transmission oil cooler fan relay I63 for proper operation	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; text-align: center; line-height: 30px; margin-right: 10px;">OK</div> <div style="font-size: 24px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; text-align: center; line-height: 30px; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 24px;">▶</div> </div> </div>	Carry-out step A7  Replace relay I63
<b>A7</b>   VOLTAGE CHECK  - With the ignition key set to "run" check for presence of 12V between pin 86 of relay I63 and ground	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; text-align: center; line-height: 30px; margin-right: 10px;">OK</div> <div style="font-size: 24px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; text-align: center; line-height: 30px; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 24px;">▶</div> </div> </div>	Carry-out step A9  Carry-out step A8
<b>A8</b>   VOLTAGE CHECK  - With the ignition key set to "run" check for presence of 12V between pin 4O of fuse box G1 and ground	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; text-align: center; line-height: 30px; margin-right: 10px;">OK</div> <div style="font-size: 24px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; text-align: center; line-height: 30px; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 24px;">▶</div> </div> </div>	Repair wiring between pin 1H of fuse box G1, pin 9 of connector G150 and pin 86 of relay I63  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2


(Cont.d)

AUTOMATIC TRANSMISSION OIL COOLING FAN INOPERATIVE	<b>TEST A</b>
--	---------------

TEST STEPS		RESULTS	REMEDY
<b>A9</b>	CONTINUITY CHECK		
	- Check for presence of continuity between pin 85 of relay I63 and thermal switch L38 (WHT-BLK wire)	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Carry-out step A10
		<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Repair or replace wires, as necessary
<b>A10</b>	VOLTAGE CHECK		
	- Check for presence of 12V between pin 87 of relay I63 and ground	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Repair wiring between pin 30 of relay I63 and pin 1 of cooling fan P34
		<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Failure of the distribution circuit, refer to the relevant circuit of sheet 2 of 2

End of test A

# FAN - - RADIATOR COOLING AND A/C CONDENSER





## GENERAL

The engine cooling is obtained by means of a suitable coolant.

The coolant temperature is controlled by an electric fan energized by closing of a thermal switch when the coolant temperature reaches a pre-set value  $\sim 92 \pm 10^{\circ}\text{C}$  ( $198^{\circ} \pm 18^{\circ}\text{F}$ ).

The electric fan is located behind the radiator and in front the air conditioning condenser, this provides cooling for both engine coolant and air conditioning freon.

The system is protected by two fuses as follows:

- **F14** fuse (7.5A) ENGINE ELECTRIC FAN, located in the fuse box **G1**.
- Free fuse **G254** (40A) ENGINE ELECTRIC FAN.

## OPERATIONAL DESCRIPTION

12V from the battery are applied to the engine coolant electric fan motor **P2** through the engine electric fan, 40A,

free fuse **G254**.











With the start key set to "run", the voltage reaches the coil of the electric fan relays **I1** and **I68** through the electric fan fuse **F14** located in the fuse box **G1**.


When the engine coolant reaches a pre-set temperature  $92 \pm 10^{\circ}\text{C}$  ( $198^{\circ} \pm 18^{\circ}\text{F}$ ), the radiator fan thermal switch **L6** closes, and allows energizing of the relevant relay **I1**. With the electric fan relay **I1** energized, the electric fan motor **P2** is grounded through the engine coolant fan supplementary resistor **O22** and becomes operative.

In the event the coolant temperature continues to increase, the supplementary thermal switch **L6** closes, and grounds the supplementary relay **I68**.

Energizing of the relay causes the closure of a contact which cuts-off the supplementary resistor **O22**, and allows the operation of the electric fan at a higher speed.

The electric fan motor **P2** can also be energized through the air conditioning system when necessary to cool the freon in the condenser (refer to the Automatic air conditioning circuit).

<p>Fuse box <span style="float: right;">(G1) (O)</span></p>	<p>Fuse box <span style="float: right;">(G1) (I)</span></p>
 <p>2.5PNK* <b>HOT IN RUN</b> 4</p>	 <p>PNK* <b>G150a</b> 5</p>
<p>Engine compartment left side ground connection <span style="float: right;">(G53b)</span></p>	<p>Connector, circuit board to engine compartment left side wiring <span style="float: right;">(G150a)</span></p>
 <p>2.5BLK* (I1) 1BLK* (L6) 6BLK* (I68)</p>	 <p>PNK* (G1) (I) 1 PNK-WHT* (I1)</p>
<p>Engine electric fan fuse <span style="float: right;">(G254)</span></p>	<p>Engine coolant electric fan relay <span style="float: right;">(I1)</span></p>
 <p>6RED* <b>HOT AT ALL TIMES</b> 6RED* (P2)</p>	 <p>2.5LTBLU* (O22) 87 PNK-WHT* <b>G150a</b> 86 PNK-WHT* (I68) 85 2.5BLK* <b>G53b</b> 30 1BRN* (L6) 85 G150a PIN 2 85</p>
<p>Engine coolant fan supplementary relay <span style="float: right;">(I68)</span></p>	<p>Radiator fan thermal switch <span style="float: right;">(L6)</span></p>
 <p>6BRN* (P2) 87 2.5BRN* (O22) 87 PNK-WHT* (I1) 85 6BLK* <b>G53b</b> 30 1BRN-WHT* (L6) 85</p>	 <p>1BRN-WHT* (I66) 1BRN* (I1) B 1BLK* <b>G53b</b> A</p>
<p>Engine coolant fan supplementary resistor <span style="float: right;">(O22)</span></p>	<p>Engine coolant electric fan motor <span style="float: right;">(P2)</span></p>
 <p>2.5BRN* (I68) 2.5LTBLU* (I1)</p>	 <p>6BRN* (I68) B 6RED* <b>G254</b> A</p>



**ENGINE COOLANT ELECTRIC FAN INOPERATIVE**

**TEST A**

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
	- Check the engine electric fan fuse <b>F14</b> in the fuse box <b>G1</b> for integrity	(OK)      ► ( <del>OK</del> )      ►	Carry-out <b>step A2</b>  Replace fuse <b>F14</b>
<b>A2</b>	<b>FUSE CHECK</b>		
	- Check the engine electric fan fuse <b>G254</b> for integrity	(OK)      ► ( <del>OK</del> )      ►	Carry-out <b>step A3</b>  Replace fuse <b>G254</b>
<b>A3</b>	<b>VOLTAGE CHECK</b>		
	- With the ignition key set to "run" check for presence of 12V between pins 86 of relays <b>I1</b> and <b>I68</b> and ground	(OK)      ► ( <del>OK</del> )      ►	Carry-out <b>step A6</b>  Carry-out <b>step A4</b>
<b>A4</b>	<b>VOLTAGE CHECK</b>		
	- With the ignition key set to "run" check for presence of 12V between pin 1 of connector <b>G150a</b> and ground	(OK)      ► ( <del>OK</del> )      ►	Repair wiring between pin 1 of <b>G150a</b> and pins 86 of relays <b>I1</b> and <b>I68</b>  Carry-out <b>step A5</b>

(Cont.d)

















ENGINE COOLANT ELECTRIC FAN INOPERATIVE	TEST A
---	--------

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>With the ignition key set to "run", check for presence of 12V between pin 40 of fusebox G1 and ground.</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 1 of G150a and pin 5l of fusebox G1</p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2</p>
<b>A6</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>With thermal switch pressed, check for presence of 0V at pins 85 of relays I1 and I68.</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Carry-out step A7</p> <p>Carry-out step A9</p>
<b>A7</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>Check for presence of <del>0V</del> at pin 87 of relay I1. 12V</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Carry-out step A11</p> <p>Carry-out step A8</p>
<b>A8</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>Check for presence of 0V at pin 30 of relay I1</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Replace relay I1</p> <p>Repair wiring between pin 30 of relay I1 and ground point G53b</p>

(Cont.d)

## ENGINE COOLANT ELECTRIC FAN INOPERATIVE









## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A9</b>	<b>CONTINUITY CHECK</b>		
- Check continuity between pins of thermal switch and pins 85 of relays I1 and I68.		   	Carry-out step A10  Repair or replace wiring, as necessary
<b>A10</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V at pin A of thermal switch L6		   	Replace thermal switch L6  Repair wiring between pin A of thermal switch and ground point G53b
<b>A11</b>	<b>CONTINUITY CHECK</b>		
- Check that circuit between pins 87 of relays I1 and I68 is not open (R = 0,23 ohm)		   	Carry-out step A13  Carry-out step A12
<b>A12</b>	<b>CONTINUITY CHECK</b>		
- Check continuity between pins of supplementary resistor and pins 87 of relays I1 and I68		   	Replace supplementary resistor O22  Repair or replace wiring, as necessary

(Cont.d)

## ENGINE COOLANT ELECTRIC FAN INOPERATIVE

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A13</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pins A and B of electric fan motor P2		 ▶  ▶	Replace electric fan motor P2.  Carry-out step A14
<b>A14</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin A of electric fan motor P2 and ground		 ▶  ▶	Carry-out step A16  Carry-out step A15
<b>A15</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin of fuse G254 (RED wire) and ground		 ▶  ▶	Repair wiring between pin A of motor and pin of fuse G254 (RED wire)  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>A16</b>	<b>GROUNDING CHECK</b>		
- With the ignition key set to "run" and the thermal switch pressed, check for presence of 0V at pin 87 of relay I68		 ▶  ▶	Repair wiring between pin 87 of relay I68 and pin B of motor P2  Carry-out step A17

(Cont.d)

## ENGINE COOLANT ELECTRIC FAN INOPERATIVE


## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A17</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V at pin 30 of relay I68		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Replace relay I68</p> <p>Repair wiring between pin 30 of I68 and ground point G53b</p>

End of test A



# FOGLAMPS - - FRONT AND REAR



## GENERAL

Actuation of the front and rear fog lamps only after the low beam lamps have been switched on. Refer to low beam lamps chapter for further details.

Switching on of the front and/or rear fog lamps is indicated by the illumination of the corresponding warning lamps on the instrument panel.

The system is protected by two fuses in the fuse box **G1**, as follows:

- Fuse **F7** (15A) FRONT FOG LAMPS AND LAMP.
- Fuse **F8** (7.5A) REAR FOG LAMPS AND LAMP.

## OPERATIONAL DESCRIPTION

12V from the battery is applied to the multiple switch **B4** and to common contact of front fog lamps relay **I17**. When the multiple switch **B4** is set to this low beam lamps

position, the electric power reaches the coil of rear fog lamps relay **I25**.

Energization of front fog lamps relay **I17**, activated by the switch on the air conditioning control unit **Q21A**, energizes the corresponding line protected by fuse **F7** in fuse box **G1**.

Therefore, electric power is applied to left and right front fog lamp **E10**, connected in parallel, and the lamps are turned on.













Energization of rear fog lamps relay **I25**, activated by the automatic control mode check unit **Q21A**, energizes the corresponding line protected by fuse **F8** in fuse box **G1**. Therefore, electric power is applied to terminals of central tail lamp **E27**, and the lamps are turned on.

Two lines derived from the front and rear fog lamps lines are connected to the instrument panel **C10**. In this way, the corresponding warning lamps on the instrument panel will illuminate any time the front and/or rear fog lamps are switched on.













## TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT										
	<u>EZ</u> FUSE	<u>EB</u> FUSE	<u>C10</u> FRONT FOG LAMP	<u>C10</u> FRONT FOG LAMP	<u>E10</u> R.H. FRONT FOG LAMP	<u>E10</u> L.H. FRONT FOG LAMP	<u>E27</u> REAR CENTER LAMP	<u>B4</u> MULTIPLE SWITCH	<u>117</u> RELAY	<u>125</u> RELAY	<u>021A</u> CONTROL UNIT
BOTH FRONT AND REAR FOG LAMPS INOPERATIVE								•			
BOTH FRONT FOG LAMPS INOPERATIVE	•								•		•
LEFT FRONT FOG LAMP INOPERATIVE						•					
RIGHT FRONT FOG LAMP INOPERATIVE					•						
FRONT FOG LAMPS WARNING LAMP ON INSTRUMENT PANEL INOPERATIVE				•							
REAR FOG LAMP INOPERATIVE		•					•		•	•	
REAR FOG LAMP WARNING LAMP ON INSTRUMENT PANEL INOPERATIVE			•								





**NOTE:** Before carrying-out any troubleshooting check the integrity of warning lamp on instrument panel by pressing the test button.


Parking/Flash/Low beam/High beam switch (B4) (A)	Parking/Flash/Low beam/High beam switch (B4) (D)
	
Instrument panel (C10) (B)	Right front fog lamp (E10)
	
Left front fog lamp (E10)	Tail lamp, left (fixed part) (E26)
	
Central tail lamps (mobile) (E27)	Fuse box (G1) (B)
	
Fuse box (G1) (A)	Fuse box (G1) (D)
	
Fuse box (G1) (C)	Fuse box (G1) (D)
	

(Cont.d)

<p>Fuse box</p>	<p>(G1) G</p>	<p>Fuse box</p>	<p>(G1) H</p>
 <p>1RED (G1) B</p>		 <p>1LTBLU-WHT (G1) 5</p>	
<p>Fuse box</p>	<p>(G1) I</p>	<p>Fuse box</p>	<p>(G1) L</p>
 <p>1LTBLU-WHT (G1) 4</p>		 <p>C10 PIN 8 (C) 5 B86 PIN 3 3</p> <p>GRY-YEL</p>	
<p>Fuse box</p>	<p>(G1) N</p>	<p>Fuse box</p>	<p>(G1) S</p>
 <p>1.5RED ISO 2 4RED HOT AT ALL TIMES 2 1.5RED (B4) (A) 1 1.5RED ISO 1</p>		 <p>1LTBLU-WHT 5</p>	
<p>Engine compartment right side ground connection</p>	<p>G53a</p>	<p>Engine compartment left side ground connection</p>	<p>G53b</p>
 <p>1BLK (E10)</p>		 <p>1BLK (E10)</p>	
<p>Connector, circuit board to engine compartment right side wiring</p>	<p>G149</p>	<p>Connector, circuit board to engine compartment left side wiring</p>	<p>G150</p>
 <p>1LTBLU-WHT (G1) I</p>		 <p>1LTBLU-WHT (G1) H</p>	
<p>Connector, circuit board to air conditioning wiring</p>	<p>G164</p>	<p>Connector, circuit board to left rear wiring</p>	<p>G171</p>
 <p>YEL-RED (G1) (A) 7 GRY-YEL (G1) (A) 8 GRY-RED (G1) (B) 9</p>		 <p>1LTBLU-WHT (G1) D</p>	

(Cont.d)









<p>Trunk left side ground</p>	<p><b>G185</b></p>	<p>Connector, left rear wiring to rear central lamp wiring</p>	<p><b>G194</b></p>
 <p>1BLK-E26</p>		 <p>1BLK-E26</p> <p>1LTBLU-WHT-E27</p> <p>1LTBLU-WHT-G171</p>	
<p>High beam lamps relay</p>	<p><b>I50</b></p>	<p>Automatic control mode check unit</p>	<p><b>Q21A</b></p>
 <p>1.5RED-G1-N-30</p> <p>1.5RED-G1-N-30</p>		 <p>2 GRY-YEL-G164</p> <p>15 GRY-RED-G164</p> <p>14 YEL-RED-G164</p>	





## BOTH FRONT AND REAR FOG LAMPS INOPERATIVE





## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>MULTIPLE SWITCH CHECK</b>		
- Check for continuity between pins 2A and 2D of multiple switch B4 when the switch is actuated			Carry-out step A2
			Replace multiple switch B4
<b>A2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2A of multiple switch B4 and ground			Carry-out step A4
			Carry-out step A3
<b>A3</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2N of fuse box G1 and ground			Repair wiring between pins 2N, 1N of fuse box and pin 2A of multiple switch B4
			Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>A4</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2B of fuse box G1 and ground when the switch is actuated			Carry-out step A5
			Repair wiring between pin 2B of fuse box G1 and pin 2D of multiple switch B4

(Cont.d)

BOTH FRONT AND REAR FOG LAMPS INOPERATIVE













TEST A

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pins 7B and 3S of fuse box G1		 	Repair wiring between pins 2B and 7B of fuse box G1
		 	Repair or replace wires, as necessary

End of test A

## BOTH FRONT FOG LAMPS INOPERATIVE







## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>F7</b> in fuse box <b>G1</b> for integrity		 	Carry-out <b>step B2</b>
		 	Replace fuse <b>F7</b>
<b>B2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pins 10A and 9A of fuse box <b>G1</b>		 	Replace relay <b>I17</b>
		 	Carry-out <b>step B3</b>
<b>B3</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pins 14 and 2 of automatic control mode check unit <b>Q21A</b>		 	Repair wiring between pin 10A of fuse box <b>G1</b> , pin 7 of connector <b>G164</b> and pin14 of control unit <b>Q21A</b> or between pin 9A of fuse box <b>G1</b> , pin 8 of connector <b>G164</b> and pin2 of control unit
		 	Failure of the air conditioning system; refer to the relevant troubleshooting procedure

End of test B







## LEFT FRONT FOG LAMP INOPERATIVE

## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C1</b>	<b>LAMP CHECK</b>		
	- Check left front fog lamp <b>E10</b> for integrity	 	Carry-out step <b>C2</b>  Replace left front fog lamp <b>E10</b>
<b>C2</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 11 of connector <b>G150</b> and ground	 	Carry-out step <b>C3</b>  Repair wiring between pin 11 of connector <b>G150</b> and pin 6H of fuse box <b>G1</b>
<b>C3</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 1 of left front fog lamp <b>E10</b> and ground	 	Repair wiring between pin 2 of lamp <b>E10</b> and ground point <b>G53b</b>  Repair wiring between pin 1 of lamp <b>E10</b> and pin 11 of connector <b>G150</b>



End of test C

<b>RIGHT FRONT FOG LAMP INOPERATIVE</b>	<b>TEST D</b>
---	---------------

TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>LAMP CHECK</b>		
	- Check right front fog lamp <b>E10</b> for integrity	 ▶  ▶	Carry-out <b>step D2</b>  Replace right front fog lamp <b>E10</b>
<b>D2</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 11 of connector <b>G149</b> and ground	 ▶  ▶	Carry-out <b>step D3</b>  Repair wiring between pin 11 of connector <b>G149</b> and pin 4I of fuse box <b>G1</b>
<b>D3</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 1 of right front fog lamp <b>E10</b> and ground	 ▶  ▶	Repair wiring between pin 2 of lamp <b>E10</b> and ground point <b>G53a</b>  Repair wiring between pin 1 of lamp <b>E10</b> and pin 11 of connector <b>G149</b>

End of test D









FRONT FOG LAMPS WARNING LAMP ON INSTRUMENT PANEL INOPERATIVE	TEST E
--	--------

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Before carrying-out any troubleshooting check the integrity of warning lamp on instrument panel by pressing the test button.</p>		
<b>E1</b> VOLTAGE CHECK	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="text-align: center; margin-right: 10px;">  </div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="text-align: center; margin-right: 10px;">  </div> <div style="font-size: 2em;">▶</div> </div> </div>	<p>Replace instrument panel C10</p> <p>Repair wiring between pin 4B of instrument panel C10 and pin 6C of fuse box G1</p>
<p>- Check for presence of 12V at pin 4B of instrument panel C10</p>		

End of test E

## REAR FOG LAMP INOPERATIVE







TEST F

TEST STEPS		RESULTS	REMEDY
NOTE: The central tail lamps E27 includes two bulbs connected in parallel.			
F1	FUSE CHECK		
- Check fuse F8 in fuse box G1 for integrity		 	Carry-out step F2  Replace fuse F8
F2	WARNING LAMP CHECK		
- Check if the rear fog lamp warning lamp on instrument panel illuminates		 	Carry-out step F3  Carry-out step F6
F3	VOLTAGE CHECK		
- Check for presence of 12V between pins 5 and 1 of connector G194		 	Carry-out step F4  Carry-out step F5
F4	VOLTAGE CHECK		
- Check for presence of 12V between pins 1 and 4 of central tail lamps E27		 	Replace rear fog lamp of central tail lamps E27  Repair wiring between pins 1 and 4 of central tail lamps E27, and pins 5 and 1 of connector G194 respectively

(Cont.d)

## REAR FOG LAMP INOPERATIVE

## TEST F





TEST STEPS		RESULTS	REMEDY
<b>F5</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 12 of connector G171 and ground			Repair wiring between pin 1 of connector G194 and ground point G185 and/or pin 5 of connector G194 and pin 12 of connector G171
			Repair wiring between pin 12 of connector G171 and pin 1D of fuse box G1
<b>F6</b>	<b>RELAY CHECK</b>		
- Check rear fog lamps relay I25 for integrity			Carry-out step F7
			Replace relay I25
<b>F7</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 15 of automatic control mode check unit Q21A			Carry-out step F8
			Failure of the air conditioning system circuit. Refer to the applicable troubleshooting procedure

(Cont.d)




## REAR FOG LAMP INOPERATIVE

## TEST F

TEST STEPS		RESULTS	REMEDY
<b>F8</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 1B of fuse box G1		 ►  ►	Carry-out step F9  Repair wiring between pin 1B of fuse box, pin 9 of connector G164 and pin 15 of control unit Q21A
<b>F9</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 11A of fuse box G1 and ground		 ►  ►	Repair wiring between pin 11A, 12A and 11D of fuse box G1  Repair wiring between pin 11A, 8G and 3B of fuse box


End of test F

**REAR FOG LAMP WARNING LAMP ON INSTRUMENT PANEL INOPERATIVE**
**TEST G**

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Before carrying-out any troubleshooting check the integrity of warning lamp on instrument panel by pressing the test button.</p>		
<b>G1</b> VOLTAGE CHECK		
<ul style="list-style-type: none"> <li>- Check for presence of 12V at pin 5B of instrument panel C10</li> </ul>		<p>Replace instrument panel C10</p> <p>Repair wiring between pin 5B of instrument panel C10 and pin 5C of fuse box G1</p>

End of test G

# FUEL DOOR - - ELECTRIC OPENING



## GENERAL

The fuel filler lid can be electrically opened by means of a switch on the pushbutton panel .

For safety reasons, opening of the fuel filler lid can be actuated only after the start key has been set to off.







The system is protected by two fuses, as follows.

- Free fuse **G4** (7.5A) FILLER LID OPENING.
- **F3** fuse (30A) FILLER LID OPENING (in the auxiliary fuse box **G2**).

## OPERATIONAL DESCRIPTION

The electronic control units power supply relay **I51** is de-energized when the start key is removed. When the relay **I51** is energised the fuel filler lid opening circuit is open.


12V from the battery are applied to fuel filler lid opening relay **I53** through the de-energized relay **I51** and the system free fuse. Pressing the fuel filler lid control switch on the pushbutton panel **B66** connects to ground the remaining terminal of relay **I53**, thus energizing the relay. When the relay **I53** is energized, 12V are applied to solenoid **M13** through the fuse **F3** and the contacts of relay **I53**, thus actuating opening of the fuel filler lid.

Position lights/hazard lights/fuel filler lid pushbutton panel	B66	Multiple switch unit	B68
 <p>1BLK=113</p> <p>1GRN-BLK=G170</p>	 <p>1BLK=G174</p> <p>1BLK=N41</p>		
Fuse box	G1 I	Fuse box	G1 T
 <p>1BRN=HOT IN RUN 2</p> <p>1BRN=151 2</p>	 <p>4RED=HOT AT ALL TIMES</p> <p>2.5RED=G2</p>		
Auxiliary fuse box	G2	Free fuse holder	G4
 <p>2.5RED=G1 T</p> <p>2.5PPL=G170</p>	 <p>1LTBLU-RED=151</p> <p>1LTBLU-RED=G170</p>		


(Cont.d)

<p>Connector, circuit board to engine compartment left side wiring</p>	<p><b>G150</b></p>	<p>Connector, circuit board to right rear wiring</p>	<p><b>G170</b></p>
<p>Steering wheel column support ground</p>	<p><b>G174</b></p>	<p>Trunk right side ground</p>	<p><b>G186</b></p>
<p>Horn relay</p>	<p><b>I13</b></p>	<p>Electronic control units power supply relay</p>	<p><b>151</b></p>

(Cont.d)















<b>FUEL FILLER LID ELECTRIC OPENING INOPERATIVE</b>	<b>TEST A</b>
---	---------------

TEST STEPS	RESULTS	REMEDY				
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%; padding: 5px;"><b>A1</b></td> <td style="padding: 5px;"><b>FUSE CHECK</b></td> </tr> <tr> <td colspan="2" style="padding: 5px;">- Check free fuse <b>G4</b> for integrity</td> </tr> </table>	<b>A1</b>	<b>FUSE CHECK</b>	- Check free fuse <b>G4</b> for integrity		<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div> </div>	<p>Carry-out <b>step A2</b></p> <p>Replace free fuse <b>G4</b></p>
<b>A1</b>	<b>FUSE CHECK</b>					
- Check free fuse <b>G4</b> for integrity						
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%; padding: 5px;"><b>A2</b></td> <td style="padding: 5px;"><b>FUSE CHECK</b></td> </tr> <tr> <td colspan="2" style="padding: 5px;">- Check fuse <b>F3</b> in the auxiliary fuse box <b>G2</b> for continuity</td> </tr> </table>	<b>A2</b>	<b>FUSE CHECK</b>	- Check fuse <b>F3</b> in the auxiliary fuse box <b>G2</b> for continuity		<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div> </div>	<p>Carry-out <b>step A3</b></p> <p>Replace fuse <b>F3</b></p>
<b>A2</b>	<b>FUSE CHECK</b>					
- Check fuse <b>F3</b> in the auxiliary fuse box <b>G2</b> for continuity						
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%; padding: 5px;"><b>A3</b></td> <td style="padding: 5px;"><b>TRUNK OPENING CHECK</b></td> </tr> <tr> <td colspan="2" style="padding: 5px;">- Check that trunk opening can be electrically actuated</td> </tr> </table>	<b>A3</b>	<b>TRUNK OPENING CHECK</b>	- Check that trunk opening can be electrically actuated		<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div> </div>	<p>Carry-out <b>step A5</b></p> <p>Carry-out <b>step A4</b></p>
<b>A3</b>	<b>TRUNK OPENING CHECK</b>					
- Check that trunk opening can be electrically actuated						
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 10%; padding: 5px;"><b>A4</b></td> <td style="padding: 5px;"><b>VOLTAGE CHECK</b></td> </tr> <tr> <td colspan="2" style="padding: 5px;">- Check for presence of 12V between pin of auxiliary fuse box <b>G2</b> (RED wire) and ground</td> </tr> </table>	<b>A4</b>	<b>VOLTAGE CHECK</b>	- Check for presence of 12V between pin of auxiliary fuse box <b>G2</b> (RED wire) and ground		<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div> </div>	<p>Repair wiring between fuse <b>F3</b> in fuse box <b>G2</b>, pin 1 of connector <b>G170</b> and pin 30 of relay <b>I53</b></p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2</p>
<b>A4</b>	<b>VOLTAGE CHECK</b>					
- Check for presence of 12V between pin of auxiliary fuse box <b>G2</b> (RED wire) and ground						

(Cont.d)

## FUEL FILLER LID ELECTRIC OPENING INOPERATIVE

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V at fuse <b>G4</b>		 	Carry-out step <b>A10</b>  Carry-out step <b>A6</b>
<b>A6</b>	<b>RELAY CHECK</b>		
- Check relay <b>I51</b> for integrity and proper operation		 	Carry-out step <b>A7</b>  Replace relay <b>I51</b>
<b>A7</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin <b>86</b> of relay <b>I51</b> and ground		 	Carry-out step <b>A8</b>  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>A8</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin <b>30</b> of relay <b>I51</b> and ground		 	Repair wiring between pin <b>85</b> of <b>I51</b> and ground point <b>G174</b>  Carry-out step <b>A9</b>

(Cont.d)





<b>FUEL FILLER LID ELECTRIC OPENING INOPERATIVE</b>	<b>TEST A</b>
---	---------------

TEST STEPS	RESULTS	REMEDY
<b>A9</b> VOLTAGE CHECK  - Check for presence of 12V between pin 5 of connector G150 and ground	(OK)      ►  <del>(OK)</del> ►	Repair wiring between pin 5 of G150 and pin 30 of relay I51  Failure of the power distribution circuit, refer to the relevant circuit of sheet 1 of 2
<b>A10</b> SOLENOID CHECK  - With the ignition key set to "run" check for presence of 12V at terminals of solenoid M13 when the fuel filler lid control switch is actuated	(OK)      ►  <del>(OK)</del> ►	Replace solenoid M13  Carry-out step A11
<b>A11</b> RELAY CHECK  - Check relay I53 for integrity and proper operation	(OK)      ►  <del>(OK)</del> ►	Carry-out step A12  Replace relay I53

(Cont.d)

## FUEL FILLER LID ELECTRIC OPENING INOPERATIVE

## TEST A


TEST STEPS		RESULTS	REMEDY
<b>A12</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>- With the ignition key set to "run" check for presence of 12V between:               <ul style="list-style-type: none"> <li>• pin 4 of connector <b>G170</b> and ground</li> <li>• pin 86 of relay <b>I53</b> and ground</li> </ul> </li> <li>- With the fuel filler lid pushbutton panel <b>B66</b> actuated, check for presence of 0V (zero) at:               <ul style="list-style-type: none"> <li>• pin 5 of connector <b>G170</b></li> <li>• pins 5 and 6 of position lamps, hazard lamps and fuel filler lid pushbutton panel <b>B66</b></li> </ul> </li> </ul>		<p style="text-align: center;">   </p> <p style="text-align: center;">   </p>	<p>Replace pushbutton panel <b>B66</b></p> <p>Repair or replace wiring, as necessary</p>

End of test A

**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>

# FUSE BOX





## GENERAL

This wiring diagram illustrates the fuse box printed circuit. The fuse box has never been entirely illustrated in the various sections of this manual; therefore refer to this

wiring diagram for a complete view of this component. Enclosed is a table listing all the signals. An adequate knowledge of signals which are expected to be present at pins of the fuse box makes trouble-shooting failures affecting the system easy.

**BASE AND L ONLY**

CONNECTOR A	
1	HAZARD LAMPS RELAY
2	HAZARD LAMPS RELAY
3	HAZARD LAMPS RELAY
4	HAZARD LAMPS RELAY
5	+30 X RELAY
6	+15
7	+ INTERMITTANCE
8	REAR WINDOW DEFOGGING SWITCH
9	POSITION LAMPS
10	FRONT FOG LAMPS SWITCH
11	JUMPER FOR REAR FOG WARN. LAMPS
12	JUMPER FOR REAR FOG WARN. LAMPS

CONNECTOR B	
1	REAR FOG SWITCH
2	JUMPER AT 7 FOR MULTIPLE SWITCH
3	+ REAR FOG
4	SPARE
5	SPARE
6	SPARE
7	JUMPER AT 2
8	CURRENT UNDER REHOST

CONNECTOR C	
1	CURRENT UNDER REHOST
2	POSITION LAMPS WARNING LAMP
3	+ HAZARD LAMPS WARNING LAMP
4	- HAZARD LAMPS WARNING LAMP
5	REAR FOG LAMP WARNING LAMP
6	FRONT FOG LAMPS WARNING LAMP
7	REAR WINDOW WARNING LAMP
8	HEAD LAMPS WARNING LAMP

CONNECTOR D	
1	SPARE
2	SPARE
3	+50
4	+ POSITION LAMP
5	+ POSITION LAMP
6	CHECK FOR STOP LAMPS
7	STOP SWITCH
8	PARKING BRAKE
9	SPARE
10	DOME LAMP DELAYED TIMER
11	REAR FOG LAMP
12	SPARE

CONNECTOR E	
1	+ POSITION LAMPS
2	SPARE
3	DOME LAMPS RELAY ENERGIZED
4	RIGH FRONT WINDOW LIFT
5	- CURRENT UNDER REHOST
6	AIR CONDITIONING RELAY
7	SPARE
8	SPARE
9	SPARE
10	- CURRENT UNDER REHOST
11	PARKING BRAKE WARNING LAMP
12	GROUND

CONNECTOR F	
1	SPARE
2	SPARE

CONNECTOR G	
1	TURN SIGNAL LAMPS
2	HORNS
3	POSITION LAMPS
4	TURN SIGNAL LAMPS
5	TURN SIGNAL LAMPS
6	LOW BEAM LAMPS
7	HIGH BEAM LAMPS
8	REAR FOG LAMPS

CONNECTOR H	
1	REAR BACK-UP SWITCH
2	+15
3	HEAD LAMPS WASHER TIMER
4	LEFT LOW BEAM LAMP
5	LEFT HIGH BEAM LAMP
6	FRONT FOG LAMPS
7	LEFT TURN SIGNAL LAMPS
8	SPARE
9	HORNS
10	POSITION LAMPS

CONNECTOR I	
1	FUEL PUMP
2	FUEL PUMP
3	RIGHT LOW BEAM LAMP
4	FRONT FOG LAMPS
5	INHIBITOR ELECTRIC FAN RELAY
6	SPARE
7	SPARE
8	RIGHT LOW BEAM LAMP
9	SPARE
10	RIGHT TURN SIGNAL LAMP

CONNECTOR L	
1	SPARE
2	SPARE
3	JUMPER AT 5 (+POSITION LAMPS)
4	SPARE
5	JUMPER AT 3 (+POSITION LAMPS)
6	SPARE

CONNECTOR M	
1	SUN ROOF, FRONT HEATED SEATS
2	SPARE

CONNECTOR N	
1	EXTERNAL JUMP
2	+ BATTERY

CONNECTOR O	
1	- DOME LAMPS
2	+30
3	+50
4	+15

CONNECTOR P	
1	- DOME LAMPS
2	+ STOP SWITCH
3	STOP LAMPS
4	LEFT FRONT WINDOW LIFTS
5	CHECK FOR STOP SWITCH
6	REAR CIGAR LIGHTERS
7	ELECTRIC DOOR LOCK/UNLOCK SYSTEM
8	FRONT CIGAR LIGHTERS

**BASE AND L ONLY**

CONNECTOR Q	
1	+15
2	+30
3	GROUND

CONNECTOR R	
1	DEFROSTERS

CONNECTOR S	
1	+ DIMMER SWITCH
2	- DIMMER SWITCH
3	JUMPER AT 5 (+FRONT FOG LAMPS)
4	+15
5	JUMPER AT 3
6	-

CONNECTOR T	
1	+ BATTERY

## LEGEND RELAYS

RELE'	UNDER-FUSE SERVICE
G221	WINDOWS LIFT SHORTING BOX CONNECTOR
I17	FRONT FOG LAMPS RELAY
I25	REAR FOG LAMPS RELAY
I26	DOME LAMP RELAY
N13	HAZARD LAMPS RELAY
I45	EXTERNAL REARVIEW MIRRORS DEFOGGING RELAY
I58	SUN ROOF/SEAT RELAY
I73	DOOR LOCK/FRONT ELECTRIC WINDOW LIFT RELAY

## LEGEND FUSEL

No.	VAL.	UNDER-FUSE SERVICE
1	7,5	RIGHT FRONT AND LEFT REAR POSITION LAMPS LICENSE PLATE, UNDERHOOD
2	7,5	LEFT FRONT AND RIGHT REAR POSITION LAMPS, TRUNK, DOME AND PANEL SWITCH, COURTESY LIGHT
3	10	RIGHT LOW LAMP (RELAY ENERGIZED)
4	10	LEFT LOW LAMP (RELAY ENERGIZED), WARNING LAMP
5	10	RIGHT HIGH LAMP AND WARNING LAMP
6	10	LEFT HIGH LAMP
7	15	FRONT FOG LAMPS AND WARNING LAMP
8	7,5	REAR FOG LAMPS AND WARNING LAMP
9	10	REAR WINDOW, WINDSHIELD, EXTERNAL MIRRORS DEFOGGING, RELAY COIL, WARNING LAMP
10	20	BACK-UP LAMPS, WINDSHIELD WASHER
11	7,5	TURN SIGNAL LAMPS, POSITION LAMPS
12	10	AIR CONDITIONING RELAY
13	10	REAR CIGAR LIGHTERS
14	7,5	ELECTRIC FAN MOTOR RELAY COIL, TEST INSTRUMENT, CRUISE CONTROL
15	15	STOP LAMPS
16	10	ELECTRIC DOOR LOCK/UNLOCK SYSTEM
17	20	HEAD LAMPS WASHER, HAZARD LAMPS
18	30	RIGHT FRONT WINDOW LIFT
19	30	LEFT FRONT WINDOW LIFT
20	30	SPARE
21	15	FRONT DOME LAMP, GLOVEBOX LAMP, FUSE BOX LAMP, FRONT CIGAR LIGHTERS
22	15	MOTOR RELAY POWER
23	20	SUN ROOF, HEAD SEAT
24	25	SPARE

**S ONLY**

CONNECTOR A	
1	HAZARD LAMPS RELAY
2	HAZARD LAMPS RELAY
3	HAZARD LAMPS RELAY
4	HAZARD LAMPS RELAY
5	+30 X RELAY
6	+15
7	+ INTERMITTANCE
8	REAR WINDOW DEFOGGING SWITCH
9	POSITION LAMPS
10	FRONT FOG LAMPS SWITCH
11	JUMPER FOR REAR FOG WARN. LAMPS
12	JUMPER FOR REAR FOG WARN. LAMPS

CONNECTOR B	
1	REAR FOG SWITCH
2	JUMPER AT 7 FOR MULTIPLE SWITCH
3	+ REAR FOG
4	SPARE
5	SPARE
6	SPARE
7	JUMPER AT 2
8	CURRENT UNDER REHOST

CONNECTOR C	
1	CURRENT UNDER REHOST
2	POSITION LAMPS WARNING LAMP
3	+ HAZARD LAMPS WARNING LAMP
4	- HAZARD LAMPS WARNING LAMP
5	REAR FOG LAMP WARNING LAMP
6	FRONT FOG LAMPS WARNING LAMP
7	REAR WINDOW WARNING LAMP
8	HEAD LAMPS WARNING LAMP

CONNECTOR D	
1	SPARE
2	CONTROLLED DAMPING SUSPENSION
3	+50
4	+ POSITION LAMP
5	+ POSITION LAMP
6	CHECK FOR STOP LAMPS
7	STOP SWITCH
8	PARKING BRAKE
9	SPARE
10	DOMELAMP DELAYED TIMER
11	REAR FOG LAMP
12	SPARE

CONNECTOR E	
1	+ POSITION LAMPS
2	SPARE
3	DOMELAMP RELAY ENERGIZED
4	RIGH FRONT WINDOW LIFT
5	- CURRENT UNDER REHOST
6	AIR CONDITIONING RELAY
7	SPARE
8	SPARE
9	SPARE
10	- CURRENT UNDER REHOST
11	PARKING BRAKE WARNING LAMP
12	GROUND

CONNECTOR F	
1	SPARE
2	SPARE

CONNECTOR G	
1	TURN SIGNAL LAMPS
2	HORNS
3	POSITION LAMPS
4	TURN SIGNAL LAMPS
5	TURN SIGNAL LAMPS
6	LOW BEAM LAMPS
7	HIGH BEAM LAMPS
8	REAR FOG LAMPS

CONNECTOR H	
1	REAR BACK-UP SWITCH
2	+15
3	HEAD LAMPS WASHER TIMER
4	LEFT LOW BEAM LAMP
5	LEFT HIGH BEAM LAMP
6	FRONT FOG LAMPS
7	LEFT TURN SIGNAL LAMPS
8	SPARE
9	HORNS
10	POSITION LAMPS

CONNECTOR I	
1	FUEL PUMP
2	FUEL PUMP
3	RIGHT LOW BEAM LAMP
4	FRONT FOG LAMPS
5	INHIBITOR ELECTRIC FAN RELAY
6	SPARE
7	SPARE
8	RIGHT LOW BEAM LAMP
9	SPARE
10	RIGHT TURN SIGNAL LAMP

CONNECTOR L	
1	SPARE
2	SPARE
3	JUMPER AT 5 (+POSITION LAMPS)
4	SPARE
5	JUMPER AT 3 (+POSITION LAMPS)
6	SPARE

CONNECTOR M	
1	SUN ROOF, FRONT HEATED SEATS
2	SPARE

CONNECTOR N	
1	EXTERNAL JUMP
2	+ BATTERY

CONNECTOR O	
1	- DOME LAMPS
2	+30
3	+50
4	+15

CONNECTOR P	
1	- DOME LAMPS
2	+ STOP SWITCH
3	STOP LAMPS
4	LEFT FRONT WINDOW LIFTS
5	CHECK FOR STOP SWITCH
6	REAR CIGAR LIGHTERS
7	ELECTRIC DOOR LOCK/UNLOCK SYSTEM
8	FRONT CIGAR LIGHTERS

**S ONLY**

CONNECTOR Q	
1	+15
2	+30
3	GROUND

CONNECTOR R	
1	DEFROSTERS

CONNECTOR S	
1	+ DIMMER SWITCH
2	- DIMMER SWITCH
3	JUMPER AT 5 (+FRONT FOG LAMPS)
4	+15
5	JUMPER AT 3
6	-

CONNECTOR T	
1	+ BATTERY

## LEGEND RELAYS

RELE*	UNDER-FUSE SERVICE
G221	WINDOWS LIFT SHORTING BOX CONNECTOR
117	FRONT FOG LAMPS RELAY
125	REAR FOG LAMPS RELAY
126	DOMELAMP RELAY
H13	HAZARD LAMPS RELAY
145	EXTERNAL REARVIEW MIRRORS DEFOGGING RELAY
158	SUN ROOF/SEAT RELAY
173	DOOR LOCK/FRONT ELECTRIC WINDOW LIFT RELAY


## LEGEND FUSEL

No.	VAL.	UNDER-FUSE SERVICE
1	7.5	RIGHT FRONT AND LEFT REAR POSITION LAMPS LICENSE PLATE, UNDERHOOD
2	7.5	LEFT FRONT AND RIGHT REAR POSITION LAMPS, TRUNK, DOME AND PANEL SWITCH, COURTESY LIGHT
3	10	RIGHT LOW LAMP (RELAY ENERGIZED)
4	10	LEFT LOW LAMP (RELAY ENERGIZED), WARNING LAMP
5	10	RIGHT HIGH LAMP AND WARNING LAMP
6	10	LEFT HIGH LAMP
7	15	FRONT FOG LAMPS AND WARNING LAMP
8	7.5	REAR FOG LAMPS AND WARNING LAMP
9	10	REAR WINDOW, WINDSHIELD, EXTERNAL MIRRORS DEFOGGING, RELAY COIL, WARNING LAMP
10	20	BACK-UP LAMPS, WINDSHIELD WASHER
11	7.5	TURN SIGNAL LAMPS, POSITION LAMPS
12	10	AIR CONDITIONING RELAY
13	10	REAR CIGAR LIGHTERS
14	7.5	ELECTRIC FAN MOTOR RELAY COIL, TEST INSTRUMENT, CRUISE CONTROL, CONTROLLED DAMPING SUSPENSION
15	15	STOP LAMPS
16	10	ELECTRIC DOOR LOCK/UNLOCK SYSTEM
17	20	HEAD LAMPS WASHER, HAZARD LAMPS
18	30	RIGHT FRONT WINDOW LIFT
19	30	LEFT FRONT WINDOW LIFT
20	30	SPARE
21	15	FRONT DOME LAMP, GLOVEBOX LAMP, FUSE BOX LAMP, FRONT CIGAR LIGHTERS
22	15	MOTOR RELAY POWER
23	20	SUN ROOF, HEAD SEAT
24	25	SPARE

**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>

# GROUNDS





## GENERAL


The ground point G53 on the right side of engine compartment allows to ground the following circuits by means of a direct mechanical connection to the vehicle's frame:

- Automatic air conditioning.

- Controlled damping suspension (only).

### NOTE

An adequate knowledge of all the circuits grounded by the same ground point facilitates the troubleshooting when a failure affects all the above mentioned circuits simultaneously.



## GENERAL


The ground point **G53a**, on the right side of engine compartment, allows to ground the following circuits by means of a direct mechanical connection to the vehicle's frame:

- Position and side marker lamps.
- Low-High beam lamps.
- Turn signal lamps.

- Fog head lamps.
- Windshield/head lamps washer.
- Windshield washer fluid level.

### NOTE

An adequate knowledge of all the circuits grounded by the same ground point facilitates the troubleshooting when a failure affects all the above mentioned circuits simultaneously.



## GENERAL



The ground point G53b, on the left side of engine compartment, allows to ground the following circuits by means of a direct mechanical connection to the vehicle's frame:

- Position and side marker lamps.
- Low-High beam lamps.
- Turn signal lamps.
- Fog head lamps.

- Alfa Romeo Control unit power circuit.
- Engine cooling.
- Automatic transmission oil cooling (BASE and L only).
- ABS brake system.



### NOTE

An adequate knowledge of all the circuits grounded by the same ground point facilitates the troubleshooting when a failure affects all the above mentioned circuits simultaneously.



## GENERAL

The ground point **G131** is located on the upper cover and allows the Motronic ML4.1 ignition/injection circuits to be grounded.





**GENERAL**

The ground point **G143**, in the center utilities well, allows to ground the following circuits by means of a direct mechanical connection to the vehicle's frame:

- Stop lamps.
- Windshield wiper.
- Instrument panel.
- Engine coolant level.

- Brake fluid level.
- Automatic air conditioning.
- Anti-theft.

Furthermore, the ground point **G143** is connected to ground point **G174** on the steering wheel column.

**NOTE**

An adequate knowledge of all the circuits grounded by the same ground point facilitates the troubleshooting when a failure affects all the relevant circuits simultaneously.



## GENERAL

The ground point **G174**, on the steering wheel column, allows to ground the following circuits by means of a direct mechanical connection to the vehicle's frame:

- Electronic control units power relay.
- Fuse box.
- Starting inhibitor (automatic transmission only) (BASE and L only).
- Cruise control.
- High beam lamps.
- Turn signal lamps.
- Stop lamps.
- Gearshift selector (automatic transmission only) (BASE and L only).
- Windshield wiper.
- Instrument panel.

- Door open warning lamps.
- Safety belts not fastened.
- Electric window lift system.
- Electrically adjustable external rearview mirrors.
- Electric door lock/unlock system.
- Cigar lighters.
- Radio.
- Horns.
- Position/license plate/side marker.
- Fuel filler lid opening.

Furthermore, the ground point **G174** is connected to ground point **G143** of the center utilities well.

### NOTE


An adequate knowledge of all the circuits grounded by the same ground point facilitates the troubleshooting when a failure affects all the relevant circuits simultaneously.

MISCELLANEOUS DOME LAMPS  
SUN ROOF CIRCUIT  
(F35 PIN 2)



## GENERAL

The ground point **G176** is located on the roof panels, and allows to ground the sun roof circuit by means of a direct mechanical connection to the vehicle's frame.



**GENERAL**


The ground point G182, in the center console area, allows to ground the following circuits by means of a direct mechanical connection to the vehicle's frame:

- Parking brake.
- Electric window lift system.
- Electric door lock/unlock system.
- Adjustable seats.

- Heated seats.
- Cigar lighters.
- Radio.

**NOTE**

An adequate knowledge of all the circuits grounded by the same ground point facilitates the troubleshooting when a failure affects all the relevant circuits simultaneously.





**GENERAL**

The ground point G185, on the left side of trunk, allows to ground the following circuits by means of a direct mechanical connection to the vehicle's frame:

- Position/license plate/side marker lamps.
- Turn signal lamps.
- Rear fog lamps.
- Stop lamps.
- Miscellaneous dome lamps.

- Door open warning lamps.
- Windshield and rear window defogging system.
- Adjustable seats.
- Heated seats.
- Rear back-up lamps.

**NOTE**

An adequate knowledge of all the circuits grounded by the same ground point facilitates the troubleshooting when a failure affects all the above mentioned circuits simultaneously.




## GENERAL

The ground point **G186**, on the right side of trunk, allows to ground the following circuits by means of a direct mechanical connection to the vehicle's frame:

- Motronic ML4.1 ignition/injection (fuel pump P18).
- Position/side marker lamps.
- Turn signal lamps.
- Miscellaneous dome lamps.
- Instrument panel (fuel quantity transmitter L9).
- Door open warning lamps.
- Rear window defogging system.
- Trunk opening.
- Fuel filler lid opening.
- Anti-theft.
- Radio Telephone.
- Controlled damping suspension (S only).







### NOTE

An adequate knowledge of all the circuits grounded by the same ground point facilitates the troubleshooting when a failure affects all the above mentioned circuits simultaneously.




## GENERAL

The ground point G202 is located on the L.H. fender in the engine compartment and allows ABS brake system circuit to be grounded.

<p>Engine compartment ground connection</p>	<p><b>G53</b></p>	<p>Engine compartment ground connection</p>	<p><b>G53</b></p>
<p><b>BASE AND L ONLY</b></p>  <p>2.5BLK* Q11</p>		<p><b>S ONLY</b></p>  <p>1BLK* M46 2.5BLK* Q11 1BLK* L41</p>	
<p>Engine compartment right side ground connection</p>	<p><b>G53a</b></p>	<p>Engine compartment left side ground connection</p>	<p><b>G53b</b></p>
 <p>1BLK* I19 1BLK* M49 2.5BLK* P20</p> <p>1BLK* E10</p> <p>1.5BLK* E23</p>		 <p>LTBLU-YEL* G150 2.5BLK* I1 1.5BLK* P34 1BLK* E10</p> <p>1.5BLK* E24 1BLK* M48 1BLK* L8</p> <p>1.5BLK* N28 4BLK* N28</p>	
<p>Upper cover ground connection</p>	<p><b>G131</b></p>	<p>Central bulkhead ground</p>	<p><b>G143</b></p>
 <p>1BLK* S25 1BLK* S11 1.5BLK* S11 1BLK* S8 1BLK* S7</p> <p>1BLK* S36 2.5BLK* S11 2.5BLK* S11 1BLK* S12b</p>		 <p>1BLK* M89 2.5GRY-BLK* G174 1.5BLK* P27</p> <p>1BLK* Q20 1BLK* L14 1.5BLK* G150 4BLK* Q31 1BLK* Q15</p>	


(Cont.d)

<p>Steering wheel column support ground</p>	<p><b>G174</b></p>	<p>Dome ground</p>	<p><b>G176</b></p>
<p>1BLK* B1 1BLK* B1 1BLK* B1 1BLK* B1</p> <p>1BLK* B88</p> <p>LTBLU-RED* C10</p> <p>2.5GRY-BLK* G143</p> <p>1.5BLK* N11</p> <p>1BLK* G166</p> <p>1BLK* G1</p> <p>1BLK* G168</p>		<p>1BLK* F35</p>	
<p>Trunk left side ground</p>		<p>Center console ground</p>	
<p>1BLK* G181 1BLK* Q25 BLK* F37 1BLK* I2 1.5BLK* I56</p> <p>2.5BLK* G190 1BLK* E12 1BLK* G194</p>		<p>BLK* B25 BLK* B20 1BLK* O7 1.5BLK* G183 1.5BLK* G184 2.5BLK* G100</p> <p>2.5GRY-BLK* B23 2.5GRY-BLK* B24 1BLK* G191 1BLK* G191 1.5BLK* G183</p> <p>1.5BLK* B21 BLK* H1 1.5BLK* G184 1BLK* G197 1BLK* G197</p>	
<p>Trunk right side ground</p>		<p>Trunk right side ground</p>	
<p><b>S ONLY</b></p> <p>1BLK* N46 1BLK* N46 1BLK* G197 BLK* L8 BLK* E12 BLK* E25 1.5BLK* P18 1PPL-BLK* N46</p> <p>1BLK* N46 BLK* F36 2.5BLK* G198 4BLK* O1 2.5BLK* M13 1BLK* N45 1BLK* O11 1BLK* N46</p>		<p><b>BASE AND L ONLY</b></p> <p>1BLK* N46 1BLK* G197 BLK* L8 BLK* E12 BLK* E25 1.5BLK* P18</p> <p>BLK* F36 2.5BLK* G198 4BLK* O1 2.5BLK* M13 1BLK* N45 1BLK* O11</p>	
<p>Trunk right side ground</p>		<p>ABS system ground connection</p>	
<p>1.5BLK* N27 1.5BLK* N27 1.5BLK* N27 1BLK* I57</p>		<p>1.5BLK* N27 1.5BLK* N27 1.5BLK* N27 1BLK* I57</p>	





INSTRUMENT PANEL - - ALFA  
ROMEO CONTROL ECU  
INTERFACE



## GENERAL

The Alfa Romeo Control unit is provided with two power supply lines: one line is directly powered by the battery, and the second line is powered when the ignition key is set to "run" position.

The first power supply line is protected by the fuse F1 (10A) DIRECT CURRENT FOR ELECTRONIC CIRCUIT while the second line is protected by the fuse F2 (7.5A) KEY - CONTROLLED CURRENTS FOR ELECTRONICS CIRCUIT.

The Alfa Romeo Control unit also acts as an interface unit between the instrument panel and some circuits of the vehicle for the illumination of the relevant warning lamps.

## OPERATIONAL DESCRIPTION

The battery power (12V) is applied to pin 1A of the Alfa Romeo Control unit N22; this line is protected by the fuse F1.

With the ignition key set to "run", the electronic control units power supply relay I51 applies the electronics monitored power supply to pin 2A of the control unit N22; this line is protected by the fuse F2.


The control unit N22 (pins 3E, 7E, 5E, 8E, 1E and 6F) provides the input signals for the illumination of the following warning lamps through the connection with the instrument panel C10:


- Serigraphs of switches and controls of the vehicle.
- Left rear door open.
- Left front door open.

- Right rear door open.
- Right front door open.
- Parking brake engaged.
- Seat belt unfastened.
- Brake pad wear.
- Defective stop lamps.
- Engine coolant maximum temperature.
- Brake fluid level.
- Engine oil level.
- Engine coolant level.
- Utilities fluid level.
- Engine oil minimum pressure.
- Automatic gear oil maximum temperature (automatic transmission only).













Furthermore, the control unit N22 supplies the instrument panel C10 with input signals for the engine tachometer, and performs the test of the warning lamps under its control.

For further information relevant to the correct operation, of the above mentioned warning lamps refer to the specific chapter of the affected circuit.





**WARNING LAMPS MANAGED BY CONTROL UNIT N22 FAIL TO ILLUMI-  
NATE ON INSTRUMENT****TEST A**

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Before attempting any troubleshooting, ascertain the integrity of the warning lamp on instrument panel by pressing the test button: replace the affected lamp if it does not illuminate.</p>			
<b>A1</b>	<b>FUSE CHECK</b>		
- Check fuse F1 in auxiliary fuse box G2 for integrity		 	Carry-out step A2
		 	Replace fuse F1
<b>A2</b>	<b>FUSE CHECK</b>		
- Check fuse F2 in auxiliary fuse box G2 for integrity		 	Carry-out step A3
		 	Replace fuse F2
<b>A3</b>	<b>WARNING LAMP ILLUMINATION CHECK</b>		
- Set the ignition key to "run" and check that the remaining warning lamps illuminate on the instrument panel		 	Carry-out step A4
		 	Carry-out step A9

(Cont.d)







WARNING LAMPS MANAGED BY CONTROL UNIT N22 FAIL TO ILLUMI- NATE ON INSTRUMENT	<b>TEST A</b>
---	---------------

TEST STEPS		RESULTS	REMEDY
<b>A4</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between fuse F1 in auxiliary fuse box G2 (RED-BLK wire) and ground		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step A5
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step A5
<b>A5</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 30 of electronic control units power supply relay I51 and ground		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between pin 30 of relay I51 and auxiliary fuse box G2 (RED-BLK wire)
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step A5
<b>A6</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 5 of connector G150 and ground		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between pin 30 of relay I51 and pin 5 of connector G150
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Failure of the power distribution circuit, refer to the relevant circuit of sheet 1 of 2

(Cont.d)

WARNING LAMPS MANAGED BY CONTROL UNIT N22 FAIL TO ILLUMI-  
NATE ON INSTRUMENT

## TEST A







TEST STEPS		RESULTS	REMEDY
<b>A7</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 12V between pin 1A of Alfa Romeo Control unit N22 and ground</li> </ul>		 ►  ►	Carry-out step A8  Repair wiring between pin 1A of control unit N22 and auxiliary fuse box G2 (RED-BLK wire)
<b>A8</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for continuity between pins:               <ul style="list-style-type: none"> <li>• 3E of control unit N22 and 8D of instrument panel C10</li> <li>• 7E of control unit N22 and 9D of instrument panel C10</li> <li>• 5E of control unit N22 and 10D of instrument panel C10</li> <li>• 8E of control unit N22 and 11D of instrument panel C10</li> <li>• 1E and 6F of control unit N22 and 12D of instrument panel C10</li> </ul> </li> </ul>		 ►  ►	Replace control unit N22 and/or instrument panel C10  Repair or replace wires, as necessary
<b>A9</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 12V between pin 2A of control unit N22 and ground</li> </ul>		 ►  ►	Failure of the instrument panel circuit; refer to the applicable troubleshooting procedure  Carry-out step A10

(Cont.d)



WARNING LAMPS MANAGED BY CONTROL UNIT N22 FAIL TO ILLUMI-  
NATE ON INSTRUMENT



## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A10</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between fuse F2 in auxiliary fuse box G2 (PNK wire) and ground		 ►	Repair wiring between pin 2A of control unit N22 and auxiliary fuse box G2 (PNK-BLK and PNK wires)
		 ►	Carry-out step A11
<b>A11</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin 87 of relay I51 and ground		 ►	Repair wiring between pin 87 of relay I51 and auxiliary fuse box G2 (PNK wire)
		 ►	Carry-out step A12
<b>A12</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin 86 of relay I51 and ground		 ►	Carry-out step A13
		 ►	Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2

(Cont.d)


WARNING LAMPS MANAGED BY CONTROL UNIT N22 FAIL TO ILLUMI-  
NATE ON INSTRUMENT

**TEST A**

TEST STEPS		RESULTS	REMEDY
<b>A13</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 85 of relay I51		 	<p>Replace relay I51</p> <p>Repair wiring between pin 85 of relay I51 and ground point G174</p>

End of test A

# INSTRUMENT PANEL - - INDICATOR CIRCUITS



## GENERAL

## NOTE

- Due to its dimensions the instrument panel layout has been subdivided into 6 diagrams, with the relevant description attached.
- The troubleshooting described at the end of the subject only concerns those circuit components which have not been already taken into consideration in other subjects. Example:  
"Low beam lamps inoperative" has not been dealt with, as already part of the subject "Low beam/High beam lamps".

The instrument panel displays all the ordinary information relevant to the status of indicators and of some of the sensors installed on the car.

Furthermore, the interface with the Alfa Romeo Control unit provides a means of monitoring the status of the sensors connected to the car warnings.

Where necessary, the power supply circuit of the instrument panel indicators has been protected by suitable fuses.

The instrument panel is energized when the ignition key is set to "run"; this circuit is protected by the F2 fuse (7.5A) in the fuse box G2.

## OPERATIONAL DESCRIPTION - INSTRUMENT PANEL POWER SUPPLY

12V from the battery are applied to the electronic control units power supply relay I51.

Energization of relay I51 supplies 12V power directly to the Air Bag diagnosis circuit and, through the fuse F2 in the auxiliary fuse box G2, to pins 1D and 6C of the instrument panel C10. This voltage is used as common power supply for a group of indicators.

12V through fuse F2 is also supplied to:


- Alfa Romeo Control unit, for the monitoring of the warning systems.
- Relay I36 for the brake fluid tank.
- Automatic air conditioning system.

The wiring diagram also shows the various ground points of the instrument panel.

Ground point G174 is connected to pin 3A of the instrument panel, and is used as ground reference for the voltmeter used to display the battery charging.

Ground point G143 is connected to pins 7B and 5C of the instrument panel, and is used as common ground point for a group of indicators.

As detailed above, the indicators and warnings are activated by the energizing the relevant circuit.



## OPERATIONAL DESCRIPTION - POSITION, LOW BEAM AND HIGH BEAM LAMPS INDICATORS

The wiring diagram shows the functional flow of the power supply lines for the position, low beam and high beam lamp indicators.

### Position Lamps

When the parking lamps switch is actuated, pin 3G of fuse box G1 is energized.

12V are applied to pins 8C and 2C of the instrument panel through fuses F1 and F2; this will cause illumination of the position lamps indicator and of the instrument panel lighting.

Lighting intensity can be dimmed by means of a rheostat;

the power supply line from the rheostat is connected to pin 1C of the instrument panel.

### Low Beam Head lamps


When the low beam head lamps switch is actuated, pin 6G of fuse box G1 is energized.

12V are applied to low beam headlamps circuit and to pin 9C of the instrument panel through fuse F4; this will cause illumination of the relevant indicator.

### High Beam Head lamps

When the high beam head lamps switch is actuated, pin 7G of fuse box G1 is energized.

12V are applied to pin 2A of the instrument panel through fuse F5; this will cause illumination of the relevant indicator.





## OPERATIONAL DESCRIPTION - TURN SIGNAL/HAZARD WARNING LAMPS, AIR BAG, ENGINE TA- CHOMETER AND ALFA ROMEO CONTROL UNIT INDICATORS

The schematic diagram shows the functional path of the control lines for the tachometer, for the illumination of the instrument panel indicator lights relevant to the direction/emergency lamps, for the Air Bag circuit and for the vehicle sensors and alarms monitored by the Alfa Romeo Control unit.

### Engine Tachometer

The engine tachometer input signals are derived from the Motronic control unit and directed to pin 5D of the instrument panel, and then to the tachometer through an interface unit.

The frequency of signal applied to pin 5D is function of the engine R.P.M. detected by the Motronic control unit, and this provides indication of the engine R.P.M. on the tachometer.

### Turn Signal/Hazard Warning Lamps Indicator

Actuation of the turn signal lamps control lever applies an intermittent 12V signal to pins 6A or 7A, as determined by the selection of the control switch (left turn or right turn); this will cause flickering of the relevant indicator on the instrument panel.

Actuation of the hazard warning lamps switch applies an intermittent 12V signal at pin 3D of the instrument panel, which is then supplied to pin 2D; this will cause flickering of the relevant indicator on the instrument panel.

### Air Bag Indicator

Proper function of the Air Bag system is continuously monitored by the relevant control unit R22, during both the starting phase and during the run.

During the starting phase, the air bag control unit connects to ground pin 4D of the instrument panel for a few seconds, causing illumination of the air bag indicator on the instrument panel; after this period, the control unit disables the indicator.

During the run phase, in the event of any malfunction of

the system, the air bag control unit will cause flickering of the air bag indicator on the instrument panel at a determined error code.


For further details refer to the relevant troubleshooting procedure.

### Alfa Romeo Control Unit Indicators

The Alfa Romeo Control unit monitors the primary parameters relevant to several circuits and utilities of the car. The control unit interfaces with pins 8D 12D of the instrument panel through the CLOCK, DATA and LOAD signals and their ground reference. These signals are decoded by an interface unit located inside the instrument panel, and monitor the illumination of the corresponding indicators.

The functions monitored by the Alfa Romeo Control unit, and displayed by an indicator lamp, are as follows:

- Door open (L.H., R.H. front and rear doors), and relevant ideograph.
- Parking brake on.
- Safety belts unfastened.
- Brake pads wear.
- Failed stop lamps.
- Coolant maximum temperature.
- Automatic transmission oil maximum temperature.
- Minimum oil pressure.
- Brake fluid level.
- Engine oil level.
- Cooling system fluid level.
- Windshield washer fluid level.



## OPERATIONAL DESCRIPTION - REAR WINDOW DEFOGGER, A.C. GENERATOR AND CHECK ENGINE INDICATORS

The wiring diagram shows the functional flow of pilot lines of the rear window defogger, alternator and engine diagnosis indicators on the instrument panel.

### Rear Window Defogger

When the rear window defogger is actuated (either manually or automatically by the air conditioning system), 12V are applied to pin 6B of the instrument panel through the contacts of relay I45 and fuse F9 in the fuse box G1; this will cause illumination of the rear window defogger indicator on the instrument panel.

### Alternator

With the ignition key set to "run" position, the alternator A2

connects to ground pin 7C of the instrument panel; this will cause illumination of the corresponding indicator.

During car traveling, the alternator charges the battery, and the indicator is turned off.

Illumination of the indicator when travelling indicates a failure to the battery charge circuit.


### Check Engine

The Motronic control unit S11 is provided with a self-diagnostic system.

In the event of a system malfunction, the control unit S11 provides, at the operator's command, flickering of the CHECK ENGINE indicator lamp on the instrument panel. Reading of the flickering error code allows quick troubleshooting of the failed system.

For further details refer to the relevant troubleshooting procedure.

**BASE AND L ONLY**



## OPERATIONAL DESCRIPTION - A.B.S. INDICATOR, OIL PRESSURE INDICATOR, SPEEDOMETER SEN- SOR AND ODOMETER RESET SWITCH

### A.B.S. System Indicator

The A.B.S. control unit N27 includes a self- diagnostic system which controls illumination of the ABS indicator on the instrument panel when the ignition key is set to "run".

During normal system operation the control units disables the indicator lamps a few seconds after the engine starts.

In the event of failure of the A.B.S. system, the control unit holds the A.B.S. indicator lamp on after the engine starts,

or turns it on during travel.


### Engine Oil Pressure

The engine oil pressure is continuously displayed by an analog gauge on the instrument panel. The engine oil pressure transmitter L8, located on the engine block, senses the oil pressure and supplies a proportional electric signal to pin 5A of the instrument panel.

### Speedometer Sensor

The car speed and mileage covered during travel are detected by the sensor L17 connected to the gear box. The sensor supplies an electric signal to both the speedometer and odometer through a specific interface unit. Resetting of the trip odometer is obtained electrically by means of the resetting switch B40. Pressing on the switch B40 connects the ground point G174 to pin 8A through the fuse box G1, thus resetting the trip odometer.

**S ONLY**



## OPERATIONAL DESCRIPTION - A.B.S. INDICATOR, OIL PRESSURE INDICATOR, SPEEDOMETER SEN- SOR AND ODOMETER RESET SWITCH

### A.B.S. System Indicator

The A.B.S. control unit N27 includes a self- diagnosis system which controls illumination of the ABS indicator on the instrument panel when the ignition key is set to "run".

During normal system operation the control units disables the indicator lamps a few seconds after engine starting.

In the event of failure of the A.B.S. system, the control unit holds the A.B.S.indicator lamp on after the engine starting, or turns it on during travel.

### Engine Oil Pressure

The engine oil pressure is continuously displayed by an

analogue indicator on the instrument panel. The engine oil pressure transmitter L8, located on the engine case, senses the oil pressure and supplies a proportional electric signal to pin 5A of the instrument panel.


### Speedometer Sensor

The car speed and mileage covered during travel are detected by the sensor L17 connected to the gear box. The sensor L17 supplies an electric original to both the speedometer and odometer through a specific interface unit.

The speedometer signal, outcoming from dash board pin 1A, is used by the following circuits:

- Controlled damping suspension
- Automatic air conditioning
- Cruise control

Resetting of trip odometer is obtained electrically by means of the resetting switch B40. Pressure on the switch B40 connects the ground point G174 to pin 8A through the fuse box G1, thus resetting the trip odometer.





## OPERATIONAL DESCRIPTION - FOG HEAD LAMPS, REAR FOG LAMPS, FUEL LEVEL AND ENGINE COOLANT TEMPERATURE INDICATORS

### Front Fog Lamps Indicator

Positioning the fog lamps switch to on, the relay I17 energizes connecting, thru fuse F7 on the fuse box G1, 12V to pin 4B of the instrument panel. Inside the instrument panel the 12V provides for illumination of the relevant indicator lamp.

### Rear Fog Lamps Indicator

When the rear fog lamps control switch is actuated 12V are applied to pin 5B of the instrument panel through the fuse F8 in the fuse box G1; this will cause illumination of the corresponding indicator lamp on the instrument panel.

### Fuel Level Gauge

The fuel level is continuously displayed by an analogue indicator on the instrument panel.


The fuel quantity transmitter L9 located inside the fuel tank senses the fuel level and transmits a proportional electric signal to pin 2B of the instrument panel.

The low fuel indicator lamp illuminates when remaining fuel in the tank is about 9.2l. (2.43 gals). Illumination of the indicator lamp is controlled by the closure of contacts of transmitter L9 (pin 3B of the instrument panel).


### Engine Coolant Temperature Gauge

The temperature of the engine coolant is continuously displayed by an analog gauge on the instrument panel.


The coolant temperature is sensed by the sender L10, which transmits a proportional electric signal to pin 1B of the instrument panel.














(Cont.d)





(Cont.d)




(Cont.d)







<p>Steering wheel column support ground</p> <p><b>G174</b></p> 		<p>Trunk right side ground</p> <p><b>G186</b></p> 
<p>Electronic control units power supply relay</p> <p><b>I51</b></p> 		<p>Engine oil pressure transmitter</p> <p><b>L8</b></p> 
<p>Fuel quantity transmitter</p> <p><b>L9</b></p> 		<p>Engine coolant temperature bulb and high temperature switch</p> <p><b>L10</b></p> 
<p>Engine oil level sensor</p> <p><b>L12</b></p> 		<p>Speedometer sensor</p> <p><b>L17</b></p> 
<p>Alfa Romeo control unit</p> <p><b>N22 E</b></p> 		<p>Alfa Romeo control unit</p> <p><b>N22 F</b></p> 
<p></p>		<p>Air bag control unit</p> <p><b>R22</b></p> 

(Cont.d)

«Blinking code» diagnosis connector	I2	Air bag test connector	I3
 <p>A diagram of a multi-pin diagnosis connector. A dashed line points to the first pin labeled "S11 PIN 17". A solid line points to the second pin labeled "1LTBLU-RED". To the right, there are two boxes: a circle containing "C10" and a square containing "C".</p>	 <p>A diagram of an air bag test connector. A solid line points to the first pin labeled "1PNK". To the right, there are two boxes: a circle containing "G2" and a square containing "D".</p>		









<b>ALL INDICATOR LAMPS INOPERATIVE</b>	<b>TEST A</b>
--	---------------

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Before carrying out troubleshooting procedure, check warning lamps for integrity on the dash-board by pressing test push-button.</p>		
<b>A1</b> FUSE CHECK		
- Check fuse <b>F2</b> in auxiliary fuse box <b>G2</b> for integrity	 ▶  ▶	Carry-out step <b>A2</b>  Replace fuse <b>F2</b>
<b>A2</b> VOLTAGE CHECK		
- With the ignition key set to "run" or "start" check for presence of 12V between fuse <b>F2</b> in the auxiliary fuse box <b>G2</b> and ground	 ▶  ▶	Carry-out step <b>A3</b>  Carry-out step <b>A5</b>
<b>A3</b> VOLTAGE CHECK		
- With the ignition key set to "run" or "start" check for presence of 12V between pins <b>6C</b> and <b>1D</b> of instrument panel and ground	 ▶  ▶	Carry-out step <b>A4</b>  Repair wiring between fuse <b>F2</b> of auxiliary fuse box <b>G2</b> and pins <b>6C</b> and <b>1D</b> of instrument panel

(Cont.d)



ALL INDICATOR LAMPS INOPERATIVE	<b>TEST A</b>
---------------------------------	---------------

TEST STEPS		RESULTS	REMEDY
<b>A4</b>	<b>GROUNDING CHECK</b>		
	- Check that pins 3A, 7B and 5C of instrument panel are connected to ground	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around; align-items: center; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p>Replace instrument panel C10</p> <p>Repair wiring between ground points G143 pin 4 of connector G150 and pin 7B, 5C and between ground point G174 and pin 3A of instrument panel</p>
<b>A5</b>	<b>RELAY CHECK</b>		
	- Check electronic control units power supply relay I51 for proper operation	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around; align-items: center; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p>Carry-out step A6</p> <p>Replace relay I51</p>
<b>A6</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 5 of connector G150 and ground	<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around; align-items: center; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p>Carry-out step A7</p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 1 of 2</p>

(Cont.d)





ALL INDICATOR LAMPS INOPERATIVE	<b>TEST A</b>
---------------------------------	---------------

TEST STEPS		RESULTS	REMEDY
<b>A7</b>	VOLTAGE CHECK		
	- Check for presence of 12V between pin 30 of relay I51 and ground	<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="font-size: 24px; margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 24px; margin-right: 10px;">▶</div> </div>	<p>Carry-out <b>step A8</b></p> <p>Repair wiring between pin 30 of relay I51 and pin 5 of G150</p>
<b>A8</b>	VOLTAGE CHECK		
	- With the ignition key set to "run" or "start" check for presence of 12V between pin 86 of relay I51 and ground	<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="font-size: 24px; margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 24px; margin-right: 10px;">▶</div> </div>	<p>Repair wiring between pin 85 of I51 and ground point G174</p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2</p>

End of test A

## SPEEDOMETER INOPERATIVE (BASE and L only)

## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>SENSOR CHECK</b>		
<ul style="list-style-type: none"> <li>- Check that sensor L17 is operational as follows:               <ul style="list-style-type: none"> <li>• apply + 12V to pin 3 of sensor L17 (PNK-BLK wire) and connect to ground the sensor case</li> <li>• insert shaft of an electric motor into sensor L17, then drive sensor L17 to various speeds</li> <li>• check pin 2 of sensor L17 (GRY wire) for presence of a signal with frequency variable in conjunction with drive motor RPM changes</li> </ul> </li> </ul>		 	<p>Carry-out step B2</p> <p>Replace sensor L17</p>
<b>B2</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of continuity between:               <ul style="list-style-type: none"> <li>• pin 2 of sensor L17 and pin 18 at connector G151 (GRY wire)</li> <li>• pin 18 of connector G151 and pin 4C of instrument panel C10</li> <li>• pin 3 of sensor L17 and 14 of connector G151 (PNK-BLK wire)</li> <li>• pin 14 of connector G151 and pin 3C of instrument panel C10</li> </ul> </li> </ul>		 	<p>Replace instrument panel C10</p> <p>Repair or replace wires, as necessary</p>



End of test B

<b>SPEEDOMETER INOPERATIVE (S only)</b>	<b>TEST B</b>
---	---------------

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>SENSOR SUPPLY CHECK</b>		
	<ul style="list-style-type: none"> <li>- With ignition key set to "run", check for presence of 12V at pin 3C of instrument panel C10</li> </ul>	<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center; width: 30px; height: 30px; margin-right: 10px;">OK</div> <div style="margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center; width: 30px; height: 30px; margin-right: 10px;"><del>OK</del></div> <div style="margin-right: 10px;">▶</div> </div>	<p>Carry-out step B2</p> <p>Check Instrument panel C10 supply by carrying out TEST A</p>
<b>B2</b>	<b>SENSOR SUPPLY CHECK</b>		
	<ul style="list-style-type: none"> <li>- With ignition key set to "run", check for presence of 12V at pin 3 of sensor L17</li> </ul>	<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center; width: 30px; height: 30px; margin-right: 10px;">OK</div> <div style="margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center; width: 30px; height: 30px; margin-right: 10px;"><del>OK</del></div> <div style="margin-right: 10px;">▶</div> </div>	<p>Carry-out step B3</p> <p>Restore wiring between pin 3 of sensor L17, pin 14 of connector G151, and pin 3C of Instrument panel C10</p>
<b>B3</b>	<b>SPEEDOMETER SIGNAL CHECK</b>		
	<ul style="list-style-type: none"> <li>- Place the vehicle on a lift platform so that the front wheels turn freely.</li> <li>- Start the engine and engage 1st speed. Have engine running at about 2000 rpm.</li> <li>- Check for approx 5V at pin 4C of instrument panel C10</li> </ul>	<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center; width: 30px; height: 30px; margin-right: 10px;">OK</div> <div style="margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center; width: 30px; height: 30px; margin-right: 10px;"><del>OK</del></div> <div style="margin-right: 10px;">▶</div> </div>	<p>Replace Instrument panel C10</p> <p>Carry-out step B4</p>

(Cont.d)

SPEEDOMETER INOPERATIVE (S only)	<b>TEST B</b>
----------------------------------	---------------

TEST STEPS		RESULTS	REMEDY
<b>B4</b>	SPEEDOMETER SIGNAL CHECK		
	<ul style="list-style-type: none"> <li>In the same condition as in step B3, check for presence of approx 5V at pin 2 of sensor L17</li> </ul>	  	<p>Restore wiring among pin 2 of sensor L17, pin 18 of connector G151 and pin 4C of Instrument panel C10</p> <p>Replace sensor L17</p>

End of test B

<b>TRIP ODOMETER RESETTING INOPERATIVE</b>	<b>TEST C</b>
--	---------------

	TEST STEPS	RESULTS	REMEDY
<b>C1</b>	<b>GROUNDING CHECK</b>		
	<ul style="list-style-type: none"> <li>- Check for presence of 0V (zero) between pin 12E of fuse box G1 and ground with the reset switch activated</li> </ul>	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px;">OK</span> <span style="font-size: 2em;">▶</span> </div> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px; text-decoration: line-through;">OK</span> <span style="font-size: 2em;">▶</span> </div> </div>	<p>Carry-out step C2</p> <p>Repair wiring between pin 12E of fuse box G1 and ground point G174</p>
<b>C2</b>	<b>SWITCH CHECK</b>		
	<ul style="list-style-type: none"> <li>- Press the switch and check for continuity between terminals 3 and 1 of switch B40</li> </ul>	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px;">OK</span> <span style="font-size: 2em;">▶</span> </div> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px; text-decoration: line-through;">OK</span> <span style="font-size: 2em;">▶</span> </div> </div>	<p>Carry-out step C3</p> <p>Replace switch B40</p>
<b>C3</b>	<b>GROUNDING CHECK</b>		
	<ul style="list-style-type: none"> <li>- Check for presence of 0V (zero) at pin 1 of switch B40</li> </ul>	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px;">OK</span> <span style="font-size: 2em;">▶</span> </div> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px; text-decoration: line-through;">OK</span> <span style="font-size: 2em;">▶</span> </div> </div>	<p>Carry-out step C4</p> <p>Repair wiring between pin 1 of switch B40 and pin 6S of fuse box G1</p>
<b>C4</b>	<b>GROUNDING CHECK</b>		
	<ul style="list-style-type: none"> <li>- Press the switch B40 and check for presence of 0V (zero) at pin 8A of instrument panel C10</li> </ul>	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px;">OK</span> <span style="font-size: 2em;">▶</span> </div> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px; text-decoration: line-through;">OK</span> <span style="font-size: 2em;">▶</span> </div> </div>	<p>Replace instrument panel C10</p> <p>Repair wiring between pin 8A of instrument panel C10 and pin 3 of switch B40</p>

End of test C

## ENGINE OIL PRESSURE GAUGE INOPERATIVE

## TEST D

TEST STEPS		RESULTS	REMEDY										
D1	VARIABLE RESISTANCE SIGNAL CHECK												
<p>- Start and accelerate engine, then check pin 15 of connector G151 for presence of a variable resistance signal proportional to the engine oil pressure, as shown in the table below:</p> <table border="1"> <thead> <tr> <th>OIL PRESSURE kg/cm<sup>2</sup>.</th> <th>RESISTANCE Ohms</th> </tr> </thead> <tbody> <tr> <td>0.0</td> <td>290 to 320</td> </tr> <tr> <td>0.4</td> <td>270 to 300</td> </tr> <tr> <td>4.0</td> <td>103 to 133</td> </tr> <tr> <td>8.0</td> <td>0 to 25</td> </tr> </tbody> </table>		OIL PRESSURE kg/cm <sup>2</sup> .	RESISTANCE Ohms	0.0	290 to 320	0.4	270 to 300	4.0	103 to 133	8.0	0 to 25	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step D2</p> <p>Carry-out step D3</p>
OIL PRESSURE kg/cm <sup>2</sup> .	RESISTANCE Ohms												
0.0	290 to 320												
0.4	270 to 300												
4.0	103 to 133												
8.0	0 to 25												
D2	GROUNDING CHECK												
<p>- Repeat test as per step E1 on pin 5A instrument panel C10</p>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace instrument panel C10</p> <p>Repair wiring between pin 5A of instrument panel C10 and pin 15 of connector G151</p>										

(Cont.d)

## ENGINE OIL PRESSURE GAUGE INOPERATIVE

## TEST D

TEST STEPS		RESULTS	REMEDY
D3	PRESSURE TRANSMITTER CHECK		
<p>- Check for presence of a variable resistance signal between terminals of transmitter L8 (RED-BLK and ground wires). The signal must be proportional to the engine oil pressure as shown in the table at test step E1</p>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between transmitter L8 (RED-BLK wire) and pin 15 of connector G151 and between transmitter L8 and ground</p> <p>Replace transmitter L8</p>

End of test D







<b>ENGINE <sup>COOLANT</sup> TEMPERATURE GAUGE INOPERATIVE</b>	<b>TEST E</b>
--	---------------

	TEST STEPS	RESULTS	REMEDY														
<b>E1</b>	<p><b>TEMPERATURE TRANSMITTER CHECK</b></p> <p>- Check functionality of engine coolant temperature transmitter L10 as follows:</p> <ul style="list-style-type: none"> <li>• ensure the engine is cool, then start the engine</li> <li>• check between terminals of transmitter L10 (BRN and BLK wires) for a resistance variable according to temperature of engine coolant as shown in the table below:</li> </ul> <table border="1" style="margin-left: 20px; border-collapse: collapse; width: 80%;"> <thead> <tr> <th style="text-align: center;">TEMPERATURE °C</th> <th style="text-align: center;">RESISTANCE Ohms</th> </tr> </thead> <tbody> <tr><td style="text-align: center;">40</td><td style="text-align: center;">900 to 1400</td></tr> <tr><td style="text-align: center;">60</td><td style="text-align: center;">470 to 600</td></tr> <tr><td style="text-align: center;">80</td><td style="text-align: center;">235 to 300</td></tr> <tr><td style="text-align: center;">90</td><td style="text-align: center;">175 to 215</td></tr> <tr><td style="text-align: center;">100</td><td style="text-align: center;">135 to 165</td></tr> <tr><td style="text-align: center;">120</td><td style="text-align: center;">80 to 100</td></tr> </tbody> </table>	TEMPERATURE °C	RESISTANCE Ohms	40	900 to 1400	60	470 to 600	80	235 to 300	90	175 to 215	100	135 to 165	120	80 to 100	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out <b>step E2</b></p> <p>Replace transmitter L10</p>
TEMPERATURE °C	RESISTANCE Ohms																
40	900 to 1400																
60	470 to 600																
80	235 to 300																
90	175 to 215																
100	135 to 165																
120	80 to 100																
<b>E2</b>	<p><b>GROUNDING CHECK</b></p> <p>- Check for presence of 0V (zero) at terminal of transmitter L10 (BLK wire)</p>	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out <b>step E3</b></p> <p>Repair wiring between transmitter L10 (BLK wire) and ground point G53</p>														

(Cont.d)

*COOLANT*  
ENGINE ~~TEMPERATURE~~ TEMPERATURE GAUGE INOPERATIVE









TEST E

TEST STEPS		RESULTS	REMEDY
E3	CONTINUITY CHECK		
	- Repeat test as per step B1 on pin 20 of connector G151	 	Carry-out step E4  Repair wiring between transmitter L10 (BRN wire) and pin 20 of connector G151
E4	CONTINUITY CHECK		
	- Repeat test as per step B1 on pin 1B instrument panel C10	 	Replace Instrument panel C10  Repair wiring between pin 20 of connector G151 and pin 1B of Instrument panel C10

End of test E

## FUEL LEVEL INDICATOR INOPERATIVE







## TEST F

TEST STEPS		RESULTS	REMEDY
<b>F1</b>	<b>FUEL QUANTITY TRANSMITTER CHECK</b>		
	<ul style="list-style-type: none"> <li>- Check that fuel quantity transmitter L9 is operational as follows:               <ul style="list-style-type: none"> <li>• dip transmitter L9 slowly into a container filled with fuel and check for presence of a variable resistance signal between pins 1 and 2 (PPL and BLK wires) of probe. The signal must be proportional to level of immersion of transmitter L9 into fuel</li> </ul> </li> </ul>	 ▶  ▶	Carry-out step F2  Replace transmitter L9
<b>F2</b>	<b>CONTINUITY CHECK</b>		
	<ul style="list-style-type: none"> <li>- Repeat check as per test step F1 with transmitter L9 connected to the car harness. Check for presence of a variable resistance signal between pin 13 of connector G170 and pin 2 of transmitter L9</li> </ul>	 ▶  ▶	Carry-out step F3  Repair wiring between pin 1 of transmitter L9 (PPL wire) and pin 13 of connector G170
<b>F3</b>	<b>CONTINUITY CHECK</b>		
	<ul style="list-style-type: none"> <li>- Repeat check as per test step F1 with transmitter L9 connected to the car harness. Check for presence of a variable resistance signal between pin 2B of instrument panel C10 and pin 2 of transmitter L9</li> </ul>	 ▶  ▶	Carry-out step F4  Repair wiring between pin 2B of Instrument panel C10 and pin 13 of connector G170
<b>F4</b>	<b>GROUNDING CHECK</b>		
	<ul style="list-style-type: none"> <li>- Check for presence of 0V (zero) at pin 2 of transmitter L9</li> </ul>	 ▶  ▶	Replace instrument panel C10  Repair wiring between pin 2 of transmitter L9 and ground point G186

End of test F

## FUEL LEVEL INDICATOR LAMP INOPERATIVE

## TEST G

TEST STEPS		RESULTS	REMEDY
<b>G1</b>	<b>FUEL PROBE CHECK</b>		
<ul style="list-style-type: none"> <li>- Check that fuel quantity transmitter L9 is operational as follows:               <ul style="list-style-type: none"> <li>• ensure the fuel level is below 9.2 litres (2.43 gals) then verify that circuit between pin 2 and 3 of transmitter L9 is closed (BLK and PPL-BLK wires)</li> </ul> </li> </ul>		 ►  ►	Carry-out step G2  Replace transmitter L9
<b>G2</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 0V (zero) at pin 2 of transmitter L9 (BLK wire)</li> </ul>		 ►  ►	Carry-out step G3  Repair wiring between pin 2 of transmitter L9 and ground point G186
<b>G3</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Establish operating conditions as per test step G1, then check for presence of 0V (zero) at pin 10 of connector G170</li> </ul>		 ►  ►	Carry-out step G4  Repair wiring between pin 10 of connector G170 and pin 3 of transmitter L9

(Cont.d)

## FUEL LEVEL INDICATOR LAMP INOPERATIVE

## TEST G


TEST STEPS		RESULTS	REMEDY
<b>G4</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Establish operating conditions as per test step G1, then check for presence of 0V (zero) at pin 3B of instrument panel <b>C10</b></li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace instrument panel <b>C10</b></p> <p>Repair wiring between pin 3B of instrument panel <b>C10</b> and pin 10 of connector <b>G170</b></p>

End of test G

**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>

INSTRUMENT PANEL - -  
INTERNAL WIRING





## GENERAL


This wiring diagram illustrates the instrument panel wiring. The instrument panel wiring diagram has never been entirely illustrated in the various sections of this

manual; therefore, refer to this wiring diagram for a complete view of this component. An adequate knowledge of this wiring diagram will allow you to quickly identify defective bulbs.

# LAMPS - - BRAKE



S ONLY



**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>

## GENERAL

Actuation of the stop lamps is not depending upon insertion of the ignition key. Pressing brake pedal, the three rear stop lamps are powered simultaneously (two lateral and one central). The vehicle is equipped with a stop lamps failure detector circuit.

Should one or all stop lamps be burned out the related warning lamp illuminates on the instrument panel (for further details refer to Alfa Romeo Control unit power circuit and instrument panel interface).

The stop lamps power supply line is protected by fuse **F15** (15A) in fuse box **G1**.

Moreover, the vehicle is provisioned with an appropriate circuit for the actuation of a trailer stop lamps, if used.

## OPERATIONAL DESCRIPTION

Battery voltage is sent to rear stop lamp switch **H3**. This line is protected by a stop lamps fuse **F15** (15A) in

fuse box **G1**.

During rest conditions, the Alfa Romeo control unit **N22** receives power (12V) at pin 4A. Pressing on the brake pedal, the rear stop lamp switch **H3** is actuated.

With brake pedal pressed the switch **H3** connects 12V to stop lamps switch relay **I69** coil and to connector **G192** for the trailer stop lamps, if used, through the fuse box **G1**.

The Alfa Romeo control unit **N22**, through stop lamps switch relay **I69**, receives 12V on pin 3A; simultaneously power is removed from line on pin 4A.

In these conditions, the control unit **N22** gives an output power (pin 6A) to turn on the 3rd center stop lamp **E28** and to rear lamps control unit **N44**.

The control unit **N44** turns on, by means of 12V, the tail lamp left (fixed part) **E26** (pin 6) and tail lamp right (fixed part) **E25** (pin 1).

Furthermore, the control unit **N44**, in case the turn signal lamps are activated, inhibits the check that the Alfa Romeo Control unit **N22** is performing on the stop lamps circuit by means of the signal present on pin 9.


## TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT								
	F15 FUSE	C10 STOP WARN. LAMP	E25 R.H. REAR STOP LAMP	E26 L.H. REAR STOP LAMP	E28 3rd STOP LAMPS	H3 SWITCH	I69 RELAY	N22 CONTROL UNIT	N44 CONTROL UNIT
ALL STOP LAMPS INOPERATIVE	●					●	●	●	
CENTER STOP LAMP INOPERATIVE					●			●	
L.H. AND R.H. STOP LAMPS INOPERATIVE								●	●
L.H. STOP LAMP INOPERATIVE				●					●
R.H. STOP LAMP INOPERATIVE			●						●
STOP LAMP WARNING LAMP INOPERATIVE ON INSTRUMENT PANEL (WITH BURNED OUT STOP LAMPS)		●							●

**NOTE:** Before attempting any troubleshooting ascertain the integrity of the affected warning lamp on the instrument panel by pressing the test button.


Tail lamp, right (fixed part)

E25



Tail lamp, left (fixed part)

E26




Center stop lamp

E28


Center stop lamp

E28

BASE AND L ONLY



S ONLY




Dome lamp, control switch on right rear post

F36

Fuse box













G1 D

BASE AND L ONLY













(Cont.d)




<p>Fuse box</p>	<p><b>G1</b> <b>N</b></p>	<p>Fuse box</p>	<p><b>G1</b> <b>P</b></p>
			
<p>Six pin connector circuit board to doors wiring</p>	<p><b>G16</b></p>	<p>Central bulkhead ground</p>	<p><b>G143</b></p>
			
<p>Connector, front doors to left rear wiring</p>	<p><b>G169</b></p>	<p>Connector, circuit board to right rear wiring</p>	<p><b>G170</b></p>
		<p><b>BASE AND L ONLY</b></p> 	
<p>Connector, circuit board to right rear wiring</p>	<p><b>G170</b></p>	<p>Connector, circuit board to left rear wiring</p>	<p><b>G171</b></p>
<p><b>S ONLY</b></p> 			
<p>Steering wheel column support ground</p>	<p><b>G174</b></p>	<p>Trunk left side ground</p>	<p><b>G185</b></p>
			
<p>Trunk right side ground</p>	<p><b>G186</b></p>	<p>Trunk right side ground</p>	<p><b>G186</b></p>
<p><b>BASE AND L ONLY</b></p> 		<p><b>S ONLY</b></p> 	


(Cont.d)

<p>Connector, provision for trailer stop lamps</p> <p><b>G192</b></p> 	<p>Connector, right rear wiring to trunk lock wiring</p> <p><b>G198</b></p> <p><b>S ONLY</b></p> 
<p>Connector, circuit board to automatic lever wiring</p> <p><b>G233</b></p> <p><b>BASE AND L ONLY</b></p> 	<p>Connector, circuit board to automatic lever wiring</p> <p><b>G233</b></p> <p><b>S ONLY</b></p> 
<p>Board wiring to aft console wiring two-way connector</p> <p><b>G244</b></p> 	<p>Rear stop lamp switch</p> <p><b>H3</b></p> 
<p>Electronic control units power supply relay</p> <p><b>H24</b></p> <p><b>S ONLY</b></p> 	<p>Electronic control units power supply relay</p> <p><b>I51</b></p> 
<p>Stop lamps switch relay</p> <p><b>I69</b></p> 	<p>Trunk opening solenoid</p> <p><b>M12</b></p> <p><b>S ONLY</b></p> 


(Cont.d)



**BASE AND L ONLY**



**S ONLY**



## ALL STOP LAMPS INOPERATIVE









## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
- Check fuse F15 in fuse box G1 for integrity		OK      ► <del>OK</del> ►	Carry-out step A2  Replace fuse F15
<b>A2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2 of rear stop lamp switch H3 and ground		OK      ► <del>OK</del> ►	Carry-out step A4  Carry-out step A3
<b>A3</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2N of fuse box G1 and ground		OK      ► <del>OK</del> ►	Repair wiring between pin 2 of switch H3 and pin 2P of fuse box G1  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>A4</b>	<b>SWITCH CHECK</b>		
- With brake pedal pressed, check for presence of 12V between pin 1 of rear stop lamp switch H3 and ground		OK      ► <del>OK</del> ►	Carry-out step A5  Replace switch H3

(Cont.d)

## ALL STOP LAMPS INOPERATIVE

## TEST A





TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>VOLTAGE CHECK</b>		
- With brake pedal pressed, check for presence of 12V between pin 3P of fuse box G1 and ground		 	Carry-out step A6  Repair wiring between pin 1 of switch H3 and pin 3P of fuse box G1
<b>A6</b>	<b>GROUNDING CHECK</b>		
- Check for presence 0V (zero) at pin 85 of stop lamps switch relay I69		 	Carry-out step A7  Repair wiring between pin 85 of relay I69 and ground point G143
<b>A7</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 30 of relay I69 and ground		 	Carry-out step A8  Repair wiring between pin 2 of switch H3, pin 6 of connector G16 and pin 30 of relay I69
<b>A8</b>	<b>RELAY CHECK</b>		
- Check relay I69 for proper operation		 	Carry-out step A9  Replace relay I69

(Cont.d)



ALL STOP LAMPS INOPERATIVE

TEST A







TEST STEPS		RESULTS	REMEDY
<b>A9</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 86 of relay I69 and ground		 ►  ►	Carry-out step A10  Repair wiring between pin 86 of relay I69 and pin 6D of fuse box G1
<b>A10</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 3A of Alfa Romeo Control unit N22 and ground		 ►  ►	Replace control unit N22  Repair wiring between pin 3A of control unit N22 and pin 87 of relay I69

End of test A



## CENTER STOP LAMP INOPERATIVE

## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>BULB CHECK</b>		
- Check bulb of center stop lamp E28 for integrity			Carry-out step B2
			Replace bulb E28
<b>B2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 6A of Alfa Romeo Control unit N22 and ground			For BASE and L version carry-out step B3. For S version carry-out step B4
			Replace control unit N22
<b>B3</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 1 of center stop lamp E28 and ground			Repair wiring between pin 2 of center stop lamp E28 and ground point G186
			Repair wiring between pin 1 of lamp E28, pin 6 of connector G170 and pin 6A of control unit N22

(Cont.d)

## CENTER STOP LAMP INOPERATIVE







## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B4</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>With brake pedal pressed, check for presence of 12V between pin 1 of center stop lamp E28 and ground</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step B5</p> <p>Repair wiring between pin 1 of lamp E28, pin 6 of G198, pin 6 of connector G170 and pin 6 of control unit</p>
<b>B5</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>Check for presence of 0V (zero) between pin 2 of connector G198 and ground</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pin 2 of connector G198 and pin 2 of center stop lamp E28</p> <p>Repair wiring between pin 2 of connector G198 and ground point G186</p>

End of test B







## LH AND RH STOP LAMPS INOPERATIVE

## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C1</b>	<b>VOLTAGE CHECK</b>		
- With brake pedal pressed check for presence of 12V at pins 5 and 7 of rear lamps control unit N44		 	Carry-out step C2  Carry-out step C3
<b>C2</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 12 of rear lamps control unit N44		 	Replace control unit N44  Repair wiring between pin 2 of connector G244 and pin 12 of control unit N44
<b>C3</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between: <ul style="list-style-type: none"> <li>• pin 7 of Alfa Romeo Control unit N22 and pin 5 of rear lamps control unit N44</li> <li>• pin 5 of Alfa Romeo Control unit N22 and pin 7 of rear lamps control unit N44</li> </ul>		 	Replace control unit N22  Repair or replace wires, as necessary

End of test C







<b>LH STOP LAMP INOPERATIVE</b>	<b>TEST D</b>
---------------------------------	---------------

<b>TEST STEPS</b>		<b>RESULTS</b>	<b>REMEDY</b>
<p><b>NOTE:</b> In case only one of the stop lamps does not illuminate, check for integrity of bulb and/or check for continuity of relevant wires.</p>			
<b>D1</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 12V between pin 6 of rear lamps control unit N44 and ground</li> </ul>		 ►  ►	Carry-out step D2  Replace control unit N44
<b>D2</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- With brake pedal pressed, check for presence of 12V between pins 2B and 2A of tail lamp left and ground</li> </ul>		 ►  ►	Carry-out step D3  Repair wiring between pins 2A and 2B of tail lamp left, pin 14 of connector G171 and pin 6 of control unit N44
<b>D3</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 0V (zero) at pins 1B and 1A of tail lamp left</li> </ul>		 ►  ►	Replace bulbs E26  Repair wiring between pins 1B and 1A of tail lamp left and ground point G185

End of test D





## RH STOP LAMP INOPERATIVE

## TEST E

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> In case only one of the stop lamps does not illuminate, check for integrity of bulb and/or check for continuity of relevant wires.</p>			
<b>E1</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 12V between pin 1 of rear lamps control unit N44 and ground</li> </ul>		 	<p>Carry-out step E2</p> <p>Replace control unit N44</p>
<b>E2</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- With brake pedal pressed, check for presence of 12V between pins 2B and 2A of tail lamp right and ground</li> </ul>		 	<p>Carry-out step E3</p> <p>Repair wiring between pins 2A and 2B of tail lamp left, pin 12 of connector G170 and pin 1 of control unit N44</p>
<b>E3</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 0V (zero) at pins 1B and 1A of tail lamp right</li> </ul>		 	<p>Replace bulbs E25</p> <p>Repair wiring between pins 1B and 1A of tail lamp right and ground point G186</p>


End of test E

**STOP LAMP WARNING LAMP INOPERATIVE ON INSTRUMENT PANEL  
(WITH BURNED OUT STOP LAMPS)**
**TEST F**

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> In case only the center stop lamp bulb is burned out, and the warning lamp does not illuminate, replace the Alfa Romeo Control unit N22.</p>			
<b>F1</b>	<b>WARNING LAMP CHECK</b>		
<ul style="list-style-type: none"> <li>- Check warning lamp on instrument panel for integrity by pressing test pushbutton</li> </ul>		 ►  ►	Carry-out step F2  Replace instrument panel warning lamp
<b>F2</b>	<b>CONTROL UNIT CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of open circuit on pins 5A, 6A and 7A of Alfa Romeo Control unit N22</li> </ul>		 ►  ►	Failure of the instrument panel - - Alfa Romeo Control ECU interface circuit; refer to the applicable troubleshooting procedure  Replace rear lamps control unit N44

**End of test F**

# LAMPS - - DOOR OPEN INDICATOR





## GENERAL

Opening of front and/or rear doors is indicated by illumination of the relevant indicators on the instrument panel. Switches located on the doors provide door open/closed inputs to the control unit.

The Alfa Romeo Control Unit monitors the activation of the warning lamp relevant to the door that has been opened.

The door open condition is also monitored by the anti-theft, door lock/unlock and courtesy lamp circuits; refer to pertinent chapters for further information.

## OPERATIONAL DESCRIPTION - FRONT DOOR OPEN WARNING LAMPS

The left front door open indicator jamb switch H5 opens when the relevant door is opened, thus disconnecting pin 2F of the Alfa Romeo Control unit N22 from the ground point.


Under this condition, the control unit N22 activates on the instrument panel the door open warning lamp corresponding to that door.

In the same way, the control unit N22 monitors the opening of the right front door through the switch H6.

### TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT		
	H5 DOOR SWITCH	H6 DOOR SWITCH	N22 CONTROL UNIT
LEFT FRONT DOOR OPEN WARNING LAMP INOPERATIVE			●
LEFT FRONT DOOR OPEN WARNING LAMP CONTINUOUSLY ILLUMINATED	●		●
RIGHT FRONT DOOR WARNING LAMP INOPERATIVE			●
RIGHT FRONT DOOR OPEN WARNING LAMP CONTINUOUSLY ILLUMINATED		●	●

**NOTE:** Before attempting any troubleshooting, check the related warning lamp on the instrument panel by pressing the test button.



## OPERATIONAL DESCRIPTION - REAR DOOR OPEN WARNING LAMPS

The left rear door open indicator jamb switch H7 opens when the relevant door is opened, thus disconnecting pin 5F of the Alfa Romeo Control unit N22 from the

ground point.












Under this condition, the control unit N22 activates on the instrument panel the door open warning lamp corresponding to that door.

In the same way, the control unit N22 monitors the opening of the right rear door through the switch H8.







### TROUBLESHOOTING TABLE


FAULT TYPE	FAILED COMPONENT		
	DOOR SWITCH H7	DOOR SWITCH H8	CONTROL UNIT N22
LEFT REAR DOOR OPEN WARNING LAMP INOPERATIVE			●
LEFT REAR DOOR OPEN WARNING LAMP CONTINUOUSLY ILLUMINATED	●		●
RIGHT REAR DOOR OPEN WARNING LAMP INOPERATIVE			●
RIGHT REAR DOOR OPEN WARNING LAMP CONTINUOUSLY ILLUMINATED		●	●

**NOTE:** Before attempting any troubleshooting, check the related warning lamp on the instrument panel by pressing the test button.

<p>Connector, right front door to right front door sensor wiring</p>	<p>Connector, left front door to left front door sensor wiring</p>
<p><b>G156</b></p>  <p>A WHT-BLK G156 B BLK G156 TO RIGHT FRONT DOOR OPEN INDICATOR JAMB SWITCH (H6)</p>	<p><b>G157</b></p>  <p>A BRN G158 B BLK G158 TO LEFT FRONT DOOR OPEN INDICATOR JAMB SWITCH (H5)</p>
<p>Connector, right rear door to right rear door sensor wiring</p>	<p>Connector, left rear door to left rear door sensor wiring</p>
<p><b>G158</b></p>  <p>A YEL-GRN G197 B BLK G197 TO RIGHT REAR DOOR OPEN INDICATOR JAMB SWITCH (H8)</p>	<p><b>G159</b></p>  <p>A YEL-GRN G191 B BLK G191 TO LEFT REAR DOOR OPEN INDICATOR JAMB SWITCH (H7)</p>
<p>Connector, front doors to right front door wiring</p>	<p>Connector, front doors to right rear wiring</p>
<p><b>G166</b></p>  <p>WHT-BLK G167 11 1BLK G174 14 11 WHT-BLK G156 14 1BLK G156 P10 PIN E</p>	<p><b>G167</b></p>  <p>WHT-BLK G168 4 4 WHT-BLK G170</p> <p><b>G168</b></p> <p>Connector, front doors to left front door wiring</p>  <p>BRN G169 11 1BLK G174 14 11 BRN G167 14 1BLK G167 BLK G167 B36 PIN 2 P11 PIN E P8 PIN E</p>
<p>Connector, front doors to left rear wiring</p>	<p>Connector, circuit board to right rear wiring</p>
<p><b>G169</b></p>  <p>BRN G168 8 8 BRN G171</p>	<p><b>G170</b></p>  <p>WHT-BLK G167 7 YEL-RED G197 3 7 WHT-BLK N22 (F) 3 YEL-RED N22 (F)</p>
<p>Connector, circuit board to left rear wiring</p>	<p>Connector, circuit board to left rear wiring</p>
<p><b>G171</b></p>  <p>YEL-GRN N22 (F) 7 BRN N22 (F) 10 7 YEL-GRN G191 10 BRN G189</p>	<p><b>G171</b></p>  <p>YEL-GRN N22 (F) 7 BRN N22 (F) 10 7 YEL-GRN G191 10 BRN G189</p>

(Cont.d)

Steering wheel column support ground	<b>G174</b>	Trunk left side ground	<b>G185</b>
			
Trunk right side ground	<b>G186</b>	Connector, left rear wiring to left rear door wiring	<b>G191</b>
			
Connector, right rear wiring to right rear door wiring	<b>G197</b>	Alfa Romeo control unit	
			



## LEFT FRONT DOOR OPEN WARNING LAMP INOPERATIVE

TEST A

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Before attempting any troubleshooting, ascertain the integrity of the affected warning lamp on the instrument panel by pressing the test button: replace the affected lamp if it does not illuminate.</p>		
<p><b>A1</b> CONTROL UNIT CHECK</p>		
<p>- With left front door open, check that circuit is open at pin 2F of Alfa Romeo Control unit N22</p>	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Failure of Instrument panel - - Alfa Romeo Control ECU interface circuit; refer to the applicable troubleshooting procedure</p> <p>Replace switch H5</p>

End of test A

## LEFT FRONT DOOR OPEN WARNING LAMP CONTINUOUSLY ILLUMI-NATED

## TEST B







TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>CONTROL UNIT CHECK</b>		
- With left front door closed, check for presence of 0V (zero) at pin 2F of Alfa Romeo Control unit N22		OK ►	Failure of the Instru-ment panel - - Alfa Romeo Control ECU interface circuit; refer to the applicable troubleshooting procedure
		<del>OK</del> ►	Carry-out step B2
<b>B2</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at terminal of left front door open indicator jamb switch H5 (BLK wire)		OK ►	Carry-out step B3
		<del>OK</del> ►	Carry-out step B6
<b>B3</b>	<b>DOOR SWITCH CHECK</b>		
- Check that circuit is closed between terminals of switch H5 when the left front door is closed		OK ►	Carry-out step B4
		<del>OK</del> ►	Replace switch H5
<b>B4</b>	<b>GROUNDING CHECK</b>		
- With left front door closed, check for presence of 0V (zero) at pin A of connector G157		OK ►	Carry-out step B5
		<del>OK</del> ►	Repair wiring between pin A of connector G157 and switch H5 (BLK wire)

(Cont.d)



## LEFT FRONT DOOR OPEN WARNING LAMP CONTINUOUSLY ILLUMINATED



## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B5</b>	<b>GROUNDING CHECK</b>		
- With left front door closed, check for presence of 0V (zero) at pin 11 of connector <b>G168</b>		 	Carry-out <b>step B6</b>  Repair wiring between <b>pin 11 of connector G168</b> and <b>pin A of connector G157</b>
<b>B6</b>	<b>GROUNDING CHECK</b>		
- With left front door closed, check for presence of 0V (zero) at pin 8 of connector <b>G169</b>		 	Carry-out <b>step B7</b>  Repair wiring between <b>pin 8 of connector G169</b> and <b>pin 11 of connector G168</b>
<b>B7</b>	<b>GROUNDING CHECK</b>		
- With left front door closed, check for presence of 0V (zero) at pin 10 of connector <b>G171</b>		 	Repair wiring between <b>pin 10 of connector G171</b> and <b>pin 2F of control unit N22</b>  Repair wiring between <b>pin 10 of connector G171</b> and <b>pin 8 of connector G169</b>

(Cont.d)

LEFT FRONT DOOR OPEN WARNING LAMP CONTINUOUSLY ILLUMI-  
NATED

TEST B

TEST STEPS		RESULTS	REMEDY
BB	GROUNDING CHECK		
- Check for presence of 0V (zero) at pin B of connector G157			Repair wiring between pin B of connector G157 and switch H5 (BLK wire)
			Repair wiring between pin B of connector G157, pin 14 of connector G168 and ground point G174

End of test B

















<b>RIGHT FRONT DOOR WARNING LAMP INOPERATIVE</b>	<b>TEST C</b>
--	---------------

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Before attempting any troubleshooting, ascertain the integrity of the affected warning lamp on the instrument panel by pressing the test button: replace the affected lamp if it does not illuminate.</p>		
<p><b>C1</b> CONTROL UNIT CHECK</p> <p>- With right front door open, check that circuit is open at pin 1F of Alfa Romeo Control unit N22</p>	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Failure of the instrument panel - - Alfa Romeo Control ECU interface circuit; refer to the applicable troubleshooting procedure</p> <p>Replace switch H6</p>

End of test C

## RIGHT FRONT DOOR OPEN WARNING LAMP CONTINUOUSLY ILLUMINATED







## TEST D

TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>CONTROL UNIT CHECK</b>		
- With right front door closed, check for presence of 0V (zero) at pin 1F of Alfa Romeo Control unit N22		 	Failure of the Instrument panel - - Alfa Romeo Control ECU Interface circuit; refer to the applicable troubleshooting procedure
		 	Carry-out step D2
<b>D2</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) between terminal of right front door open indicator jamb switch H6 (BLK wire) and ground		 	Carry-out step D3
		 	Carry-out step D8
<b>D3</b>	<b>DOOR SWITCH CHECK</b>		
- Check that circuit is closed between terminals of switch H6 when the right front door is closed		 	Carry-out step D4
		 	Replace switch H6
<b>D4</b>	<b>GROUNDING CHECK</b>		
- With right front door closed, check for presence of 0V (zero) between pin A of connector G156 and ground		 	Carry-out step D5
		 	Repair wiring between pin A of connector G156 and switch H6 (BLK wire)

(Cont.d)

RIGHT FRONT DOOR OPEN WARNING LAMP CONTINUOUSLY ILLUMINATED

TEST D

TEST STEPS		RESULTS	REMEDY
<b>D5</b>	<b>GROUNDING CHECK</b>		
- With right front door closed, check for presence of 0V (zero) at pin 11 of connector <b>G166</b>		 ►  ►	Carry-out <b>step D6</b>  Repair wiring between <b>pin 11 of connector G166</b> and <b>pin A of connector G156</b>
<b>D6</b>	<b>GROUNDING CHECK</b>		
- With right front door closed, check for presence of 0V (zero) at pin 4 of connector <b>G167</b>		 ►  ►	Carry-out <b>step D7</b>  Repair wiring between <b>pin 4 of connector G167</b> and <b>pin 11 of connector G166</b>
<b>D7</b>	<b>GROUNDING CHECK</b>		
- With right front door closed, check for presence of 0V (zero) at pin 7 of connector <b>G170</b>		 ►  ►	Repair wiring between <b>pin 7 of connector G170</b> and <b>pin 1F of control unit N22</b>  Repair wiring between <b>pin 7 of connector G170</b> and <b>pin 4 of connector G167</b>

(Cont.d)

RIGHT FRONT DOOR OPEN WARNING LAMP CONTINUOUSLY ILLUMI-  
NATED



TEST D

TEST STEPS		RESULTS	REMEDY
D8	GROUNDING CHECK		
- Check for presence of 0V (zero) at pin B of connector G156		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin B of connector G156 and switch H6 (BLK wire)</p> <p>Repair wiring between pin B of connector G156, pin 14 of connector G166 and ground point G174</p>

End of test D

## LEFT REAR DOOR OPEN WARNING LAMP INOPERATIVE









TEST E

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Before attempting any troubleshooting, ascertain the integrity of the affected warning lamp on the instrument panel by pressing the test button: replace the affected lamp if it does not illuminate.</p>		
<b>E1</b> CONTROL UNIT CHECK	 ►   ►	<p>Failure of the instrument panel - - Alfa Romeo Control ECU interface circuit; refer to the applicable troubleshooting procedure</p> <p>Replace switch H7</p>
<p>- With left rear door open, check that circuit is open at pin 5F of Alfa Romeo Control unit N22</p>		

End of test E

## LEFT REAR DOOR OPEN WARNING LAMP CONTINUOUSLY ILLUMINATED

## TEST F







TEST STEPS		RESULTS	REMEDY
<b>F1</b>	<b>CONTROL UNIT CHECK</b>		
- With left rear door closed, check for presence of 0V (zero) at pin 5F of Alfa Romeo Control unit N22		 	Failure of the Instrument panel - - Alfa Romeo Control ECU Interface circuit; refer to the applicable troubleshooting procedure  Carry-out step F2
<b>F2</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at terminal of left rear door open indicator jamb switch H7 (BLK wire)		 	Carry-out step F3  Carry-out step F7
<b>F3</b>	<b>DOOR SWITCH CHECK</b>		
- Check that circuit is closed between terminals of switch H7 when the left rear door is closed		 	Carry-out step F4  Replace switch H7
<b>F4</b>	<b>GROUNDING CHECK</b>		
- With left rear door closed, check for presence of 0V (zero) at pin A of connector G159		 	Carry-out step F5  Repair wiring between pin A of connector G159 and switch H7 (BLK wire)

(Cont.d)



LEFT REAR DOOR OPEN WARNING LAMP CONTINUOUSLY ILLUMINATED

TEST F

TEST STEPS		RESULTS	REMEDY
<b>F5</b>	<b>GROUNDING CHECK</b>		
- With left rear door closed, check for presence of 0V (zero) at pin 12 of connector <b>G191</b>		 	Carry-out <b>step F6</b>  Repair wiring between <b>pin 12 of connector G191</b> and <b>pin 7 of connector G171</b>
<b>F6</b>	<b>GROUNDING CHECK</b>		
- With left rear door closed, check for presence of 0V (zero) at pin 7 of connector <b>G171</b>		 	Repair wiring between <b>pin 7 of connector G171</b> and <b>pin 5F of control unit N22</b>  Repair wiring between <b>pin 7 of connector G171</b> and <b>pin 12 of connector G191</b>
<b>F7</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin <b>B</b> of connector <b>G159</b>		 	Repair wiring between <b>pin B of connector G159</b> and <b>switch H7 (BLK wire)</b>  Repair wiring between <b>pin B of connector G159</b> , <b>pin 14 of connector G191</b> and <b>ground point G185</b>

End of test F

## RIGHT REAR DOOR OPEN WARNING LAMP INOPERATIVE

## TEST G

## TEST STEPS

## RESULTS

## REMEDY

**NOTE:** Before attempting any troubleshooting, ascertain the integrity of the affected warning lamp on the instrument panel by pressing the test button: replace the affected lamp if it does not illuminate.

## G1 CONTROL UNIT CHECK

- With right rear door open, check that circuit is open at pin 4F of Alfa Romeo Control unit N22

OK



Failure of the instrument panel - - Alfa Romeo Control ECU interface circuit; refer to the applicable troubleshooting procedure







~~OK~~



Replace switch HB

End of test G









<b>RIGHT REAR DOOR OPEN WARNING LAMP CONTINUOUSLY ILLUMINATED</b>	<b>TEST H</b>
---	---------------

TEST STEPS		RESULTS	REMEDY
<b>H1</b>	<b>GROUNDING CHECK</b>		
- With right rear door closed, check for presence of 0V (zero) at pin 12 of connector <b>G197</b>		 ►  ►	Carry-out <b>step H2</b>  Carry-out <b>step H3</b>
<b>H2</b>	<b>GROUNDING CHECK</b>		
- With right rear door closed, check for presence of 0V (zero) at pin 4F of Alfa Romeo Control unit <b>N22</b>		 ►  ►	Failure of the Instrument panel - - Alfa Romeo Control ECU Interface circuit refer to the applicable troubleshooting procedure  Repair wiring between pin 12 of <b>G197</b> , pin 3 of <b>G170</b> and pin 4F of <b>N22</b>
<b>H3</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 14 of connector <b>G197</b>		 ►  ►	Carry-out <b>step H4</b>  Repair wiring between pin 14 of connector <b>G197</b> and ground point <b>G186</b>

(Cont.d)

RIGHT REAR DOOR OPEN WARNING LAMP CONTINUOUSLY ILLUMI-  
NATED

TEST H

TEST STEPS		RESULTS	REMEDY
<b>H4</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin B of connector G158		 ►  ►	Carry-out <b>step H5</b>  Repair wiring between <b>pin B of G158 and pin 14 of G197</b>
<b>H5</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at terminal of right rear door open indicator jamb switch H8 (BLK wire)		 ►  ►	Carry-out <b>step H6</b>  Repair wiring between <b>pin B of G158 and terminal of switch H8</b>
<b>H6</b>	<b>DOOR SWITCH CHECK</b>		
- Check that circuit is closed between terminals of switch H8 when the right rear door is closed		 ►  ►	Carry-out <b>step H7</b>  Replace <b>switch H8</b>
<b>H7</b>	<b>GROUNDING CHECK</b>		
- With right rear door closed, check for presence of 0V (zero) at pin A of connector G158		 ►  ►	Repair wiring between <b>pin A of G158 and pin 12 of G197</b>  Repair wiring between <b>pin A of G158 and terminal of switch H8 (BLK wire)</b>

End of test H

LAMPS - - GROUND ILLUMINA-  
TION, DOOR OPEN, TRUNK  
LIGHTING



## GENERAL

The vehicle is provided with front and rear door open indicator lamps located on the instrument panel.

Moreover, each door is provided with a ground illumination lamp.

The door open warning lamps are activated by the domes relay under control of the Alfa Romeo control unit, which is connected to the door open sensors (refer to the Alfa Romeo control unit circuit).

The trunk is provided with a dome lamp, that is actuated by closure of a switch.

The circuit relevant to the ground illumination lamps and to the trunk lighting is protected by fuses in the auxiliary fuse box G2, as follows:

- fuse F5 (10A) GROUND ILLUMINATION.
- fuse F6 (10A) TRUNK RELAY.

## OPERATIONAL DESCRIPTION

The battery power (12V) is supplied to the dome lamp relay I26 through the auxiliary fuse box G2. The relay power supply line is protected by the trunk relay fuse F6. When any of the four doors of the vehicle is opened, the Alfa Romeo control unit energizes the relay I26.

Closure of relay I26 contacts connects to ground the door open warning lamps and the ground illumination lamps. Power (12V) is supplied to the above mentioned lamps through the ground illumination fuse F5 in the auxiliary fuse box G2.

The lamps activated by the energization of relay I26 are:

- Left front door open warning lamp F28.
- Right front door open warning lamp F27.
- Left rear door open warning lamp F30.
- Right rear door open warning lamp F29.
- Left front door open ground illumination lamp F32.
- Right front door open ground illumination lamp F31.
- Left rear door open ground illumination lamp F34.
- Right rear door open ground illumination lamp F33.

Power (12V) is also supplied to the rear cargo lamp F5 through the fuse F5 in the auxiliary fuse box G2.







Opening of the trunk lid closes the trunk illumination switch H24, thus switching on the rear cargo lamp F5.

TROUBLESHOOTING TABLE


FAULT TYPE	FAILED COMPONENT													
	F5	F6	F5	F27	F28	F29	F30	F31	F32	F33	F34	H24	I26	N22
	FUSE	FUSE	TRUNK DOME	R.H. FRONT LAMP	L.H. FRONT LAMP	R.H. REAR LAMP	L.H. REAR LAMP	R.H.F. DOOR OPEN LAMP	L.H.F. DOOR OPEN LAMP	R.H.R. DOOR OPEN LAMP	L.H.R. DOOR OPEN LAMP	TRUNK ILL. SWITCH	DOME LAMP RELAY	CONTROL UNIT
DOOR OPEN INDICATOR LAMPS AND GROUND ILLUMINATION LAMPS INOPERATIVE	●	●											●	
LEFT FRONT DOOR OPEN INDICATOR LAMP AND GROUND ILLUMINATION LAMP INOPERATIVE					●				●					
LEFT FRONT DOOR OPEN INDICATOR LAMP INOPERATIVE					●									
LEFT FRONT DOOR GROUND ILLUMINATION LAMP INOPERATIVE									●					
RIGHT FRONT DOOR OPEN INDICATOR LAMP AND GROUND ILLUMINATION				●				●						
RIGHT FRONT DOOR OPEN INDICATOR LAMP INOPERATIVE				●										
RIGHT FRONT DOOR GROUND ILLUMINATION LAMP INOPERATIVE								●						
LEFT REAR DOOR OPEN INDICATOR LAMP AND GROUND ILLUMINATION INOPERATIVE							●				●			



FAULT TYPE	FAILED COMPONENT													
	F5	F6	F5	F27	F28	F29	F30	F31	F32	F33	F34	H24	I26	N22
	FUSE	FUSE	TRUNK DOME	R.H. FRONT LAMP	L.H. FRONT LAMP	R.H. REAR LAMP	L.H. REAR LAMP	R.H.F. DOOR OPEN LAMP	L.H.F. DOOR OPEN LAMP	R.H.R. DOOR OPEN LAMP	L.H.R. DOOR OPEN LAMP	TRUNK ILL. SWITCH	DOMELAMP RELAY	CONTROL UNIT
LEFT FRONT DOOR OPEN INDICATOR LAMP INOPERATIVE							•							
LEFT FRONT DOOR GROUND ILLUMINATION LAMP UNOPERATIVE											•			
RIGHT REAR DOOR OPEN INDICATOR LAMP AND GROUND ILLUMINATION LAMP INOPERATIVE						•				•				
RIGHT REAR DOOR OPEN INDICATOR LAMP INOPERATIVE						•								
RIGHT REAR DOOR GROUND ILLUMINATION LAMP INOPERATIVE										•				
TRUNK DOME INOPERATIVE	•		•									•		

Rear cargo lamp	F5	Right front door open warning lamp	F27
 <p>1RED-BLK* F38</p> <p>GRY-BLK* G128</p> <p>G248</p>		 <p>WHT* G160</p> <p>1RED-BLK* G160</p>	
Left front door open warning lamp	F28	Right rear door open warning lamp	F29
 <p>WHT* G161</p> <p>1RED-BLK* G161</p>		 <p>WHT* G162</p> <p>1RED-BLK* G162</p>	
Left rear door open warning lamp	F30	Dome lamp, control switch on right rear post	F36
 <p>WHT* G163</p> <p>1RED-BLK* G163</p>		 <p>RED-BLK* F5</p> <p>RED-BLK* G167</p> <p>Fuse box</p> <p>GRN-WHT* N22 A 10</p>	

(Cont.d)




(Cont.d)

<p>Connector, left rear door to ground illumination lamp wiring</p>	<p>Connector, front doors to right front door wiring</p>
<p><b>G163</b></p>	<p><b>G166</b></p>
<p>Connector, front doors to right rear wiring</p>	<p>Connector, front doors to left front door wiring</p>
<p><b>G167</b></p>	<p><b>G168</b></p>
<p>Connector, front doors to left rear wiring</p>	<p>Steering wheel column support ground</p>
<p><b>G169</b></p>	<p><b>G174</b></p> <p><b>G186</b></p>

(Cont.d)

<p>Connector, left rear wiring to left rear door wiring</p>	<p>G191</p>	<p>Connector, right rear wiring to right rear door wiring</p>	<p>G197</p>
<p>1RED-BLK• G183 20 WHT• G183 22 1RED-BLK• G189 20 WHT• G189 22</p>		<p>1RED-BLK• G182 20 WHT• G182 22 RED-BLK• G187 20 WHT• G187 22</p>	
<p>Connector, right rear wiring to trunk lock wiring</p>	<p>G198</p>	<p>Trunk illumination switch</p>	<p>H24</p>
<p>GRY-BLK• H24 5 2.5BLK• M12 2 GRY-BLK• F5 5 2.5BLK• G186 2</p>		<p>BASE AND L ONLY</p> <p>GRY-BLK• G198 1BLK• M12</p>	
<p>Trunk illumination switch</p>	<p>H24</p>	<p>Trunk opening solenoid</p>	<p>M12</p>
<p>S ONLY</p> <p>GRY-BLK• G198 1BLK• M12 E28 PIN 2</p>		<p>1BLK• H24 2 2.5BLK• G198 2</p> <p>Alfa Romeo control unit</p> <p>GRN-WHT• G1 D 8</p>	<p>N22 A</p>



**DOOR OPEN INDICATOR LAMPS AND GROUND ILLUMINATION LAMPS  
INOPERATIVE**
**TEST A**













TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> In case also the trunk dome is inoperative, replace the ground illumination fuse <b>F5</b> in auxiliary fuse box <b>G2</b>, and/or repair wiring between pin 2 of connector <b>G16</b> and auxiliary fuse box <b>G2</b> (RED-BLK wire).</p>			
<b>A1</b>	<b>FUSE CHECK</b>		
<ul style="list-style-type: none"> <li>- Check trunk relay <b>F6</b> in auxiliary fuse box <b>G2</b> for integrity</li> </ul>		OK ► <del>OK</del> ►	Carry-out step <b>A2</b>  Replace fuse <b>F6</b>
<b>A2</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 12V between pin 3E of fuse box <b>G1</b> and ground</li> </ul>		OK ► <del>OK</del> ►	Carry-out step <b>A4</b>  Carry-out step <b>A3</b>
<b>A3</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 12V between pin 1 of connector <b>G16</b> and ground</li> </ul>		OK ► <del>OK</del> ►	Repair wiring between pin 1 of connector <b>G16</b> and pin 3E of fuse box <b>G1</b>  Repair wiring between pin 1 of connector <b>G16</b> and auxiliary fuse box <b>G2</b> (WHT-RED wire)

(Cont.d)



DOOR OPEN INDICATOR LAMPS AND GROUND ILLUMINATION LAMPS  
INOPERATIVE

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A4</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 10D of fuse box G1	 	Carry-out step A6
		 	Carry-out step A5
<b>A5</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 8A of Alfa Romeo control unit N22	 	Repair wiring between pin 8A of control unit N22 and pin 10D of fuse box G1
		 	Failure of the Alfa Romeo control unit; refer to the applicable troubleshooting procedure
<b>A6</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 12E of fuse box G1	 	Carry-out step A7
		 	Repair wiring between pin 12E of fuse box G1 and ground point G174

(Cont.d)



DOOR OPEN INDICATOR LAMPS AND GROUND ILLUMINATION LAMPS  
INOPERATIVE





## TEST A

TEST STEPS		RESULTS	REMEDY
A7	GROUNDING CHECK		
- Check for presence of 0V (zero) at pin 1P of fuse box G1		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace wiring between pin 1P of fuse box G1 and pin 5 of connector G169</p> <p>Replace relay I26</p>

End of test A

## LEFT FRONT DOOR OPEN INDICATOR LAMP AND GROUND ILLUMINATION LAMP INOPERATIVE

## TEST B

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> In case the failure also affects the right front door open warning lamp F27, the right front door open ground illumination lamp F31, the right rear door open warning lamp F29 and the right rear door open ground illumination lamp F33, repair wiring between pin 5 of connector G169 and pin 6 of connector G168.</p>			
<b>B1</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 3 of connector G168 and ground		 	<p>Carry-out step B2</p> <p>Repair wiring between pin 2 of connector G16 and pin 3 of connector G168</p>
<b>B2</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 1 of connector G161		 	<p>Repair wiring between pin 3 of connector G168 and pin 2 of connector G161</p> <p>Repair wiring between pin 6 of connector G168 and pin 1 of connector G161</p>

End of test B





<b>LEFT FRONT DOOR OPEN INDICATOR LAMP INOPERATIVE</b>	<b>TEST C</b>
--	---------------

TEST STEPS		RESULTS	REMEDY
<b>C1</b>	<b>LAMP CHECK</b>		
- Check left front door open warning lamp F28 for integrity		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div>	Carry-out <b>step C2</b>
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>○ OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Replace lamp F28
<b>C2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between terminal of lamp F28 (RED-BLK wire) and ground		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between pin 1 of connector G161 and lamp F28 (WHT wire)
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>○ OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between pin 2 of connector G161 and lamp F28 (RED-BLK wire)

End of test C

## LEFT FRONT DOOR GROUND ILLUMINATION LAMP INOPERATIVE







## TEST D

TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>LAMP CHECK</b>		
- Check left front door open ground illumination lamp F32 for integrity		 ►  ►	Carry-out step D2  Replace lamp F32
<b>D2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between terminal of lamp F32 (RED-BLK wire) and ground		 ►  ►	Repair wiring between pin 1 of connector G161 and lamp F32 (WHT wire)  Repair wiring between pin 2 of connector G161 and lamp F32 (RED-BLK wire)

End of test D

## RIGHT FRONT DOOR OPEN INDICATOR LAMP AND GROUND ILLUMINATION









TEST E

TEST STEPS		RESULTS	REMEDY
<b>E1</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 3 of connector G166 and ground		 ►  ►	Carry-out step E2  Repair wiring between pin 2 of connector G16 and pin 3 of connector G166
<b>E2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2 of connector G160 and ground		 ►  ►	Carry-out step E3  Repair wiring between pin 2 of connector G160 and pin 3 of connector G166
<b>E3</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 6 of connector G166		 ►  ►	Repair wiring between pin 1 of connector G160 and pin 6 of connector G166  Repair wiring between pin 6 of connector G166 and pin 9 of connector G167

End of test E

## RIGHT FRONT DOOR OPEN INDICATOR LAMP INOPERATIVE





## TEST F

TEST STEPS		RESULTS	REMEDY
<b>F1</b>	<b>LAMP CHECK</b>		
- Check right front door open warning lamp F27 for integrity		 	Carry-out step F2
		 	Replace lamp F27
<b>F2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between terminal of lamp F27 (RED-BLK wire) and ground		 	Repair wiring between pin 1 of connector G160 and lamp F27 (WHT wire)
		 	Repair wiring between pin 2 of connector G160 and lamp F27 (RED-BLK wire)

End of test F

## RIGHT FRONT DOOR GROUND ILLUMINATION LAMP INOPERATIVE







TEST G

TEST STEPS		RESULTS	REMEDY
<b>G1</b>	<b>LAMP CHECK</b>		
- Check right front door open ground illumination lamp <b>F31</b> for integrity		 ►  ►	Carry-out step <b>G2</b>  Replace lamp <b>F31</b>
<b>G2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between terminal of lamp <b>F31</b> (RED-BLK wire) and ground		 ►  ►	Repair wiring between <b>pin 1 of connector G160 and lamp F31 (WHT wire)</b>  Repair wiring between <b>pin 2 of connector G160 and lamp F31 (RED-BLK wire)</b>

End of test G

## LEFT REAR DOOR OPEN INDICATOR LAMP AND GROUND ILLUMINATION INOPERATIVE

## TEST H

TEST STEPS		RESULTS	REMEDY
H1	VOLTAGE CHECK		
	- Check for presence of 12V between pin 4 of connector G169 and ground	 	Carry-out step H2  Repair wiring between pin 2 of connector G16 and pin 4 of connector G169
H2	VOLTAGE CHECK		
	- Check for presence of 12V between pin 1 of connector G163 and ground	 	Carry-out step H3  Repair wiring between pin 4 of connector G169, pin 20 of connector G191 and pin 1 of connector G163
H3	GROUNDING CHECK		
	- Check for presence of 0V (zero) at pin 22 of connector G191	 	Repair wiring between pin 22 of connector G191 and pin 2 of connector G163  Repair wiring between pin 5 of connector G169 and pin 22 of connector G191

End of test H



## LEFT REAR DOOR OPEN INDICATOR LAMP INOPERATIVE









## TEST I

TEST STEPS		RESULTS	REMEDY
11	LAMP CHECK		
	- Check left rear door open warning lamp F30 for integrity	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Carry-out step 12</p> <p>Replace lamp F30</p>
12	VOLTAGE CHECK		
	- Check for presence of 12V between terminal of lamp F30 (RED-BLK wire) and ground	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 2 of connector G163 and lamp F30 (WHT wire)</p> <p>Repair wiring between pin 1 of connector G163 and lamp F30 (RED-BLK wire)</p>

End of test I







## LEFT FRONT DOOR GROUND ILLUMINATION LAMP INOPERATIVE

## TEST J

TEST STEPS		RESULTS	REMEDY
<b>J1</b>	<b>LAMP CHECK</b>		
	- Check left rear door open ground illumination lamp <b>F34</b> for integrity	   	Carry-out step <b>J2</b>  Replace lamp <b>F34</b>
<b>J2</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between terminal of lamp <b>F34</b> (RED-BLK wire) and ground	   	Repair wiring between <b>pin 2 of connector G163 and lamp F34 (WHT wire)</b>  Repair wiring between <b>pin 1 of connector G163 and lamp F34 (RED-BLK wire)</b>

End of test J





<b>RIGHT REAR DOOR OPEN INDICATOR LAMP AND GROUND ILLUMINATION LAMP INOPERATIVE</b>	<b>TEST K</b>
---	---------------

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> In case the failure also affects the right front door open warning lamp F27 and the right front door open ground illumination lamp F31, repair wiring between pin 9 of connector G167 and pin 6 of connector G168.</p>			
<b>K1</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 12V between pin 20 of connector G197 and ground</li> </ul>		 ►  ►	<p>Carry-out step K2</p> <p>Repair wiring between pin 20 of connector G197 and pin 8 of connector G167</p>
<b>K2</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 12V between pin 1 of connector G162 and ground</li> </ul>		 ►  ►	<p>Carry-out step K3</p> <p>Repair wiring between pin 1 of connector G162 and pin 20 of connector G197</p>
<b>K3</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 0V (zero) at pin 22 of connector G197</li> </ul>		 ►  ►	<p>Repair wiring between pin 2 of connector G162 and pin 22 of connector G197</p> <p>Repair wiring between pin 22 of connector G197 and pin 9 of connector G167</p>

End of test K

**RIGHT REAR DOOR OPEN INDICATOR LAMP INOPERATIVE**





**TEST L**

TEST STEPS		RESULTS	REMEDY
<b>L1</b>	<b>LAMP CHECK</b>		
- Check right rear door open warning lamp F29 for integrity		 ►  ►	Carry-out step L2  Replace lamp F29
<b>L2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between terminal of lamp F29 (RED-BLK wire) and ground		 ►  ►	Repair wiring between pin 2 of connector G162 and lamp F29 (WHT wire)  Repair wiring between pin 1 of connector G162 and lamp F29 (RED-BLK wire)

End of test L

## RIGHT REAR DOOR GROUND ILLUMINATION LAMP INOPERATIVE

## TEST M

TEST STEPS		RESULTS	REMEDY
<b>M1</b>	<b>LAMP CHECK</b>		
- Check right rear door open ground illumination lamp F33 for integrity		 	Carry-out step M2  Replace lamp F33
<b>M2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between terminal of lamp F33 (RED-BLK wire) and ground		 	Repair wiring between pin 2 of connector G162 and lamp F33 (WHT wire)  Repair wiring between pin 1 of connector G162 and lamp F33 (RED-BLK wire)

End of test M

## TRUNK DOME INOPERATIVE







TEST N

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> In case the failure also affects the door open warning lamps, and the ground illumination lamps replace the ground illumination fuse <b>F5</b> in the auxiliary fuse box <b>G2</b>, and/or repair wiring between pin 2 of connector <b>G16</b> and auxiliary fuse box <b>G2</b> (RED-BLK wire).</p>			
<b>N1</b>	<b>LAMPS ACTUATION CHECK</b>		
<ul style="list-style-type: none"> <li>Open right rear door and check that right rear door open warning lamp <b>F29</b> and ground illumination lamp <b>F33</b> illuminate</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out <b>step N2</b></p> <p>Repair wiring between pin 2 of connector <b>G16</b> and pin 8 of connector <b>G167</b></p>
<b>N2</b>	<b>LAMP CHECK</b>		
<ul style="list-style-type: none"> <li>Check trunk dome lamp <b>F5</b> for integrity</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out <b>step N3</b></p> <p>Replace lamp <b>F5</b></p>
<b>N3</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>With trunk lid open, check for presence of 0V (zero) at terminal of trunk illumination switch <b>H24</b> (BLK wire)</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pin 5 of connector <b>G198</b> and switch <b>H24</b> (GRY-BLK wire)</p> <p>Carry-out <b>step N4</b></p>

(Cont.d)

## TRUNK DOME INOPERATIVE

TEST N

TEST STEPS		RESULTS	REMEDY
<b>N4</b>	<b>SWITCH CHECK</b>		
- Check that trunk illumination switch <b>H24</b> is operational by simulating trunk lid closure, and checking that circuit is open between terminals of switch <b>H24</b>		 	Carry-out <b>step N5</b>  Replace <b>switch H24</b>
<b>N5</b>	<b>GROUNDING CHECK</b>		
- With trunk lid open, check for presence of 0V (zero) at pin 5 of connector <b>G198</b>		 	Repair wiring between <b>pin 5 of connector G198</b> and rear cargo lamp <b>F5</b>  Carry-out <b>step N6</b>
<b>N6</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 2 of connector <b>G198</b>		 	Repair wiring between <b>pin 2 of connector G198</b> and <b>switch H24 (BLK wire)</b>  Repair wiring between <b>pin 2 of connector G198</b> and ground point <b>G186</b>

End of test N

# LAMPS - - LOW BEAM AND HIGH BEAM

<https://www.automotive-manuals.net/>





## GENERAL

The low beam and high beam lamps can be turned on only if the position lamps have been previously turned on (refer to the position lamps circuit for further details).

The low beam and high beam lamps are controlled by the PARKING/FLASH/LOW BEAM/HIGH BEAM switch **B4**. The system is protected by four fuses in the fuse box **G1**, as follows:

- Fuse **F3** (10A) R.H. LOW BEAM.
- Fuse **F4** (10A) L.H. LOW BEAM AND WARN. LAMP.
- Fuse **F5** (10A) R.H. HIGH BEAM AND WARN. LAMP.
- Fuse **F6** (10A) L.H. HIGH BEAM.

## OPERATIONAL DESCRIPTION

12V from the battery are applied to high beam lamps relay **I50** and to multiple switch **B4** (pin 2A).

The multiple switch **B4** controls illumination of various lamps, as determined by the setting of the switch.

With the position lamps on, and the low/high beam selector set to low beam, 12V are applied to fuses **F3** and **F4**

through contacts of switch **B4**. Power supply from fuses **F3** and **F4** is also applied to the low beam indicator lamp on the instrument panel, and to the coil of low beam lamps relays **I49**.

12V from the battery are applied to the head lamp units **E23** and **E24** through the relay contacts, and the low beam lamps are turned on.

### NOTE

The low beam lamps and circuit are also protected by the 10A fuses of the low beam lamps relays.

Pushing the low/high beam selector in the "high beam" position, 12V are applied to coil of high beam lamps relay **I50** through contacts of switch **B4**.

12V from the battery are applied to the head lamp units **E23** and **E24** through the relay **I50** contacts and fuses **F5** and **F6**, and the high beam lamps are turned on.











Fuse **F5** also energizes the high beam indicator lamp on the instrument panel.

The multiple switch **B4** is provided with additional momentary position contacts.

Pulling the low/high beam selector lever the flash contacts close, and momentarily energize the high beam lamp relay **I50**, with consequent flashing of the relevant lamps.


TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT											
	F3 FUSE	F4 FUSE	F5 FUSE	F6 FUSE	149 RELAY FUSE SX	149 RELAY FUSE DX	E23 FRONT RIGHT OPTICAL UNIT	E24 FRONT LEFT OPTICAL UNIT	B4 MULTIPLE SWITCH	149 RELAY SX	149 RELAY DX	150 RELAY
BOTH LOW BEAM LAMPS INOPERATIVE							•	•	•			
LEFT LOW BEAM LAMP INOPERATIVE		•			•			•		•		
RIGHT LOW BEAM LAMP INOPERATIVE	•					•	•				•	
BOTH HIGH BEAM LAMPS INOPERATIVE								•				•
LEFT HIGH BEAM LAMP INOPERATIVE				•				•				
RIGHT HIGH BEAM LAMP INOPERATIVE			•				•					

<p>Parking/Flash/Low beam/High beam switch</p>	<p>(B4) A</p>	<p>Parking/Flash/Low beam/High beam switch</p>	<p>(B4) D</p>
			
<p>Instrument panel</p>	<p>(C10) A</p>	<p>Instrument panel</p>	<p>(C10) C</p>
			
<p>Front head lamp-right</p>	<p>(E23) B</p>	<p>Front head lamp-left</p>	<p>(E24) B</p>
			
<p>Fuse box</p>	<p>(G1) C</p>	<p>Fuse box</p>	<p>(G1) G</p>
			
<p>Fuse box</p>	<p>(G1) H</p>	<p>Fuse box</p>	<p>(G1) I</p>
			

(Cont.d)

<p>Fuse box</p>	<p><b>G1</b> <b>N</b></p>	<p>Fuse box</p>	<p><b>G1</b> <b>O</b></p>
<p>Engine compartment left side ground connection</p>	<p><b>G53b</b></p>	<p>Engine compartment right side ground connection</p>	<p><b>G53a</b></p>
<p>Connector, circuit board to engine compartment left side wiring</p>	<p><b>G150</b></p>	<p>Connector, circuit board to engine compartment right side wiring</p>	<p><b>G149</b></p>
<p>Connector, circuit board to engine compartment left side wiring</p>	<p><b>G150</b></p>	<p>Steering wheel column support ground</p>	<p><b>G174</b></p>
<p>Horn relay</p>	<p><b>I3</b></p>	<p>Low beam lamps relay (left)</p>	<p><b>149</b></p>
<p>Low beam lamps relay (right)</p>	<p><b>149</b></p>	<p>High beam lamps relay</p>	<p><b>150</b></p>



<b>BOTH LOW BEAM LAMPS INOPERATIVE</b>	<b>TEST A</b>
--	---------------









TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>LAMPS CHECK</b>		
	- Check low beam lamps in head lamps <b>E23</b> and <b>E24</b> for integrity	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 2px 5px;">OK</span> <span style="margin: 0 10px;">▶</span> </div> <div style="display: flex; align-items: center;"> <span style="border: 1px solid black; border-radius: 50%; padding: 2px 5px; opacity: 0.5;"><del>OK</del></span> <span style="margin: 0 10px;">▶</span> </div> </div>	<p>Carry-out <b>step A2</b></p> <p>Replace lamps <b>E23</b> and/or <b>E24</b></p>
<b>A2</b>	<b>VOLTAGE CHECK</b>		
	- With the ignition switch to "run" and low beam lamps selected, check for presence of 12V between pin 4D of multiple switch <b>B4</b> and ground	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 2px 5px;">OK</span> <span style="margin: 0 10px;">▶</span> </div> <div style="display: flex; align-items: center;"> <span style="border: 1px solid black; border-radius: 50%; padding: 2px 5px; opacity: 0.5;"><del>OK</del></span> <span style="margin: 0 10px;">▶</span> </div> </div>	<p>Repair wiring between pin <b>4D</b> of multiple switch <b>B4</b> and pin <b>6G</b> of fuse box <b>G1</b></p> <p>Carry-out <b>step A3</b></p>
<b>A3</b>	<b>MULTIPLE SWITCH CHECK</b>		
	- With low beam lamps selected check for continuity between pins 4D and 2A of multiple switch <b>B4</b>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 2px 5px;">OK</span> <span style="margin: 0 10px;">▶</span> </div> <div style="display: flex; align-items: center;"> <span style="border: 1px solid black; border-radius: 50%; padding: 2px 5px; opacity: 0.5;"><del>OK</del></span> <span style="margin: 0 10px;">▶</span> </div> </div>	<p>Carry-out <b>step A4</b></p> <p>Replace multiple switch <b>B4</b></p>
<b>A4</b>	<b>VOLTAGE CHECK</b>		
	- With the ignition key set to "run", check for presence of 12V between pin 4O or fuse box <b>G1</b> and ground	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 2px 5px;">OK</span> <span style="margin: 0 10px;">▶</span> </div> <div style="display: flex; align-items: center;"> <span style="border: 1px solid black; border-radius: 50%; padding: 2px 5px; opacity: 0.5;"><del>OK</del></span> <span style="margin: 0 10px;">▶</span> </div> </div>	<p>Repair wiring between pin <b>2A</b> of multiple switch <b>B4</b> and pin <b>4O</b> of fuse box <b>G1</b></p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2</p>

End of test A



## LEFT LOW BEAM LAMP INOPERATIVE

## TEST B









TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Before carrying-out any troubleshooting procedure, check the integrity of warning lamp on instrument panel by pressing the test button.</p>			
<b>B1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>F4</b> in fuse box <b>G1</b> for integrity		 ►  ►	Carry-out <b>step B2</b>  Replace fuse <b>F4</b>
<b>B2</b>	<b>RELAY FUSE CHECK</b>		
- Check fuse of low beam lamps relay <b>I49</b> fuse for integrity		 ►  ►	Carry-out <b>step B3</b>  Replace relay <b>I49</b> fuse
<b>B3</b>	<b>INDICATOR LAMP CHECK</b>		
- Check if low beam indicator lamp on instrument panel is illuminated		 ►  ►	Carry-out <b>step B5</b>  Carry-out <b>step B4</b>
<b>B4</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin <b>9C</b> of instrument panel and ground		 ►  ►	Replace low beam indicator lamp on instrument panel <b>C10</b>  Repair wiring between pin <b>4H</b> of fuse box <b>G1</b> and pin <b>9C</b> of <b>C10</b>

(Cont.d)



## LEFT LOW BEAM LAMP INOPERATIVE

## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B5</b>	<b>LAMP CHECK</b>		
- Check low/high beam lamp in head lamp E24 for integrity		 ►  ►	Carry-out step B6  Replace lamp E24
<b>B6</b>	<b>HIGH BEAM LAMPS CHECK</b>		
- With the ignition key set to "run" turn on and check if the high beam lamp in head lamp E24 is operational		 ►  ►	Carry-out step B7  Repair wiring between pin 3B of head lamp E24 and ground point G53b
<b>B7</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin 14 of connector G150 and ground		 ►  ►	Carry-out step B8  Repair wiring between pin 14 of connector G150 and pin 4H of fuse box G1
<b>B8</b>	<b>RELAY CHECK</b>		
- Check low beam lamps relay I49 for proper operation		 ►  ►	Carry-out step B9  Replace relay I49

(Cont.d)

## LEFT LOW BEAM LAMP INOPERATIVE

















## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B9</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>With the ignition key set to "run" check for presence of 12V between pins 85 and 86 of low beam lamps relay I49 when switch B4 is engaged</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step B10</p> <p>Repair wiring between pin 86 of relay I49 and pin 14 of connector G150, and between pin 85 of relay I49 and ground point G53b</p>
<b>B10</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>Check for presence of 12V between pin 30 of relay I49 and ground</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pin 2B of head lamp E24 and pin 87 of relay I49</p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2</p>

End of test B

## RIGHT LOW BEAM LAMP INOPERATIVE

## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>F3</b> in fuse box <b>G1</b> for integrity		 	Carry-out <b>step C2</b>
		 	Replace fuse <b>F3</b>
<b>C2</b>	<b>RELAY FUSE CHECK</b>		
- Check fuse of low beam lamps relay <b>I49</b> for integrity		 	Carry-out <b>step C3</b>
		 	Replace relay <b>I49</b> fuse
<b>C3</b>	<b>LAMP CHECK</b>		
- Check low/high beam lamp in head lamp <b>E23</b> for integrity		 	Carry-out <b>step C4</b>
		 	Replace lamp <b>E23</b>
<b>C4</b>	<b>HIGH BEAM LAMPS CHECK</b>		
- Turn on and check if the high beam lamp in head lamp <b>E23</b> is operational		 	Carry-out <b>step C5</b>
		 	Repair wiring between pin <b>3B</b> of head lamp <b>E23</b> and ground point <b>G53a</b>

(Cont.d)

## RIGHT LOW BEAM LAMP INOPERATIVE

## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C5</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>With the ignition key set to "run", switch to "run" and low beam selected check for presence of 12V between pin 14 of connector <b>G149</b> and ground</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out <b>step C6</b></p> <p>Repair wiring between pin 14 of connector <b>G149</b> and pin 31 of fuse box <b>G1</b></p>
<b>C6</b>	<b>RELAY CHECK</b>		
<ul style="list-style-type: none"> <li>Check low beam lamps relay <b>I49</b> for proper operation</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out <b>step C7</b></p> <p>Replace relay <b>I49</b></p>
<b>C7</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>With the ignition key set to "run", switch to "run" and low beam selected check for presence of 12V between pins 85 and 86 of low beam lamps relay <b>I49</b></li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out <b>step C8</b></p> <p>Repair wiring between pin 86 of relay <b>I49</b> and pin 14 of connector <b>G149</b>, and between pin 85 of relay <b>I49</b> and ground point <b>G53a</b></p>

(Cont.d)









RIGHT LOW BEAM LAMP INOPERATIVE

TEST C

TEST STEPS		RESULTS	REMEDY
C8	VOLTAGE CHECK		
- Check for presence of 12V between pin 30 of relay I49 and ground		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 2 of head lamp E23 and pin 87 of relay I49</p> <p>Failure of power distribution circuit, refer to the relevant circuit of sheet 2 of 2</p>

End of test C





<b>BOTH HIGH BEAM LAMPS INOPERATIVE</b>	<b>TEST D</b>
---	---------------

TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>With the ignition key set to "run" and with high beam lamps selected check for presence of 12V between pin 1A of multiple switch B4 and ground</li> </ul>		OK  <del>OK</del> 	Carry-out step D3  Carry-out step D2
<b>D2</b>	<b>MULTIPLE SWITCH CHECK</b>		
<ul style="list-style-type: none"> <li>With high beam lamp selected check for continuity between pins 2A and 1A of multiple switch B4</li> </ul>		OK  <del>OK</del> 	Carry-out step D3  Replace multiple switch B4
<b>D3</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>With the ignition key set to "run" and high beam lamps selected check for presence of 12V between pins 85 and 86 of high beam lamps relay I50</li> </ul>		OK  <del>OK</del> 	Carry-out step D4  Repair wiring between pin 86 of relay I50 and pin 1A of multiple switch B4, and between pin 85 of relay I50 and ground point G174
<b>D4</b>	<b>RELAY CHECK</b>		
<ul style="list-style-type: none"> <li>Check high beam lamps relay I50 for proper operation</li> </ul>		OK  <del>OK</del> 	Carry-out step D5  Replace relay I50

(Cont.d)

BOTH HIGH BEAM LAMPS INOPERATIVE

TEST D

TEST STEPS		RESULTS	REMEDY
D5	VOLTAGE CHECK		
- Check for presence of 12V between pin 30 of relay I50 and ground			Repair wiring between pin 87 of relay I50 and pin 7G of fuse box G1
			Carry-out step D6
D6	VOLTAGE CHECK		
- Check for presence of 12V between pin 2N of fuse box G1 and ground			Repair wiring between pin 30 of relay I50 and pin 2N of fuse box
			Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2

End of test D

<b>LEFT HIGH BEAM LAMP INOPERATIVE</b>	<b>TEST E</b>
--	---------------

















TEST STEPS		RESULTS	REMEDY
<b>E1</b>	<b>FUSE CHECK</b>		
- Check fuse F6 in fuse box G1 for integrity		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out <b>step E2</b>  Replace fuse F6
<b>E2</b>	<b>LAMP CHECK</b>		
- Check high beam lamp in head lamp E24 for integrity		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out <b>step E3</b>  Replace lamp E24
<b>E3</b>	<b>LOW BEAM LAMPS CHECK</b>		
- Turn and check if the low beam lamp in head lamp E24 is operational		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out <b>step E4</b>  Repair wiring between <b>pin 3B of head lamp E24 and ground point G53b</b>
<b>E4</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" and with high beam lamps selected check for presence of 12V between pin 15 of connector G150 and ground		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between <b>pin 15 of connector G150 and pin 1B of head lamp E24</b>  Repair wiring between <b>pin 15 of connector G150 and pin 5H of fuse box G1</b>

End of test E



## RIGHT HIGH BEAM LAMP INOPERATIVE

## TEST F

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Before carrying-out any troubleshooting procedure, check the integrity of warning lamp on instrument panel by pressing the test button.</p>			
<b>F1</b>	<b>FUSE CHECK</b>		
- Check fuse F5 in fuse box G1 for integrity		 	Carry-out step F2
		 	Replace fuse F5
<b>F2</b>	<b>INDICATOR LAMP CHECK</b>		
- Check illumination of high beam indicator lamp on instrument panel		 	Carry-out step F6
		 	Carry-out step F3
<b>F3</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2A of instrument panel and ground		 	Replace high beam Indicator lamp on Instrument panel C10
		 	Carry-out step F4
<b>F4</b>	<b>LAMP CHECK</b>		
- Check high beam lamp in head lamp E23 for integrity		 	Carry-out step F5
		 	Replace lamp E23

(Cont.d)

RIGHT HIGH BEAM LAMP INOPERATIVE	TEST F
----------------------------------	--------


TEST STEPS		RESULTS	REMEDY
<b>F5</b>	<b>LOW BEAM LAMPS CHECK</b>		
- Turn on and check if the low beam lamp in head lamp E23 is operational		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Carry-out step F6</p> <p>Repair wiring between pin 3B of head lamp E23 and ground point G53a</p>
<b>F6</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" and with high beam lamps selected check for presence of 12V between pin 15 of connector G149 and ground		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 15 of connector G149 and pin 1B of head lamp E23</p> <p>Repair wiring between pin 15 of connector G149 and pin 8I of fuse box G1</p>

End of test F

# LAMPS - - MISCELLANEOUS DOME

LAMPS - - MISCELLANEOUS DOME (WITHOUT  
SUN ROOF) ..... page 433

LAMPS - - MISCELLANEOUS DOME (WITH  
SUN ROOF) ..... page 466



## GENERAL

### NOTA

This subject refers to vehicles without sun roof. Should this optional be installed we suggest the user to consult the final section which includes all technical information concerning different dome lamps for vehicles equipped with sun roof.

The vehicle is equipped of timed interior lamps whose illumination is controlled by any one of the four doors; in this way, access to the vehicle is made easy, even in bad light conditions.

When a door is opened, the center dome lamp, both dome lamps, on rear right and left posts, and the fuse box illuminate automatically.

For better comfort, the above lamps remain on for a few seconds after the door has been closed.

The rear post domes and the dome lamp control switch are equipped with spot that are switched on by their relevant switch.

Some courtesy lamps are installed on the vehicle to illuminate the controls; those lamps illuminate upon activation of position lamps:

- glovebox lamp, switched on by opening the glovebox lid.
- dome lamp control switch and rear post domes, switched on automatically upon activation of position lamps.
- courtesy mirror on the sun visor, switched on by its own push button.

The system is protected by three fuses, as follows:

- fuse F21 (15A) DOME LAMP/GLOVEBOX LAMP in fuse box G1.
- fuse F5 (10A) DOME LAMP in auxiliary fuse box G2.
- fuse F6 (7.5A) DOME LAMP RELAY in the auxiliary fuse box G2.

## OPERATIONAL DESCRIPTION

### Lamps actuation by the relevant pushbutton.

Battery voltage (12V) always present is sent to the two spot on the dome lamp with cabin lighting control switch F35 through fuse F21 of fuse box G1. In the same way, 12V through fuse F5 of auxiliary fuse box G2 is sent to dome lamp control switches F36 and F37 on the right and left rear post. Pushing the pushbutton, the relevant spot illuminates.

### Time lighting upon door opening.

Opening any of the doors, the Alfa Romeo Control unit N22 sets and maintains for some seconds pins 8A and 9A to a low logic level thus providing a ground path to dome lamp relay I26 on the fuse box G1 and to dome lamp relay I26. Both relays are always connected to a positive voltage through fuse F6 in the auxiliary fuse box G2, thus they are held energized only for the time controlled by the control unit N22. The dome lamp relay I26, once energized, transfers a ground connection to dome lamp with cabin lighting control switch F35 to right and left feet illuminations F23 and F24, to dome lamp control switch on left rear post F37 and to fuse box lamp F7, thus lighting them all. The dome lamp relay I26 in the fuse box G1, when energized, transfers a ground to dome lamp control switch on right rear post F36, thus lighting it.













### Lighting monitored by the position lamps.

The wiring diagram shows the path of the lines that control the courtesy mirror illumination lamps, whose lighting is depending on position lamps.

With position lamp turned on, the dome lamp with cabin lighting control switch F35, rear left and right dome lamps F36 and F37 are illuminated. From the dome lamp F35 it is possible to control lighting of rear left and right dome lamps F36 and F37. When the position lamps are turned on, it is possible, by the appropriate pushbutton, to turn on the courtesy mirror illumination lamp F25; furthermore, opening the glovebox, the switch H25 closes, thus turning on the lamp within the box it self.









## TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT																
	F5	F6	F21	F7	F9	F23	F24	F25	F35/36/37	F35/36/37	F35/36/37	F35/36/37	F35/36/37	H25	I26	I26	I26
	FUSE	FUSE	TRUNK DOME	FUSE LAMP BULB	BULB	DOME LAMP BULB	DOME LAMP BULB	DOME LAMP	DOME PUSHB.	SPOT PUSHB.	CONTR. LAMP	SPOT LAMP	DOME LAMP	SWITCH	RELAY	RELAY (G1)	CONTROL UNIT
DOME MAP LAMP CONTROL SWITCH INOPERATIVE (PUSHBUTTON ACTUATED)			•							•		•					
LEFT REAR POST DOME SPOT INOPERATIVE (PUSHBUTTON ACTUATED)	•									•		•					
RIGHT REAR POST DOME SPOT INOPERATIVE (PUSHBUTTON ACTUATED)	•									•		•					
LEFT REAR POST DOME LAMP INOPERATIVE (DOME LAMP CONTROL SWITCH PUSHBUTTON ACTUATED)	•								•				•				
RIGHT REAR POST DOME LAMP INOPERATIVE (DOME LAMP CONTROL SWITCH PUSHBUTTON ACTUATED)	•								•				•				
GLOVEBOX LAMP INOPERATIVE			•		•									•			
MALFUNCTION OF TIMED LAMPS		•		•		•	•						•		•	•	•
CONTROLS LIGHTING INOPERATIVE (POSITION LAMPS ON)								•			•						

<p>Fuse box lamp</p>	<p>F7</p>	<p>Glovebox illumination lamp</p>	<p>F9</p>
			
<p>Feet illumination lamp, interior, right side</p>	<p>F23</p>	<p>Feet illumination lamp, interior, left side</p>	<p>F24</p>
			
<p>Courtesy mirror illumination lamp</p>	<p>F25</p>	<p>Dome lamp with cabin lighting control switch</p>	<p>F35</p>
			
<p>Dome lamp, control switch on right rear post</p>	<p>F36</p>	<p>Dome lamp, control switch on right rear post</p>	<p>F36</p>
<p><b>BASE AND L ONLY</b></p> 		<p><b>S ONLY</b></p> 	
<p>Dome lamp, control switch on left rear post</p>	<p>F37</p>	<p>Fuse box</p>	<p>G1 D</p>
			
<p>Fuse box</p>	<p>G1 E</p>	<p>Fuse box</p>	<p>G1 N</p>
			









(Cont.d)




<p>Fuse box <span style="float: right;">(G1) (O)</span></p>	<p>Fuse box <span style="float: right;">(G1) (Q)</span></p>
	
<p>Fuse box <span style="float: right;">(G1) (T)</span></p>	<p>Auxiliary fuse box <span style="float: right;">(G2)</span></p>
	
<p>Six pin connector circuit board to doors wiring <span style="float: right;">(G16)</span></p>	<p>Connector, front doors to right rear wiring <span style="float: right;">(G167)</span></p>
	
<p>Connector, front door to left rear wiring <span style="float: right;">(G169)</span></p>	<p>Connector, circuit board to right rear wiring <span style="float: right;">(G170)</span></p>
	

(Cont.d)



















<p>Connector, circuit board to left rear wiring</p>	<p><b>G171</b></p>	<p>Steering wheel column support ground</p>	<p><b>G174</b></p>	
				
<p>Connector, left rear wiring to dome lamp wiring</p>		<p>Trunk left side ground</p>	<p><b>G185</b></p>	
				
<p>Connector, provision for radio antenna</p>		<p>Trunk right side ground</p>	<p><b>G186</b></p>	
				
<p>Dome lamp relay</p>		<p><b>I26</b></p>	<p>Glovebox illumination switch</p>	<p><b>H25</b></p>
				



## DOME MAP LAMP CONTROL SWITCH INOPERATIVE (PUSHBUTTON ACTUATED)

TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>F21</b> on fuse box <b>G1</b> for integrity		 	Carry-out <b>step A2</b>
		 	Replace fuse <b>F21</b>
<b>A2</b>	<b>MAP LAMP CHECK</b>		
- Check that both spot of dome lamp <b>F35</b> and dome lamp <b>F35</b> can not be turned on		 	Repair wiring between ground point <b>G176</b> and pin 2 of dome lamp <b>F35</b>
		 	Carry-out <b>step A3</b>
<b>A3</b>	<b>TIMED LAMP CHECK</b>		
- Check that the timed lamp of dome lamp <b>F35</b> is inoperative		 	Carry-out <b>step A4</b>
		 	Carry-out <b>step A7</b>
<b>A4</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 6 of connector <b>G171</b> and ground		 	Carry-out <b>step A6</b>
		 	Carry-out <b>step A5</b>

(Cont.d)

DOME MAP LAMP CONTROL SWITCH INOPERATIVE (PUSHBUTTON AC-  
TUATED)









TEST A

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2N of fuse box G1 and ground		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 6 of connector G171 and pin 20 of fuse box G1</p> <p>Failure of power distribution circuit, refer to the relevant circuit of sheet 2 of 2</p>
<b>A6</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 6 of connector G179 and ground		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 6 of G179 and pin 5 of dome lamps F35</p> <p>Repair wiring between pin 6 of connector G17 9 and pin 6 of connector G171</p>
<b>A7</b>	<b>LH MAP LAMP INOPERATIVE CHECK</b>		
- Check that only the LH spot of dome lamp F35 does not illuminate		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Carry-out step A8</p> <p>Carry-out step A9</p>

(Cont.d)

DOME MAP LAMP CONTROL SWITCH INOPERATIVE (PUSHBUTTON AC-  
TUATED)









TEST A

TEST STEPS		RESULTS	REMEDY
<b>A8</b>	<b>BULB CHECK</b>		
	- Check for integrity of LH spot bulb of dome lamp F35	   	Replace pushbutton of LH spot on dome lamp F35  Replace bulb
<b>A9</b>	<b>BULB CHECK</b>		
	- Check for integrity of RH spot bulb of dome lamp F35	   	Replace pushbutton of RH spot on dome lamp F35  Replace bulb

End of test A

## LEFT REAR POST DOME SPOT INOPERATIVE (PUSHBUTTON ACTUATED)







## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>FUSE CHECK</b>		
	- Check for integrity of fuse F5 in auxiliary fuse box G2	 ►  ►	Carry-out <b>step B2</b>  Replace fuse F5
<b>B2</b>	<b>REAR RH SPOT CHECK</b>		
	- Check illumination of rear RH post dome lamp	 ►  ►	Carry-out <b>step B3</b>  Carry-out <b>step B5</b>
<b>B3</b>	<b>CONTROLS LIGHTINGS CHECK</b>		
	- Switch on position lamps and check for lighting of controls on rear LH post dome lamp	 ►  ►	Carry-out <b>step B4</b>  Repair wiring between <b>pin 1 of dome lamp F37</b> and <b>ground point G185</b>
<b>B4</b>	<b>BULB CHECK</b>		
	- Check for integrity of bulb in rear LH post dome spot	 ►  ►	Replace <b>pushbutton on dome lamp F37</b>  Replace <b>bulb on dome lamp F37</b>

(Cont.d)

LEFT REAR POST DOME SPOT INOPERATIVE (PUSHBUTTON ACTUATED)

TEST B

TEST STEPS		RESULTS	REMEDY
<b>B5</b>	VOLTAGE CHECK		
- Check for presence of 12V between pin 4 of connector <b>G169</b> and ground			Carry-out step B7
			Carry-out step B6
<b>B6</b>	VOLTAGE CHECK		
- Check for presence of 12V between pin 2 of connector <b>G16</b> and ground			Repair wiring between pin 4 of connector <b>G169</b> and pin 2 of connector <b>G16</b>
			Repair wiring between pin 2 of connector <b>G16</b> and fuse box <b>G2</b> (RED-BLK wire)
<b>B7</b>	VOLTAGE CHECK		
- Check for presence of 12V between pin 1 of connector <b>G193</b> and ground			Repair wiring between pin 1 of connector <b>G193</b> and pin 4 of dome lamp <b>F37</b>
			Repair wiring between pin 1 of <b>G193</b> and pin 4 of <b>G169</b>

End of test B

## RIGHT REAR POST DOME SPOT INOPERATIVE (PUSHBUTTON ACTIVATED)

## TEST C





TEST STEPS		RESULTS	REMEDY
<b>C1</b>	<b>FUSE CHECK</b>		
	- Check for integrity of fuse F5 in auxiliary fuse box G2	OK      ► <del>OK</del> ►	Carry-out step C2  Replace fuse F5
<b>C2</b>	<b>REAR LH MAP LAMP CHECK</b>		
	- Check illumination of rear LH post dome spot	OK      ► <del>OK</del> ►	Carry-out step C3  Carry-out step C5
<b>C3</b>	<b>CONTROLS LIGHTING CHECK</b>		
	- Switch on position lamps and check for lighting of controls on rear RH post dome lamp	OK      ► <del>OK</del> ►	Carry-out step C4  Repair wiring between pin 1 of dome lamp F36 and ground point G186
<b>C4</b>	<b>BULB CHECK</b>		
	- Check for integrity of bulb in rear RH post dome spot	OK      ► <del>OK</del> ►	Replace pushbutton on dome lamp F36  Replace bulb on dome lamp F36

(Cont.d)



RIGHT REAR POST DOME SPOT INOPERATIVE (PUSHBUTTON ACTUATED)

















TEST C

TEST STEPS		RESULTS	REMEDY
C5	VOLTAGE CHECK		
- Check for presence of 12V between pin 8 of connector G167 and ground			Repair wiring between pin 8 of connector G167 and pin 4 of dome F36
			Carry-out step C6
C6	VOLTAGE CHECK		
- Check for presence of 12V between pin 2 of connector G16 and ground			Repair wiring between pin 8 of connector G167 and pin 2 of connector G16
			Repair wiring between pin 2 of connector G16 and fuse box G2 (RED-BLK wire)

End of test C

## LEFT REAR POST DOME LAMP INOPERATIVE (DOME LAMP CONTROL SWITCH PUSHBUTTON ACTUATED)







## TEST D

TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>FUSE CHECK</b>		
	- Check fuse F5 in auxiliary fuse box G2 for integrity	 	Carry-out step D2
		 	Replace fuse F5
<b>D2</b>	<b>DOME SPOT CHECK</b>		
	- Check that spot lamps of dome lamp F35 can not be switched on	 	Repair wiring between ground point G176 and pin 2 of dome lamp F35
		 	Carry-out step D3
<b>D3</b>	<b>TIMED LAMPS CHECK</b>		
	- Check that opening either door, the rear LH post dome lamp illuminates for a few seconds	 	Carry-out step D4
		 	Carry-out step D6
<b>D4</b>	<b>GROUNDING CHECK</b>		
	- Check that, pushing the pushbutton on dome lamp F35, the rear LH post dome turns on, and that pin 3 of dome lamp F35 is connected to ground	 	Carry-out step D5
		 	Replace pushbutton on dome F35

(Cont.d)

LEFT REAR POST DOME LAMP INOPERATIVE (DOME LAMP CONTROL SWITCH PUSHBUTTON ACTUATED)





TEST D

TEST STEPS		RESULTS	REMEDY
<b>D5</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 5 of connector G179		 	Repair wiring between pin 5 of connector G179 and pin 5 of connector G171  Repair wiring between pin 5 of connector G179 and pin 3 of dome lamp F35
<b>D6</b>	<b>BULB CHECK</b>		
- Check bulb of rear LH post dome lamp for integrity		 	Carry-out step D7  Replace bulb
<b>D7</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 4 of connector G169 and ground		 	Carry-out step D9  Carry-out step D8

(Cont.d)









LEFT REAR POST DOME LAMP INOPERATIVE (DOME LAMP CONTROL SWITCH PUSHBUTTON ACTUATED)

TEST D

TEST STEPS		RESULTS	REMEDY
<b>D8</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2 of connector G16 and ground		 	Repair wiring between pin 4 of connector G169 and pin 2 of connector G16  Repair wiring between pin 2 of connector G16 and auxiliary fuse box G2 (RED-BLK wire)
<b>D9</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 1 of connector G193 and ground		 	Repair wiring between pin 1 of connector G193 and pin 4 of dome lamp F37  Repair wiring between pin 1 of connector G193 and pin 4 of connector G169

End of test D













**RIGHT REAR POST DOME LAMP INOPERATIVE (DOME LAMP CONTROL SWITCH PUSHBUTTON ACTUATED)**
**TEST E**

TEST STEPS.		RESULTS	REMEDY
<b>E1</b>	<b>FUSE CHECK</b>		
	- Check fuse <b>F5</b> in auxiliary fuse box <b>G2</b> for integrity		Carry-out <b>step E2</b>
			Replace fuse <b>F5</b>
<b>E2</b>	<b>CENTER DOME MAP LAMP CHECK</b>		
	- Check that both spot of dome lamp <b>F35</b> can not be switched on		Repair wiring between ground point <b>G176</b> and pin 2 of dome lamp <b>F35</b>
			Carry-out <b>step E3</b>
<b>E3</b>	<b>TIMED LAMP CHECK</b>		
	- Check that, opening either door, the rear RH post dome lamp illuminates for a few seconds		Carry-out <b>step E4</b>
			Carry-out <b>step E6</b>
<b>E4</b>	<b>GROUNDING CHECK</b>		
	- Check that, pushing the pushbutton on dome lamp <b>F35</b> , the rear RH post dome turns on and that pin 4 of dome lamp <b>F35</b> is connected to ground		Carry-out <b>step E5</b>
			Replace pushbutton on dome lamp <b>F35</b>

(Cont.d)

RIGHT REAR POST DOME LAMP INOPERATIVE (DOME LAMP CONTROL SWITCH PUSHBUTTON ACTUATED)







TEST E

TEST STEPS		RESULTS	REMEDY
<b>E5</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 2 of connector <b>G179</b>	 	Repair wiring between pin 2 of connector <b>G179</b> and pin 10 of fuse box <b>G1</b> (through pin 2 of connector <b>G171</b> )
		 	Repair wiring between pin 2 of connector <b>G179</b> and pin 4 of dome lamp <b>F35</b>
<b>E6</b>	<b>BULB CHECK</b>		
	- Check bulb in rear RH post dome for integrity	 	Carry-out step <b>E7</b>
		 	Replace bulb
<b>E7</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 2 of connector <b>G16</b> and ground	 	Carry-out step <b>E8</b>
		 	Repair wiring between pin 2 of connector <b>G16</b> and fuse box <b>G2</b> (RED-BLK wire)

(Cont.d)

RIGHT REAR POST DOME LAMP INOPERATIVE (DOME LAMP CONTROL SWITCH PUSHBUTTON ACTUATED)









TEST E

TEST STEPS		RESULTS	REMEDY
<b>E8</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 8 of connector G167 and ground		 	<p>Carry-out step E9</p> <p>Repair wiring between pin 8 of connector G167 and pin 2 of connector G16</p>
<b>E9</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 4 of dome lamp F36 and ground		 	<p>Carry-out step E10</p> <p>Repair wiring between pin 4 of dome lamp F36 and pin 8 of connector G167</p>
<b>E10</b>	<b>GROUNDING CHECK</b>		
- Check that pin 8 of connector G170 is connected to ground		 	<p>Repair wiring between pin 8 of connector G170 and pin 3 of dome lamp F36</p> <p>Repair wiring between pin 8 of connector G170 and pin 10 of fuse box G1</p>

End of test E

## GLOVEBOX LAMP INOPERATIVE







## TEST F

TEST STEPS		RESULTS	REMEDY
<b>F1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>F21</b> in fuse box <b>G1</b> for integrity		 ►  ►	Carry-out step <b>F2</b>  Replace fuse <b>F21</b>
<b>F2</b>	<b>TIMED LAMPS CHECK</b>		
- Check that, opening either door, both <b>LH</b> and <b>RH</b> lamps below instrument panel illuminate		 ►  ►	Carry-out step <b>F3</b>  Carry-out step <b>F6</b>
<b>F3</b>	<b>BULB CHECK</b>		
- Check bulb of glovebox lamp <b>F9</b>		 ►  ►	Carry-out step <b>F4</b>  Replace bulb
<b>F4</b>	<b>SWITCH CHECK</b>		
- Check for proper operation of switch <b>H25</b> (open circuit with glovebox closed, closed circuit with glovebox open)		 ►  ►	Carry-out step <b>F5</b>  Replace switch <b>H25</b>

(Cont.d)



















GLOVEBOX LAMP INOPERATIVE	<b>TEST F</b>
---------------------------	---------------

TEST STEPS		RESULTS	REMEDY
<b>F5</b>	CONTINUITY CHECK		
	- Check for continuity between pin 30 of dome lamp relay I26 and glovebox illumination switch H25	OK 	Repair wiring between switch H25 and lamp F9
		<del>OK</del> 	Repair or replace wires, as necessary
<b>F6</b>	CONTINUITY CHECK		
	- Check for continuity between glovebox illumination lamp F9 and pin 2Q of fuse box G1	OK 	Carry-out step F7
		<del>OK</del> 	Repair or replace wires, as necessary
<b>F7</b>	GROUNDING CHECK		
	- Check for presence of 0V (zero) at pin 12E of fuse box G1	OK 	Repair wiring between pin 3Q of fuse box G1 and pin 30 of relay I26
		<del>OK</del> 	Repair wiring between pin 12E of fuse box G1 and ground point G174

End of test F

## MALFUNCTION OF TIMED LAMPS









## TEST G

TEST STEPS		RESULTS	REMEDY
<b>G1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>F6</b> in auxiliary fuse box <b>G2</b> for integrity		 	Carry-out step <b>G2</b>
		 	Replace fuse <b>F6</b>
<b>G2</b>	<b>ALL TIMED LAMPS INOPERATIVE CHECK</b>		
- Check that none of the lamps comes on, opening either door		 	Replace Alfa Romeo Control unit <b>N22</b>
		 	Carry-out step <b>G3</b>
<b>G3</b>	<b>ONE OR MORE TIMED LAMPS INOPERATIVE CHECK</b>		
- Check for failed illumination of dome lamp <b>F35</b> , of rear LH dome lamp <b>F37</b> , of fuse box illumination lamp <b>F7</b> and of RH and LH feet illumination lamps <b>F23</b> and <b>F24</b>		 	Carry-out step <b>G4</b>
		 	Carry-out step <b>G7</b>
<b>G4</b>	<b>RELAY CHECK</b>		
- Check relay <b>I26</b> for proper operation		 	Carry-out step <b>G5</b>
		 	Replace relay <b>I26</b>

(Cont.d)

## MALFUNCTION OF TIMED LAMPS







TEST G

TEST STEPS		RESULTS	REMEDY
<b>G5</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 86 of dome lamp relay I26 and ground		 ►  ►	Carry-out step G6  Repair wiring between pin 86 of relay I26 and fuse box G2 (RED wire)
<b>G6</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 85 of dome lamp relay I26		 ►  ►	Repair wiring between pin 30 of relay I26 and pin 3A of fuse box G1  Repair wiring between pin 85 of relay I26 and pin 9A of control unit N22
<b>G7</b>	<b>REAR RH DOME CHECK</b>		
- Check that rear RH dome lamp only fails to illuminate		 ►  ►	Carry-out step G8  Carry-out step G12
<b>G8</b>	<b>BULB CHECK</b>		
- Check for integrity of rear RH dome lamp bulb		 ►  ►	Carry-out step G9  Replace bulb

(Cont.d)













## MALFUNCTION OF TIMED LAMPS

## TEST G

TEST STEPS		RESULTS	REMEDY
<b>G9</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 86 of dome lamp relay I26 in fuse box G1 and ground		 ►  ►	Carry-out step G10  Repair wiring between fuse box G2, pin 1 of connector G16 and pin 3E of fuse box G1
<b>G10</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 85 of relay I26 in fuse box G1		 ►  ►	Carry-out step G11  Repair wiring between pin 10D of fuse box G1 and pin 8A of control unit N22
<b>G11</b>	<b>CONTINUITY CHECK</b>		
- Check for presence continuity between: <ul style="list-style-type: none"> <li>• pin 10 of fuse box G1 and pin 8 of connector G170</li> <li>• pin 8 of connector G170 and pin 3 of dome lamp control switch on right rear post F36</li> <li>• pin 2 of connector G16 and pin 8 of connector G167</li> <li>• pin 8 of connector G167 and pin 4 of dome lamp control switch on right rear post F36</li> </ul>		 ►  ►	Replace relay I26 of fuse box G1  Repair or replace wires, as necessary
<b>G12</b>	<b>CENTER DOME CHECK</b>		
- Check that the dome lamp F35 only fails to illuminate		►  ►	Carry-out step G13  Carry-out step G14

(Cont.d)









<b>MALFUNCTION OF TIMED LAMPS</b>	<b>TEST G</b>
-----------------------------------	---------------

TEST STEPS		RESULTS	REMEDY
<b>G13</b>	<b>BULB CHECK</b>		
- Check bulb of dome lamp F35 for integrity		 	Repair wiring between pin 6 of dome lamp F35, pin 4 of connector G179 and pin 4 of connector G171
		 	Replace bulb
<b>G14</b>	<b>FUSE BOX ILLUMINATION CHECK</b>		
- Check that fuse box lamp F7 only fails to illuminate		 	Carry-out step G15
		 	Carry-out step G16
<b>G15</b>	<b>BULB CHECK</b>		
- Check fuse box lamp F7 for integrity of bulb		 	Repair wiring between lamp F7 and pin 2Q of fuse box G1 (RED-BLK wire), and between lamp F7 and pin 4 of connector G171 (PPL-WHT wire)
		 	Replace bulb of lamp F7

(Cont.d)

## MALFUNCTION OF TIMED LAMPS

## TEST G

TEST STEPS		RESULTS	REMEDY
<b>G16</b>	<b>BULB CHECK</b>		
- Check that rear LH dome lamp only fails to illuminate		 ►	Carry-out step G17
		 ►	Carry-out step G18
<b>G17</b>	<b>LH FEET ILLUMINATION LAMP CHECK</b>		
- Check for integrity of bulb of dome lamp F37		 ►	Repair wiring between pin 3 of dome lamp F37, pin 5 of connector G171, and pin 87 of relay I26
		 ►	Replace bulb of RH rear dome F37
<b>G18</b>	<b>BULB CHECK</b>		
- Check that the LH feet illumination lamp interior left side F24 only fails to illuminate		 ►	Carry-out step G19
		 ►	Carry-out step G20
<b>G19</b>	<b>BULB CHECK</b>		
- Check for integrity of bulb of LH feet illumination lamp interior left side F24		 ►	Repair wiring between lamp interior left side F24 and pin 6 of G171 (RED-BLK wire)
		 ►	Replace bulb of lamp F24

(Cont.d)

## MALFUNCTION OF TIMED LAMPS

## TEST G

TEST STEPS		RESULTS	REMEDY
G20	BULB CHECK		
<ul style="list-style-type: none"> <li>- Check for integrity of bulb of RH feet illumination lamp interior right side F23</li> </ul>		<p>OK ►</p>	<p>Repair wiring between lamp F23 and pin 87a of relay I26 (PPL-WHT wire) and between lamp F23 and glovebox illumination lamp F9 (RED-BLK wire)</p>
		<p><del>OK</del> ►</p>	<p>Replace bulb of lamp F23</p>

End of test G

## CONTROLS LIGHTING INOPERATIVE (POSITION LAMPS ON)

## TEST H













TEST STEPS		RESULTS	REMEDY
H1	ALL LAMPS INOPERATIVE CHECK		
	- Check that, with position lamps switched on, the following lamps do not illuminate: controls illumination of dome lamp F35, rear RH and LH post lamp and courtesy mirror illumination lamp F25 on sun visor (upon actuation of related pushbutton)	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Failure of position lamps circuit; refer to the applicable troubleshooting procedure</p> <p>Carry-out step H2</p>
H2	DOMELAMP CHECK		
	- Check that only the dome lamp F35 controls lighting fails to illuminate	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step H3</p> <p>Carry-out step H4</p>
H3	BULB CHECK		
	- Check for integrity of bulb of controls illumination of dome lamp F35	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pin 1 of dome lamp F35 and pin 4D of fuse box G1 through pin 3 of connectors of G171 and G179</p> <p>Replace bulb of dome lamp F35</p>

(Cont.d)



## CONTROLS LIGHTING INOPERATIVE (POSITION LAMPS ON)







## TEST H

TEST STEPS		RESULTS	REMEDY
<b>H4</b>	<b>COURTESY MIRROR ILLUMINATION LAMP CHECK</b>		
- Check that fault simultaneously affects dome lamp F35 and courtesy mirror illumination lamp F25		 	Repair wiring between pin 1 of dome lamp F35 and pin 3 of connector G179, pin 3 of connector G171 and pin 4D of fuse box G1
		 	Carry-out step H5
<b>H5</b>	<b>COURTESY MIRROR LAMP CHECK</b>		
- Check that the courtesy mirror illumination lamp only fails to illuminate		 	Carry-out step H6
		 	Carry-out step H8
<b>H6</b>	<b>BULB CHECK</b>		
- Check for integrity of bulb of dome lamp F25		 	Carry-out step H7
		 	Replace bulb of dome lamp F25

(Cont.d)

## CONTROLS LIGHTING INOPERATIVE (POSITION LAMPS ON)

## TEST H

TEST STEPS		RESULTS	REMEDY
H7	SWITCH CHECK		
- Check control switch of courtesy mirror illumination lamp F25 for proper operation		 ►	Repair wiring between dome lamp F35 (pins 1 and 2) and courtesy mirror illumination lamp F25 (GRY-YEL and BLK wires)
		 ►	Replace switch of courtesy mirror illumination lamp F25
H8	REAR LH POST DOME LAMP CHECK		
- Check that the dome lamp control switch on left rear post F37 only fails to illuminate		 ►	Carry-out step H9
		 ►	Carry-out step H10
H9	BULB CHECK		
- Check bulb of dome lamp control switch on left rear post F37 controls lighting for integrity		 ►	Repair wiring between pin 2 of LH post dome lamp F37 and left tail lamp unit E26
		 ►	Replace bulb of dome lamp F37

(Cont.d)

## CONTROLS LIGHTING INOPERATIVE (POSITION LAMPS ON)

## TEST H

TEST STEPS		RESULTS	REMEDY
H10	BULB CHECK		
<ul style="list-style-type: none"> <li>- Check bulb of dome lamp control switch on right rear post F36-controls lighting for integrity</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pin 2 of RH post dome lamp F36 and pin 2 of right tail lamp unit E28</p> <p>Replace bulb of dome lamp F36</p>

End of test H



## GENERAL

The vehicle is equipped of timed interior lamps whose illumination is controlled by any one of the four doors; In this way, access to the vehicle is made easy, even in bad light conditions.

When a door is opened, the center dome lamp with relevant spot lamp, both dome lamps, on rear right and left posts, and the fuse box illuminate automatically.

For better comfort, the above lamps remain on for a few seconds after the door has been closed.

The rear post domes and the dome lamp control switch are equipped with spot lamps that are switched on by their relevant switch. Except for lamps on central dome lamp, which can also be actuated by door opening, as already mentioned above.

Some courtesy lamps are installed on the vehicle to illuminate the controls; those lamps illuminate upon activation of position lamps:

- glovebox lamp, switched on by opening the glovebox lid.
- dome lamp control switch and rear post domes, switched on automatically upon activation of position lamps.
- sun roof pushbutton.

The system is protected by three fuses, as follows:

- fuse F21 (15A) DOME LAMP/GLOVEBOX LAMP in fuse box G1.
- fuse F5 (10A) DOME LAMP in auxiliary fuse box G2.
- fuse F6 (10A) DOME LAMP RELAY in the auxiliary fuse box G2.

## OPERATIONAL DESCRIPTION

### Lamps actuation by the relevant pushbutton.

Battery voltage (12V) always present is sent to the spot on the dome lamp with cabin lighting control switch F35 through fuse F21 of fuse box G1. In the same way, 12V through fuse F5 of auxiliary fuse box G2 is sent to dome lamp control switches F36 and F37 on the right and left rear post. Pushing the pushbutton, the relevant spot illuminates.

### Time lighting upon door opening.

Opening any of the doors, the Alfa Romeo Control unit N22 sets and maintains for some seconds pins 8A and 9A to a low logic level thus providing a ground path to dome lamp relay I26 on the fuse box G1 and to dome lamp relay I26. Both relays are always connected to a positive voltage through fuse F6 in the auxiliary fuse box G2, thus they are held energized only for the time controlled by the control unit N22. The dome lamp relay I26, once energized, transfers a ground connection to dome lamp with cabin lighting control switch F35 to right and left feet illuminations F23 and F24, to dome lamp control switch on left rear post F37 and to fuse box lamp F7, thus lighting them all. The dome lamp relay I26 in the fuse box G1, when energized, transfers a ground to dome lamp control switch on right rear post F36, thus lighting it.












### Lighting monitored by the position lamps.

The wiring diagram shows the path of the lines that control the courtesy mirror illumination lamps, whose lighting is depending on position lamps.

With position lamp turned on, the dome lamp with cabin lighting control switch F35, rear left and right dome lamps F36 and F37 and sun roof pushbutton are illuminated. From the dome lamp F35 it is possible to control lighting of rear left and right dome lamps F36 and F37. When the position lamps are turned on, opening the glovebox, the switch H25 closes, thus turning on the lamp within the box it self.









TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT															
	F5	F6	F21	F7	F9	F23	F24	F35/36/37	F35/36/37	F35/36/37	F35/36/37	F35/36/37	H25	I26	I26	I26
	FUSE	FUSE	TRUNK DOME	FUSE LAMP BULB	BULB	DOME LAMP BULB	DOME LAMP BULB	DOME PUSHB.	SPOT PUSHB.	CONTR. LAMP	SPOT LAMP	DOME LAMP	SWITCH	RELAY	RELAY (G1)	CONTROL UNIT
DOME MAP LAMP CONTROL SWITCH INOPERATIVE (PUSHBUTTON ACTUATED)			•						•		•					
LEFT REAR POST DOME SPOT INOPERATIVE (PUSHBUTTON ACTUATED)	•								•		•					
RIGHT REAR POST DOME SPOT INOPERATIVE (PUSHBUTTON ACTUATED)	•								•		•					
DOME LAMPS ON REAR RIGHT AND LEFT POSTS INOPERATIVE (BY PUSHBUTTON ACTUATION ON CENTER DOME LAMP)	•							•				•				
GLOVEBOX LAMP INOPERATIVE			•		•								•			
MALFUNCTION OF TIMED LAMPS		•		•		•	•					•		•	•	•
CONTROLS LIGHTING INOPERATIVE (POSITION LAMPS ON)										•						

<p>Fuse box lamp</p>	<p>F7</p>	<p>Glovebox illumination lamp</p>	<p>F9</p>
			
<p>Feet illumination lamp, interior, right side</p>	<p>F23</p>	<p>Feet illumination lamp, interior, left side</p>	<p>F24</p>
			
<p>Dome lamp with cabin lighting control switch</p>	<p>F35</p>	<p>Dome lamp, control switch on right rear post</p>	<p>F36</p>
		<p><b>BASE AND L ONLY</b></p> 	
		<p>Dome lamp, control switch on right rear post</p>	<p>F36</p>
		<p><b>S ONLY</b></p> 	
<p>Dome lamp, control switch on left rear post</p>	<p>F37</p>	<p>Fuse box</p>	<p>G1 D</p>
			
<p>Fuse box</p>	<p>G1 E</p>	<p>Fuse box</p>	<p>G1 N</p>
			











(Cont.d)




<p>Fuse box <span style="float: right;">(G1) (O)</span></p>	<p>Fuse box <span style="float: right;">(G1) (Q)</span></p>
	
<p>Fuse box <span style="float: right;">(G1) (T)</span></p>	<p>Auxiliary fuse box <span style="float: right;">(G2)</span></p>
	
<p>Six pin connector circuit board to doors wiring <span style="float: right;">(G16)</span></p>	<p>Connector, front doors to right rear wiring <span style="float: right;">(G167)</span></p>
	
<p>Connector, front door to left rear wiring <span style="float: right;">(G169)</span></p>	<p>Connector, circuit board to right rear wiring <span style="float: right;">(G170)</span></p>
	

















(Cont.d)



<p>Connector, circuit board to left rear wiring</p>	<p><b>G171</b></p>	<p>Steering wheel column support ground</p>	<p><b>G174</b></p>
			
		<p>Dome ground</p>	<p><b>G176</b></p>
			
<p>Connector, left rear wiring to dome lamp wiring</p>	<p><b>G179</b></p>	<p>Trunk left side ground</p>	<p><b>G185</b></p>
			
		<p>Trunk right side ground</p>	<p><b>G186</b></p>
			
<p>Connector, provision for radio antenna</p>	<p><b>G193</b></p>	<p>Glovebox illumination switch</p>	<p><b>H25</b></p>
			
<p>Dome lamp relay</p>	<p><b>I26</b></p>	<p>Alfa Romeo control unit</p>	<p><b>N22 A</b></p>
			















**DOMELAMP CONTROL SWITCH INOPERATIVE (PUSHBUTTON AC-  
TUATED)**
**TEST A**

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
- Check fuse F21 on fuse box G1 for integrity		 	Carry-out step A2
		 	Replace fuse F21
<b>A2</b>	<b>SPOT LAMP CHECK</b>		
- Check that both spot lamp of dome lamp F35 and dome lamp F35 can not be turned on		 	Repair wiring between ground point G176 and pin 2 of dome lamp F35
		 	Carry-out step A3
<b>A3</b>	<b>TIMED LAMP CHECK</b>		
- Check that the timed lamp of dome lamp F35 is inoperative		 	Carry-out step A4
		 	Carry-out step A7
<b>A4</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 6 of connector G171 and ground		 	Carry-out step A6
		 	Carry-out step A5

(Cont.d)

## DOME MAP LAMP CONTROL SWITCH INOPERATIVE (PUSHBUTTON ACTUATED)

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2N of fuse box G1 and ground		 	Repair wiring between pin 6 of connector G171 and pin 20 of fuse box G1
		 	Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>A6</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 6 of connector G179 and ground		 	Repair wiring between ground point G176 and pin 2 of dome lamp F35
		 	Repair wiring between pin 6 of connector G179 and pin 6 of connector G171
<b>A7</b>	<b>BULB CHECK</b>		
- Check for integrity of spot bulb of dome lamp F35		 	Replace pushbutton of spot on dome lamp F35
		 	Replace bulb

End of test A

<b>LEFT REAR POST DOME SPOT INOPERATIVE (PUSHBUTTON ACTUATED)</b>	<b>TEST B</b>
---	---------------

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>FUSE CHECK</b>		
	- Check for integrity of fuse F5 in auxiliary fuse box G2	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step B2  Replace fuse F5
<b>B2</b>	<b>REAR RH SPOT CHECK</b>		
	- Check illumination of rear RH post dome lamp	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step B3  Carry-out step B5
<b>B3</b>	<b>CONTROLS LIGHTINGS CHECK</b>		
	- Switch on position lamps and check for lighting of controls on rear LH post dome lamp	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step B4  Repair wiring between pin 1 of dome lamp F37 and ground point G185
<b>B4</b>	<b>BULB CHECK</b>		
	- Check for integrity of bulb in rear LH post dome spot	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Replace pushbutton on dome lamp F37  Replace bulb on dome lamp F37

(Cont.d)

LEFT REAR POST DOME SPOT INOPERATIVE (PUSHBUTTON ACTUATED)

















TEST B

TEST STEPS		RESULTS	REMEDY
<b>B5</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 4 of connector G169 and ground		OK ►	Carry-out step B7
		<del>OK</del> ►	Carry-out step B6
<b>B6</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2 of connector G16 and ground		OK ►	Repair wiring between pin 4 of connector G169 and pin 2 of connector G16
		<del>OK</del> ►	Repair wiring between pin 2 of connector G16 and fuse box G2 (RED-BLK wire)
<b>B7</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 1 of connector G193 and ground		OK ►	Repair wiring between pin 1 of connector G193 and pin 4 of dome lamp F37
		<del>OK</del> ►	Repair wiring between pin 1 of G193 and pin 4 of G169

End of test B

## RIGHT REAR POST DOME SPOT INOPERATIVE (PUSHBUTTON ACTUATED)





TEST C

TEST STEPS		RESULTS	REMEDY
<b>C1</b>	<b>FUSE CHECK</b>		
- Check for integrity of fuse F5 in auxiliary fuse box G2		 	Carry-out step C2
		 	Replace fuse F5
<b>C2</b>	<b>REAR LH MAP LAMP CHECK</b>		
- Check illumination of rear LH post dome spot		 	Carry-out step C3
		 	Carry-out step C5
<b>C3</b>	<b>CONTROLS LIGHTING CHECK</b>		
- Switch on position lamps and check for lighting of controls on rear RH post dome lamp		 	Carry-out step C4
		 	Repair wiring between pin 1 of dome lamp F36 and ground point G186
<b>C4</b>	<b>BULB CHECK</b>		
- Check for integrity of bulb in rear RH post dome spot		 	Replace pushbutton on dome lamp F36
		 	Replace bulb on dome lamp F36

(Cont.d)

RIGHT REAR POST DOME SPOT INOPERATIVE (PUSHBUTTON ACTUATED)









TEST C

TEST STEPS		RESULTS	REMEDY
<b>C5</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 8 of connector G167 and ground			Repair wiring between pin 8 of connector G167 and pin 4 of dome F36
			Carry-out step C6
<b>C6</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2 of connector G16 and ground			Repair wiring between pin 8 of connector G167 and pin 2 of connector G16
			Repair wiring between pin 2 of connector G16 and fuse box G2 (RED-BLK wire)

End of test C











**DOME LAMPS ON REAR RIGHT AND LEFT POSTS INOPERATIVE (BY PUSHBUTTON ACTUATION ON CENTER DOME LAMP)**
**TEST D**

TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>FUSE CHECK</b>		
	- Check fuse F5 in auxiliary fuse box G2 for integrity	 	Carry-out step D2  Replace fuse F5
<b>D2</b>	<b>CENTER DOME LAMP AND SPOT LAMP CHECK</b>		
	- Check that also the center dome lamp and relevant spot lamp do not illuminate	 	Repair wiring between ground G176 and pin 2 of dome lamp F35  Carry-out step D3
<b>D3</b>	<b>DOME LAMP CHECK ON REAR POSTS</b>		
	- Check that, by pressing the pushbutton on center dome lamp, none of dome lamps F37 and F36 illuminate	 	Carry-out step D4  Carry-out step D7
<b>D4</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V at pin 3 of center dome lamp, by pressing the pushbutton for rear post dome lamp	 	Carry-out step D5  Replace pushbutton on dome lamp F35

(Cont.d)

## DOME LAMPS ON REAR RIGHT AND LEFT POSTS INOPERATIVE (BY PUSHBUTTON ACTUATION ON CENTER DOME LAMP)









## TEST D

TEST STEPS		RESULTS	REMEDY
<b>D5</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 2 of connector G179		 ▶  ▶	Carry-out step D6  Repair wiring between pin 3 of dome lamp F35 and pin 2 of G179
<b>D6</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2 of G16 and ground		 ▶  ▶	Repair wiring between pin 2 of G16 and pins 4 and 8 of connectors G169 and G167 respectively  Repair wiring between pin 2 of G16 and auxiliary fuse box G2 (RED-BLK wire)
<b>D7</b>	<b>REAR LEFT DOME LAMP CHECK</b>		
- Check that only left dome lamp F37 is inoperative		 ▶  ▶	Carry-out step D8  Carry-out step D14
<b>D8</b>	<b>TIMED LAMP CHECK</b>		
- Check that, by opening either doors, the dome lamp on rear left post illuminates		 ▶  ▶	Carry-out step D9  Carry-out step D11

(Cont.d)

**DOMES LAMPS ON REAR RIGHT AND LEFT POSTS INOPERATIVE (BY PUSHBUTTON ACTUATION ON CENTER DOME LAMP)**

**TEST D**

TEST STEPS		RESULTS	REMEDY
<b>D9</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V at pin 5 of connector <b>G179</b>	 ▶  ▶	Carry-out step <b>D10</b>  Repair wiring between pin 2 of <b>G179</b> and pin 5 of <b>G179</b>
<b>D10</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V at pin 5 of connector <b>G171</b>	 ▶  ▶	Repair wiring between pin 5 of <b>G171</b> and pin 3 of dome lamp <b>F37</b>  Repair wiring between pin 5 of <b>G171</b> and pin 5 of <b>G179</b>
<b>D11</b>	<b>BULB CHECK</b>		
	- Check the bulb of dome lamp on rear left post for integrity	 ▶  ▶	Carry-out step <b>D12</b>  Replace bulb
<b>D12</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 4 of connector <b>G169</b> and ground	 ▶  ▶	Carry-out step <b>D13</b>  Repair wiring between pin 4 of <b>G169</b> and pin 2 of <b>G16</b>

(Cont.d)

**DOMES LAMPS ON REAR RIGHT AND LEFT POSTS INOPERATIVE (BY PUSHBUTTON ACTUATION ON CENTER DOME LAMP)**

**TEST D**

TEST STEPS		RESULTS	REMEDY
<b>D13</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 1 of G193 and ground	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pin 1 of G193 and pin 4 of dome lamp F37</p> <p>Repair wiring between pin 1 of G193 and pin 4 of G169</p>
<b>D14</b>	<b>BULB CHECK</b>		
	- Check the bulb of dome lamp on rear right post F36 for integrity	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step D15</p> <p>Replace the bulb</p>
<b>D15</b>	<b>TIMED LAMP CHECK</b>		
	- Check that, by opening either doors, the dome lamp on rear right post illuminates	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step D16</p> <p>Carry-out step D17</p>
<b>D16</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V at pin 2 of connector G171	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pin 2 of G171 and pin 10 of fuse box G1</p> <p>Repair wiring between pin 2 of G171 and pin 2 of G179</p>

(Cont.d)









DOME LAMPS ON REAR RIGHT AND LEFT POSTS INOPERATIVE (BY PUSHBUTTON ACTUATION ON CENTER DOME LAMP)

TEST D

TEST STEPS		RESULTS	REMEDY
<b>D17</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 8 of connector G167 and ground		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step D18</p> <p>Repair wiring between pin 8 of G167 and pin 2 of G16</p>
<b>D18</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 4 of dome lamp on rear right post F36 and ground		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step D19</p> <p>Repair wiring between pin 8 of G167 and pin 4 of dome lamp F36</p>
<b>D19</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V at pin 8 of connector G170		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pin 8 of G170 and pin 3 of dome lamp F36</p> <p>Repair wiring between pin 8 of G170 and pin 10 of fuse box G1</p>

End of test D













<b>GLOVEBOX LAMP INOPERATIVE</b>	<b>TEST E</b>
----------------------------------	---------------

TEST STEPS		RESULTS	REMEDY
<b>E1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>F21</b> in fuse box <b>G1</b> for integrity		 ►  ►	Carry-out step <b>E2</b>  Replace fuse <b>F21</b>
<b>E2</b>	<b>TIMED LAMPS CHECK</b>		
- Check that, opening either door, both LH and RH lamps below instrument panel illuminate		 ►  ►	Carry-out step <b>E3</b>  Carry-out step <b>E6</b>
<b>E3</b>	<b>BULB CHECK</b>		
- Check bulb of glovebox lamp <b>F9</b>		 ►  ►	Carry-out step <b>E4</b>  Replace bulb
<b>E4</b>	<b>SWITCH CHECK</b>		
- Check for proper operation of switch <b>H25</b> (open circuit with glovebox closed, closed circuit with glovebox open)		 ►  ►	Carry-out step <b>E5</b>  Replace switch <b>H25</b>

(Cont.d)

















## GLOVEBOX LAMP INOPERATIVE

## TEST E

TEST STEPS		RESULTS	REMEDY
<b>E5</b>	<b>CONTINUITY CHECK</b>		
	- Check for continuity between pin 30 of dome lamp relay I26 and glovebox illumination switch H25	 	Repair wiring between switch H25 and lamp F9
		 	Repair or replace wires, as necessary
<b>E6</b>	<b>CONTINUITY CHECK</b>		
	- Check for continuity between glovebox illumination lamp F9 and pin 2Q of fuse box G1	 	Carry-out step E7
		 	Repair or replace wires, as necessary
<b>E7</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 12E of fuse box G1	 	Repair wiring between pin 3Q of fuse box G1 and pin 30 of relay I26
		 	Repair wiring between pin 12E of fuse box G1 and ground point G174

End of test E

<b>MALFUNCTION OF TIMED LAMPS</b>	<b>TEST F</b>
-----------------------------------	---------------

TEST STEPS		RESULTS	REMEDY
<b>F1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>F6</b> in auxiliary fuse box <b>G2</b> for integrity		 	Carry-out <b>step F2</b>
		 	Replace fuse <b>F6</b>
<b>F2</b>	<b>ALL TIMED LAMPS INOPERATIVE CHECK</b>		
- Check that none of the lamps comes on, opening either door		 	Replace <b>Alfa Romeo Control unit N22</b>
		 	Carry-out <b>step F3</b>
<b>F3</b>	<b>ONE OR MORE TIMED LAMPS INOPERATIVE CHECK</b>		
- Check for failed illumination of dome lamp <b>F35</b> , of rear LH dome lamp <b>F37</b> , of fuse box illumination lamp <b>F7</b> and of RH and LH feet illumination lamps <b>F23</b> and <b>F24</b>		 	Carry-out <b>step F4</b>
		 	Carry-out <b>step F7</b>
<b>F4</b>	<b>RELAY CHECK</b>		
- Check relay <b>I26</b> for proper operation		 	Carry-out <b>step F5</b>
		 	Replace relay <b>I26</b>

(Cont.d)



## MALFUNCTION OF TIMED LAMPS







## TEST F

TEST STEPS		RESULTS	REMEDY
<b>F5</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 86 of dome lamp relay I26 and ground		<div style="display: flex; align-items: center; gap: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px; margin-top: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out <b>step F6</b>  Repair wiring between <b>pin 86 of relay I26 and fuse box G2 (RED wire)</b>
<b>F6</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 85 of dome lamp relay I26		<div style="display: flex; align-items: center; gap: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px; margin-top: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between <b>pin 30 of relay I26 and pin 3A of fuse box G1</b>  Repair wiring between <b>pin 85 of relay I26 and pin 9A of control unit N22</b>
<b>F7</b>	<b>REAR RH DOME CHECK</b>		
- Check that rear RH dome lamp only fails to illuminate		<div style="display: flex; align-items: center; gap: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px; margin-top: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out <b>step F8</b>  Carry-out <b>step F12</b>
<b>F8</b>	<b>BULB CHECK</b>		
- Check for integrity of rear RH dome lamp bulb		<div style="display: flex; align-items: center; gap: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px; margin-top: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out <b>step F9</b>  Replace <b>bulb</b>

(Cont.d)

## MALFUNCTION OF TIMED LAMPS









## TEST F

TEST STEPS		RESULTS	REMEDY
F9	VOLTAGE CHECK		
- Check for presence of 12V between pin 86 of dome lamp relay I26 in fuse box G1 and ground		 ▶  ▶	Carry-out step F10  Repair wiring between fuse box G2, pin 1 of connector G16 and pin 3E of fuse box G1
F10	GROUNDING CHECK		
- Check for presence of 0V (zero) at pin 85 of relay I26 in fuse box G1		 ▶  ▶	Carry-out step F11  Repair wiring between pin 10D of fuse box G1 and pin 8A of control unit N22
F11	CONTINUITY CHECK		
- Check for continuity between: <ul style="list-style-type: none"> <li>• pin 10 of fuse box G1 and pin 8 of connector G170</li> <li>• pin 8 of connector G170 and pin 3 of rear right dome lamp F36</li> <li>• pin 2 of connector G16 and pin 8 of connector G167</li> <li>• pin 8 of connector G167 and pin 4 of rear right dome lamp F36</li> </ul>		 ▶  ▶	Replace relay I26 of fuse box G1  Repair or replace wires, as necessary

(Cont.d)

## MALFUNCTION OF TIMED LAMPS









## TEST F

TEST STEPS		RESULTS	REMEDY
<b>F12</b>	<b>CHECK ON CENTER DOME LAMP AND RELEVANT SPOT LAMP INOPERATIVE</b>		
	- Check that neither center dome lamp nor spot lamp illuminate	 ►  ►	Carry-out step F13  Carry-out step F16
<b>F13</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V at pin 4 of connector G179	 ►  ►	Carry-out step F14  Repair wiring between pin 4 of G179 and pin 4 of G171
<b>F14</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V at pin 6 of center dome lamp F35	 ►  ►	Carry-out step F15  Repair wiring between pin 6 of dome lamp F35 and pin 4 of G179
<b>F15</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 6 of G179 and ground	 ►  ►	Repair wiring between pin 6 of G179 and pin 5 of dome lamp F35  Repair wiring between pin 6 of G179 and pin 6 of G171

(Cont.d)

## MALFUNCTION OF TIMED LAMPS









## TEST F

TEST STEPS		RESULTS	REMEDY
<b>F16</b>	<b>CENTER DOME LAMP CHECK</b>		
	- Check that only center dome lamp <b>F35</b> fails to illuminate	 ▶  ▶	Replace bulb of center dome lamp  Carry-out step <b>F17</b>
<b>F17</b>	<b>CENTER DOME LAMP SPOT LAMP CHECK</b>		
	- Check that only center dome lamp spot lamp fails to illuminate	 ▶  ▶	Replace bulb of spot lamp  Carry-out step <b>F18</b>
<b>F18</b>	<b>FUSE BOX ILLUMINATION CHECK</b>		
	- Check that fuse box lamp <b>F7</b> only fails to illuminate	 ▶  ▶	Carry-out step <b>F19</b>  Carry-out step <b>F20</b>
<b>F19</b>	<b>BULB CHECK</b>		
	- Check fuse box lamp <b>F7</b> for integrity of bulb	 ▶  ▶	Repair wiring between lamp <b>F7</b> and pin <b>2Q</b> of fuse box <b>G1</b> (RED-BLK wire), and between lamp <b>F7</b> and pin <b>4</b> of connector <b>G171</b> (PPL-WHT wire)  Repair bulb of lamp <b>F7</b>

(Cont.d)

## MALFUNCTION OF TIMED LAMPS

TEST F

TEST STEPS		RESULTS	REMEDY
<b>F20</b>	<b>BULB CHECK</b>		
- Check that rear LH dome lamp only fails to illuminate		 ▶  ▶	Carry-out step F21  Carry-out step F22
<b>F21</b>	<b>LH FEET ILLUMINATION LAMP CHECK</b>		
- Check for integrity of bulb of dome lamp F37		 ▶  ▶	Repair wiring between <b>pin 3 of dome lamp F37, pin 5 of connector G171, and pin 87 of relay I26</b>  Replace bulb of RH rear dome F37
<b>F22</b>	<b>BULB CHECK</b>		
- Check that the LH feet illumination lamp interior left side F24 only fails to illuminate		 ▶  ▶	Carry-out step F23  Carry-out step F24
<b>F23</b>	<b>BULB CHECK</b>		
- Check for integrity of bulb of LH feet illumination lamp interior left side F24		 ▶  ▶	Repair wiring between <b>lamp interior left side F24 and pin 6 of G171 (RED-BLK wire)</b>  Replace bulb of lamp F24

(Cont.d)

## MALFUNCTION OF TIMED LAMPS









## TEST F

TEST STEPS		RESULTS	REMEDY
F24	BULB CHECK		
- Check for integrity of bulb of RH feet illumination lamp interior right side F23		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between lamp F23 and pin 87a of relay I26 (PPL-WHT wire) and between lamp F23 and glovebox illumination lamp F9 (RED-BLK wire)</p> <p>Replace bulb of lamp F23</p>

End of test F

## CONTROLS LIGHTING INOPERATIVE (POSITION LAMPS ON)









TEST G

TEST STEPS		RESULTS	REMEDY
<b>G1</b>	<b>ALL LAMPS INOPERATIVE CHECK</b>		
- Check that, with position lamps switched on, the following lamps do not illuminate: controls illumination of dome lamp F35, rear RH and LH post lamp		 ▶   ▶	Failure of position lamps circuit; refer to the applicable troubleshooting procedure  Carry-out step G2
<b>G2</b>	<b>DOMELAMP CHECK</b>		
- Check that only the dome lamp F35 controls lighting fails to illuminate		 ▶   ▶	Carry-out step G3  Carry-out step G4
<b>G3</b>	<b>BULB CHECK</b>		
- Check for integrity of bulb of controls illumination of dome lamp F35		 ▶   ▶	Repair wiring between pin 1 of dome lamp F35 and pin 4D of fuse box G1 through pin 3 of connectors G171 and G179  Replace bulb of dome lamp F35
<b>G4</b>	<b>REAR LH POST DOME LAMP CHECK</b>		
- Check that the dome lamp control switch on left rear post F37 only fails to illuminate		 ▶   ▶	Carry-out step G5  Carry-out step G6

(Cont.d)

## CONTROLS LIGHTING INOPERATIVE (POSITION LAMPS ON)

TEST G

TEST STEPS		RESULTS	REMEDY
<b>G5</b>	<b>BULB CHECK</b>		
- Check bulb of dome lamp control switch on left rear post F37 controls lighting for integrity		 	Repair wiring between pin 2 of LH post dome lamp F37 and left tail lamp unit E26
		 	Replace bulb of dome lamp F37
<b>G6</b>	<b>BULB CHECK</b>		
- Check bulb of dome lamp control switch on right rear post F36 controls lighting for integrity		 	Repair wiring between pin 2 of RH post dome lamp F36 and pin 2 of right tail lamp unit E28
		 	Replace bulb of dome lamp F36

End of test G



LAMPS - - POSITION,  
SIDE MARKER,  
LICENSE PLATE ILLUMINATION



## GENERAL

The position, license and side marker lamps can be activated by the relevant button on the pushbutton panel B66. When the vehicle is running, activation is controlled by the multiple switch. When the ignition key is set to park position, the lamps can be activated by pressing the relevant button on the pushbutton panel B66.

When either switch is activated, simultaneous illumination of the four position lamps (two on the front and two on the rear), four side marker lamps (two on the front and two on the rear) and of the two license lamps is obtained. Furthermore, the instrument panel and pushbutton panel lighting will turn on as well as all different silk-screen printings of the vehicle; lighting of the instrument panel and pushbutton panel can be dimmed through a rehostat, to allow proper reading of instruments and controls regardless of the exterior lighting.

Rotation of the rehostat completely upwards will turn off the instrument panel lighting. The system is protected by three fuses in the fuse box G1, as follows:

- Fuse F1 (7.5A) R.H. FRONT, L.H. REAR POSITION LAMPS and LICENSE PLATE LAMPS.
- Fuse F2 (7.5A) R.H. FRONT L.H. REAR POSITION LAMPS.

- Fuse F11 (7.5A) POSITION LAMPS.

## OPERATIONAL DESCRIPTION - LEFT FRONT AND RIGHT REAR POSITION AND SIDE MARKER LAMPS

With the ignition key set to "run" position, the battery power is supplied to the parking lamps control unit N41 through the fuse F11 in fuse box G1; furthermore, 12V are applied to the multiple switch B4 after "bridging" on fuse box G1.

Control unit N41 activates illumination of the position lamps (12V at pin 6) when either the multiple switch or the relevant pushbutton on the pushbutton panel is actuated. Electric power output from pin 6 of control unit N41 is applied to fuses F1 and F2 of fuse box G1. Fuse F1 protects the pushbutton panel lighting power supply lines. Fuse F2 protects the power supply lines of position lamps in the front head lamp left E24 and tail lamp right (fixed part) E25, of front side marker lamp E4 and rear side marker lamp E12 and of instrument panel C10 lighting.

The power supply line protected by fuse F2 is also connected to dimmer switch B16 dimming the instrument panel illumination lamp F12 and pushbutton panel B66. Instrument panel illumination lamp F12 and pushbutton panel B66 can be turned off by rotating dimmer switch B16 completely upwards.

## TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT										
	FUSE E2	FUSE F11	INSTR. PANEL LIGHTING F12	L.H. FRONT SIDE MARKER E4	R.H. REAR SIDE MARKER E12	L.H. HEAD LAMP UNIT E24	L.H. TAIL LAMP UNIT E25	MULTIPLE SWITCH B4	DIMMER SWITCH B16	PUSHBUTTON PANEL LIGHT B66	CONTROL UNIT N41
ALL LAMPS INOPERATIVE WITH CONTROL SWITCH ACTUATED		•									•
LEFT FRONT POSITION AND SIDE MARKER LAMPS INOPERATIVE	•			•		•					
RIGHT REAR SIDE MARKER LAMP INOPERATIVE	•				•		•				
PUSHBUTTON PANEL LIGHTING INOPERATIVE			•					•		•	•
INSTRUMENT PANEL LIGHTING INOPERATIVE			•						•		

**NOTE:** Before carrying-out any troubleshooting check the integrity of warning lamp on instrument panel by pressing the test button.



## OPERATIONAL DESCRIPTION - RIGHT FRONT AND LEFT REAR POSITION LAMPS AND SIDE MAR- KER LAMPS, LICENSE PLATE LAMP

With the ignition key set to "run" position, the battery power is supplied to the parking lamps control unit N41 through the fuse F11 in fuse box G1; furthermore, 12V are applied to the multiple switch B4 after "bridging" on fuse box G1.

Control unit N41 activates illumination of the position lamps (12V at pin 6) when either the multiple switch or the

relevant pushbutton on the pushbutton panel is actuated. Electric power output from pin 6 of control unit N41 is applied to fuse F1 of fuse box G1.













Fuse F1 protects the power supply lines of position lamps in the front head lamp right E23 and tail lamp left E26, of license plate lamp in central tail lamp E27, and of front side marker lamp E4 and rear side marker lamp E12.

The power supply line protected by fuse F1 is also connected to a circuit that monitors the illumination of position lamps indicator on the instrument panel C10 and serigraphs on the automatic air conditioning controls.

### TROUBLESHOOTING TABLE


FAULT TYPE	FAILED COMPONENT						
	FUSE F1	R.H. FRONT SIDE MARKER E4	L.H. REAR SIDE MARKER E12	R.H. HEAD LAMP UNIT E23	L.H. TAIL LAMP UNIT E26	LICENSE LAMP E27	INST. PANEL INDICATOR C10
RIGHT FRONT POSITION AND SIDE MARKER LAMPS INOPERATIVE	•	•		•			
LEFT REAR POSITION AND SIDE MARKER LAMPS, AND LICENSE PLATE LAMP INOPERATIVE	•		•		•	•	
POSITION LAMPS INDICATOR ON INSTRUMENT PANEL INOPERATIVE	•						•

**NOTE:** Before carrying-out any troubleshooting check the integrity of warning lamp on instrument panel by pressing the test button.

<p>Ignition/switch</p>	<p>B1</p>	<p>Parking/Flash/Low beam/High beam switch</p>	<p>B4 A</p>
			
<p>Parking/Flash/Low beam/High beam switch</p>	<p>B4 D</p>	<p>Dimmer switch, instrument panel illumination lamps</p>	<p>B16</p>
			
<p>Position lights/Hazard lights/Fuel filler lid pushbutton panel</p>	<p>B66</p>	<p>Instrument panel</p>	<p>C10 C</p>
			
<p>Front side marker lamp (right)</p>	<p>E4</p>	<p>Front side marker lamp (left)</p>	<p>E4</p>
			
<p>Right front fog lamp</p>	<p>E10</p>	<p>Left front fog lamp</p>	<p>E10</p>
			
<p>Rear side marker lamp (right)</p>	<p>E12</p>	<p>Rear side marker lamp (left)</p>	<p>E12</p>
			













(Cont.d)

















(Cont.d)




<p>Fuse box <span style="float: right;">(G1) A</span></p>	<p>Fuse box <span style="float: right;">(G1) B</span></p>
	
<p>Fuse box <span style="float: right;">(G1) C</span></p>	<p>Fuse box <span style="float: right;">(G1) D</span></p>
	
<p>Fuse box <span style="float: right;">(G1) E</span></p>	<p>Fuse box <span style="float: right;">(G1) G</span></p>
	
<p>Fuse box <span style="float: right;">(G1) H</span></p>	<p>Fuse box <span style="float: right;">(G1) L</span></p>
	
<p>Fuse box <span style="float: right;">(G1) N</span></p>	<p>Fuse box <span style="float: right;">(G1) O</span></p>
	
<p>Fuse box <span style="float: right;">(G1) S</span></p>	<p>Engine compartment right side ground connection <span style="float: right;">G53a</span></p>
	

(Cont.d)

<p>Engine compartment left side ground connection</p>	<p><b>G53b</b></p>	<p>Connector, circuit board to engine compartment right side wiring</p>	<p><b>G149</b></p>
			
<p>Connector, circuit board to engine compartment left side wiring</p>	<p><b>G150</b></p>	<p>Connector, door utilities to air conditioning wiring</p>	<p><b>G165</b></p>
			
<p>Connector, circuit board to right rear wiring</p>	<p><b>G170</b></p>	<p>Connector, circuit board to left rear wiring</p>	<p><b>G171</b></p>
			
<p>Steering wheel column support ground</p>	<p><b>G174</b></p>	<p>Trunk left side ground</p>	<p><b>G185</b></p>
			
<p>Trunk right side ground</p>	<p><b>G186</b></p>	<p>Splice in left rear wiring</p>	<p><b>G187</b></p>
			
<p>Splice in right rear wiring</p>	<p><b>G188</b></p>	<p>Connector, left rear wiring to rear central lamp wiring</p>	<p><b>G194</b></p>
			









(Cont.d)

<p><b>Starter motor inhibitor relay</b></p>	<p><b>I10</b></p>	<p><b>Rear window lifts relay</b></p>	<p><b>I13</b></p>
<p><b>Head lamps washer pump relay</b></p>	<p><b>I19</b></p>	<p><b>Low beam lamps relay (right)</b></p>	<p><b>I49</b></p>
<p><b>Low beam lamps relay (left)</b></p>	<p><b>I49</b></p>	<p><b>High beam lamps relay</b></p>	<p><b>I50</b></p>
<p><b>Parking lamps control unit</b></p>			<p><b>N41</b></p>



## ALL LAMPS INOPERATIVE WITH CONTROL SWITCH ACTUATED













## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>F11</b> in fuse box <b>G1</b> for integrity		 ►  ►	Carry-out step <b>A2</b>  Replace fuse <b>F11</b>
<b>A2</b>	<b>PUSHBUTTON PANEL CONTROL SWITCH CHECK</b>		
- With the vehicle stopped, check if position lamps can be turned on by means of button on pushbutton panel <b>B66</b>		 ►  ►	Carry-out step <b>A3</b>  Carry-out step <b>A6</b>
<b>A3</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin <b>2A</b> of multiple switch <b>B4</b> and ground		 ►  ►	Carry out step <b>A5</b>  Carry out step <b>A4</b>
<b>A4</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin <b>2N</b> of fuse box <b>G1</b> and ground		 ►  ►	Repair wiring between pin <b>2N</b> , pin <b>1N</b> of <b>G1</b> and pin <b>2A</b> of multiple switch <b>B4</b>  Failure of power distribution circuit refer to the relevant circuit of sheet 2 of 2

(Cont.d)

## ALL LAMPS INOPERATIVE WITH CONTROL SWITCH ACTUATED









## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>MULTIPLE SWITCH CHECK</b>		
- With multiple switch <b>B4</b> activated to parking light position, check for presence of 12V between pin <b>3D</b> and ground		 	Repair wiring between pin <b>3D</b> of multiple switch <b>B4</b> and pin <b>5</b> of control unit <b>N41</b>
		 	Replace multiple switch <b>B4</b>
<b>A6</b>	<b>PUSHBUTTON PANEL CONTROL SWITCH CHECK</b>		
- With the ignition switch set to "run" check for presence of 12V between pin <b>4</b> of parking lamps control unit <b>N41</b> and ground		 	Carry-out step <b>A8</b>
		 	Carry out step <b>A7</b>
<b>A7</b>	<b>VOLTAGE CHECK</b>		
- With the ignition switch set to "run" check for presence of 12V between pin <b>4O</b> of fuse box <b>G1</b> and ground		 	Repair wiring between pin <b>4</b> of control unit <b>N41</b> and pin <b>6A</b> of fuse box <b>G1</b>
		 	Failure of power distribution circuit refer to the relevant circuit of sheet 2 of 2

(Cont.d)

ALL LAMPS INOPERATIVE WITH CONTROL SWITCH ACTUATED

TEST A

TEST STEPS		RESULTS	REMEDY
<b>A8</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 6 of parking lamps control unit N41 and ground		 	Repair wiring between pin 3G of fuse box G1 and pin 6 of control unit N41
		 	Carry out step A9
<b>A9</b>	<b>CONTROL UNIT CHECK</b>		
- Check for presence of 12V between pin 2 of control unit N41 and ground		 	Replace control unit N41
		 	Failure of power distribution circuit refer to the relevant circuit of sheet 2 of 2

End of test A

<b>LEFT FRONT POSITION AND SIDE MARKER LAMPS INOPERATIVE</b>	<b>TEST B</b>
--	---------------

TEST STEPS	RESULTS	REMEDY
<p><b>NOTES:</b> - In case the failure affects only one of the four position or side marker lamps, or the license plate lamp only, check integrity of the affected lamp and/or check for continuity of the related connecting wires and/or the ground connection.</p> <p>- In case the failure simultaneously affects the left front and right rear position lamps, left front and right rear side marker lamps, instrument panel lighting, position lamps indicator on instrument panel and pushbutton panel lighting, replace fuse F2 in fuse box G1.</p>		
<p><b>B1</b> CONTINUITY CHECK</p> <p>- Check for continuity between pin 10H of fuse box G1 and pin 12 of connector G150</p>	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 12 of connector G150 and pin 3A of head lamp E24</p> <p>Repair wiring between pin 12 of connector G150 and pin 10H of fuse box G1</p>

End of test B





## RIGHT FRONT POSITION AND SIDE MARKER LAMPS INOPERATIVE

## TEST C

TEST STEPS	RESULTS	REMEDY
<p><b>NOTES:</b> - In case the failure affects only one of the four position or side marker lamps, or the license plate lamp only, check integrity of the affected lamp and/or check for continuity of the related connecting wires and/or the ground connection.</p> <p>- In case the failure simultaneously affects the right front and left rear position lamps, right front and left rear side marker lamps, license plate lamp and position lamps indicator on instrument panel replace fuse F1 in fuse box G1.</p>		
<b>C1</b> CONTINUITY CHECK		
<ul style="list-style-type: none"> <li>- Check for continuity between pin 5D of fuse box G1 and pin 3 of connector G149</li> </ul>	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 3 of connector G149 and pin 3A of head lamp E23</p> <p>Repair wiring between pin 3 of connector G149 and pin 5D of fuse box G1</p>

End of test C


<b>LEFT REAR POSITION AND SIDE MARKER LAMPS, AND LICENSE PLATE LAMP INOPERATIVE</b>	<b>TEST D</b>
---	---------------

TEST STEPS	RESULTS	REMEDY
<p><b>NOTES:</b> - In case the failure affects only one of the four position or side marker lamps, or the license plate lamp only, check integrity of the affected lamp and/or check for continuity of the related connecting wires and/or the ground connection.</p> <p>- In case the failure simultaneously affects the right front and left rear position lamps, right front and left rear side marker lamps, license plate lamp and position lamps indicator on instrument panel, replace fuse <b>F1</b> in fuse box <b>G1</b>.</p> <p>- Central tail lamp <b>E27</b>, tail lamp right <b>E25</b>, tail lamp left <b>E26</b>, instrument panel illumination lamp <b>F12</b> and pushbutton panel <b>B66</b> include each two bulbs connected in parallel. Bulbs replacement should be necessary in case only one of the two bulbs does not switch on.</p>		
<b>D1</b>   CONTINUITY CHECK		
- Check for continuity between pin 5D of fuse box <b>G1</b> and pin 11 of connector <b>G171</b>	 	<p>Repair wiring between pin 11 of connector <b>G171</b> and connector <b>G187</b> (YEL-BLK wire)</p> <p>Repair wiring between pin 11 of connector <b>G171</b> and pin 5D of fuse box <b>G1</b></p>

End of test D

## RIGHT REAR SIDE MARKER LAMP INOPERATIVE



TEST E

TEST STEPS	RESULTS	REMEDY
<p><b>NOTES:</b> - In case the failure affects only one of the four position or side marker lamps, or the license plate lamp only check integrity of the affected lamp and/or check for continuity of the related connecting wires and/or the ground connection.</p> <p>- In case the failure simultaneously affects the left front and right rear position lamps, left front and right rear side marker lamps, instrument panel, lighting position lamps indicator on instrument panel and pushbutton panel, replace fuse F2 in fuse box G1.</p> <p>- Central tail lamp E27, tail lamp right E25, left tail lamp unit E26, instrument panel illumination lamp F12 and pushbutton panel B66 include each two bulbs connected in parallel. Bulbs replacement should be necessary in case only one of the two bulbs does not switch on.</p>		
E1 CONTINUITY CHECK		
<ul style="list-style-type: none"> <li>- Check for continuity between pin 4D of fuse box G1, pin 9 of connector G170, and connector G188</li> </ul>		<p>Repair wiring towards ground point G188</p> <p>Repair or replace wires, as necessary</p>

End of test E

## POSITION LAMPS INDICATOR ON INSTRUMENT PANEL INOPERATIVE







TEST F

TEST STEPS	RESULTS	REMEDY
<p><b>NOTES:</b> - Before carrying-out any troubleshooting, check the integrity of warning lamp on instrument panel by pressing the test button.</p> <p>- In case the failure simultaneously affects the right front and left rear position lamps, right front and left rear side marker lamps, license plate lamp and position lamps indicator on instrument panel, replace fuse F1 in fuse box G1.</p>		
<b>F1</b>   VOLTAGE CHECK	 ►  ►	<p>Replace Instrument panel C10</p> <p>Repair wiring between pin 8C of Instrument panel C10 , pin 5L and pin 3L of fuse box G1</p>
<p>- Check for presence of 12V between pin 8C of instrument panel C10 and ground</p>		

End of test F

## PUSHBUTTON PANEL LIGHTING INOPERATIVE







TEST G

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Lighting of pushbutton panel B66 includes two bulbs connected in parallel. In case of uneven lighting of pushbutton panel, it is necessary to replace only the burned out bulb.</p>		
<b>G1</b> INSTRUMENT PANEL LIGHTING CHECK	 ►  ►	Carry-out step G2  Carry out TEST H
- Check illumination of instrument panel and lamp F12.		 ►  ►
<b>G2</b> VOLTAGE CHECK	 ►  ►	
- Check for presence of 12V between pin 3 of pushbutton panel B66 and ground		<b>G3</b> REHOSTAT OUTPUT CHECK  - Check for presence at pin 1 of pushbutton panel of a voltage depending on setting of dimmer switch B16

End of test G

## INSTRUMENT PANEL LIGHTING INOPERATIVE







TEST H

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Lighting of instrument panel includes eight bulbs connected in parallel. In case of uneven lighting of instrument panel, it is necessary to replace only the burned out lamp(s).</p>			
H1	PUSHBUTTON PANEL LIGHTING CHECK		
	- Check illumination of pushbutton panel B66	 	<p>Carry-out step H4</p> <p>Carry out step H2</p>
H2	VOLTAGE CHECK		
	- Check for presence of 12V between pin "+" of dimmer switch B16 and ground	 	<p>Carry-out step H3</p> <p>Replace wiring between pin "+" of B16 and pin 1S of G1</p>
H3	GROUNDING CHECK		
	- Check for presence of 0V at pin "-" of dimmer switch B16	 	<p>Replace dimmer switch B16</p> <p>Replace wiring between pin "-" of B16, pin 12E and ground point G174</p>

(Cont.d)

## INSTRUMENT PANEL LIGHTING INOPERATIVE





## TEST H

TEST STEPS		RESULTS	REMEDY
<b>H4</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2C of instrument panel and ground		 ►  ►	Carry-out step H5  Repair wiring between pin 2C of Instrument panel and pin 2C of fuse box G1
<b>H5</b>	<b>DIMMER SWITCH OUTPUT CHECK</b>		
- Check for presence at pin 1C of instrument panel C10 of a voltage depending on setting of dimmer switch B16		 ►  ►	Replace instrument panel  Carry out step H6
<b>H6</b>	<b>DIMMER SWITCH OUTPUT CHECK</b>		
- Check for presence at pin 5E of fuse box G1 of a voltage depending on setting of dimmer switch B16		 ►  ►	Repair wiring between pin 1C of fuse box G1 and pin 1C of instrument panel  Repair wiring between pin 10E of fuse box G1, pin 2 of connector G165 and pin 5E of fuse box G1

End of test H

## TEST PUSHBUTTON AND RHEOSTAT SERIGRAPHS LIGHTING INOPERATIVE

TEST I

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Lighting of tet button and rheostat serigraphs includes two bulbs connected in parallel. In case of uneven lighting of serigraphs, it is necessary to replace only the burned out lamp.</p>			
I1	PUSHBUTTON PANEL AND INSTRUMENT PANEL LIGHTING CHECK		
	- Check operation of pushbutton panel B66 and instrument panel lighting	 ►  ►	Carry-out step I2  Replace dimmer switch B16
I2	RHEOSTAT OUTPUT CHECK		
	- Check for presence at terminals of lamps F12 (WHT-BLK and YEL wires) of a voltage depending on setting of dimmer switch B16	 ►  ►	Replace lamps F12  Replace wiring between lamps F12 (WHT-BLK and YEL wires) and dimmer switch B16 (pins + and V)

End of test I



# LAMPS - - REVERSE AND GEAR SELECTOR ILLUMINATION



## GENERAL

To facilitate driving, the gear selector is illuminated by appropriate lighting. The vehicle is equipped with back-up lamps, located in the central rear lamp unit. The lights are turned on when reverse gear is selected.

This selection can be accomplished, either on cars equipped with manual or automatic transmission, by setting the lever to the appropriate position. Below the transmission (automatic or manual) is installed the back-up lamp switch that controls the illumination of the related lights of the central rear lamp unit.

The schematic diagram shows the gear selector illumination lamps that is installed on vehicles equipped with automatic transmission. The system is protected, in both cases, by fuse F10 (20A) REVERSE LAMP in the fuse box G1.

## FUNCTIONAL DESCRIPTION

Battery voltage (12V), present when the ignition key is set to "run", through fuse F10 of fuse box G1, lights up of gear selector illumination lamps automatic transmission F38.

The same voltage reaches the back-up lamp in central tail lamps E27 lighting it up, by means of appropriate switches.












These switches are different dependently of gear installed on the vehicle.

On vehicles equipped with automatic transmission, the back-up lamp illuminates by the back-up lamp switch and switch H16.



On vehicles equipped with manual transmission, the back-up lamp illuminates by the back-up lamp switch H2.


TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT			
	F10	E27	F38	H16
	FUSE	BACK-UP LAMP	BULB	SWITCH
GEAR SELECTOR ILLUMINATION INOPERATIVE (AUTOMATIC TRANSMISSION)	●		●	
BACK-UP LAMP INOPERATIVE	●	●		●

<p>Central tail lamps (mobile)</p>	<p><b>E27</b></p>	<p>Gear selector illumination lamps automatic transmission</p>	<p><b>F38</b></p>
			
<p>Fuse box</p>	<p><b>G1 H</b></p>	<p>Fuse box</p>	<p><b>G1 O</b></p>
			
<p>Connector, circuit board to engine compartment left side wiring</p>	<p><b>G150</b></p>	<p>Connector, circuit board to left rear wiring</p>	<p><b>G171</b></p>
			
<p>Steering wheel column support ground</p>	<p><b>G174</b></p>		
<p>Trunk left side ground</p>	<p><b>G185</b></p>	<p>Connector, left rear wiring to rear central lamp wiring</p>	<p><b>G194</b></p>
			
<p>Connector, circuit board to automatic gear lever wiring</p>	<p><b>G233</b></p>	<p>Back-up lamp switch</p>	<p><b>H2</b></p>
			









(Cont.d)

Start and reverse gear inhibitor switch	H16	Electronic control units power supply relay	I51
 <p>1PNK-G223</p> <p>1WHT-G223</p>		 <p>1BLK-G174</p> <p>1BLK-G223</p>	



## GEAR SELECTOR ILLUMINATION INOPERATIVE (AUTOMATIC TRANSMISSION)

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
- Check for integrity of fuse <b>F10</b> in fuse box <b>G1</b>		 	Carry-out <b>step A2</b>  Replace <b>fuse F10</b>
<b>A2</b>	<b>BACK-UP LAMP CHECK</b>		
- With ignition key set to "run", select "R" position and check for lighting of the back up lamp in the central tail lamps <b>E27</b>		 	Carry-out <b>step A4</b>  Carry-out <b>step A3</b>
<b>A3</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run", check for presence of 12V between pin <b>4O</b> of fuse box <b>G1</b> and ground		 	Repair wiring between <b>pin 1</b> of connector <b>G233</b> and <b>pin 1M</b> of fuse box <b>G1</b>  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>A4</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) on pin <b>3</b> of connector <b>G233</b>		 	Carry-out <b>step A5</b>  Repair wiring between <b>pin 3</b> of connector <b>G233</b> and ground point <b>G174</b>

(Cont.d)

## GEAR SELECTOR ILLUMINATION INOPERATIVE (AUTOMATIC TRANSMISSION)













## TEST A

TEST STEPS		RESULTS	REMEDY
A5	LAMP CHECK		
<ul style="list-style-type: none"> <li>- Check for integrity of gear selector illumination lamps automatic transmission F38</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pins 1 and 3 of connector G233, and then between pins 1 and 2 of lamp F38</p> <p>Replace lamps F38</p>

End of test A



















<b>BACK-UP LAMP INOPERATIVE</b>	<b>TEST B</b>
---------------------------------	---------------

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> The back-up lamp included in the central tail lamps E27 is composed of two bulbs; it is essential to replace only the one burned out.</p>			
<b>B1</b>	<b>FUSE CHECK</b>		
- Check for integrity of fuse F10 in fuse box G1		 	Carry-out step B2
		 	Replace fuse F10
<b>B2</b>	<b>AUTOMATIC TRANSMISSION LAMP ILLUMINATION CHECK</b>		
- With ignition key set to "run" check that the manual or automatic transmission illumination lamp is on		 	Carry-out step B4
		 	Carry-out step A3
<b>B3</b>	<b>VOLTAGE CHECK</b>		
- With ignition key set to "run" check for presence of 12V between pins 1 and 4 of connector G194		 	Carry-out step B4
		 	Carry-out step B5

(Cont.d)

## BACK-UP LAMP INOPERATIVE

## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B4</b>	<b>LAMPS CHECK</b>		
	- Check for integrity of back-up lamps in central tail lamps E27	 	Repair wiring between pins 3 and 4 of lamp E27 and then between pin 4 and 1 of G194
		 	Replace back-up lamp E27
<b>B5</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) on pin 1 of G194	 	Carry-out step B6
		 	Repair wiring between pin 1 of G194 and ground point G185
<b>B6</b>	<b>VOLTAGE CHECK</b>		
	- With the ignition key set to "run", check for presence of 12V between pin 9 of connector G171 and ground	 	Repair wiring between pin 9 of connector G171 and pin 4 of G194
		 	Carry-out step B7
<b>B7</b>	<b>VOLTAGE CHECK</b>		
	- With the ignition key set to "run", check for presence of 12V between pin 2 of connector G233 and ground	 	Repair wiring between pin 9 of G171 and pin 2 of G233
		 	Carry-out step B8

(Cont.d)

## BACK-UP LAMP INOPERATIVE

## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B8</b>	<b>SWITCH CHECK</b>		
<ul style="list-style-type: none"> <li>- With the ignition key set to "run", check for mechanical operation of start and reverse gear inhibitor switch H16 (closed circuit between PNK, and WHT wires with reverse gear selected)</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pin 2 of G233 and switch H16 (WHT wire) and between pin 1 of G233 and switch H16 (PNK wire)</p> <p>Replace switch H16</p>

End of test B

# LAMPS - - TURN SIGNAL AND HAZARD WARNING



## GENERAL

Actuation of turn signal lamps is dependent on setting of ignition key to "run" position, and on actuation of the L.H. section of the multiple switch.

Moving the L.H. section of the multiple switch upwards actuates the right turn signal lamps, while moving the multiple switch downwards actuates the left turn signal lamps; a corresponding warning lamp on the instrument panel is also switched on any time the turn signal lamps are actuated.

Once a turn signal lamp is actuated, the multiple switch locks in the selected position until the steering wheel returns it to its rest position.

While overtaking another vehicle, momentary actuation of turn signal lamps can be obtained by slightly moving the multiple switch (without engaging the lock) and holding it in position as long as required.

Hazard lamps actuation is obtained by means of a switch, and is not dependent on setting of the ignition key.

Actuation of the control switch turns on the four turn signal lamps simultaneously and the corresponding warning lamp on the instrument panel.

The circuit is protected by two fuses in the fuse box G1, as follows:

- fuse F11 (7.5A) POSITION LAMPS.
- fuse F17 (20A) HAZARD LAMPS.

## OPERATIONAL DESCRIPTION

The battery power (12V) available when the ignition key is set to "run" position is applied to fuse F11 in fuse box G1.

Fuse F11 protects the turn signal lamps intermittence circuit power supply line.

The power (12V) is applied to contacts of turn signal

lamps and hazard lamps relay I24, which powers the emergency lamps relay N13 in fuse box G1.

When the left (or right) turn signal lamps are actuated by means of the multiple switch, the front head lamp left E24 (or right E23) receives from fuse box G1 an intermittent signal for the actuation of the turn signal lamps.

The same signal is supplied to pin 11 (or pin 8) of the rear lamps control unit N44; the control unit N44 will then supply through its pin 6 (or pin 1) an intermittent signal for the actuation of the turn signal lamp in the tail lamp, left (fixed part) E26 (or right E25). Actuation of the left (or right) turn signal lamps is indicated by intermittent illumination of the relevant warning lamp on instrument panel C10.

The hazard lamps are actuated by pressing the relevant pushbutton on the pushbutton panel B66 (position lamps, hazard signal lamps and fuel filler lid opening).

The 12V power (available at all times) is supplied to relays I24 and I248 through fuse F17 in fuse box G1.

Actuation of the hazard lamps switch on pushbutton panel B66 energizes the relays I24 and I248 and the 12V powers the hazard lamps relay N13 in fuse box G1.

The intermittent signal is directed from the turn signal lamp and hazard lamps relay I24 to the front head lamp left E24 (pin 7H of fuse box G1) for the actuation of the front hazard lamps, and to the rear lamps control unit N44 (pins 11 and 8).

The control unit N44 transfers the intermittent signal to tail lamp, left (fixed part) E26 (pin 6) and to the tail lamp right (fixed part) E25 (pin 1) for the actuation of the rear hazard lamps.

Furthermore, when the turn signal lamps are turned on, the control unit N44 inhibits the check performed by the Alfa Romeo Control unit N22 on the stop lamps circuit through the signal activated on pin 9.

Actuation of the hazard lamps is indicated by intermittent illumination of the relevant warning lamp on instrument panel C10.











## TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT														
	F11 FUSE	F12 FUSE	C10 INST. PANEL WARN. LAMP	C10 R.T. SIGNAL WARN. LAMP	C10 L.T. SIGNAL WARN. LAMP	E23 R.H.F. TURN SIGNAL LAMP	E24 L.H.F. TURN SIGNAL LAMP	E25 R.H.R. TURN SIGNAL LAMP	E26 R.H.R. TURN SIGNAL LAMP	B6 MULTIPLE SWITCH	B66 PUSHBUTTON PANEL	I24 RELAY	I49 RELAY	N13 RELAY	N44 CONTROL UNIT
ALL TURN SIGNAL LAMPS INOPERATIVE	●											●		●	
BOTH LEFT TURN SIGNAL LAMPS INOPERATIVE										●					
BOTH RIGHT TURN SIGNAL LAMPS INOPERATIVE										●					
LEFT FRONT TURN SIGNAL LAMP ONLY INOPERATIVE						●									
RIGHT FRONT TURN SIGNAL LAMP ONLY INOPERATIVE						●									
BOTH REAR TURN SIGNAL LAMPS INOPERATIVE															●
LEFT REAR TURN SIGNAL LAMP ONLY INOPERATIVE									●						●
RIGHT REAR TURN SIGNAL LAMP ONLY INOPERATIVE								●							●


FAULT TYPE	FAILED COMPONENT														
	FUSE F11	FUSE F17	INST. PANEL WARN. LAMP C10	R.T. SIGNAL WARN. LAMP C10	L.T. SIGNAL WARN. LAMP C10	R.H.F. TURN SIGNAL LAMP E23	L.H.F. TURN SIGNAL LAMP E24	R.H.R. TURN SIGNAL LAMP E25	R.H.R. TURN SIGNAL LAMP E26	MULTIPLE SWITCH B6	PUSHBUTTON PANEL B66	RELAY I24	RELAY I24B	RELAY M13	CONTROL UNIT N44
LEFT TURN SIGNAL LAMPS WARNING LAMP ON INSTRUMENT PANEL INOPERATIVE					•										
RIGHT TURN SIGNAL LAMPS WARNING LAMP ON INSTRUMENT PANEL INOPERATIVE				•											
ALL HAZARD LAMPS INOPERATIVE		•								•	•	•	•		
LEFT FRONT HAZARD LAMP INOPERATIVE							•								
RIGHT FRONT HAZARD LAMP INOPERATIVE						•									
BOTH REAR HAZARD LAMPS INOPERATIVE															•
LEFT REAR HAZARD LAMP INOPERATIVE								•							•
RIGHT REAR HAZARD LAMP INOPERATIVE															•
LAMP ON INSTRUMENT PANEL INOPERATIVE			•												

NOTE: Before attempting any troubleshooting ascertain the integrity of the affected warning lamp on the instrument panel by pressing the test button.















Turn signal lamps switch	Turn signal lamps switch
	
Position lights/Hazard lights/Fuel filler lid pushbutton panel	Instrument panel
	
Instrument panel	Right front fog lamp
	
Front head lamp - right	Left front fog lamp
	
Front head lamp - left	Tail lamp, right (fixed part)
	

(Cont.d)




(Cont.d)

<p>Engine compartment left side ground connection</p>	<p><b>G53b</b></p>	<p>Connector, circuit board to engine compartment right side wiring</p>	<p><b>G149</b></p>
			
<p>Connector, circuit board to engine compartment left side wiring</p>	<p><b>G150</b></p>	<p>Connector, circuit board to right rear wiring</p>	<p><b>G170</b></p>
			
<p>Connector, circuit board to left rear wiring</p>	<p><b>G171</b></p>	<p>Steering wheel column support ground</p>	<p><b>G174</b></p>
			
<p>Trunk left side ground</p>	<p><b>G185</b></p>	<p>Trunk right side ground</p>	<p><b>G186</b></p>
			
<p>Connector, circuit board to automatic</p>	<p><b>G233</b></p>	<p>Board wiring to aft console wiring two-way connector</p>	<p><b>G244</b></p>
			
<p>Rear window lifts relay</p>	<p><b>I13</b></p>	<p>Turn signal lamps and hazard lamps relay</p>	<p><b>I24</b></p>
			









(Cont.d)

<p>Turn signal lamps and hazard lamps relay</p>	<p>24B</p>	<p>Electronic control units power supply relay</p>	<p>151</p>
<p>Parking lamps conl unit</p>	<p>N41</p>	<p>Rear lamps control unit</p>	<p>N44</p>



## ALL TURN SIGNAL LAMPS INOPERATIVE





## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>F11</b> in fuse box <b>G1</b> for integrity		 ►  ►	Carry-out step <b>A2</b>  Replace fuse <b>F11</b>
<b>A2</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run", check for presence of 12V between pin <b>40</b> of fuse box <b>G1</b> and ground		 ►  ►	Carry-out step <b>A3</b>  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>A3</b>	<b>VOLTAGE CHECK</b>		
- With ignition key set to "run", check for presence of 12V between pin <b>87</b> of turn signal lamps and hazard lamps relay <b>I24</b> and ground		 ►  ►	Carry-out step <b>A4</b>  Repair wiring between pin <b>87a</b> of relay <b>I24</b> and pin <b>6A</b> of fuse box <b>G1</b>
<b>A4</b>	<b>RELAY CHECK</b>		
- Check relay <b>I24</b> for proper operation		 ►  ►	Carry-out step <b>A5</b>  Replace relay <b>I24</b>

(Cont.d)

## ALL TURN SIGNAL LAMPS INOPERATIVE





## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 7A of fuse box G1 and ground		 ►  ►	Carry - out step A6  Repair wiring between pin 30 of relay I24 and pin 7A of fuse box G1
<b>A6</b>	<b>INTERMITTENT SIGNAL CHECK</b>		
- Check for presence of intermittent signal at pin 4G of fuse box G1		 ►  ►	Repair wiring between pin 4G of fuse box G1 and pin 4A of switch B6  Replace relay N13 in fuse box G1

End of test A

## BOTH LEFT TURN SIGNAL LAMPS INOPERATIVE

## TEST B

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Before attempting any troubleshooting ascertain the integrity of the warning lamp on instrument panel by pressing the test button: replace the affected lamp if it does not illuminate.</p>			
<b>B1</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- Check that left turn signal lamps warning lamp illuminates on instrument panel</li> </ul>		 ►	Repair wiring between pin 10 of connector G150 and pin 7H of fuse box G1
		 ►	Carry-out step B2
<b>B2</b>	<b>INTERMITTENT SIGNAL CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of intermittent signal at pin 1D of switch B6</li> </ul>		 ►	Repair wiring between pin 1D of switch B6 and pin 1G of fuse box G1
		 ►	Replace switch B6

End of test B



## BOTH RIGHT TURN SIGNAL LAMPS INOPERATIVE

## TEST C

## TEST STEPS

## RESULTS

## REMEDY

**NOTE:** Before attempting any troubleshooting ascertain the integrity of the warning lamp on instrument panel by pressing the test button: replace the affected lamp if it does not illuminate.

## C1 WARNING LAMP CHECK

- Check that right turn signal lamps warning lamp illuminates on instrument panel

OK

~~OK~~

Repair wiring between pin 10 of connector G149 and pin 10I of fuse box G1

Carry-out step C2

## C2 INTERMITTENT SIGNAL CHECK

- Check for presence of intermittent signal at pin 3A of switch B6

OK

~~OK~~





Repair wiring between pin 3A of switch B6 and pin 5G of fuse box G1

Replace switch B6

End of test C

## LEFT FRONT TURN SIGNAL LAMP ONLY INOPERATIVE





## TEST D

TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>LAMP CHECK</b>		
	- Check bulb in front head lamp left E24 for integrity	 ►  ►	Carry-out step D2  Replace bulb in front head lamp left E24
<b>D2</b>	<b>INTERMITTENT SIGNAL CHECK</b>		
	- Check for presence of intermittent signal at pin 2A of front head lamp left E24	 ►  ►	Repair wiring between pin 1A of front head lamp left E24 and ground point G53b  Repair wiring between pin 2A of front head lamp left E24 and pin 10 of connector G150

End of test D

## RIGHT FRONT TURN SIGNAL LAMP ONLY INOPERATIVE





## TEST E

TEST STEPS		RESULTS	REMEDY
<b>E1</b>	<b>LAMP CHECK</b>		
- Check bulb in front head lamp right E23 for integrity		 ►  ►	Carry-out step E2  Replace bulb in front head lamp right E23
<b>E2</b>	<b>INTERMITTENT SIGNAL CHECK</b>		
- Check for presence of intermittent signal at pin 2A of front head lamp right E23		 ►  ►	Repair wiring between pin 1A of front head lamp right E23 and ground point G53a  Repair wiring between pin 2A of front head lamp right E23 and pin 10 of connector G149

End of test E

## BOTH REAR TURN SIGNAL LAMPS INOPERATIVE





## TEST F

TEST STEPS		RESULTS	REMEDY
<b>F1</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 10 of rear lamps control unit N44 and ground	 ►  ►	Carry-out step F2  Repair wiring between pin 10 of control unit N44 and pin 7A of fuse box G1
<b>F2</b>	<b>CONTROL UNIT CHECK</b>		
	- Check for presence of 0V (zero) at pin 12 of control unit N44	 ►  ►	Replace control unit N44  Repair wiring between pin 2 of connector G244, pin 3 of connector G233 and ground point G174

End of test F

## LEFT REAR TURN SIGNAL LAMP ONLY INOPERATIVE





## TEST G

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> In case the failure affects only one of the two stop lamps, check the integrity of the affected lamp and/or check the continuity of the two relevant connecting wires.</p>		
<b>G1</b> INTERMITTENT SIGNAL CHECK	 ►  ►	Carry-out step G2  Repair wiring between pin 10 of connector G150 and pin 11 of control unit N44
- Check for presence of intermittent signal at pin 11 of rear lamps control unit N44		 ►  ►
<b>G2</b> INTERMITTENT SIGNAL CHECK	- Check for presence of intermittent signal at pin 6 of control unit N44	

End of test G

## RIGHT REAR TURN SIGNAL LAMP ONLY INOPERATIVE

## TEST H

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> In case the failure affects only one of the two stop lamps, check the integrity of the affected lamp and/or check the continuity of the two relevant connecting wires.</p>			
<b>H1</b>	<b>INTERMITTENT SIGNAL CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of intermittent signal at pin 8 of rear lamps control unit N44</li> </ul>		 ▶  ▶	<p>Carry-out step H2</p> <p>Repair wiring between pin 10 of connector G149 and pin 8 of control unit N44</p>
<b>H2</b>	<b>INTERMITTENT SIGNAL CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of intermittent signal at pin 1 of control unit N44</li> </ul>		 ▶  ▶	<p>Repair wiring between pin 12 of connector G170 and pin 1 of control unit N44</p> <p>Replace control unit N44</p>

End of test H





LEFT TURN SIGNAL LAMPS WARNING LAMP ON INSTRUMENT PANEL  
INOPERATIVE

## TEST I

TEST STEPS		RESULTS	REMEDY
I1	INTERMITTENT SIGNAL CHECK		
- Check for presence of intermittent signal at pin 87 of turn signal lamps and hazard lamps relay I248		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step I2</p> <p>Repair wiring between pin 87 of relay I248 and pin 1A of fuse box G1</p>
I2	INTERMITTENT SIGNAL CHECK		
- Check for presence of intermittent signal at pin 7A of instrument panel C10		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace lamp on instrument panel C10</p> <p>Repair wiring between pin 7A of instrument panel C10 and pin 87 of relay I248</p>

End of test I

**RIGHT TURN SIGNAL LAMPS WARNING LAMP ON INSTRUMENT PANEL  
INOPERATIVE**
**TEST J**









TEST STEPS		RESULTS	REMEDY
<b>J1</b>	<b>INTERMITTENT SIGNAL CHECK</b>		
	- Check for presence of intermittent signal at pin 87a of turn signal lamps and hazard lamps relay <b>I24B</b>	 	Carry-out step J2  Repair wiring between pin 87a of relay <b>I24B</b> and pin 2A of fuse box <b>G1</b>
<b>J2</b>	<b>INTERMITTENT SIGNAL CHECK</b>		
	- Check for presence of intermittent signal at pin 6A of instrument panel <b>C10</b>	 	Replace lamp on instrument panel <b>C10</b>  Repair wiring between pin 6A of instrument panel <b>C10</b> and pin 87a of relay <b>I24B</b>

**End of test J**



## ALL HAZARD LAMPS INOPERATIVE

## TEST K

TEST STEPS		RESULTS	REMEDY
K1	FUSE CHECK		
- Check fuse F17 in fuse box G1 for integrity		 ►  ►	Carry-out step K2  Replace fuse F17
K2	GROUNDING CHECK		
- Check for presence of 0V (zero) at pin 6 of pushbutton panel B66		 ►  ►	Carry-out step K3  Repair wiring between pin 6 of pushbutton panel B66 and ground point G174
K3	SWITCH CHECK		
- With hazard lamp switch actuated, check for presence of 0V (zero) at pin 4 of pushbutton panel B66		 ►  ►	Carry-out step K4  Replace pushbutton panel B66
K4	GROUNDING CHECK		
- With hazard lamp switch actuated, check for presence of 0V (zero) at pin 85 of relays I24 and I24B		 ►  ►	Carry-out step K5  Repair wiring between pin 4 of pushbutton panel B66 and pin 85 of relays I24 and I24B

(Cont.d)

ALL HAZARD LAMPS INOPERATIVE	TEST K
------------------------------	--------

TEST STEPS		RESULTS	REMEDY
<b>K5</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 86 of relay I24A and ground		OK ►	Carry-out step K7
		<del>OK</del> ►	Carry-out step K6
<b>K6</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2N of fuse box G1 and ground		OK ►	Repair wiring between pins 86 and 87 of relay I24 and pin 86 of relay I28 and pin 5A of fuse box G1
		<del>OK</del> ►	Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>K7</b>	<b>RELAY CHECK</b>		
- Check relay I24 for proper operation		OK ►	Carry-out step K8
		<del>OK</del> ►	Replace relay I24A
<b>K8</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 7A of fuse box G1 and ground		OK ►	Carry-out step K9
		<del>OK</del> ►	Repair wiring between pin 30 of relay I24 and pin 7A of fuse box G1

(Cont.d)







ALL HAZARD LAMPS INOPERATIVE

TEST K

TEST STEPS		RESULTS	REMEDY
<b>K9</b>	<b>INTERMITTANCE CHECK</b>		
- Check that hazard lamps relay N13 in fuse box G1 is operational by verifying the presence of intermittent signal at pin 3A of fuse box G1		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Carry-out step K10</p> <p>Replace relay N13</p>
<b>K10</b>	<b>INTERMITTENCE SIGNAL CHECK</b>		
- Check for presence of intermittent signal at pin 30 of relay I24 B		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Replace relay I24 B</p> <p>Repair wiring between pin 30 of relay I24 B and pin 3A of fuse box G1</p>

End of test K

<b>LEFT FRONT HAZARD LAMP INOPERATIVE</b>	<b>TEST L</b>
---	---------------

TEST STEPS		RESULTS	REMEDY
<b>L1</b>	<b>LAMP CHECK</b>		
- Check bulb in front head lamp left E24 for integrity		 	Carry-out step L2  Replace bulb in front head lamp left E24
<b>L2</b>	<b>INTERMITTENT SIGNAL CHECK</b>		
- Check for presence of intermittent signal at pin 1A of fuse box G1		 	Carry-out step L3  Repair wiring between pin 87 of relay I28 and pin 1A of fuse box G1
<b>L3</b>	<b>INTERMITTENT SIGNAL CHECK</b>		
- Check for presence of intermittent signal at pin 10 of connector G150		 	Carry-out step L4  Repair wiring between pin 10 of connector G150 and pin 7H of fuse box G1

(Cont.d)

LEFT FRONT HAZARD LAMP INOPERATIVE







TEST L

TEST STEPS		RESULTS	REMEDY
L4	INTERMITTENT SIGNAL CHECK		
- Check for presence of intermittent signal at pin 2A of front head lamp left E24		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 1A of front head lamp left E24 and ground point G53b</p> <p>Repair wiring between pin 2A of front head lamp left E24 and pin 10 of connector G150</p>

End of test L

## RIGHT FRONT HAZARD LAMP INOPERATIVE

## TEST M

TEST STEPS		RESULTS	REMEDY
<b>M1</b>	<b>LAMP CHECK</b>		
- Check bulb in front head lamp right E23 for integrity		 	Carry-out step M2  Replace bulb in front head lamp right E23
<b>M2</b>	<b>INTERMITTENT SIGNAL CHECK</b>		
- Check for presence of intermittent signal at pin 2A of fuse box G1		 	Carry-out step M3  Repair wiring between pin 87a of relay I2 and pin 2A of fuse box G1
<b>M3</b>	<b>INTERMITTENT SIGNAL CHECK</b>		
- Check for presence of intermittent signal at pin 10 of connector G149		 	Carry-out step M4  Repair wiring between pin 10 of connector G149 and pin 10 of fuse box G1

(Cont.d)





RIGHT FRONT HAZARD LAMP INOPERATIVE

TEST M

TEST STEPS		RESULTS	REMEDY
M4	INTERMITTENT SIGNAL CHECK		
- Check for presence of intermittent signal at pin 2A of front head lamp right E23		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 1A of front head lamp right E23 and ground point G53a</p> <p>Repair wiring between pin 2A of front head lamp right E23 and pin 10 of connector G149</p>

End of test M

**BOTH REAR HAZARD LAMPS INOPERATIVE****TEST N**





TEST STEPS		RESULTS	REMEDY
<b>N1</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 10 of rear lamps control unit N44 and ground		 	Carry-out step N2  Repair wiring between pin 10 of control unit N44 and pin 7A of fuse box G1
<b>N2</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 12 of control unit N44		 	Replace control unit N44  Repair wiring between pin 12 of control unit N44, pin 2 of connector G244, pin 3 of connector G233 and ground point G174

**End of test N**



## LEFT REAR HAZARD LAMP INOPERATIVE





TEST O

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> In case the failure affects only one of the two stop lamps, check the integrity of the affected lamp and/or check the continuity of the two relevant connecting wires.</p>			
O1	INTERMITTENT SIGNAL CHECK		
	- Check for presence of intermittent signal at pin 11 of rear lamps control unit N44	 	<p>Carry-out step O2</p> <p>Repair wiring between pin 10 of connector G150 and pin 11 of control unit N44</p>
O2	CONTROL UNIT CHECK		
	- Check for presence of intermittent signal at pin 6 of control unit N44	 	<p>Repair wiring between pin 14 of connector G171 and pin 6 of control unit N44</p> <p>Replace control unit N44</p>

End of test O

## RIGHT REAR HAZARD LAMP INOPERATIVE

TEST P

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> In case the failure affects only one of the two stop lamps, check the integrity of the affected lamp and/or check the continuity of the two relevant connecting wires.</p>			
<b>P1</b>	<b>INTERMITTENT SIGNAL CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of intermittent signal at pin 8 of rear lamps control unit N44</li> </ul>		 ▶  ▶	<p>Carry-out step P2</p> <p>Repair wiring between pin 10 of connector G149 and pin 8 of control unit N44</p>
<b>P2</b>	<b>CONTROL UNIT CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of intermittent signal at pin 1 of control unit N44</li> </ul>		 ▶  ▶	<p>Repair wiring between pin 12 of connector G170 and pin 1 of control unit N44</p> <p>Replace control unit N44</p>

End of test P


## HAZARD LAMPS WARNING LAMP ON INSTRUMENT PANEL INOPERATIVE

## TEST Q

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Before attempting any troubleshooting, ascertain the integrity of the warning lamp on instrument panel by pressing the test button: replace the affected lamp if it does not illuminate.</p>			
<b>Q1</b>	<b>VOLTAGE CHECK</b>		
	<ul style="list-style-type: none"> <li>Check for presence of 12V between pin 3D of instrument panel C10 and ground</li> </ul>	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step Q2</p> <p>Repair wiring between pin 3D of instrument panel C10 and pin 3C of fuse box G1</p>
<b>Q2</b>	<b>GROUNDING CHECK</b>		
	<ul style="list-style-type: none"> <li>Check for presence of 0V (zero) at pin 4A of fuse box G1</li> </ul>	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step Q3</p> <p>Repair wiring between pin 85 of relay 124B and pin 4A of fuse box G1</p>
<b>Q3</b>	<b>GROUNDING CHECK</b>		
	<ul style="list-style-type: none"> <li>Check for presence of 0V (zero) at pin 2D of instrument panel C10</li> </ul>	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace instrument panel C10</p> <p>Repair wiring between pin 2D of instrument panel C10 and pin 4C of fuse box G1</p>

End of test Q

# LOCKS - - POWER DOOR



## GENERAL

The car doors can be automatically locked/unlocked from the exterior by means of the lock of either front door, or from the interior.

Acting from the interior, the electric door lock system can be operated in two different ways: by means of the switch located on the central console (with the ignition key set to "run" position only) or by means of the pushbutton located on both front doors (when the doors are closed). The locking/unlocking of the two rear doors is obtained by acting on the pushbutton of the affected door only. With the ignition key set to the "run" position, improper locking of either door is indicated by the illumination of the relevant warning lamp on the instrument panel.

The system is protected by two fuses in the fuse box G1 as follows:

- F16 fuse (10A) DOOR LOCK CONTROL UNIT.
- F18 fuse (25A) DOOR LOCK SWITCH.

## OPERATIONAL DESCRIPTION

12V from the battery is applied to the door lock control unit N11 through the F16 fuse in the fuse box G1; moreover, the 12V supplied when the ignition key is in the

"run" position, energize the relay I73 located in the fuse box G1. The relay, when energized, supplies 12V to the integral light switch B20 through the fuse F18.

By pressing the switch B20 in either direction, a 12V pulse is applied between pins 4 and 5 of the door lock control unit N11 (e.g. positive at pin 4).

In the above condition the control unit locks the doors by means of motors P10, P11, P12 and P13.

If the switch B20 is pressed in the opposite direction the polarity of voltage applied to pins 4 and 5 of the control unit is reversed: in this condition the control unit unlocks the doors by reversing the operation of motors P10, P11, P12 and P13.

The front door motors P10 and P11 are provided with a contactor that can be operated by means of the door lock or by means of a switch located on the interior side of the door.


Operation of either system on the front doors connects to ground the control unit N11 at pin 2 or at pin 3 which in turn actuates the electric door lock/unlock system.

The two front doors can be individually locked/unlocked by acting on the relevant switches located on the inner side of the doors.

Inproper locking, or an open door, is indicated on the instrument panel by the illumination of the corresponding warning light of the Alfa Romeo Control control unit, treated in another chapter.

TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT								
	F16 FUSE	F18 FUSE	B20 SWITCH	I73 RELAY	P10 MOTOR	P11 MOTOR	P12 MOTOR	P13 MOTOR	N11 CONTROL UNIT
INTERIOR AND EXTERNAL LOCK/UNLOCK SYSTEM INOPERATIVE	•								•
INTERIOR LOCK/UNLOCK SYSTEM INOPERATIVE		•	•	•					•
EXTERIOR LOCK/UNLOCK SYSTEM INOPERATIVE					•	•			•
LEFT REAR DOOR LOCK/UNLOCK SYSTEM INOPERATIVE								•	
RIGHT REAR DOOR LOCK/UNLOCK SYSTEM INOPERATIVE							•		





(Cont.d)



<p>Connector, front doors to right rear wiring <b>G167</b></p>	<p>Connector, front doors to left front door wiring <b>G168</b></p>
<p>Connector, front doors to left rear wiring <b>G169</b></p>	<p>Steering wheel column support ground <b>G174</b></p>
	<p>Center console ground <b>G174</b></p>
<p>Connector, left rear wiring to left rear door wiring <b>G191</b></p>	<p>Connector, right rear wiring to right rear door wiring <b>G197</b></p>









(Cont.d)













## INTERIOR AND EXTERIOR LOCK/UNLOCK SYSTEM INOPERATIVE

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
	- Check F16 fuse in the fuse box G1 for integrity	 ►  ►	Carry-out step A2  Replace fuse F16
<b>A2</b>	<b>CONTROL UNIT POWER CHECK</b>		
	- Check for presence of 12V between pins "+" and "↓" of control unit N11	 ►  ►	Replace control unit N11  Carry-out step A3
<b>A3</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin "↓" of control unit N11	 ►  ►	Carry-out step A4  Repair wiring between pin "↓" of control unit N11 and ground point G174
<b>A4</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 2N of fuse box G1 and ground	 ►  ►	Repair wiring between pin "+" of control unit N11 and pin 7P of fuse box G1  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2

End of test A









<b>INTERIOR LOCK/UNLOCK SYSTEM INOPERATIVE</b>	<b>TEST B</b>
--	---------------

	TEST STEPS	RESULTS	REMEDY
<b>B1</b>	<b>FUSE CHECK</b>		
	- Check F18 fuse in the fuse box G1 for integrity	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Carry-out step B2
		<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Replace fuse F18
<b>B2</b>	<b>VOLTAGE CHECK</b>		
	- With the ignition key to "run" position check for presence of 12V between pin 4E of fuse box G1 and ground	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Carry-out step B6
		<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Carry-out step B3
<b>B3</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 12E of fuse box G1	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Carry-out step B4
		<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Repair wiring between pin 12E of fuse box G1 and ground point G174
<b>B4</b>	<b>VOLTAGE CHECK</b>		
	- With the ignition key set to "run", check for presence of 12V between pin 4O of fuse box G1 and ground	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Carry-out step B5
		<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Failure of power distribution circuit, refer to the relevant circuit of sheet 2 of 2

(Cont.d)



## INTERIOR LOCK/UNLOCK SYSTEM INOPERATIVE

## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B5</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2N of fuse box G1 and ground		 ►  ►	Replace relay I73  Failure of power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>B6</b>	<b>VOLTAGE CHECK</b>		
- With the start key to "run" position check for presence of 12V between pin 3 of switch B20 and ground		 ►  ►	Carry-out step B7  Repair wiring between pin 3 of switch B20, pin 2 of G100 and pin 4E of fuse box G1
<b>B7</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 4 of switch B20		 ►  ►	Carry-out step B8  Repair wiring between pin 4 of switch B20 and ground point G182
<b>B8</b>	<b>CONTROL UNIT CHECK</b>		
- With the ignition key to "run" position, check that by pressing switch B20 in both directions 12V are applied between pins 4 and 5 of control unit N11 and ground; the voltage polarity depends on the setting of switch B20		 ►  ►	Replace control unit N11  Carry-out step B9


(Cont.d)

INTERIOR LOCK/UNLOCK SYSTEM INOPERATIVE	<b>TEST B</b>
---	---------------

TEST STEPS		RESULTS	REMEDY
<b>B9</b>	<b>SWITCH CHECK</b>		
<p>- With the ignition key to "run" position check that when switch <b>B20</b> is actuated, 12V are applied between pins 2 and 1 of the switch and ground; the voltage polarity depends on the setting of switch</p>		<p style="text-align: center;">    </p>	<p>Repair wiring at pins 7 and 10 of connector <b>G100</b> to switch <b>B20</b> and/or control unit <b>N11</b></p> <p>Replace switch <b>B20</b></p>

End of test B


<b>EXTERIOR LOCK/UNLOCK SYSTEM INOPERATIVE</b>	<b>TEST C</b>
--	---------------

	TEST STEPS	RESULTS	REMEDY																							
<b>C1</b>	<b>BOTH DOORS FAILED SYSTEM CHECK</b>																									
	- Check that system of both L.H. and R.H. doors has failed	(OK)     ► (OK)     ►	Replace control unit N11  Carry-out step C2																							
<b>C2</b>	<b>L.H. DOOR FAILED SYSTEM CHECK</b>																									
	- Check that failure is present at the left door only	(OK)     ► (OK)     ►	Carry-out step C3  Carry-out step C6																							
<b>C3</b>	<b>MOTOR CHECK</b>																									
	- Depending on the locking or unlocking operation of the system check for continuity between pins of motor P11 as indicated in the table below:	(OK)     ► (OK)     ►	Carry-out step C4  Replace motor P11																							
	<div style="display: flex; align-items: flex-start;"> <div style="margin-right: 10px;"> <p>1BLK= Q128 E</p> <p>BRN-WHT= Q128 D</p> <p>PPL-WHT= Q128 C</p> <p>1LTBLU= Q128 B</p> <p>1RED= Q128 A</p> </div>  </div> <table border="1" style="margin-left: 100px; border-collapse: collapse; text-align: center;"> <tr> <td style="width: 20px;">A</td> <td style="width: 20px;">B</td> <td style="width: 20px;">C</td> <td style="width: 20px;">D</td> <td style="width: 20px;">E</td> </tr> <tr> <td>RED</td> <td>LTBLU</td> <td>PPL-WHT</td> <td>BRN-WHT</td> <td>BLK</td> </tr> <tr> <td colspan="2">● — ●</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td colspan="2">● — ●</td> <td>●</td> </tr> <tr> <td></td> <td></td> <td></td> <td colspan="2">● — ●</td> </tr> </table> <div style="margin-left: 100px;"> <p>ANY TIME</p> <p>DEPENDING ON LOCK/UNLOCK OPERATION</p> </div>	A	B	C	D	E	RED	LTBLU	PPL-WHT	BRN-WHT	BLK	● — ●							● — ●		●				● — ●	
A	B	C	D	E																						
RED	LTBLU	PPL-WHT	BRN-WHT	BLK																						
● — ●																										
		● — ●		●																						
			● — ●																							

(Cont.d)



EXTERIOR LOCK/UNLOCK SYSTEM INOPERATIVE	<b>TEST C</b>
---	---------------

	TEST STEPS	RESULTS	REMEDY
<b>C4</b>	<b>GROUNDING CHECK</b>		
	<ul style="list-style-type: none"> <li>- Check that pin E of motor P11 is connected to ground</li> </ul>	<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div>	<p>Carry-out step C5</p> <p>Repair wiring between ground point G174, pin 14 of G168 connector and pin E of motor P11</p>
<b>C5</b>	<b>GROUNDING CHECK</b>		
	<ul style="list-style-type: none"> <li>- Depending on the locking or unlocking operation of the system, check that pins 7 and 8 of connector G168 are connected to ground</li> </ul>	<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div>	<p>Repair wiring between pins 7 and 8 of connector G168 and pins 2 and 3 of control unit N11</p> <p>Repair wiring between pins 7 and 8 of connector G168 and pins C and D of motor P11</p>
<b>C6</b>	<b>MOTOR CHECK</b>		
	<ul style="list-style-type: none"> <li>- Depending on the locking or unlocking operation of the system check for continuity between pins of motor P10 as indicated in the table on the next page</li> </ul> <div style="margin-top: 20px;">  <p style="font-size: small; margin-top: 5px;">             1BLK -&gt; G168 E              1BRN -&gt; G168 D              1PPL -&gt; G168 C              1LTBLU -&gt; G168 B              1RED -&gt; G168 A         </p> </div>	<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div>	<p>Carry-out step C7</p> <p>Replace motor P10</p>

(Cont.d)







EXTERIOR LOCK/UNLOCK SYSTEM INOPERATIVE	<b>TEST C</b>
---	---------------

TEST STEPS	RESULTS	REMEDY															
<div style="display: flex; align-items: center;"> <div style="margin-right: 20px;"> <p>ANY TIME DEPENDING ON LOCK/ UNLOCK OPERATION</p> </div> <table border="1" style="border-collapse: collapse; text-align: center;"> <tr> <td style="padding: 2px 5px;">A RED</td> <td style="padding: 2px 5px;">B LTBLU</td> <td style="padding: 2px 5px;">C PPL</td> <td style="padding: 2px 5px;">D BRN-WHT</td> <td style="padding: 2px 5px;">E BLK</td> </tr> <tr> <td colspan="2" style="text-align: left; padding: 5px;">●————●</td> <td></td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td style="text-align: left; padding: 5px;">●————●</td> <td style="text-align: left; padding: 5px;">●————●</td> <td></td> </tr> </table> </div>	A RED	B LTBLU	C PPL	D BRN-WHT	E BLK	●————●							●————●	●————●			
A RED	B LTBLU	C PPL	D BRN-WHT	E BLK													
●————●																	
		●————●	●————●														
<b>C7</b> GROUNDING CHECK																	
- Check that pin E of motor P10 is connected to ground	<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="font-size: 2em; margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 2em; margin-right: 10px;">▶</div> </div>	<p>Carry-out step C8</p> <p>Repair wiring between ground point G174 and pin E of motor P10</p>															
<b>C8</b> GROUNDING CHECK																	
- Depending on the locking or unlocking operation of the system, check that pin 7 and 8 of connector G166 are connected to ground	<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="font-size: 2em; margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 2em; margin-right: 10px;">▶</div> </div>	<p>Repair wiring between pins 7 and 8 of connector G166 and pins 2 and 3 of control unit N11</p> <p>Repair wiring between pins 7 and 8 of connector G166 and pins C and D of motor P10</p>															

End of test C

## LEFT REAR DOOR LOCK/UNLOCK SYSTEM INOPERATIVE

## TEST D

TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>MOTOR CHECK</b>		
- Check left rear motor P13 for integrity verifying that circuit between pins A and B of motor is not open		 ►  ►	Carry-out step D2  Replace motor P13
<b>D2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pins 9 and 6 of connector G169 with system activated		 ►  ►	Carry-out step D3  Repair wiring between pin 9 and 6 of connector G169 and pins 1M and 2M of control unit N11
<b>D3</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pins 7 and 21 of connector G191 with system activated		 ►  ►	Repair wiring between pins 7 and 21 of connector G191 and pins 9 and 6 of connector G169  Repair wiring between pins B and A of motor P13 and pins 7 and 21 of connector G191


End of test D

<b>RIGHT REAR DOOR LOCK/UNLOCK SYSTEM INOPERATIVE</b>	<b>TEST E</b>
---	---------------

TEST STEPS		RESULTS	REMEDY
<b>E1</b>	<b>MOTOR CHECK</b>		
- Check right rear motor P12 for integrity verifying that circuit between pins A and B of motor is not open		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step E2  Replace motor P12
<b>E2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pins 1 and 2 of connector G167 with system activated		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step E3  Repair wiring between pins 1 and 2 of connector G167 and pins 1M and 2M of control unit N11
<b>E3</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pins 7 and 21 of connector G197 with system activated		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between pins 7 and 21 of connector G197 and pins 1 and 2 of connector G167  Repair wiring between pins B and A of motor P12 and pins 7 and 21 of connector G197

End of test E

# MIRRORS - - EXTERNAL POWER



## GENERAL

Adjustment of the external rearview mirrors is electrically operated by means of switches located on the left front door trim panel. These switches consist of:

- Left/right mirror selector.
- Four positions selector which controls the movement of the selected mirror in the four possible directions.

The system is protected by the fuse F5 (30A) OUTSIDE REARVIEW MIRRORS located in the auxiliary fuse box G2.

## OPERATIONAL DESCRIPTION

12V from the battery are applied to the electric external mirror control switch B36 through the fuse F5. A section of this switch controls the selection of the left or right mirror.

The second section of this switch allows the adjustment of the selected mirror in four possible directions by means of the four positions selector.

The following description refers to the left mirror; operation of the right mirror is identical, except for the setting of

the Left/Right mirror selector.


- Outward rotation. Pressing the four position selector toward left, 12V from the battery are applied to pin A, while the ground is connected to pin C of the left external rearview mirror motor P8: the mirror rotates outwards.
- Inward rotation. Pressing the four position selector toward right, 12V from the battery are applied to pin C, while the ground is connected to pin A of the left external rearview mirror motor P8: the mirror rotates inwards.
- Upward rotation. Pressing the four position selector upwards, the ground is connected to pin A, while 12V from the battery are applied to pin B of the left external rearview mirror motor P8: the mirror rotates upwards.
- Downward rotation. Pressing the four position selector downwards, 12V from the battery are applied to pin A, while the ground is connected to pin B of the left external rearview mirror motor P8: the mirror rotates downwards.

## TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT			
	<u>F5</u> FUSE	<u>B36</u> DUAL SWITCH	<u>P8</u> MOTOR	<u>P9</u> MOTOR
BOTH EXTERNAL REARVIEW MIRRORS ADJUSTMENT INOPERATIVE	●	●		
LEFT EXTERNAL REARVIEW MIRROR ADJUSTMENT INOPERATIVE		●	●	
RIGHT EXTERNAL REARVIEW MIRROR ADJUSTMENT INOPERATIVE		●		●



















<p>Electric external mirror control switch</p>	<p><b>B36</b></p>	<p>Fuse box</p>	<p><b>G1 T</b></p>
<p>Auxiliary fuse box</p>	<p><b>G2</b></p>	<p>Six pin connector circuit board to doors wiring</p>	<p><b>G16</b></p>
<p>Connector, front doors to right front door wiring</p>	<p><b>G166</b></p>	<p>Connector, front doors to left front door wiring</p>	<p><b>G168</b></p>
<p>Steering wheel column support ground</p>	<p><b>G174</b></p>		
<p>Left electric external rearview mirror motor</p>	<p><b>P8</b></p>	<p>Right electric external rearview mirror motor</p>	<p><b>P9</b></p>



## BOTH EXTERNAL REARVIEW MIRRORS ADJUSTMENT INOPERATIVE

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
- Check fuse F5 in the auxiliary fuse box G2 for integrity		 	Carry-out step A2
		 	Replace fuse F5
<b>A2</b>	<b>DOOR OPEN INDICATOR CHECK</b>		
- Check for failed illumination of the door open indicator, opening either door		 	Carry-out step A3
		 	Carry-out step A5
<b>A3</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2 of connector G16 and ground		 	Repair wiring between pin 2 of connector G16 and pin 3 of connector G168
		 	Carry-out step A4
<b>A4</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin f auxiliary fuse box G2 (RED wire) and ground		 	Repair wiring between pin 2 of connector G16 and pin of auxiliary fuse box G2
		 	Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2

(Cont.d)

## BOTH EXTERNAL REARVIEW MIRRORS ADJUSTMENT INOPERATIVE



## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pins 4 and 2 of switch B36		OK ►	Replace switch B36
		<del>OK</del> ►	Carry-out step A6
<b>A6</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 3 of connector G168 and ground		OK ►	Repair wiring between pin 3 of connector G168 and pin 4 of switch B36
		<del>OK</del> ►	Carry-out step A7
<b>A7</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 2 of switch B36		OK ►	Repair wiring between pin 3 of switch B36, and pin 9 of connector G168
		<del>OK</del> ►	Repair wiring between pin 2 of switch B36, pin 14 of connector G168 and ground point G174

End of test A

LEFT EXTERNAL REARVIEW MIRROR ADJUSTMENT INOPERATIVE





TEST B

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>SWITCH CHECK</b>		
<p>- With left mirror selected, and depending on the direction selected, check for continuity between pins of switch B36 as indicated in the table below:</p>  		<p>OK →</p> <p><del>OK</del> →</p>	<p>Carry-out step B2</p> <p>Replace switch B36</p>

(Cont.d)

## LEFT EXTERNAL REARVIEW MIRROR ADJUSTMENT INOPERATIVE



## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B2</b>	<b>VOLTAGE CHECK</b>		
- Press switch <b>B36</b> as required to rotate the mirror upwards or downwards; check for presence of 12 V between pins <b>A</b> and <b>B</b> of motor <b>P8</b> (polarity of the voltage is related to the selected rotation)		 ►  ►	Replace motor <b>P8</b>  Carry-out step <b>B3</b>
<b>B3</b>	<b>VOLTAGE CHECK</b>		
- Press switch <b>B36</b> as required to rotate the mirror inwards or outwards; check for presence of 12V between pins <b>A</b> and <b>C</b> of motor <b>P8</b> (polarity of the voltage is related to the selected rotation)		 ►  ►	Replace motor <b>P8</b>  Repair wiring between: • Pin <b>L</b> (LT BLU-BLK wire) at switch <b>B36</b> and pin <b>B</b> of motor <b>P8</b> • Pin <b>L</b> (LT BLU wire) of switch <b>B36</b> and pin <b>C</b> of motor <b>P8</b>

End of test B

**RIGHT EXTERNAL REARVIEW MIRROR ADJUSTMENT INOPERATIVE**







**TEST C**

TEST STEPS		RESULTS	REMEDY																																								
<b>C1</b>	<b>SWITCH CHECK</b>																																										
<p>- With right mirror selected, and depending on the direction selected, check for continuity between pins of switch B36 as indicated in the table below:</p>   <table border="1" data-bbox="290 1539 980 2039"> <thead> <tr> <th></th> <th>2 BLK</th> <th>3 YEL</th> <th>4 RED-BLK</th> <th>L LTRBU</th> <th>R LTRBU YEL</th> <th>L LTRBU BLK</th> <th>R YEL-BLK</th> </tr> </thead> <tbody> <tr> <td>← LEFT</td> <td>●</td> <td></td> <td>●</td> <td>●</td> <td>●</td> <td></td> <td>●</td> </tr> <tr> <td>→ RIGHT</td> <td>●</td> <td>●</td> <td>●</td> <td></td> <td>●</td> <td></td> <td></td> </tr> <tr> <td>↑ UP</td> <td>●</td> <td></td> <td>●</td> <td>●</td> <td></td> <td></td> <td>●</td> </tr> <tr> <td>↓ DOWN</td> <td>●</td> <td>●</td> <td></td> <td></td> <td></td> <td></td> <td>●</td> </tr> </tbody> </table>			2 BLK	3 YEL	4 RED-BLK	L LTRBU	R LTRBU YEL	L LTRBU BLK	R YEL-BLK	← LEFT	●		●	●	●		●	→ RIGHT	●	●	●		●			↑ UP	●		●	●			●	↓ DOWN	●	●					●	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step C2</p> <p>Replace switch B36</p>
	2 BLK	3 YEL	4 RED-BLK	L LTRBU	R LTRBU YEL	L LTRBU BLK	R YEL-BLK																																				
← LEFT	●		●	●	●		●																																				
→ RIGHT	●	●	●		●																																						
↑ UP	●		●	●			●																																				
↓ DOWN	●	●					●																																				

(Cont.d)

## RIGHT EXTERNAL REARVIEW MIRROR ADJUSTMENT INOPERATIVE

## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C2</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>Press switch <b>B36</b> as required to rotate the mirror upwards or downwards; check for presence of 12V between pins A and B of motor <b>P9</b> (polarity of the voltage is related to the selected rotation)</li> </ul>		OK  <del>OK</del> 	Replace motor <b>P9</b>  Carry-out step <b>C3</b>
<b>C3</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>Press switch <b>B36</b> as required to rotate the mirror inwards or outwards; check for presence of 12V between pins A and C of motor <b>P9</b> (polarity of the voltage is related to the selected rotation)</li> </ul>		OK  <del>OK</del> 	Replace motor <b>P9</b>  Carry-out step <b>C4</b>
<b>C4</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>Check for continuity between:               <ul style="list-style-type: none"> <li>pin R (YEL-BLK wire) of switch <b>B36</b> and pin 12 of connector <b>G168</b></li> <li>pin 12 of connector <b>G168</b> and pin 12 of connector <b>G166</b></li> <li>pin 12 of connector <b>G166</b> and pin B of motor <b>P9</b></li> <li>pin A of motor <b>P9</b> and pin 9 of connector <b>G166</b></li> <li>pin 9 of connector <b>G166</b> and pin 9 of connector <b>G168</b></li> <li>pin R (LT BLU-YEL wire) of switch <b>B36</b> and pin 15 of connector <b>G168</b></li> <li>pin 15 of connector <b>G168</b> and pin 15 of connector <b>G166</b></li> <li>pin 15 of connector <b>G166</b> and pin C of motor <b>P9</b></li> </ul> </li> </ul>		OK  <del>OK</del> 	Replace motor <b>P9</b>  Repair or replace wires, as necessary

End of test C



# MOTRONIC ML4.1





## GENERAL

The Motronic ML4.1 system electronically performs the check of the ignition and injection system to optimize both the vehicle performances and fuel economy.

The system is monitored by a control unit with self-diagnosis capability that allows storing of any malfunction that should occur during operation.

The Motronic ML4.1 system functions are as follows:

- Injection time setting.
- Spark lead setting.
- Cold start monitoring.
- Enrichment monitoring during acceleration.
- Fuel cut-off during release phase.
- Constant idle speed setting.
- Maximum RPM Control.
- Self-diagnosis.
- Heated Lambda probe control.
- Evaporation solenoid valve.
- Control unit auxiliary functions.

### Injection time setting

The Motronic control unit provides an extremely fast and precise operation of electronic injectors; the injection time is optimized on the basis of battery voltage and engine temperature.

Further adjustments are performed whenever any possibility of spark pinging exists, or when the intake air quantity is less than the scheduled quantity.

### Spark lead setting

Spark lead is obtained by the control unit schedule, and calculated on the basis of engine RPM and load.

The calculated value is optimized in relation to the intake air and engine temperatures.

In case the calculated value is noticeably different from the scheduled value, the control unit increases the injection time.

### Cold start monitoring

During the cold start phase, the control unit monitors the spark lead and the injection time.

The spark lead is controlled on the basis of engine RPM and temperature, and its maximum value is obtained at a temperature of -30°C (-22°F).

The injection time is stored in the control unit and is corrected for the intake air temperature, engine temperature, battery voltage and engine RPM.

When the pre-set engine RPM's are reached (function of engine temperature), the control unit returns the injection control to the normal condition.

### Enrichment monitoring during acceleration

Following an acceleration demand, the control unit adjusts the injection system for the new operating condition, thus increasing the injection of fuel so that the required engine RPM are quickly reached.

While approaching to the required RPM, the fuel injection increase is gradually eliminated.

### Fuel cut-off during release phase

With a closed throttle recognition, and engine speed above 1080 RPM, the fuel injection is de-activated.

When the injection is off, the engine RPM begin to decrease to a rate depending on vehicle operating conditions.

Before reaching the idle setting, the RPM decrease dynamic is verified, and if found above a certain value, the fuel supply is partially re-activated on the basis of a logic that will smoothly bring the engine to idle speed.

Once this condition is reached, the normal idling functions are re-activated, and fuel cut-off will be restored only if the fuel cut-off threshold is overcome, to avoid jerking operation of the engine.

Fuel supply and cut-off re-activation thresholds vary as a function of engine temperature.

### Constant idle speed setting

Constant idle speed setting is controlled during all the operating phases by means of the monowinding constant idle speed actuator.

During engine idling, the actuator will bring the actual RPM to normal RPM acting on the throttle by-pass valve. Besides of idle speed control, the actuator also acts as an

additional air chamber and control for the actuation of the air conditioning system.

Idle speed adjustment is also obtained through the adjustment of spark lead, since its response is faster.

#### Maximum RPM control

When the maximum RPM are exceeded (6300 RPM), the fuel injection is cut-off to prevent engine overload.

#### Self-Diagnosis

The electronic injection and ignition control unit includes a sophisticated self-diagnosis device.

Whenever a system malfunction is detected, the control unit alerts the driver by turning on the CHECK ENGINE warning lamp on the instrument panel.

#### NOTE

Sporadic illumination of the warning lamp indicates a sporadic malfunction, and does not affect normal operation of vehicle.

#### Heated Lambda probe control

Proper air-fuel ratio is obtained by means of the heated lambda probe, that supplies the control unit with informations concerning the combustion of the air-fuel mixture. To obtain the optimum air-fuel mixture, the engine intake air quantity must equal the theoretic quantity which should be necessary to fire the injected fuel completely ( $\lambda$  factor = 1).

The heated lambda probe, which is in contact with the exhaust gases, generates an electric signal whose voltage is proportional to the concentration of oxygen present in the gases.

The voltage is characterized by a sudden change when the mixture composition moves from  $\lambda = 1$  value.

When a low voltage signal is received, the control unit senses the mixture is too poor, and provides to slightly increase the injected fuel; when a high voltage signal is received, the control unit senses the mixture is too rich, and therefore decreases the quantity of fuel injected.

The lambda probe changes the injection times so that the signal voltage will remain within two reference voltages, and therefore the engine operates with a  $\lambda$  factor very close to the theoretic factor.

#### Evaporation solenoid valve

The control unit opens the evaporator emission solenoid valve only when the engine is under load; the valve is

closed when the engine is cold or at idle speed.

Opening of the evaporator emission solenoid valve allows the fuel vapors to flow from the fuel vapor filter to the engine for further use.

#### Control unit auxiliary functions

Control unit auxiliary functions are as follows:

- Idle speed setting with air conditioning system.
- Self-diagnosis system-flashing error code.
- Manual or automatic gear identification.

## OPERATIONAL DESCRIPTION

The engine is provided with a Motronic ML4.1 injection system controlled, adjusted and monitored by the Motronic control unit S11.

The control unit S11 has a program memory which controls the fuel injection time and correct spark lead as a function of engine RPM and load, intake air temperature and engine coolant temperature.

The control unit S11 is powered directly on pins 18 and 35 by the Motronic relay with diode S12b, which is energized when the ignition key is set to "run" position.

The relay S12b power supply line is protected by fuse F22-ENGINE RELAY in fuse box G1.

The Motronic control unit S11 includes a self-diagnosis system.

Pressing the diagnosis indicator light pushbutton T4, the control unit turns on the CHECK ENGINE warning lamp on instrument panel C10.

The warning lamp flashes at a codified error code which allows identification of the failure.

Refer to the troubleshooting table for further details.

The control unit S11 activates the electric fuel pump P18 through the fuel pump motronic relay S12a.

The relay S12a is energized when the outlet pin 20 of the control unit S11 is connected to ground.

On the basis of its own program and of information received by the various sensors, the control unit S11 calculates and monitors the opening time of electro-injectors S3 (pin 14).

Information on engine speed is supplied to pins 23 and 25 of the control unit S11 by the RPM and timing sensor



**S31.** The sensor is of the inductive type, and is operated by the variation of the magnetic field caused by the passage of teeth of a toothed pulley (impulse emitting wheel) on crankshaft.

The throttle switch **S6** supplies to pins 2 and 3 of control unit **S11** information regarding the acceleration throttle angle, and therefore about the engine load.

The switch includes two microswitches. One microswitch (idle speed) supplies a signal for throttle angles between 0° (fully closed) and 1°; the second microswitch (maximum speed) supplies signals for throttle angles above 60°.

The engine coolant temperature sensor **S7** is of the NTC type (Negative Temperature Coefficient), and supplies engine temperature information to control unit **S11**.

The air flow meter **S5** measures the air flow, and supplies the control unit **S11** with a signal that permits exact metering of fuel.

The signal is generated by a potentiometer which transmits to control unit **S11** a voltage corresponding to the oscillating throttle angle.

A temperature sensor (NTC) inside the meter **S5** senses the intake air temperature.

Electro-injectors **S3** are controlled in parallel by the control unit **S11** through pin 14 and by the Motronic relay with diode **S12b** on the basis of all the parameters received from the control unit.

In case the throttle is fully closed, or slightly open, the control unit **S11** is capable of controlling an air flow through the idle adjustment actuator **S29** which acts as a by-pass line of the throttle body.

The idle adjustment actuator **S29** is monitored by a portion of the control unit **S11** program, and is used to determine the exact amount of air necessary to maintain an ideal idle speed in any operating condition of the engine.

The ignition system is integrated in the control unit **S11**, and allows adjustment of spark lead by means of a stored program.

The starting output signal from the control unit **S11** (pin 1)

is supplied directly to the ignition coil **A8** which activates the distributor **A5** and supplies required signal for the engine tachometer on instrument panel **C10** (pin 5D).

The evaporation solenoid valve **M15**, powered with 12V, is opened by control unit **S11** (pin 31).

The valve opening is actuated only when the ignition key is set to "run" position and only when the engine is loaded; The evaporation solenoid valve **M15** is closed when the engine is cold or at idle speed.

The heated lambda probe **S35**, in contact with exhaust gases, generates an electric signal whose voltage is dependent on oxygen concentration in the exhaust gases. The signal voltage is characterized by a sudden change when the mixture composition moves away from the optimum value.

When the probe **S35** signal voltage is low, the control unit senses the mixture is poor, and provides to slightly increase the injected fuel.

When the signal voltage is high, the control unit senses the mixture is rich, and therefore decreases the quantity of injected fuel.

The heated lambda probe **S35** is heated by a resistor powered through the Motronic relay with diode **S12b** only when the ignition key is to "run" position.

When the air conditioning system is actuated, 12V power is applied to pins 29 and 32 of Motronic control unit **S11**. The control unit **S11** is therefore capable of adjusting the idle speed for the new power request due to activation of the air conditioning.

The control unit is capable to identify through pin 11 if the vehicle is equipped with manual or automatic transmission.

When a 0V condition is present at pin 11, the control unit **S11** senses the transmission is manual; on the opposite, when pin 11 is free, the control unit **S11** senses the transmission is automatic.

When the automatic transmission is in "Drive" position, or in any other transmission speed, the 12V power is applied to pin 28 in order to adapt the engine operating conditions for a smooth starting of the vehicle into movement.

## SELF-DIAGNOSIS - GENERAL INFORMATION

The diagnosis procedure is divided in two groups:

A = Display of errors stored by the control unit.

B = Monitoring of some engine actuators and devices.

The button provided on the steering column performs three separate functions, depending on duration of pressure on the button; these functions are as follows:

T1 = Pressure duration between 2.5 and 5 seconds.

T2 = Pressure duration between 5 and 10 seconds.

T3 = Pressure duration over 10 seconds.

To select procedure A press the pushbutton for duration T1 after the ignition key has been turned to "run" position.

To select procedure B press the pushbutton first, then rotate the ignition key to position 1 and hold the pushbutton pressed for duration T1.

### Procedure A

Press pushbutton for duration T1 after the ignition key has been turned to "run" position: the CHECK ENGINE warning lamp performs a long flashing (about 2.5 seconds).

Following this flashing, series of short flashings is performed (about 0.5 seconds); record the number of flashings since this is the first digit of the error code (consisting of four digits) which will allow identification of the malfunction. Each series of short flashings is separated by a long flashing.

By pressing again the pushbutton for a period T1 will display the second digit of the error code, and so on until all the five defects that can be stored in the control unit memory are displayed. If the pushbutton is not pressed, the system will repeat the last sequence of flashings, thus allowing to check the recorded code.

When all malfunctions have been displayed, the warning lamp performs a series of long flashings.

If the code of the first series of flashings is 4-4-4-4, that means the control unit has stored no errors.

Pressing the pushbutton for duration T2, the warning lamp will repeat the flashings from the beginning.

The control unit memory can be reset in any of the following modes:

- Disconnecting the battery (-) lead for at least 10 seconds.

- Pressing the pushbutton for duration T3 after the display of errors is finished, in other words when the warning lamp performs long flashings.

In any case, if the malfunction is no longer present, the control unit is automatically reset after 50 engine starts.

### Procedure B

Press and hold the pushbutton and turn the ignition key to "run" position.

Subsequently, hold pushbutton pressed for duration T1 after the ignition Key has been turned, but with engine not running.

A few seconds after the pushbutton has been released, the electro-injectors will begin to operate, while the CHECK ENGINE warning lamp will indicate which actuator has been activated by means of a four digits code in accordance with methodology described for procedure A.

The sequence of activated actuators is as follows:

- Electro-injectors.
- Idle adjustment actuator.
- Evaporation solenoid valve.

Pressing the pushbutton for duration T2 you will return to the beginning of procedure with actuation of the electro-injectors.

Pressing the pushbutton for duration T3 the activation of actuators is completed.

The codes of the above mentioned procedures are as follows:

- 1-4-1-1: Electro-injectors actuation test activated: continuous control at the frequency of 10 Hz.
- 1-4-1-2: Idle adjustment actuator activation test: continuous control for 1 second at idle position and 1 second at maximum speed.
- 1-4-1-3: evaporation solenoid valve actuation test: continuous control at the frequency of 0.5 Hz.









If operator performing the check has a device which is capable to interface with the control unit on a "SIX pole" line, two other codes can be obtained, as follows:

- 1-2-6-5: shortcircuit towards ground of final stage of CHECK ENGINE error warning lamp.  
Shortcircuit towards battery positive of final stage of CHECK ENGINE error warning lamp.


- 1-5-5-5: inability of the control unit to receive control inputs and to emit control outputs to the CHECK ENGINE warning lamp.

The following table contains the troubleshooting for the Motronic ML4.1 system where, starting from the flashing error code displayed by the CHECK ENGINE warning lamp, the existing failure can be detected, and the faulty components can be identified.




<p>Ignition coil</p>	<p><b>A8</b></p>	<p>Instrument panel</p>	<p><b>C10 C</b></p>
			
<p>Fuse box</p>	<p><b>G1 I</b></p>	<p>Upper cover ground connection</p>	<p><b>G131</b></p>
			
<p>Connector, engine wiring to circuit board</p>	<p><b>G154</b></p>	<p>Connector, circuit board to air conditioning wiring</p>	<p><b>G164</b></p>
			
<p>Connector, circuit board to right rear wiring</p>	<p><b>G170</b></p>	<p>Trunk right side ground</p>	<p><b>G186</b></p>
			

(Cont.d)



(Cont.d)

<p>Fuel pump Motronic relay</p>	<p>S12a</p>	<p>Motronic relay with diode</p>	<p>S12b</p>
<p>Automatic/Manual transmission connector</p>	<p>S25</p>		
<p>Idle adjustment actuator</p>	<p>S29</p>	<p>RPM and timing sensor</p>	<p>S31</p>
<p>Heated Lambda probe</p>	<p>S35</p>	<p>ALFA TESTER connector</p>	<p>I1</p>
<p>"Blinking code" diagnosis connector</p>	<p>I2</p>	<p>Diagnosis indicator light pushbutton</p>	<p>T4</p>



<b>SELF-DIAGNOSIS - TROUBLESHOOTING TABLE</b>
---

CODE	MALFUNCTION	TEST REFERENCE
4-4-4-4	- NO malfunction displayed-malfunctions memory clear.	
1-2-1-1	- Abnormal battery voltage (<10V or >16V).	A
1-2-1-2	- Shortcircuit to ground of minimum throttle opening switch. Check conditions: <ul style="list-style-type: none"> <li>• Engine speed &gt;1000 RPM.</li> <li>• Engine temperature &gt;80.2°C (176.36°F).</li> <li>• Engine load &gt;2.5 msec.</li> <li>• Malfunction duration &gt;5 sec.</li> </ul>	B
1-2-1-3	- Shortcircuit to ground of maximum throttle opening switch. Check conditions: <ul style="list-style-type: none"> <li>• Min. throttle opening switch pressed.</li> <li>• Engine load &lt;3 msec.</li> </ul>	C
1-2-1-4	- Temperature sensed by engine coolant temperature sensor above 140.3°C (284.54°F), or shortcircuit to battery positive pole.  - Temperature sensed by engine temperature sensor below -35.4°C (-95.72°F), or circuit interrupted. Check conditions: <ul style="list-style-type: none"> <li>• Air temperature &gt;-20°C (-68°F).</li> </ul>	D
1-2-2-1	- Air flow meter indications not appropriate to engine RPM and position of idle adjustment switch.  - Shortcircuit to battery positive pole of air flow meter.  - Shortcircuit to ground of air flow meter.  - Circuit interrupted.	E
1-2-2-2	- Shortcircuit to ground of the final stage of the idle adjustment actuator, or circuit interrupted.	F

(Cont.d)

<b>SELF-DIAGNOSIS - TROUBLESHOOTING TABLE</b>
---

CODE	MALFUNCTION	TEST REFERENCE
1-2-2-3	<ul style="list-style-type: none"> <li>- Shortcircuit to battery positive pole of the final stage of idle adjustment actuator.</li> <li>- The heated lambda probe regulator inner adjuster reaches the minimum or the maximum value of correction.</li> </ul>	G
1-2-2-4	<ul style="list-style-type: none"> <li>- The heated lambda probe transmits to the control unit a tension &gt;1.009V or &lt;0.0928V.</li> <li>- The heated lambda probe malfunction persists for more than 2.5 sec. after the following conditions verify:               <ul style="list-style-type: none"> <li>• Engine temperature &lt;74.6°C (66.28°F) for at least 3 minutes.</li> <li>• Engine load &gt; 4 msec for at least 5 seconds.</li> </ul> </li> </ul>	H
1-2-2-5	<ul style="list-style-type: none"> <li>- Temperature displayed by intake air flow meter above 140.3°C (284.54°F).</li> <li>- Temperature displayed by intake air flow meter below - 35.4°C (95.72°F).</li> </ul> <p>Check conditions:</p> <ul style="list-style-type: none"> <li>• At least 180 seconds after engine start.</li> <li>• Minimum throttle opening switch pressed for at least 30 seconds after 180 seconds from engine start.</li> </ul>	I
1-2-4-3	<ul style="list-style-type: none"> <li>- Fuel pump relay final stage shortcircuited to ground, or circuit interrupted.</li> <li>- Fuel pump motronic relay final stage shortcircuited to battery positive pole.</li> </ul> <p>Check conditions:</p> <ul style="list-style-type: none"> <li>• The malfunction is identified only if conditions that require pump operation exist (starting phase, or engine running).</li> </ul>	J









(Cont.d)

<b>SELF-DIAGNOSIS - TROUBLESHOOTING TABLE</b>
---

CODE	MALFUNCTION	TEST REFERENCE
	<p><b>NOTE</b></p> <p>The above malfunction can be identified only when another actuator is malfunctioning.</p>	
1-2-4-4	<ul style="list-style-type: none"> <li>- Evaporation solenoid valve final stage shortcircuited to ground, or circuit interrupted.</li> <li>- Evaporation solenoid valve final stage short circuited to battery positive pole. Check conditions:               <ul style="list-style-type: none"> <li>• The malfunction is identified only during actuation of evaporation solenoid valve (sudden acceleration while standing, or engine under loads).</li> </ul> </li> </ul>	K
1-2-5-1	<ul style="list-style-type: none"> <li>- RAM/EPROM memory of control unit is not operating normally.</li> </ul>	Replace <b>Motronic control unit S11</b>
None	<ul style="list-style-type: none"> <li>- CHECK ENGINE warning lamp inoperative.</li> <li>- CHECK ENGINE warning lamp continuously illuminated.</li> </ul>	L

## BATTERY FAILURE

TEST A  
CODE 1-2-1-1

















TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
- Check fuse F22 in fuse box G1 for integrity		 ▶  ▶	Carry-out step A2  Replace fuse F22
<b>A2</b>	<b>VOLTAGE CHECK</b>		
- Check battery terminals for presence of a voltage of 11.5V to 13V		 ▶  ▶	Carry-out step A3  Recharge battery and/or check for possible power leakage
<b>A3</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of a voltage of 11.5 to 13V between pins 18 and 5 of Motronic control unit S11		 ▶  ▶	Carry-out step A4  Replace or repair wires, as necessary
<b>A4</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of a voltage of 11.5V to 13V at pin 35 of control unit S11		 ▶  ▶	Replace control unit S11  Carry-out step A5

(Cont.d)



## BATTERY FAILURE









TEST A  
CODE 1-2-1-1

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of a voltage of 11.5V to 13V at pin 87 of Motronic relay with diode S12b		 	Repair wiring between pin 87 of relay S12b and pin 35 of control unit S11
		 	Carry-out step A6
<b>A6</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of a voltage of 11.5V to 13V at pin 86 of relay S12b		 	Carry-out step A7
		 	Carry-out step A9
<b>A7</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 85 of relay S12b		 	Carry-out step A8
		 	Repair wiring between pin 85 of relay S12b and ground point G131
<b>A8</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 11.5V to 13V between pin 30 of relay S12b and ground		 	Replace relay S12b
		 	Failure of power distribution circuit, refer to the relevant circuit of sheet 1 of 2

(Cont.d)

## BATTERY FAILURE







TEST A  
CODE 1-2-1-1

TEST STEPS		RESULTS	REMEDY
<b>A9</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of a voltage of 11.5V to 13V at pin 1 of connector G154		 	Repair wiring between pin 1 of connector G154 and pin 86 of relay S12b through pin 30 of relay S12a
		 	Carry-out step A10
<b>A10</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 11.5V to 13V between pin 2l of fuse box G1 and ground		 	Repair wiring between pin 1 of connector G154 and pin 1l of fuse box G1
		 	Failure of power distribution circuit, refer to the relevant circuit of sheet 2 of 2

End of test A

## MINIMUM THROTTLE OPENING SWITCH FAILURE







TEST B  
CODE 1-2-1-2

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>SWITCH CHECK</b>		
- With accelerator pedal released, check for presence of shortcircuit between pins 2 and 18 of accelerator throttle switch S6; with accelerator pedal fully pressed, check for presence of open circuit		 ►  ►	Carry-out step B2  Adjust position of switch S6, or replace switch
<b>B2</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 18 of accelerator throttle switch S6		 ►  ►	Carry-out step B3  Repair wiring between pin 18 of switch S6 and ground point G131
<b>B3</b>	<b>CONNECTIONS CHECK</b>		
- Perform checks stated at test step B1 between pin 2 and ground point of Motronic control unit S11		 ►  ►	Replace control unit S11  Repair wiring between pin 18 of switch S6 and pin 2 of control unit S11

End of test B

## MAXIMUM THROTTLE OPENING SWITCH FAILURE

TEST C  
CODE 1-2-1-3

TEST STEPS		RESULTS	REMEDY
<b>C1</b>	<b>SWITCH CHECK</b>		
	- With accelerator pedal released, check for presence of shortcircuit between pins 3 and 18 of accelerator throttle switch S6; with accelerator pedal fully pressed, check for presence of open circuit	 ►  ►	Carry-out step C2  Adjust position of switch S6, or replace switch
<b>C2</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 18 of accelerator throttle switch S6	 ►  ►	Carry-out step C3  Repair wiring between pin 18 of switch S6 and ground point G131
<b>C3</b>	<b>CONNECTIONS CHECK</b>		
	- Perform checks stated at test step C1 between pin 3 and ground point of Motronic control unit S11	 ►  ►	Replace control unit S11  Repair wiring between pin 18 of switch S6 and pin 3 of control unit S11

End of test C

**ENGINE TEMPERATURE SENSOR FAILURE**





**TEST D  
CODE 1-2-1-4**

TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>SENSOR CHECK</b>		
<p>- Check for presence at terminals of engine coolant temperature sensor <b>S7</b> of a resistance depending on temperature of engine as shown in diagram below</p>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step D2</p> <p>Replace sensor <b>S7</b></p>
<b>D2</b>	<b>CONTINUITY CHECK</b>		
<p>- Check continuity between pin 13 of Motronic control unit <b>S11</b> and sensor <b>S7</b> (BRN wire), and between ground point <b>G131</b> and sensor <b>S7</b> (BLK wire)</p>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace control unit <b>S11</b></p> <p>Repair or replace wires, as necessary</p>

End of test D

## AIR FLOW METER FAILURE







TEST E  
CODE 1-2-2-1

TEST STEPS		RESULTS	REMEDY
<b>E1</b>	<b>METER CHECK</b>		
<ul style="list-style-type: none"> <li>- Check that meter <b>S5</b> is operational performing the following tests:               <ul style="list-style-type: none"> <li>• Check for presence of a resistance of about 400Ω between pins 3 and 4 of air flow meter <b>S5</b></li> <li>• Check for presence of a resistance of about 5Ω between pins 2 and 4 of air flow meter <b>S5</b></li> <li>• Operate manually the air flow meter throttle and check that resistance varies in a continuous mode (without sudden variations)</li> </ul> </li> </ul>		<p style="text-align: center;">     ►      ►         </p>	<p style="text-align: center;">           Carry-out <b>step E2</b>             Replace meter <b>S5</b> </p>
<b>E2</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for continuity between pins 2, 3 and 4 of meter <b>S5</b> and pins 7,9 and 6 respectively of Motronic control unit <b>S11</b></li> </ul>		<p style="text-align: center;">     ►      ►         </p>	<p style="text-align: center;">           Replace control unit <b>S11</b>             Repair or replace wires, as necessary         </p>

End of test E

## IDLE SPEED SETTING ACTUATOR FAILURE









TEST F  
CODE 1-2-2-2

TEST STEPS		RESULTS	REMEDY
<b>F1</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pins 2 and 1 of idle adjustment setting actuator <b>S29</b>	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step <b>F2</b>
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step <b>F3</b>
<b>F2</b>	<b>CONTINUITY CHECK</b>		
	- Check for continuity between pin 1 of actuator <b>S29</b> and pin 33 of Motronic control unit <b>S11</b>	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Replace control unit <b>S11</b>
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Repair or replace wires, as necessary
<b>F3</b>	<b>CONTINUITY CHECK</b>		
	- Check for continuity between pin 87 of Motronic relay with diode <b>S12b</b> and pin 2 of actuator <b>S29</b>	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Replace actuator <b>S29</b>
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Repair or replace wires, as necessary

End of test F

## LAMBDA PROBE INNER ADJUSTER FAILURE

TEST G  
CODE 1-2-2-3

TEST STEPS		RESULTS	REMEDY
<b>G1</b>	<b>DUCT CHECK</b>		
	- Check air duct for leaks	 ▶  ▶	Carry-out step G2  Replace air duct or repair any leaks
<b>G2</b>	<b>FILTER CHECK</b>		
	- Check air filter for integrity	 ▶  ▶	Carry-out step G3  Replace air filter
<b>G3</b>	<b>SPARK PLUGS CHECK</b>		
	- Check distributor A5 spark plugs for integrity	 ▶  ▶	Carry-out step G4  Replace defective spark plug (s)
<b>G4</b>	<b>INJECTORS CHECK</b>		
	- Check electroinjectors for integrity by means of flashing code 1-4-1-1 as indicated in paragraph "Self-Diagnosis - General Information"	 ▶  ▶	Carry-out step G5  Replace any defective electroinjectors

(Cont.d)



## LAMBDA PROBE INNER ADJUSTER FAILURE

TEST G  
CODE 1-2-2-3

TEST STEPS		RESULTS	REMEDY
<b>G5</b>	<b>PRESSURE CHECK</b>		
- Check that fuel pressure is 284 thru 323 KPa		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step G6</p> <p>Failure of the fuel system pressure; refer to the relevant troubleshooting procedure (Group 04)</p>
<b>G6</b>	<b>COIL CHECK</b>		
- Check for coil secondary winding integrity (H.V. cable)		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace control unit S11</p> <p>Replace H.V. cable</p>

End of test G

## LAMBDA PROBE FAILURE

TEST H  
CODE 1-2-2-4

TEST STEPS		RESULTS	REMEDY
H1	HEATED LAMBDA PROBE CHECK		
	- Start engine and wait until normal operating conditions are established; check for presence of a voltage of 0.1V to 1V at terminal of heated lambda probe S35 (GRN wire)	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Carry-out step H2</p> <p>Replace heated lambda probe S35</p>
H2	CONTINUITY CHECK		
	- Repeat test step H1 check on pin 24 of Motronic control unit S11	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Replace control unit S11</p> <p>Repair wiring between probe S35 and pin 24 of control unit S11, and between probe S35 and ground point G131 (BLK wire)</p>

End of test H

**ENGINE TEMPERATURE SENSOR FAILURE**





**TEST I  
CODE 1-2-2-5**

TEST STEPS		RESULTS	REMEDY																								
<b>I1</b>	<b>SENSOR CHECK</b>																										
<p>- Check for presence between terminals 5 and 4 of air flow meter S5 of a resistance depending on air temperature as shown in diagram below</p> <table border="1"> <caption>Approximate data points from the RNTC vs T graph</caption> <thead> <tr> <th>Temperature (°C)</th> <th>Resistance (Ohms)</th> </tr> </thead> <tbody> <tr><td>-30</td><td>30,000</td></tr> <tr><td>-20</td><td>15,000</td></tr> <tr><td>-10</td><td>7,000</td></tr> <tr><td>0</td><td>3,500</td></tr> <tr><td>20</td><td>1,800</td></tr> <tr><td>40</td><td>900</td></tr> <tr><td>60</td><td>450</td></tr> <tr><td>80</td><td>220</td></tr> <tr><td>100</td><td>110</td></tr> <tr><td>120</td><td>55</td></tr> <tr><td>130</td><td>100</td></tr> </tbody> </table>		Temperature (°C)	Resistance (Ohms)	-30	30,000	-20	15,000	-10	7,000	0	3,500	20	1,800	40	900	60	450	80	220	100	110	120	55	130	100	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step I2</p> <p>Replace air flow meter S5</p>
Temperature (°C)	Resistance (Ohms)																										
-30	30,000																										
-20	15,000																										
-10	7,000																										
0	3,500																										
20	1,800																										
40	900																										
60	450																										
80	220																										
100	110																										
120	55																										
130	100																										
<b>I2</b>	<b>CONTINUITY CHECK</b>																										
<p>- Repeat test step I1 between pins 22 and 6 of Motronic control unit S11</p>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace control unit S11</p> <p>Repair or replace wires, as necessary</p>																								

End of test I

## FUEL PUMP RELAY CONTROL FINAL STAGE FAILURE

TEST J  
CODE 1-2-4-3

TEST STEPS		RESULTS	REMEDY
J1	VOLTAGE CHECK		
- Check for presence of 12V between pin 86 of fuel pump Motronic relay S12a and ground		 ►  ►	Carry-out step J2  Repair wiring between pin 86 of relay S12a and pin 87 of relay S12b
J2	GROUNDING CHECK		
- Check for presence of 0V (zero) at pin 20 of Motronic control unit S11		 ►  ►	Repair wiring between pin 20 of control unit S11 and pin 85 of relay S12a  Replace control unit S11

End of test J

## EVAPORATOR EMISSION SOLENOID VALVE FAILURE









TEST K  
CODE 1-2-4-4

TEST STEPS		RESULTS	REMEDY
K1	CONTROL UNIT CHECK		
	- With engine warm, accelerate with slight pulses and check for presence of 0V (zero) at pin 34 of control unit S11 at each pulse of accelerator pedal	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step K2</p> <p>Replace control unit S11</p>
K2	GROUNDING CHECK		
	- Check for presence of 0V (zero) at pin 1 (HZL wire) of evaporation solenoid valve M15 under conditions stated at test step K1	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step K3</p> <p>Repair wiring between pin 34 of control unit S11 and pin of evaporation solenoid valve M15 (HZL wire)</p>
K3	VOLTAGE CHECK		
	- Check for presence of 12V between pin of evaporation solenoid valve M15 (BLU-RED wire) and ground	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace evaporation solenoid valve M15</p> <p>Repair wiring between pin of evaporation solenoid valve M15 and pin 86 of relay S12b (BLU-RED wire)</p>

End of test K

## CHECK ENGINE WARNING LAMP FAILURE







TEST L

TEST STEPS		RESULTS	REMEDY
<b>L1</b>	<b>WARN. LAMP ILLUMINATION CHECK</b>		
<ul style="list-style-type: none"> <li>- Turn Ignition key to "run" position and check that CHECK ENGINE warning lamp illuminates together with all other warning lamps on instrument panel, and then extinguishes</li> </ul>		OK  <del>OK</del> 	Carry-out step L2  CHECK ENGINE warning lamp remains off. Carry-out step L3
<b>L2</b>	<b>SELF-DIAGNOSIS CHECK</b>		
<ul style="list-style-type: none"> <li>- With CHECK ENGINE warning lamp on with steady light, press pushbutton located on steering column to perform self-diagnosis procedure (refer to paragraph Self-Diagnosis). Check flashing of warning lamp</li> </ul>		OK  <del>OK</del> 	Carry-out troubleshooting procedure relevant to flashing code displayed  CHECK ENGINE warning lamp steady on; replace control unit S11
<b>L3</b>	<b>SIGNAL CHECK</b>		
<ul style="list-style-type: none"> <li>- Check that a variable frequency square wave signal is present at pin 10C of instrument panel C10 when pushbutton T4 is pressed</li> </ul>		OK  <del>OK</del> 	Replace lamp on instrument panel C10  Carry-out step L4
<b>L4</b>	<b>BUTTON CHECK</b>		
<ul style="list-style-type: none"> <li>- Check that pushbutton T4 is operational verifying the presence of shortcircuit between pins 3 and 4 of pushbutton (LT BLU-YEL and BLK wires)</li> </ul>		OK  <del>OK</del> 	Carry-out step L5  Replace pushbutton T4

(Cont.d)

## CHECK ENGINE WARNING LAMP FAILURE









## TEST L

TEST STEPS		RESULTS	REMEDY
<b>L5</b>	<b>CONTINUITY CHECK</b>		
- Press pushbutton T4 and check for presence of closed circuit condition between pins 2 and 3 of connector T2		 ►  ►	Carry-out step L6  Repair wiring between pins 2 and 3 of connector T2 and pins 4 and 3 respectively of pushbutton T4
<b>L6</b>	<b>CONTINUITY CHECK</b>		
- Press pushbutton T4 and check for presence of shortcircuit between pins 4 and 5 of Motronic control unit S11		 ►  ►	Carry-out step L7  Repair wiring between pins 4 and 5 of control unit S11 and pins 2 and 3 of connector T2
<b>L7</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 5 of Motronic control unit S11		 ►  ►	Carry-out step L8  Repair wiring between pin 5 of control unit S11 and ground point G131

(Cont.d)

## CHECK ENGINE WARNING LAMP FAILURE

## TEST L







TEST STEPS		RESULTS	REMEDY
L8	CONTROL UNIT CHECK		
- Press pushbutton T4 and check for presence of a square wave signal at pin 17 of motronic control unit S11		 	Repair wiring between pin 17 of control unit S11, pin 1 of connector T2 and pin 10C of instrument panel C10
		 	Replace control unit S11
L9	CONTROL UNIT CHECK		
- Check for presence of any error code		 	Perform troubleshooting procedure of displayed code
		 	Replace control unit S11

End of test L



## LOSS OF ENGINE POWER WHEN AIR CONDITIONING ACTUATED

## TEST M

TEST STEPS		RESULTS	REMEDY
M1	VOLTAGE CHECK		
- Check for presence of 12V at pins 29 and 32 of Motronic control unit S11, when the air conditioning is actuated		 ►  ►	Replace control unit S11  Carry-out step M2
M2	VOLTAGE CHECK		
- Check for presence of 12V at pins 3 and 7 of connector G154, when the air conditioning is actuated		 ►  ►	Repair wiring between pins 3 and 7 of connector G154 and pins 32 and 29 of control unit S11  Carry-out step M3
M3	VOLTAGE CHECK		
- Check for presence of 12V at pin 13 of connector G164, when the air conditioning is actuated		 ►  ►	Repair wiring between pin 13 of connector G164 and pins 3 and 7 of connector G154  Carry-out step M4

(Cont.d)

## LOSS OF ENGINE POWER WHEN AIR CONDITIONING ACTUATED

## TEST M

TEST STEPS		RESULTS	REMEDY
M4	VOLTAGE CHECK		
<ul style="list-style-type: none"> <li>- Check for presence of 12V at pin 87 of electro-magnetic coupling control relay Q22, when the air conditioning is actuated</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 87 of relay Q22 and pin 13 of connector G164</p> <p>Failure of the air conditioning system; refer to the applicable troubleshooting procedure</p>

End of test M

# POWER DISTRIBUTION



## GENERAL

The vehicle electrical system is powered by a maintenance-free 12V battery.

The battery power is distributed by cables of suitable cross section and colors, which supply the whole electrical system.

Some of the circuits are continuously powered, even when the vehicle is stopped.

Some of the circuits are controlled by the ignition key, therefore they can be operated only after the ignition key has been inserted in the ignition switch, and turned.

From an initial analysis of the wiring diagram, it can be noted that the various electrical systems of the vehicle are powered in different ways.

Four different types of power supply are present:

- **HOT AT ALL TIMES:** circuits directly connected to the battery.
- **HOT AT START:** circuits powered after the ignition key has been turned to "start" position (line activated at pin 4 of the ignition switch **B1**).
- **HOT AT START OR RUN:** circuits powered when the ignition key is either in "start" and "run" positions (line activated at pin 2 of the ignition switch **B1**).
- **HOT IN RUN:** circuits powered only when the ignition key is rotated to "run" position (line activated at pin 1 of the ignition switch **B1**).

Due to the considerable complexity of the function the wiring diagram has been subdivided into two sheets (sheet 1 of 2 and sheet 2 of 2).

## OPERATIONAL DESCRIPTION (Sheet 1 of 2)


The battery power (12V) is directly supplied to:

- Alarm - - Electronic anti-theft system.
- Seats - - Power adjustable circuit.
- Seats - - Heater circuit.
- Defogger - - Rear window, circuit.
- Controlled damping suspensions circuit (S only).

The battery power (12V) is also supplied to the remaining electrical circuits of the vehicle through the circuit board **G56**.

The following components and circuits are powered directly by circuit board **G56**:

- Motronic ML4.1 circuit.
- Seats - - Power adjustable circuit.
- Instrument panel - - Alfa Romeo control ECU (interface through fuse **F1** in auxiliary fuse box **G2**).
- Air conditioning system circuit (through fuse **F1** in auxiliary fuse box **G2**).
- ABS brake system.
- Radio circuit (both directly and through fuse **F1** in auxiliary fuse box **G2**).



## OPERATIONAL DESCRIPTION (Sheet 2 of 2)

Battery power (12V) is supplied directly to the following electrical circuits of the vehicle through the circuit board G56.

- Horns circuits.
- Fuse box G1 (pins 3E, 2N and T).
- Starting and charging circuit.
- Lamps - - Position circuit.
- Lamps - - Low and High beam lamps circuit.
- Lamps - - Ground illumination door open warning lamp circuits (through fuse F5 in auxiliary fuse box G2).
- Lamps - - Miscellaneous dome circuit (through fuses F5 and F6 in auxiliary fuse box G2).
- Safety belts not fastened/Ignition - key in buzzer circuit (through fuse F6 in auxiliary fuse box G2).
- Fan - - Radiator cooling and A/C condenser circuit.
- Fan - - Automatic transmission oil cooler circuit.
- Windows - - Electric opening circuit.
- Mirrors - - External power circuit (through fuse F5 in auxiliary fuse box G2).

- Seats - -Power adjustable circuit.
- Trunk electric opening circuit (through fuse F3 in auxiliary fuse box G2).
- Fuel door - - Electric opening circuit (through fuse F3 in auxiliary fuse box G2).
- Air conditioning system circuit.
- ABS brake system.
- Radio circuit (both directly and through fuse F5 in auxiliary fuse box G2).

The battery power (12V) is also supplied to the following circuits if not inhibited by the ignition switch B1:

- Alarm - - Electronic anti-theft system.
- ABS brake system.
- Motronic ML4.1 circuit.
- ECU - - Power supply relay circuit.
- Fuse box G1 (pins 2I, 3O and 4O).


### NOTE


An adequate knowledge of all the circuits powered by the same line facilitates the troubleshooting when a failure affects all the relevant circuits simultaneously.

<p>Battery</p>	<p>A1</p>	<p>Battery</p>	<p>A1</p>
<p><b>BASE AND L ONLY</b></p> <p>6RED➤ G56 1.5RED➤ G190 2.5RED➤ 158 35BLK➤ G56 1RED➤ O11 1.5RED➤ G258 4RED➤ G201</p>	<p><b>S ONLY</b></p> <p>1RED-BLK➤ 171 6RED➤ G56 1.5RED➤ G190 1.5RED➤ 158 35BLK➤ G56 1RED➤ O11 1.5RED➤ G258 4RED➤ G201</p>		
<p>Ignition switch</p>	<p>B1</p>	<p>Fuse box</p>	<p>G1 I</p>
<p>2.5GRN-BLK➤ G154 1.5BRN➤ G1 2.5PNK➤ G1 PPL➤ G1 PPL➤ G241 2.5RED➤ 110 2.5RED➤ G56</p>	<p>1.5BRN➤ B1 1BRN➤ 151</p>	<p>Fuse box</p>	<p>G1 N</p>
<p>Fuse box</p>	<p>G1 T</p>	<p>Auxiliary fuse box</p>	<p>G2</p>
<p>4RED➤ G56 2.5RED➤ G2</p>	<p>1.5RED-BLK➤ 170 1.5RED-BLK➤ 151 1.5RED➤ G164 RED-BLK➤ N22A 2.5PPL➤ G170 2.5RED➤ G1 2.5RED➤ 113 2.5RED➤ G18 1RED-BLK➤ G16 1WHT-RED➤ G16 1RED➤ 126</p>		
<p>Six pin connector circuit board to doors wiring</p>	<p>G16</p>		
<p>1WHT-RED➤ G2 1 WHT-RED➤ G1</p>			

(Cont.d)







# RADIO



## GENERAL

The radio system consists of an autoreverse cassette radio with digital display, four two-way loudspeakers and an automatic power antenna.

The radio is installed at the center of the central console.

The front loudspeakers are installed on the front door side panels, and the rear loudspeakers are installed on sides of the rear window shelf tray.

The radio can be used only when the ignition key is set to "run".

Use of the radio when the engine is not running is allowed by turning the ignition key to "run" and then back to "parking", without removing it from the ignition switch.

When the radio is off the clock function is displayed, while when the radio is on, the display indicates the tune frequency.

The system is protected by four fuses as follows:

- Fuse **F1** (7.5A) KEY-CONTROLLED CURRENTS FOR ELECTRONIC UNITS in auxiliary fuse box **G2**.
- Fuse **F2** (7.5A) RADIO LIGHTING in fuse box **G1**.
- Free fuse **F5** (10A) POWER ANTENNA in supplementary fuse box **G2**.
- Free fuse **G239** (15A) RADIO, TELEPHONE.

- Fuse **F2** (7.5A) KEY-CONTROLLED CURRENTS FOR ELECTRONIC UNITS in auxiliary fuse box **G2**.

## OPERATIONAL DESCRIPTION

The battery power (12V) is applied to the radio relay **I51** and to the electronic circuits protection fuses **F1** and **F2** in the auxiliary fuse box **G2**.

Energization of relay **I70** is enabled by ignition switch (microswitch) **B1**.

The ignition switch (microswitch) **B1** is closed when the ignition key is set to "run", or to "parking" after selection of "run" position. When the relay **I51** is energized, the battery power is applied to the radio **O4**, through the fuse **F2**, relay **I70** and the telephone free fuse **G239**.

The radio **O4** is powered by the supply lines protected by fuses **F1** and **F2** in the auxiliary fuse box **G2** and free fuse **G239** with reference to ground point **G182**.

The radio **O4** is connected to the right and left front loudspeakers (pins **5A/3D** and **6A/4B** respectively), to the right and left rear loudspeakers (pins **1B/5B** and **2B/6B** respectively), to the electric antenna (pin **7B**) and to the headset (pin **6B/5B**) and ground point **G182**.

The electric antenna is protected by **F5** fuse in auxiliary fuse box **G2**.

The radio serigraphs are illuminated when the position lamps are on; this line is activated by the parking lamps control unit **N41**, and is protected by fuse **F2** in the fuse box **G1**.

Pin **3** of the radio is connected to the reostat, thus allowing dimming of the radio **O4** controls lighting.

TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT											
	F1 FUSE	F2 FUSE (G1)	F3 FUSE	G239 FUSE	I51 RELAY	O3 ANTENNA	O4 RADIO	LOUDSPEAKER L.H. FRONT	LOUDSPEAKER R.H. FRONT	LOUDSPEAKER L.H. REAR	LOUDSPEAKER R.H. REAR	N41 CONTROL UNIT
RADIO INOPERATIVE	●	●		●	●		●					
LEFT FRONT LOUDSPEAKER INOPERATIVE								●				
RIGHT FRONT LOUDSPEAKER INOPERATIVE									●			
LEFT REAR LOUDSPEAKER INOPERATIVE										●		
RIGHT REAR LOUDSPEAKER INOPERATIVE											●	
RADIO LIGHTING INOPERATIVE (POSITION LAMPS ON)		●										●
POWER ANTENNA INOPERATIVE			●			●						










<p>Ignition switch</p>	<p><b>B1</b></p>	<p>Fuse box</p>	<p><b>G1 E</b></p>
<p>Fuse box</p>	<p><b>G1 E</b></p>		
<p>Fuse box</p>	<p><b>G1 G</b></p>	<p>Fuse box</p>	<p><b>G1 I</b></p>
<p>Fuse box</p>	<p><b>G1 N</b></p>	<p>Fuse box</p>	<p><b>G1 T</b></p>
<p>Auxiliary fuse box</p>	<p><b>G2</b></p>	<p>Two pin connector circuit board to doors wiring</p>	<p><b>G15</b></p>


(Cont.d)

<p>Six pin connector circuit board to doors wiring</p>	<p>Connector, doors to center console wiring</p>
<p><b>G16</b></p>	<p><b>G100</b></p>
<p>Connector, front doors to right front door wiring</p>	<p>Connector, front doors to right rear wiring</p>
<p><b>G166</b></p>	<p><b>G167</b></p>
<p>Connector, front doors to left front door wiring</p>	<p>Steering wheel column support ground</p>
<p><b>G168</b></p>	<p><b>G174</b></p>
<p>Connector, front doors to left rear wiring</p>	<p>Center console ground</p>
<p><b>G169</b></p>	<p><b>G182</b></p>
<p>Center console ground</p>	<p>Connector, provision for radio antenna</p>
<p><b>G182</b></p>	<p><b>G193</b></p>









(Cont.d)



<p>Connector, provision for left rear loudspeaker</p>	<p><b>G195</b></p>	<p>Connector, provision for right rear loudspeaker</p>	<p><b>G196</b></p>
			
<p>Connector, provision for left front loudspeaker</p>	<p><b>G217</b></p>	<p>Connector, provision for right front loudspeaker</p>	<p><b>G218</b></p>
			
<p>Radio, Radio-Telephone fuse</p>	<p><b>G239</b></p>	<p>Electronic control units power supply relay</p>	<p><b>I51</b></p>
			
<p>Radio relay</p>	<p><b>I70</b></p>	<p>Radio</p>	<p><b>O4 A</b></p>
			
<p>Cigar lighter</p>		<p><b>O6</b></p>	<p>Radio</p> <p><b>O4 B</b></p> 



<b>RADIO INOPERATIVE</b>	<b>TEST A</b>
--------------------------	---------------

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
- Check fuses <b>F1</b> and <b>F2</b> in auxiliary fuse box <b>G2</b> for integrity		 	<p>▶ <b>Carry-out step A2</b></p> <p>▶ <b>Replace fuse F1 and/or fuse F2</b></p>
<b>A2</b>	<b>VOLTAGE CHECK</b>		
- Check free fuse <b>G239</b> for integrity		 	<p>▶ <b>Carry-out step A3</b></p> <p>▶ <b>Replace fuse G239</b></p>
<b>A3</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 1A of radio <b>O4</b> and ground		 	<p>▶ <b>Carry-out step A6</b></p> <p>▶ <b>Carry-out step A4</b></p>
<b>A4</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin of <b>F1</b> in auxiliary fuse box <b>G2</b> (RED-BLK wire) and ground		 	<p>▶ <b>Repair wiring between pin of F1, pin 4 of G16 and pin 1A of radio O4</b></p> <p>▶ <b>Carry-out step A5</b></p>

(Cont.d)

RADIO INOPERATIVE









TEST A

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 5 of connector G150 and ground		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px; margin-top: 10px;"> <div style="text-align: center;"><del>○ OK</del></div> <div style="font-size: 2em;">▶</div> </div>	<p>Repair wiring between pin 5 of G150 and pin 30 of relay I51</p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 1 of 2</p>
<b>A6</b>	<b>GROUNDING CHECK</b>		
- Check that the radio is connected to ground		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px; margin-top: 10px;"> <div style="text-align: center;"><del>○ OK</del></div> <div style="font-size: 2em;">▶</div> </div>	<p>Carry-out step A7</p> <p>Repair wiring between between radio case, pin 8 of connector G100 and ground point G182</p>
<b>A7</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" or "start", check for presence of 12V between pin 2A of radio O4 and ground		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px; margin-top: 10px;"> <div style="text-align: center;"><del>○ OK</del></div> <div style="font-size: 2em;">▶</div> </div>	<p>Replace radio O4</p> <p>Carry-out step A8</p>
<b>A8</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" or "start", check for presence of 12V between pin of free fuse G239 and ground		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">○ OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px; margin-top: 10px;"> <div style="text-align: center;"><del>○ OK</del></div> <div style="font-size: 2em;">▶</div> </div>	<p>Repair wiring between pin of fuse G239, pin 5 of G16 and pin 2 of radio O4</p> <p>Carry-out step A9</p>

(Cont.d)

## RADIO INOPERATIVE





## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A9</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" or "start", check for presence of 12V between pin 86 of relay I51 and ground		 	Carry-out step A11  Carry-out step A10
<b>A10</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run", check for presence of 12V between pin 21 of fuse box G1 and ground		 	Repair wiring between pin 21 of fuse box and pin 86 of relay I51  Failure of power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>A11</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 85 of relay I51		 	Carry-out step A12  Repair wiring between pin 85 of I51 and ground point G174
<b>A12</b>	<b>RELAY CHECK</b>		
- Check relay I51 for proper operation		 	Carry-out step A13  Replace relay I51

(Cont.d)

RADIO INOPERATIVE





TEST A

TEST STEPS		RESULTS	REMEDY
<b>A13</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" or "start", check for presence of 12V between pin 87 of relay I51 and ground		 	Carry-out step A14  Carry-out step A5
<b>A14</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" or "start", check for presence of 12V between pin 87 of relay I70 and ground		 	Repair wiring between pin 30 of relay I70 and pin of free fuse G239 (WMT wire)  Repair wiring between pin 87 of I70 and F2 in auxiliary fuse box G2 and between pin of F2 and pin 87 of relay I51

End of test A

## LEFT FRONT LOUDSPEAKER INOPERATIVE









## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>LOUDSPEAKER CHECK</b>		
<ul style="list-style-type: none"> <li>Set multimeter scale to "<math>\Omega \times 1</math>" reading, then connect in parallel the multimeter prods to left front loudspeaker, thus causing a very short discharge</li> </ul>		<p>OK </p> <p><del>OK</del> </p>	<p>Carry-out step B2</p> <p>Replace left front loudspeaker</p>
<b>B2</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>Check for continuity between terminals of left front loudspeaker (connector G217) and pins 10 and 13 of connector G168</li> </ul>		<p>OK </p> <p><del>OK</del> </p>	<p>Repair wiring between pins 10 and 13 of connector G168 and pins 6A and 4B of radio O4</p> <p>Replace or repair wires, as necessary</p>

End of test B

## RIGHT FRONT LOUDSPEAKER INOPERATIVE

## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C1</b>	<b>LOUDSPEAKER CHECK</b>		
<ul style="list-style-type: none"> <li>- Set multimeter scale to "<math>\Omega \times 1</math>" reading, then connect in parallel the multimeter prods to right front loudspeaker, thus causing a very short discharge</li> </ul>		   	<p>Carry-out step C2</p> <p>Replace right front loudspeaker</p>
<b>C2</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for continuity between terminals of right front loudspeaker (connector G218) and pins 10 and 13 of connector G166</li> </ul>		   	<p>Repair wiring between pins 10 and 13 of connector G166 and pins 5A and 3B of radio O4</p> <p>Replace or repair wires, as necessary</p>

End of test C



## LEFT REAR LOUDSPEAKER INOPERATIVE





## TEST D

TEST STEPS		RESULTS	REMEDY
D1	LOUDSPEAKER CHECK		
<ul style="list-style-type: none"> <li>- Set multimeter scale to "<math>\Omega \times 1</math>" reading, then connect in parallel the multimeter prods to left rear loudspeaker, thus causing a very short discharge</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step D2</p> <p>Replace left rear loudspeaker</p>
D2	CONTINUITY CHECK		
<ul style="list-style-type: none"> <li>- Check for continuity between terminals of left rear loudspeaker (connector G195) and pins 3 and 12 of connector G167</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pins 3 and 12 of connector G167 and pins 2B and 6B of radio O4</p> <p>Replace or repair wires, as necessary</p>

End of test D

## RIGHT REAR LOUDSPEAKER INOPERATIVE













## TEST E

TEST STEPS		RESULTS	REMEDY
E1	LOUDSPEAKER CHECK		
<ul style="list-style-type: none"> <li>Set multimeter scale to "<math>\Omega \times 1</math>" reading, then connect in parallel the multimeter prods to right rear loudspeaker, thus causing a very short discharge</li> </ul>		<p>OK </p> <p><del>OK</del> </p>	<p>Carry-out step E2</p> <p>Replace right rear loudspeaker</p>
E2	CONTINUITY CHECK		
<ul style="list-style-type: none"> <li>Check for continuity between terminals of right rear loudspeaker (connector G196) and pins 10 and 11 of connector G167</li> </ul>		<p>OK </p> <p><del>OK</del> </p>	<p>Repair wiring between pins 10 and 11 of connector G167 and pins 5B and 1B of radio O4</p> <p>Replace or repair wires, as necessary</p>

End of test E

## RADIO LIGHTING INOPERATIVE (POSITION LAMPS ON)

TEST F

TEST STEPS		RESULTS	REMEDY
<b>F1</b>	<b>FUSE CHECK</b>		
- Check fuse F2 in fuse box G1 for integrity		 	Carry-out step F2
		 	Replace fuse F2
<b>F2</b>	<b>LIGHT DIMMING CHECK</b>		
- Check that lighting is present, but dimming through the rehostat is inoperative		 	Failure of dimming circuit; refer to the lamps - - position troubleshooting procedure
		 	Carry-out step F3
<b>F3</b>	<b>PARKING LAMPS CHECK</b>		
- Check illumination of position lamps		 	Carry-out step F4
		 	Failure of position lamps circuit; refer to relevant troubleshooting procedure

(Cont.d)

RADIO LIGHTING INOPERATIVE (POSITION LAMPS ON)









TEST F

TEST STEPS		RESULTS	REMEDY
F4	VOLTAGE CHECK		
- Check for presence of 12V between pin 3G of fuse box G1 and ground		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 1E of fuse box G1, pin 14 of connector G100 and pin 4A of radio O4</p> <p>Repair wiring between pin 3G of fuse box G1 and pin 6 of position lamps control unit N41</p>

End of test F

## POWER ANTENNA INOPERATIVE





## TEST G

TEST STEPS		RESULTS	REMEDY
<b>G1</b>	<b>FUSE CHECK</b>		
	- Check fuse <b>F5</b> in auxiliary fuse box <b>G2</b> for integrity	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step <b>G2</b>
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Replace fuse <b>F5</b>
<b>G2</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin of fuse <b>F5</b> in auxiliary fuse box <b>G2</b> (RED wire)	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step <b>G3</b>
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>G3</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 1 of connector <b>G193</b> and ground	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step <b>G6</b>
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step <b>G4</b>
<b>G4</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 4 of connector <b>G169</b> and ground	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between pin 4 of <b>G169</b> and pin 1 of <b>G193</b>
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step <b>G5</b>

(Cont.d)


## POWER ANTENNA INOPERATIVE

## TEST G

TEST STEPS		RESULTS	REMEDY
G5	VOLTAGE CHECK		
- Check for presence of 12V between pin 2 of connector G16 and ground		 ►  ►	Repair wiring between pin 2 G10 and pin 4 of G169  Repair wiring between pin 2 of G16 and pin of fuse F5 in auxiliary fuse box
G6	POWER ANTENNA CHECK		
- With the ignition key set to "run" or "start" and with radio power switch ON, check for presence of 12V between pin 2 of connector G193 and ground		 ►  ►	Replace power antenna O3  Repair wiring between pin 2 of G193 and pin 1 of G169

End of test G

# SEATS - - HEATER





## GENERAL

Both front and rear seats are electrically heated by heat pads.

The heat pads are energized by means of four control switches, two located on front seat side panels (B51 and B62) and two located on the rear central console (B57 and B59).

The heat pads are connected to thermal breakers which automatically open the circuit when the temperature reaches approximately  $30^{\circ}\pm 5^{\circ}\text{C}$  ( $86^{\circ}\pm 9^{\circ}\text{F}$ ). When the temperature decreases below  $15^{\circ}\text{C}$  ( $59^{\circ}\text{F}$ ) the thermal breakers close and allow the seat heat pads to warm-up. The system is protected by two fuses as follows:

- F23 fuse (20A) SEAT HEATER in the fuse box G1.
- Relay I56 fuse (30A).

## OPERATIONAL DESCRIPTION

The relay I56 is energized when the ignition key is set to "run" position.

12V from the battery is applied to the fuse F23 through the relay contacts, and the the control switches B51 and B62 and the coil of relay I56.

By pressing either B51 or B62 control switches the voltage reaches the corresponding front seat heater pad O14 or O17, thus allowing heating of the affected seat.

Operation of the rear seats heating system is similar to that of the front seats.

The control switches B57 and B59 are operative after the relay I56 has been energized.

By pressing either control switch, the voltage reaches the corresponding rear seat heater pad O15 or O16, thus allowing heating of the affected seat.

## TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT											
	F23 FUSE	156 RELAY FUSE	B51 SWITCH	B57 SWITCH	B59 SWITCH	B62 SWITCH	156 RELAY	158 RELAY	014 HEAT PAD	015 HEAT PAD	016 HEAT PAD	017 HEAT PAD
HEATING OF ALL SEATS INOPERATIVE	•							•				
LEFT FRONT SEAT HEATING INOPERATIVE			•						•			
RIGHT FRONT SEAT HEATING INOPERATIVE						•						•
HEATING OF BOTH REAR SEATS INOPERATIVE		•					•					
LEFT REAR SEAT HEATING INOPERATIVE					•						•	
RIGHT REAR SEAT HEATING INOPERATIVE				•						•		


<p>Left front seat heater control switch</p>	<p><b>B51</b></p>	<p>Right rear seat adjustment control switch</p>	<p><b>B56</b></p>
<p>Right rear seat heater control switch</p>	<p><b>B57</b></p>	<p>Left rear seat adjustment central switch</p>	<p><b>B58</b></p>
<p>Left rear seat heater control switch</p>	<p><b>B59</b></p>	<p>Right front seat heater control switch</p>	<p><b>B62</b></p>
<p>Fuse box</p>	<p><b>G1 E</b></p>	<p>Fuse box</p>	<p><b>G1 M</b></p>
<p>Fuse box</p>	<p><b>G1 N</b></p>	<p>Fuse box</p>	<p><b>G1 O</b></p>
<p>Steering wheel column support ground</p>	<p><b>G174</b></p>	<p>Center console ground</p>	<p><b>G182</b></p>

(Cont.d)

<p>Connector rear center console to front right seat wiring</p>	<p><b>G183</b></p>	<p>Connector, rear center console to front left seat wiring</p>	<p><b>G184</b></p>
<p>Trunk left side ground</p>	<p><b>G185</b></p>	<p>Connector, rear seats to rear console wiring</p>	<p><b>G189</b></p>
<p>Connector to rear seats wiring</p>	<p><b>G190</b></p>	<p>Connector doors wiring to rear console wiring</p>	<p><b>G210</b></p>









(Cont.d)

<p>Rear seats relay</p>	<p>I56</p>	<p>Left front seat heater pad</p>	<p>O14</p>
		<p>Right rear seat heater pad</p>	<p>O15</p>
<p>Left rear seat heater pad</p>	<p>O16</p>	<p>Right front seat heater pad</p>	<p>O17</p>



## HEATING OF ALL SEATS INOPERATIVE

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
- Check fuse F23 in fuse box G1 for integrity		 ►  ►	Carry-out step A2  Replace fuse F23
<b>A2</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin 1M of fuse box G1 and ground		 ►  ►	Repair wiring between pin 1M of fuse box G1 and pin 3 of connector G210  Carry-out step A3
<b>A3</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin 4O of fuse box G1 and ground		 ►  ►	Carry-out step A4  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>A4</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 12V between pin 2N of fuse box G1 and ground		 ►  ►	Carry-out step A5  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2

(Cont.d)

HEATING OF ALL SEATS INOPERATIVE

TEST A









TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 12E of fuse box G1	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; margin-right: 10px;">OK</div> <div style="font-size: 2em; margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 2em; margin-right: 10px;">▶</div> </div> </div>	<p>Replace relay I58</p> <p>Repair wiring between pin 12E of fuse box G1 and ground point G174</p>

End of test A



## RIGHT FRONT SEAT HEATING INOPERATIVE

















## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C1</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin 3 of switch B62 and ground		 ►  ►	Carry-out step C2  Repair wiring between pin 3 of switch B62, pin 1 of connector G183 and pin 3 of connector G210
<b>C2</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin 2 of switch B62 and ground when the switch is actuated		 ►  ►	Carry-out step C3  Replace switch B62
<b>C3</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin 1 of heater pad O17 and ground		 ►  ►	Carry-out step C4  Repair wiring between pin 2 of switch B62 and pin 1 of heater pad O17
<b>C4</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 2 of heater pad O17		 ►  ►	Replace heater pad O17  Repair wiring between pin 2 of heater pad O17, pin 2 of connector G183 and ground point G182

End of test C

## HEATING OF BOTH REAR SEATS INOPERATIVE

## TEST D

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> If failure of both rear seats heating is associated to failure of left front seat heating, repair wiring between pin 3 of connector G210 and pin 1 of connector G184.</p>			
<b>D1</b>	<b>FUSE CHECK</b>		
- Check fuse of relay I56 for integrity		 	Carry-out <b>step D2</b>
		 	Replace <b>relay fuse</b>
<b>D2</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin 85 of relay I56 and ground		 	Carry-out <b>step D3</b>
		 	Carry-out <b>step D7</b>
<b>D3</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 86 of relay I56		 	Carry-out <b>step D4</b>
		 	Restore continuity between <b>ground point G185 and pin 86 of relay I56</b>
<b>D4</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin 30 of relay I56 and ground		 	Carry-out <b>step D6</b>
		 	Carry-out <b>step D5</b>

(Cont.d)

## HEATING OF BOTH REAR SEATS INOPERATIVE









## TEST D

TEST STEPS		RESULTS	REMEDY
D5	VOLTAGE CHECK		
- Check for presence of 12V between pin 87 of relay I56 and ground		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace relay I56</p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 1 of 2</p>
D6	VOLTAGE CHECK		
- With the ignition key set to the "run" position check for presence of 12V between pin 4 of connector G190 and ground		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between ground point G185, pin 1 of connector G109 and pin 2 of heater pad O15</p> <p>Repair wiring between pin 4 of connector G190 and pin 30 of relay I56</p>
D7	VOLTAGE CHECK		
- With the ignition key set to the "run" position check for presence of 12V between pin 1 of connector G189 and ground		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pin 1 of connector G189 and pin 85 of relay I56</p> <p>Repair wiring between pin 1 of connector G184 and pin 1 of connector G189</p>

End of test D

## LEFT REAR SEAT HEATING INOPERATIVE







## TEST E

TEST STEPS		RESULTS	REMEDY
E1	VOLTAGE CHECK		
- With the ignition key set to "run" check for presence of 12V between pin 3 of switch B59 and ground		 ►  ►	Carry-out step E2  Repair wiring between pin 3 of switch B59 and pin 4 of connector G190
E2	VOLTAGE CHECK		
- With the ignition key set to "run" check for presence of 12V between pin 2 of switch B59 and ground when the switch is actuated		 ►  ►	Carry-out step E3  Replace switch B59
E3	VOLTAGE CHECK		
- With the ignition key set to "run" and the switch activated B59, check for presence of 12V between pin 1 of heater pad O16 and ground		 ►  ►	Carry-out step E4  Repair wiring between pin 2 of switch B59 and pin 1 of heater pad O16
E4	GROUNDING CHECK		
- With the ignition key set to "run" and the switch activated B59, check for presence of 0V (zero) between pin 2 of heater pad O16 and ground		 ►  ►	Replace heater pad O16  Repair wiring between pin 2 of heater pad O16 and pin 2 of heater pad O15

End of test E

## RIGHT REAR SEAT HEATING INOPERATIVE

## TEST F

TEST STEPS		RESULTS	REMEDY
<b>F1</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin 3 of switch <b>B57</b> and ground		 ►  ►	Carry-out step <b>F2</b>  Repair wiring between pin 3 of switch <b>B57</b> and pin 4 of connector <b>G190</b>
<b>F2</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin 2 of switch <b>B57</b> and ground when the switch is actuated		 ►  ►	Carry-out step <b>F3</b>  Replace switch <b>B57</b>
<b>F3</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" and the switch activated <b>B57</b> , check for presence of 12V between pin 1 of heater pad <b>O15</b> and ground		 ►  ►	Replace heater pad <b>O15</b>  Repair wiring between pin 2 of switch <b>B57</b> and pin 1 of heater pad <b>O15</b>

End of test F

**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>

SEATS - - POWER ADJUSTABLE





## GENERAL

Both front and rear seats can be electrically adjusted, even when the ignition key is in the "off" position. Adjustment is controlled by means of switches.

Adjustment of the front seats is obtained by three integral light buttons on the seat side panel.

- Longitudinal adjustment (fore and aft).
- Vertical adjustment (up and down).
- Backrest adjustment.

Longitudinal adjustment of rear seats is obtained by the buttons on the rear central console. To facilitate access to the rear seats, opening of either rear door automatically retracts the rear seats to the most rear position.

The front seats circuit is protected by free fuse **G240** (20A) FRONT SEATS FUSE, while the rear seats circuit is protected by the free fuse **G246** (20A).

## OPERATIONAL DESCRIPTION - POWER ADJUSTABLE FRONT SEATS

The battery power (12V), available even when the ignition key is set to "off", is applied to connector **G210** through the free fuse **G240**.

12V from connector **G210** is supplied to the six control switches (three switches for each seat) through suitable bridges.

Pressing the fore or aft control switch **B54** in one direction, 12V with reference to ground point **G182** are supplied with a certain polarity to corresponding motor **P29**, with consequent fore or aft movement of left front seat.

Pressing the switch **B54** in the opposite direction reverses the polarity of power supplied to motor **P29**, with consequent movement of the seat in the opposite direction.


Remaining power adjustments of the right and left front seats are obtained in the same mode.

## TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT												
	G240 FUSE	B29 SWITCH	B63 SWITCH	B52 SWITCH	B26 SWITCH	B27 SWITCH	B54 SWITCH	P6 MOTOR	P30 MOTOR	P28 MOTOR	P7 MOTOR	P5 MOTOR	P29 MOTOR
BOTH FRONT SEATS INOPERATIVE	•												
LEFT FRONT SEAT LONGITUDINAL ADJUSTMENT INOPERATIVE							•						•
LEFT FRONT SEAT VERTICAL ADJUSTMENT INOPERATIVE						•						•	
LEFT FRONT SEAT BACKREST ADJUSTMENT INOPERATIVE					•						•		
RIGHT FRONT SEAT LONGITUDINAL ADJUSTMENT INOPERATIVE				•						•			
RIGHT FRONT SEAT VERTICAL ADJUSTMENT INOPERATIVE			•						•				
RIGHT FRONT SEAT BACKREST ADJUSTMENT INOPERATIVE		•						•					

**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>



## OPERATIONAL DESCRIPTION - ADJUSTABLE REAR SEATS

The battery power (12V), available even when the ignition key is set to the "off", is applied to coil of right and left rear seat relays I54 and I55; furthermore, power is applied to rear seat adjustment control switches B56 and B58 through fuse G246.

Pressing the left rear seat adjustment control switch B58 in one direction, 12V with reference to ground point G185 are supplied with a certain polarity to the motor P33, with consequent fore or aft movement of the corresponding seat.

Pressing the switch B58 in the opposite direction reverses the polarity of power supplied to the motor P33, with consequent movement of the seat in the opposite direction.

Opening of the left rear door closes the switches normally open H41, thus providing the ground to relay I55.

When the relay I55 is energized, 12V are applied to motor P33 with polarity such as that the seat retracts to the most rear position.


When the seat reaches the end of its travel, the stop microswitch normally closed H39 opens and switches off the motor. Adjustment of the right rear seat is obtained in the same mode.

### TROUBLESHOOTING TABLE











FAULT TYPE	FAILED COMPONENT										
	G246 FUSE	H38 MICROSWITCH	H39 MICROSWITCH	H40 SWITCH	H41 SWITCH	B56 SWITCH	B58 SWITCH	I54 RELAY	I55 RELAY	P32 MOTOR	P33 MOTOR
BOTH REAR SEATS ADJUSTMENT INOPERATIVE	•										
LEFT REAR SEAT ADJUSTMENT INOPERATIVE							•				•
RIGHT REAR SEAT ADJUSTMENT INOPERATIVE						•				•	
LEFT REAR SEAT AUTOMATIC RETRACTION INOPERATIVE			•		•				•		•
RIGHT REAR SEAT AUTOMATIC RETRACTION INOPERATIVE		•		•				•		•	

<p>Left front seat height control switch</p>	<p><b>B27</b></p>	<p>Left front seat back control switch</p>	<p><b>B28</b></p>
		<p>Right front seat back control switch</p>	<p><b>B29</b></p>
		<p>Left front seat longitudinal control switch</p>	<p><b>B54</b></p>
		<p>Left rear seat adjustment control switch</p>	<p><b>B58</b></p>
		<p>Fuse box</p>	<p><b>G1 T</b></p>
		<p>Six pin connector circuit board to doors wiring</p>	<p><b>G16</b></p>


(Cont.d)



(Cont.d)









<p>Rear seat adjustment fuse - 20A</p>	<p>G246</p>	<p>Right rear seat microswitch</p>	<p>H38</p>
			
<p>Left rear seat microswitch</p>	<p>H39</p>	<p>Right rear door for rear seats inhibitor switch</p>	<p>H40</p>
			
<p>Left rear door for rear seats inhibitor switch</p>	<p>H41</p>	<p>Right rear seat relay</p>	<p>I54</p>
			
<p>Left rear seat relay</p>	<p>I55</p>	<p>Rear seats relay</p>	<p>I56</p>
			
<p>Right rear seat motor</p>	<p>P32</p>	<p>Left rear seat motor</p>	<p>P33</p>
			





## BOTH FRONT SEATS INOPERATIVE









## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
- Check free fuse <b>G240</b> for integrity		 ►  ►	Carry-out step <b>A2</b>  Replace free fuse <b>G240</b>
<b>A2</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between pins of auxiliary fuse box		 ►  ►	Carry-out step <b>A3</b>  Repair wiring
<b>A3</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin of auxiliary fuse box (RED wire) and ground		 ►  ►	Carry-out step <b>A4</b>  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>A4</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 3 of connector <b>G16</b> and ground		 ►  ►	Repair wiring between pin 3 of <b>G16</b> and pin of free fuse <b>G240</b> , and between pin of <b>G240</b> and pin 1 of <b>G210</b>  Repair wiring between pin of <b>G240</b> and pin 3 of <b>G16</b>

End of test A

## LEFT FRONT SEAT LONGITUDINAL ADJUSTMENT INOPERATIVE







## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>ADJUSTMENTS CHECK</b>		
- Check if left front seat vertical and backrest adjustments are operational		 ►  ►	Carry-out step B2  Carry-out step B7
<b>B2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pins 3 and 5 and ground of switch B54		 ►  ►	Carry-out step B3  Repair wiring between switch B54 (pins 3 and 5) and pin 5 of switch B27
<b>B3</b>	<b>GROUNDING CHECK</b>		
- Check that pin 4 of switch B54 has 0V to ground with the switch activated		 ►  ►	Carry-out step B4  Repair wiring between pin 4 of switch B54 and pin 4 of switch B27
<b>B4</b>	<b>SWITCH CHECK</b>		
- Check switch B54 for proper operation		 ►  ►	Carry-out step B5  Replace switch B54

(Cont.d)

## LEFT FRONT SEAT LONGITUDINAL ADJUSTMENT INOPERATIVE









## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B5</b>	<b>MOTOR CHECK</b>		
- Press switch <b>B54</b> in both directions and check for presence of 12V at terminals of motor <b>P29</b> ; polarity is dependent on direction of pressure on the switch		 ►  ►	Replace motor <b>P29</b>  Carry-out step <b>B6</b>
<b>B6</b>	<b>VOLTAGE CHECK</b>		
- Press switch <b>B54</b> in both directions and check for presence of 12V between pins 3 and 4 of connector <b>G155b</b> ; polarity is dependent on direction of pressure on the switch		 ►  ►	Repair wiring between pins 3 and 4 of connector <b>G155b</b> and pin of motor <b>P29</b>  Repair wiring between switch <b>B54</b> (pins 1 and 2) and connector <b>G155b</b> (pins 3 and 4)
<b>B7</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 3 and 5 to ground of left front seat back control switch <b>B28</b>		 ►  ►	Repair wiring between ground point <b>G182</b> , pin 2 of connector <b>G184a</b> and pin 4 of switch <b>B28</b>  Repair wiring between pin 1 of connector <b>G210</b> , pin 1 of connector <b>G184a</b> and pins 3 and 5 of switch <b>B28</b>

End of test B

## LEFT FRONT SEAT VERTICAL ADJUSTMENT INOPERATIVE







## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C1</b>	<b>ADJUSTMENTS CHECK</b>		
- Check if left front seat longitudinal and backrest adjustments are operational		 ▶  ▶	Carry-out <b>step C2</b>  Carry-out <b>step C7</b>
<b>C2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pins 3 and 5 and ground of switch B27		 ▶  ▶	Carry-out <b>step C3</b>  Repair wiring between <b>switch B27 (pins 3 and 5) and pin 5 of switch B28</b>
<b>C3</b>	<b>GROUNDING CHECK</b>		
- Check that pin 4 of switch B27 has 0V to ground with the switch activated		 ▶  ▶	Carry-out <b>step C4</b>  Repair wiring between <b>pin 4 of switch B27 and pin 4 of switch B28</b>
<b>C4</b>	<b>SWITCH CHECK</b>		
- Check switch B27 for proper operation		 ▶  ▶	Carry-out <b>step C5</b>  Replace <b>switch B27</b>

(Cont.d)

## LEFT FRONT SEAT VERTICAL ADJUSTMENT INOPERATIVE









## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C5</b>	<b>MOTOR CHECK</b>		
- Press switch <b>B27</b> in both directions and check for presence of 12V at terminals of motor <b>P5</b> ; polarity is dependent on direction of pressure on the switch		 ►  ►	Replace motor <b>P5</b>  Carry-out step <b>C6</b>
<b>C6</b>	<b>VOLTAGE CHECK</b>		
- Press switch <b>B27</b> in both directions and check for presence of 12V between pins 5 and 6 of <b>G155b</b> connector; polarity is dependent on direction of pressure on the switch		 ►  ►	Repair wiring between pins 5 and 6 of connector <b>G155b</b> ; and motor <b>P5</b>  Repair wiring between switch <b>B27</b> (pins 1 and 2) and connector <b>G155b</b> (pins 5 and 6)
<b>C7</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pins 3 and 5 and ground of control switch <b>B28</b>		 ►  ►	Repair wiring between ground point <b>G182</b> , pin 2 of connector <b>G184a</b> and pin 4 of switch <b>B28</b>  Repair wiring between pin 1 of connector <b>G210</b> , pin 1 of connector <b>G184a</b> and pins 3 and 5 of switch <b>B28</b>

End of test C

## LEFT FRONT SEAT BACKREST ADJUSTMENT INOPERATIVE



## TEST D

TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>ADJUSTMENTS CHECK</b>		
	- Check if left front seat longitudinal and vertical adjustments are operational	 	Carry-out <b>step D2</b>  Carry-out <b>step D5</b>
<b>D2</b>	<b>SWITCH CHECK</b>		
	- Check switch <b>B28</b> for proper operation	 	Carry-out <b>step D3</b>  Replace <b>switch B28</b>
<b>D3</b>	<b>MOTOR CHECK</b>		
	- Press switch <b>B28</b> in both directions and check for presence of 12V at terminals of motor <b>P7</b> ; polarity is dependent on direction of pressure on the switch	 	Replace <b>motor P7</b>  Carry-out <b>step D4</b>
<b>D4</b>	<b>VOLTAGE CHECK</b>		
	- Press switch <b>B28</b> in both directions and check for presence of 12V between pins 1 and 2 of connector <b>G155b</b> ; polarity is dependent on direction pressure on the switch	 	Repair wiring between <b>pins 1 and 2 of connector G155b and motor P7</b>  Repair wiring between <b>switch B28 (pins 1 and 2) and connector G155b (pins 1 and 2)</b>

(Cont.d)

## LEFT FRONT SEAT BACKREST ADJUSTMENT INOPERATIVE

## TEST D









TEST STEPS		RESULTS	REMEDY
D5	VOLTAGE CHECK		
- Check for presence of 12V between pins 3 and 5 and ground of control switch B28			Repair wiring between ground point G182, pin 2 of connector G184a and pin 4 of switch B28
			Repair wiring between pin 1 of connector G210, pin 1 of connector G184a and pins 3 and 5 of switch B28

End of test D



## RIGHT FRONT SEAT LONGITUDINAL ADJUSTMENT INOPERATIVE







## TEST E

TEST STEPS		RESULTS	REMEDY
<b>E1</b>	<b>ADJUSTMENTS CHECK</b>		
	- Check if right front seat vertical and backrest adjustments are operational	 ►  ►	Carry-out <b>step E2</b>  Carry-out <b>step E7</b>
<b>E2</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pins 3 and 5 and ground of switch B52	 ►  ►	Carry-out <b>step E3</b>  Repair wiring between <b>switch B52 (pins 3 and 5) and switch B63 (pins 5 and 3)</b>
<b>E3</b>	<b>GROUNDING CHECK</b>		
	- Check that pin 4 of switch B52 has 0V to ground with the switch	 ►  ►	Carry-out <b>step E4</b>  Repair wiring between <b>pin 4 of switch B52 and pin 4 of switch B63</b>
<b>E4</b>	<b>SWITCH CHECK</b>		
	- Check switch B52 for proper operation	 ►  ►	Carry-out <b>step E5</b>  Replace <b>switch B52</b>

(Cont.d)

## RIGHT FRONT SEAT LONGITUDINAL ADJUSTMENT INOPERATIVE









## TEST E

TEST STEPS		RESULTS	REMEDY
<b>E5</b>	<b>MOTOR CHECK</b>		
- Press switch <b>B52</b> in both directions and check for presence of 12V at terminals of motor <b>P28</b> ; polarity is dependent on direction of pressure on the switch		 ►  ►	Replace motor <b>P28</b>  Carry-out step <b>E6</b>
<b>E6</b>	<b>MOTOR CHECK</b>		
- Press switch <b>B52</b> in both directions and check for presence of 12V between pins 3 and 4 of connector <b>G155a</b> ; polarity is dependent on direction of pressure on the switch		 ►  ►	Repair wiring between pins 3 and 4 of connector <b>G155a</b> and motor <b>P28</b>  Repair wiring between switch <b>B52</b> (pin 1 and 2) and connector <b>G155a</b> (pins 3 and 4)
<b>E7</b>	<b>MOTOR CHECK</b>		
- Check for presence of 12V between pins 3 and 5 and ground of control switch <b>B29</b>		 ►  ►	Repair wiring between ground point <b>G182</b> , pin 2 of connector <b>G183b</b> and pin 4 of switch <b>B29</b>  Repair wiring between pin 1 of connector <b>G210</b> , pin 1 of connector <b>G183b</b> and pins 3 and 5 of switch <b>B29</b>

End of test E

## RIGHT FRONT SEAT VERTICAL ADJUSTMENT INOPERATIVE







TEST F

TEST STEPS		RESULTS	REMEDY
<b>F1</b>	<b>ADJUSTMENTS CHECK</b>		
- Check if right front seat longitudinal and backrest adjustments are operational		 	Carry-out step F2  Carry-out step F7
<b>F2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pins 3 and 5 and ground of switch B63		 	Carry-out step F3  Repair wiring between switch B63 (pins 3 and 5) and pin 5 of control switch B29
<b>F3</b>	<b>GROUNDING CHECK</b>		
- Check that pin 4 of switch B63 is connected to ground		 	Carry-out step F4  Repair wiring between pin 4 of switch B63 and pin 4 of control switch B29
<b>F4</b>	<b>SWITCH CHECK</b>		
- Check switch B63 for proper operation		 	Carry-out step F5  Replace switch B63

(Cont.d)

## RIGHT FRONT SEAT VERTICAL ADJUSTMENT INOPERATIVE









## TEST F

TEST STEPS		RESULTS	REMEDY
<b>F5</b>	<b>MOTOR CHECK</b>		
- Press switch <b>B63</b> in both directions and check for presence of 12V at terminals of motor <b>P30</b> ; polarity is dependent on direction of pressure on the switch		 	Replace motor <b>P30</b>  Carry-out <b>step F6</b>
<b>F6</b>	<b>VOLTAGE CHECK</b>		
- Press switch <b>B63</b> in both directions and check for presence 12V between pins 5 and 6 of connector <b>G155a</b> ; polarity is dependent on direction of pressure on the switch		 	Repair wiring between <b>pins 5 and 6</b> of connector <b>G155a</b> and motor <b>P30</b>  Repair wiring between switch <b>B63</b> (pins 1 and 2) and connector <b>G155a</b> (pins 5 and 6)
<b>F7</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pins 3 and 5 and ground of control switch <b>B29</b>		 	Repair wiring between ground point <b>G182</b> , pin 2 of connector <b>G183b</b> and pin 4 of switch <b>B29</b>  Repair wiring between pin 1 of connector <b>G210</b> , pin 1 of connector <b>G183b</b> and pins 3 and 5 of switch <b>B29</b>

End of test F

## RIGHT FRONT SEAT BACKREST ADJUSTMENT INOPERATIVE



TEST G

TEST STEPS		RESULTS	REMEDY
<b>G1</b>	<b>ADJUSTMENTS CHECK</b>		
- Check if right front seat longitudinal and vertical adjustments are operational		 ►  ►	Carry-out step G2  Carry-out step G5
<b>G2</b>	<b>SWITCH CHECK</b>		
- Check switch B29 for proper operation		 ►  ►	Carry-out step G3  Replace switch B29
<b>G3</b>	<b>MOTOR CHECK</b>		
- Press switch B29 in both directions and check for presence of 12V at terminals of motor P6; polarity is dependent on direction of pressure on the switch		 ►  ►	Replace motor P6  Carry-out step G4
<b>G4</b>	<b>VOLTAGE CHECK</b>		
- Press switch B29 in both directions and check for presence 12V between pins 1 and 2 of connector G155a; polarity is dependent on direction of pressure on the switch		 ►  ►	Repair wiring between pins 1 and 2 of connector G155a and motor P6  Repair wiring between switch B29 (pins 1 and 2) and connector G155a (pins 1 and 2)

(Cont.d)

RIGHT FRONT SEAT BACKREST ADJUSTMENT INOPERATIVE







TEST G

TEST STEPS		RESULTS	REMEDY
G5	VOLTAGE CHECK		
- Check for presence of 12V between pins 3 and 5 and ground of control switch B29			Repair wiring between ground point G182, pin 2 of connector G183b and pin 4 of switch B29
			Repair wiring between pin 1 of connector G210, pin 1 of connector G183b and pins 3 and 5 of switch B29

End of test G

## BOTH REAR SEATS ADJUSTMENT INOPERATIVE







## TEST H

TEST STEPS		RESULTS	REMEDY
H1	FUSE CHECK		
- Check free fuse G246 for integrity		 	Carry-out step H2  Replace free fuse G246
H2	VOLTAGE CHECK		
- Check for presence of 12V between pins U and T and ground of switch B58		 	Repair wiring between ground point G185, pin 1 of connector G190 and switch B58  Carry-out step H3
H3	RELAY CHECK		
- Check relay I56 for correct connection with the wiring		 	Repair wiring between fuse G246, G190 (pin 3) and pin "U" and "T" of switch B58 (PPL wire) and between pin 87a of relay I56 and fuse G246  Restore proper connection of relay I56

End of test H

## LEFT REAR SEAT ADJUSTMENT INOPERATIVE







## TEST I

TEST STEPS		RESULTS	REMEDY
<b>I1</b>	<b>AUTOMATIC RETRACTION CHECK</b>		
- Open left rear door and check that left rear seat automatically retracts to the most rear position		 ►  ►	Carry-out <b>step I2</b>  Carry-out <b>step I3</b>
<b>I2</b>	<b>SWITCH CHECK</b>		
- Check integrity switch <b>B58</b>		 ►  ►	Repair wiring between <b>switch B58 (YEL wire)</b> and <b>pin 1</b> of <b>motor P33</b>  Replace <b>switch B58</b>
<b>I3</b>	<b>MOTOR CHECK</b>		
- Press switch <b>B58</b> in both directions and check for presence of 12V between pins 1 and 2 of motor <b>P33</b> ; polarity is dependent on direction of pressure on the switch		 ►  ►	Replace <b>motor P33</b>  Repair wiring between <b>pin 2</b> of <b>motor P33</b> and <b>pin 30</b> of <b>relay I55</b>

End of test I



















<b>RIGHT REAR SEAT ADJUSTMENT INOPERATIVE</b>	<b>TEST J</b>
---	---------------

TEST STEPS		RESULTS	REMEDY
<b>J1</b>	<b>AUTOMATIC RETRACTION CHECK</b>		
- Open right rear door and check that right rear seat automatically retracts to the most rear position		 	Carry-out step J2  Carry-out step J3
<b>J2</b>	<b>SWITCH CHECK</b>		
- Check integrity switch <b>B56</b>		 	Repair wiring between pin v of switch <b>B56</b> (GRN wire) and pin 1 of motor <b>P32</b>  Replace switch <b>B56</b>
<b>J3</b>	<b>MOTOR CHECK</b>		
- Press switch <b>B56</b> in both directions and check for presence of 12V between pins 1 and 2 of motor <b>P32</b> ; polarity is dependent on direction of pressure on the switch		 	Replace motor <b>P32</b>  Repair wiring between pin 2 of motor <b>P32</b> and pin 30 of relay <b>I54</b>

End of test J

## LEFT REAR SEAT AUTOMATIC RETRACTION INOPERATIVE

## TEST K

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> The rear seats automatic retraction circuit includes a seat microswitch that checks the seat end of travel. If, when the rear door is opened the seat retracts to the end of travel, but the actuating motor does not de-energize, replace left rear seat microswitch H39.</p>			
<b>K1</b>	<b>ADJUSTMENTS CHECK</b>		
- Check that left rear seat adjustment is operational when switch B58 is actuated		 	Carry-out step K2
		 	Carry-out step K6
<b>K2</b>	<b>SWITCH CHECK</b>		
- Open left rear door and check that circuit between terminals of switch H41 is closed		 	Carry-out step K3
		 	Replace switch H41
<b>K3</b>	<b>GROUNDING CHECK</b>		
- Check that ground is connected to:		 	Carry-out step K4
<ul style="list-style-type: none"> <li>• terminals of switch H41</li> <li>• pin 6 of connector G190</li> <li>• terminals of microswitch H39</li> </ul>		 	Replace or repair wires, as necessary
<b>K4</b>	<b>RELAY CHECK</b>		
- Check relay I55 for proper operation		 	Carry-out step K5
		 	Replace relay I55

(Cont.d)

## LEFT REAR SEAT AUTOMATIC RETRACTION INOPERATIVE













## TEST K

TEST STEPS		RESULTS	REMEDY
<b>K5</b>	<b>RIGHT REAR SEAT AUTOM. RETRACTION CHECK</b>		
	<ul style="list-style-type: none"> <li>Open right rear door and check that right rear seat automatically retracts</li> </ul>	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pins 86 and 87 of relay I54 and pins 86 and 87 of relay I55</p> <p>Repair wiring between pin 3, pin 2 of connector G190 and pins 86 and 87 of relay I54</p>
<b>K6</b>	<b>MOTOR CHECK</b>		
	<ul style="list-style-type: none"> <li>Open left rear door, then check for presence of 12V between pins 2 and 1 of motor P33 (positive at pin 2)</li> </ul>	<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace motor P33</p> <p>Repair wiring between pin 2 of motor P33 and pin 30 of relay I55</p>

End of test K

## RIGHT REAR SEAT AUTOMATIC RETRACTION INOPERATIVE





## TEST L

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> The rear seats automatic retraction circuit includes a seat microswitch that checks the seat end of travel. If, when the rear door is opened the seat retracts to the end of travel, but the actuating motor does not de-energize, replace right rear seat microswitch H38.</p>			
L1	ADJUSTMENTS CHECK		
- Check that right rear seat adjustment is operational when switch B56 is actuated		 	Carry-out step L2
		 	Carry-out step L5
L2	SWITCH CHECK		
- Open right rear door and check that circuit between terminals of switch H40 is closed		 	Carry-out step L3
		 	Replace switch H40
L3	GROUNDING CHECK		
- When switch H40 e H38 are actuated check that ground G185 is connected to:		 	Carry-out step L4
<ul style="list-style-type: none"> <li>• pin 1 of connector G190</li> <li>• terminals of switch H40</li> <li>• pin 5 of connector G190</li> <li>• terminals of microswitch H38</li> </ul>		 	Replace or repair wires, as necessary

(Cont.d)

## RIGHT REAR SEAT AUTOMATIC RETRACTION INOPERATIVE

## TEST L

TEST STEPS		RESULTS	REMEDY
<b>L4</b>	<b>RIGHT REAR SEAT AUTOM. RETRACTION CHECK</b>		
	- Open right rear door and check that right rear seat automatically retracts	 ►  ►	Replace relay I54  Repair wiring between pins 3 and 2 of connector G190 and pins 86 and 87 of relay I54
<b>L5</b>	<b>MOTOR CHECK</b>		
	- Open right rear door, then check for presence of 12V between pins 2 and 1 of motor P32 (positive at pin 2)	 ►  ►	Replace motor P32  Repair wiring between pin 2 of motor P32 and pin 30 of relay I54

End of test L

SENSORS - - BRAKE AND  
WINDSHIELD WASHER FLUID  
LEVELS, PARKING BRAKE  
WARNING LAMPS


REFER TO POWER DISTRIBUTION CIRCUIT G56 (SHEET 1 OF 2)

HOT AT ALL TIMES

HOT IN RUN

REFER TO POWER DISTRIBUTION CIRCUIT B1 PIN 2 (SHEET 2 OF 2)

FUSE BOX G1 PIN 2



## GENERAL

The brake fluid level, windshield washer fluid level and parking brake engagement are monitored by an electronic control unit which, in case of a malfunction, alerts the user by switching on the related warning lamps on the instrument panel. The power supply line is protected by the fuse F2 (7.5A) KEY-CONTROLLED CURRENTS FOR ELECTR. CIRCUIT in the auxiliary fuse box G2. For further information refer to the instrument panel circuits chapter.

## OPERATIONAL DESCRIPTION

When the level of the windshield washer fluid decreases below the minimum, the windshield and headlamps washer fluid sensor L13 opens, thus disconnecting the Alfa Romeo Control unit N22 from its ground point. The control unit N22 alerts the user of the low fluid level by switching on the related warning lamp on the instrument panel (refer to the instrument panel circuits chap-

ter).

When the parking brake is engaged, the parking brake switch H1 opens, thus disconnecting the control unit N22 from its ground point. The control unit N22 alerts the user that parking brake is engaged by switching on the related warning lamp on the instrument panel (refer to the instrument panel circuits chapter).

The brake fluid minimum level warning indicator switch H17 consists of a contact which is open when the level of brake fluid is sufficient.

When the level of brake fluid becomes insufficient, the switch H17 closes, and energizes the brake fluid and reservoir relay I73

Energization of relay I36 disconnects the 12V power supply from pin 7A of control unit N22, which in turn alerts the user of the malfunction by switching on the related warning lamp on the instrument panel (refer to the instrument panel circuits chapter).












The 12V power for the energization of relay I36 is supplied by the electronic control units power supply relay I51, provided the ignition key is set to "run" position.













TROUBLESHOOTING TABLE


FAULT TYPE	FAILED COMPONENT						
	E2	H1	H17	L13	151	172	N22
	FUSE	SWITCH	SWITCH	SENSOR	RELAY	RELAY	CONTROL UNIT
BRAKE FLUID LEVEL WARNING LAMP INOPERATIVE	●		●		●	●	●
BRAKE FLUID LEVEL WARNING LAMP CONTINUOUSLY ILLUMINATED			●			●	●
MINIMUM WINDSHIELD WASHER FLUID LEVEL WARNING LAMP INOPERATIVE				●			●
MINIMUM FLUID LEVEL/WINDSHIELD WASHER FLUID LEVEL WARNING LAMP CONTINUOUSLY ILLUMINATED				●			●
PARKING BRAKE ENGAGED WARNING LAMP INOPERATIVE		●					●
PARKING BRAKE ENGAGED WARNING LAMP CONTINUOUSLY ILLUMINATED		●					●

NOTE: Before attempting any troubleshooting, ascertain the integrity of the affected warning lamp on the instrument panel by pressing the test button.







<p>Fuse box</p>  <p>GRY-BLK* (N22) 8</p>	<p>(G1) D</p>	<p>Fuse box</p>  <p>GRY-BLK* (G100) 11</p>	<p>(G1) E</p>
<p>Fuse box</p>  <p>1.5BRN* HOT IN RUN 2 1BRN* (I51) 2</p>	<p>(G1) I</p>	<p>Auxiliary fuse box</p>  <p>1.5PNK* (I51) N22 PIN 2 C10 PIN 6 (C) C10 PIN 1 (D) G164 PIN 2 PNK-BLK* (I72) I70 PIN 87</p>	<p>(G2)</p>
<p>Engine compartment right side ground connection</p>  <p>1BLK* I19</p>	<p>G53a</p>		
<p>Connector, doors to center console wiring</p>	<p>G100</p>	<p>Connector, circuit board to engine compartment right side wiring</p>	<p>G149</p>
 <p>GRY-BLK* (G1) E 15 GRY-BLK* (H1) 15</p>		 <p>WHT-RED* (N22) B 12 WHT-RED* (L13) 12</p>	
<p>Central bulkhead ground</p>	<p>G143</p>	<p>Connector, circuit board to engine compartment left side wiring</p>	<p>G150</p>
 <p>BLK* L14</p>		 <p>1.5RED* (I51) 8 1.5RED* HOT AT ALL TIMES 8 ORN-BLK* (I72) 8 ORN-BLK* (H17) 8</p>	
<p>Steering wheel column support ground</p>	<p>G174</p>	<p>Center console ground</p>	<p>G182</p>
 <p>1BLK* (I51)</p>		 <p>BLK* (H1)</p>	

(Cont.d)

<p>Parking brake switch</p>	<p>(H1)</p>	<p>Brake fluid minimum level warning indicator switch</p>	<p>(H17)</p>
			
<p>Head lamps washer pump relay</p>	<p>I19</p>	<p>Electronic control units power supply relay</p>	<p>(I51)</p>
			
<p>Brake fluid reservoir relay</p>	<p>(I72)</p>	<p>Windshield and head lamps washer fluid sensor</p>	<p>(L13)</p>
			
<p>Engine coolant level sensor</p>	<p>L14</p>	<p>Alfa Romeo control unit</p>	<p>(N22) B</p>
			
<p>Alfa Romeo control unit</p>	<p>(N22) D</p>	<p>Windshield washer electric pump</p>	<p>P19</p>
			















<b>BRAKE FLUID LEVEL WARNING LAMP INOPERATIVE</b>	<b>TEST A</b>
---	---------------

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Before attempting any troubleshooting, check the related warning lamp on the instrument panel by pressing the test button: replace the affected lamp if it does not illuminate.</p>		
<b>A1</b> FUSE CHECK	 ►  ►	Carry-out step A2
- Check fuse F2 in auxiliary fuse box G2 for integrity		Replace fuse F2
<b>A2</b> VOLTAGE CHECK	 ►  ►	Carry-out step A7
- Check for presence of 12V between pin 87 of electronic control units power supply relay I51 and ground		Carry-out step A3
<b>A3</b> VOLTAGE CHECK	 ►  ►	Carry-out step A5
- Check for presence of 12V between pin 30 of relay I51 and ground		Carry-out step A4

(Cont.d)

## BRAKE FLUID LEVEL WARNING LAMP INOPERATIVE







## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A4</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 5 of connector G150 and ground		 	Repair wiring between pin 5 of connector G150 and pin 30 of relay I51
		 	Failure of the power distribution circuit, refer to the relevant circuit of sheet 1 of 2
<b>A5</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) between pin 85 of relay I51 and ground		 	Carry-out step A6
		 	Repair wiring between pin 85 of relay I51 and ground point G174
<b>A6</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run", check for presence of 12V between pin 86 of relay I51 and ground		 	Replace relay I51
		 	Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2

(Cont.d)

**BRAKE FLUID LEVEL WARNING LAMP INOPERATIVE**













**TEST A**

TEST STEPS		RESULTS	REMEDY
<b>A7</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between auxillary fuse box G2 (PNK wire) and ground		 	Carry-out <b>step A8</b>  Repair wiring between auxillary fuse box G2 pin (PNK wire) and pin 87 of relay I51
<b>A8</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 85 of brake fluid level reservoir relay I72 and ground		 	Carry-out <b>step A9</b>  Repair wiring between pin 85 of relay I72 and auxillary fuse box G2 (PNK-BLK wire)
<b>A9</b>	<b>GROUNDING CHECK</b>		
- With brake fluid level below minimum, check for presence of 0V (zero) at pin 86 of relay I72		 	Carry-out <b>step A10</b>  Carry-out <b>step A11</b>

(Cont.d)

## BRAKE FLUID LEVEL WARNING LAMP INOPERATIVE

## TEST A



TEST STEPS		RESULTS	REMEDY
<b>A10</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>- With brake fluid level below minimum, check that circuit is open between pins 7B and 8B of Alfa Romeo Control unit N22</li> </ul>		 	Failure of the Instrument panel - - Alfa Romeo Control ECU Interface circuit; refer to the applicable troubleshooting procedure
		 	Replace relay I72
<b>A11</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 0V (zero) at pin 6 of connector G150 with brake fluid level below minimum</li> </ul>		 	Repair wiring between pin 6 of connector G150 and pin 86 of relay I36
		 	Carry-out step A12
<b>A12</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 0V at terminal of brake fluid minimum level warning indicator switch H17 (ORN-BLK wire) under conditions stated at test step A8</li> </ul>		 	Repair wiring between pin 6 of connector G150 and terminal of switch H17 (ORN-BLK wire)
		 	Carry-out step A13

(Cont.d)



BRAKE FLUID LEVEL WARNING LAMP INOPERATIVE







TEST A

TEST STEPS		RESULTS	REMEDY
<b>A13</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin of switch H17 (BLK wire)		 	Replace switch H17  Repair wiring between terminal of switch H17 (BLK wire) and ground point G143

End of test A

## BRAKE FLUID LEVEL WARNING LAMP CONTINUOUSLY ILLUMINATED

## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>BRAKE FLUID LEVEL CHECK</b>		
- Check level of brake fluid		 	Carry-out step B2  Top-up brake fluid
<b>B2</b>	<b>CONTROL UNIT CHECK</b>		
- Check that circuit is closed between pins 7B and 8B of Alfa Romeo Control unit N22		 	Failure of the instrument panel -- Alfa Romeo Control ECU Interface circuit; refer to the applicable trouble-shooting procedure  Carry-out step B3
<b>B3</b>	<b>OPEN CIRCUIT CHECK</b>		
- Check that circuit is open at pin 86 of relay I72		 	Replace relay I72  Replace switch H17

End of test B

**MINIMUM WINDSHIELD WASHER FLUID LEVEL WARNING LAMP INOPERATIVE**

**TEST C**

**TEST STEPS**

**RESULTS**

**REMEDY**

**NOTE:** Before attempting any troubleshooting, check the related warning lamp on the instrument panel by pressing the test button; replace the affected lamp if it does not illuminate.

**C1 CONTROL UNIT CHECK**

- With windshield washer fluid level below minimum, check that circuit is open at pin 5B of Alfa Romeo Control unit N22









Failure of the instrument panel-- Alfa Romeo Control ECU interface circuit; refer to the applicable trouble-shooting procedure



Replace windshield and head lamps washer fluid sensor L13

End of test C

**MINIMUM FLUID LEVEL/WINDSHIELD WASHER FLUID LEVEL WARNING LAMP CONTINUOUSLY ILLUMINATED**
**TEST D**

TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>FLUID LEVEL CHECK</b>		
	- Check level of windshield washer fluid	 ►  ►	Carry-out step D2  Top-up windshield washer fluid
<b>D2</b>	<b>SENSOR CHECK</b>		
	- With sufficient windshield washer fluid, check that circuit is closed between terminals of windshield and head lamps washer fluid sensor L13	 ►  ►	Carry-out step D3  Replace sensor L13
<b>D3</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) between terminal of sensor L13 (BLK wire) and ground	 ►  ►	Carry-out step D4  Repair wiring between terminal of sensor L13 (BLK wire) and ground point G53a

(Cont.d)







MINIMUM FLUID LEVEL/WINDSHIELD WASHER FLUID LEVEL WARNING LAMP CONTINUOUSLY ILLUMINATED	TEST D
---	--------

TEST STEPS		RESULTS	REMEDY
D4	CONTROL UNIT CHECK		
<ul style="list-style-type: none"> <li>With sufficient windshield washer fluid, check for presence of 0V (zero) at pin 5B of Alfa Romeo Control unit N22</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Failure of the Instrument panel -- Alfa Romeo Control ECU Interface circuit; refer to the applicable trouble-shooting procedure</p> <p>Carry-out step D5</p>
D5	GROUNDING CHECK		
<ul style="list-style-type: none"> <li>With sufficient windshield washer fluid, check for presence of 0V (zero) at pin 12 of connector G149</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 12 of connector G149 and pin 5B of control unit N22</p> <p>Repair wiring between pin 12 of connector G149 and terminal of sensor L13 (WHT-RED wire)</p>

End of test D

## PARKING BRAKE ENGAGED WARNING LAMP INOPERATIVE

TEST E

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Before attempting any troubleshooting, check the related warning lamp on the instrument panel by pressing the test button: replace the affected lamp if it does not illuminate.</p>			
<b>E1</b>	<b>CONTROL UNIT CHECK</b>		
<ul style="list-style-type: none"> <li>- With parking brake engaged, check that circuit is open at pin 2D of Alfa Romeo Control unit N22</li> </ul>		<p>OK </p> <p><del>OK</del> </p>	<p>Failure of the Instrument panel-- Alfa Romeo Control ECU Interface circuit; refer to the applicable trouble-shooting procedure</p> <p>Carry-out step E2</p>
<b>E2</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>- With parking brake engaged, check that circuit is open at pin 11E of fuse box G1</li> </ul>		<p>OK </p> <p><del>OK</del> </p>	<p>Repair wiring between pin 11E, 8D of fuse box G1 and pin 2D of control unit</p> <p>Carry-out step E3</p>
<b>E3</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>- With parking brake engaged, check that circuit is open at terminal of switch H1 (GRY-BLK)</li> </ul>		<p>OK </p> <p><del>OK</del> </p>	<p>Repair wiring between terminal of switch H1 pin 15 of connector G100 and 11E of G1</p> <p>Carry-out step E4</p>







(Cont.d)

PARKING BRAKE ENGAGED WARNING LAMP INOPERATIVE	<b>TEST E</b>
--	---------------

TEST STEPS		RESULTS	REMEDY
<b>E4</b>	GRUNDING CHECK		
	- Check for presence of 0V (zero) between terminal of switch H1 and ground	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; margin-right: 10px;">OK</div> <div style="font-size: 24px; margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 24px; margin-right: 10px;">▶</div> </div> </div>	<p>Replace parking brake switch H1</p> <p>Repair wiring between terminal H1 and ground point G182</p>

End of test E

**PARKING BRAKE ENGAGED WARNING LAMP CONTINUOUSLY ILLUMINATED**
**TEST F**

TEST STEPS		RESULTS	REMEDY
<b>F1</b>	<b>PARKING BRAKE CHECK</b>		
	- Check that parking brake is disengaged	 	Carry-out step F2  Disengage parking brake
<b>F2</b>	<b>PARKING BRAKE SWITCH CHECK</b>		
	- Check that circuit is closed between terminals of parking brake switch H1	 	Carry-out step F3  Replace switch H1
<b>F3</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at terminal of switch H1 (BLK wire)	 	Carry-out step F4  Repair wiring between terminal of switch H1 (BLK wire) and ground point G182

(Cont.d)




**PARKING BRAKE ENGAGED WARNING LAMP CONTINUOUSLY ILLUMINATED**

**TEST F**

TEST STEPS		RESULTS	REMEDY
<b>F4</b>	<b>CONTROL UNIT CHECK</b>		
	- Check for presence of 0V (zero) at pin 2D of Alfa Romeo Control unit N22	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Failure of the Instrument panel -- Alfa Romeo Control ECU Interface circuit; refer to the applicable trouble-shooting procedure</p> <p>Carry-out step F5</p>
<b>F5</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 11E of fuse box G1	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 8D of fuse box G1 and pin 2D of control unit N22</p> <p>Carry-out step F6</p>
<b>F6</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 15 of connector G100	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 11E of fuse box G1 and pin 15 of connector G100</p> <p>Repair wiring between pin 15 of connector G100 and terminal of switch H1 (GRY-BLK wire)</p>

End of test F

SENSORS - - BRAKE PAD WEAR,  
ENGINE COOLANT LEVEL, MAXI-  
MUM COOLANT TEMPERATURE



## GENERAL

The front brake pads wear and the level and temperature of the engine coolant are continuously monitored by an electronic control unit that, in case of a malfunction, alerts the user by turning on the appropriate warning lamp on the instrument panel.

## OPERATIONAL DESCRIPTION

The right and left front brake pads switches H9 and H10 connect to ground pins 9B and 10B of the Alfa Romeo control unit N22 whenever the corresponding brake pads are slightly worn, and the brake pedal is actuated.

Severe wear of the brake pads causes opening of contacts of switches H9 and/or H10, with consequent open-

ing of circuit to pins 9B and 10B of control unit N22.

The level of engine coolant is monitored by the control unit N22 through the level sensor L14.

The engine coolant level sensor L14 contacts open when the engine coolant level decreases below the minimum, and disconnect pin 4B of control unit N22 from the ground point.

The wiring diagram also shows the engine coolant temperature bulb and high temperature switch L10, that opens and disconnect from ground point the pin 4D of the control unit N22 when the engine coolant temperature reaches the critical value of  $115\pm 3^{\circ}\text{C}$  ( $239\pm 5.4^{\circ}\text{F}$ ).













The switch L10 will close when the engine coolant temperature decreases below  $102^{\circ}\text{C}$  ( $183.6^{\circ}\text{F}$ ).


The control unit N22 will turn on the corresponding warning lamp on the instrument panel whenever any of the above mentioned failures occurs.

TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT				
	H9 SWITCH	H10 SWITCH	L10 SWITCH	L14 SENSOR	N22 CONTROL UNIT
BRAKE PADS WEAR WARNING LAMP INOPERATIVE	●	●			●
BRAKE PADS WEAR WARNING LAMP CONTINUOUSLY ILLUMINATED	●	●			●
ENGINE COOLANT LEVEL WARNING LAMP INOPERATIVE				●	●
ENGINE COOLANT LEVEL WARNING LAMP CONTINUOUSLY ILLUMINATED TEST				●	●
ENGINE COOLANT MAXIMUM TEMPERATURE WARNING LAMP INOPERATIVE			●		●
ENGINE COOLANT MAXIMUM TEMPERATURE WARNING LAMP CONTINUOUSLY ILLUMINATED TEST			●		●







**NOTE:** Before attempting any trouble shooting, check the related warning lamp on the instrument panel by pressing the test button.

<p>Central bulkhead ground</p>	<p><b>G143</b></p>	<p>Connector, circuit board to engine compartment right side wiring</p>	<p><b>G149</b></p>
			
<p>Connector, circuit board to engine compartment left side wiring</p>	<p><b>G150</b></p>	<p>Connector, circuit board to engine utilities wiring</p>	<p><b>G151</b></p>
			
<p>Right front brake pad switch</p>	<p><b>H9</b></p>		
		<p>Engine coolant temperature bulb and high temperature switch</p>	
<p>Left front brake pad switch</p>	<p><b>H10</b></p>	<p><b>L10</b></p>	
			
<p>Engine oil level sensor</p>	<p><b>L12</b></p>	<p>Engine coolant level sensor</p>	<p><b>L14</b></p>
			
<p>Alfa Romeo control unit</p>	<p><b>N22 B</b></p>	<p>Alfa Romeo control unit</p>	<p><b>N22 D</b></p>
			



## BRAKE PADS WEAR WARNING LAMP INOPERATIVE

## TEST A

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Before attempting any troubleshooting check the related warning lamp on the instrument panel by pressing the test button: replace the affected lamp if it does not illuminate.</p>			
<b>A1</b>	<b>BRAKE PADS WEAR CHECK</b>		
<ul style="list-style-type: none"> <li>- Check that brake pads (front right or front left) are just slightly worn (severe wear is not acceptable)</li> </ul>		 ►  ►	Carry-out step A2  Carry-out step A4
<b>A2</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Check that terminal of brake pad switch H9 and/or H10 is connected to ground (wires connecting to pin 1 of connector G149 and/or pin 1 of connector G150)</li> </ul>		 ►  ►	Carry-out step A3  Replace brake pad switch H9 (or H10)
<b>A3</b>	<b>CONTROL UNIT CHECK</b>		
<ul style="list-style-type: none"> <li>- Press and hold brake pedal and check for presence of 0V (zero) at pins 9B and/or 10B of Alfa Romeo control unit N22</li> </ul>		 ►  ►	Failure of Instrument panel - - Alfa Romeo Control ECU interface circuit; refer to the applicable troubleshooting procedure  Repair wiring between switch H9 (or H10), pin 1 of connector G149 (or pin 1 of connector G150) and pin 9B (or pin 10B) of control unit N22

(Cont.d)



**BRAKE PADS WEAR WARNING LAMP INOPERATIVE**









**TEST A**

TEST STEPS		RESULTS	REMEDY
<b>A4</b>	<b>SWITCH CHECK</b>		
<ul style="list-style-type: none"> <li>With left front brake pad seriously worn, check for open circuit condition between terminals of left front brake pad switch H10</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Carry-out step A5</p> <p>Replace brake pads</p>
<b>A5</b>	<b>CONTROL UNIT CHECK</b>		
<ul style="list-style-type: none"> <li>With right front brake pad seriously worn, check for open circuit condition between terminals of right front brake pad switch H9</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Failure of Instrument panel - - Alfa Romeo Control ECU interface circuit; refer to the applicable troubleshooting procedure</p> <p>Replace brake pads</p>

End of test A





## BRAKE PADS WEAR WARNING LAMP CONTINUOUSLY ILLUMINATED

## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>BRAKE PADS WEAR CHECK</b>		
	- Check wear of both right and left front brake pads	 ►  ►	Carry-out <b>step B2</b>  Replace <b>brake pads</b>
<b>B2</b>	<b>SWITCH CHECK</b>		
	- Check that circuit is closed between terminals of left front brake pad switch H10	 ►  ►	Carry-out <b>step B3</b>  Replace <b>switch H10</b>
<b>B3</b>	<b>SWITCH CHECK</b>		
	- Check that circuit is closed between terminals of right front brake pad switch H9	 ►  ►	Carry-out <b>step B4</b>  Replace <b>switch H9</b>
<b>B4</b>	<b>CONTROL UNIT CHECK</b>		
	- Check that circuit is closed between pins 9B and 10B of Alfa Romeo control unit N22	 ►  ►	Failure of <b>Instrument panel - - Alfa Romeo Control ECU Interface circuit</b> ; refer to the applicable <b>troubleshooting procedure</b>  Carry-out <b>step B5</b>







(Cont.d)

BRAKE PADS WEAR WARNING LAMP CONTINUOUSLY ILLUMINATED	<b>TEST B</b>
---	---------------

TEST STEPS		RESULTS	REMEDY
<b>B5</b>	CONTINUITY CHECK		
	- Check that circuit is closed between pin 10B of Alfa Romeo control unit N22, pin 1 of connector G150 and terminal of left front brake pad switch H10 (GRY-BLK wire)	 ►  ►	Carry-out <b>step B6</b>  Repair or replace wires, as necessary
<b>B6</b>	CONTINUITY CHECK		
	- Check that circuit is closed between terminal of left front brake pad switch H10 (GRY-BLK wire), pin 2 of connector G150, pin 2 of connector G149 and terminal of right front brake pad switch H9 (GRY-BLK wire)	 ►  ►	Repair wiring between terminal of switch H9, pin 1 of connector G149 and pin 9B of control unit N22  Repairs or replace wire, as necessary

End of test B









<b>ENGINE COOLANT LEVEL WARNING LAMP INOPERATIVE</b>	<b>TEST C</b>
--	---------------

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Before attempting any troubleshooting, check the related warning lamp on the instrument panel by pressing the test button: replace the affected lamp if it does not illuminate.</p>		
<b>C1</b>	<b>CONTROL UNIT CHECK</b>	
<ul style="list-style-type: none"> <li>- With the engine coolant level below the minimum, check that circuit is open at pin 4B of Alfa Romeo control unit N22</li> </ul>	 ►   ►	<p>Failure of Instrument panel - - Alfa Romeo Control ECU Interface circuit; refer to the applicable troubleshooting procedure</p> <p>Carry-out step C2</p>
<b>C2</b>	<b>CONTINUITY CHECK</b>	
<ul style="list-style-type: none"> <li>- With the engine coolant level below the minimum check that circuit is open at terminal of sensor L14 (ORN-WHT wire)</li> </ul>	 ►   ►	<p>Repair wiring between terminal of sensor L14, pin 13 of connector G150 and pin 4B of control unit</p> <p>Carry-out step C3</p>
<b>C3</b>	<b>GROUNDING CHECK</b>	
<ul style="list-style-type: none"> <li>- Check that terminal of sensor L14 (BLK wire) is connect to ground</li> </ul>	 ►   ►	<p>Replace sensor L14</p> <p>Repair wiring between sensor L14 and ground point G143 (BLK wire)</p>

End of test C

## ENGINE COOLANT LEVEL WARNING LAMP CONTINUOUSLY ILLUMINATED TEST

TEST D

TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>COOLANT LEVEL CHECK</b>		
	- Check level of engine coolant	 	Carry-out step D2  Top-up engine coolant
<b>D2</b>	<b>SENSOR CHECK</b>		
	- With engine coolant level within limits, check that circuit is closed between terminals of engine coolant level sensor L14	 	Carry-out step D3  Replace sensor L14
<b>D3</b>	<b>CONTROL UNIT CHECK</b>		
	- With engine coolant level within limits, check for presence of 0V (zero) at pin 4B of Alfa Romeo control unit N22	 	Failure of Instrument panel - - Alfa Romeo Control ECU interface circuit; refer to the applicable troubleshooting procedure  Carry-out step D4
<b>D4</b>	<b>GROUNDING CHECK</b>		
	- Check that terminal of sensor L14 is connected to ground (BLK wire)	 	Carry-out step D5  Repair wiring between sensor L14 and ground point G143 (BLK wire)

(Cont.d)

## ENGINE COOLANT LEVEL WARNING LAMP CONTINUOUSLY ILLUMINATED TEST

TEST D

TEST STEPS		RESULTS	REMEDY
D5	GROUNDING CHECK		
<ul style="list-style-type: none"> <li>- With engine coolant level within limits, check for presence of 0V (zero) at pin 13 of connector G150</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 13 of connector G150 and pin 4B of control unit N22</p> <p>Repair wiring between pin 13 of connector G150 and terminal of sensor L14 (ORN-WHT wire)</p>

End of test D













<b>ENGINE COOLANT MAX. TEMPERATURE WARNING LAMP INOPERATIVE</b>	<b>TEST E</b>
---	---------------

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Before attempting any troubleshooting, check the related warning lamp on the instrument panel by pressing the test button: replace the affected lamp if it does not illuminate.</p>		
<p><b>E1</b> TRANSMITTER CHECK</p>		
<p>- Check that engine coolant temperature bulb and high temperature switch L10 is operational as follows:</p> <ul style="list-style-type: none"> <li>• Remove switch L10 and dip it into a suitable container filled with water</li> <li>• Bring water to boil, and check that contacts of switch L10 open (open circuit between BLK and ORN-BLK wires) when the water reaches the temperature of 115°C</li> </ul>	<p>OK </p> <p><del>OK</del> </p>	<p>Failure of Instrument panel - - Alfa Romeo Control ECU interface circuit; refer to the applicable troubleshooting procedure</p> <p>Replace switch L10</p>

End of test E

## ENGINE COOLANT MAX. TEMPERATURE WARNING LAMP CONTINUOUSLY ILLUMINATED TEST

TEST F







TEST STEPS		RESULTS	REMEDY
F1	COOLANT TEMPERATURE CHECK		
- Check engine coolant temperature by reading the engine coolant temperature gauge on instrument panel ~115°C (239°F)		 	Failure of the engine cooling system; refer to the "ENGINE" troubleshooting procedure (Group 01)
		 	Carry-out step F2
F2	CONTROL UNIT CHECK		
- Check for presence of 0V (zero) at pin 4D of Alfa Romeo control unit N22		 	Failure of Instrument panel - - Alfa Romeo Control ECU Interface interface system; refer to the applicable troubleshooting procedure
		 	Carry-out step F3
F3	VOLTAGE CHECK		
- Check that circuit is closed between terminals of engine coolant temperature gauge and of engine coolant temperature bulb and high temperature switch L10 (ORN-BLK and BLK wires)		 	Carry-out step F4
		 	Replace switch L10

(Cont.d)



ENGINE COOLANT MAX. TEMPERATURE WARNING LAMP CONTINUOUSLY ILLUMINATED TEST

TEST F

TEST STEPS		RESULTS	REMEDY
<b>F4</b>	<b>GROUNDING CHECK</b>		
	- Check that terminal of switch <b>L10</b> is connected to ground (BLK wire)	 ►  ►	Carry-out step <b>F5</b>  Carry-out step <b>F5</b>
<b>F5</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 16 of connector <b>G151</b>	 ►  ►	Repair wiring between pin 16 of connector <b>G151</b> and pin 4D of control unit <b>N22</b>  Repair wiring between pin 16 of connector <b>G151</b> and terminal of switch <b>L10</b> (ORN-BLK wire)
<b>F6</b>	<b>GROUNDING CHECK</b>		
	- Check that pin 5 of connector <b>G151</b> is connected to ground (BLK wire)	 ►  ►	Repair wiring between pin 5 of connector <b>G151</b> and terminal of switch <b>L10</b>  Carry-out step <b>F7</b>

(Cont.d)

## ENGINE COOLANT MAX. TEMPERATURE WARNING LAMP CONTINUOUSLY ILLUMINATED TEST

TEST F


TEST STEPS		RESULTS	REMEDY
<b>F7</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Check that pin 4 of connector G150 is connected to ground (BLK wire)</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 4 of connector G150 and pin 5 of connector G151</p> <p>Repair wiring between pin 4 of connector G150 and ground point G143</p>

End of test F

**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>

SENSORS - - ENGINE OIL MINI-  
MUM LEVEL, ENGINE OIL MINI-  
MUM PRESSURE, AUTOMATIC  
TRANSMISSION MAXIMUM  
TEMPERATURE,  
TEST PUSHBUTTON



## GENERAL

The engine oil minimum level and minimum pressure and the automatic transmission oil temperature are continuously monitored by the Alfa Romeo control unit.

In the event of a failure, the control unit alerts the user by illumination on the instrument panel of the warning lamp relevant to the affected system.

The Alfa Romeo control unit monitors the warning lamps on the instrument panel, as listed below:

- Minimum level and minimum engine oil pressure.
- Automatic transmission oil temperature.
- Brake pads wear.
- Minimum level and maximum engine coolant temperature.
- Brake fluid level.
- Windshield washer fluid level.
- Parking brake engaged.
- Door open.
- Acoustic warning relevant to seat belt unfastened and/or ignition key inserted.

The integrity of all the warning lamps on the instrument panel is verified by pressing the test pushbutton.

The system is protected by the fuse **F14** (7.5A) TEST PUSHBUTTON in the fuse box **G1**.

## OPERATIONAL DESCRIPTION

The engine oil level is detected by the engine oil level sensor **L12**, consisting of a bimetallic plate and a resistor connected in series and wound around the plate.

When the engine oil level is too low, the heat of the bimetallic plate can not be dissipated, the contact opens and pin **1B** of the Alfa Romeo control unit **N22** is no longer connected to ground; as a consequence, the control unit turns on the relevant warning lamp on the instrument panel, thus alerting of the abnormal operating condition. The check of the engine oil level is performed only when the ignition key is rotated from position "parking" to position "run", and the eventual abnormal condition warning is then stored.

To clear the warning of this abnormal condition, it is necessary to top-up the engine oil level and repeat the check procedure by returning the ignition key to "parking" position, and then back to "run" position.

In case the engine oil pressure decreases to the minimum limit, the contacts of the engine oil low pressure switch **L2** open, thus opening the circuit to pin **3D** of the control unit **N22**.

For the **BASE** and **L** version the maximum temperature of the automatic transmission oil is sensed by a sensor **L39** that closes the circuit to pin **6D** of the control unit **N22**, thus connecting pin **6D** to ground when the automatic transmission oil temperature reaches **130°C (266°F)** (the contacts re-open when the oil temperature decreases to about **120°C (248°F)**).









The wiring diagram also shows the test pushbutton, used to check the integrity of all the warning lamps on the instrument panel. By pressing the pushbutton **B60**, the 12V power available when the ignition key is set to "run" position, and protected by fuse **F14** in the fuse box **G1**, is applied to pin **4E** of the control unit **N22**.

The control unit **N22** will provide for simultaneous illumination of all the warning lamps, and activation of the acoustic warnings of the vehicle.

**TROUBLESHOOTING TABLE**










FAULT TYPE	FAILED COMPONENT					
	F14 FUSE	B60 TEST BUTTON	L2 SENSOR	L12 SENSOR	L39 SENSOR (BASE AND L ONLY)	N22 CONTROL UNIT
ENGINE OIL LEVEL WARNING LAMP INOPERATIVE						•
ENGINE OIL LEVEL WARNING LAMP CONTINUOUSLY ILLUMINATED				•		•
MINIMUM ENGINE OIL PRESSURE WARNING LAMP INOPERATIVE			•			•
MINIMUM ENGINE OIL PRESSURE WARNING LAMP CONTINUOUSLY ILLUMINATED			•			•
AUTOMATIC TRANSMISSION OIL MAXIMUM TEMPERATURE WARNING LAMP INOPERATIVE					•	•
AUTOMATIC TRANSMISSION OIL MAXIMUM TEMPERATURE WARNING LAMP CONTINUOUSLY ILLUMINATED					•	•
ALL WARNING LAMPS INOPERATIVE ON INSTRUMENT PANEL WHEN TEST PUSHBUTTON IS ACTUATED	•	•				•

**NOTE:** Before attempting any troubleshooting ascertain the integrity of the affected warning lamp on the instrument panel by pressing the test button.


Instrument panel warning lights test pushbutton	<b>B60</b>	Fuse box	<b>G1</b> <b>Q</b>
			
Fuse box	<b>G1</b> <b>S</b>	Fuse box	<b>G1</b> <b>S</b>
<p><b>BASE AND L ONLY</b></p> 		<p><b>S ONLY</b></p> 	
Engine compartment left side ground connection	<b>G53b</b>	Central bulkhead ground	<b>G143</b>
<p><b>S ONLY</b></p> 			
Connector, circuit board to engine compartment left side wiring	<b>G150</b>	Connector, circuit board to engine compartment left side wiring	<b>G150</b>
<p><b>BASE AND L ONLY</b></p> 		<p><b>S ONLY</b></p> 	

(Cont.d)




Connector, circuit board to engine utilities wiring	<b>G151</b>	Engine oil low pressure switch	<b>L2</b>
			
		Engine oil level sensor	<b>L12</b>
Maximum oil temperature sensor, automatic transmission			
			
Alfa Romeo control unit	<b>N22 B</b>	Alfa Romeo control unit	<b>N22 D</b>
			
Alfa Romeo control unit	<b>N22 E</b>		
			

**BASE AND L ONLY**





**S ONLY**



## ENGINE OIL LEVEL WARNING LAMP INOPERATIVE

TEST A

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Before attempting any troubleshooting ascertain the integrity of the warning lamp on the instrument panel by pressing the test button: replace the affected lamp if it does not illuminate.</p>		
<b>A1</b> CONTROL UNIT CHECK	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 20px;"> <div style="text-align: center; margin-right: 10px;">  </div> <div style="font-size: 2em; margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="text-align: center; margin-right: 10px;">  </div> <div style="font-size: 2em; margin-right: 10px;">▶</div> </div> </div>	<p>Failure of the Instrument panel - - Alfa Romeo Control ECU Interface circuit; refer to the applicable troubleshooting procedure</p> <p>Replace sensor L12</p>
<ul style="list-style-type: none"> <li>- With the engine oil level below the minimum, check for presence of open circuit at pin 1B of Alfa Romeo Control unit N22</li> </ul>		

End of test A

**ENGINE OIL LEVEL WARNING LAMP CONTINUOUSLY ILLUMINATED**

**TEST B**

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>CONTROL UNIT CHECK</b>		
	- With the engine oil level above the minimum, check for presence of 0V (zero) at pin 1B of Alfa Romeo Control unit N22	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Failure of the Instrument panel - - Alfa Romeo Control ECU Interface circuit; refer to the applicable troubleshooting procedure</p> <p>Carry-out step B2</p>
<b>B2</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at terminal of engine oil level sensor L12 (BLK wire)	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Carry-out step B4</p> <p>Carry-out step B3</p>
<b>B3</b>	<b>GROUNDING CHECK</b>		
	- Check for presence of 0V (zero) at pin 4 of connector G150	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 4 of G150, pin 5 of G151 and pin of L12 (BLK wire)</p> <p>Repair wiring between pin 4 of G150 and ground point G143</p>



(Cont.d)

ENGINE OIL LEVEL WARNING LAMP CONTINUOUSLY ILLUMINATED	<b>TEST B</b>
--	---------------

TEST STEPS	RESULTS	REMEDY
<p><b>B4</b> CONTINUITY CHECK</p> <p>- Check for continuity between:</p> <ul style="list-style-type: none"> <li>• Terminal of engine oil level sensor L12 and pin 17 of connector G151 (GRY-RED wire)</li> <li>• Pin 17 of connector G151 and pin 1B of control unit N22</li> </ul>	<div style="display: flex; flex-direction: column; align-items: center; gap: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="font-size: 24px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 24px;">▶</div> </div> </div>	<p>Replace <b>sensor L12</b></p> <p>Repair or replace <b>wires, as necessary</b></p>







**End of test B**

MINIMUM ENGINE OIL PRESSURE WARNING LAMP INOPERATIVE	TEST C
--	--------

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Before attempting any troubleshooting ascertain the integrity of the warning lamp on the instrument panel by pressing the test button: replace the affected lamp if it does not illuminate.</p>		
<p><b>C1</b> CONTROL UNIT CHECK</p>		
<p>- With the engine oil pressure to minimum, check for presence of open circuit at pin 3D of Alfa Romeo Control unit N22</p>	<p>       ►        ►                 </p>	<p>Failure of the Instrument panel - - Alfa Romeo Control ECU Interface circuit; refer to the applicable troubleshooting procedure</p> <p>Replace switch L2</p>

End of test C

**MINIMUM ENGINE OIL PRESSURE WARNING LAMP CONTINUOUSLY ILLUMINATED**
**TEST D**









TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>OIL PRESSURE CHECK</b>		
<ul style="list-style-type: none"> <li>- Start the engine, wait a few seconds and check that the engine oil pressure gauge does not indicate insufficient pressure</li> </ul>		 ►  ►	Carry-out <b>step D2</b> and top-up oil, if necessary  Check engine oil level and for presence of leaks from the engine; refer to <b>SERVICE MANUAL-ENGINE-TROUBLESHOOTING PROCEDURE (Group 01)</b>
<b>D2</b>	<b>CONTROL UNIT CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 0V (zero) at pin 3D of Alfa Romeo Control unit N22</li> </ul>		 ►  ►	Failure of the Instrument panel - - Alfa Romeo Control ECU interface circuit; refer to the applicable troubleshooting procedure  Carry-out <b>step D3</b>
<b>D3</b>	<b>SENSOR CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of closed circuit condition between terminals of engine oil low pressure switch L2 contacts</li> </ul>		 ►  ►	Carry-out <b>step D4</b>  Replace <b>switch L2</b>

(Cont.d)







MINIMUM ENGINE OIL PRESSURE WARNING LAMP CONTINUOUSLY ILLUMINATED

TEST D

TEST STEPS		RESULTS	REMEDY
<b>D4</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 19 of connector G151		 	Repair wiring between pin 19 of connector G151 and pin 3D of control unit N22
		 	Carry-out step D5
<b>D5</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at terminal of switch L2 (GRY-GRN wire)		 	Repair wiring between pin 19 of connector G151 and terminal of switch L2 (GRY-GRN wire)
		 	Repair wiring between terminal of switch L2 and ground point

End of test D





**AUTOMATIC TRANSMISSION OIL MAXIMUM TEMPERATURE WARNING LAMP INOPERATIVE (BASE and L only)**
**TEST E**

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Before attempting any troubleshooting ascertain the integrity of the warning lamp on the instrument panel by pressing the test button: replace the affected lamp if it does not illuminate.</p>			
<b>E1</b>	<b>SENSOR CHECK</b>		
<ul style="list-style-type: none"> <li>- Check integrity of maximum oil temperature sensor automatic transmission L39 verifying the presence of short circuit between sensor terminals when temperature is above 118°C (≅ 244°F)</li> </ul>		 	Carry-out step E2  Replace sensor L39
<b>E2</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for continuity between:               <ul style="list-style-type: none"> <li>• Sensor L39 (LT BLU-YEL wire) and pin 3 of connector G150</li> <li>• Pin 3 of connector G150 and pin 6D of Alfa Romeo Control unit N22</li> <li>• Sensor L39 and ground point</li> </ul> </li> </ul>		 	Failure of the Instrument panel - - Alfa Romeo Control ECU interface circuit; refer to the applicable troubleshooting procedure  Repair or replace wires, as necessary

End of test E









**AUTOMATIC TRANSMISSION OIL MAXIMUM TEMPERATURE WARNING LAMP CONTINUOUSLY ILLUMINATED (BASE and L only)**

**TEST F**

TEST STEPS		RESULTS	REMEDY
F1	SENSOR CHECK		
- Park the vehicle, wait until the automatic transmission oil has cooled off, then check for presence of open circuit condition at pin 6D of Alfa Romeo Control unit N22		 	Failure of the Instrument panel - - Alfa Romeo Control ECU interface circuit; refer to the applicable troubleshooting procedure
		 	Replace max. oil temperature sensor automatic transmission L39

End of test F

**ALL WARNING LAMPS INOPERATIVE ON INSTRUMENT PANEL WHEN TEST PUSHBUTTON IS ACTUATED**
**TEST G**

TEST STEPS		RESULTS	REMEDY
<b>G1</b>	<b>FUSE CHECK</b>		
- Check fuse F14 in fuse box G1 for integrity		 ►  ►	Carry-out step G2  Replace fuse F14.
<b>G2</b>	<b>WARNING LAMPS ILLUMINATION CHECK</b>		
- Check that failure affects all the warning lamps simultaneously		 ►  ►	Carry-out step G3  Replace the affected warning lamp
<b>G3</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run", check for presence of 12V between terminal of instrument panel warning lights test pushbutton B60 (PNK wire) and ground		 ►  ►	Carry-out step G5  Carry-out step G4
<b>G4</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run", check for presence of 12V between pin 40 of fuse box G1 and ground		 ►  ►	Repair wiring between pin 4S of fuse box G1 and test pushbutton B60 (PNK wire)  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2


(Cont.d)

ALL WARNING LAMPS INOPERATIVE ON INSTRUMENT PANEL WHEN TEST PUSHBUTTON IS ACTUATED	<b>TEST G</b>
--	---------------

	TEST STEPS	RESULTS	REMEDY
<b>G5</b>	<b>TEST PUSHBUTTON CHECK</b>		
	<ul style="list-style-type: none"> <li>- With the ignition key set to "run" and press test push button <b>B60</b>, check for presence of 12V between push button terminal (WHT-RED wire) and ground</li> </ul>	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px;">OK</span> <span style="font-size: 2em;">▶</span> </div> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px; text-decoration: line-through;">OK</span> <span style="font-size: 2em;">▶</span> </div> </div>	<p>Carry-out <b>step G6</b></p> <p>Replace pushbutton <b>B60</b></p>
<b>G6</b>	<b>CONTROL UNIT CHECK</b>		
	<ul style="list-style-type: none"> <li>- With the ignition key set to "run" and press test pushbutton <b>B60</b>, check for presence of 12V between pin 4E of Alfa Romeo Control unit <b>N22</b> and ground</li> </ul>	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px;">OK</span> <span style="font-size: 2em;">▶</span> </div> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px; text-decoration: line-through;">OK</span> <span style="font-size: 2em;">▶</span> </div> </div>	<p>Failure of the Instrument panel - - Alfa Romeo Control ECU interface circuit; refer to the applicable troubleshooting procedure</p> <p>Repair wiring between pin 4E of control unit <b>N22</b> and test pushbutton <b>B60</b> (WHT-RED wire)</p>

End of test G

# STARTING AND CHARGING



## GENERAL

The starting and charging circuit is mainly composed of the battery (12V), of the starting motor and of the alternator.

When the ignition key is rotated, 12 Volts, upon control of the anti-theft control unit, are connected to the control solenoid coil.

The control solenoid coil attracts and closes the starting contact. In this way, a circuit is completed for the 12V power to the starter, with consequent operation of the motor.

During run, the alternator recharges the battery to which it is paralleled.

The instrument panel is provided with an indicator lamp that informs the driver of the battery charge status.

In case the vehicle is equipped with automatic transmission, the starting operation is enabled by the inhibitor relay which allows starting only when the transmission selector is set to positions N or P.

## OPERATIONAL DESCRIPTION

The starter motor inhibitor relay I10 connects, when energized, the battery power (12V) to the starter motor solenoid.

The relay energization is monitored by the anti-theft control unit; in this way, starting cannot be accomplished if the antitheft system is activated.

Furthermore, as a safety precaution, on vehicles equipped with automatic transmission, the relay energization and the engine starting is inhibited by the inhibitor switch H16, which closes only if the transmission selector is set to P or N.













12V power connected to the starter A11 (pin 50) enables the solenoid to energize, thus closing the contact allowing the motor to rotate. During drive the alternator A2, through the circuit board G56, recharges the battery A1. In the case the alternator is not rotating, or it is unable to recharge the battery, the relevant warning lamp illuminates on the instrument panel C10.

TROUBLESHOOTING TABLE






FAULT TYPE	FAILED COMPONENT						
	H16 SWITCH	C10 ALTERNATOR WARN. LAMP	I10 RELAY	A1 BATTERY	A2 ALTERNATOR	A11 STARTER	N45 CONTROL UNIT
ENGINE FAILS TO START	●		●	●	●	●	●
ALTERNATOR WARNING LAMP INOPERATIVE ON INSTRUMENT PANEL		●			●		


- NOTES:** - A missed start might be caused by the ignition switch B1; for better understanding refer to power distribution schematic diagram.
- Before attempting any troubleshooting ascertain the integrity of the affected warning lamps on the instrument panel by pressing the test button.









<p>Battery</p>	<p>A1</p>	<p>Alternator</p>	<p>A2</p>
			
<p>Starter</p>	<p>A11</p>	<p>Ignition switch</p>	<p>B1</p>
			
<p>Instrument panel</p>	<p>C10 C</p>	<p>Circuit board</p>	<p>G56</p>
			
<p>ABS system connector</p>	<p>G124</p>	<p>Connector, circuit board to engine utilities</p>	<p>G151</p>
			
<p>Steering wheel column support ground</p>	<p>G174</p>	<p>Connector, circuit board to automatic gear lever wiring</p>	<p>G233</p>
			

(Cont.d)

<p>Board wiring to antitheft system wiring connector</p>	<p><b>G241</b></p>	<p>Start and reverse gear inhibitor switch</p>	<p><b>H16</b></p>
			
<p>Starter motor inhibitor relay</p>	<p><b>I10</b></p>	<p>Electronic control units control relay</p>	<p><b>I51</b></p>
			
		<p>Anti-theft control unit</p>	<p><b>N45</b></p>
			











ENGINE FAILS TO START		TEST A	
TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>BATTERY CHECK</b>		
- Visually check battery and connecting leads for conditions; check for presence of 12V on the battery leads		 ►  ►	Carry-out step A2  Repair wiring, re-charge and/or replace battery A1
<p><b>NOTE:</b> A battery malfunction might be dependent on an excessive charging from the alternator. In this case it is necessary to replace the voltage regulator on alternator A2.</p>			
<b>A2</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between circuit board G56 and ground		 ►  ►	Carry-out step A3  Repair wiring between battery "+" lead and circuit board G56
<b>A3</b>	<b>ALTERNATOR BELT CHECK</b>		
- Check that belt does not show abrasion, wear, fraying; check for correct tension		 ►  ►	Carry-out step A4  Replace alternator A2

(Cont.d)

## ENGINE FAILS TO START







## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A4</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 30 of starter A11 and ground		 ►  ►	Carry-out step A5  Repair wiring between circuit board G56 and pin 30 of starter A11
<b>A5</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 50 of starter A11 and ground		 ►  ►	Replace starter A11  Carry-out step A6
<b>A6</b>	<b>VOLTAGE CHECK</b>		
- With anti-theft system deactivated and ignition key set to run, check for presence of 12V between pin 2 of anti-theft control unit N45 and ground		 ►  ►	Carry-out step A7  Failure of the circuit, Alarm - - electronic anti-theft system refer to the relevant troubleshooting procedure
<b>A7</b>	<b>VOLTAGE CHECK</b>		
- With ignition key set to "start", check for presence of 12V between pin 86 of starter motor inhibitor relay I10 and ground		 ►  ►	Carry-out step A8  Carry-out step A11

(Cont.d)

## ENGINE FAILS TO START







## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A8</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 85 of starter motor inhibition relay I10		 ►  ►	Carry-out step A9  Carry-out step A12 (automatic transmission) or step A14 (manual transmission)
<b>A9</b>	<b>RELAY CHECK</b>		
- Check starter motor inhibition relay I10 for proper operation		 ►  ►	Carry-out step A10  Replace relay I10
<b>A10</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 30 of relay I10 and ground		 ►  ►	Repair wiring between pin 87a of relay I10, pin 1 of connector G151 and pin 50 of starter A11  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2

(Cont.d)

## ENGINE FAILS TO START

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A11</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 2 of connector G241 and ground		 ►	Repair wiring between pin 2 of connector G241 and pin 86 of relay I10
		 ►	Repair wiring between pin 2 of connector G241 and pin 2 of anti-theft control unit N45
<b>A12</b>	<b>CONTINUITY CHECK (AUTOMATIC TRANSMISSION ONLY)</b>		
- With transmission set to P or N, check for shorted connection between pins 3 and 4 of connector G233		 ►	Repair wiring between G233 (pin 4) and relay I10 (pin 85), and between G233 (pin 3) and ground point G174)
		 ►	Carry-out step A13
<b>A13</b>	<b>SWITCH CHECK (AUTOMATIC TRANSMISSION ONLY)</b>		
- With gear set to P or N, check for shorted connection between terminals of start and reserve gear inhibitor switch H16 (GRY-BLK and BLK wires)		 ►	Repair wiring between switch H16 (GRY-BLK and BLK wires) and G233 (pins 3 and 4)
		 ►	Replace switch H16

(Cont.d)

ENGINE FAILS TO START	TEST A
-----------------------	--------

TEST STEPS		RESULTS	REMEDY
<b>A14</b>	<b>GROUNDING CHECK (MANUAL TRANSMISSION ONLY)</b>		
<ul style="list-style-type: none"> <li>- Check for presence of OV (zero) at pin 3 of connector <b>G233</b></li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 3 of connector <b>G233</b> and pin 85 of relay <b>I10</b></p> <p>Repair wiring between pin 3 of connector <b>G233</b> and ground point <b>G174</b></p>

End of test A




## ALTERNATOR WARNING LAMP INOPERATIVE ON INSTRUMENT PANEL

## TEST B

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Before attempting any troubleshooting, ascertain the integrity of the warning lamp on instrument panel by pressing test button; replace the affected lamp if it does not illuminate.</p>			
<b>B1</b>	<b>ALTERNATOR CONTROL</b>		
<ul style="list-style-type: none"> <li>With engine running, check for presence of 12V between pin D of alternator <b>A2</b> and ground</li> </ul>		OK ► <del>OK</del> ►	Carry-out step <b>B2</b>  Overhaul or replace alternator <b>A2</b>
<b>B2</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>Check for presence of 12V between pin 7C of instrument panel <b>C10</b> and ground</li> </ul>		OK ► <del>OK</del> ►	Replace Instrument panel <b>C10</b>  Carry-out step <b>B3</b>
<b>B3</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>Check for presence of 12V between pin 13 of connector <b>G151</b> and ground</li> </ul>		OK ► <del>OK</del> ►	Repair wiring between pin 13 of <b>G151</b> , pin 2 of connector <b>G124</b> and pin 7C of Instrument panel <b>C10</b>  Repair wiring between pin 13 of <b>G151</b> and pin D+ of alternator <b>A2</b>

End of test B

# SUN ROOF



## GENERAL

The sun roof can be electrically operated in two different modes.

- Fully or partially open by sliding backwards.
- The rear edge can be raised (with the sun roof completely closed).

The sun roof is operated by means of two pushbuttons located on the central dome.

One switch controls opening of the sun roof, the other controls the closure, as well as raising of the rear edge of the sun roof.

The system is protected by the fuse F23 (20A) SUN ROOF in the fuse box G1.

## OPERATIONAL DESCRIPTION











Relay I58 is energized when the ignition key is set to "run".


12V from the battery is applied to the fuse F23 through the relay contacts, and reach the contacts of the sun roof motor P24 control relays.

Pressure on the "opening" pushbutton located on the central dome F35 causes energization of one of the two relays, and consequent actuation of the sun roof motor P24 in the opening direction.

Pressure on the "closure" pushbutton causes energization of the second relay and consequent reverse of the electrical polarity to the motor terminals: the motor will rotate in the "closure" direction.

















When the sun roof is fully closed, pressure on the "closure" switch will raise the sun roof rear edge.

<p>Dome lamp with cabin lighting control switch</p> <p><b>F35</b></p> 	<p>Fuse box</p> <p><b>G1 E</b></p> 
<p>Fuse box</p> <p><b>G1 M</b></p> 	<p>Fuse box</p> <p><b>G1 O</b></p> 
<p>Fuse box</p> <p><b>G1 T</b></p> 	<p>Connector, front doors to left rear wiring</p> <p><b>G169</b></p> 
<p>Steering wheel column support ground</p> <p><b>G174</b></p> 	<p>Dome ground</p> <p><b>G176</b></p> 
<p>Connector, left rear wiring to dome lamp wiring</p> <p><b>G179</b></p> 	<p>Connector, doors wiring to rear console wiring</p> <p><b>G210</b></p> 



## SUN ROOF INOPERATIVE







## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
	- Check fuse F23 in fuse box G1 for integrity	 	Carry-out step A2
		 	Replace fuse F23
<b>A2</b>	<b>MOVEMENT CHECK</b>		
	- Check if the sun roof can be actuated in any mode	 	Carry-out step A3
		 	Carry-out step A4
<b>A3</b>	<b>MECHANICAL SEIZURE CHECK</b>		
	- Check for of foreign objects in the sun roof channels or on the roof tracks	 	Replace sun roof motor P24
		 	Remove any obstruction
<b>A4</b>	<b>VOLTAGE CHECK</b>		
	- With the ignition key set to "run" check for presence of 12V between pin 1M of fuse box G1 and ground	 	Carry-out step A5
		 	Carry-out step A8

(Cont.d)

## SUN ROOF INOPERATIVE

## TEST A







TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for continuity between:               <ul style="list-style-type: none"> <li>• pin 1M of fuse box <b>G1</b> and pin 3 of connector <b>G210</b></li> <li>• pin 3 of connector <b>G210</b> and pin 2 of connector <b>G169</b></li> <li>• pin 2 of connector <b>G169</b> and pin 1 of connector <b>G179</b></li> <li>• pin 1 of connector <b>G179</b> and pin 4 of dome connector and sun roof motor</li> </ul> </li> </ul>		 ►  ►	<p>Carry-out <b>step A6</b></p> <p>Repair or replace cables, as required</p>
<b>A6</b>	<b>PUSHBUTTONS CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for continuity between terminals of pushbuttons, when actuated</li> </ul>		 ►  ►	<p>Carry-out <b>step A7</b></p> <p>Replace the affected <b>pushbutton (s)</b></p>
<b>A7</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 0V (zero) at pins 2 of dome connector and sun roof motor</li> </ul>		 ►  ►	<p>Replace motor <b>P24</b></p> <p>Repair wiring between <b>pin 2 of dome connector</b> and ground point <b>G176</b></p>

(Cont.d)




## SUN ROOF INOPERATIVE

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A8</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 12E of fuse box G1		 ▶  ▶	Carry-out <b>step A9</b>  Repair wiring between <b>pin 12E of fuse box G1</b> and ground point <b>G174</b>
<b>A9</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run", check for presence of 12V between pin 4O of fuse box G1 and ground		 ▶  ▶	Carry-out <b>step A10</b>  Failure of the <b>power distribution circuit</b> , refer to the relevant circuit of sheet 2 of 2
<b>A10</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin T of fuse box G1 and ground		 ▶  ▶	Replace relay <b>I58</b>  Failure of the <b>power distribution circuit</b> , refer to the relevant circuit of sheet 2 of 2

End of test A

SWITCH - - NEUTRAL  
SAFETY (AUTOMATIC  
TRANSMISSION ONLY)



## GENERAL

On cars equipped with automatic transmission, the engine can be started only when the selector lever is set to park (P) or to neutral (N) positions.

After the engine has been started, and the selection lever being operated in order to move the car, the Motronic control unit will monitor the engine operating condition to obtain a smooth engagement of the car into motion.

The system is protected by fuse F22 (15A) ENGINE RELAY POWER SUPPLY in the fuse box G1.

## OPERATIONAL DESCRIPTION











12V from the battery are available when the ignition


key is set to "run" or to "start".

12V are applied to the coil of the selected gear signal (automatic transmission) relay I62 (for Motronic control unit) through fuse F22 in fuse box G1.

The ground section of the relay is connected to ground through the start inhibitor switch H16; the switch contacts are closed when the selector lever is positioned to P or N, and open when the selector lever is positioned to D, 1, 2, 3, or R.









When the selector lever is set to D, 1, 2, 3 or R the relay I62 (for the Motronic control unit) is de-energized, and supplies 12V to the Motronic control unit S11 (pin 28); therefore the Motronic control unit will monitor the engine operating condition to obtain a smooth engagement of the car into motion.

<p>Fuse box <span style="float: right;">G1 I</span></p>	<p>Connector, engine wiring to circuit board <span style="float: right;">G154</span></p>
	
<p>Steering wheel column support ground <span style="float: right;">G174</span></p>	
	<p>Connector, circuit board to automatic gear lever wiring <span style="float: right;">G233</span></p>
	<p>Start and reverse gear inhibition switch <span style="float: right;">H16</span></p> 
<p>Starter motor inhibitor relay <span style="float: right;">110</span></p>	<p>Electronic control units power supply relay <span style="float: right;">151</span></p>
	
<p>Selected gear signal (automatic transmission) relay for Motronic control unit <span style="float: right;">162</span></p>	<p>Motronic control unit <span style="float: right;">S11</span></p>
	



## CAR DOES NOT RUN SMOOTHLY

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>F22</b> in fuse box <b>G1</b> for integrity		 	Carry-out step <b>A2</b>  Replace fuse <b>F22</b>
<b>A2</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "start" or to "run" check for presence of 12V between pin 86 of relay <b>I62</b> and ground		 	Carry-out step <b>A4</b>  Carry-out step <b>A3</b>
<b>A3</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" or to "start" check for presence of 12V between pin 21 of fuse box and ground		 	Repair wiring between pin 86, pin 30 of relay <b>I62</b> and pin 11 of fuse box <b>G1</b>  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>A4</b>	<b>CONTROL UNIT CHECK</b>		
- With the ignition key set to "start" or to "run" and with car in R, D, 1, 2, 3 check for presence of 12V between pin 28 of Motronic control unit <b>S11</b> and ground		 	Failure of Motronic circuit; refer to the relevant troubleshooting procedure  Carry-out step <b>A5</b>

(Cont.d)

CAR DOES NOT RUN SMOOTHLY

TEST A

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>With the ignition key set to "start" or to "run" and gear selector in R, D, 1, 2, 3 check for presence of 12V between pin 4 of connector <b>G154</b> and ground</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 4 of connector <b>G154</b> and pin 28 of control unit <b>S11</b></p> <p>Carry-out step <b>A6</b></p>
<b>A6</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>With the ignition key set to "start" or to "run" check for presence of 12V at pin 87a of selected gear signal (automatic transmission) relay <b>I62</b> (for Motronic control unit)</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 87a of relay <b>I62</b> and pin 4 of connector <b>G154</b></p> <p>Carry-out step <b>A7</b></p>
<b>A7</b>	<b>OPEN CIRCUIT CHECK</b>		
<ul style="list-style-type: none"> <li>Check that an open circuit exists in R, D, 1, 2, 3 between pins 3 and 4 of connector <b>G233</b></li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Replace relay <b>I62</b></p> <p>Replace inhibitor switch <b>H16</b></p>

End of test A



**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>

# TELEPHONE



## GENERAL

The vehicle is equipped with a radio telephone located inside the front seats armrest.

A cap on the armrest top side allows comfortable access to the radio telephone.

Use of radiotelephone is possible only when the ignition key is set to "run".

To use the radio telephone when the vehicle is stopped, first turn the ignition key to "run" position, then back to "parking" position and leave it inserted in the ignition switch.

The system is protected by the free fuse G239 (15A) RADIO, RADIO-TELEPHONE, fuse F2 (7,5A) KEY-CONTROLLED CURRENTS FOR ELECTRONIC UNITS and F5 (10A) POWER ANTENNA in fuse box G2.

## OPERATIONAL DESCRIPTION







12V from the battery are applied to the radio relay I70, which becomes energized when the ignition switch (microswitch) B1 is closed by setting the ignition key to "run" position, or to "parking" position after setting of "run" position.


When relay I51 is energized, the battery power is applied to the radio telephone control unit N48 through the free fuse G239; the control unit N48 is also connected to ground point G186.

The control unit N48 monitors the operation of the radio telephone interfacing with a circuit realized with 15 conductors.

<p>Ignition switch</p>	<p><b>B1</b></p>	<p>Fuse box</p>	<p><b>G1 I</b></p>
<p>Fuse box</p>	<p><b>G1 T</b></p>	<p>Auxiliary fuse box</p>	<p><b>G2</b></p>
<p>Two pin connector circuit board to doors wiring</p>	<p><b>G15</b></p>		
<p>Six pin connector circuit board to doors wiring</p>	<p><b>G16</b></p>	<p>Connector, circuit board to engine compartment left side wiring</p>	<p><b>G150</b></p>
		<p>Connector, front doors to left rear wiring</p>	<p><b>G169</b></p>
<p>Connector, circuit board to right rear wiring</p>	<p><b>G170</b></p>	<p>Steering wheel column support ground</p>	<p><b>G174</b></p>

(Cont.d)

<p>Trunk right side ground</p>	<p><b>G186</b></p>	<p>Connector, provision for radio antenna</p>	<p><b>G193</b></p>
 <p>1.5BLK* N48</p>		 <p>YEL-RED* G189 1RED-BLK* G189 F37 PIN 4 TO POWER ANTENNA G3</p>	
<p>Radio, radio-telephone fuse</p>	<p><b>G239</b></p>	<p>Electronic control units power supply relay</p>	<p><b>I51</b></p>
 <p>G16 PIN 5 1.5RED* G170 1WHT* I70</p>		 <p>1BLK* G174 1.5RED* G150 1.5PNK* G2 1.5RED-BLK* G2 1BRN* G1</p>	
<p>Radio relay</p>	<p><b>I70</b></p>	<p>Radio telephone control unit</p>	<p><b>N48</b></p>
 <p>N22 PIN 12 A GRY* B1 1.5PNK* G2 1.5RED-BLK* G2 1WHT* G239 GRY-RED* G15</p>		 <p>1.5RED* G170 1.5BLK* G186</p>	




**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>



# TRUNK - - ELECTRIC OPENING



## GENERAL

Trunk opening is electrically actuated by pressing a switch on the air conditioner panel.

For safety reasons, trunk opening can be actuated only when the vehicle has come to a complete stop.

The system is protected by the **F3** (30A) fuse TRUNK OPENING in the auxiliary fuse box **G2**.

## OPERATIONAL DESCRIPTION

The trunk opening relay **I52** is energized only when the start key is set to "parking", and the fuel filler lid










opening is not activated and when the vehicle has come to a complete stop.

The relay coil is connected to ground by the automatic control mode check unit **Q21A** (detects "vehicle stationary" condition) through the switch **B55**, when actuated.




Contacts of switch **B55** are open when the trunk has been locked with the relevant key.


In this event the trunk opening can not be electrically actuated.

12V from the battery reach the trunk opening solenoid **M12** through the fuse **F3** and contacts of relay **I52**, thus providing automatic opening of the trunk lid.









<p>Trunk opening switch</p>	<p>Fuse box</p>
<p style="text-align: right;"><b>B55</b></p> 	<p style="text-align: right;"><b>G1 T</b></p> 
<p>Connector, circuit board to air conditioning wiring</p>	<p>Auxiliary fuse box</p>
<p style="text-align: right;"><b>G164</b></p> 	<p style="text-align: right;"><b>G2</b></p> 
<p>Connector, circuit board to right rear wiring</p>	<p>Trunk right side ground</p>
<p style="text-align: right;"><b>G170</b></p> 	<p style="text-align: right;"><b>G186</b></p> 
<p>Connector, right rear wiring to trunk lock wiring</p>	<p>Trunk opening relay</p>
<p style="text-align: right;"><b>G198</b></p>  	<p style="text-align: right;"><b>152</b></p> 

(Cont.d)

Filler lid opening relay	I53	Automatic control mode check unit	Q21a
			
Trunk opening solenoid	M12		
			











<b>TRUNK ELECTRIC OPENING SYSTEM INOPERATIVE</b>	<b>TEST A</b>
--	---------------

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
	- Check fuse F3 in auxiliary fuse box G2 for integrity	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p>Carry-out step A2</p> <p>Replace fuse F3</p>
<b>A2</b>	<b>FUEL FILLER LID OPENING CHECK</b>		
	- Check that fuel filler lid can be opened electrically	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p>Carry-out step A4</p> <p>Carry-out step A3</p>
<b>A3</b>	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin of auxiliary fuse box G2 (RED wire) and ground	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p>Repair wiring between fuse F3 of auxiliary fuse box G2, pin 1 of G170 and pin 30 of relay I52</p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2</p>
<b>A4</b>	<b>CONTROL UNIT CHECK</b>		
	- Verify that pin 17 of control unit Q21A is connected to ground when the trunk opening control switch is actuated	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	<p>Carry-out step A5</p> <p>Replace control unit Q21A</p>

(Cont.d)

## TRUNK ELECTRIC OPENING SYSTEM INOPERATIVE

## TEST A













TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 0V (zero) at:               <ul style="list-style-type: none"> <li>• pin 4 of connector G164</li> <li>• pin 2 of connector G170</li> <li>• pin 4 of connector G198</li> </ul> </li> </ul>		 ►  ►	Carry-out <b>step A6</b>  Repair wiring between <b>pin 17 of control unit Q21A and pin 4 of connector G198</b>
<b>A6</b>	<b>CONTROL SWITCH CHECK</b>		
<ul style="list-style-type: none"> <li>- Check that the circuit is closed between pins of switch B55 when actuated</li> </ul>		 ►  ►	Carry-out <b>step A7</b>  Replace <b>switch B55</b>
<b>A7</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 0V (zero) at pin 85 of relay I52</li> </ul>		 ►  ►	Carry-out <b>step A8</b>  Repair wiring between <b>pin of switch B55 (YEL-GRN wire), pin 3 of connector G198 and pin 85 of relay I52</b>
<b>A8</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- With the ignition key set to "park", check for presence of 12 between pin 86 of relay I52 and ground</li> </ul>		 ►  ►	Carry-out <b>step A9</b>  Failure of the fuel door - - electric circuit, refer to the relevant troubleshooting procedure

(Cont.d)



## TRUNK ELECTRIC OPENING SYSTEM INOPERATIVE

## TEST A


TEST STEPS		RESULTS	REMEDY
<b>A9</b>	<b>RELAY CHECK</b>		
- Check relay I52 for integrity and proper operation		 	Carry-out step A10
		 	Replace relay I52
<b>A10</b>	<b>SOLENOID CHECK</b>		
- With the ignition key set to "park" and switch B55 actuated, check for presence of 12V between terminals of solenoid M12		 	Replace solenoid M12
		 	Carry-out step A11
<b>A11</b>	<b>CONTINUITY CHECK</b>		
- Check for continuity between:		 	Repair wiring between pin 2 of solenoid M12, pin 2 of connector G198 and ground point G186
<ul style="list-style-type: none"> <li>• pin 1 of solenoid M12 and pin 1 of connector G198</li> <li>• pin 1 of connector G198 and pin 87 of relay I52</li> </ul>		 	Repair wiring between pin 1 of solenoid M12, pin 1 of connector G198 and pin 87 of relay I52

End of test A

**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>

# WINDOWS - - ELECTRIC OPENING



## GENERAL

The front and rear door windows are electrically operated by means of four control switches located on the control console, and by two control switches located on the rear door panels.

A switch on the control console disables the operation of the rear windows.

The left front window can also be fully lowered by a pulse on the relevant control switch.

The electric window lift system is protected by fuses as follows:

- **F11** fuse (7.5A) REAR WINDOW LIFTS, located in the fuse box **G1**.
- **F18** fuse (30A) R.H. FRONT WINDOW LIFT, located in the fuse box **G1**.
- **F19** fuse (30A) L.H. FRONT WINDOW LIFT, located in the fuse box **G1**.
- **G247** free fuse (30A) R.H. REAR WINDOW LIFT.
- **G247** free fuse (30A) L.H. REAR WINDOW LIFT.

## OPERATIONAL DESCRIPTION - FRONT WINDOWS

The relay **I73** is energized when the ignition key is set to "run".

12V from the battery is applied to fuses **F18** and **F19** of the left and right front windows through the relay contacts. The electric power is then supplied to control switches **B21** and **B53** through the fuse **F18**.

Pressing the switch **B21** in one direction, the corresponding motor **P14** is energized, with positive pole of the battery power at one of its two terminals; the motor will therefore rotate in one direction (e.g. lowering the window). Pressing the switch **B21** in the opposite direction, the positive pole of the battery power will be connected to the second motor terminal, and the motor **P14** sense of rotation will be reversed (e.g. lifting the window).

The operation of the left and right windows is similar, with the exception that the operation of motor **P15** of the left window is controlled by the electric window lift control unit **N38**, which is powered through the fuse **F19** in the fuse box **G1**.

The control unit selects the window mode of operation on the base of input received from the switch **B53** (e.g. lifting, lowering or pulse lowering).

TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT							
	<u>F18</u> FUSE	<u>F19</u> FUSE	<u>B21</u> SWITCH CONSOLE	<u>B53</u> SWITCH CONSOLE	<u>I73</u> RELAY	<u>P14</u> MOTOR	<u>P15</u> MOTOR	<u>N38</u> CONTROL UNIT
BOTH FRONT WINDOW LIFTS INOPERATIVE	●				●			
LEFT FRONT WINDOW LIFT INOPERATIVE		●		●			●	●
RIGHT FRONT WINDOW LIFT INOPERATIVE			●			●		



## OPERATIONAL DESCRIPTION - REAR WINDOW

With the ignition key set to "run" 12V from the battery is applied to fuse F11 in the fuse box G1, and then to the I13 relay coil.

Closure of the relay contacts allows energization of the sensing switch B25, which enables the operation of switches B23 and B24 of the rear windows.

When the sensing switch contacts are closed, the electric

power energizes the switches B23 and B24 (on console) through the two free fuses G247.

Pressing either switch B23 or B24 in one direction, the corresponding motor is energized and will rotate in the selected direction (e.g. lifting of the window).

Pressing the switch in the opposite direction will reverse the polarity of the electric power, and the motor will rotate in opposite direction (e.g. lowering of the window).

The same functions can also be activated by means of the control switches located on the rear doors.












### TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT									
	F11	G247	B23	B23	B24	B24	B25	I13	P16	P17
	FUSE	FUSE	DOOR SWITCH	CONSOLE SWITCH	DOOR SWITCH	CONSOLE SWITCH	SENSING SWITCH	RELAY	MOTOR	MOTOR
BOTH REAR WINDOW LIFTS INOPERATIVE	•						•	•		
LEFT REAR WINDOW LIFT INOPERATIVE		•			•	•				•
RIGHT REAR WINDOW LIFT INOPERATIVE		•	•	•					•	








<p>Door lock internal switch</p>	<p>B20</p>	<p>Right front window lift switch</p>	<p>B21</p>
<p>Right rear window lift switch (on door)</p>	<p>B23</p>	<p>Right rear window lift switch (on console)</p>	<p>B23</p>
<p>Left rear window lift switch (on door)</p>	<p>B24</p>	<p>Left rear window lift switch (on console)</p>	<p>B24</p>

(Cont.d)











<p>Rear window lifts sensing switch</p>	<p><b>B25</b></p>	<p>Front left window automatic lift switch</p>	<p><b>B53</b></p>
<p>2.5 RED-BLK* <b>G247</b> 3                  2.5 RED-BLK* <b>G243</b> 2                  BLK* <b>G182</b> 1</p> 		<p>PNK* <b>B21</b> 5                  BLK* <b>B20</b> 4                  2 ORN* <b>G100</b>                  1 ORN-BLK* <b>G100</b></p> 	
<p>Multiple switch unit</p>	<p><b>B68</b> ↓</p>		
<p>1 BLK* <b>N41</b>                  1 BLK* <b>G174</b></p> 			
<p>Fuse box</p>	<p><b>G1</b> <b>A</b></p>	<p>Fuse box</p>	<p><b>G1</b> <b>E</b></p>
<p>N41 PIN 4 6                  1 PNK* <b>I24</b> 6</p> 		<p>1 BLK* <b>G174</b> 12                  1.5 PNK-BLK* <b>G100</b> 4</p> 	
<p>Fuse box</p>	<p><b>G1</b> <b>N</b></p>	<p>Fuse box</p>	<p><b>G1</b> <b>N</b></p>
<p>4 RED* <b>HOT AT ALL TIMES</b> 2                  ISO PIN 30 2</p> 		<p>2.5 PNK* <b>HOT IN RUN</b> 4</p> 	
<p>Fuse box</p>	<p><b>G1</b> <b>O</b></p>	<p>Fuse box</p>	<p><b>G1</b> <b>P</b></p>
<p>4 RED* <b>HOT AT ALL TIMES</b>                  2.5 RED* <b>G2</b></p> 	<p><b>G1</b> <b>T</b></p>	<p>1.5 PNK-BLK* <b>N38</b> 4</p> 	
<p>4 RED* <b>HOT AT ALL TIMES</b>                  2.5 RED* <b>G2</b></p> 		<p>1.5 PNK-BLK* <b>N38</b> 4</p> 	

(Cont.d)


<p>Auxiliary fuse box</p>	<p><b>G2</b></p>	<p>Connector, doors to center console wiring</p>	<p><b>G100</b></p>	
				
<p>Connector, front doors to right front door wiring</p>	<p><b>G166</b></p>	<p>Connector, front doors to left front door wiring</p>		<p><b>G168</b></p>
				
<p>Steering wheel column support ground</p>	<p><b>G174</b></p>	<p>Connector, left rear wiring to rear center console</p>		<p><b>G181</b></p>
		<p>Center console ground</p> <p><b>G182</b></p> 		
<p>Connector, left rear wiring to rear center console</p> <p><b>G181</b></p> 				

(Cont.d)

<p>Connector, left rear wiring to left rear door wiring</p>	<p><b>G191</b></p>	<p>Connector, right rear wiring to right rear door wiring</p>	<p><b>G197</b></p>
			
<p>Connector, right rear wiring to rear console wiring</p>	<p><b>G209</b></p>	<p>Board-wiring aft console wiring splice</p>	<p><b>G243</b></p>
			
<p>Rear power window lifts fuse 30A</p>	<p><b>G247</b></p>	<p>Rear window lifts relay</p>	<p><b>I13</b></p>
			
<p>Turn signal lamps and hazard lamps relay</p>	<p><b>I24</b></p>	<p>Door lock control unit</p>	<p><b>N11</b></p>
			

(Cont.d)

<p>Window lift control unit</p>	<p>N38</p>	<p>Parking lamps control unit</p>	<p>N41</p>
<p>Right front electric window lift motor</p>	<p>P14</p>	<p>Left front electric window lift motor</p>	<p>P15</p>
<p>Right rear electric window lift motor</p>	<p>P16</p>	<p>Left rear electric window lift motor</p>	<p>P17</p>



<b>BOTH FRONT WINDOW LIFTS INOPERATIVE</b>	<b>TEST A</b>
--	---------------

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>  - Check fuse F18 in fuse box G1 for integrity	OK <del>OK</del>	Carry-out step A2  Replace fuse F18
<b>A2</b>	<b>RELAY CHECK</b>  - Check relay I73 in fuse box G1 for integrity	OK <del>OK</del>	Carry-out step A3  Replace relay I73
<b>A3</b>	<b>CONTINUITY CHECK</b>  - Check for presence of 0V (zero) at pin 12E of fuse box G1	OK <del>OK</del>	Carry-out step A4  Repair wiring between pin 12E of fuse box G1 and ground point G174
<b>A4</b>	<b>VOLTAGE CHECK</b>  - With the ignition key set to "run" check for presence of 12V between pin 4O of fuse box G1 and ground	OK <del>OK</del>	Carry-out step A5  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2

(Cont.d)

BOTH FRONT WINDOW LIFTS INOPERATIVE

TEST A

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 12V between pin 2T of fuse box G1 and ground</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 4E of fuse box G1 and pin 2 of connector</p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2</p>

End of test A

**LEFT FRONT WINDOW LIFT INOPERATIVE**

**TEST B**

**TEST STEPS**

**RESULTS**

**REMEDY**

**NOTE:** B53 is an integral light switch which illuminates any time the ignition key is set to "run". Replace the switch if it does not illuminate, even if its function is operative.

**B1 FUSE CHECK**

- Check fuse F19 in fuse box G1 for integrity



Carry-out step B2



Replace fuse F19

**B2 CONTROL SWITCH CHECK**

- Check control switch B53 for proper operation



Carry-out step B3



Replace switch B53

**B3 VOLTAGE CHECK**

- With the ignition key set to "run" press and hold switch B53 and check for presence of 12V at pins B1 and B4 of control unit N38



Carry-out step B4









Repair wiring between pins B1 of N38, pin 12 of connector G100 and pin 1 of B22, repair wiring between B4 of control unit N38, pin 11 of connector G100 and pin 2 of switch B22

(Cont.d)









LEFT FRONT WINDOW LIFT INOPERATIVE	TEST B
------------------------------------	--------

TEST STEPS		RESULTS	REMEDY
<b>B4</b>	<b>CONTROL UNIT CHECK</b>		
<ul style="list-style-type: none"> <li>With the ignition key set to "run" press and hold switch <b>B53</b> and check for presence of 12V between pins <b>A1</b> and <b>A4</b> of control unit <b>N38</b></li> </ul>		 	Carry-out step <b>B5</b>  Replace control unit <b>N38</b>
<b>B5</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>Check for presence of 12V between pins 1 and 2 of connector <b>G168</b></li> </ul>		 	Carry-out step <b>B6</b>  Repair wiring between pin <b>A1</b> of control unit <b>N38</b> and pin 1 of connector <b>G168</b> , repair wiring between pin <b>A4</b> of control unit <b>N38</b> and pin 2 of connector <b>G168</b>
<b>B6</b>	<b>MOTOR CHECK</b>		
<ul style="list-style-type: none"> <li>Check motor <b>P15</b> for proper operation</li> </ul>		 	Repair wiring between motor <b>P15</b> and pins 1 and 2 of connector <b>G168</b>  Replace motor <b>P15</b>

End of test B

<b>RIGHT FRONT WINDOW LIFT INOPERATIVE</b>	<b>TEST C</b>
--	---------------

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> B21 is an integral light switch which illuminates any time the ignition key is set to "run". Replace the switch if it does not illuminate, even if its function is operative.</p>		
<b>C1</b> CONTROL SWITCH CHECK	 	Carry-out step C2  Replace switch B21
- Check switch B21 for proper operation		
<b>C2</b> VOLTAGE CHECK	 	Carry-out step C3  Repair or replace wires, as necessary
- Check for presence of 12V between: <ul style="list-style-type: none"> <li>• pins 1 and 3 of connector G100 and ground</li> <li>• pins 1 and 2 of connector G166 and ground</li> </ul>		
<b>C3</b> MOTOR CHECK	 	Repair wiring between motor P14 and pins 1 and 2 of connector G166  Replace motor P14
- Check motor P14 for proper operation		

End of test C

## BOTH REAR WINDOW LIFTS INOPERATIVE









## TEST D

TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>FUSE CHECK</b>		
- Check fuse F11 in fuse box G1 for integrity		(OK)      ► ( <del>OK</del> )      ►	Carry-out step D2  Replace fuse F11
<b>D2</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V, at pin 2 of switch B25		(OK)      ► ( <del>OK</del> )      ►	Carry-out step D3  Carry-out step D4
<b>D3</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" press and hold switch B25; check for presence of 0V at pin 3 of switch B25		(OK)      ► ( <del>OK</del> )      ►	Repair wiring between switch B25 and free fuse G247 (RED-BLK wire)  Replace switch B25
<b>D4</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between connector G243 and ground		(OK)      ► ( <del>OK</del> )      ►	Repair wiring between pin 2 of switch B25 and connector G243 (RED-BLK wire)  Carry-out step D5

(Cont.d)

## BOTH REAR WINDOW LIFTS INOPERATIVE

## TEST D

TEST STEPS		RESULTS	REMEDY
D5	VOLTAGE CHECK		
- With the ignition key set to "run" check for presence of 12V between pin 87 of relay I13 and ground		 ►	Repair wiring between pin 87 of relay I13 and connector G243 (RED-BLK wire)
		 ►	Carry-out step D6
D6	VOLTAGE CHECK		
- Check for presence of 12V between pin T of fuse box G1 and ground		 ►	Carry-out step D7
		 ►	Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
D7	VOLTAGE CHECK		
- Check for presence of 12V between pin 30 of relay I13 and ground		 ►	Carry-out step D8
		 ►	Repair wiring between pin 30 of I13 and pin T of fuse box G1
D8	VOLTAGE CHECK		
- With the ignition key set to "run" check for presence of 12V between pin 86 of relay I13 and ground		 ►	Carry-out step D10
		 ►	Carry-out step D9

(Cont.d)

BOTH REAR WINDOW LIFTS INOPERATIVE

TEST D

TEST STEPS		RESULTS	REMEDY
<b>D9</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" check for presence of 12V between pin 40 of fuse box G1 and ground		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 6A of fuse box G1 and pin 86 of relay I13</p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2</p>
<b>D10</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 85 of relay I13		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Replace relay I13</p> <p>Repair wiring between pin 85 of I13 and ground point G174</p>

End of test D

**LEFT REAR WINDOW LIFT INOPERATIVE**

**TEST E**

TEST STEPS		RESULTS	REMEDY
<b>E1</b>	<b>FUSE CHECK</b>		
<ul style="list-style-type: none"> <li>- Check fuse G247 for integrity</li> </ul>		<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="margin-right: 10px;">▶</div> </div>	<p>Carry-out step E2</p> <p>Replace fuse G247</p>
<b>E2</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- With the ignition key set to "run" press and hold switch B25; check for presence of 12V between:                             <ul style="list-style-type: none"> <li>• connector G181 and ground</li> <li>• pins 3 and 5 of switch B24 on central console</li> </ul> </li> </ul>		<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="margin-right: 10px;">▶</div> </div>	<p>Carry-out step E3</p> <p>Repair or replace wires, as necessary</p>
<b>E3</b>	<b>SWITCH CHECK</b>		
<ul style="list-style-type: none"> <li>- Check switch B24 on central console for proper operation</li> </ul>		<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="margin-right: 10px;">▶</div> </div>	<p>Carry-out step E4</p> <p>Replace switch B24</p>
<b>E4</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- With the ignition key set to "run" press and hold switch B25; check for presence of 12V between:                             <ul style="list-style-type: none"> <li>• pins 13 and 15 of connector G191</li> <li>• pins 3 and 5 of switch B24 on the left rear door</li> </ul> </li> </ul>		<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="margin-right: 10px;">▶</div> </div>	<p>Carry-out step E5</p> <p>Repair or replace wires, as necessary</p>

(Cont.d)

## LEFT REAR WINDOW LIFT INOPERATIVE

















## TEST E

TEST STEPS		RESULTS	REMEDY
<b>E5</b>	<b>SWITCH CHECK</b>		
<ul style="list-style-type: none"> <li>- Check switch <b>B24</b> on the left rear door for proper operation</li> </ul>		<p style="text-align: center;">(OK)      ►</p> <p style="text-align: center;"><del>(OK)</del>      ►</p>	<p>Carry-out step E6</p> <p>Replace switch B24</p>
<b>E6</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 0V (zero) at: <ul style="list-style-type: none"> <li>• between pin 4 of switch <b>B24</b> on central console and ground</li> <li>• between pin 4 of switch <b>B24</b> on left rear door and ground</li> </ul> </li> </ul>		<p style="text-align: center;">(OK)      ►</p> <p style="text-align: center;"><del>(OK)</del>      ►</p>	<p>Carry-out step E7</p> <p>Repair wiring between ground point G182 and pin 4 of switch B24 on central console, between ground point G182 and pins 1 and 2 of connector G191 and between pins 1 and 2 of G191 and pin 4 of B24 on left rear door</p>
<b>E7</b>	<b>MOTOR CHECK</b>		
<ul style="list-style-type: none"> <li>- With the ignition key set to "run" press and switch <b>B25</b> and either switch <b>B24</b>; check for presence of 12V between terminals of motor <b>P17</b></li> </ul>		<p style="text-align: center;">(OK)      ►</p> <p style="text-align: center;"><del>(OK)</del>      ►</p>	<p>Replace motor P17</p> <p>Repair or replace wires, as necessary</p>

End of test E

## RIGHT REAR WINDOW LIFT INOPERATIVE

## TEST F

TEST STEPS		RESULTS	REMEDY
<b>F1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>G247</b> for integrity		 	Carry-out <b>step F2</b>
		 	Replace fuse <b>G247</b>
<b>F2</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" press and switch <b>B25</b> ; check for presence of 12V between:		 	Carry-out <b>step F3</b>
<ul style="list-style-type: none"> <li>• connector <b>G209</b> and ground</li> <li>• pins 3 and 5 of switch <b>B23</b> on central console</li> </ul>		 	Repair or replace wires, as necessary
<b>F3</b>	<b>SWITCH CHECK</b>		
- Check switch <b>B23</b> on central console for proper operation		 	Carry-out <b>step F4</b>
		 	Replace switch <b>B23</b>
<b>F4</b>	<b>VOLTAGE CHECK</b>		
- With the ignition key set to "run" press and hold switch <b>B25</b> ; check for presence of 12V between:		 	Carry-out <b>step F5</b>
<ul style="list-style-type: none"> <li>• pins 13 and 15 of connector <b>G197</b></li> <li>• pins 3 and 5 of switch <b>B23</b> on the right rear door</li> </ul>		 	Repair or replace wires, as necessary

(Cont.d)



## RIGHT REAR WINDOW LIFT INOPERATIVE

## TEST F

TEST STEPS		RESULTS	REMEDY
<b>F5</b>	<b>SWITCH CHECK</b>		
<ul style="list-style-type: none"> <li>- Check switch <b>B23</b> on the left rear door for proper operation</li> </ul>		<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="margin-right: 10px;">▶</div> </div>	<p>Carry-out step F6</p> <p>Replace switch B23</p>
<b>F6</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>- Check for presence of 0V (zero) between:               <ul style="list-style-type: none"> <li>• pin 4 of switch <b>B23</b> on central console and ground</li> <li>• pin 4 of switch <b>B23</b> on right rear door and ground</li> </ul> </li> </ul>		<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="margin-right: 10px;">▶</div> </div>	<p>Carry-out step F7</p> <p>Repair wiring between ground point G182 and pin 4 of switch B23 on central console, between ground point G182 and pins 1 and 2 of connector G197 and between pins 1 and 2 of G197 and pin 4 of B23 on right rear door</p>
<b>F7</b>	<b>MOTOR CHECK</b>		
<ul style="list-style-type: none"> <li>- With the ignition key set to "run" press and switch <b>B25</b> and either switch <b>B23</b>; check for presence of 12V between terminals of motor <b>P16</b></li> </ul>		<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="margin-right: 10px;">▶</div> </div>	<p>Replace motor P16</p> <p>Repair or replace wires, as necessary</p>

End of test F

**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>

## GENERAL

The windshield wipers can be operated only with the ignition key set to "run".

Actuation of the windshield wipers is accomplished through the multiple switch lever located on the right of the steering wheel.

Three windshield wipers operating modes are available:

- position 1 (⊗): intermittent operation.
- position 2 (—): continuous operation, normal speed.
- position 3 (≡): continuous operation, high speed.

To operate the windshield washer pull towards the steering wheel the multiple switch lever located to the right of the steering wheel.

Actuation of the windshield washer with position lamps on automatically actuates the head lamps washer.

### NOTE

In case of lack of washer fluid, do not actuate the electric pump to avoid damages.

The horns are actuated by pushing the switches located on the steering wheel

The system is protected by three fuses in the fuse box G1, as follows:

- fuse F1 (7.5A) POSITION LAMPS.
- fuse F10 (20A) WINDSHIELD WASHER/WIPER.
- fuse F17 (20A) HEAD LAMPS WASHER.

## OPERATIONAL DESCRIPTION

Battery power available when the ignition key is set to "run", is applied through the fuse F10 (windshield wiper and washer) to the windshield wiper motor and control unit P27, and to the windshield wiper control B2.

Moving the windshield wiper control B2 to position 1, power is applied to the windshield wiper motor and control unit P27 through pin 1E of the windshield wiper control. The motor P27 actuates the wiper in the intermittent mode.

Moving the windshield wiper control B2 to the position 2, power is applied to the control unit P27 through pin 4B of the windshield wiper control.

In this case the motor P27 actuates the wipers in the continuous mode normal speed.

Moving the multiple switch to the position 3, power is applied to the control unit P27 through pin 2C of the multiple switch.

In this case the motor P27 actuates the wiper in the continuous mode, high speed.

When the windshield washer is activated, 12V are applied, through pin 3C of multiple switch, to the head lamps washer pump relay I19, to the windshield washer electric pump P19 and to pin 7 of the motor P27 to momentarily operate the windshield wipers.

Energization of the relay I19 applies 12V to the head lamps washer electric pump P20 only if the position lamps are on.













The power line to pump P20 is protected by the head lamps washer fuse F17.

Horn O2 is actuated by pushing on a microswitch on the steering wheel, which closes and connects to ground the horn relay I3 coil, thus energizing the relay.









The relay I3 contacts closure powers the horn O2.

TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT											
	F1 FUSE	F10 FUSE	F17 FUSE	B2 SWITCH	B3 SWITCH	B5 SWITCH	13 RELAY	119 RELAY	02 HORN	P19 ELECTRIC PUMP	P20 ELECTRIC PUMP	P27 MOTOR
WINDSHIELD WIPERS INOPERATIVE		●										●
WINDSHIELD WIPERS INTERMITTENT MODE INOPERATIVE				●								●
WINDSHIELD WIPERS CONTINUOUS MODE (LOW SPEED) INOPERATIVE				●								●
WINDSHIELD WIPERS CONTINUOUS MODE (HIGH SPEED) INOPERATIVE				●								●
BOTH WINDSHIELD AND HEAD LAMPS WASHERS INOPERATIVE					●			●				
WINDSHIELD WIPERS INOPERATIVE WHEN WINDSHIELD WASHER IS ACTUATED					●							●
WINDSHIELD WASHER INOPERATIVE										●		
HEAD LAMPS WASHER INOPERATIVE	●		●					●			●	
HORN INOPERATIVE						●	●		●			


<p>Ignition switch</p> <p>B1</p> 	<p>Windshield wiper control</p> <p>(B2) B</p> 
<p>Windshield wiper control</p> <p>(B2) C</p> 	<p>Windshield wiper control</p> <p>(B2) E</p> 
<p>Head lamp washer/wiper and windshield washer pump control</p> <p>(B3) C</p> 	<p>Horn control switch</p> <p>(B5) B</p> 
<p>Fuse box</p> <p>(G1) D</p> 	<p>Fuse box</p> <p>(G1) G</p> 
<p>Fuse box</p> <p>(G1) H</p> 	<p>Fuse box</p> <p>(G1) N</p> 
<p>Fuse box</p> <p>(G1) O</p> 	<p>Engine compartment right side ground connection</p> <p>G53a</p> 

(Cont.d)

<p>Central bulkhead ground</p>	<p><b>G143</b></p>	<p>Connector, circuit board to engine compartment right side wiring</p>	<p><b>G149</b></p>
 <p>1.5BLK • P27</p>		 <p>YEL-BLK • G1 D WHT-BLK • B3 C 2.5RED-BLK • G1 H</p> <p>YEL-BLK • I19 WHT-BLK • I19 2.5RED-BLK • I19</p>	
<p>Connector, circuit board to engine compartment left side wiring</p>	<p><b>G150</b></p>	<p>Steering wheel column support ground</p> <p><b>G174</b></p>  <p>1BLK • B1</p>	
 <p>PPL-BLK • G1 H PPL-BLK • I3</p>		<p>Head lamps washer pump relay</p>	<p><b>I19</b></p>
<p>Horn relay</p>	<p><b>I3</b></p>	 <p>1BLK • G53 31 1BLK • P19 31 2.5RED-BLK • G149 30 E23 PIN 3 (A) 56 YEL-BLK • G149 56 1WHT-BLK • P19 8 WHT-BLK • G149 8 2.5GRY-BLK • P20 F</p>	
 <p>PPL-BLK • G150 85 1PPL • O2 87 1PPL • O2 87 2.5RED • HOT AT ALL TIMES 86 2.5RED</p>		<p>Parking lamps control unit</p>	<p><b>O2</b></p>
 <p>1.5YEL-BLK • G1 G L(6)</p>		<p>Horn</p>  <p>1PPL • I3 1PPL • I3</p>	

(Cont.d)

<p>Windshield washer electric pump</p>	<p>P19</p>	<p>Windshield wiper motor and control unit</p>	<p>P27</p>
<p>Head lamps washer electric pump</p>	<p>P20</p>		





## WINDSHIELD WIPERS INOPERATIVE

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
	- Check fuse F10 in fuse box G1 for integrity	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Carry-out step A2</p> <p>Replace fuse F10</p>
<b>A2</b>	<b>VOLTAGE CHECK</b>		
	- With the ignition key set to "run", check for presence of 12V between pin 6 of motor and control unit P27 and ground	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Carry-out step A4</p> <p>Carry-out step A3</p>
<b>A3</b>	<b>VOLTAGE CHECK</b>		
	- With the ignition key set to "run", check for presence of 12V between pin 4O of fuse box G1 and ground	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 2H of fuse box and pin 6 of motor P27</p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2</p>
<b>A4</b>	<b>VOLTAGE CHECK</b>		
	- With ignition key set to "run", check for presence of 12V between pin 4C of windshield wiper control B2 and ground	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Carry-out step A5</p> <p>Repair wiring between pin 4C of windshield wiper control B2 and pin 2H of fuse box G1</p>

(Cont.d)

WINDSHIELD WIPERS INOPERATIVE

TEST A

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>MOTOR CHECK</b>		
- Check motor P27 for proper operation		(OK)      ► (OK)      ►	Replace windshield wiper control B2  Replace motor P27

End of test A

## WINDSHIELD WIPERS INTERMITTENT MODE INOPERATIVE

## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B1</b>	<b>SIGNAL CHECK</b>		
<ul style="list-style-type: none"> <li>With ignition key set to "run" and windshield wiper control <b>B2</b> to position 1 check for presence of a 12V intermittent signal at pin 1E of windshield wiper control <b>B2</b></li> </ul>		(OK)      ► (OK)      ►	Carry-out step B2  Replace windshield wiper control B2
<b>B2</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>Check for continuity between pin 1E of windshield wiper control <b>B2</b> and pin 4 of motor <b>P27</b></li> </ul>		(OK)      ► (OK)      ►	Replace motor P27  Repair or replace wires, as necessary

End of test B

<b>WINDSHIELD WIPERS CONTINUOUS MODE (LOW SPEED) INOPERATIVE</b>	<b>TEST C</b>
--	---------------

	TEST STEPS	RESULTS	REMEDY
<b>C1</b>	<b>SIGNAL CHECK</b>		
	<ul style="list-style-type: none"> <li>- With ignition key set to "run" and windshield wiper control <b>B2</b> set to position 2 check for presence of a 12V signal between pin 4B of windshield wiper control <b>B2</b> and ground</li> </ul>	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div> </div>	<p>Carry-out step C2</p> <p>Replace windshield wiper control <b>B2</b></p>
<b>C2</b>	<b>CONTINUITY CHECK</b>		
	<ul style="list-style-type: none"> <li>- Check for continuity between pin 4B of windshield wiper control <b>B2</b> and pin 3 of motor <b>P27</b></li> </ul>	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div> </div>	<p>Replace motor <b>P27</b></p> <p>Repair or replace wires, as necessary</p>

End of test C

## WINDSHIELD WIPERS CONTINUOUS MODE (HIGH SPEED) INOPERATIVE

## TEST D

TEST STEPS		RESULTS	REMEDY
<b>D1</b>	<b>SIGNAL CHECK</b>		
<ul style="list-style-type: none"> <li>With ignition key set to "run" and windshield wiper control <b>B2</b> set to position 3 check for presence of a 12V signal between pin 2C of windshield wiper control <b>B2</b> and ground</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step D2</p> <p>Replace windshield wiper control <b>B2</b></p>
<b>D2</b>	<b>CONTINUITY CHECK</b>		
<ul style="list-style-type: none"> <li>Check for continuity between pin 2C of windshield wiper control <b>B2</b> and pin 2 of motor <b>P27</b></li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace motor <b>P27</b></p> <p>Repair or replace wires, as necessary</p>

End of test D

**BOTH WINDSHIELD AND HEAD LAMPS WASHERS INOPERATIVE**

**TEST E**

TEST STEPS		RESULTS	REMEDY
<b>E1</b>	<b>MULTIPLE SWITCH CHECK</b>		
- With ignition key set to "run", operate the windshield washer and check for presence of 12V between pin 3C of of head lamp washer/wiper and windshield washer pump control B3 and ground		(OK)      ▶ (OK)      ▶	Carry-out step E2  Replace pump control B3
<b>E2</b>	<b>VOLTAGE CHECK</b>		
- With ignition key set to "run", operate the windshield washer and check for presence of 12V between pin 9 of connector G149 and ground		(OK)      ▶ (OK)      ▶	Carry-out step E3  Repair wiring between pin 3C of pump control B3 and pin 9 connector G149
<b>E3</b>	<b>VOLTAGE CHECK</b>		
- With ignition key set to "run", operate the windshield washer and check for presence of 12V between pin S of the head lamps washer pump relay I19 and ground		(OK)      ▶ (OK)      ▶	Carry-out step E4  Repair wiring between pin S of relay I19 and pin 9 of connector G149
<b>E4</b>	<b>GROUNDING CHECK</b>		
- Check for presence of 0V (zero) at pin 31 of relay I19		(OK)      ▶ (OK)      ▶	Replace relay I19  Repair wiring between pin 31 of relay I19 and ground point G53a

End of test E

## WINDSHIELD WIPERS INOPERATIVE WHEN WINDSHIELD WASHER IS ACTUATED

TEST F

TEST STEPS		RESULTS	REMEDY
<b>F1</b>	<b>MULTIPLE SWITCH CHECK</b>		
<ul style="list-style-type: none"> <li>With ignition key set to "run", operate the windshield washer and check for presence of 12V between pin 3C of pump control <b>B3</b> and ground</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step F2</p> <p>Replace pump control <b>B3</b></p>
<b>F2</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>With ignition key set to "run", operate the windshield washer and check for presence of 12V between pin 7 of motor <b>P27</b> and ground</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace motor <b>P27</b></p> <p>Repair wiring between pin 3C of pump control <b>B3</b> and pin 7 of motor <b>P27</b></p>

End of test F

## WINDSHIELD WASHER INOPERATIVE









## TEST G

TEST STEPS		RESULTS	REMEDY
<b>G1</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>With ignition key set to "run", operate the windshield washer and check for presence of 12V between pin 2 of windshield washer electric pump P19 and ground</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Carry-out step G2</p> <p>Repair wiring between pin S of relay I19 and pin 2 of electric pump P19</p>
<b>G2</b>	<b>GROUNDING CHECK</b>		
<ul style="list-style-type: none"> <li>With ignition key set to "run" check for presence of 0V (zero) at pin 1 of electric pump P19</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Replace electric pump P19</p> <p>Repair wiring between pin 1 of electric pump P19 and pin 31 of relay I19</p>

End of test G



<b>HEAD LAMPS WASHER INOPERATIVE</b>	<b>TEST H</b>
--------------------------------------	---------------

TEST STEPS		RESULTS	REMEDY
<b>H1</b>	<b>FUSE CHECK</b>		
- Check fuse F17 in fuse box G1 for integrity		 ▶  ▶	Carry-out step H2  Replace fuse F17
<b>H2</b>	<b>FUSE CHECK</b>		
- Check fuse F1 in fuse box G1 for integrity		 ▶  ▶	Carry-out step H3  Replace fuse F1
<b>H3</b>	<b>VOLTAGE CHECK</b>		
- With position lamps on, check for presence of 12V between pin 6 of parking lamps control unit N41 and ground		 ▶  ▶	Carry-out step H4  Failure of the lamps -- position circuit, refer to the applicable troubleshooting procedure
<b>H4</b>	<b>VOLTAGE CHECK</b>		
- With position lamps on, check for presence of 12V between pin 3G of fuse box G1 and ground		 ▶  ▶	Carry-out step H5  Repair wiring between pin 6 of control unit N41 and pin 3G of fuse box G1

(Cont.d)

HEAD LAMPS WASHER INOPERATIVE	<b>TEST H</b>
-------------------------------	---------------

	TEST STEPS	RESULTS	REMEDY
H5	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 30 of head lamps washer electric pump relay I19 and ground	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step H7
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step H6
H6	<b>VOLTAGE CHECK</b>		
	- Check for presence of 12V between pin 2N of of fuse box G1 and ground	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between pin 30 of relay I19, pin 13 of connector G149 and pin 3H of fuse box G1
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
H7	<b>VOLTAGE CHECK</b>		
	- With the position lamps on, check for presence of 12V between pin 56 of head lamps washer pump relay I19 and ground	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Carry-out step H8
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between pin 56 of relay I19, pin 3 of connector G149 and pin 5D of fuse box G1







(Cont.d)

<b>HEAD LAMPS WASHER INOPERATIVE</b>	<b>TEST H</b>
--------------------------------------	---------------

	TEST STEPS	RESULTS	REMEDY
<b>H8</b>	<b>RELAY CHECK</b>		
	<ul style="list-style-type: none"> <li>- With ignition key set to "run", check the operation of head lamps washer pump relay I19 by actuating the multiple switch and checking for presence, at intervals, of a high level logic signal on pin P of relay I19</li> </ul>	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px;">OK</span> <span style="font-size: 2em;">▶</span> </div> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px; text-decoration: line-through;">OK</span> <span style="font-size: 2em;">▶</span> </div> </div>	<p>Carry-out step H9</p> <p>Replace relay I19</p>
<b>H9</b>	<b>VOLTAGE CHECK</b>		
	<ul style="list-style-type: none"> <li>- With ignition key set to "run", operate the windshield washer and check for presence of 12V between pin of the head lamps washer electric pump P20 (GRY-BLK wire) and ground</li> </ul>	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px;">OK</span> <span style="font-size: 2em;">▶</span> </div> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px; text-decoration: line-through;">OK</span> <span style="font-size: 2em;">▶</span> </div> </div>	<p>Carry-out step H10</p> <p>Repair wiring between pin of pump P20 (GRY-BLK wire) and pin P of relay I19</p>
<b>H10</b>	<b>GROUNDING CHECK</b>		
	<ul style="list-style-type: none"> <li>- Check for presence of 0V (zero) at pin of pump P20 (BLK wire)</li> </ul>	<div style="display: flex; flex-direction: column; gap: 10px;"> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px;">OK</span> <span style="font-size: 2em;">▶</span> </div> <div style="display: flex; align-items: center; gap: 10px;"> <span style="border: 1px solid black; border-radius: 50%; padding: 5px; text-decoration: line-through;">OK</span> <span style="font-size: 2em;">▶</span> </div> </div>	<p>Replace pump P20</p> <p>Repair wiring between pin of pump P20 (BLK wire) and ground point G53a</p>









End of test H

<b>HORN INOPERATIVE</b>	<b>TEST I</b>
-------------------------	---------------

	TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> In case only one of the horn O2 does not operate, verify its connection to ground, or replace the horn.</p>			
<b>I1</b>	<b>FUSE CHECK</b>		
	- Check horn relay I3 fuse for integrity	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Carry-out step I2
		<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Replace relay I3
<b>I2</b>	<b>GROUNDING CHECK</b>		
	- Operating the horn, check for presence of 0V (zero) at pin 3B of horn control switch B5	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Carry-out step I3
		<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Replace switch B5
<b>I3</b>	<b>GROUNDING CHECK</b>		
	- Operate the horn and check for presence of 0V (zero) at pin 2G of fuse box G1	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Carry-out step I4
		<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;">  </div> <div style="text-align: center;">▶</div> </div>	Repair wiring between pin 2G of fuse box G1 and pin 3B of horn control switch B5

(Cont.d)

HORN INOPERATIVE	<b>TEST I</b>
------------------	---------------

TEST STEPS		RESULTS	REMEDY
<b>14</b>	<b>GROUNDING CHECK</b>		
- Operate the horn and check for presence of 0V (zero) at pin 85 of horn relay I3		 ▶  ▶	Carry-out <b>step 15</b>  Repair wiring between <b>pin 85 of relay I3, pin 7 of connector G150 and pin 9H of fuse box G1</b>
<b>15</b>	<b>RELAY CHECK</b>		
- Check relay I3 for proper operation		 ▶  ▶	Carry-out <b>step 16</b>  Replace relay I3
<b>16</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 30 of relay I3 and ground		 ▶  ▶	Carry-out <b>step 18</b>  Carry-out <b>step 17</b>
<b>17</b>	<b>VOLTAGE CHECK</b>		
- Check for presence of 12V between pin 86 of relay I3 and ground		 ▶  ▶	Repair wiring between <b>pin 30 and pin 86 of horn relay I3</b>  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2

(Cont.d)

HORN INOPERATIVE	TEST I
------------------	--------

TEST STEPS		RESULTS	REMEDY
18	VOLTAGE CHECK		
- Operate the horn and check for presence of 12V between horn O2 (PPL wire) and ground		(OK)      ► ( <del>OK</del> )      ►	Replace horn O2  Repair wiring between pin 87 of relay I3 and horn O2 (PPL wire)

End of test I

---

# **ELECTRICAL SYSTEM SUBJECT FOR CANADA VERSION ONLY**

**THIS PAGE OF THE SHOP MANUAL WAS BLANK**

<https://www.automotive-manuals.net/>



# FOGLAMPS - - FRONT AND REAR



## GENERAL

When the ignition key is in "run" position the front and rear foglamps can be turned on. Refer to low beam lamps chapter for further details.

Switching on of the front and/or rear fog lamps is indicated by the illumination of the corresponding warning lamps on the instrument panel.

The system is protected by two fuses in the fuse box G1, as follows:

- Fuse F7 (15A) FRONT FOG LAMPS AND LAMP.
- Fuse F8 (7.5A) REAR FOG LAMPS AND LAMP.

## OPERATIONAL DESCRIPTION

12V from the battery is applied to the fuse box G1 and to common contact of front fog lamps relay I17.

The electric power reaches the coil of rear foglamps relay I25.

Energization of front foglamps relay I17, activated by the switch on the air conditioning control unit Q21A, energizes the corresponding line protected by fuse F7 in fuse box G1.

Therefore, electric power is applied to left and right front foglamp E10, connected in parallel, and the lamps are turned on.

Energization of rear foglamps relay I25, activated by the automatic control mode check unit Q21A, energizes the corresponding line protected by fuse F8 in fuse box G1. Therefore, electric power is applied to terminals of central tail lamp E27, and the lamps are turned on.

Two lines derived from the front and rear fog lamps lines are connected to the instrument panel C10. In this way, the corresponding warning lamps on the instrument panel will illuminate any time the front and/or rear fog lamps are switched on.













TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT										
	<u>E7</u> FUSE	<u>E8</u> FUSE	<u>C10</u> FRONT FOG LAMP	<u>C10</u> FRONT FOG LAMP	<u>E10</u> R.H. FRONT FOG LAMP	<u>E10</u> L.H. FRONT FOG LAMP	<u>E27</u> REAR CENTER LAMP	<u>I17</u> RELAY	<u>I25</u> RELAY	<u>Q21A</u> CONTROL UNIT	<u>G1</u> FUSE BOX
BOTH FRONT AND REAR FOG LAMPS INOPERATIVE										•	
BOTH FRONT FOG LAMPS INOPERATIVE	•				•	•		•		•	•
LEFT FRONT FOG LAMP INOPERATIVE	•					•		•			•
RIGHT FRONT FOG LAMP INOPERATIVE	•				•			•			•
REAR FOG LAMP INOPERATIVE		•					•		•	•	•
FRONT FOG LAMPS WARNING LAMP ON INSTRUMENT PANEL INOPERATIVE	•			•							•
REAR FOG LAMP WARNING LAMP ON INSTRUMENT PANEL INOPERATIVE		•	•								•



**NOTE:** Before carrying-out any troubleshooting, check the integrity of warning lamp on instrument panel by pressing the test button.


<p>Instrument panel <span style="float: right;">(C10) (B)</span></p> <p>YEL-RED (G1) (C) 4          GRY-RED (G1) (C) 5</p>	<p>Right front fog lamp <span style="float: right;">(E10)</span></p> <p>1BLK (G53a) 2          E23 PIN 1 (A) 2          1LTBLU-WHT (G149) 1</p>
<p>Left front fog lamp <span style="float: right;">(E10)</span></p> <p>1BLK (G53b) 2          E24 PIN 1 (A) 2          1LTBLU-WHT (G150) 1</p>	<p>Tail lamp, left (fixed part) <span style="float: right;">E26</span></p> <p>1BLK (G184)          1BLK (G185)</p>
<p>Central tail lamps (mobile) <span style="float: right;">(E27)</span></p> <p>1BLK (G194) 4          1LTBLU-WHT (G194) 1</p>	<p>Fuse box <span style="float: right;">(G1) (A)</span></p> <p>1WHT 22          11          10          9          8</p>
<p>Fuse box <span style="float: right;">(G1) (A)</span></p> <p>1WHT 22          11          10          9          8</p>	<p>Fuse box <span style="float: right;">(G1) (B)</span></p> <p>1RED (G1) (G) 3          GRY-YEL (G1) (L) 2          1LTBLU-WHT 7          1LTBLU-WHT 2          1 GRY-RED (G154) 1          C10 PIN 8 (C) 2</p>
<p>Fuse box <span style="float: right;">(G1) (C)</span></p> <p>YEL-RED (C10) (B) 6          GRY-RED (C10) (B) 5</p>	<p>Fuse box <span style="float: right;">(G1) (D)</span></p> <p>1LTBLU-WHT (G171) 11</p>
<p>Fuse box <span style="float: right;">(G1) (G)</span></p> <p>1RED (G1) (B) 8</p>	<p>Fuse box <span style="float: right;">(G1) (H)</span></p> <p>1LTBLU-WHT (G150) 6</p>

(Cont.d)

<p>Fuse box</p> <p><b>G1 I</b></p>	<p>Fuse box</p> <p><b>G1 L</b></p>
 <p>1LTBLU-WHT G149 4</p>	 <p>GRY-YEL G1 B 5 C10 PIN 8 C 5 GRY-YEL B66 PIN 3</p>
<p>Fuse box</p> <p><b>G1 N</b></p>	<p>Fuse box</p> <p><b>G1 S</b></p>
 <p>1.5RED I50 2 4RED HOT AT ALL TIMES 2 1.5RED I50 1</p>	 <p>1LTBLU-WHT 3</p>
<p>Engine compartment right side ground connection</p> <p><b>G53a</b></p>	<p>Engine compartment left side ground connection</p> <p><b>G53b</b></p>
 <p>1BLK E10</p>	 <p>1BLK E10</p>
<p>Connector, circuit board to engine compartment right side wiring</p> <p><b>G149</b></p>	<p>Connector, circuit board to engine compartment left side wiring</p> <p><b>G150</b></p>
 <p>1LTBLU-WHT G1 I 11</p>	 <p>1LTBLU-WHT G1 H 11 1LTBLU-WHT E10</p>
<p>Connector, circuit board to air conditioning wiring</p> <p><b>G164</b></p>	<p>Connector, circuit board to left rear wiring</p> <p><b>G171</b></p>
 <p>YEL-RED G1 A 7 GRY-YEL G1 A 8 GRY-RED G1 B 9</p> <p>YEL-RED Q21A GRY-YEL Q21A GRY-RED Q21A</p>	 <p>1LTBLU-WHT G1 D 12 1LTBLU-WHT G194</p>
<p>Trunk left side ground</p> <p><b>G185</b></p>	<p>Connector, left rear wiring to rear central lamp wiring</p> <p><b>G194</b></p>
 <p>1BLK E26</p>	 <p>1BLK E27 1 1LTBLU-WHT E27 5 1BLK E26 1 1LTBLU-WHT G171 6</p>

(Cont.d)







High beam lamps relay	150	Automatic control mode check unit	Q21A
 <p>1.5RED+ G1 N 30 1.5RED+ G1 N 30</p>		 <p>GRY-RED+ Q184 15 YEL-RED+ Q184 14 2 GRY-YEL+ Q184</p>	





## BOTH FRONT AND REAR FOG LAMPS INOPERATIVE









## TEST A

TEST STEPS		RESULTS	REMEDY
NOTE: Turn ignition key to "run" position.			
<b>A1</b>	<b>VOLTAGE CHECK</b>		
- Connect: <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to pin 3 L of fuse box G1</li> </ul> Meter reads 12V?		 ►  ►	Failure of the lamps - position, side marker, license plate illumination circuit, refer to the relevant troubleshooting  Go to step A2
<b>A2</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 5L of fuse box G1 Meter reads 12V?		 ►  ►	Go to step A3  Repair wiring between pin 5L of fuse box G1 and pin 3L of fuse box G1
<b>A3</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 2N of fuse box G1 Meter reads 12V?		 ►  ►	Failure of the air conditioning system, refer to the relevant troubleshooting procedure  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2

End of test A

## BOTH FRONT FOG LAMPS INOPERATIVE

## TEST B

TEST STEPS		RESULTS	REMEDY
<b>NOTE:</b> Turn ignition key to "run" position.			
<b>B1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>F7</b> (15A) in fuse box <b>G1</b>		 	Go to step <b>B2</b>  Replace fuse <b>F7</b>
<b>B2</b>	<b>VOLTAGE CHECK</b>		
- Connect: <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to <b>pin 86</b> of relay <b>I17</b></li> </ul> Meter reads 12V?		 	Go to step <b>B3</b>  Repair wiring between <b>pin 5L</b> of fuse box <b>G1</b> and <b>pin 86</b> of relay <b>I17</b>
<b>B3</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (-) lead to <b>pin 85</b> of relay <b>I17</b> Meter reads 12V?		 	Go to step <b>B4</b>  Go to step <b>B5</b>
<b>B4</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 30</b> of relay <b>I17</b> Meter reads 12V?		 	Replace relay <b>I17</b>  Repair wiring between <b>pin 2N</b> of fuse box <b>G1</b> and <b>pin 30</b> of relay <b>I17</b>

(Cont.d)

BOTH FRONT FOG LAMPS INOPERATIVE	TEST B
----------------------------------	--------

TEST STEPS		RESULTS	REMEDY
<b>B5</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (-) lead to <b>pin 7</b> of connector <b>G164</b> Meter reads 12V?		OK      ►	Repair wiring between <b>pin 7</b> of connector <b>G164</b> and <b>pin 10A</b> of fuse box <b>G1</b>
		<del>OK</del> ►	Go to step <b>B6</b>
<b>B6</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (-) lead to <b>pin 14</b> of automatic control mode check <b>Q21A</b> Meter reads 12V?		OK      ►	Repair wiring between <b>pin 14</b> of control unit <b>Q21A</b> and <b>pin 7</b> of connector <b>G164</b>
		<del>OK</del> ►	Go to step <b>B7</b>
<b>B7</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 8</b> of connector <b>G164</b> Meter reads 12V?		OK      ►	Repair wiring between <b>pin 8</b> of connector <b>G164</b> and <b>pin 9A</b> of fuse box <b>G1</b>
		<del>OK</del> ►	Go to step <b>B8</b>

(Cont.d)

BOTH FRONT FOG LAMPS INOPERATIVE







TEST B

TEST STEPS		RESULTS	REMEDY
B8	VOLTAGE CHECK		
<ul style="list-style-type: none"> <li>Move voltmeter (+) lead to pin 2 of automatic control mode check unit Q21A</li> <li>Meter reads 12V?</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pin 2 of control unit Q21A and pin 8 of connector G164</p> <p>Failure of the air conditioning system, refer to the relevant troubleshooting procedure</p>

End of test B

## LEFT FRONT FOG LAMP INOPERATIVE

## TEST C

TEST STEPS		RESULTS	REMEDY
NOTE: Turn ignition key to "run" position.			
<b>C1</b>	<b>LAMP CHECK</b>		
- Check left front fog lamp E10		 	Go to step C2  Replace left front fog lamp E10
<b>C2</b>	<b>VOLTAGE CHECK</b>		
- Connect: <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to pin 11 of connector G150</li> </ul> Meter reads 12V?		 	Go to step C3  Repair wiring between pin 11 of connector G150 and pin 6H of fuse box G1
<b>C3</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 1 of left front fog lamp E10 Meter reads 12V?		 	Go to step C4  Repair wiring between pin 1 of left front fog lamp E10 and pin 11 of connector G150

(Cont.d)

LEFT FRONT FOG LAMP INOPERATIVE

TEST C

TEST STEPS		RESULTS	REMEDY
C4	VOLTAGE CHECK		
- Move voltmeter (-) lead to ground G53b Meter reads 12V?		<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="font-size: 24px; margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 24px; margin-right: 10px;">▶</div> </div>	<p>Repair wiring between pin 2 of left front fog lamp E10 and ground G53b</p> <p>Repair ground G53b</p>

End of test C

<b>RIGHT FRONT FOG LAMP INOPERATIVE</b>	<b>TEST D</b>
---	---------------

TEST STEPS	RESULTS	REMEDY
<b>NOTE:</b> Turn ignition key to "run" position.		
<b>D1. LAMP CHECK</b>		
- Check right front fog lamp E10	<div style="display: inline-block; vertical-align: middle;"> <div style="text-align: center;">OK <span style="font-size: 2em;">▶</span></div>  <div style="text-align: center;"><del>OK</del> <span style="font-size: 2em;">▶</span></div> </div>	Go to step D2  Replace left front fog lamp E10
<b>D2. VOLTAGE CHECK</b>		
- Connect:		
<ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to <b>pin 11</b> of connector G149</li> </ul> Meter reads 12V?	<div style="display: inline-block; vertical-align: middle;"> <div style="text-align: center;">OK <span style="font-size: 2em;">▶</span></div>  <div style="text-align: center;"><del>OK</del> <span style="font-size: 2em;">▶</span></div> </div>	Go to step D3  Repair wiring between pin 11 of connector G150 and pin 4l of fuse box G1
<b>D3. VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 1</b> of right front fog lamp E10 Meter reads 12V?	<div style="display: inline-block; vertical-align: middle;"> <div style="text-align: center;">OK <span style="font-size: 2em;">▶</span></div>  <div style="text-align: center;"><del>OK</del> <span style="font-size: 2em;">▶</span></div> </div>	Go to step D4  Repair wiring between pin 1 of right front fog lamp E10 and pin 11 of connector G149

(Cont.d)

## RIGHT FRONT FOG LAMP INOPERATIVE

## TEST D

TEST STEPS		RESULTS	REMEDY
D4	VOLTAGE CHECK		
<ul style="list-style-type: none"> <li>Move voltmeter (-) lead to ground <b>G53a</b> Meter reads 12V?</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between pin 2 of right front fog lamp E10 and ground G53a</p> <p>Repair ground G53a</p>

End of test D



## REAR FOG LAMP INOPERATIVE







TEST E

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Turn ignition key to "run" position. Before carrying out any troubleshooting, check the integrity of warning lamp on instrument panel by pressing the test button. The central tail lamp E27 includes two bulbs connected in parallel. Replacement of a single bulb is allowed in case one of the two bulbs does not switch on</p>			
<b>E1</b>	<b>WARNING LAMP CHECK</b>		
<ul style="list-style-type: none"> <li>- Check if the rear fog lamp warning lamp on instrument panel illuminates</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Go to step E2</p> <p>Go to step E8</p>
<b>E2</b>	<b>LAMP CHECK</b>		
<ul style="list-style-type: none"> <li>- Check central tail lamp E27</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Go to step E3</p> <p>Replace central tail lamp E27</p>
<b>E3</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>- Connect: <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to pin 12 of connector G171</li> </ul> </li> <li>Meter reads 12V?</li> </ul>		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Go to step E4</p> <p>Repair wiring between pin 11D of fuse box G1 and pin 12 of connector G171</p>

(Cont.d)

## REAR FOG LAMP INOPERATIVE

## TEST E

TEST STEPS		RESULTS	REMEDY
<b>E4</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 5</b> of connector <b>G194</b> Meter reads 12V?		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	<p>Go to step E5</p> <p>Repair wiring between <b>pin 12</b> of connector <b>G171</b> and <b>pin 5</b> of connector <b>G194</b></p>
<b>E5</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 1</b> of central tail lamp <b>E27</b> Meter reads 12V ?		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	<p>Go to step E6</p> <p>Repair wiring between <b>pin 1</b> of central tail lamp and <b>pin 5</b> of connector <b>G194</b></p>
<b>E6</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (-) lead to <b>pin 1</b> of connector <b>G194</b> Meter reads 12V?		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px; margin-top: 10px;"> <div style="text-align: center;">  </div> <div style="font-size: 2em;">▶</div> </div>	<p>Repair wiring between <b>pin 4</b> of central tail lamp and <b>pin 1</b> of connector <b>G194</b></p> <p>Go to step E7</p>

(Cont.d)

## REAR FOG LAMP INOPERATIVE

## TEST E

TEST STEPS		RESULTS	REMEDY
<b>E7</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>Move voltmeter (-) lead to ground G185</li> <li>Meter reads 12V?</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 1 of connector G194 and ground G185</p> <p>Repair ground G185</p>
<b>E8</b>	<b>FUSE CHECK</b>		
<ul style="list-style-type: none"> <li>Check fuse F8 (7.5 A) in fuse box G1</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Go to step E9</p> <p>Replace fuse F8</p>
<b>E9</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>Connect: <ul style="list-style-type: none"> <li>voltmeter (-) lead to known good ground</li> <li>voltmeter (+) lead to pin 86 of relay I25</li> </ul> </li> <li>Meter reads 12V?</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Go to step E10</p> <p>Repair wiring between pin 86 of relay I25 and pin 2B of fuse box G1</p>
<b>E10</b>	<b>VOLTAGE CHECK</b>		
<ul style="list-style-type: none"> <li>Move voltmeter (-) lead to pin 85 of relay I25</li> <li>Meter reads 12V?</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Go to step E13</p> <p>Go to step E11</p>

(Cont.d)

## REAR FOG LAMP INOPERATIVE

## TEST E

TEST STEPS		RESULTS	REMEDY
<b>E11</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (-) lead to <b>pin 15</b> of automatic control mode check unit <b>Q21A</b> Meter reads 12V?		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	<p>Go to step E12</p> <p>Failure of the air conditioning system, refer to the relevant troubleshooting procedure</p>
<b>E12</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 9</b> of connector <b>G164</b> Meter reads 12V?		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	<p>Repair wiring between <b>pin 9</b> of connector <b>G164</b> and <b>pin 1B</b> of fuse box <b>G1</b></p> <p>Repair wiring between <b>pin 9</b> of connector <b>G164</b> and <b>pin 15</b> of control unit <b>Q21A</b></p>
<b>E13</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 1N</b> of fuse box <b>G1</b> Meter reads 12V?		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div> <div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	<p>Go to step E14</p> <p>Repair wiring between <b>pin 1N</b> and <b>2N</b> of fuse box <b>G1</b></p>

(Cont.d)

## REAR FOG LAMP INOPERATIVE





## TEST E

TEST STEPS		RESULTS	REMEDY
<b>E14</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 87b of relay I25 Meter reads 12V?		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Go to step E15
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Replace relay I25
<b>E15</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 8G of fuse box G1 Meter reads 12V?		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Go to step E16
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between pin 8G and 3B of fuse box G1
<b>E16</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (-) lead to pin 12A of fuse box G1 Meter reads 12V?		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between pin 12A and 11D of fuse box G1
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between pin 11A and 12A of fuse box G1

End of test E

## FRONT FOG LAMPS WARNING LAMP ON INSTRUMENT PANEL INOPERATIVE

TEST F

TEST STEPS	RESULTS	REMEDY
NOTE: Turn ignition key to "run" position.		
F1 VOLTAGE CHECK		
- Connect: <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to pin 4B of instrument panel C10</li> </ul> Meter reads 12V?	 	Replace instrument panel C10  Go to step F2
F2 VOLTAGE CHECK		
- Move voltmeter (+) lead to pin 6C of fuse box G1 Meter reads 12V?	 	Repair wiring between pin 4B of instrument panel C10 and pin 6C of fuse box G1  Replace fuse box G1

End of test F

**REAR FOG LAMP WARNING LAMP ON INSTRUMENT PANEL INOPERATIVE**
**TEST G**

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Turn ignition key to "run" position. Before carrying out any troubleshooting check</p>			
<b>G1</b>	<b>VOLTAGE CHECK</b>		
<p>- Connect:</p> <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to pin 5B of instrument panel C10</li> </ul> <p>Meter reads 12V?</p>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Replace instrument panel C10</p> <p>Go to step G2</p>
<b>G2</b>	<b>VOLTAGE CHECK</b>		
<p>- Move voltmeter (+) lead to pin 5C of fuse box G1</p> <p>Meter reads 12V?</p>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 5B of instrument panel C10 and pin 5C of fuse box G1</p> <p>Replace fuse box G1</p>

**End of test G**

# LAMPS - - LOW BEAM AND HIGH BEAM





## GENERAL

When the ignition key is in "run" position the low beam lamps turned on and the high beam lamps can be turned on with the multiple switch **B4** (refer to the position lamps circuit for further details).

The low beam and high beam lamps are controlled by the PARKING/FLASH/LOW BEAM/HIGH BEAM switch **B4**. The system is protected by five fuses in the fuse box **G1**, as follows:

- Fuse **F2** (7,5A) POSITION LAMPS.
- Fuse **F3** (10A) R.H. LOW BEAM.
- Fuse **F4** (10A) L.H. LOW BEAM AND WARN. LAMP.
- Fuse **F5** (10A) R.H. HIGH BEAM AND WARN. LAMP.
- Fuse **F6** (10A) L.H. HIGH BEAM.

## OPERATIONAL DESCRIPTION

12V from the battery are applied to high beam lamps relay **I50**, **I66**, **I67** and to multiple switch **B4** (pin 2A) when the ignition key is in "run" position.

The multiple switch **B4** controls illumination of various lamps, as determined by the setting of the switch.

With the ignition key in "run" position, and the low/high beam selector set to low beam, 12V are applied to fuses **F2**, **F3** and **F4** through contacts of switch **B4**.

Power supply from fuses **F3** and **F4** is also applied to the low beam indicator lamp on the instrument panel, and to the coil of low beam lamps relays **I49**. 12V from the battery are applied to the head lamp units **E23** and **E24** through the relay contacts, and the low beam lamps are turned on.

### NOTE

The low beam lamps and circuit are also protected by the 10A fuses of the low beam lamps relays.

Pushing the low/high beam selector in the "high beam" position, 12V are applied to coil of high beam lamps relay **I50** through contacts of switch **B4**.

12V from the battery are applied to the head lamp units **E23** and **E24** through the relay **I50** contacts and fuses **F5** and **F6**, and the high beam lamps are turned on.

Fuse **F5** also energizes the high beam indicator lamp on the instrument panel.

The multiple switch **B4** is provided with additional momentary position contacts.











Pulling the low/high beam selector lever the flash contacts close, and momentarily energize the high beam lamp relay **I50**, with consequent flashing of the relevant lamps.

TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT															
	FUSE E2	FUSE E3	FUSE E4	FUSE E5	FUSE E6	RELAY FUSE SX 149	RELAY FUSE DX 149	FRONT RIGHT OPTICAL UNIT E23	FRONT LEFT OPTICAL UNIT E24	MULTIPLE SWITCH B4	RELAY SX 149	RELAY DX 149	RELAY 150	RELAY 166	RELAY 167	FUSE BOX G1
BOTH LOW BEAM LAMPS INOPERATIVE	•							•	•					•	•	•
LEFT LOW BEAM LAMP INOPERATIVE			•			•		•			•					•
RIGHT LOW BEAM LAMP INOPERATIVE		•					•	•				•				•
BOTH HIGH BEAM LAMPS INOPERATIVE										•			•			•
LEFT HIGH BEAM LAMP INOPERATIVE					•			•								•
RIGHT HIGH BEAM LAMP INOPERATIVE				•			•									•


<p>Parking/Flash/Low beam/High beam switch <b>(B4) (A)</b></p> <p>1GRN-BLK (150) 1PNK (G1) (D) 1.5PNK (G1) (O)</p>	<p>Parking/Flash/Low beam/High beam switch <b>(B4) (D)</b></p> <p>1LTBLU-WHT (G23B) NM1 PIN 5 1.5GRY (G1) (C)</p>
<p>Instrument panel <b>(C10) (A)</b></p> <p>GRN-BLK (G1) (C)</p>	<p>Instrument panel <b>(C10) (C)</b></p> <p>GRY-BLK (G1) (H)</p>
<p>Front head lamp-right <b>(E23) (B)</b></p> <p>1.5BLK (G53B) 1.5GRY (149) 1.5GRN (G14B)</p>	<p>Front head lamp-left <b>(E24) (B)</b></p> <p>1.5BLK (G53B) 1.5GRY-BLK (149) 1.5GRN-BLK (G150)</p>
<p>Fuse box <b>(G1) (C)</b></p> <p>GRN-BLK (C10) (A)</p>	<p>Fuse box <b>(G1) (D)</b></p> <p>1PNK (G23B) 1PNK (B4) (A) 1PNK</p>
<p>Fuse box <b>(G1) (G)</b></p> <p>1.5GRN (150) 1.5GRY (B4) (D) 1.5YEL-BLK (NM1)</p>	<p>Fuse box <b>(G1) (H)</b></p> <p>1.5GRN-BLK (G150) GRY-BLK (C10) (C) 1GRY-BLK (G150)</p>
<p>Fuse box <b>(G1) (I)</b></p> <p>1.5GRN (G149) 1GRY (G149)</p>	<p>Fuse box <b>(G1) (N)</b></p> <p>1.5RED (150) 4RED (HOT AT ALL TIMES) 1.5RED (150)</p>

(Cont.d)

<p>Fuse box</p>	<p>G10</p>	<p>Engine compartment right side ground connection</p>	<p>G53a</p>
			
		<p>Engine compartment left side ground connection</p>	<p>G53b</p>
			
<p>Connector, circuit board to engine compartment right side wiring</p>	<p>G149</p>	<p>Connector, circuit board to engine compartment left side wiring</p>	<p>G150</p>
			
<p>Steering wheel column support ground</p>	<p>G174</p>	<p>Terminal strip wiring connection with day lights wiring</p>	<p>G238</p>
			
<p>Horn relay</p>	<p>I3</p>		
<p>Low beam lamps relay (left)</p>	<p>I49</p>	<p>Low beam lamps relay (right)</p>	<p>I49</p>
			









(Cont.d)

<p>High beam lamps relay</p>	<p>150</p>	<p>Day lights on relay switch</p>	<p>166</p>
<p>1BLK= G176 85 1.5GRN= G1 87 1.5RED= G1 30 1GRN-BLK= B4 86</p>		<p>1BLK= 167 86 1.5YEL-BLK= N41 87 1.5RED= G238 30 1WHT= 167 85 1GRY= G238 87a</p>	
<p>Day lights off relay switch</p>	<p>167</p>	<p>Parking lamps control unit</p>	<p>N41</p>
<p>1BLK= 166 85 1WHT= 166 87 1.5RED= G238 30 1LTBLU-WHT= G238 86</p>		<p>1.5RED= G238 30 (2) 1.5YEL-BLK= G1 L (R) 1.5YEL-BLK= G238 L (L)</p>	



## BOTH LOW BEAM LAMPS INOPERATIVE

## TEST A







TEST STEPS		RESULTS	REMEDY
<b>NOTE:</b> Turn ignition key to "run" position.			
<b>A1</b>	<b>FUSE CHECK</b>		
- Check fuse F2 (7.5A) in fuse box G1		 	Go to step A2  Replace fuse F2
<b>A2</b>	<b>VOLTAGE CHECK</b>		
- Connect : <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to pin 87a of relay I67</li> </ul> Meter reads 12V?		 	Go to step A7  Go to step A3
<b>A3</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 30 of relay I67 Meter reads 12V?		 	Replace relay I67  Go to step A4
<b>A4</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 5 of connector G238 Meter reads 12V?		 	Repair wiring between pin 5 of connector G238 and pin 30 of relay I67  Go to step A5

(Cont.d)



BOTH LOW BEAM LAMPS INOPERATIVE

TEST A

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to 2A of multiple switch B4 Meter reads 12V?		 	Repair wiring between <b>pin 2A of switch B4</b> and <b>pin 5 of connector G238</b>  Go to step A6
<b>A6</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 40 of fuse box G1 Meter reads 12V?		 	Repair wiring between <b>pin 40 of fuse box G1</b> and <b>pin 2A of multiple switch B4</b>  Failure of the <b>power distribution circuit</b> , refer to the relevant <b>circuit of sheet 2 of 2</b>
<b>A7</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 86 of relay I66 Meter reads 12V?		 	Go to step A8  Repair wiring between <b>pin 86 of relay I66</b> and <b>pin 87a of relay I67</b>

BOTH LOW BEAM LAMPS INOPERATIVE	<b>TEST A</b>
---------------------------------	---------------

TEST STEPS		RESULTS	REMEDY
<b>A8</b>	<b>VOLTAGE CHECK</b>		
	- Move voltmeter (-) lead to pin 85 of relay I66 Meter reads 12V?	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Go to step A11
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Go to step A9
<b>A9</b>	<b>VOLTAGE CHECK</b>		
	- Move voltmeter (-) lead to pin 1 of connector G238 Meter reads 12V?	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between pin 1 of connector G238 and pin 85 of relay I66
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Go to step A10
<b>A10</b>	<b>VOLTAGE CHECK</b>		
	- Move voltmeter (-) lead to ground G174 Meter reads 12V?	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Repair wiring between pin 1 of connector G238 and ground G174
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Repair ground G174
<b>A11</b>	<b>VOLTAGE CHECK</b>		
	- Move voltmeter (+) lead to pin 87 of relay I66 Meter reads 12V?	<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;">OK</div> <div style="font-size: 2em;">▶</div> </div>	Go to step A15
		<div style="display: flex; align-items: center; gap: 10px;"> <div style="text-align: center;"><del>OK</del></div> <div style="font-size: 2em;">▶</div> </div>	Go to step A12

(Cont.d)

BOTH LOW BEAM LAMPS INOPERATIVE













TEST A

TEST STEPS		RESULTS	REMEDY
<b>A12</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 6 of control unit N41 Meter reads 12V?		OK ►	Repair wiring between pin 6 of control unit N41 and pin 87 of relay I66
		<del>OK</del> ►	Go to step A13
<b>A13</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 3G of fuse box G1 Meter reads 12V?		OK ►	Repair wiring between pin 3G of fuse box G1 and pin 6 of control unit N41
		<del>OK</del> ►	Go to step A14
<b>A14</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 4D of fuse box G1 Meter reads 12V?		OK ►	Replace fuse box G1
		<del>OK</del> ►	Repair wiring between pin 4D of fuse box G1 and pin 2A of multiple switch B4
<b>A15</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 30 of relay I66 Meter reads 12V?		OK ►	Go to step A17
		<del>OK</del> ►	Go to step A16

(Cont.d)

## BOTH LOW BEAM LAMPS INOPERATIVE

## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A16</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 4</b> of connector <b>G238</b> Meter reads 12V?		 	Repair wiring between <b>pin 4</b> of connector <b>G238</b> and <b>pin 30</b> of relay <b>I66</b>
		 	Repair wiring between <b>pin 4</b> of connector <b>G238</b> and <b>pin 2</b> of control unit <b>N41</b>
<b>A17</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 87a</b> of relay <b>I66</b> Meter reads 12V?		 	Go to <b>step A18</b>
		 	Replace relay <b>I66</b>
<b>A18</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 3</b> of connector <b>G238</b> Meter reads 12V?		 	Repair wiring between <b>pin 3</b> of connector <b>G238</b> and <b>pin 6G</b> of fuse box <b>G1</b>
		 	Repair wiring between <b>pin 3</b> of connector <b>G238</b> and <b>pin 87a</b> of relay <b>I66</b>

End of test A

## LEFT LOW BEAM LAMP INOPERATIVE









## TEST B

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> Turn ignition key to "run" position. Before carrying-out any troubleshooting procedure, check the integrity of warning lamp on instrument panel by pressing the test button.</p>		
<b>B1</b> INDICATOR LAMP CHECK		
<ul style="list-style-type: none"> <li>- Check if low beam indicator lamp on instrument panel is illuminated</li> </ul>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div> </div>	<p>Go to step B4</p> <p>Go to step B2</p>
<b>B2</b> FUSE CHECK		
<ul style="list-style-type: none"> <li>- Check fuse F4 (10A) in fuse box G1</li> </ul>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div> </div>	<p>Go to step B3</p> <p>Replace fuse F4</p>
<b>B3</b> VOLTAGE CHECK		
<ul style="list-style-type: none"> <li>- Connect :             <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to pin 9C of instrument panel C10</li> </ul> </li> <li>Meter reads 12V?</li> </ul>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;">OK</div> <div style="margin: 0 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; text-align: center;"><del>OK</del></div> <div style="margin: 0 10px;">▶</div> </div> </div>	<p>Replace low beam indicator lamp on instrument panel C10</p> <p>Repair wiring between pin 9C of instrument panel C10 and pin 4H of fuse box G1</p>

(Cont.d)

## LEFT LOW BEAM LAMP INOPERATIVE

## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B4</b>	<b>FUSE CHECK</b>		
- Check fuse of low beam lamp relay I49		 ►  ►	Go to step B5  Replace relay I49 fuse
<b>B5</b>	<b>LAMP CHECK</b>		
- Check low/high beam lamp in head lamp E24		 ►  ►	Go to step B6  Replace lamp E24
<b>B6</b>	<b>VOLTAGE CHECK</b>		
- Connect : <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to pin 14 of connector G150</li> </ul> Meter reads 12V?		 ►  ►	Go to step B7  Repair wiring between pin 14 of connector G150 and pin 4H of fuse box G1
<b>B7</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 86 of relay I49 Meter reads 12V?		 ►  ►	Go to step B8  Repair wiring between pin 86 of relay I49 and pin 14 of connector G150

(Cont.d)

## LEFT LOW BEAM LAMP INOPERATIVE





## TEST B

TEST STEPS		RESULTS	REMEDY
<b>B8</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (-) lead to pin 85 of relay I49 Meter reads 12V?		OK ►	Go to step B10
		<del>OK</del> ►	Go to step B9
<b>B9</b>	<b>GROUNDING CHECK</b>		
- Move voltmeter (-) lead to ground G53b Meter reads 12V?		OK ►	Repair wiring between ground G53b and pin 85 of relay I49
		<del>OK</del> ►	Repair ground G53b
<b>B10</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 30 of relay I49 Meter reads 12V?		OK ►	Go to step B11
		<del>OK</del> ►	Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>B11</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 87 of relay I49 Meter reads 12V?		OK ►	Go to step B12
		<del>OK</del> ►	Replace relay I49

(Cont.d)

## LEFT LOW BEAM LAMP INOPERATIVE

## TEST B

















TEST STEPS		RESULTS	REMEDY
<b>B12</b>	<b>VOLTAGE CHECK</b>		
Move voltmeter (+) lead to pin 2B of lamp E24 Meter reads 12V?		 ►  ►	Go to step B13  Repair wiring between <b>pin 2B of lamp E24</b> <b>and pin 87 of relay I49</b>
<b>B13</b>	<b>GROUNDING CHECK</b>		
- Move voltmeter (-) lead to ground G53b Meter reads 12V?		 ►  ►	Repair wiring between <b>pin 3B of lamp E24</b> <b>and ground G53b</b>  Repair ground G53b

End of test B



## RIGHT LOW BEAM LAMP INOPERATIVE









## TEST C

TEST STEPS		RESULTS	REMEDY
NOTE: Turn ignition key set to "run" position.			
<b>C1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>F3</b> (10A) in fuse box <b>G1</b>		 	Go to <b>step C2</b>
		 	Replace fuse <b>F3</b>
<b>C2</b>	<b>RELAY FUSE CHECK</b>		
- Check fuse of low beam lamp relay <b>I49</b>		 	Go to <b>step C3</b>
		 	Replace relay <b>I49</b> fuse
<b>C3</b>	<b>LAMP CHECK</b>		
- Check low/high beam lamp in head lamp <b>E23</b> for integrity		 	Go to <b>step C4</b>
		 	Replace lamp <b>E23</b>
<b>C4</b>	<b>VOLTAGE CHECK</b>		
- Connect :		 	Go to <b>step C5</b>
<ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to pin 14 of connector <b>G149</b></li> </ul> Meter reads 12V?		 	Repair wiring between pin 14 of connector <b>G149</b> and pin 31 of fuse box <b>G1</b>

(Cont.d)

## RIGHT LOW BEAM LAMP INOPERATIVE







## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C5</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 85 of relay I49 Meter reads 12V?		 ▶  ▶	Go to step C6  Repair wiring between <b>pin 85 of relay I49 and            pin 14 of connector            G149</b>
<b>C6</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (-) lead to pin 85 of relay I49 Meter reads 12V?		 ▶  ▶	Go to step C8  Go to step C7
<b>C7</b>	<b>GROUNDING CHECK</b>		
- Move voltmeter (-) lead to ground G53a Meter reads 12V?		 ▶  ▶	Repair wiring between <b>pin 85 of relay I49 and            ground G53a</b>  Repair ground G53a
<b>C8</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 30 of relay I49 Meter reads 12V?		 ▶  ▶	Go to step C9  Failure of power dis- tribution circuit, refer <b>to the relevant circuit            of sheet 2 of 2</b>

(Cont.d)

## RIGHT LOW BEAM LAMP INOPERATIVE

## TEST C

TEST STEPS		RESULTS	REMEDY
<b>C9</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 87</b> of relay <b>I49</b> Meter reads 12V?		 	Go to step <b>C10</b>  Replace relay <b>I49</b>
<b>C10</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 2B</b> of lamp <b>E23</b> Meter reads 12V?		 	Go to step <b>C11</b>  Repair wiring between <b>pin 2B</b> of lamp <b>E23</b> and <b>pin 87</b> of relay <b>I49</b>
<b>C11</b>	<b>GROUNDING CHECK</b>		
- Move voltmeter (-) lead to ground <b>G53a</b> Meter reads 12V?		 	Repair wiring between <b>pin 3B</b> of lamp <b>E23</b> and ground <b>G53a</b>  Repair ground <b>G53a</b>

End of test C

<b>BOTH HIGH BEAM LAMPS INOPERATIVE</b>	<b>TEST D</b>
---	---------------

TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Turn ignition key to "run" position and multiple switch to high beam for remainder of test D.</p>			
<b>D1</b>	<b>VOLTAGE CHECK</b>		
<p>- Connect :</p> <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to pin 86 of relay I50</li> </ul> <p>Meter reads 12V?</p>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Go to step D6</p> <p>Go to step D2</p>
<b>D2</b>	<b>VOLTAGE CHECK</b>		
<p>- Move voltmeter (+) lead to pin 1A of multiple switch B4</p> <p>Meter reads 12V?</p>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 1A of switch B4 and pin 86 of relay I50</p> <p>Go to step D3</p>
<b>D3</b>	<b>VOLTAGE CHECK</b>		
<p>- Move voltmeter (+) lead to pin 2A of multiple switch B4</p> <p>Meter reads 12V?</p>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Go to step D4</p> <p>Go to step D5</p>
<b>D4</b>	<b>GROUNDING CHECK</b>		
<p>- Move voltmeter (-) lead to ground G174</p> <p>Meter reads 12V?</p>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Replace multiple switch B4</p> <p>Repair ground G174</p>

(Cont.d)

BOTH HIGH BEAM LAMPS INOPERATIVE

TEST D

TEST STEPS		RESULTS	REMEDY
<b>D5</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 40 of fuse box G1 Meter reads 12V?		OK ►	Repair wiring between pin 40 of fuse box G1 and pin 2A of multiple switch B4
		<del>OK</del> ►	Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>D6</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (-) lead to pin 85 of relay I50 Meter reads 12V?		OK ►	Go to step D8
		<del>OK</del> ►	Go to step D7
<b>D7</b>	<b>GROUNDING CHECK</b>		
- Move voltmeter (-) lead to ground G174 Meter reads 12V?		OK ►	Repair wiring between pin 85 of relay I50 and ground G174
		<del>OK</del> ►	Repair ground G174
<b>D8</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 30 of relay I50 Meter reads 12V?		OK ►	Go to step D10
		<del>OK</del> ►	Go to step D9

(Cont.d)

BOTH HIGH BEAM LAMPS INOPERATIVE









TEST D

TEST STEPS		RESULTS	REMEDY
<b>D9</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 2N</b> of fuse box <b>G1</b> Meter reads 12V?		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between <b>pin 30</b> of relay <b>I50</b> and <b>pin 2N</b> of fuse box <b>G1</b></p> <p>Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2</p>
<b>D10</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 87</b> of relay <b>I50</b> Meter reads 12V?		<p>OK      ►</p> <p><del>OK</del>      ►</p>	<p>Repair wiring between <b>pin 87</b> of relay <b>I50</b> and <b>pin 7G</b> of fuse box <b>G1</b></p> <p>Replace relay <b>I50</b></p>

End of test D

## LEFT HIGH BEAM LAMP INOPERATIVE

## TEST E

TEST STEPS		RESULTS	REMEDY
NOTE: Turn ignition key to "run" position and low beam lamps selected to high beam for remainder of test E.			
E1	FUSE CHECK		
- Check fuse F6 (10A) in fuse box G1		 ▶  ▶	Go to step E2  Replace fuse F6
E2	LAMP CHECK		
- Check high beam lamp in head lamp E24 for integrity		 ▶  ▶	Go to step E3  Replace lamp E24
E3	VOLTAGE CHECK		
- Connect :  • voltmeter (-) lead to known good ground • voltmeter (+) lead to pin 15 of connector G150 Meter reads 12V?		 ▶  ▶	Go to step E4  Repair wiring between pin 15 of connector G150 and pin 5H of fuse box G1
E4	VOLTAGE CHECK		
- Move voltmeter (+) lead to pin 1B of lamp E24 Meter reads 12V?		 ▶  ▶	Go to step E5  Repair wiring between pin 1B of lamp E24 and pin 15 of connector G150

(Cont.d)

<b>LEFT HIGH BEAM LAMP INOPERATIVE</b>	<b>TEST E</b>
--	---------------









TEST STEPS		RESULTS	REMEDY
<b>E5</b>	<b>GROUNDING CHECK</b>		
	- Move voltmeter (-) lead to ground <b>G53b</b> Meter reads 12V?	<div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;">OK</div> <div style="font-size: 24px; margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; border-radius: 50%; width: 30px; height: 30px; display: flex; align-items: center; justify-content: center; margin-right: 10px;"><del>OK</del></div> <div style="font-size: 24px; margin-right: 10px;">▶</div> </div>	<p>Repair wiring between <b>pin 3B of lamp E24</b> and ground <b>G53b</b></p> <p>Repair ground <b>G53b</b></p>

End of test E



## RIGHT HIGH BEAM LAMP INOPERATIVE







## TEST F

TEST STEPS		RESULTS	REMEDY
NOTE: Turn ignition key to "run" position and low beam lamps selected to high beam for remainder of test F			
<b>F1</b>	<b>INDICATOR LAMP CHECK</b>		
- Check illumination of high beam indicator lamp on instrument panel <b>C10</b>		 ►  ►	Go to step F4  Go to step F2
<b>F2</b>	<b>FUSE CHECK</b>		
- Check fuse F5 (10A) in fuse box <b>G1</b>		 ►  ►	Go to step F3  Replace fuse F5
<b>F3</b>	<b>VOLTAGE CHECK</b>		
- Connect : <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to <b>pin 2A</b> of instrument panel <b>C10</b></li> </ul> Meter reads 12V?		 ►  ►	Replace high beam lamp on instrument panel <b>C10</b>  Repair wiring between <b>pin 2A</b> of instrument panel <b>C10</b> and <b>pin 8C</b> of fuse box <b>G1</b>
<b>F4</b>	<b>LAMP CHECK</b>		
- Check high beam lamp in head lamp <b>E23</b>		 ►  ►	Go to step F5  Replace lamp <b>E23</b>

(Cont.d)


## RIGHT HIGH BEAM LAMP INOPERATIVE

## TEST F

TEST STEPS		RESULTS	REMEDY
<b>F5</b>	<b>VOLTAGE CHECK</b>		
- Connect: <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to pin 15 of connector G149</li> </ul> Meter reads 12V?		 	Go to step F6  Repair wiring between pin 15 of connector G149 and pin 8I of fuse box G1
<b>F6</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 1B of lamp E23 Meter reads 12V?		 	Go to step F7  Repair wiring between pin 1B of lamp E23 and pin 15 of connector G150
<b>F7</b>	<b>GROUNDING CHECK</b>		
- Move voltmeter (-) lead to ground G53a Meter reads 12V?		 	Repair wiring between pin 3B of lamp E23 and ground G53a  Repair ground G53a

End of test F

LAMPS - - POSITION, SIDE  
MARKER, LICENSE PLATE  
ILLUMINATION



## GENERAL

The position, license and side marker lamps can be activated by the air conditioning pushbutton panel, or through the multiple switch. When the vehicle is running, activation is controlled by the multiple switch. When the ignition key is set to park position, the lamps can be activated by pressing the relevant button on the air conditioning pushbutton panel. When either switch is activated, simultaneous illumination of the four position lamps (two on the front and two on the rear), four side marker lamps (two on the front and two on the rear) and of the two license lamps is obtained. Furthermore, the instrument panel and pushbutton panel lighting will turn on as well as all different silk-screen printings of the vehicle; lighting of the instrument panel and pushbutton panel can be dimmed through a reostat, to allow proper reading of instruments and controls regardless of exterior lighting. Rotation of the reostat completely upwards will turn off the instrument panel lighting. The system is protected by three fuses in the fuse box G1, as follows:

- Fuse F1 (7.5A) R.H. FRONT, L.H. REAR POSITION LAMPS AND LICENSE PLATE LAMPS.
- Fuse F2 (7.5A) R.H. FRONT L.H. REAR POSITION LAMPS.

- Fuse F11 (7.5A) POSITION LAMPS

## OPERATIONAL DESCRIPTION - LEFT FRONT AND RIGHT REAR POSITION AND SIDE MARKER LAMPS

With the ignition key set to "run" position, the battery power is supplied to the parking lamps control unit N41 through the fuse F11 in fuse box G1; furthermore, 12V are applied to the multiple switch B4 after "bridging" on fuse box G1.

Control unit N41 activates illumination of the position lamps (12V at pin 6) when either the multiple switch or the relevant button on the pushbutton panel is actuated.

Electric power output from pin 6 of control unit N41 is applied to fuses F1 and F2 of fuse box G1.

Fuse F2 protects the power supply lines of position lamps in the front head lamp left E24 and tail lamp right (fixed part) E25, of front side marker lamp E4 and rear side marker lamp E12 and of instrument panel C10 lighting.

The power supply line protected by fuse F2 is also connected to dimmer switch B16 dimming the instrument panel illumination lamp F12 and pushbutton panel B66.

Instrument panel illumination lamp F12 and pushbutton panel B66 can be turned off by rotating dimmer switch B16 completely upwards.

## TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT												
	F2 FUSE	E11 FUSE	E4 L.H. FRONT SIDE MARKER	E12 R.H. REAR SIDE MARKER	E24 L.H. HEAD LAMP UNIT	E25 L.H. TAIL LAMP UNIT	F12 INSTR. PNL LIGHTING	B4 MULTIPLE SWITCH	B16 DIMMER SWITCH	B66 PUSHBUTTON PANEL	B66 PUSHBUTTON PANEL LIGHT	N41 CONTROL UNIT	G1 FUSE BOX
ALL LAMPS INOPERATIVE WITH CONTROL SWITCH ACTUATED		•						•		•		•	•
LEFT FRONT POSITION AND SIDE MARKER LAMPS INOPERATIVE	•		•		•			•		•			•
RIGHT REAR POSITION AND SIDE MARKER LAMPS INOPERATIVE	•			•		•		•		•			•
LEFT FRONT POSITION LAMP INOPERATIVE	•				•			•		•			•
LEFT FRONT SIDE MARKER LAMP INOPERATIVE	•		•					•		•			•
RIGHT REAR POSITION LAMP INOPERATIVE	•					•		•		•			•
PUSHBUTTON PANEL LIGHTING INOPERATIVE	•	•						•	•	•	•		•
INSTRUMENT PANEL LIGHTING INOPERATIVE	•	•				•		•					•
TEST PUSHBUTTON AND RHEOSTAT SERIGRAPHS LIGHTING INOPERATIVE	•					•	•	•	•	•			•

**NOTE:** Before carrying-out any troubleshooting, check the integrity of warning lamp on instrument panel by pressing the test button.





## **OPERATIONAL DESCRIPTION - RIGHT FRONT AND LEFT REAR PO- SITION LAMPS AND SIDE MARKER LAMPS, LICENSE PLATE LAMP**

With the ignition key set to "run" position, the battery power is supplied to the parking lamps control unit N41 through the fuse F11 in fuse box G1; furthermore, 12V are applied to the multiple switch B4 after "bridging" on fuse box G1. Control unit N41 activates illumination of the position lamps (12V at pin 6) when either the multiple

switch or the relevant button on the pushbutton panel is actuated.

Electric power output from pin 6 of control unit N41 is applied to fuses F1 of fuse box G1.

Fuse F1 protects the power supply lines of position lamps in the front head lamp right E23 and tail lamp left E26, of license plate lamp E4 and rear side marker E12.













The power supply line protected by fuse F1 is also connected to a circuit that monitors the illumination of position lamps indicator on the instrument panel C10 and serigraphs on the automatic air conditioning controls.



## TROUBLESHOOTING TABLE

FAULT TYPE	FAILED COMPONENT										
	E1 FUSE	E11 FUSE	E4 R.H. FRONT SIDE MARKER	E12 L.H. REAR SIDE MARKER	E23 R.H. HEAD LAMP UNIT	E26 L.H. TAIL LAMP UNIT	E27 LICENSE LAMP	B4 MULTIPLE SWITCH	B66 PUSHBUTTON PANEL	C10 INSTR. PANEL INDICATOR	G1 FUSE BOX
RIGHT FRONT POSITION AND SIDE MARKER LAMPS INOPERATIVE	•	•	•		•			•	•		•
LEFT REAR POSITION AND SIDE MARKER LAMPS AND LICENSE PLATE LAMP INOPERATIVE	•	•		•		•	•	•	•		•
RIGHT FRONT POSITION LAMP INOPERATIVE	•				•			•	•		•
RIGHT FRONT SIDE MARKER LAMP INOPERATIVE	•		•					•	•		•
LICENSE PLATE LAMP INOPERATIVE	•						•	•	•		•
LEFT REAR POSITION LAMP INOPERATIVE	•							•	•		•
RIGHT REAR SIDE MARKER LAMP INOPERATIVE	•			•				•	•		•
POSITION LAMPS INDICATOR ON INSTRUMENT PANEL INOPERATIVE	•									•	•


**NOTE:** Before carrying-out any troubleshooting, check the integrity of warning lamp on instrument panel by pressing the test button.

<p>Ignition/switch</p>	<p>B1</p>	<p>Parking/Flash/Low beam/High beam switch</p>	<p>B4 A</p>
			
<p>Parking/Flash/Low beam/High beam switch</p>	<p>B4 D</p>	<p>Dimmer switch, instrument panel illumination lamps</p>	<p>B16</p>
			
<p>Position lights/Hazard lights/Fuel filler lid pushbutton panel</p>	<p>B66</p>	<p>Instrument panel</p>	<p>C10 C</p>
			
<p>Front side marker lamp (right)</p>	<p>E4</p>	<p>Front side marker lamp (left)</p>	<p>E4</p>
			
<p>Right front fog lamp</p>	<p>E10</p>	<p>Left front fog lamp</p>	<p>E10</p>
			
<p>Rear side marker lamp (right)</p>	<p>E12</p>	<p>Rear side marker lamp (left)</p>	<p>E12</p>
			

(Cont.d)


Front head lamp - right

**E23** **A**




Front head lamp - left

**E24** **A**




Tail lamp, right (fixed part)

**E25**




Tail lamp, left (fixed part)

**E26**




Central tail lamps (mobile)

**E27**



Instrument panel illumination lamp













**F12**



(Cont.d)


<p>Fuse box <span style="float: right;">(G1) A</span></p>	<p>Fuse box <span style="float: right;">(G1) B</span></p>
<p>Fuse box <span style="float: right;">(G1) C</span></p>	<p>Fuse box <span style="float: right;">(G1) D</span></p>
<p>Fuse box <span style="float: right;">(G1) E</span></p>	<p>Fuse box <span style="float: right;">(G1) G</span></p>
<p>Fuse box <span style="float: right;">(G1) H</span></p>	<p>Fuse box <span style="float: right;">(G1) L</span></p>
<p>Fuse box <span style="float: right;">(G1) O</span></p>	<p>Fuse box <span style="float: right;">(G1) S</span></p> <p>Engine compartment right side ground connection <span style="float: right;">G53a</span></p>

(Cont.d)

<p>Engine compartment left side ground connection</p>	<p><b>G53b</b></p>	<p>Connector, circuit board to engine compartment right side wiring</p>	<p><b>G149</b></p>
			
<p>Connector, circuit board to engine compartment left side wiring</p>	<p><b>G150</b></p>	<p>Connector, door utilities to air conditioning wiring</p>	<p><b>G165</b></p>
			
<p>Connector, circuit board to right rear wiring</p>	<p><b>G170</b></p>	<p>Connector, circuit board to left rear wiring</p>	<p><b>G171</b></p>
			
<p>Steering wheel column support ground</p>	<p><b>G174</b></p>	<p>Trunk left side ground</p>	<p><b>G185</b></p>
			
<p>Trunk right side ground</p>	<p><b>G186</b></p>	<p>Splice in left rear wiring</p>	<p><b>G187</b></p>
			
<p>Splice in right rear wiring</p>	<p><b>G188</b></p>	<p>Connector, left rear wiring to rear central lamp wiring</p>	<p><b>G194</b></p>
			









(Cont.d)

<p>Starter motor inhibitor relay</p>	<p>I10</p>	<p>Rear window lifts relay</p>	<p>I13</p>
<p>Head lamps washer pump relay</p>	<p>I19</p>	<p>Low beam lamps relay (right)</p>	<p>I49</p>
<p>Low beam lamps relay (left)</p>	<p>I49</p>	<p>Parking lamps control unit</p> <p style="text-align: right;"><b>N41</b></p>	



## ALL LAMPS INOPERATIVE WITH CONTROL SWITCH ACTUATED

## TEST A









TEST STEPS		RESULTS	REMEDY
<b>A1</b>	<b>FUSE CHECK</b>		
- Check fuse <b>F11</b> (7.5A) in fuse box <b>G1</b>		 ►  ►	Go to step <b>A2</b>  Replace fuse <b>F11</b>
<b>A2</b>	<b>VOLTAGE CHECK</b>		
- Connect: <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to <b>pin 2A</b> of multiple switch <b>B4</b></li> </ul> Meter reads 12V?		 ►  ►	Go to step <b>A4</b>  Go to step <b>A3</b>
<b>A3</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 40</b> of fuse box <b>G1</b> Meter reads 12V?		 ►  ►	Repair wiring between <b>pin 40</b> of fuse box <b>G1</b> and <b>pin 2A</b> of multiple switch <b>B4</b>  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>A4</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (-) lead to <b>pin 2</b> of pushbutton panel <b>B66</b> Meter reads 12V?		 ►  ►	Go to step <b>A8</b>  Go to step <b>A5</b>

(Cont.d)



ALL LAMPS INOPERATIVE WITH CONTROL SWITCH ACTUATED









TEST A

TEST STEPS		RESULTS	REMEDY
<b>A5</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (-) lead to <b>pin 6</b> of pushbutton panel <b>B66</b> Meter reads 12V?		 	Replace pushbutton panel <b>B66</b>  Go to step <b>A6</b>
<b>A6</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (-) lead to <b>pin 1</b> of control unit <b>N41</b> Meter reads 12V?		 	Repair wiring between <b>pin 6</b> of pushbutton panel <b>B66</b> and <b>pin 1</b> of control unit <b>N41</b>  Go to step <b>A7</b>
<b>A7</b>	<b>GROUNDING CHECK</b>		
- Move voltmeter (-) lead to ground <b>G174</b> Meter reads 12V?		 	Repair wiring between <b>ground G174</b> and <b>pin 1</b> of control unit <b>N41</b>  Repair ground <b>G174</b>
<b>A8</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (-) lead to <b>pin 8</b> of control unit <b>N41</b> Meter reads 12V?		 	Go to step <b>A9</b>  Repair wiring between <b>pin 2</b> of pushbutton panel <b>B66</b> and <b>pin 8</b> of control unit <b>N41</b>

(Cont.d)

## ALL LAMPS INOPERATIVE WITH CONTROL SWITCH ACTUATED



## TEST A

TEST STEPS		RESULTS	REMEDY
<b>A9</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 3D of multiple switch B4 Meter reads 12V?		 ▶  ▶	Go to step A10  Replace multiple switch B4
<b>A10</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 5 of control unit N41 Meter reads 12V?		 ▶  ▶	Go to step A11  Repair wiring between pin 5 of control unit N41 and pin 3D of multiple switch B4
<b>A11</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 2 of control unit N41 Meter reads 12V?		 ▶  ▶	Go to step A12  Failure of the power distribution circuit, refer to the relevant circuit of sheet 2 of 2
<b>A12</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin 6 of control unit N41 Meter reads 12V?		 ▶  ▶	Repair wiring between pin 6 of control unit N41 and pin 3G of fuse box G1  Replace control unit N41

End of test A

BOTH FRONT FOG LAMPS INOPERATIVE



TEST B

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> In case the failure simultaneously effects the left front and right rear position lamps, left front and right rear side marker lamps, instrument panel lighting, position lamps indicator on instrument panel and pushbutton panel lighting, replace fuse F2 in fuse box G1.</p>		
<b>B1</b> VOLTAGE CHECK		
<p>- Connect:</p> <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to pin 12 of connector G150</li> </ul> <p>Meter reads 12V?</p>	<div style="display: flex; flex-direction: column; align-items: center;"> <div style="display: flex; align-items: center; margin-bottom: 20px;"> <div style="text-align: center; margin-right: 10px;">  </div> <div style="font-size: 2em; margin-right: 10px;">▶</div> </div> <div style="display: flex; align-items: center;"> <div style="text-align: center; margin-right: 10px;">  </div> <div style="font-size: 2em; margin-right: 10px;">▶</div> </div> </div>	<p>Repair wiring between pin 12 of connector G150 and pin 3A of lamp E24</p> <p>Repair wiring between pin 12 of connector G150 and pin 10H of fuse box G1</p>

End of test B

## RIGHT FRONT POSITION AND SIDE MARKER LAMPS INOPERATIVE

## TEST C

TEST STEPS	RESULTS	REMEDY
<p><b>NOTE:</b> In case the failure simultaneously effects the left front and right rear position lamps, left front and right rear side marker lamps, instrument panel lighting, position lamps indicator on instrument panel and pushbutton panel lighting, replace fuse F1 in fuse box G1.</p>		
<p><b>C1</b> VOLTAGE CHECK</p>		
<p>- Connect:</p> <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to <b>pin 3</b> of connector G149</li> </ul> <p>Meter reads 12V?</p>	<p>OK </p> <p><del>OK</del> </p>	<p>Repair wiring between <b>pin 3</b> of connector G149 and <b>pin 3A</b> of lamp E23</p> <p>Repair wiring between <b>pin 3</b> of connector G149 and <b>pin 5D</b> of fuse box G1</p>

End of test C

## LEFT REAR POSITION AND SIDE MARKER LAMPS, AND LICENSE PLATE LAMP INOPERATIVE

## TEST D

## TEST STEPS

## RESULTS

## REMEDY

**NOTES:** - In case the failure simultaneously affects the right front and left rear position lamps, right front and left rear side marker lamps, license plate lamp and position lamps indicator on instrument panel, replace fuse F1 in fuse box G1.

- Central tail lamp E27, tail lamp right E25, tail lamp left E26, instrument panel illumination F12 and pushbutton panel B66 include each two bulbs connected in parallel. Bulbs replacement should be necessary in case only one of the two bulbs does not switch on.

## D1 VOLTAGE CHECK

- Connect:

- voltmeter (-) lead to known good ground
  - voltmeter (+) lead to pin 11 of connector G171
- Meter reads 12V?



Go to step D2

Repair wiring between pin 5D of fuse box G1 and pin 11 of connector G171

## D2 VOLTAGE CHECK

- Move voltmeter (+) lead to connector G187

Meter reads 12V?





Repair wiring between connector G187 and crimping connection

Repair wiring between connector G187 and pin 11 of connector G171

End of test D

## RIGHT REAR POSITION AND SIDE MARKER LAMP INOPERATIVE





## TEST E

TEST STEPS	RESULTS	REMEDY
<p><b>NOTES:</b> - In case the failure simultaneously affects the right front and right rear position lamps, left front and right rear side marker lamps, instrument panel, lighting position lamps indicator on instrument panel and pushbutton panel, replace fuse F2 in fuse box G1.</p> <p>- Central tail lamp E27, tail lamp right E25, tail lamp left E26, instrument panel illumination F12 and pushbutton panel B66 include each two bulbs connected in parallel. Bulbs replacement should be necessary in case only one of the two bulbs does not switch on.</p>		
<b>E1</b> VOLTAGE CHECK		
<ul style="list-style-type: none"> <li>- Connect:               <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to pin 9 of connector G170</li> </ul>               Meter reads 12V?             </li> </ul>		<p>Go to step E2</p> <p>Repair wiring between pin 4D of fuse box G1 and pin 9 of connector G170</p>
<b>E2</b> VOLTAGE CHECK		
<ul style="list-style-type: none"> <li>- Move voltmeter (+) lead to connector G188</li> </ul> Meter reads 12V?		<p>Repair wiring between connector G188 and crimping connection</p> <p>Repair wiring between connector G188 and pin 9 of connector G170</p>

End of test E

## LEFT FRONT POSITION LAMP INOPERATIVE





## TEST F

TEST STEPS		RESULTS	REMEDY
<b>F1</b>	<b>LAMP CHECK</b>		
- Check left front position lamp in head lamp E24		 	Go to step F2  Replace lamp E24
<b>F2</b>	<b>GROUNDING CHECK</b>		
- Connect: <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to pin 3A of lamp E24</li> </ul> Meter reads 12V?		 	Repair wiring between pin 1A of lamp E24 and ground G53b  Repair ground G53b

End of test F

## LEFT FRONT POSITION LAMP INOPERATIVE

TEST G





TEST STEPS		RESULTS	REMEDY
<b>G1</b>	<b>LAMP CHECK</b>		
- Check left front side marker lamp E4		 	Go to step G2  Replace lamp E4
<b>G2</b>	<b>GROUNDING CHECK</b>		
- Connect: <ul style="list-style-type: none"> <li>• voltmeter (-) lead to ground G53b</li> <li>• voltmeter (+) lead to pin A of lamp E4</li> </ul> Meter reads 12V?		 	Repair wiring between <b>pin B of lamp E4 and            ground G53b</b>  Repair ground G53b

End of test G



## RIGHT FRONT POSITION LAMP INOPERATIVE





## TEST H

TEST STEPS		RESULTS	REMEDY
H1	LAMP CHECK		
	- Check right front position lamp in head lamp E23	 	Go to step H2  Replace lamp E23
H2	GROUNDING CHECK		
	- Connect: <ul style="list-style-type: none"> <li>• voltmeter (-) lead to ground G53a</li> <li>• voltmeter (+) lead to pin 3A of lamp E23</li> </ul> Meter reads 12V?	 	Repair wiring between <b>pin 1A of lamp E23</b> <b>and ground G53a</b>  Repair ground G53a

End of test H

## RIGHT FRONT SIDE MARKER LAMP INOPERATIVE









## TEST I

TEST STEPS		RESULTS	REMEDY
11	LAMP CHECK		
	- Check right front side marker lamp E4	 	Go to step 12  Replace lamp E4
12	GROUNDING CHECK		
	- Connect: <ul style="list-style-type: none"> <li>• voltmeter (-) lead to ground G53a</li> <li>• voltmeter (+) lead to pin A of lamp E4</li> </ul> Meter reads 12V?	 	Repair wiring between pin B of lamp E4 and ground G53a  Repair ground G53a

End of test I

## LICENSE PLATE LAMP INOPERATIVE









## TEST J

TEST STEPS		RESULTS	REMEDY
J1	LAMP CHECK		
	<ul style="list-style-type: none"> <li>Check license plate lamp E27</li> </ul>	OK  <del>OK</del> 	Go to step J2  Replace lamp E27
J2	VOLTAGE CHECK		
	Connect: <ul style="list-style-type: none"> <li>voltmeter (-) lead to known good ground</li> <li>voltmeter (+) lead to pin 2 of connector G194</li> </ul> Meter reads 12V?	OK  <del>OK</del> 	Go to step J3  Repair wiring between pin 2 of connector G194 and crimping connection
J3	VOLTAGE CHECK		
	Move voltmeter (+) lead to pin 2 of lamp E27 Meter reads 12V?	OK  <del>OK</del> 	Go to step J4  Repair wiring between pin 2 of lamp E27 and pin 2 of connector G194
J4	VOLTAGE CHECK		
	Move voltmeter (-) lead to pin 1 of connector G194 Meter reads 12V?	OK  <del>OK</del> 	Repair wiring between pin 1 of G194 and pin 4 of lamp E27  Repair wiring between pin 1 of G194 and crimping connection

End of test J

## LEFT REAR POSITION LAMP INOPERATIVE

## TEST K

TEST STEPS		RESULTS	REMEDY
K1	LAMP CHECK		
	- Check left rear position lamps E26	 	Go to step K2  Replace lamps E26
K2	VOLTAGE CHECK		
	- Connect: <ul style="list-style-type: none"> <li>• voltmeter (-) lead to know good ground</li> <li>• voltmeter (+) lead to pin 3A of lamp E26</li> </ul> Meter reads 12V?	 	Go to step K3  Repair wiring between pin 3A of lamp E26 and crimping connection
K3	VOLTAGE CHECK		
	- Move voltmeter (+) lead to pin 3B of lamp E26 Meter reads 12V?	 	Go to step K4  Repair wiring between pin 3B of lamp E26 and crimping connection
K4	VOLTAGE CHECK		
	- Move voltmeter (-) lead to pin 1A of lamp E26	 	Repair wiring between pin 1B of lamp E26 and crimping connection  Repair wiring between pin 1A of E26 and crimping connection

End of test K

## RIGHT REAR SIDE MARKER LAMP INOPERATIVE









## TEST L

TEST STEPS		RESULTS	REMEDY
L1	LAMP CHECK		
	- Check right rear side marker lamp E12	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Go to step L2</p> <p>Replace lamp E12</p>
L2	VOLTAGE CHECK		
	- Connect: <ul style="list-style-type: none"> <li>voltmeter (-) lead to known good ground</li> <li>voltmeter (+) lead to pin A of lamp E12</li> </ul> Meter reads 12V?	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Go to step L3</p> <p>Repair wiring between pin A of lamp E12 and crimping connection</p>
L3	GROUNDING CHECK		
	- Move voltmeter (-) lead to ground G185 Meter reads 12V?	<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin B of lamp E12 and ground G185</p> <p>Repair ground G185</p>

End of test L

## RIGHT REAR POSITION LAMP INOPERATIVE













## TEST M

TEST STEPS		RESULTS	REMEDY
M1	LAMP CHECK		
- Check right rear position lamps E25		OK  <del>OK</del> 	Go to step M2  Replace lamp E25
M2	VOLTAGE CHECK		
- Connect: <ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to pin 3A of lamp E25</li> </ul> Meter reads 12V?		OK  <del>OK</del> 	Go to step M3  Repair wiring between pin 3A of lamp E25 and crimping connection
M3	VOLTAGE CHECK		
- Move voltmeter (+) lead to pin 3B of lamp E25 Meter reads 12V?		OK  <del>OK</del> 	Go to step M4  Repair wiring between pin 3B of E25 and crimping connection
M4	VOLTAGE CHECK		
- Move voltmeter (-) lead to pin 1A of lamp E25 Meter reads 12V?		OK  <del>OK</del> 	Repair wiring between pin 1B of lamp E25 and crimping connection  Repair wiring between pin 1A of lamp E25 and crimping connection

End of test M

## LEFT REAR SIDE MARKER LAMP INOPERATIVE







## TEST N

TEST STEPS		RESULTS	REMEDY
N1	LAMP CHECK		
- Check left rear side marker lamp E12		 	Go to step N2
		 	Replace lamp E12
N2	VOLTAGE CHECK		
- Connect:		 	Go to step N3
<ul style="list-style-type: none"> <li>• voltmeter (-) lead to known good ground</li> <li>• voltmeter (+) lead to pin A of lamp E12</li> </ul> Meter reads 12V?		 	Repair wiring between pin A of lamp E12 and crimping connection
N3	GROUNDING CHECK		
- Move voltmeter (-) lead to ground G186 Meter reads 12V?		 	Repair wiring between pin B of lamp E12 and ground G186
		 	Repair ground G186

End of test N









## POSITION LAMPS INDICATOR ON INSTRUMENT PANEL INOPERATIVE

TEST O

TEST STEPS		RESULTS	REMEDY
<p>NOTES: - Before carrying-out any troubleshooting, check the integrity of warning lamp on instrument panel by pressing the test button.</p> <p>- In case the failure simultaneously affects the right front and left rear position lamps, right front and left rear side marker lamps, license plate lamp and position lamps indicator on instrument panel, replace fuse F1 (7.5A) in fuse box G1</p>			
O1	VOLTAGE CHECK		
<p>- Connect:</p> <ul style="list-style-type: none"> <li>voltmeter (-) lead to known good ground</li> <li>voltmeter (+) lead to <b>pin 8C</b> of instrument panel C10</li> </ul> <p>Meter reads 12V?</p>		<p>OK </p> <p><del>OK</del> </p>	<p>Replace Instrument panel C10</p> <p>Go to step O2</p>
O2	VOLTAGE CHECK		
<p>- Move voltmeter (+) lead to <b>pin 2B</b> of fuse box G1</p> <p>Meter reads 12V?</p>		<p>OK </p> <p><del>OK</del> </p>	<p>Repair wiring between pin 2B of fuse box G1 and pin 8C of Instrument panel C10</p> <p>Go to step O3</p>
O3	VOLTAGE CHECK		
<p>- Move voltmeter (+) lead to <b>pin 5L</b> of fuse box G1</p> <p>Meter reads 12V?</p>		<p>OK </p> <p><del>OK</del> </p>	<p>Repair wiring between pin 5L of fuse box G1 and pin 2B of fuse box G1</p> <p>Repair wiring between pin 3L and pin 5L of fuse box G1</p>

End of test O











PUSHBUTTON PANEL LIGHTING INOPERATIVE		TEST P	
TEST STEPS		RESULTS	REMEDY
<p><b>NOTE:</b> Lighting of pushbutton panel <b>B66</b> includes two bulbs connected in parallel. In case of uneven lighting of pushbutton panel, it is necessary to replace only the burned out bulb.</p>			
<b>P1</b>	<b>LAMP CHECK</b>		
- Check pushbutton panel bulbs		 	<p>Go to step P2</p> <p>Replace pushbutton panel bulbs</p>
<b>P2</b>	<b>INSTRUMENT PANEL LIGHTING CHECK</b>		
- Check illumination of test pushbutton and instrument panel illumination lamp <b>F12</b> and of instrument panel lighting		 	<p>Go to step P3</p> <p>Replace dimmer switch <b>B16</b></p>
<b>P3</b>	<b>VOLTAGE CHECK</b>		
<p>- Connect:</p> <ul style="list-style-type: none"> <li>voltmeter (-) lead to known good ground</li> <li>voltmeter (+) lead to pin 3 of pushbutton panel <b>B66</b></li> </ul> <p>Meter reads 12V?</p>		 	<p>Go to step P4</p> <p>Repair wiring between pin 3 of pushbutton panel <b>B66</b> and pin 3L of fuse box</p>
<b>P4</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to pin + of dimmer switch <b>B16</b> Meter reads 12V?		 	<p>Go to step P5</p> <p>Repair wiring between pin 1S of fuse box <b>G1</b> and pin + of dimmer switch <b>B16</b></p>

(Cont. d)

## PUSHBUTTON PANEL LIGHTING INOPERATIVE

## TEST P

TEST STEPS		RESULTS	REMEDY
<b>P5</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 2S</b> of fuse box <b>G1</b> Meter reads 12V?		 	Go to <b>step P6</b>  Repair wiring between <b>pin U</b> of <b>dimmer switch B16</b> and <b>pin 2S</b> of fuse box <b>G1</b>
<b>P6</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (+) lead to <b>pin 1</b> of pushbutton panel <b>B66</b> Meter reads 12V?		 	Go to <b>step P7</b>  Repair wiring between <b>pin 1</b> of pushbutton panel <b>B66</b> and <b>pin 8B</b> of fuse box <b>G1</b>
<b>P7</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (-) lead to ground <b>G174</b> Meter reads 12V?		 	Go to <b>step P8</b>  Repair ground <b>G174</b>
<b>P8</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (-) lead to <b>pin 12E</b> of fuse box <b>G1</b> meter reads 12V.		 	Repair wiring between <b>pin 6S</b> of fuse box <b>G1</b> and <b>pin -</b> of <b>dimmer switch B16</b>  Repair wiring between <b>pin 12E</b> of fuse box <b>G1</b> and ground <b>G174</b>

End of test P

## INSTRUMENT PANEL LIGHTING INOPERATIVE

TEST Q

## TEST STEPS

## RESULTS

## REMEDY

**NOTE:** Lighting of pushbutton panel B66 includes two bulbs connected in parallel. In case of uneven lighting of pushbutton panel, it is necessary to replace only the burned out lamp(s).

## Q1 PUSHBUTTON PANEL LIGHTING CHECK

- Check illumination of pushbutton panel B66, of test pushbutton, and dimmer switch B16

OK



Go to step Q2

~~OK~~

Replace dimmer switch B16

## Q2 VOLTAGE CHECK

- Connect:
  - voltmeter (-) lead to known good ground
  - voltmeter (+) lead to pin 2C of instrument panel C10
- Meter reads 12V?

OK



Go to step Q3

~~OK~~

Repair wiring between pin 2C of instrument panel C10 and pin 2C of fuse box G1

## Q3 VOLTAGE CHECK

- Move voltmeter (-) lead to pin 1C of instrument panel C10
- Meter reads 12V?

OK



Replace instrument panel C10

~~OK~~

Go to step Q4

## Q4 VOLTAGE CHECK

- Move voltmeter (-) lead to pin 5E of fuse box G1
- Meter reads 12V?

OK



Repair wiring between pin 1C of fuse box G1 and pin 1C of instrument panel C10

~~OK~~

Go to step Q5

(Cont. d)

## INSTRUMENT PANEL LIGHTING INOPERATIVE

## TEST Q

TEST STEPS		RESULTS	REMEDY
Q5	VOLTAGE CHECK		
<ul style="list-style-type: none"> <li>Move voltmeter (-) lead to pin 2 of connector G165 Meter reads 12V?</li> </ul>		<p>OK ►</p> <p><del>OK</del> ►</p>	<p>Repair wiring between pin 5E of fuse box G1 and pin 2 of connector G165</p> <p>Repair wiring between pin 10E of fuse box G1 and pin 2 of connector G165</p>

End of test Q

## TEST PUSHBUTTON AND RHEOSTAT SERIGRAPHS LIGHTING INOPERATIVE

TEST R

## TEST STEPS

## RESULTS

## REMEDY

**NOTE:** Lighting of pushbutton panel B66 and rheostat serigraphs includes two bulbs connected in parallel. In case of uneven lighting of serigraphs, it is necessary to replace only the burned out lamp.

## R1 LAMP CHECK

- Check instrument panel illumination lamp

OK



Go to step R2

~~OK~~

Replace lamp F12

## R2 PUSHBUTTON PANEL LIGHTING CHECK

- Check operation of pushbutton panel B66 and instrument panel lighting

OK



Go to step R3

~~OK~~

Replace dimmer switch B16

## R3 VOLTAGE CHECK

- Connect:
  - voltmeter (-) lead to known good ground
  - voltmeter (+) lead to lamp F12A yel wires
 Meter reads 12V?

OK



Go to step R4

~~OK~~

Repair wiring between pin + of dimmer switch B16 and lamp F12A yel wires

## R4 VOLTAGE CHECK

- Move voltmeter (+) lead to lamp F12B yel wires
- Meter reads 12V?

OK



Go to step R5





~~OK~~

Repair wiring between lamp F12A yel wires and lamp F12B yel wires

(Cont. d)

## TEST PUSHBUTTON AND RHEOSTAT SERIGRAPHS INOPERATIVE

## TEST R

TEST STEPS		RESULTS	REMEDY
<b>R5</b>	<b>VOLTAGE CHECK</b>		
- Move voltmeter (-) lead to lamp F12B wht-blk wires Meter reads 12V?		 ▶	Repair wiring between lamp F12A wht-blk wires and lamp F12B wht-blk wires
		 ▶	Go to step R6
<b>R6</b>	<b>VOLTAGE CHECK</b>		
Move voltmeter (-) lead to pin U of dimmer switch B16 Meter reads 12V?		 ▶	Repair wiring between pin U of dimmer switch B16 and lamp F12A wht-blk wires
		 ▶	Replace fuse box G1

End of test R

## KEY TO ELECTRICAL COMPONENTS

Code	Description	Reference
<b>A</b>	<b>STARTING-CHARGING</b>	
A1	Battery .....	05-3
A2	Alternator .....	05-6
A5	Distributor .....	05-14
A8	Ignition coil .....	05-14
A11	Starter .....	05-9
<b>B</b>	<b>MANUAL ELECTRIC CONTROLS</b>	
B1	Ignition switch .....	40-35
B2	Windshield wiper control .....	40-44
B3	Head lamp washer/Wiper and windshield washer pump control .....	40-44
B4	Parking/Flash/Low beam/High beam switch .....	40-44
B5	Horn control switch .....	23-6
B6	Turn signal lamps switch .....	40-44
316	Dimmer switch, instrument panel illumination lamps .....	43-3
320	Door lock internal switch .....	40-40
321	Right front window lift switch .....	40-40
323	Right rear window lift switch .....	40-40/40-41
B24	Left rear window lift switch .....	40-40/40-41
B25	Rear window lift sensing switch .....	40-40
B27	Left front seat height control switch .....	40-41
B28	Left front seat back control switch .....	40-41
B29	Right front seat back control switch .....	40-41
B36	Electric external mirror control switch .....	40-33
B40	Trip odometer reset switch .....	43-3
B51	Left front seat heater control switch .....	40-41
B52	Right front seat longitudinal control switch .....	40-41
B53	Front left window automatic lift switch .....	40-40
B54	Left front seat longitudinal control switch .....	40-41
B55	Trunk opening switch .....	56-6
B56	Right rear seat adjustment control switch .....	40-41
B57	Right rear seat heater control switch .....	40-41
B58	Left rear seat adjustment control switch .....	40-41
B59	Left rear seat heater control switch .....	40-41
B60	Instrument panel warning lights test pushbutton .....	43-3
B62	Right front seat heater control switch .....	40-41
B63	Right front seat height control switch .....	40-41
B64	Cruise control OFF/RESUME switch .....	40-32

Code	Description	Reference
B66	Position lights/hazard lights/fuel filler lid pushbutton panel .....	21-37
B67	Suspension system control panel .....	21-37
B68	Multiple switch unit .....	40-44
<b>C</b>	<b>INSTRUMENTS</b>	
C10	Instrument panel .....	43-2
<b>D</b>	<b>WARNINGS LAMPS</b>	
D31	Anti-theft system Led .....	40-40
<b>E</b>	<b>EXTERIOR LIGHTS</b>	
E4	Front side marker lamp .....	40-14
E10	Fog lamp .....	40-12
E12	Rear side marker lamp .....	40-14
E23	Front head lamp-right .....	40-11
E24	Front head lamp-left .....	40-11
E25	Tail lamp, right (fixed part) .....	40-13
E26	Tail lamp, left (fixed part) .....	40-13
E27	Central tail lamps (mobile part) .....	40-13
E28	Center stop lamp (BASE and L only) .....	40-13
E28	Center stop lamp (S only) .....	40-14
<b>F</b>	<b>INTERIOR LIGHTS</b>	
F5	Rear cargo lamp .....	40-17
F7	Fuse box lamp .....	40-16
F9	Glovebox illumination lamp .....	40-16
F12	Instrument panel illumination lamp .....	43-3
F23	Feet illumination lamp, interior, right side .....	40-17
F24	Feet illumination lamp, interior, left side .....	40-17
F25	Courtesy mirror illumination lamp .....	40-15
F27	Right front door open warning lamp .....	40-15
F28	Left front door open warning lamp .....	40-15
F29	Right rear door open warning lamp .....	40-15
F30	Left rear door open warning lamp .....	40-15
F31	Right front door open ground illumination lamp .....	40-15
F32	Left front door open ground illumination lamp .....	40-15
F33	Right rear door open ground illumination lamp .....	40-15
F34	Left rear door open ground illumination lamp .....	40-15
F35	Dome lamp with cabin lighting control switch .....	40-16



Code	Description	Reference
F36	Dome lamp, control switch on right rear post .....	40-17
F37	Dome lamp, control switch on left rear post .....	40-17
F38	Gear selector illumination lamps, automatic transmission .....	40-18
<b>G</b>	<b>FUSE BOX-CONNECTORS-GROUND CONNECTIONS</b>	
G1	Fuse box	
G2	Auxiliary fuse box	
G4	Free fuse holder	
G15	Two pin connector circuit board to doors wiring	
G16	Six pin connector circuit board to doors wiring	
G27	Left rear door wiring connector	
G53	Engine compartement ground connection	
G53a	Engine compartement right side ground connection	
G53b	Engine compartement left side ground connection	
G56	Circuit board	
G100	Connector, doors to center console wiring	
G124	ABS system connector	
G125	ABS system free fuse holder	
G131	Upper cover ground connection	
G143	Central bulkhead ground	
G149	Connector, circuit board to engine compartment right side wiring	
G150	Connector, circuit board to engine compartment left side wiring	
G151	Connector, circuit board to engine utilities wiring	
G154	Connector, engine wiring to circuit board	
G155a	Connector, right hand seats adjustment wiring	
G155b	Connector, left hand seats adjustment wiring	
G156	Connector, right front door to right front door sensor wiring	
G157	Connector, left front door to left front door sensor wiring	
G158	Connector, right rear door to right rear door sensor wiring	
G159	Connector, left rear door to left rear door sensor wiring	
G160	Connector, right front door to ground illumination lamp wiring	
G161	Connector, left front door to ground illumination lamp wiring	
G164	Connector, circuit board to air conditioning wiring	
G165	Connector, door utilities to air conditioning wiring	
G166	Connector, front doors to right front door wiring	
G167	Connector, front doors to right rear wiring	
G168	Connector, front doors to left front door wiring	
G169	Connector, front doors to left rear wiring	
G170	Connector, circuit board to right rear wiring	
G171	Connector, circuit board to left rear wiring	
G174	Steering wheel column support ground	
G176	Dome ground	

<b>Code</b>	<b>Description</b>
G177	Connector, doors utilities circuit board wiring
G179	Connector, left rear wiring to dome lamp wiring
G180	Connector, left rear wiring to front doors
G181	Connector, left rear wiring to rear center console
G182	Center console ground
G183	Connector, rear center console to front right seat wiring
G184	Connector, rear center console to front left seat wiring
G185	Trunk left side ground
G186	Trunk right side ground
G187	Splice in left rear wiring
G188	Splice in right rear wiring
G189	Connector, rear seats to rear console wiring
G190	Connector, rear seats wiring
G191	Connector, left rear wiring to left rear door wiring
G192	Connector, provision for trailer stop lamps
G193	Connector, provision for radio antenna
G194	Connector, left rear wiring to rear central lamp wiring
G195	Connector, provision for left rear loudspeaker
G196	Connector, provision for right rear loudspeaker
G197	Connector, right rear wiring to right rear door wiring
G198	Connector, right rear wiring to trunk lock wiring
G199	Connector, right rear door
G200	Connector for radio headset junction box
G201	Rear window defogging fuse
G202	ABS system ground connection
G203	Connector, right rear wiring to front door wiring
G204	Front right sensor connection-ABS
G205	Front left sensor connection-ABS
G206	Rear right sensor connection-ABS
G207	Rear left sensor connection-ABS
G209	Connector, right rear wiring to rear console wiring
G210	Connector, doors wiring to rear console wiring
G217	Connector, provision for left front loudspeaker
G218	Connector, provision for right front loudspeaker
G221	Windows lift shorting box connector
G233	Connector, circuit board to automatic gear lever wiring
G238	Terminal strip wiring connection with day lights wiring
G239	Radio, Telephone fuse
G240	Front seats fuse (20 Amp.)
G241	Board wiring to anti-theft system wiring connector
G242	Board wiring to cruise control wiring connector
G243	Board wiring-aft console wiring splice
G244	Board wiring to aft console wiring two-way connector

Code	Description	Reference
G245	Rightrear wiring connector, Anti-theft system	
G246	Rear seat adjustment fuse-20A	
G247	Rear power window lifts fuse-30A	
G248	Anti-theft system wiring connector-Right rear wiring	
G249	Anti-theft system wiring connector-Console wiring	
G251	Suspension control system connector	
G252a	Connector, terminal board wiring-rear right wiring for suspension control system	
G252b	Connector, terminal board wiring-rear right wiring for suspension control system	
G252c	Connector, terminal board wiring-rear right wiring for suspension control system	
G253	Left rear wiring connector-Air conditioning wiring	
G254	Engine electric fan fuse	
G255	Air conditioning fan fuse-40A	
G256	Left rear wiring connector, Anti-theft system	
G258	Anti-theft system fuse-15A	
<b>H</b>	<b>SWITCHES</b>	
H1	Parking brake switch .....	40-19
H2	Back-up lamp switch .....	40-21
H3	Rear stop lamp switch .....	40-42/40-43
H5	Left front door open indicator jamb switch .....	40-29
H6	Right front door open indicator jamb switch .....	40-29
H7	Left rear door open indicator jamb switch .....	40-29
H8	Right rear door open indicator jamb switch .....	40-29
H9	Right front brake pad switch .....	22-13
H10	Left front brake pad switch .....	22-13
H16	Start and reverse gear inhibitor switch .....	40-21
H17	Brake fluid minimum level warning indicator switch .....	22-7
H24	Trunk illumination switch .....	40-30
H25	Glovebox illumination switch .....	40-16
H38	Right rear seat microswitch .....	66-13
H39	Left rear seat microswitch .....	66-13
H40	Right rear door for rear seats inhibitor switch .....	40-42
H41	Left rear door for rear seats inhibitor switch .....	40-42
H44	Engine compartment anti-theft system switch .....	40-43
H45a	Clutch switch for Cruise Control device .....	40-43
H45b	Brake switch for Cruise Control device .....	40-42/40-43
H46	Gear box switch for suspension control system .....	40-21
H47	Engine throttle microswitch for suspension system .....	01-14/04-28
<b>I</b>	<b>RELAYS</b>	
I1	Engine coolant electric fan relay .....	40-7

Code	Description	Reference
I2	Rear window defogging relay .....	40-10
I3	Horn relay.....	40-7
I10	Starter motor inhibitor relay .....	40-8
I13	Rear window lifts relay .....	40-8/40-9
I17	Front fog lamps relay .....	40-9
I19	Head lamps washer pump relay .....	40-7
I24	Turn signal lamps and hazard lamps relay .....	40-8
I25	Rear fog lamps relay .....	40-9
I26	Dome lamp relay .....	40-8/40-9
I28	Turn signal lamps and hazard lamps relay .....	40-8
I45	External rearview mirrors defogging relay .....	40-9
I49	Low beam lamps relay .....	40-7
I50	High beam lamps relay .....	40-8
I51	Electronic control units power supply relay .....	40-8
I52	Trunk opening relay .....	40-10
I53	Filler lid opening relay .....	40-10
I54	Right rear seat relay .....	40-9
I55	Left rear seat relay .....	40-9
I56	Rear seats relay .....	40-10
I57	ABS system electronic relay .....	22-35
I58	Sun roof/Seat heater relay .....	40-9
I62	Selected gear signal (automatic gear) relay for Motronic control unit .....	40-8
I63	Automatic transmission oil cooler fan relay .....	40-7
I66	Day lights on relay switch.....	40-9
I67	Day lights off relay switch.....	40-9
I68	Engine coolant fan supplementary relay .....	40-7
I69	Stop lamps switch relay .....	40-7
I70	Radio relay .....	40-8
I71	Suspension control system relay-20A .....	40-10
I72	Brake fluid reservoir relay .....	40-8
I73	Door lock/front electric window lift relay .....	40-9
<b>L</b>	<b>TRANSMITTERS</b>	
L2	Engine oil low pressure switch .....	01-14
L6	Radiator fan thermal switch .....	07-9
L8	Engine oil pressure transmitter .....	01-14
L9	Fuel quantity transmitter .....	40-18
L10	Engine coolant temperature sender and over-heating temperature switch .....	07-7
L12	Engine oil level sensor .....	01-87
L13	Windshield and head lamps washer fluid sensor .....	40-25
L14	Engine coolant level sensor .....	07-5
L17	Speedometer sensor .....	13-7

Code	Description	Reference
L28	Right front phonic wheel sensor .....	22-33
L29	Left front phonic wheel sensor .....	22-33
L30	Right rear phonic wheel sensor.....	22-33
L31	Left rear phonic wheel sensor .....	22-33
L38	Oil cooler thermal switch-automatic transmission .....	40-19
L39	Maximum oil temperature sensor, automatic transmission.....	40-19
L40	Steering wheel rotation angle sensor .....	21-34
L41	Oil microswitch for suspension control system .....	21-34
<b>M</b>	<b>SOLENOIDS-SOLENOID VALVES</b>	
M12	Trunk opening solenoid .....	40-30
M13	Filler lid opening solenoid .....	40-31
M14	Cruise control actuator.....	16-30
M15	Evaporation solenoid valve .....	04-21
M17	Front right shock absorber solenoid valve .....	21-31
M18	Front left shock absorber solenoid valve .....	21-31
M19	Rear right shock absorber solenoid valve.....	21-32
M20	Rear left shock absorber solenoid valve .....	21-32
<b>N</b>	<b>ELECTRONIC UNITS, INTERMITTANT RELAY, TIMERS</b>	
N11	Door lock control unit .....	43-5
N13	Hazard lamps relay .....	40-9
N22	Alfa Romeo control unit .....	43-5
N27	ABS control unit .....	43-6
N28	ABS brake fluid electric pump .....	22-33
N38	Window lift control unit .....	43-5
N39	Cruise control unit .....	43-7
N41	Parking lamps control unit .....	40-8
N44	Rear lamps control unit .....	43-8
N45	Anti-theft control unit .....	43-8
N46	Suspension system electronic control unit .....	21-33
N47	Accelerometer.....	21-33
N48	Radio Telephone control unit (pre-engineering) .....	--
N57	Diode of protection relay autoradio .....	40-8
<b>O</b>	<b>AUXILIARY EQUIPMENT</b>	
O1	Electrically heated rear window .....	75-12
O2	Hom .....	40-30
O3	Power antenna .....	40-44
O4	Radio .....	40-34



Code	Description	Reference
O6	Front cigar lighter .....	40-31
O7	Rear cigar lighter .....	40-31
O11	Syren .....	40-34
O14	Left front seat heater pad .....	40-38
O15	Right rear seat heater pad .....	40-39
O16	Left rear seat heater pad .....	40-39
O17	Right front seat heater pad .....	40-38
O18	Right electric external rearview mirror defogger .....	40-33
O19	Left electric external rearview mirror defogger .....	40-33
O22	Engine coolant electric fan supplementary resistor .....	07-11
O24	Radio Telephone (pre-engineering) .....	--
O25	Windshield defogger .....	75-9
<b>P</b>	<b>ELECTRIC MOTORS</b>	
P2	Engine coolant electric fan motor .....	07-9
P5	Left front seat adjustment motor .....	40-37
P6	Right front seat back reclining motor .....	40-37
P7	Left front seat back reclining motor .....	40-37
P8	Left electric external rearview mirror motor .....	40-33
P9	Right electric external rearview mirror motor .....	40-33
P10	Right front door locking motor .....	40-29
P11	Left front door locking motor .....	40-29
P12	Right rear door locking motor .....	40-29
P13	Left rear door locking motor .....	40-29
P14	Right front electric window lift motor .....	40-27
P15	Left front electric window lift motor .....	40-27
P16	Right rear electric window lift motor .....	40-28
P17	Left rear electric window lift motor .....	40-28
P18	Electric fuel pump .....	04-14
P19	Windshield washer electric pump .....	40-25
P20	Head lamps washer electric pump .....	40-25
P24	Sun roof motor .....	40-36
P27	Windshield wiper motor and control unit .....	40-24
P28	Right front seat longitudinal adjustment motor .....	40-36
P29	Left front seat longitudinal adjustment motor .....	40-36
P30	Right front seat adjustment motor .....	40-37
P32	Right rear seat motor .....	40-39
P33	Left rear seat motor .....	40-39
P34	Oil cooler electric fan motor-automatic transmission .....	16-24

Code	Description	Reference
<b>Q</b>	<b>HEAT/VENT/AIR CONDITIONING</b>	
Q1	Heater blower electric fan .....	80-28
Q11	Compressor electro-magnetic coupling .....	80-22
Q15	Heater blower relay .....	40-7
Q20	Min-Max pressure switch (Trinary) .....	80-23
Q21A	Automatic control mode check unit .....	43-9
Q22	Electro-magnetic coupling control relay .....	40-8
Q24	Outside air temperature sensor .....	80-26
Q25	Mixed air temperature sensor .....	80-27
Q26	Anti-frost thermostat .....	80-24
Q27	Air recirculation flap control motor .....	80-25
Q29	Air conditioning system clinching point .....	80-27
Q30	Flap doors and air mixing control units .....	80-27
Q30A	Ventilation distribution motor .....	80-27
Q30B	Warm/cool air blend motor .....	80-27
Q31	Air conditioning unit fan speed control .....	80-24
Q33	Cabin interior temperature sensor (with motor) .....	40-21
<b>R</b>	<b>SAFETY DEVICES</b>	
R20	Air Bag right front sensor .....	40-23
R21	Air Bag left front sensor .....	40-23
R22	Air bag control unit .....	43-7
R23	Air bag capsule .....	00-20
R24	Seat belt unfastened and ignition key inserted buzzer .....	43-5
R25	Safety belt fastened switch .....	40-20
<b>S</b>	<b>ELECTRONIC FUEL INJECTION</b>	
S3	Electroinjectors .....	04-18
S5	Air flow meter .....	04-26
S6	Throttle switch .....	04-28
S7	Engine coolant temperature sensor .....	04-20
S11	Motronic control unit .....	43-6
S12a	Fuel pump Motronic relay .....	01-11
S12b	Motronic relay with diode .....	01-11
S25	Automatic/Manual transmission connector .....	43-6
S29	Idle adjustment actuator .....	04-29
S31	RPM and timing sensor .....	04-19
S35	Heated Lambda probe .....	04-40

Code	Description	Reference
T	DIAGNOSIS	
T1	ALFA TESTER connector .....	43-6
T2	"Blinking code" diagnosis connector .....	04-49
T3	Air bag test connector .....	66-22
T4	Diagnosis indicator light pushbutton .....	40-40
T5	Suspension control system diagnosis connector .....	43-9





**ASSISTENZA TECNICA**

**ALFA - LANCIA S.p.A.,  
V.le Alfa Romeo — 20020 - ARESE (Milano)**

**Public. PA4596**

**- 9/90**

**Printed in Italy**

**All rights reserved. This book, or parts thereof,  
may not be reproduced in any form without permission  
of ALFA-LANCIA S.p.A.**

<https://www.automotive-manuals.net/>