

GEELY
















PARTS CATALOG

MK 2




JULY 2009

PICTURE INDEX

<p style="text-align: center;">2000 BODY</p>	<p>2010 BODY ASSY.</p> 	<p>2020 BODY FRAME ASSY.</p> 	<p>2030 ENGINE COMPARTMENT</p> 	<p>2040 ROOF ASSY.</p> 	<p>2040-1 SUNROOF ASSY.</p> 	<p>2050 BACK DOOR ASSY.</p> 
						<p>2060 RF DOOR ASSY.</p> 
						<p>2070 LF DOOR ASSY.</p> 
						<p>2080 LR DOOR ASSY.</p> 
						<p>2090 RR DOOR ASSY.</p> 
			<p>2130 L/R SIDE WALL ASSY.</p>  <p style="text-align: center;">21</p>	<p>2120 FRONT CROSS MEMBER ASSY.</p>  <p style="text-align: center;">16</p>	<p>2110 ENGINE HOOD ASSY.</p>  <p style="text-align: center;">32</p>	<p>2100 RADIATOR CROSS MEMBER</p> 

2010 BODY ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
1	1	101201025103	BODY ASSY.	1	
2	2	101201741602	ENGINE HOOD ASSY.	1	
3	3		HEXAGON FLANGE BOLT	4	
4	4	10120004990103	RIGHT FENDER	1	
5	5		HEXAGON HEAD BOLT & SPRING WASHER ASSY.	14	
6	6	10120015500103	RF DOOR ASSY.	1	
7	7	101201032002	RR DOOR ASSY.	1	
8	8	Q32010	HEXAGON HEAD FLANGE NUT	2	
9	9	101201020802	BACK DOOR ASSY.	1	
10	10		REAR HOOK	2	
11	11		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	4	
12	12		HEXAGON HEAD BOLT & SPRING WASHER ASSY.	2	
13	13	1012010417	OIL FILLER CAP ASSY.	1	
14	14	101201031002	LR DOOR ASSY.	1	
15	15	Q32008	HEXAGON FLANGE NUT	4	
16	16		DOOR HINGE MOUNTING BOLT	4	
17	17	10120011000103	LF DOOR ASSY.	1	
18	18		DOOR HINGE MOUNTING BOLT	8	
19	19		COWL PANEL PRESSURE PLATE	2	
20	20		HEXAGON FLANGE BOLT	4	
21	21	10120005140103	LEFT FENDER	1	
22	22		HEXAGON FLANGE BOLT	2	
23	23	1018005066	FRONT HOOK	1	
24	24		FRONT CROSS MEMBER ASSY.	1	
25	25		M8 FLANGE NUT	4	




2020 BODY FRAME ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1		BODY FRAME ASSY.	1	
	2	101200002102	LF INTERIOR BAFFLE PLATE	1	
	3	101200715002	COWL PANEL UPPER PART ASSY.	1	
	4		ENGINE COMPARTMENT ASSY.	1	
	5	101200002002	RF INTERIOR BAFFLE PLATE	1	
	6		ROOF 1# CROSS MEMBER	1	
	7	101201037002	ROOF SKIN ASSY.	1	
		101201038002	ROOF SKIN ASSY.	1	SUNROOF
	8		ROOF REAR CROSS MEMBER ASSY.	1	
	9	101201040002	RIGHT SIDE WALL ASSY.	1	
	10	101201039002	REAR END WALL ASSY.	1	
	11	101201026002	REAR FLOOR ASSY.	1	
	12	101201043302	LEFT SIDE WALL ASSY.	1	
13		FRONT FLOOR ASSY.	1		


2030 ENGINE COMPARTMENT ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	101201732102	RADIATOR CENTER BRACKET ASSY.	1	MT
		105201732102	RADIATOR CENTER BRACKET ASSY.	1	AT
	2	101200035702	RF SHOCK ABSORBER LOWER FRONT PLATE ASSY.	1	
	3	101200018202	RIGHT SIDE RAIL ASSY.	1	
	4		RF SHOCK ABSORBER INTERIOR ANGLE BRACKET ASSY.	1	
	5	Q1460616	HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	
	6	101200018302	LEFT SIDE RAIL ASSY.	1	
	7	101200035902	LF SHOCK ABSORBER LOWER FRONT PLATE ASSY.	1	
	8		LF SHOCK ABSORBER LOWER FRONT PLATE SUB-ASSY.	1	
	9		LF HOOK FIXING PLATE ASSY.	1	
10		COWL PANEL BAFFLE PLATE ASSY.	1		
	1018011470	ENGINE BOTTOM RIGHT SHIELD PLATE	1		
	1018011472	ENGINE BOTTOM LEFT SHIELD PLATE	1		


2040 ROOF SKIN ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	101201037002	ROOF SKIN ASSY.	1	W/O SUNROOF
	2		ROOF 2# CROSS MEMBER	1	
	3		ROOF 3# CROSS MEMBER	1	
	4		ROOF 4# CROSS MEMBER	1	

2040-1 ROOF SKIN ASSY.(SUNROOF)

	NO.	PART NO.	DES.	QTY	REMARK
	1	101201038002	ROOF SKIN ASSY.(SUNROOF)	1	
	2		SUNROOF REINFORCEMENT ASSY.	1	
	3		SUNROOF REINFORCEMENT	1	
	4		HEXAGON FLANGE BOLT	1	
	5		ROOF 4# CROSS MEMBER	1	

2050 BACK DOOR ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
 <p>The diagram shows an exploded view of a back door assembly. Callout 1 points to the main door frame. Callout 2 points to a hinge assembly mounted on the top edge of the frame. Callout 3 points to a hexagonal flange bolt that fits into the hinge assembly.</p>	1	101201020802	BACK DOOR ASSY.	1	
	2	1012010212	BACK DOOR HINGE ASSY	2	
	3	Q1800820	HEXAGON FLANGE BOLT	4	


2060 RF DOOR ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	10120015500103	RF DOOR ASSY.	1	
	2	1012001551	RF DOOR UPPER HINGE ASSY.	1	
	3	1012000970	RF DOOR LOWER HINGE ASSY.	1	
	4		DOOR HINGE MOUNTING BOLT	4	

2070 LF DOOR ASSY.


	NO.	PART NO.	DES.	QTY	REMARK
	1	10120011000103	LF DOOR ASSY.	1	
	2	1012001101	LF DOOR UPPER HINGE ASSY.	1	
	3	1012000972	LF DOOR LOWER HINGE ASSY.	1	
	4		DOOR HINGE MOUNTING BOLT	4	

2080 LR DOOR ASSY.




NO.	PART NO.	DES.	QTY	REMARK
1	101201031002	LR DOOR ASSY.	1	
2		DOOR HINGE MOUNTING BOLT	4	
3	1012002051	LR DOOR UPPER HINGE ASSY.	1	
4	1012000974	LR DOOR LOWER HINGE ASSY.	1	

2090 RR DOOR ASSY.



NO.	PART NO.	DES.	QTY	REMARK
1	101201032002	RR DOOR ASSY.	1	
2		DOOR HINGE MOUNTING BOLT	4	
3	1012002541	RR DOOR UPPER HINGE ASSY.	1	
4	1012000976	RR DOOR LOWER HINGE ASSY.	1	

2100 RADIATOR CROSS MEMBER



2100 RADIATOR CROSS MEMBER

NO.	PART NO.	DES.	QTY	REMARK	NO.	PART NO.	DES.	QTY	REMARK
1		CROSS MEMBER RIGHT PILLAR	1		25		OIL COOLER RIGHT BRACKET	1	
2		CROSS MEMBER RIGHT PILLAR EXTERIOR PLATE	1		26		OIL COOLER LEFT BRACKET	1	
3		CROSS MEMBER PILLAR CENTER REINFORCEMENT	2		27		RADIATOR GRILL LEFT BRACKET SUB-ASSY.	1	
4		RF COMBINATION LAMP UPPER BRACKET	1		28		RADIATOR GRILL LEFT BRACKET ASSY.	1	
5		RADIATOR GRILL RIGHT BRACKET ASSY.	1		29		LF COMBINATION LAMP UPPER BRACKET	1	
6		RADIATOR GRILL HOLE BRACKET	2		30		CROSS MEMBER LEFT PILLAR EXTERIOR PLATE	1	
7		RADIATOR GRILL RIGHT BRACKET SUB-ASSY.	1		31		CROSS MEMBER LEFT PILLAR ASSY.	1	
8		CROSS MEMBER RIGHT PILLAR INTERIOR PLATE	1		32	101200030303	RADIATOR LEFT PILLAT ASSY.	1	
9	101200029103	RADIATOR RIGHT PILLAR ASSY.	1						
10		RADIATOR UPPER CROSS MEMBER SUB-ASSY.	1						
11		HORN BRACKET ASSY.	2						
12	101201730502	RADIATOR UPPER CROSS MEMBER ASSY.	1						
13		HEXAGON HEAD BOLT & SPRING WASHER ASSY.	4						
14		CROSS SLOTED HEAD SCREW & SPRING WASHER ASSY.	1						
15		HEXAGON HEAD BOLT & SPRING WASHER ASSY.	1						
16	105201732102	RADIATOR CENTER BRACKET ASSY.	1						
17		FRONT GRILL MOUNTING BRACKET	1						
18		ENGINE HOOD LOCK BRACKET	1						
19		OIL COOLER CENTER BRACKET ASSY.	1						
20		RADIATOR CENTER BRACKET	1						
21	101201731002	RADIATOR LOWER CROSS MEMBER ASSY.	1						
22		RADIATOR LOWER CROSS MEMBER SUB-ASSY.	1						
23		LOWER CROSS MEMBER RIGHT REINFORCEMENT	1						
24		LOWER CROSS MEMBER LEFT REINFORCEMENT	1						

2110 ENGINE HOOD ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
		101201741602	ENGINE HOOD ASSY.	1	
	1	1018011471	ENGINE HOOD LOCK ASSY.	1	
		101201731802	ENGINE HOOD LOCK BUCKLE FIXING PLATE	1	
	2	1018011471	ENGINE HOOD INTERIOR PLATE	1	
	3		ENGINE HOOD EXTERIOR PLATE	1	
4	1012003542	ENGINE HOOD RIGHT HINGE ASSY.	1		
5	1012003537	ENGINE HOOD LEFT HINGE ASSY.	1		





















2120 FRONT CROSS MEMBER ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
		101200018503	FRONT CROSS MEMBER ASSY.	1	
	1	1012010366	LEFT CROSS MEMBER SIDE RAIL	1	
		1012010367	RIGHT CROSS MEMBER SIDE RAIL	1	
	2	101200033502	FRONT CROSS MEMBER LEFT BRACKET ASSY.	1	
	3	101200033902	FRONT CROSS MEMBER RIGHT BRACKET ASSY.	1	
	4		FRONT CROSS MEMBER EXTERIOR PLATE ASSY.	1	
5		FRONT CROSS MEMBER INTERIOR PLATE ASSY.	1		
6		FRONT CROSS MEMBER SUB-ASSY.	1		

2130 L/R SIDE WALL ASSY.

NO.	PART NO.	DES.	QTY	REMARK	NO.	PART NO.	DES.	QTY	REMARK
1	101201043502	LEFT SIDE WALL OUTER PANEL ASSY.	1						
	101201040202	RIGHT SIDE WALL OUTER PANEL ASSY.	1						
28		LEFT CENTER PILLAR LOWER REINFORCEMENT	1						
		RIGHT CENTER PILLAR LOWER REINFORCEMENT	1						
29		LEFT CENTER PILLAR UPPER REINFORCEMENT	1						
		RIGHT CENTER PILLAR UPPER REINFORCEMENT	1						
37	101200074802	LF PILLAR UPPER REINFORCEMENT	1						
	101200066802	RF PILLAR UPPER REINFORCEMENT	1						
38	101201044702	LR WHEEL HOUSE ASSY.	1						
	101201041502	RR WHEEL HOUSE ASSY.	1						
46	101200428902	LR WHEEL HOUSE OUTER PANEL	1						
	101200474102	RR WHEEL HOUSE OUTER PANEL	1						
66	1012010453	OIL FILLER CAP ASSY.	1						

PICTURE INDEX

<p>4000 CHASSIS</p>	<p>4010 BRAKE PEDAL</p> 	<p>4020 ACCELERATOR PEDAL</p> 	<p>4030 CLUTCH CONTROL</p> 	<p>4040 BRAKE PIPELINE (ABS)</p> 	<p>4050 BRAKE PIPELINE(W/O ABS)</p> 	<p>4060 FRONT DISC BRAKE</p> 
<p>4210 MK CHASSIS REPAIR KIT</p>						<p>4070 FRONT STEERING KNUCKLE</p> 
<p>4200 MK CHASSIS REPAIR KIT</p>						<p>4080 REAR DRUM BRAKE</p> 
<p>4190 STEERING WHEEL ASSY.</p> 						<p>4090 PARKING BRAKE CONTROL</p> 
<p>4180 WHEEL</p> 						<p>4100 STEERING LINKAGE</p> 
<p>4170 CONSTANT VELOCITY DRIVE SHAFT</p> 	<p>4160 REAR SUSPENSION</p> 	<p>4150 FRONT SUSPENSION</p> 	<p>4140 AT CONTROL</p> 	<p>4130 MT CONTROL</p> 	<p>4120 STEERING PIPELINE</p> 	<p>4110 EPS ASSY.</p> 


4010 BRAKE PEDAL & ACCESSORY

	NO.	PART NO.	DES.	QTY	REMARK
	1		VACUUM HOSE	1	
	2		STEEL HOOP	2	
	3	1014001600	VACUUM BOOSTER & BRAKE MASTER CYLINDER ASSY.	1	MT
		1014003364	VACUUM BOOSTER & BRAKE MASTER CYLINDER ASSY.	1	AT
		1014001975	VACUUM BOOSTER & BRAKE MASTER CYLINDER ASSY.	1	W/O ABS
	4		BOOSTER MOUNTING MAT	1	
	5		HEXAGON FLANGE NUT	4	
	6		HEXAGON HEAD BOLT	1	
	7	1014001612	BRAKE PEDAL & BRACKET ASSY.	1	MT
		1014001936	BRAKE PEDAL & BRACKET ASSY.	1	AT

4020 ACCELERATOR PEDAL & ACCESSORY


	NO.	PART NO.	DES.	QTY	REMARK
	1	1014001696	ACCELERATOR CABLE ASSY.	1	
	2		HEXAGON FLANGE NUT	2	
	3	1014001609	ACCELERATOR PEDAL & BRACKET ASSY.	1	
	4		PEDAL LEVER ASSY.	1	
	5		PEDAL BRACKET ASSY.	1	
	6		SPECIAL ELASTIC GASKET	1	
	7		LUBRICATING SHAFT BUSHING	2	
	8		CONNECTING SHAFT ROD	1	
	9		RETURN SPRING	1	
	10		CUSHION	1	

4030 CLUTCH PEDAL & ACCESSORY



NO.	PART NO.	DES.	QTY	REMARK
1	1014001775	CLUTCH HOSE	1	
2		"L" TYPE CIRCLIP	2	
3	1016001927	CLUTCH HOSE FIXING BRACKET	1	
4	Q1840616	HEXAGON FLANGE BOLT	1	
5		STEEL SPRING HOOP	2	
6	1014001771	MASTER CYLINDER INLET PIPE ASSY.	1	
7	1014001773	MASTER CYLINDER OUTLET PIPE ASSY.	1	
8	1014001688	CLUTCH MASTER CYLINDER ASSY.	1	
	1016001310	CLUTCH RELEASE CYLINDER ASSY.	1	
9		HEXAGON NUT	2	
10		HEXAGON FLANGE BOLT	1	
11	1014001611	CLUTCH PEDAL & BRACKET ASSY.	1	


4040 BRAKE PIPELINE (ABS)



4040 BRAKE PIPELINE (ABS)

NO.	PART NO.	DES.	QTY	REMARK	NO.	PART NO.	DES.	QTY	REMARK
1	1014001865	RF BRAKE PIPE ASSY.	1		25	1014001738	LR BRAKE PIPE ASSY.II	1	
2	1014001649	RF BRAKE HOSE ASSY.	1		26	1014001739	RR BRAKE PIPE ASSY.II	1	
3		"L" TYPE SPRING CLIP	4		27	1014001737	SINGLE-WAY CLIP	2	
4	1014001950	COPPER SEALING WASHER	2		28		HEXAGON HEAD BOLT & WASHER ASSY.	2	
5		HEXAGON HEAD BOLT & SPRING WASHER ASSY.	1		29		RR BRAKE HOSE FIXING PLATE ASSY.	1	
6		DUAL-WAY CLIP	1		30		LR BRAKE HOSE FIXING PLATE ASSY.	1	
7	1014003926	BRAKE MASTER CYLINDER 1# BRAKE PIPE ASSY.	1		31		HEXAGON HEAD BOLT & WASHER ASSY.	2	
8	1014001863	BRAKE MASTER CYLINDER 2# BRAKE PIPE ASSY.	1			1406141180	BRAKE PIPE DUAL-WAY CONNECTING	1	
9	1014003650	HECU	1						
10	1014001867	RR BRAKE PIPE ASSY.	1						
11	1014003923	CONNECTING BOLT	3						
12	1014003924	ABS RUBBER CUSHION	3						
13	1014001864	LF BRAKE PIPE ASSY.	1						
14	1014003411	HECU CONTROL BRACKET ASSY.	1						
15		HEXAGON HEAD BOLT & SPRING WASHER ASSY.	3						
16	1014001648	LF BRAKE HOSE ASSY.	1						
17		HEXAGON FLANGE NUT	5						
18	1014001866	LR BRAKE PIPE ASSY.	1						
19		FIVE-WAY CLIP II	5						
20	1014001868	LR BRAKE PIPE ASSY.III	1						
21	1014001869	RR BRAKE PIPE ASSY.III	2						
22		SEVEN-WAY CLIP	2						
23	1014001765	BRAKE HOSE CONNECTING BOLT	4						
24	1014001650	REAR BRAKE HOSE ASSY.	2						


4050 BRAKE PIPELINE(W/O ABS)



4050 BRAKE PIPELINE(W/O ABS)

NO.	PART NO.	DES.	QTY	REMARK	NO.	PART NO.	DES.	QTY	REMARK
1	Q1460825	HEXAGON BOLT	3		25	1014006370	FRONT BRAKE PIPE, LH	1	
2	1014001648	FRONT BRAKE HOSE, LH	1		26	1014006372	FRONT BRAKE PIPE, RH	1	
3	1014001649	FRONT BRAKE HOSE, RH	1		27	1014006382	REAR PIPE, LH	1	
4		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2		28	1014006384	REAR PIPE, RH	1	
5	1014001950	SEAL WASHER	2		29	1014006378	FIVE-WAY VALVE TO PROPORTIONAL VALVE LR BRAKE PIPE ASSY.	1	
6		SEVEN-WAY CLIP	2		30	1014006380	FIVE-WAY VALVE TO PROPORTIONAL VALVE RR BRAKE PIPE ASSY.	1	
7	Q1460620	HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2						
8	1014001738	REAR PIPE, LH II	1						
9	1014001739	REAR PIPE, RH II	1						
10		FIVE-WAY CLIP II	5						
11	Q32006	HEXAGON FLANGE NUT	7						
12	1014001737	SINGLE-WAY CLIP	2						
13	1014001650	REAR BRAKE HOSE	2						
14		REAR HOSE FIXING PLATE, LH	1						
15		REAR HOSE FIXING PLATE, RH	1						
16		HEXAGON BOLT	2						
17	Q1840645	HEXAGON FLANGE BOLT	1						
18	1014001765	BRAKE HOSE CONNECTING BOLT	2						
19		"L" TYPE CIRCLIP	4						
20	1014006374	1# BRAKE PIPE-BRAKE MASTER CYLINDER	1						
21	1014006376	2# BRAKE PIPE-BRAKE MASTER CYLINDER	1						
22	1014003882	FIVE-WAY VALVE	1						
23	1014001920	PROPORTIONAL VALVE	1						
24	1014001922	BRACKET-CONNECTING ROD	1						

4060 FRONT DISC BRAKE & STEERING KNUCKLE ASSY.




NO.	PART NO.	DES.	QTY	REMARK
	1014001602	LF DISC BRAKE & STEERING KNUCKLE ASSY.	1	W/O ABS
	1014003281	LF DISC BRAKE & STEERING KNUCKLE ASSY.	1	ABS
	1014001601	RF DISC BRAKE & STEERING KNUCKLE ASSY.	1	W/O ABS
	1014003283	RF DISC BRAKE & STEERING KNUCKLE ASSY.	1	ABS
1		CROSS SLOT HEAD SCREW	2	
2	1014001811	BRAKE DISC	1	
3	1014001809-01	LEFT BRAKE CALIPER ASSY.	1	
	1014001810-01	RIGHT BRAKE CALIPER ASSY.	1	
4		LEFT STEERING KNUCKLE & WHEEL HUB ASSY.	1	
		RIGHT STEERING KNUCKLE & WHEEL HUB ASSY.	1	
5		BRACKET MOUNTING BOLT	4	
	1017009293	LF WHEEL SPEED SENSOR ASSY.	1	
	1017009294	RF WHEEL SPEED SENSOR ASSY.	1	

4070 FRONT STEERING KNUCKLE & FRONT WHEEL HUB ASSY.


	NO.	PART NO.	DES.	QTY	REMARK
<p style="text-align: center;"> 2 1 9 8 3 4 5 6 7 </p>	1	1014001997	LEFT STEERING KNUCKLE	1	ABS
		1014001998	RIGHT STEERING KNUCKLE	1	ABS
		1014001807	LEFT STEERING KNUCKLE	1	W/O ABS
		1014001808	RIGHT STEERING KNUCKLE	1	W/O ABS
	3	1014003153	LEFT SPLASH GUARD	1	
		1014003154	RIGHT SPLASH GUARD	1	
			M6 HEXAGON HEAD BOLT	3	
	6	1014003218	FRONT WHEEL HUB BOLT	4	
	7	1014003148	FRONT WHEEL HUB	1	
8	1014003273	DUAL ROW BALL BEARING	1		
9	1014003150	HOLE CIRCLIP	1		

4080 REAR DRUM BRAKE & WHEEL HUB ASSY.




NO.	PART NO.	DES.	QTY	REMARK
1	1014001815	REAR BRAKE DRUM	1	
2	1014001814	REAR WHEEL HUB	1	W/O ABS
	1014003295	REAR WHEEL HUB	1	ABS
3	1014003873	LR BRAKE ASSY.	1	
	1014003874	RR BRAKE ASSY.	1	
4	1014001603	RL DRUM BRAKE & WHEEL HUB ASSY.	1	W/O ABS
	1014003291	RL DRUM BRAKE & WHEEL HUB ASSY.	1	ABS
	1014001604	RR DRUM BRAKE & WHEEL HUB ASSY.	1	W/O ABS
	1014003293	RR DRUM BRAKE & WHEEL HUB ASSY.	1	ABS

4090 PARKING BRAKE CONTROL




NO.	PART NO.	DES.	QTY	REMARK
1	1014001661	PARKING BRAKE CONTROL LEVER ASSY.	1	
2		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	
3		PARKING BRAKE CABLE FIXING BRACKET	1	
4		HEXAGON HEAD BOLT	1	
5		HEXAGON HEAD BOLT	8	
6	1014001818	LEFT PARKING BRAKET CABLE ASSY,	1	
7	1014001819	RIGHT PARKING BRAKET CABLE ASSY,	1	


4100 STEERING COLUMN

	NO.	PART NO.	DES.	QTY	REMARK
 <p>The diagram shows an exploded view of a steering column assembly. Callout 1 points to the main steering column shaft. Callout 2 points to a hexagon head bolt and plain washer assembly. Callout 3 points to a hexagon flange bolt. Callout 4 points to a hexagon head bolt. Callout 5 points to the universal joint assembly. Callout 6 points to the steering column spline dust boot.</p>	1	1014001698	STEERING COLUMN ASSY.	1	
	2		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	
	3		HEXAGON FLANGE BOLT	1	
	4		HEXAGON HEAD BOLT	2	
	5	1014001749	UNIVERSAL JOINT ASSY.	1	
	6	1014001834	STEERING COLUMN SPLINE DUST BOOT	1	

4110 HEPS ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1014001831	DUST BOOT	1	
	2	1014001832	DUST BOOT INTERIOR LINER	1	
	3	1014001833	DUST BOOT CLIP	1	
	4	Q32006	HEXAGON FLANGE BOLT	1	
	5	1014001834	STEERING COLUMN SPLINDE DUST BOOT	1	
	6		HEXAGON FLANGE BOLT	2	
	7	1014001633	HEPS & TIE ROD ASSY.	1	
	8		"2" TYPE HEXAGON SLOTTED NUT	2	
	9		COTTER PIN	2	


4130 MT CONTROLLER

	NO.	PART NO.	DES.	QTY	REMARK
	1	1064000191	TRANSMISSION CONTROL LEVER HANDLE	1	LUXURY
2	1018011415	TRANSMISSION CONTROL LEVER DUST BOOT	1		
3	1064000192	MANUAL GEARSHIFT ASSY.	1	LUXURY	
4	1016000019	MANUAL GEARSHIFT ASSY.	1		
5	1014001685	GEARSHIFT CABLE ASSY.	1		
6		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	3		
7	1014001762	ELASTIC CLIP	2		
8		GEARSHIFT BRACKET	1		
9	Q40208	WASHER	2		
10	Q50108	LOCKPIN	2		
11		GEARSHIFT BRACKET	1		
12		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	4		
13	Q50110	LOCKPIN	1		

4140 AT CONTROLLER

	NO.	PART NO.	DES.	QTY	REMARK
	1		AUTO GEARSHIFT CONTROL LEVER	1	
	2		LOCKPIN	4	
	3		"2" TYPE HEXAGON NUT	1	
	4	1014001876	AUTO GEARSHIFT ASSY.	1	
	5		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	
	6	1400991180	"E" TYPE CLIP	1	
	7	1014001937	GEARSHIFT CABLE ASSY.	1	
	8	1014001938	KEY RESTRICT CABLE	2	
	9		PLAIN WASHER	1	
	10		SPRING WASHER	1	
	11		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	

4150 FRONT SUSPENSION




4150 FRONT SUSPENSION

NO.	PART NO.	DES.	QTY	REMARK	NO.	PART NO.	DES.	QTY	REMARK
1	1014001605	FRONT SUSPENSION CROSS MEMBER ASSY.	1		25	1014001707	FRONT COIL SPRING	2	
2	1014001335	HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2		26	1014001709	FRONT CUSHION	2	
3	1014001336	HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2		27	1014001708	FRONT SHOCK ABSORBER ASSY.	2	
4	1014001682	FRONT SUSPENSION REINFORCEMENT RAIL	2		30	1014001683	FRONT STABILIZER BAR	1	
5		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	4		31	1014001667	FRONT STABILIZER BAR PRESSURE PLATE	2	
6	1014001607	LEFT LOWE TRAILING ARM ASSY.	1		32	1014001669	FRONT STABILIZER BAR BUSHING	2	
7	1014001606	RIGHT LOWE TRAILING ARM ASSY.	1		33		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	4	
8	1014001338	HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2		34	1014001670	FRONT STABILIZER BAR BOLT	2	
9		HEXAGON FLANGE NUT	2		35	1014001671	FRONT STABILIZER BAR BOLT	8	
10	1014001339	HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2		36	1014001672	GASKET	8	
11		HEXAGON SLOTTED NUT	2		37	1014001668	BIG WASHER	2	
12		LOCKPIN	2		38		HEXAGON HEAD LOCKING NUT	4	
13		FRONT STABILIZER BAR SET	1						
14		FRONT POLE ASSY.	2						
15		HEXAGON FLANGE BOLT	4						
16	Q32014	HEXAGON FLANGE NUT	4						
17	1014001715	FRONT SUSPENSION UPPER SEAT PRESSURE PLATE	2						
18		HEXAGON NUT	3						
19	1014001714	FRONT SUSPENSION UPPER SEAT DUST BOOT	2						
20		HEXAGON LOCKING NUT	2						
21	1014001713	FRONT SUSPENSION UPPER SEAT	2						
22	1014001712	FRONT SUSPENSION UPPER SEAT SEAL GASKET	2						
23	1014001711	SPRING UPPER SEAT	2						
24	1014001710	SPRING & DUST BOOT	2						

4160 REAR SUSPENSION


	NO.	PART NO.	DES.	QTY	REMARK
	1	1014002428	REAR AXLE ASSY.	1	
	2	1014001675	REAR AXLE BRACKET BUSHING ASSY.	2	
	3	1014001337	HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	
	4	1014001681	LOWER CUSHION	2	
	5	1014001678	REAR SPRING	2	
	6	1014001680	UPPER CUSHION	2	
	7	1014001676	REAR SHOCK ABSORBER	2	
	8	1014001724	LOWER SEAT LOWER PRESSURE PLATE	2	
	9	1014001725	REAR SHOCK ABSORBER LOWER SEAT	2	
	10	1014001706	REAR SHOCK ABSORBER UPPER SEAT	2	
	11	1014001726	UPPER SEAT UPPER PRESSURE PLATE	2	
	12		HEXAGON NUT	4	
	13	1014001723	REAR CUSHION	2	
	14		BIG WASHER	2	
	15		"A" TYPE HEXAGON FLANG NUT M12X1.25	2	
	16	1014002432	REAR SHOCK ABSORBER DUST BOOT	2	
	17	1014001957	BRAKE MOUNTING BOLT	8	
	18	1014017073	REAR SHOCK ABSORBER SLEEVE	2	

4170 CONSTANT VELOCITY DRIVE SHAFT (ABS)



NO.	PART NO.	DES.	QTY	REMARK
1	1014001420	RIGHT CONSTANT VELOCITY DRIVE SHAFT ASSY.	1	S160G
	1014001884	RIGHT CONSTANT VELOCITY DRIVE SHAFT ASSY.	1	AT
2	1014001885	LEFT CONSTANT VELOCITY DRIVE SHAFT ASSY.	1	S160G
	1014001883	LEFT CONSTANT VELOCITY DRIVE SHAFT ASSY.	1	AT
3	1014001757	FIXING NUT	2	
4		FRONT GEAR RING	2	


4180 WHEEL



NO.	PART NO.	DES.	QTY	REMARK
1	1014002000	TIRE ASSY.	4	
2	3101615106	TIRE VALVE	4	
3	1054005001	WHEEL NUT	4	
4	1408053180	WHEEL HUB TRIM COVER	1	
5		BALANCE WEIGHT	1	
6	1014001974	STEEL WHEEL RIM ASSY.	1	
7	1014011137	ALUMINUM WHEEL RIM ASSY.	1	
	1018001968	WHEEL ASSY.	1	
		SPARE TIRE PRESSURE PLATE	1	


4190 STEERING WHEEL ASSY.

NO.	PART NO.	DES.	QTY	REMARK
1	1018011091	STEERING WHEEL ASSY.	1	
	1018006347	STEERING WHEEL COVER	1	
2		HEXAGON FLANGE NUT	1	



The diagram illustrates the assembly of the steering wheel cover. Part 1, the steering wheel cover, is shown with a central hub. Part 2, a hexagon flange nut, is shown being inserted into the center of the hub. The nut is secured to the hub, and the cover is then placed over the hub to complete the assembly.


4200 MK CHASSIS REPAIR KIT



4200 MK CHASSIS REPAIR KIT















NO.	PART NO.	DES.	QTY	REMARK	NO.	PART NO.	DES.	QTY	REMARK
1		EXTERIOR BRAKE FRICTION PAD	1						
2		EXTERIOR NOISE INSULATOR ASSY.	1						
3		LEFT INTERIOR BRAKE FRICTION PAD	1						
4		RIGHT INTERIOR BRAKE FRICTION PAD	1						
5		INTERIOR NOISE INSULATOR ASSY.	1						
	1014003350	FRONT BRAKE FRICTION PAD	1						
6	1014003351	REAR BRAKE FRICTION PAD	1						
7		BRAKE SHOE ASSY. I	1						
8		LEFT BRAKE SHOE II	1						
		RIGHT BRAKE SHOE II	1						
9	1014003192	LEFT BRAKE WHEEL CYLINDER	1						
	1014003193	RIGHT BRAKE WHEEL CYLINDER	1						
10	1014001962	STEERING TIE ROD	1						
11	1014001960	LEFT STEERING TIE ROD & BALL JOINT	1						
12	1014001961	RIGHT STEERING TIE ROD & BALL JOINT	1						
13	1014003354	EXTERIOR RZEPPA CONSTANT VELOCITY JOINT	1						
14	1014003356	LEFT INTERIOR RZEPPA CONSTANT VELOCITY JOINT	1	MT					
	1014003358	LEFT INTERIOR RZEPPA CONSTANT VELOCITY JOINT	1	AT					
15	1014003359	RIGHT INTERIOR RZEPPA CONSTANT VELOCITY JOINT	1	AT					
	1014003357	RIGHT INTERIOR RZEPPA CONSTANT VELOCITY JOINT	1	MT					
16	1014003360	INTERIOR RZEPPA REPAIR KIT	1						
17	1014003361	EXTERIOR RZEPPA REPAIR KIT	1						

4210 MK CHASSIS REPAIR KIT




NO.	PART NO.	DES.	QTY	REMARK
1	1014003369	RESERVOIR	1	
2	1014003370	RESERVOIR COVER	1	
3	1014003371	BRAKE MASTER CYLINDER	1	ABS
	1014003386	BRAKE MASTER CYLINDER	1	W/O ABS
4		VACUUM BOOSTER GASKET	1	
5	1014013478	BRAKE MASTER CYLINDER &VACUUM BOOSTER	1	MT
	1014013886	BRAKE MASTER CYLINDER &VACUUM BOOSTER	1	AT
	1014001975	BRAKE MASTER CYLINDER &VACUUM BOOSTER	1	W/O ABS

PICTURE INDEX

<p style="text-align: center;">6000 POWER</p>	<p>6010 MR479QA ENGINE ASSY.</p>  <p style="text-align: right;">1-1-1</p>	<p>6020 MR481QA ENGINE ASSY.</p>  <p style="text-align: right;">1-1-2</p>	<p>6030 ENGINE MOUNT</p>  <p style="text-align: right;">2-1</p>	<p>6040 ENGINE MOUNT</p>  <p style="text-align: right;">2-2</p>	<p>6050 FUEL TANK</p>  <p style="text-align: right;">3</p>	<p>6060 FUEL LINE</p> 
						<p>6070 FUEL PUMP ASSY.</p> 
						<p>6080 AIR INTAKE SYSTEM</p>  <p style="text-align: right;">7</p>
						<p>6090 AIR CLEANER ASSY.</p>  <p style="text-align: right;">7</p>
						<p>6100 COOLING SYSTEM (MT)</p>  <p style="text-align: right;">8-1</p>
				<p>6130 EXHAUST SYSTEM (1.6L)</p>  <p style="text-align: right;">10-2</p>	<p>6120 EXHAUST SYSTEM (1.5L)</p>  <p style="text-align: right;">10-1</p>	<p>6110 COOLING SYSTEM (AT)</p>  <p style="text-align: right;">8-2</p>

6010 MR479QA ENGINE ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	2000000002	MR479QA ENGINE ASSY.	1	
		1086090501	MR479QA ENGINE ASSY.	1	OBD
		1086001015	MR479QA ENGINE ASSY.	1	AT
		1086090507	MR479QA ENGINE ASSY.	1	EURO IV
		1016003746	MR479QA ENGINE ASSY.	1	ANTI-THEFT
	2		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	
	3		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	
	4		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	
	5		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	3	
	6		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	
	7	3000000011	5-GEAR TRANSMISSION (JL160G)	1	
		3000000001	5-GEAR TRANSMISSION (JL160)	1	
		3000000013	AUTO TRANSMISSION (JL-ZA130)	1	
		1106010361	ENGINE OVERHAUL KIT (MR479Q, MR479QA)	1	

6020 MR481QA ENGINE ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	2160013901	MR481QA ENGINE ASSY.	1	
		1086090601	MR481QA ENGINE ASSY.	1	OBD
		1086090600	MR481QA ENGINE ASSY.	1	AT
	2		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	
	3		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	
	4		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	
	5		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	3	
	6		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	
	7	3000000005	5-GEAR TRANSMISSION (JL160A)	1	
		3000000013	AUTO TRANSMISSION (JL-ZA130)	1	
	1086000000	ENGINE OVERHAUL KIT (MR481A)	1		

6030 ENGINE MOUNTING(MT)

	NO.	PART NO.	DES.	QTY	REMARK
	1	1016001760	ENGINE REAR BRACKET	1	
	2		HEXAGON FLANGE BOLT	4	
	3	1016000632	ENGINE REAR INSULATOR	1	
	4		HEXAGON FLANGE BOLT	1	
	5		HEXAGON FLANGE NUT	3	
	6		HEXAGON FLANGE BOLT	1	
	7	1016000633	ENGINE LEFT BRACKET	1	
	8	JQ184C1030	HEXAGON FLANGE BOLT	7	
	9	1016000634	ENGINE LEFT INSULATOR	1	
	10		HEXAGON FLANGE BOLT	1	
	11	1016000636	ENGINE RIGHT INSULATOR	1	
	12		HEXAGON FLANGE BOLT	2	

6040 ENGINE MOUNTING (AT)

	NO.	PART NO.	DES.	QTY	REMARK
	1	1016000648	ENGINE REAR BRACKET	1	
	2		HEXAGON FLANGE BOLT	2	
	3		HEXAGON FLANGE BOLT	1	
	4	1016000632	ENGINE REAR INSULATOR	1	
	5		HEXAGON FLANGE BOLT	1	
	6		HEXAGON FLANGE NUT	3	
	7		HEXAGON FLANGE BOLT	1	
	8	1016000651	ENGINE LEFT BRACKET	1	
	9		HEXAGON FLANGE BOLT	6	
	10	1016000649	ENGINE LEFT INSULATOR	1	
	11	JQ184C1030	HEXAGON FLANGE BOLT	2	
	12		HEXAGON FLANGE BOLT	1	
	13	1016000636	ENGINE RIGHT INSULATOR	1	
	14		HEXAGON FLANGE BOLT	2	

6050 FUEL TANK


	NO.	PART NO.	DES.	QTY	REMARK
	1	1016001331	OIL FILLER CAP ASSY.	1	
	2	1016001506	OIL FILLER SEAL	1	
	3	1016002663	OIL FILLER PIPE	1	
	4		CROSS SLOTTED HEXAGON HEAD BOLT & WASHER ASSY.	4	
	5		CROSS SLOTTED HEXAGON HEAD BOLT & WASHER ASSY.	2	
	6	1016001338	OIL FILLER HOSE	1	
	7		"A" TYPE WORM DRIVE HOSE HOOP	2	
	8	1016001339	OIL FILLER VENT HOSE	1	
	9		"A" TYPE WORM DRIVE HOSE HOOP	2	
	10	1016001859	FUEL TANK ASSY.	1	
	11		CROSS SLOTTED HEXAGON HEAD BOLT & WASHER ASSY.	4	
	2000100006	OIL LEVEL INDICATOR COMPONENT	1		

6060 FUEL LINE & FUEL EVAPORATOR

	NO.	PART NO.	DES.	QTY	REMARK
	1	1016001494	CONTROL VALVE TO ENGINE HOSE	1	
	2		STEEL HOOP	3	
	3		STEEL HOOP	3	
	4	1036000974	CANISTER CONTROL VALVE	1	
	5		CROSS HEXAGON HEAD BOLT & SPRING WASHER ASSY.	3	
	6	1016001495	CONTROL VALVE TO CANISTER HOSE	1	
	7	1016001355	CANISTER(VERTICAL)	1	
	8	1016001354	CANISTER AIR INTAKE PIPE	1	
	9		STEEL HOOP	2	
	10	1016001352	METAL VENT PIPE	1	
	11	1016001351	METAL FUEL PIPE	1	
	12	1016001353	METAL FUEL RETURN PIPE	1	
	13		FIVE- WAY CLIP	2	
	14		FUEL RETURN HOSE	1	
	15		"A" TYPE WORM DRIVE HOSE HOOP	4	
	16	1016001507	FUEL HOSE	1	
	17		CANISTER CONTROL VALVE MOUNTING BRACKET	1	
	18	1016001503	CANISTER MOUNTING BRACKET WELDING ASSY.	1	
	19		PIPE CLIP	1	

6070 FUEL PUMP ASSY.

NO.	PART NO.	DES.	QTY	REMARK
1		FUEL TANK BODY	1	
2	1016001861	FUEL PUMP ASSY.	1	
	1016003452	FUEL SENSOR	1	
	1016003704	FUEL PUMP SCREEN	1	
3	1016001523	FUEL TANK COVER	1	
4	1016001512	INLET FUEL FILTER HOSE	1	
5	1016001864	OIL RETURN HOSE	1	
6	1016001511	VENT HOSE	1	
7	1016001512	OUTLET FUEL FILTER HOSE	1	
8	10160001520	FUEL FILTER ASSY.	1	
9		FUEL TANK BAFFLE PLATE	1	
10	1016001526	SEAL	1	
11		CROSS SLOTTED HEAD SELF-TAPPING SCREW	3	



6080 AIR INTAKE SYSTEM

	NO.	PART NO.	DES.	QTY	REMARK
	1	1016000585	AIR CLEANER ASSY.	1	
	2		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	3	
	3	1018004652	PLASTIC EXPANSION CLIP(φ7)	1	
	4	1016000588	AIR CLEANER INTAKE HOSE	1	
	5		WORM DRIVE HOSE HOOP	2	
	6		CRANKCASE EXHAUST EMISSION HOSE	1	
	7		HEAT AIR GUIDE PIPE	1	
	8		STEEL HOOP	2	
	9		BRACKET	1	


6090 AIR CLEANER ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1016000574	AIR CLEANER INTAKE PIPE ASSY.	1	
	2		AIR CLEANER UPPER BODY	1	
	3		AIR CLEANER LOWER BODY	1	
	4	1016000577	AIR CLEANER ELEMENT	1	
	5		RUBBER CUSHION	3	
	6		BOLT BUSHING	3	
	7		CLIP	2	

6100 COOLING SYSTEM (MT)

	NO.	PART NO.	DES.	QTY	REMARK
	1	1602041180-01	RADIATOR ASSY.(MT)	1	
	2	1602197180	RADIATOR LOWER CUSHION	2	
	3	1016001408	RADIATOR UPPER CUSHION	2	
	4	1016002191	COOLING FAN & MOTOR ASSY. I	1	
	5	1016002192	COOLING FAN & MOTOR ASSY. II	1	
	6		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	
	7	1016003339	RADIATOR WATER INLET PIPE	1	
	8	1602200180	RADIATOR WATER OUTLET PIPE	1	
	9		"A" TYPE WORM DRIVE HOSE HOOP	4	
	10	160204518001	EXPANSION TANK WITH OVERFLOW PIPE ASSY.	1	
	11	1601457180	CROSS SLOT SCREW & PLAIN WASHER ASSY.	3	
		RADIATOR CAP	1		


6110 COOLING SYSTEM (AT)



NO.	PART NO.	DES.	QTY	REMARK
1	1016000231	RADIATOR ASSY.(AT)	1	
2	1602197180	RADIATOR LOWER CUSHION	2	
3	1016001408	RADIATOR UPPER CUSHION	2	
4	1016002191	COOLING FAN & MOTOR ASSY. I	1	
5	1016002192	COOLING FAN & MOTOR ASSY. II	1	
6		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	
7	1016003339	RADIATOR WATER INLET PIPE	1	
8	1602200180	RADIATOR WATER OUTLET PIPE	1	
9		"A" TYPE WORM DRIVE HOSE HOOP	4	
10	160204518001	EXPANSION TANK WITH OVERFLOW PIPE ASSY.	1	
11		CROSS SLOT SCREW & PLAIN WASHER ASSY.	3	
12	1016000177	OIL COOLER WITH MOUNTING BRACKET ASSY.	1	
13		HEXAGON HEAD BOLT & SPRING WASHER ASSY.	1	
14	1016000179	ATF OUTLET HOSE	1	
15	1016000180	OIL COOLER OUTLET HOSE	1	
16	1016000182	ATF INLET HOSE	1	
17		"C" TYPE WORM DRIVE HOSE HOOP	6	
	1601457180	RADIATOR CAP	1	

6120 EXHAUST SYSTEM(1.5L)



















NO.	PART NO.	DES.	QTY	REMARK
1	1016001384	FRONT EXHAUST PIPE ASSY.(TWC)	1	
2	1203312005	EXHAUST PIPE GASKET	2	
3	1602026180	SPRING	4	
4	1203131101	EXHAUST PIPE CONNECTING BOLT	4	
5	1016001678	CENTER MUFFLER ASSY.	1	
6	1016001444	FRONT EXHAUST SEAL IV	1	
7		HEXAGO HEAD BOLT & SPRING WASHER ASSY.	2	
8	1016002506	REAR MUFFLER ASSY.	1	
9	1016001388	REAR RUBBER SEAT	2	
10	1016001399	FRONT RUBBER SEAT	2	
11	1016001389	FRONT FLOOR HEAT INSULATOR	1	
12		HEXAGON HEAD BOLT & SPRING WASHER ASSY.	5	
13	1016001390	FRONT EXHAUST PIPE BRACKET	1	
14		HEXAGON HEAD BOLT & SPRING WASHER ASSY.	2	
15	1016002506	REAR FLOOR HEAT INSULATOR	1	
16	1016002495	EXHAUST MANIFOLD ASSY.(TWC)(OBD)	1	
17	1017007963	REAR OXYGEN SENSOR WIRING HARNESS BRACKET	1	

















6120-01 EXHAUST SYSTEM(1.6L)

	NO.	PART NO.	DES.	QTY	REMARK
	1	1016001447	FRONT EXHAUST PIPE ASSY.	1	
	2	1203312005	EXHAUST PIPE GASKET	2	
	3	1602026180	SPRING	4	
	4	1203131101	EXHAUST PIPE CONNECTING BOLT	4	
	5	1016001448	CENTER MUFFLER ASSY.	1	
		1016002496	CENTER MUFFLER ASSY.(OBD)	1	
	6	1016001444	FRONT EXHAUST SEAL IV	1	
	7		HEXAGO HEAD BOLT & SPRING WASHER ASSY.	2	
	8	1016002506	REAR MUFFLER ASSY.	1	
	9	1016001388	REAR RUBBER SEAT	2	
	10	1016001399	FRONT RUBBER SEAT	2	
	11	1016001389	FRONT FLOOR HEAT INSULATOR	1	
	12		HEXAGON HEAD BOLT & SPRING WASHER ASSY.	5	
	13	1016001390	FRONT EXHAUST PIPE BRACKET	1	
	14		HEXAGON HEAD BOLT & SPRING WASHER ASSY.	2	
	15	1016002506	REAR FLOOR HEAT INSULATOR	1	
	16	2160141901	EXHAUST MANIFOLD ASSY.(TWC)	1	
	1086001113	EXHAUST MANIFOLD ASSY.(TWC)(OBD)	1		
17	1017007963	REAR OXYGEN SENSOR WIRING HARNESS BRACKET	1		

PICTURE INDEX


<p>7000 ELECTRONIC</p>	<p>7010 COMBINATION MEMBER ASSY.</p> 	<p>8020 ELECTRIC SWITCH</p> 	<p>7030 FRONT HEADLIGHT ASSY.</p> 	<p>7040 FOGLIGHT ASSY.</p> 	<p>7050 INTERIOR DOME LAMP</p> 	<p>7060 SUNROOF SWITCH ASSY.</p> 
<p>7210 FRONT WIRING HARNESS ASSY.</p> 					<p>7070 REAR COMBINATION LAMP</p> 	
<p>7200 SRS ASSY.</p> 					<p>7080 LICENSE PLATE LAMP ASSY.</p> 	
<p>7190 ON-BOARD HANDSFREE PHONE</p> 					<p>7090 HEIGHT-MOUNT BRAKE LAMP</p> 	
<p>7180 BATTERY ASSY.</p> 					<p>7100 WIPER ASSY.</p> 	
<p>7170 HORN ASSY.</p> 					<p>7160 CIGARETTE LIGHTER ASSY.</p> 	<p>7150 SINGLE CD-ROM + MP3 ASSY.</p> 

PICTURE INDEX

<p style="text-align: center;">7000 ELECTRONIC</p>	<p>7220 I/P WIRING HAF</p> 	<p>7230 ABS SYSTEM ASSY.</p> 	<p>7240 BODY WIRING HARNESS</p> 	<p>7250 BATTERY GROUND</p> 	<p>7260 ELECTRONIC CONTROL SET(REMOTE CONTROL)</p> 	<p>7270 PARKING SENSOR ASSY.</p> 
						<p>7280 FUSE BOX</p> 
						<p>7290 ECU BRACKET</p> 
						<p>7300 COMPRESSOR ASSY.</p> 
						<p>7310 A/C PIPELINE ASSY.</p> 
			<p>7350 A/C CONTROL SET ASSY.</p> 	<p>7340 A/C SET ASSY.</p>	<p>7330 A/C SET ASSY.</p> 	<p>7320 CONDENSER ASSY.</p> 


7010 COMBINATION METER ASSY.

NO.	PART NO.	DES.	QTY	REMARK
1	1017000187	COMBINATION METER ASSY.	1	
2		HEXAGON FLANGE SELF-TAPPING SCREW	2	




7020 ELECTRONIC SWITCH

7020 电器开关



NO.	PART NO.	DES.	QTY	REMARK
1	1017000650	RIGHT COMBINATION SWITCH ASSY.	1	
2	1017000636	LEFT COMBINATION SWITCH ASSY.	1	
3	1017000942	POWER REARVIEW MIRROR SWITCH WITH LAMP ADJUSTABLE SWITCH ASSY.	1	
4		MOUNTING PANEL	1	
5		POWER REARVIEW MIRROR SWITCH	1	
6	1017000943	POWER REARVIEW MIRROR SWITCH PANEL WITH DEFROST SWITCH	1	
7		LAMP ADJUSTABLE SWITCH	1	
8	1017000942	POWER REARVIEW MIRROR SWITCH WITH ANTI- THEFT LAMP ASSY.	2	
9		IGNITION SWITCH ASSY.	1	
10	1017000703	IGNITION SWITCH LOWER BRACKET	1	
	1017000707	IGNITION SWITCH UPPER BRACKET	1	
11	1017000705	IGNITION LOCK LOCKING NUT	1	
12	1017000948	WARNING LAMP SWITCH	2	
13	1017000947	A/C SWITCH	1	
14	1017000946	BLOWER SWITCH	1	
15	1017000949	I/O CIRCLE SWITCH	1	
16	1017000950	RF SAFTEY BELT INDICATOR LIGHT	1	
17	1017002565	REAR DOOR WINDOW REGULATOR CONTROL SWITCH & PANEL ASSY.	1	
18	1017002564	RF DOOR WINDOW REGULATOR CONTROL SWITCH & PANEL ASSY.	2	
19	372010001	BRAKE LIGHT SWITCH	1	
20	1017002563	LF WINDOW REGULATOR CONTROL SWITCH & PANEL ASSY.	1	
21	1017000872	DOOR CONTROL SWITCH WITH WIRING	1	
	1017009987	FRONT DOOR CONTROL SWITCH	1	
	1017009988	REAR DOOR CONTROL SWITCH	1	

7030 FRONT HEADLIGHT ASSY.


	NO.	PART NO.	DES.	QTY	REMARK	
	1		CROSS HEAD SELF-TAPPING SCREW & WASHER ASSY.	1		
	2	1018005273	FRONT HEADLIGHT FIXING CLIP	8		
	3		THROUGH HOLE PLASTIC NUT	2		
	4	1017001093	LEFT HEADLIGHT ASSY.	1		
	5	1017001094	RIGHT HEADLIGHT ASSY.	1		
		1017010346	FRONT HEADLIGHT ADJUSTER MOTOR	1		
		1017009814	LEFT HEADLIGHT ASSY.	1	HEADLIGHT ADJUSTER	
		1017009815	RIGHT HEADLIGHT ASSY.	1	HEADLIGHT ADJUSTER	

7040 FRONT FOGLIGHT ASSY.


	NO.	PART NO.	DES.	QTY	REMARK
	1		HEXAGON FLANGE BOLT	4	
	2		"B" TYPE REED NUT	4	
	3	1017001245	LF FOGLIGHT ASSY.	1	
		1017001246	RF FOGLIGHT ASSY.	1	
	4	1058000021	LEFT TURNING SIGNAL LAMP COVER	1	
		1058000023	RIGHT TURNING SIGNAL LAMP COVER	1	

7050 INTERIOR DOME LAMP


NO.	PART NO.	DES.	QTY	REMARK
1	1017001443	REAR READING LAMP ASSY.	1	
2		CROSS SLOTTED HEAD SELF-TAPPING SCREW	2	




7060 SUNROOF SWITCH ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1017001445	SUNROOF SWITCH	1	
	2	1017001444	FRONT READING LAMP ASSY.	1	
	3		CROSS SLOTTED HEAD SELF-TAPPING SCREW	2	


7070 REAR COMBINATION LAMP

	NO.	PART NO.	DES.	QTY	REMARK
	1	1017001549	LR COMBINATION LAMP ASSY.	1	SPECIAL CHILE
		1017001550	RR COMBINATION LAMP ASSY.	1	
		1017009820	LR COMBINATION LAMP ASSY.	1	
	2		HEXAGON FLANGE NUT	6	
	3	1017001109	TAILLIGHT CLIP	2	

7080 REAR LICENSE PLATE LAMP ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
		1017001748	REAR LICENSE PLATE LAMP ASSY.	1	


7090 HEIGHT-MOUNT BRAKE LAMP ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
		1017001944	HEIGHT-MOUNT BRAKE LAMP ASSY.	1	W/O HOLE
		1017010259	HEIGHT-MOUNT BRAKE LAMP ASSY.	1	2 HOLES

7100 WIPER ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1017002049	WIPER MOTOR & CONNECTING ROD ASSY.	1	
		1017002075	WIPER MOTOR	1	
		1017015254	CONNECTING ROD	1	
	2		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	
	3	1017002069	MASTER WIPER BLADE	1	
	4	1017002070	SECOND WIPER BLADE	1	
	5		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	
	6	1017002071	MASTER WIPER ARM	1	
	7	1017002072	SECOND WIPER ARM	1	
8	1017002051	MASTER WIPER BLADE & ARM ASSY.	1		
9	1017002052	SECOND WIPER BLADE & ARM ASSY.	1		

7110 BACK DOOR WIPER ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1017002087	BACK DOOR WIPER MOTOR ASSY.	1	
	2	1017002088	BACK DOOR WIPER BADLE & ARM ASSY.	1	
	3		HEXAGON FLANGE NUT	2	
		1017015259	WIPER NUT COVER	1	

7120 WINDSHIELD WASHER ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1017002220	WATER RESERVIOR WITH WASHER MOTOR	1	
		1017002192	WASHER MOTOR	1	
	2		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	3	
	3	1017002185	WASHER NOZZLE	1	
	4	1017002187	WASHER HOSE	1	
	5		WASHER HOSE FIXING CLIP 1#	1	
	6		WASHER HOSE FIXING CLIP 2#	1	
	7	1017002224	REAR WASHER HOSE 3#	1	
	8	1017002225	REAR WASHER HOSE JOINT	2	
	9	1017002226	REAR WASHER HOSE BOOT	1	
	10	1017002221	REAR WASHER NOZZLE	1	
	11	1017002223	REAR WASHER HOSE 2#	1	
	12	1017002227	HOSE BOOT	1	
	13	1017002222	REAR WASHER HOSE 1#	1	
14		CLIP	2		

7130 SINGLE CD-ROM ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1017002787	ANTENNA ASSY.	1	
	2		CROSS SLOTTED HEAD SELF-TAPPING SCREW	4	
	3	1017002804	SINGLE CD-ROM WITH BRACKET ASSY.	1	
	4	1017002768	FRONT ALT-SPEAKER	2	
	5		CROSS SLOTTED HEAD SELF-TAPPING SCREW	4	
	6	1017002754	FRONT DOOR SPEAKER	4	
	7		BIG WASHER	12	
	8		COTTER TYPE RIVET	12	


7140 RADIO ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1017002787	ANTENNA ASSY.	1	
	2		CROSS SLOTTED HEAD SELF-TAPPING SCREW	1	
	3	1017002803	RADIO RECORDER	4	
	4	1017002754	FRONT DOOR SPEAKER	1	
	5		BIG WASHER	4	
	6		COTTER TYPE RIVET	12	

7150 SINGLE CD-ROM + MP3 ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1017002787	ANTENNA ASSY.	1	
	2		CROSS SLOTTED HEAD SELF-TAPPING SCREW	4	
	3	1017002806	SINGLE CD-ROM + MP3	1	
	4	1017002768	FRONT ALT-SPEAKER	2	
	5		CROSS SLOTTED HEAD SELF-TAPPING SCREW	4	
	6	1017002754	FRONT DOOR SPEAKER	4	
	7		BIG WASHER	12	
	8		COTTER TYPE RIVET	12	
	9	1017002784	128MB FLASH	1	
	10	1017002785	U-FLASH CONNECTING WIRE	1	


7160 CIGARETTE LIGHTER ASSY.



NO.	PART NO.	DES.	QTY	REMARK
	372510000205-01	CIGARETTE LIGHTER	1	

7170 HORN ASSY.(BASIN TYPE)

NO.	PART NO.	DES.	QTY	REMARK
1	1067000045	BASS-HORN ASSY.	1	
	1067000216	ALT-HORN ASSY.	1	
2		GB9074.17M8*16 HEXAGON HEAD BOLT	1	



The diagram shows an exploded view of the horn assembly. Part 1 is the horn assembly, which includes a circular horn with a central hub and a mounting bracket. Part 2 is a hexagon head bolt that fits into the mounting bracket.

7180 BATTERY ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1017003338	BATTERY BRACKET	1	
	2	1017003336	BATTERY PRESSURE BOARD ASSY.	1	
	3	3703100001	BATTERY	1	
	4	1017003337	BATTERY PULL ROD	1	
	5		HEXAGON FLANGE LOCKING NUT	2	
			3703240005	BATTERY TERMINAL SUB-ASSY.	1

7190 ON-BOARD HANDSFREE PHONE ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1		MIC LINKER	1	
	2		ON-BOARD HANDSFREE PHONE CONNECTING PANEL	1	
	3		CROSS SLOTTED HEAD SELF-TAPPING SCREW	2	
	4	1017003922	ON-BOARD HANDSFREE PHONE	1	
	5		MIC LINKER CONNECTING	1	
	6	1017003924	ON-BOARD HANDSFREE PHONE CONNECTING	1	MOTOLORA
	7	1017003925	ON-BOARD HANDSFREE PHONE CONNECTING	1	NOKIA
	8	1017003926	ON-BOARD HANDSFREE PHONE CONNECTING	1	SIMENS

7200 SRS ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1017003537	SRS ECU	1	
	2		HEXAGON FLANGE NUT	5	
	3	1018011092	DAB MODULE ASSY.	1	
	4		INNER HEXAGON FLOWER TYPE HEAD SCREW	2	
	5	1017003546	PAB MODULE ASSY.	1	
	6		HEXAGON FLANGE NUT	1	
	7		HEXAGON FLANGE BOLT	1	
		1017003539	CLOCK SPRING	1	


7210 FRONT WIRING HARNESS ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1017009871	ENGINE COMPARTMENT WIRING HARNESS	1	
		1017000340	ENGINE COMPARTMENT WIRING HARNESS	1	HEADLIGHT ADJUSTER
	2		HEXAGON HEAD BOLT & SPRING WASHER ASSY.	2	
	3		HEXAGON FLANGE NUT	1	
	4	Q1460625	HEXAGON HEAD BOLT & SPRING WASHER ASSY.	1	
	5		BOOT 1# (COWL PANEL)	1	
	6		BOOT 2# (WIPER MOTOR)	1	
	7	1017004249	FUSE BOX ASSY.	1	
	8	1017004245	FUSE BOX COVER	1	
	9	1017004246	FUSE BOX BLOCK	1	
	10		FUSE BOX LOWER PART	1	
11		EMBLEM	1		

7220 INSTRUMENT PANEL WIRING HARNESS

	NO.	PART NO.	DES.	QTY	REMARK
	1	1017004479	INSTRUMENT PANEL WIRING HARNESS ASSY.	1	AT
	2	1017004494	INSTRUMENT PANEL WIRING HARNESS ASSY.	1	MT
		1017010338	INSTRUMENT PANEL WIRING HARNESS ASSY.	1	HEADLIGHT ADJUSTER
	3		FUSE BOX	1	
	4	Q1460616	HEXAGON HEAD BOLT & SPRING WASHER ASSY.	2	
	5		HEXAGON FLANGE SELF-TAPPING SCREW	1	
	6		FRONT DOOR WIRING HARNESS FIXING BRACKET	2	
	7		CROSS SLOTTED HEAD SELF-TAPPING SCREW	2	
	8		INSTRUMENT PANEL WIRING HARNESS FIXING BRACKET	1	
9		EMBLEM	1		

7230 ABS SYSTEM ASSY.




NO.	PART NO.	DES.	QTY	REMARK
1	1017009293	LF WHEEL SENSOR ASSY.	1	
2		LF WHEEL SENSOR	1	
3		FRONT FIXING CLIP	2	
4		CLIP	1	
5	1017009294	RF WHEEL SENSOR ASSY.	1	
6		RF WHEEL SENSOR	1	
7		CLIP	1	
8	1017009296	REAR WHEEL SENSOR	2	
9		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	4	
10	1017009299	LR WHEEL SENSOR WIRING HARNESS ASSY.	1	
11		LR WHEEL SENSOR WIRING HARNESS	1	
12		LR FIXING CLIP 1#	1	
13		LR FIXING CLIP 2#	1	
14		STRIP	2	
15	1017009300	RR WHEEL SENSOR WIRING HARNESS ASSY.	1	
16		RR WHEEL SENSOR WIRING HARNESS	1	
17		RR FIXING CLIP 1#	1	
18		RR FIXING CLIP 2#	1	
19		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	6	
20	1017009279	WARNING LAMP MODULE	1	

7240 BODY WIRING HARNESS

	NO.	PART NO.	DES.	QTY	REMARK	
	1	1017004860	BOTTOM WIRING HARESS ASSY.	1	BEFORE 2009.4 AFTER 2009.4	
		1017015159	BOTTOM WIRING HARESS ASSY.	1		
		1017005627	REAR DOOR WIRING HARNESS ASSY.	1		
		1017004861	BACK DOOR WIRING HARNESS ASSY.	1		
		1017005484	RF DOOR WIRING HARNESS ASSY.	1		
		1017005333	LF DOOR WIRING HARNESS ASSY.	1		
		1017004513	SUNROOF WIRING HARNESS ASSY.	1		
		2		FUEL PUMP BOOT	1	
		3		LICENSE PLATE BOOT	1	
		4	Q1460616	HEXAGON HEAD BOLT & SPRING WASHER ASSY.	2	
		5		RUBBERIZED FABRIC	3	
			1017004846	DEFROST GROUND WIRE	1	


7250 BATTERY GROUND

NO.	PART NO.	DES.	QTY	REMARK
1	1017005953	BATTERY GROUND	1	
2	Q1460616	HEXAGON HEAD BOLT & SPRING WASHER ASSY.	1	
3		HEXAGON HEAD BOLT & SPRING WASHER ASSY.	1	



The diagram illustrates the assembly of the battery ground. Part 1 is the main ground cable, which has a ring terminal at the top and a hook terminal at the bottom. Part 2 is a hexagon head bolt and spring washer assembly, shown being inserted into the hook terminal. Part 3 is another hexagon head bolt and spring washer assembly, shown being inserted into the ring terminal.


7260 CENTER CONTROLLER




NO.	PART NO.	DES.	QTY	REMARK
1	1017002356-01	CENTER CONTROLLER	1	
2		HEXAGON FLANGE NUT	4	
3	1017003351	CENTER CONTROLLER FIXING BRACKET	1	
4		CROSS SLOTTED HEAD SELF-TAPPING SCREW	2	
5		CROSS SLOTTED HEAD SCREW & PLAIN WASHER ASSY.	2	
6	1017003349	REMOTE CONTROL	2	

7270 PARKING SENSOR ASSY.


NO.	PART NO.	DES.	QTY	REMARK
1	1017003724	PARKING SENSOR CONTROL	1	
2	1017003426	PARKING SENSOR	2	
3	1017003728	SENSOR WIRING HARNESS	1	
4		HEXAGON HEAD CROSS SLOTTED BOLT & WASHER ASSY.	1	




7280 FUSE BOX



A-1




A-2




熔断器盒

A-3



NO.	PART NO.	DES.	QTY	REMARK
1		FUSE LINKER	2	
2	JQDBL30	FLAT TYPE FUSE	2	
	JQDBL40	FLAT TYPE FUSE	1	
	JQDBL60	FLAT TYPE FUSE	2	
3	JQDCAL30	PLUG TYPE FUSE	2	
	JQDCAL20	PLUG TYPE FUSE	2	
4	JQDPDL10	PLATE TYPE FUSE	18	
	JQDPDL15	PLATE TYPE FUSE	7	
	JQDPDL20	PLATE TYPE FUSE	9	
	JQDPDL30	PLATE TYPE FUSE	1	
	JQDPDL7.5	PLATE TYPE FUSE	1	
5	JQDJDQ-B	RELAY	8	
6	JQDJDQ-C	RELAY	3	
	1057004472	WIPER RELAY	1	
	1057004744	FLASH RELAY	1	

7290 ECU BRACKET



NO.	PART NO.	DES.	QTY	REMARK
1	1086001116	ENGINE ECU(OBD)(M7.9)	1	EURO III
	2150110008-01	ENGINE ECU(M7.9)	1	EURO III
	1016003479	ENGINE ECU(OBD)(M7.8)	1	EURO III
	1016000619	ENGINE ECU	1	EURO IV
	1016003881	ENGINE ECU(ANTI-THEFT)	1	EURO IV
2	1017007059	ECU LEFT BRACKET ASSY.	1	
3	1017007056	ECU RIGHT BRACKET ASSY.	1	
4		CROSS SLOTTED HEAD SELF-TAPPING SCREW	1	
5		CROSS SLOTTED HEAD SELF-TAPPING SCREW	2	
6	1017007062	CLIP	1	
7		HEXAGON FLANGE BOLT	4	

7300 COMPRESSOR ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018002690	COMPRESSOR ASSY.	1	
	2	Q150B08105	HEXAGON HEAD BOLT	4	
	3		PLAIN WASHER	4	
	4		SPRING WASHER	4	
	5	1018002691	COMPRESSOR BRACKET	1	
	6		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	3	
	7		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	
	8	1018002692	TENSIONER ASSY.	1	
	9	1018002703	COMPRESSOR DRIVE BELT 4PK-820	1	

7310 A/C PIPELINE ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1017009661	COMPRESSOR DISCHARGE HOSE	1	
		1017010291	COMPRESSOR SIDE SEAL	1	φ10.8×1.9
		1067000232	LIQUID PIPE SIDE SEAL	1	φ10.8×2.4
	2	1018002700	COMPRESSOR SUCTION HOSE	1	
		1017010292	COMPRESSOR SIDE SEAL	1	φ14×1.9
		1067000233	LOWER PRESSURE SIDE SEAL	1	φ13.8×2.4
	3		HEXAGON HEAD BOLT & SPRING WASHER ASSY.	2	
	4		SINGEL PIPE CLIP	1	
	5		CROSS SLOTTED HEAD BOLT & PLAIN WASHER ASSY.	5	
	6	1018002701	LIQUID PIPE	1	
	1067000232	CONDENSER SIDE SEAL	1	φ10.8×2.4	
7	1017009660	HIGH/LOW PRESSURE PIPE ASSY.	1		
	1017010295	CONDENSER SIDE SEAL	1	φ6.8×1.9	
	1067000233	LOWER PRESSURE SIDE SEAL	1	φ13.8×2.4	
8		DUAL PIPE CLIP	1		
9	Q1460616	HEXAGON HEAD BOLT & SPRING WASHER ASSY.	2		
10	1018002714	PRESSURE SWITCH	1		

7320 CONDENSER ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1017009659	CONDENSER ASSY.	1	
	2		HEXAGON FLANGE LOCKING SCREW	2	M8×32
	3		CONDENSER UPPER CUSHION	2	
	4		CONDENSER LOWER CUSHION	2	
	5	1018002718	CONDENSER FAN MOTOR ASSY.	1	
		1017001413	CONDENSER FAN MOTOR ASSY.	1	AT
	6		CROSS SLOTTED HEAD BOLT & PLAIN WASHER ASSY.	1	M6×30
	7	1018002726	CONDENSER FAN UPPER CUSHION	1	
8	1018002727	CONDENSER FAN LOWER CUSHION	2		

7330 HVAC ASSY.


	NO.	PART NO.	DES.	QTY	REMARK
	1	1017008223	HVAC	1	
	2		HEXAGON HEAD NUT & SPRING WASHER ASSY.	5	M6
	3		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	
	4		SEALING	1	
	5		DRAINPIPE SEALING	1	
	6	1017008027	1# WATER PIPE	1	
	7	8101706106	WATER VALVE SWITCH	1	
	8	1017008028	2# WATER PIPE	1	
	9		DUAL STEEL WIRE HOOP	4	
	10	1018002622	DRAINPIPE	1	
	11	1017008045	1# DUAL HALF-ROUND CLIP	1	
	1017008046	2# DUAL HALF-ROUND CLIP	1		
	1017008172	3# WATER PIPE	1		

7340 HVAC SUB-ASSY.






















	NO.	PART NO.	DES.	QTY	REMARK
	1		UPPER CASING	1	
	2		LOWER CASING	1	
	3		AIR INTAKE CASING	1	
	4		CROSS SLOTTED HEAD SELF-TAPPING SCREW	14	ST3.8×16
	5	1018002732	EVAPORATOR ELEMENT	1	
	6	1018002733	THERMISTOR	1	
	7	1018002734	"H" TYPE EXPANSION	1	
	8		INNER HEXAGON ROUND HEAD SCREW	2	M5×35
	9	1018002735	HEATER ELEMENT	1	
	10		HEATER ELEMENT CLIP	1	
	11		CROSS SLOTTED HEAD SELF-TAPPING SCREW	1	ST3.8×14
	12	1018002736	BLOWER MOTOR & IMPELLER ASSY.	1	
	13		CROSS SLOTTED HEAD SELF-TAPPING SCREW	3	ST5.0×16
	14	1018002760	ADJUSTABLE RESISTOR	1	
	15		REAR VENT CASING	1	
	16		SCREEN BRACKET	1	
	17	1018002773	AIR SCREEN	1	
	18		ACTUATOR ASSY.	1	
	19		CROSS SLOTTED HEAD SCREW & WASHER ASSY.	3	

7350 A/C CONTROLLER



















NO.	PART NO.	DES.	QTY	REMARK
1	1017008211	A/C CONTROLLER	1	
2		CROSS SLOTTED HEAD SELF-TAPPING SCREW	2	
3	1018002705	KNOB	3	





PICTURE INDEX

<p style="text-align: center;">8000 TRIM</p>	<p>8010 TOOLS & ACCESSORIES</p> 	<p>8020 FLOOR INTERIOR TRIM & ACCESSORY</p> 	<p>8030 CARPET & INSULATOR</p> 	<p>8040 INSTRUMENT PANEL FRAME</p> 	<p>8050 INSTRUMENT PANEL ASSY.</p> 	<p>8060 GLOVE COMPARTMENT</p> 
<p>8210 RF DOOR WEATHERSTRIP</p> 						<p>8070 INSTRUMENT PANEL LOWER PART</p> 
<p>8200 RF DOOR INTERIOR TRIM</p> 						<p>8080 I/P CENTER UPPER PANEL</p> 
<p>8190 LF DOOR LOCK & HANDLE</p> 						<p>8090 I/P CENTER LOWER PANEL</p> 
<p>8180 LF DOOR WEATHERSTRIP</p> 						<p>8100 I/P UPPER PART</p> 
<p>8170 LF DOOR INTERIOR TRIM BOARD ASSY.</p> 	<p>8160 LF DOOR INTERIOR TRIM</p> 	<p>8150 ROOF INTERIOR TRIM</p> 	<p>8140 ROOF INTERIOR TRIM</p> 	<p>8130 SAFETY BELT ASSY.</p> 	<p>8120 TRUNK INTERIOR TRIM</p> 	<p>8110 SIDE WALL INTERIOR TRIM</p> 

PICTURE INDEX

<p style="text-align: center;">8000 TRIM</p>	<p>8220 RF DOOR INTERIOR TRIM BOARD ASSY.</p>	<p>8230 RF DOOR LOCK & HANDLE</p> 	<p>8240 FRONT DOOR WINDOW RE</p> 	<p>8250 LR DOOR INTERIOR TRIM</p> 	<p>8260 LR DOOR LOCK & HANDLE</p> 	<p>8270 LR DOOR INTERIOR TRIM BOARD ASSY.</p>
<p>8420 REARVIEW MIRROR</p> 						<p>8280 LR DOOR WEATHERSTRIP</p> 
<p>8410 EXTERIOR TRIM</p>  <p style="text-align: right;">6</p>						<p>8290 RR DOOR INTERIOR TRIM</p> 
<p>8400 FRONT WINDSHIELD ASSY.</p>  <p style="text-align: right;">4</p>						<p>8300 RR DOOR WEATHERSTRIP</p> 
<p>8390 REAR BUMPER ASSY.</p>  <p style="text-align: right;">2</p>						<p>8310 RR DOOR INTERIOR TRIM BOARD ASSY.</p>
<p>8380 FRONT BUMPER ASSY.</p>  <p style="text-align: right;">1</p>	<p>8370 REAR SEAT ASSY.</p> 	<p>8360 BACK DOOR INTERI</p> 	<p>8350 RF SEAT ASSY.</p> 	<p>8340 LF SEAT ASSY.</p> 	<p>8330 REAR DOOR GLASS REGULATOR</p> 	<p>8320 RR DOOR LOCK & HANDLE</p> 

PICTURE INDEX

8000 TRIM	8430 SUNROOF ASSY 	8440 SEAT REPAIR KIT	8450 ENGINE HOOD INTERIOR TRIM  32			

8010 TOOLS & ACCESSORY

	NO.	PART NO.	DES.	QTY	REMARK
<p> 1: Jack assembly 2: Jack rocker 3: Screwdriver 4: Tire sleeve 5: Slip joint plier 6: Onboard toolkit 7: Triangular warning plate assembly 8: Triangular warning plate box 9: Triangular warning plate </p>	1	1018004850	JACK ASSY.	1	
	2	1018004851	JACK ROCKER	1	
	3		SCREWDRIVER	1	
	4		TIRE SLEEVE	1	
	5		SLIP JOINT PLIER	1	
	6		ONBOARD TOOLKIT	1	
	7	3922000180	TRIANGULAR WARNING PLATE ASSY.	1	
	8		TRIANGULAR WARNING PLATE BOX	1	
	9		TRIANGULAR WARNING PLATE	1	


8020 FLOOR INTERIOR TRIM & ACCESSORY

	NO.	PART NO.	DES.	QTY	REMARK
	1		CLIP	8	
	2	1018006338	CARPET ASSY.	1	
	3	1018005710	"E" TYPE CLIP	1	
	4	1018005709	FLEX CLIP	1	
	5		RIGHT FOOT MAT	1	
	6		LEFT FOOT MAT CLIP	1	
	7		LEFT FOOT MAT CLIP SEAT	1	
	8		LEFT FOOT MAT	1	
	9		FIRE EXTINGUISHER ASSY.	1	
	10		CROSS SLOTTED HEAD BOLT & PLAIN WASHER ASSY.	2	
	11	1018003950	FIRE EXTINGUISHER BRACKET	1	

8030 CARPET & INSULATOR

	NO.	PART NO.	DES.	QTY	REMARK
	<p>1 2 3 4 5 6 7</p> <p>12 11 10 9 8</p>	1	1018005688	ENGINE HOOD SOUND INSULATOR	1
	2	1018004659	COWL PANEL OUTER PANEL HEAT INSULATOR	1	
	3	1018004658	COWL PANEL SOUND INSULATOR ASSY.	1	
	4	1018005087	RF PILLAR SOUND INSULATOR	1	
	5	1018005793	ROOF HEAT INSULATOR (860×150×5)	2	
	6	1018005794	ROOF HEAT INSULATOR (820×280×5)	2	
	7		REAR BAFFLE PLATE SOUND INSULATOR	1	
	8	1018005704	FRONT FLOOR RR SOUND INSULATOR	1	
	9	1018005702	FRONT FLOOR LR SOUND INSULATOR	1	
	10	1018005703	FRONT FLOOR RF SOUND INSULATOR	1	
	11	1018005701	FRONT FLOOR LF SOUND INSULATOR	1	
	12	1018005086	LF PILLAR SOUND INSULATOR	1	


8040 I/P CROSS MEMBER ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018005209	INSTRUMENT PANEL RIGHT SHIELD PLATE	1	
	2		HEXAGON FLANGE NUT	1	
	3		HEXAGON FLANGE BOLT	1	
	4	1012000524	INSTRUMENT PANEL RIGHT FIXING BRACKET ASSY.	1	
	5	1012005488	INSTRUMENT PANEL SUPPORT ROD ASSY.	1	
	6	1012000455	INSTRUMENT PANEL LEFT FIXING BRACKET ASSY.	1	
	7	Q32008	HEXAGON FLANGE NUT	9	
	8		HEXAGON FLANGE BOLT	6	
	9	Q1460616	HEXAGON HEAD BOLT & SPRING WASHER ASSY.	8	
	10	1018005208	INSTRUMENT PANEL LEFT SHIELD PLATE	1	
	11	1018006102	CROSS MEMBER ASSY.	1	

8050 INSTRUMENT PANEL ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018008134	COMBINATION METER COVER	1	
	2	1018006083	INSTRUMENT PANEL CENTER UPPER PANEL ASSY.	1	
	3	1018008202	INSTRUMENT PANEL UPPER PART ASSY.	1	
	4	1018006080	INSTRUMENT PANEL LOWER PART ASSY.	1	
	5	1018006088	INSTRUMENT PANEL CENTER LOWER PANEL ASSY.	1	
	6	1018005920	GLOVE COMPARTMENT	1	
	7	1018005204	A/C LOWER RIGHT VENT PIPE	1	
	8	1018005255	A/C LOWER RIGHT CONNECTING PIPE	1	
	9	1018006094	CONSOLE ARMREST BOX ASSY.	1	
	10	1018005927	CONSOLE FRAME	1	
	11	1018005237	PARKING BRAKE COVER BOARD	1	
	12	1018005254	A/C LOWER LEFT CONNECTING PIPE	1	
	13	1018005203	A/C LOWER LEFT VENT PIPE	1	
	14	1018005236	CUP SEAT	1	
	15	1018005901	COMBINATION SWITCH LOWER TRIM COVER	1	
	16	1018005900	COMBINATION SWITCH UPPER TRIM COVER	1	
	17		HEXAGON HEAD BOLT & SPRING WASHER ASSY.	2	
	18	JQ691F06	"E" TYPE CLIP	2	
	19		HEXAGON HEAD BOLT & SPRING WASHER ASSY.	2	
	20		CROSS SLOTTED HEAD SELF-TAPPING SCREW	13	
	21	1018005866	"E" TYPE CLIP(FOR CONSOLE)	2	φ8
	22		CROSS SLOTTED HEAD SELF-TAPPING LOCKING SCREW	2	
	23		CROSS SLOTTED HEAD SELF-TAPPING SCREW	1	
	24		COMBINATION SWITCH UPPER TRIM COVER PLUG	1	
	25		HEXAGON FLANGE NUT	2	

8060 GLOVE COMPARTMENT



NO.	PART NO.	DES.	QTY	REMARK
1		GLOVE COMPARTMENT FRAME	1	
2		GLOVE COMPARTMENT COVER	1	
3		GLOVE COMPARTMENT CUSHION BLOCK(L/R)	2	
4	1018005244	GLOVE COMPARTMENT LOCK BUCKLE	1	
5		GLOVE COMPARTMENT CUSHION BLOCK(CENTER)	1	
6	1018005243	GLOVE COMPARTMENT HANDLE	1	
7		GLOVE COMPARTMENT SOUND INSULATOR	1	

8070 INSTRUMENT PANEL LOWER PART

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018005312	LEFT SOUND INSULATOR	1	
	2	1018005920	GLOVE COMPARTMENT ASSY.	1	
	3	1018005314	CENTER LEFT SOUND INSULATOR	1	
	4		CENTER VENT PIPE	1	
	5	1018005315	CENTER RIGHT SOUND INSULATOR	1	
	6	1018005919	ENGINE HOOD CONTROL HANDLE ASSY.	1	
	7		CROSS SLOTTED HEAD SELF-TAPPING SCREW	12	
	8		INSTRUMENT PANEL LOWER PART FRAME	1	
	9	1018005313	RIGHT SOUND INSULATOR	1	
	10		GLOVE COMPARTMENT LOCK BUCKLE	1	
	11		FUSE BOX COVER	1	
	12	1018008143	LEFT CONNECTING BRACKET	1	
	13	1018008144	RIGHT CONNECTING BRACKET	1	

8080 INSTRUMENT PANEL CENTER UPPER PANEL

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018008121	CENTER RIGHT VENT ASSY.	1	
	2	1018006083	INSTRUMENT PANEL CENTER UPPER PANEL SUB-ASSY.	1	
	3		TOOL BOX	1	
	4		TOOL BOX COVER INTERIOR PLATE	1	
	5		TOOL BOX COVER EXTERIOR PLATE	1	
	6	1018006085	CENTER LEFT VENT ASSY.	1	
	7		NYLON CLIP	6	
	8		NYLON BLOCK	1	
	9		CROSS SLOTTED HEAD SELF-TAPPING SCREW	2	
	10		TOOL BOX SPRING	1	
	11		TOOL BOX SWITCH	1	

8090 INSTRUMENT PANEL CENTER LOWER PANEL

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018008274	VANE EMBLEM	1	
	2		INSTRUMENT PANEL CENTER LOWER PANEL FRAME	1	
	3		NYLON CLIP	2	
	4		ASHTRAY FRONT BRACKET	1	
	5		RIGHT SLIDE RAIL	1	
	6		ASHTRAY REAR BRACKET	1	
	7		ASHTRAY COVER	1	
	8	1018005933	ASHTRAY ASSY.	1	
	9		LEFT SLIDE RAIL	1	
	10	1018008273	WIND SPEED EMBLEM	1	
	11	1018008272	COOL/HEAT EMBLEM	1	
	12	1018005925	RAY GUIDE PALTE	1	

8100 INSTRUMENT PANEL UPPER PART

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018008202	INSTRUMENT PANEL UPPER PART SUB-ASSY.	1	W/O PAB
2		UPPER SOUND INSULATOR (250×130×10)	1		
3		UPPER SOUND INSULATOR (150×150×10)	1		
4		CROSS SLOTTED HEAD SELF-TAPPING SCREW	4		
5		RIGHT VENT PIPE	1		
6	1018006076	DEFROST VENT PIPE ASSY.	1		
7		DEFROST VENT PIPE REAR COVER	1		
8		DEFROST VENT PIPE FRONT COVER	1		
9		LEFT VENT PIPE	1		
10		UPPER SOUND INSULATOR (400×400×10)	1		
11		SPONGE (SHORT)	1		
12	1018006073	SIDE VENT ASSY.	2		
13		SPONGE (LONG)	1		
14		UPPER SOUND INSULATOR (150×370×10)	1		

8120 TRUNK INTERIOR TRIM & ACCESSORY

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018006051	TRUNK COMPARTMENT TRIM BOARD ASSY.	1	
	2	1018006058	UPPER BAFFLE PLATE RIGHT SUPPORT	1	
	3	1018006053	RIGHT TRIM BOARD	1	
	4	JQ691C66	"E" TYPE CLIP	8	
	5	1018006065	RIGHT TOOL BOX ASSY.	1	
	6	1018008120	RIGHT TOOL BOX MOUNTING PLATE	1	
	7		HEXAGON FLANGE BOLT M6X12	2	
	8	1018006062	SPARE WHEEL COVER BOARD	1	
	9	3922000180	TRIANGLE WARNING PLATE ASSY.	1	
	10		LEFT TOOL BOX MOUNTING PLATE	1	
	11	1018006063	LEFT TOOL BOX ASSY.	1	
	12	1018006052	LEFT TRIM BOARD	1	
	13	1018006165	REAR END PANEL VENT ASSY.	1	
	14		HEXAGON FLANGE BOLT M6X12	6	
	15	1018006056	UPPER BAFFLE PLATE LEFT SUPPORT	1	
	16		REAR END PANEL INTERIOR TRIM BOARD ASSY.	1	
	17	JQ691C66	"E" TYPE CLIP	4	
	18	1012012205	BACK DOOR SEALING	1	
	1018008269	REAR GEELY LOGO	1		


8130 SAFETY BELT ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018003024	LONG-DISTANCE ADJUSTER ASSY.	2	
		1018009123	LONG-DISTANCE ADJUSTER ASSY.	2	E-MARK
	2	1018005764	LF SAFETY BELT ASSY.	1	
		1018005870	LF SAFETY BELT ASSY.(PRETENSIONER)	1	
		1018009128	LF SAFETY BELT ASSY.(PRETENSIONER)	1	E-MARK
	3	1018005766	RF SAFETY BELT ASSY.	1	
		1018005878	RF SAFETY BELT ASSY.(PRETENSIONER)	1	
		1018009129	RF SAFETY BELT ASSY.(PRETENSIONER)	1	E-MARK
	4	1018005887	LF SAFETY BELT BUCKLE ASSY.	1	
		1018009126	LF SAFETY BELT BUCKLE ASSY.	1	E-MARK
	5	1018005888	RF SAFETY BELT BUCKLE ASSY.	1	
		1018009127	RF SAFETY BELT BUCKLE ASSY.	1	E-MARK
	6	1018005884	LR SAFETY BELT BUCKLE ASSY.	1	
		1018010913	LR SAFETY BELT BUCKLE ASSY.	1	E-MARK
	7	1013000058	REAR SEAT CENTER SAFETY BELT ASSY.	1	
		1018009133	REAR SEAT CENTER SAFETY BELT ASSY.	1	E-MARK
	8	1018006106	LR SAFETY BELT ASSY.	1	
		1018009130	LR SAFETY BELT ASSY.	1	E-MARK
		1013000059	LR SAFETY BELT LOCK BUCKLE	1	
		1013000034	LR SAFETY BELT LOCK BUCKLE	1	E-MARK
9	1018005886	RR SAFETY BELT BUCKLE & LAP BELT ASSY.	1		
	1018006107	RR SAFETY BELT ASSY.	1		
	1018010914	RR SAFETY BELT ASSY.	1	E-MARK	

8140 ROOF INTERIOR TRIM & ACCESSORY(W/O SUNROOF)

	NO.	PART NO.	DES.	QTY	REMARK
	1	1058005673	RIGHT SUN VISOR ASSY.	1	
	2	1018005123	SUN VISOR CLIP SEAT	2	
	3	1018005800	SUN VISOR CLIP	2	
	4	1058005671	LEFT SUN VISOR ASSY.	1	
	5		CROSS SLOTTED HEAD SELF-TAPPING SCREW	4	
	6	1018006305	ROOF INTERIOR TRIM BOARD	1	BEFORE 2009.4 AFTER 2009.4
	7	1018015655	ROOF INTERIOR TRIM BOARD	1	
	7	1018002069	LR SAFETY PULL HANDLE ASSY.	1	
	8	1018006306	ROOF INTERIOR TRIM BOARD CUSHION BLOCK	2	
	9	1018005803	"E" TYPE CLIP	3	
	10	1018001982	RR SAFETY PULL HANDLE ASSY.	1	
	11		CROSS SLOTTED HEAD SCREW	6	
12	1018002096	FRONT SAFETY PULL HANDLE ASSY.	1		

8150 ROOF INTERIOR TRIM & ACCESSORY(SUNROOF)

	NO.	PART NO.	DES.	QTY	REMARK
	1	1058005673	RIGHT SUN VISOR ASSY.	1	
	2	1018005800	SUN VISOR CLIP	2	
	3		SUN VISOR CLIP SEAT	2	
	4	1058005671	LEFT SUN VISOR ASSY.	1	
	5		CROSS SLOTTED HEAD SELF-TAPPING SCREW	4	
	6	1018005783	ROOF LF INTERIOR LINER	1	
	7	1018006304	ROOF LR INTERIOR LINER	1	
	8	1018002069	LR SAFETY PULL HANDLE ASSY.	1	
	9	1018005333	LR SAFETY PULL HANDLE MOUNTING BRACKET ASSY.	1	
	10		ROOF INTERIOR TRIM BOARD CUSHION BLOCK	2	
	11		"E" TYPE CLIP	3	
	12	1018006302	ROOF INTERIOR TRIM BOARD	1	SUNROOF
	13	1018006305	ROOF RR INTERIOR LINER	1	
	14	1018005335	RR SAFETY PULL HANDLE MOUNTING BRACKET ASSY.	1	
	15	1018001982	RR SAFETY PULL HANDLE ASSY.	1	
	16		CROSS SLOTTED HEAD SCREW	6	
	17		HEXAGON FLANGE TAPER SCREW	6	
	18	1018005798	ROOF RF INTERIOR LINER	1	
	19	1018005334	RF SAFETY PULL HANDLE MOUNTING BRACKET ASSY.	1	
	20	1018002096	FRONT SAFETY PULL HANDLE ASSY.	1	
	21	JQ691F06	"E" TYPE CLIP	4	
	22		HEXAGON FLANGE BOLT	9	

8160 LF DOOR INTERIOR TRIM & ACCESSORY

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018005661	LF DOOR WINDOW REGULATOR	1	
	2	1018005665	FRONT DOOR CHECK	1	
	3		"D" TYPE CLIP	1	
	4	1018005631	LF DOOR INTERIOR QUARTER TRIM	1	
	5		LF DOOR INTERIOR TRIM BOARD ASSY.	1	
	6	1038001715	DOOR CUSHION BLOCK	1	
	7	1018005048	FRONT DOOR HOLE PLUG	1	
	8	1018004706	LF DOOR WATERPROOF FILM	1	
	9		LF DOOR SOUND INSULATOR	1	
	10		LF DOOR WEATHERSTRIP	1	
	11		CROSS SLOTTED HEXAGON HEAD SELF-TAPPING SCREW	2	
	12		LF DOOR LOCK & HANDLE	1	
	13		CROSS SLOTTED HEXAGON HEAD SELF-TAPPING SCREW	1	
	14	1018005629	DOOR INTERIOR TRIM BOARD HANDLE	1	
	15		THROUGH HOLE PLASTIC NUT	3	
	16	1018005992	LF DOOR INTERIOR HANDLE MOUNTING BRACKET	1	

8170 LF DOOR INTERIOR TRIM BOARD ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	JQ690E82	"D" TYPE CLIP	7	
	2		"J" TYPE CLIP	2	
	3	1018005983	LF DOOR INTERIOR TRIM BOARD SUB-ASSY.	1	
	4		LF DOOR INTERIOR TRIM SOUND INSULATOR (465×210×10)	1	
	5		LF DOOR INTERIOR TRIM SOUND INSULATOR (600×420×10)	1	

8180 LF DOOR WEATHERSTRIP

	NO.	PART NO.	DES.	QTY	REMARK
	1	1058005005	LF DOOR WINDOW CHANNEL	1	
	2	1018005633	LF DOOR INTERIOR TRIM BOARD LOWER WEATHERSTRIP	1	
	3	1018004788	LF DOORFRAME WEATHERSTRIP	1	
	4	1018004790	LF DOOR WINDOW EXTERIOR WEATHERSTRIP	1	
	5	1018005477	LF DOOR WEATHERSTRIP ASSY.	1	
	6	1018006174	LF DOOR WINDOW INTERIOR WEATHERSTRIP	1	

8190 LF DOOR LOCK & HANDLE

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018005293	LEFT DOOR INTERIOR UNLOCKING HANDLE ASSY.	1	
	2	JQ398M85	THROUGH HOLE INSERT PLASTIC NUT	1	
	3		"C" TYPE CROSS SLOTTED HEAD SELF-TAPPING SCREW	1	
	4	1058005289	LF DOOR LOCK ASSY.(W/O LOCK ACTUATOR)	1	
		1018005289	LF DOOR LOCK ASSY.	1	
	5		INNER HEXAGON FLOWER HEAD SCREW	3	
	6		CROSS SLOTTED HEAD SCREW & PLAIN WASHER ASSY.	5	
	7		"C" TYPE CROSS SLOTTED HEAD SELF-TAPPING SCREW	1	
	8	1018004995	DOOR EXTERIOR UNLOCKING HANDLE HOLE COVER	1	
	9	1018005039-01	DOOR EXTERIOR UNLOCKING HANDLE ASSY.	1	
	10	1018005039	LF DOOR EXTERIOR UNLOCKING HANDLE MOUNTING BRACKET ASSY.	1	
	11		LF DOOR LOCK CYLINDER ASSY.	1	
	12	1018005043	LOCK STRIKER	1	
	13		INNER HEXAGON FLOWER HEAD SCREW	2	
	14		DOOR EXTERIOR HANDLE FRONT LINER	1	
	15		DOOR EXTERIOR HANDLE REAR LINER	1	
	16	1018011447	KEY & LOCK CYLINDER REPAIR KIT ASSY.	1	
	17		LF DOOR LOCKING CABLE ASSY.	1	
	18		FRONT DOOR INTERIOR UNLOCKING CABLE ASSY.	1	
19		CABLE CLIP	1		
	1018008853	LF DOOR LOCK ACTUATOR ASSY.	1		

8200 RF DOOR INTERIOR TRIM & ACCESSORY

	NO.	PART NO.	DES.	QTY	REMARK
	1		RF DOOR WEATHERSTRIP	1	
	2		RF DOOR WATERPROOF FILM	1	
	3	1018004707	RF DOOR SOUND INSULATOR	1	
	4	1018005048	FRONT DOOR HOLE PLUG	1	
	5	1038001715	DOOR CUSHION BLOCK	1	
	6		RF DOOR INTERIOR TRIM BOARD ASSY.	1	
	7	1018005642	RF DOOR INTERIOR QUARTER TRIM	1	
	8		"D" TYPE CLIP	1	
	9		RF DOOR LOCK & HANDLE	1	
	10	1018005660	RF DOOR WINDOW REGULATOR	1	
	11		CROSS SLOTTED HEAD SELF-TAPPING SCREW	1	
	12	1018005629	DOOR INTERIOR TRIM BOARD HANDLE	1	
	13		THROUGH HOLE PLASTIC NUT	3	
	14		CROSS SLOTTED HEAD SELF-TAPPING SCREW	2	
	15	1018006005	RF DOOR INTERIOR PULL HANDLE MOUNTING BRACKET	1	
	16	1018005665	FRONT DOOR CHECK	1	

8210 RF DOOR WEATHERSTRIP

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018005644	RF DOOR INTERIOR TRIM BOARD LOWER WEATHERSTRIP	1	
	2	1058005006	RF DOOR WINDOW CHANNEL	1	
	3	1018004789	RF DOORFRAME SEALING	1	
	4	1018004791	RF DOOR WINDOW EXTERIOR WEATHERSTRIP	1	
	5	1018005478	RF DOOR SEALING ASSY.	1	
	6	1018006175	RF DOOR WINDOW INTERIOR WEATHERSTRIP	1	



8220 RF DOOR INTERIOR TRIM BOARD ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1		RF DOOR INTERIOR TRIM BOARD SOUND INSULATOR	1	465×210×10
	2	1018005996	RF DOOR INTERIOR TRIM BOARD SUB-ASSY.	1	
	3		"J" TYPE CLIP	2	
	4	JQ690E82	"D" TYPE CLIP	7	
	5		RF DOOR INTERIOR TRIM BOARD SOUND INSULATOR	1	600×420×10

8230 RF DOOR LOCK & HANDLE

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018005294	RIGHT DOOR INTERIOR UNLOCKING HANDLE ASSY.	1	
	2	JQ398M85	THROUGH HOLE INSERT PLASTIC NUT	1	
	3		"C" TYPE CROSS SLOTTED HEAD SELF-TAPPING SCREW	1	
	4	1058005290	RF DOOR LOCK ASSY.(W/O LOCK ACTUATOR)	1	
		1018005290	RF DOOR LOCK ASSY.	1	
	5		INNER HEXAGON FLOWER HEAD SCREW	3	
	6		CROSS SLOTTED HEAD SCREW & PLAIN WASHER ASSY.	2	
	7		"C" TYPE CROSS SLOTTED HEAD SELF-TAPPING SCREW	1	
	8	1018004995	DOOR EXTERIOR UNLOCKING HANDLE HOLE COVER	1	
	9	1018005040-01	DOOR EXTERIOR UNLOCKING HANDLE ASSY.	1	
	10	1018005040	RF DOOR EXTERIOR UNLOCKING HANDLE MOUNTING BRACKET ASSY.	1	
	11		RF DOOR LOCK CYLINDER ASSY.	1	
	12	1018005043	LOCK STRIKER	1	
	13		INNER HEXAGON FLOWER HEAD SCREW	2	
	14		DOOR EXTERIOR HANDLE FRONT LINER	1	
	15		DOOR EXTERIOR HANDLE REAR LINER	1	
	16	1018003958	RF DOOR LOCKING CABLE ASSY.	1	
	17		FRONT DOOR INTERIOR UNLOCKING CABLE ASSY.	1	
18		CABLE CLIP	1		
		1018006215	RF DOOR LOCK ACTUATOR ASSY.	1	

8240 FRONT DOOR WINDOW REGULATOR ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018005661	LF DOOR WINDOW REGULATOR ASSY.	1	
	2	1018005660	RF DOOR WINDOW REGULATOR ASSY.	1	
	3		HEXAGON FLANGE BOLT	6	
	4		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	
	5	1012001129	LF DOOR WINDOW REAR CHANNEL ASSY.	1	
	6	1012001579	RF DOOR WINDOW REAR CHANNEL ASSY.	1	
	7	1058005001	LF DOOR WINDOW ASSY.(TOUGHENED GLASS)	1	
	8	1058005003	LF DOOR WINDOW ASSY.(GREEN/HEAT INSULATOR)	1	
	9	1058005002	RF DOOR WINDOW ASSY.(TOUGHENED GLASS)	1	
		1058005004	RF DOOR WINDOW ASSY.(GREEN/HEAT INSULATOR)	1	
		1018005129	FRONT DOOR GLASS RUBBER STRIP	1	

8250 LR DOOR INTERIOR TRIM & ACCESSORY

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018005663	LR DOOR WINDOW REGULATOR	1	
	2		LR DOOR LOCK & HANDLE	1	
	3	1018005666	REAR DOOR CHECK	1	
	4		LR DOOR INTERIOR TRIM BOARD ASSY.	1	
	5		CHILDREN LOCK DUST BOOT	1	
	6	1018010881	REAR DOOR WATERPROOF FILM	1	
		1018004704	REAR DOOR SHEILD FILM	1	
	7		LR DOOR SEALING	1	
	8		CROSS SLOTTED HEXAGON HEAD SELF-TAPPING SCREW	2	
	9		CROSS SLOTTED HEAD SELF-TAPPING SCREW	1	
	10	1018005629	DOOR INTERIOR TRIM BOARD HANDLE	1	
	11		THROUGH HOLE PLASTIC NUT	2	
12	1018008141	LR DOOR INTERIOR PULL HANDLE MOUNTING BRACKET	1		


8260 LR DOOR LOCK & HANDLE

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018005293	LEFT DOOR INTERIOR UNLOCKING HANDLE ASSY.	1	
	2	JQ398M85	THROUGH HOLE INSERT PLASTIC NUT	1	
	3		"C" TYPE CROSS SLOTTED HEAD SELF-TAPPING SCREW	1	
	4	1058005291	RL DOOR LOCK ASSY.(W/O LOCK ACTUATOR)	1	
		1018005291	RL DOOR LOCK ASSY.	1	
	5		INNER HEXAGON FLOWER COUNTERSUNK SCREW	3	
	6		CROSS SLOTTED HEAD SCREW & PLAIN WASHER ASSY.	1	
	7		"C" TYPE CROSS SLOTTED HEAD SELF-TAPPING SCREW	1	
	8	1018004769	REAR DOOR EXTERIOR UNLOCKING HANDLE POLE COVER	1	
	9	1018005041-01	LR DOOR EXTERIOR HANDLE ASSY.	1	
	10	1018005041	REAR DOOR EXTERIOR UNLOCKING HANDLE MOUNTING BRACKET ASSY.	1	
	11	1018005043	LOCK STRIKER	1	
	12		INNER HEXAGON FLOWER COUNTERSUNK SCREW	2	
	13		DOOR EXTERIOR HANDLE FRONT LINER	1	
	14		DOOR EXTERIOR HANDLE REARLINER	1	
	15	1018003957	REAR DOOR INTERIOR UNLOCKING CABLE ASSY.	1	
	16	1018003729	LR DOOR LOCKING CABLE ASSY.	1	
17		CABLE CLIP	1		
	1018008854	LR DOOR LOCK ACTUATOR ASSY.			

8270 LR DOOR INTERIOR TRIM BOARD ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018006009	LR DOOR INTERIOR TRIM BOARD SUB-ASSY.	1	
	2	JQ690E82	"D" TYPE CLIP	6	
	3		LR DOOR SOUND INSULATOR (525×230×10)	1	
	4		LR DOOR SOUND INSULATOR (600×500×10)	1	
	5		"J" TYPE CLIP	1	

8280 LR DOOR WEATHERSTRIP



NO.	PART NO.	DES.	QTY	REMARK
1	1012012219	LR DOOR WEATHERSTRIP ASSY.	1	
2	1012012221	LR DOORFRAME WEATHERSTRIP	1	
3	1012012222	LR DOOR WINDOW EXTERIOR WEATHERSTRIP	1	
4	1012012223	LR DOOR QUARTER WINDOW WEATHERSTRIP	1	
5	1012012218	LR DOOR WINDOW CHANNEL	1	
6	1018006172	LR DOOR WINDOW INTERIOR WEATHERSTIP	1	

8290 RR DOOR INTERIOR TRIM & ACCESSORY

	NO.	PART NO.	DES.	QTY	REMARK
	1		RR DOOR SEALING	1	
	2	1018010881	REAR DOOR WATERPROOF FILM	1	
		1018004704	REAR DOOR SHEILD FILM	1	
	3		CHILDREN LOCK DUST BOOT	1	
	4		RR DOOR INTERIOR TRIM BOARD ASSY.	1	
	5	1018005666	REAR DOOR CHECK	1	
	6		RR DOOR LOCK & HANDLE	1	
	7	1018005662	RR DOOR WINDOW REGULATOR	1	
	8		CROSS SLOTTED HEAD SELF-TAPPING SCREW	1	
	9	1018005629	DOOR INTERIOR TRIM BOARD HANDLE	1	
	10		CROSS SLOTTED HEAD SELF-TAPPING SCREW	2	
	11	1018008142	RR DOOR INTERIOR PULL HANDLE MOUNTING BRACKET	1	
12		THROUGH HOLE PLASTIC NUT	3		

8300 RR DOOR WEATHERSTRIP


	NO.	PART NO.	DES.	QTY	REMARK
	1	1012012234	RR DOOR WEATHERSTRIP ASSY.	1	
	2	1012012236	RR DOORFRAME WEATHERSTRIP	1	
	3	1012012237	RR DOOR WINDOW EXTERIOR WEATHERSTRIP	1	
	4	1012012238	RR DOOR QUARTER WINDOW WEATHERSTIP	1	
	5	1012012233	RR DOOR WINDOW CHANNEL	1	
	6	1018006173	RR DOOR WINDOW INTERIOR WEATHERSTRIP	1	

8310 RR DOOR INTERIOR TRIM BOARD ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018006020	RR DOOR INTERIOR TRIM BOARD SUB-ASSY.	1	
	2		"J" TYPE CLIP	1	
	3	JQ690E82	"D" TYPE CLIP	1	
	4		RR DOOR SOUND INSULATOR (525×230×10)	1	
	5		RR DOOR SOUND INSULATOR (600×500×10)	1	

8320 RR DOOR LOCK & HANDLE

NO.	PART NO.	DES.	QTY	REMARK
1	1018005294	RIGHT DOOR INTERIOR UNLOCKING HANDLE ASSY.	1	
2	JQ398M85	THROUGH HOLE INSERT PLASTIC NUT	1	
3		"C" TYPE CROSS SLOTTED HEAD SELF-TAPPING SCREW	1	
4	1058005292	RR DOOOR LOCK ASSY.(W/O LOCK ACTUATOR)	1	
	1018005292	RR DOOOR LOCK ASSY.		
5		INNER HEXAGON FLOWER COUNTERSUNK SCREW	3	
6		CROSS SLOTTED HEAD SCREW & PLAIN WASHER ASSY.	1	
7		"C" TYPE CROSS SLOTTED HEAD SELF-TAPPING SCREW	1	
8	1018004769	REAR DOOR EXTERIOR UNLOCKING HANDLE POLE COVER	1	
9	1018005042-01	RR DOOR EXTERIOR HANDLE ASSY.	1	
10	1018005042	REAR DOOR EXTERIOR UNLOCKING HANDLE MOUNTING BRACKET ASSY.	1	
11	1018005043	LOCK STRIKER	1	
12		INNER HEXAGON FLOWER COUNTERSUNK SCREW	2	
13		DOOR EXTERIOR HANDLE FRONT LINER	1	
14		DOOR EXTERIOR HANDLE REARLINER	1	
15	1018003957	REAR DOOR INTERIOR UNLOCKING CABLE ASSY.	1	
16	1018003959	RR DOOR LOCKING CABLE ASSY.	1	
17		CABLE CLIP	1	
	1018008855	RR DOOR LOCK ACTUATOR ASSY.	1	



8330 REAR DOOR GLASS REGULATOR

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018005663	LR DOOR GLASS REGULATOR ASSY.	1	
	2	1018005662	RR DOOR GLASS REGULATOR ASSY.	1	
	3		HEXAGON FLANGE BOLT	4	
	4		REGULATOR HANDLE	1	
	5		PLASTIC GASKET	1	
	6		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	
	7	1012017333	LR DOOR GLASS BAFFLE PLATE ASSY.	1	
	8	1012017334	RR DOOR GLASS BAFFLE PLATE ASSY.	1	
	9		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	
	10		CROSS SLOTTED HEAD SCREW	1	
	11		LR DOOR GLASS BAFFLE PLATE END CAP	1	
	12		RR DOOR GLASS BAFFLE PLATE END CAP	1	
	13	1018006206	LR DOOR QUARTER GLASS	1	
	14	1018006209	RR DOOR QUARTER GLASS	1	
	15	1018006204	LR DOOR GLASS ASSY.	1	
	16	1018006207	RR DOOR GLASS ASSY.	1	
	17	1018005135	REAR DOOR GLASS RUBBER STRIP	1	
	18	1018005299	LR DOOR GLASS LOWER BRACKET ASSY.	1	
	1018005303	RR DOOR GLASS LOWER BRACKET ASSY.	1		
	1012002057	LR DOOR GLASS FRONT GUIDE RAIL	1		
	1012002547	RR DOOR GLASS FRONT GUIDE RAIL	1		
	1012010347	LR DOOR GLASS UPPER GUIDE RAIL	1		
	1012010348	RR DOOR GLASS UPPER GUIDE RAIL	1		


8340 LF SEAT ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018004745	LF SEAT ASSY.(LEATHER)	1	
		1018011033	LF SEAT ASSY.	1	
	2		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	4	
	3		LF SEAT LEFT MOUNTING BRACKET TRIM COVER	1	
	4		LF SEAT RIGHT MOUNTING BRACKET TRIM COVER	1	
5		TRIM COVER MOUNTING CLIP	1		

8350 RF SEAT ASSY.


	NO.	PART NO.	DES.	QTY	REMARK
	1	1018004746	RF SEAT ASSY.(LEATHER)	1	
		1018011034	RF SEAT ASSY.	1	
	2		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	4	
	3		RF SEAT LEFT MOUNTING BRACKET TRIM COVER	1	
	4		RF SEAT RIGHT MOUNTING BRACKET TRIM COVER	1	
5		TRIM COVER MOUNTING CLIP	1		

8360 BACK DOOR INTERIOR TRIM & ACCESSORY




NO.	PART NO.	DES.	QTY	REMARK
1	1018006201	BACK DOOR WINDOW ASSY.	1	
	1018006344	BACK DOOR WINDOW SEAL	1	
2	1018006226	BACK DOOR INTERIOR UPPER TRIM BOARD	1	
	1018006227	BACK DOOR INTERIOR LEFT TRIM BOARD	1	
	1018006228	BACK DOOR INTERIOR RIGHT TRIM BOARD	1	
3		BACK DOOR INTERIOR PULL HANDLE	1	
	1018006054	BACK DOOR INTERIOR PULL HANDLE BOX	1	
4		BACK DOOR LOCK CYLINDER ASSY.	1	
5	1012012202	BACK DOOR EXTERIOR HANDLE	1	
6	1018008256	BACK DOOR LOCK ASSY.	1	
7		BACK DOOR LOCK CYLINDER SEALING	1	
8		BACK DOOR EXTERIOR HANDLE LINER	1	
9		CROSS SLOTTED HEAD SCREW & LOCKING WASHER ASSY.	2	
10	1018006162	TRUNK LID CUSHION BLOCK	2	
11	1018006202	BACK DOOR LEFT AIR SPRING ASSY.	1	
12	1018006211	BACK DOOR RIGHT AIR SPRING ASSY.	1	
13	1012012204	BACK DOOR LOCK BUCKLE ASSY.	1	
14		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	10	
15		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	
16	JQ690E82	"D" TYPE CLIP	4	
17		"J" TYPE CLIP	6	
18	1018006330	BACK DOOR INTERIOR TRIM BOARD ASSY.	1	
19	1012012202	BACK DOOR EXTERIOR UNLOCKING HANDLE ASSY.	1	
	1018008269	GEELY LOGO(BACK DOOR)	1	


8370 REAR SEAT ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018006032	LR SEAT BACK ASSY.	1	
		1018008213	LR SEAT BACK ASSY.(LEATHER)	1	
	2	1018006033	RR SEAT BACK ASSY.	1	
		1018008214	RR SEAT BACK ASSY.(LEATHER)	1	
	3	1018006035	REAR SEAT HINGE	2	
	4		REAR SEAT HINGE MOUNTING BOLT	2	
	5		HEXAGON FLANGE BOLT	4	
	6	1018006034	REAR SEAT CROSS MEMBER ASSY.	1	
	7		HEXAGON FLANGE BOLT	9	
	8	1018008215	REAR SEAT CUSHION ASSY.(LEATHER)	1	
		1018006036	REAR SEAT CUSHION ASSY.	1	
	1018004657	REAR SEAT CUSHION CLIP	2		
	1018006038	REAR SEAT PILLOW(LEATHER)	1		
	1018008250	REAR SEAT PILLOW	2		
	1018016553	REAR SEAT LOCK BUCKLE	2		
		REAR SEAT LOCKIN KNOB	1		


8380 FRONT BUMPER ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	
	2	JQ694E79	"J" TYPE CLIP	2	
	3		RADIATOR GRILL MOUNTING BOLT	2	
	4	1018005962	FRONT BUMPER LEFT MOUNTING BRACKET	1	
	5	1018005963	FRONT BUMPER RIGHT MOUNTING BRACKET	1	
	6		FRONT BUMPER MOUNTING CLIP	2	
	7		CROSS SLOTTED HEXAGON SELF-TAPPING SCREW	4	
	8	1018006112	FRONT BUMPER ASSY.	1	
	9	1018006116	RADIATOR GRILL ASSY.	1	
	10	1018006153	FRONT BUMPER CUSHION BLOCK	1	
	11		FRONT BUMPER CUSHION BLOCK LEFT PRESSURE BOARD	1	
	12		FRONT BUMPER CUSHION BLOCK RIGHT PRESSURE BOARD	1	
	13	1018006156	FRONT BUMPER CUSHION BLOCK FIXING BOLT	2	
	14	1018008914	BIG WASHER	2	
	15	1018008268	GEELY LOGO	1	
	16	1018006113	FRONT BUMPER BOTTOM LEFT PANEL	1	
	17	1018006114	FRONT BUMPER BOTTOM RIGHT PANEL	1	
	1018006115	FRONT BUMPER BOTTOM CENTER PANEL	1		

8390 REAR BUMPER ASSY.


	NO.	PART NO.	DES.	QTY	REMARK
 <p style="text-align: center;">目录索引图1</p>	1	1018004853	REAR BUMPER MOUNTING BOLT 1#	4	
	2	1018004860	REAR BUMPER MOUNTING BOLT 2#	2	
	3	1018006132	REAR BUMPER ASSY.	1	
	4	1018006129	REAR BUMPER LEFT MOUNTING BRACKET	1	
	5	1018006131	REAR BUMPER RIGHT MOUNTING BRACKET	1	

8400 FRONT WINDSHIELD ASSY.



NO.	PART NO.	DES.	QTY	REMARK
1	1057002509	INTERIOR REARVIEW MIRROR ASSY.	1	ANTIDAZZLE
	8201120002-01	INTERIOR REARVIEW MIRROR ASSY.	1	
2		FRONT WINDSHIELD STOPPER 1#	2	
3		FRONT WINDSHIELD STOPPER 2#	2	
4	1018003951	FRONT WINDSHIELD SUB-ASSY.	1	
5	1018005751	FRONT WINDSHIELD RUBBER STRIP	1	
6	1018004759	FRONT WINDSHIELD WEATHERSTRIP	1	

8410 EXTERIOR TRIM & ACCESSORY



8410 EXTERIOR TRIM & ACCESSORY

NO.	PART NO.	DES.	QTY	REMARK	NO.	PART NO.	DES.	QTY	REMARK
1	1018011472	ENGINE BOTTOM LEFT SHIELD BOARD	1		25	1018008126	REAR BUMPER LEFT SPLASH GUARD	1	
	1018011470	ENGINE BOTTOM RIGHT SHIELD BOARD	1		26	1018008127	REAR BUMPER RIGHT SPLASH GUARD	1	
2	1018005842	VENT PIPE COVER BOARD SEALING	1		27	1018004652	PLASTIC EXPAND CLIP	14	φ7
3	1018005831	LEFT VENT PIPE COVER BOARD ASSY.	1		28	1018003590	REAR BUMPER SPLASH GUARD MOUNTING BRACKET	1	
4	1018005836	RIGHT VENT PIPE COVER BOARD ASSY.	1		29		CROSS SLOTTED HEAD SELF-TAPPING SCREW	2	
5	1018005840	PLASTIC CLIP ASSY.(FOR VENT COVER BOARD)	2	φ5.5	30	1018005353	LICENSE PLATE TRIM BOARD	2	
6		VENT COVER BOARD FIXING CLIP	8		31		CROSS SLOTTED SMALL HEAD SCREW	4	
7	1018005351	ENGINE COMPARTMENT WATER OUTLET PLATE ASSY.	1		32	1018003801	LF SPLASH GUARD	1	
8		CROSS HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	8		33	1018003802	RF SPLASH GUARD	1	
9	1018004709	LF DOOR EXTERIOR QUARTER TRIM	1			1018003803	LR SPLASH GUARD	1	
10	1018004710	RF DOOR EXTERIOR QUARTER TRIM	1			1018003804	RR SPLASH GUARD	1	
11	1018003956	"D" TYPE CLIP	1		34		"A" TYPE REED NUT	1	
12	JQ695B.1	"J" TYPE CLIP	2		35		CROSS SLOTTED HEAD SELF-TAPPING SCREW	1	
13	Q1460616	HEXAGON HEAD BOLT & SPRING WASHER ASSY.	2		36	1012010453	OIL FILLER CAP CONTROLLER	1	
14	1012012207	ROOF LEFT TRIM MOLDING ASSY.	1						
15	1012012208	ROOF RIGHT TRIM MOLDING ASSY.	1						
16	1018004815-01	LEFT REARVIEW MIRROR ASSY.	1						
17	1018004816-01	RIGHT REARVIEW MIRROR ASSY.	1						
18		HEXAGON FLANGE NUT	6						
19	1018005076	LF WING LINER	1						
20	1018005077	RF WING LINER	1						
21	1018004652	PLASTIC EXPAND CLIP	6	φ7					
22		THROUGH HOLE PLASTIC NUT	8						
23	1018005861	"S" TYPE CLIP	2						
24	JQ2226325	CROSS SLOTTED HEAD SELF-TAPPING SCREW	2						



8420 REARVIEW MIRROR

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018004816-01	OUTSIDE REARVIEW MIRROR,RH	1	
		1018004815-01	OUTSIDE REARVIEW MIRROR,LH	1	
	2		FRONT DOOR OUTER MAT,RH	1	
			FRONT DOOR OUTER MAT,LH	1	
	3	1018004710	FRONT DOOR OUTER QUARTER TRIM,RH	1	
		1018004709	FRONT DOOR OUTER QUARTER TRIM,LH	1	
	4		"D" TYPE CLIP	1	
5		"K" TYPE CLIP	1		
6		HEXAGON FLANGE BOLT	3		
7	1058000022	OUTSIDE REARVIEW MIRROR LENS,RH	1		
	1058000020	OUTSIDE REARVIEW MIRROR LENS,LH	1		

8430 SUNROOF ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	1058005097	SUNROOF ASSY.	12	
	2	1012003658	SUNROOF REINFROCEMENT FRONT BRACKET	2	
	3		STEEL TYPE SPRING HOOP	4	
	4		HEXAGON FLANGE BOLT	6	
	5	1018005097	SUNROOF ASSY.	1	
	6	1018005109	ROOF TRIM MOLDING	1	
	7	1018005110	SUNROOF FRONT WATER PIPE	2	
	8		REAR WATER PIPE RUBBER BOOT	2	
	9	1018005496	SUNROOF DOME LAMP BRACKET	1	
	10	1012000018	ROOF TRIM MOLDING END COVER	1	
	11	1018005695	SUNROOF REAR WATER PIPE	2	
	12	1012010373	SUNROOF CONNECTING PLATE	2	
	13	1012003659	SUNROOF REINFROCEMENT REAR BRACKET	2	
	14	1018011403	SUNROOF GLASS	1	
	15	1017000991	SUNROOF CONTROL	1	
	16	1018011400	SUNROOF MOTOR	1	
		1018011401	SUNROOF DEFLECTOR PLATE	1	
		1018011402	SUNROOF SUN VISOR	1	
		1018011403	SUNROOF SEAL	1	

8440 SEAT REPAIR KIT

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018003844	FRONT SEAT PILLOW	2	
			FRONT SEAT PILLOW(LEATHER)	2	
	2	1018003846	REAR SEAT PILLOW	2	
			REAR SEAT PILLOW(LEATHER)	1	
	3	1018003848-01	RF SEAT RIGHT ADJUSTER ASSY.	1	
	4	1018003849-01	RF SEAT LEFT ADJUSTER ASSY.	1	
	5	1018003850-01	LF SEAT RIGHT ADJUSTER ASSY.	1	
	6	1018003851-01	LF SEAT LEFT ADJUSTER ASSY.	1	
		101800912300652	HEIGHT ADJUSTER ASSY.(DARK)	1	


8450 ENGINE HOOD INTERIOR TRIM & ACCESSORY

	NO.	PART NO.	DES.	QTY	REMARK
	1	1018005689	ENGINE HOOD INTERIOR SEAL	1	
	2		ENGINE HOOD INTERIOR SEAL FIAXING CLIP	6	
	3	JQ398N145	ENGINE HOOD SUPPORT BAR CLIP SEAT	1	
	4	1018005058	ENGINE HOOD SUPPORT BAR CLIP	1	
	5	1018004724	ENGINE HOOD SUPPORT BAR ASSY.	1	
	6		ENGINE HOOD SUPPORT BAR	1	
	7		ENGINE HOOD SUPPORT BAR BOOT	1	
	8	1018005018	ENGINE HOOD CUSHION	4	
	9		CABLE CLIP	1	
	10		PIPE CLIP	1	
	11	1018011226	FRONT BUMPER UPPER TRIM BOARD	1	
	12	JQ694D63Y653	"J" TYPE CLIP	3	
	1018004747	ENGINE HOOD CABLE ASSY.	1		

CONTENT


1	PETROL ENGINE ASSY.	21	IGNITION CABLE ASSY.
2	PETROL ENGINE COMPONENTS	22	ECU & IGNITION COIL
3	CYLINDER BLOCK SUB-ASSY.	23	ALTERNATOR COMPONENTS
4	CYLINDER HEAD COVER COMPONENTS	24	STARTER
5	CYLINDER HEAD	25	FUEL PUMP ASSY.
6	CYLINDER BLOCK COMPONENTS	26	ENGINE MOUNTING
7	TIMING BELT COVER AND BELT PULLEYS	27	PHASE SENSOR AND BASE
8	PISTON CONNECTING ROD COMPONENTS	28	COLD AIR INTAKE BOX
9	CRANKSHAFT FLYWHEEL COMPONENT	29	CLUTCH ASSY.
10	CAMSHAFT		
11	VALVE		
12	TIMING BELT		
13	OIL PUMP ASSY.		
14	OIL STRAINER AND OIL PAN COMPONENTS		
15	THERMOSTAT ASSY.		
16	WATER PUMP ASSY.		
17	THROTTLE		
18	INTAKE MANIFOLD COMPONENTS		
19	EXHAUST MANIFOLD COMPONENTS		
20	FUEL INJECTOR		

1 PETROL ENGINE ASSY.



NO.		DES	QTY	REMARK
10		PETROL ENGINE ASSY.	1	
11		PETROL ENGINE FILM COVER (FOR TRANSPORTATION)	1	1.3L
12		PETROL ENGINE MAINTAINANCE PASTER	1	
13		PETROL ENGINE MAINTAINANCE PASTER	1	1.5L

2 PETROL ENGINE COMPONENTS




3 CYLINDER BLOCK SUB-ASSY.

	NO.	PART NO.	DES	QTY	REMARK
		E000010010	CYLINDER BLOCK SUB-ASSY.	1	1.3L
		E000010002	CYLINDER BLOCK SUB-ASSY.	1	1.5L
		1086001043	CYLINDER BLOCK SUB-ASSY.	1	1.6L

4 CYLINDER HEAD COVER COMPONENTS

	NO.	PART NO.	DES	QTY	REMARK
	10	E010400101	CYLINDER HEAD COVER	1	
	11	1106013110	CYLINDER HEAD COVER OIL BAFFLER GASKET	1	
	12	E010400301	OIL BAFFLER A	1	
	13	E010400401	OIL BAFFLER B	1	
	14	E010001501	CYLINDER HEAD COVER GASKET	1	
	15	1106013107	CYLINDER HEAD OIL SEAL ASSY.	4	
	16	1106013115	OIL CAP	1	
	17	E010402001	CONTROL VALVE	1	
	18	E010400501	VENTILATION HOSE JOINT	1	
	19		OIL CAP SEAL WASHER	1	
	20	E010401001	WIRE HARNESS BRACKET	1	
	21		WIRE HARNESS BRACKET FIXING BOLT M6x16	1	
	22	E010400901	SEAL SHEATH	1	
	23	1106013109	CYLINDER HEAD COVER COMPONENTS	1	
	24	1086000532	CYLINDER HEAD COVER NUT	4	
	25	E010401501	WASHER	4	
	26	2000000701	MR479Q PETROL ENGINE SCUTCHEON	1	
	27	1106010506	DOUBLE END STUD M6x83	4	
	28		COVER Φ 7x10 (FOR TRANSPORTATION)	1	
	29		MR479QA PETROL ENGINE SCUTCHEON	1	

5 CYLINDER HEAD

	NO.	PART NO.	DES	QTY	REMARK
	11	E010001601	CYLINDER HEAD GASKET	1	1.3L/1.5L
		2100309021	CYLINDER HEAD GASKET	1	1.6L
	12		STEEL BALL	2	
	13	E010500105	CYLINDER HEAD	1	1.3L/1.5L
	14	E010500301	SEALING COVER B	2	
	15	E010500601	SPARK PLUG TUBE	4	
	16	E010500901-01	CYLINDER HEAD BOLT M10x1.25x108	5	
	17	E010500801-01	CYLINDER HEAD BOLT M10x1.25x90	5	
	18	E010501001	WASHER $\Phi 20.5 \times 3$	10	
	20		CYLINDER HEAD PLUG M20x1.5	3	
	21		CYLINDER HEAD PLUG WASHER	3	
	22		ALIGNING PIN BUSH	6	
	23	E010500201	SEALING COVER A	2	
	24	2010001801	SEMICIRCLE PLUG	1	
	25	E010001701	WATER OUTLET	1	
	26		WATER OUTLET FIXING BOLT	2	
	27		WATER OUTLET (FOR SHANGHAI MAPLE ONLY)	1	
	28		COVER $\Phi 32 \times 14$ (FOR TRANSPORTATION)	1	

6 CYLINDER BLOCK COMPONENTS

	NO.	PART NO.	DES	QTY	REMARK
	10	E020300104	CYLINDER BLOCK	1	1.3L/1.5L
		2100203121	CYLINDER BLOCK		1.6L
	11		MAIN BEARING CAP (1ST、 2ND、 4TH、 5TH)	4	
	12		MAIN BEARING (3RD)	1	
	13	E020300201	ALIGNING PIN Φ 11x8	2	
	14	E020300401	OIL GALLERY BOLT R3/8x10	2	
	15	E020300301	HANGING PIN Φ 6x22	1	
	16	1106013216	UPPER MAIN BEARING	5	
	17	1106013217	LOWER MAIN BEARING	5	
	18	E020301601	CRANKSHAFT UPPER THRUST WASHER	2	
	19	E020301701	CRANKSHAFT LOWER THRUST WASHER	2	
	20	1106010501	SEALING COVER Φ 40	1	
	21	1106010502	SEALING COVER Φ 35	4	
	22	E150040005	KNOCK SENSOR	1	
	23	E020300801	ALIGNING PIN Φ 13x12	2	
	24	E020300501	ALIGNING PIN Φ 10x22	2	
	25	E020300701	ALIGNING PIN Φ 6x14	2	
	26		HEXAGON SOCKET DOUBLE END SCREW CANNULA	1	
	27	1106013268	MASTER BEARING CAP BOLT M10x1.25x60	10	
	28	E020302101	DOUBLE END STUD M6x18	2	
	29		PREVAILING TORQUE TYPE HEXAGON NUT WITH FLANGE	2	M6
	30		CYLINDER BLOCK COMPONENTS	1	
	31		BOLT M8x12	1	
	32	E020301201	DRAIN PLUG R1/4x12	1	
	33	1106013221	OIL FILTER COMPONENTS	1	

6 CYLINDER BLOCK COMPONENTS

NO.	PART NO.	DES	QTY	REMARK	NO.	PART NO.	DES	QTY	REMARK
34	1106013220	OIL PRESSURE SWITCH	1						
35		SPEED SENSOR MOUNTING BRACKET ALIGNING PIN BUSH	2						
36	E020000201	SPEED SENSOR MOUNTING BRACKET	1						
37	E20110003	HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	3						
38	E150030005	ENGINE SPEED SENSOR	1	EURO II					
	2150030006	ENGINE SPEED SENSOR	1	EURO III					
	3170933320	ENGINE SPEED SENSOR	1	AT					
41	2000410104	ENGINE RIGHT MOUNTING BRACKET	1	CK-1					
	1086000442	ENGINE RIGHT MOUNTING BRACKET	1	MK					
	E000410101	ENGINE RIGHT MOUNTING BRACKET(OLD TYPE)	1						
42		BOLT	3						
43	E050000301	O RING 34.5x2.65	1						

7 TIMING BELT COVER & BELT PULLEYS

NO.	PART NO.	DES	QTY	REMARK
10	1106013231	CRANKSHAFT PULLEY	1	
11	E030100101	NO.1 TIMING BELTS COVER	1	
12	E030000301	TIMING BELT GUIDE	1	
13	E030000201	CRANKSHAFT TIMING PULLEY	1	
14	E030100201	NO.2 TIMING BELTS COVER	1	
15	E030100301	NO.3 TIMING BELTS COVER	1	
16		HEXAGON FLANGE BOLT-PRODUCT GRADE B	9	M6x20

8 PISTON CONNECTING ROD COMPONENTS

	NO.	PART NO.	DES	QTY	REMARK
	11		TOP COMPRESSION RING	4	
	12		SECOND COMPRESSION RING	4	
	13		OIL RING EXP&ER	4	
	14		OIL RING SIDE RAIL	8	
	15		OIL RING COMPONENTS	4	
	16	E020110010	PISTON RING COMPONENTS	4	1.3L/1.5L
	17	2100404021	PISTON RING COMPONENTS		1.6L
	17	E020100103-01	PISTON	4	1.3L
	26	E020100106	PISTON	4	1.5L
	26	2100401121	PISTON	4	1.6L
	18	1106013100	PISTON PIN	4	
	19		CONNECTING ROD BODY	4	
	20		CONNECTING ROD BOLT	8	
	21		CONNECTING ROD HEAD	4	
22		CONNECTING ROD NUT	8		
23	E020120501	CONNECTING ROD BEARINGS	8		
24	E020120005	CONNECTING ROD COMPONENTS	4		
25		PISTON CONNECTING ROD COMPONENTS	4		
27	MR479QA	PISTON CONNECTING ROD COMPONENTS	4		


9 CRANKSHAFT FLYWHEEL COMPONENT

	NO.	PART NO.	DES	QTY	REMARK
	11	E020210301	CRANKSHAFT BELT PULLEY FIXING BOLT	1	
	12		WASHER	1	
	13	E020210201	SEMICIRCLE KEY	1	
	14	E020210103	MR479Q CRANKSHAFT	1	
	15		CRANKSHAFT COMPONENTS	1	
	21	E020500201	REAR OIL SEAL RETAINER GASKET	1	
	22	E020500005	CRANKSHAFT REAR OIL SEAL RETAINER	1	
	23	E20103011	HEXAGON FLANGE BOLT-PRODUCT GRADE B	6	M6x16
	24	1106013094	CRANKSHAFT REAR OIL SEAL ASSY.	1	
	25		REAR OIL SEAL RETAINER COMPONENTS	1	
	26	E020000101	CLUTCH HOUSING PLATE	1	
	27		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	M6x13
	31	1106013307	FLYWHEEL GEAR RING	1	1.3L/1.5L
	32	1106013095	FLYWHEEL	1	1.3L
		1086000783	FLYWHEEL	1	1.5L
		1106018024	FLYWHEEL	1	1.6L
	33	E020220501	FLYWHEEL FIXING BOLT M10x1.25x23	6	
	34	E020220301	ALIGNING PIN Φ8x20	3	
	35		FLYWHEEL COMPONENTS	1	
	41		SENSOR PLATE	1	
42		CRANKSHAFT FLYWHEEL COMPONENTS	1		
43	E020210106	MR479QA & MR481QA CRANKSHAFT	1		
44		MR479QA CRANKSHAFT COMPONENTS	1		
45		MR479QA CRANKSHAFT FLYWHEEL COMPONENTS	1		

10 CAMSHAFT


	NO.	PART NO.	DES	QTY	REMARK
	10	E010110101	INTAKE CAMSHAFT	1	1.3L/1.5L
		2100603121	INTAKE CAMSHAFT	1	1.6L
		1106018094	INTAKE CAMSHAFT(SPECIAL CHILE)	1	1.6L
	12	E010110301	DRIVING GEAR	1	
	13	E010110501	SUB-GEAR	1	
	14	E010110401	CAMSHAFT GEAR SPRING	1	
	15	E010110701	WAVE WASHER	1	
	16	E010110801	SNAP RING	1	
	17	E010110601	DRIVING GEAR ALIGNING PIN $\Phi 5 \times 8$	1	
	18	E010110201	SUB-GEAR ALIGNING PIN $\Phi 5 \times 7$	1	
	19	E010120201	ALIGNING PIN $\Phi 5 \times 12$	1	
	20	E010000103	INTAKE CAMSHAFT BEARING CAP A	1	
	21		EXHAUST CAMSHAFT BEARING CAP A	1	
	22		EXHAUST CAMSHAFT BEARING CAP B	1	
	23	E010000203	CAMSHAFT BEARING CAP	8	
	25	E010002701	CAMSHAFT BEARING CAP BOLT	18	
	30	E010120101	EXHAUST CAMSHAFT	1	
		1106018095	EXHAUST CAMSHAFT(SPECIAL CHILE)	1	1.6L
	31	E010120301	TRANSMITTING GEAR	1	
	32	E030000101	CAMSHAFT TIMING BELT GUIDE	1	
	33	1106013187	EXHAUST CAMSHAFT OIL SEAL ASSY.	1	
	34		SNAP RING	1	
	36	E010110005	INTAKE CAMSHAFT COMPONENTS	1	
	37	E010120005	EXHAUST CAMSHAFT COMPONENTS	1	
	38	E030000801	CAMSHAFT TIMING BELT GUIDE FIXING BOLT	1	

11 VALVE




NO.	PART NO.	DES	QTY	REMARK
10	E010001201	SHIM	16	
11	1086001194	VALVE TAPPET	16	
12	1106018005	VALVE KEEPER	32	
13	E010000901	VALVE SPRING SEAT	16	
14	E010000801	VALVE SPRING	16	
15	1106013097	INTAKE OIL SEAL ASSY.	8	
16	1106018006	VALVE SPRING RETAINER	16	
17	E010500703	VALVE GUIDE	16	
18	E010000501	INTAKE VALVE	8	1.3L/1.5L
	2100701221	INTAKE VALVE	8	1.6L
20	E010000601	EXHAUST VALVE	8	1.3L/1.5L
	2100701321	EXHAUST VALVE	8	1.6L
21	1106013098	EXHAUST OIL SEAL ASSY.	8	

12 TIMING BELT

	NO.	PART NO.	DES	QTY	REMARK
	10	E030000701	TIMING BELT	1	
	11	E030000501	TENSION SPRING	1	
	12	1106013230	BELT TENSIONER COMPONENTS	1	
	13	E030000901	TIMING BELT TENSIONER FIXING BOLT	1	M10x1.25x40

13 OIL PUMP ASSY.



NO.	PART NO.	DES	QTY	REMARK
10	1106013209	CRANKSHAFT FRONT OIL SEAL RETAINER GASKET	1	
11		SCREW M6x10	5	
12		OIL PUMP BODY COVER	1	
13		DRIVING ROTOR	1	
14		DRIVEN ROTOR	1	
15		OIL PUMP BODY	1	
16	E040000601	OIL PUMP SHORT FIXING BOLT M8x25	5	
17	E040000701	OIL PUMP FIXING BOLT M8x35	2	
18		POSITION BUSH	1	
19	E040000801	DOUBLE END STUD M6x22	2	
20		RETAINER	1	
21	1106013209	CRANKSHAFT FRONT OIL SEAL ASSY.	1	
22		OIL PUMP PRESSURE RELIEF VALVE	1	
23		SPRING	1	
24		SNAP RING	1	
25		HEXAGON SOCKET PLUG R3/8x10	1	
26		PREVAILING TORQUE TYPE HEXAGON NUT WITH FLANGE	2	M6
27	E040100005	OIL PUMP ASSY.	1	

14 OIL STRAINER & OIL PAN COMPONENTS

	NO.	PART NO.	DES	QTY	REMARK
	10	1106013215	OIL PAN COMPONENT	1	
	11		BAFFLE BOARD	1	
	12		NUT M12x1.25	1	
	13		OIL PAN	1	
	14	E020400201	OIL DRAIN PLUG WASHER	1	
	15		PREVAILING TORQUE TYPE HEXAGON NUT WITH FLANGE	2	M6
	16	E020400101	OIL DRAIN PLUG M12x1.25x16	1	
	17		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	19	M6x12
	21	E020900101	OIL STRAINER GASKET	1	
	22	E020900005	OIL STRAINER	1	
	23		PREVAILING TORQUE TYPE HEXAGON NUT WITH FLANGE	2	M6
	24		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	M6x12
	30	1106013170	OIL DIPSTICK	1	
	31		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	M6x12
32		O RING 10x1.8	1		
33		PETROL ENGINE QUALIFICATION CERTIFICATION	1	1.3L	
34		PETROL ENGINE QUALIFICATION CERTIFICATION	1	1.5L	


15 THERMOSTAT ASSY.

	NO.	PART NO.	DES	QTY	REMARK
	10	1106013089	WATER INLET HOUSING	1	
	11		SIMPLE CIRCULATION WATER INLET/OUTLET PIPE JOINT	2	
	12	1106013067	COOLING WATER BYPASS HOSE JOINT	2	
	13	1086001088	WATER TEMPERATURE SENSOR	1	
	14	E040000701	OIL PUMP FIXING BOLT	1	
	15	E010400901	SEAL WASHER	1	
	16	1106013088	THERMOSTAT	1	
	17	E060000101	WATER INTEL	1	
	18		DOUBLE END STUD M6x25	2	
	19		PREVAILING TORQUE TYPE HEXAGON NUT WITH FLANGE	2	M6
	20		THERMOSTAT ASSY.	1	
	21	E010501301	DOUBLE END STUD M8x45	2	
	22		WATER INLET (FOR SHANGHAI MAPLE ONLY)	1	
	23		PLUG FOR WATER TEMPERAURE SWITCH SCREW	1	
	24		COVER Φ 32X14 (FOR TRANSPORTATION)	1	
	25		COVER Φ 17X12 (FOR TRANSPORTATION)	2	

16 WATER PUMP ASSY.

	NO.	PART NO.	DES	QTY	REMARK	
	10	1106013239	WATER PUMP PULLEY	1	CK-1	
		2160197501	WATER PUMP PULLEY	1	MK	
		11		PULLEY SEAT	1	
		12		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	4	M6x12
		13		WATER PUMP PIVOT BEARING	1	
		14		WATER PUMP FIXING BOLT M8x35	3	
		15		WATER PUMP BODY	1	
		16		ROTOR	1	
		17		WATER PUMP GASKET	1	
		18		WATER PUMP SUCTION COVER	1	
		19	E050200501	WATER PUMP INLET PIPE GASKET	1	
		20	E050200201	INLET HOSE	1	
		21	Q67645	CLIP	2	
		22	1106013085	WATER TEMPERATURE GAUGE SENSOR	1	
		23	E050200401	2# WATER INLET PIPE	1	
		24	E050100005	WATER PUMP BODY ASSY.	1	
		25		WATER PUMP SEAL	1	
		26		WATER PUMP ASSY.	1	
		27		DOUBLE END STUD M6x25	1	
		28	E010501501	DOUBLE END STUD M8x33.5	2	

17-1 THROTTLE(EURO II)

	NO.	PART NO.	DES	QTY	REMARK
 <p>The diagram shows an exploded view of the throttle body assembly. Part 10 is the main throttle body. Part 11 is the throttle body gasket. Part 12 is a mounting bolt. Part 13 is a hex nut. Part 14 is an adjuster-idle. Part 15 is the adjuster-idle seat. Part 16 is the control rocker components. Part 17 is another throttle body component. Part 18 is an adjuster-idle gasket. Part 19 is a seal. Part 20 is the throttle position sensor. Part 21 is the throttle cover. The diagram also shows a separate view of the throttle cover (21) and the adjuster-idle (14) with its gasket (18).</p>	10	E110320005	THROTTLE BODY COMPONENTS	1	
	11	1106013071	THROTTLE BODY GASKET	2	
	12		THROTTLE BODY MOUNTING BOLT M8x54	2	
	13		PREVAILING TORQUE TYPE HEXAGON NUT WITH FLANGE	1	M8
	14	1106013160	ADJUSTER-IDLE	1	
	15	1106010336	ADJUSTER-IDLE SEAT	1	
	16		CONTROL ROCKER COMPONENTS	1	
	17	E110320005	THROTTLE BODY COMPONENTS	1	
	18	1106010337	ADJUSTER-IDLE GASKET	1	
	19		SEAL	1	
	20	1106013159	THROTTLE POSITION SENSOR	1	
	21		THROTTLE COVER	1	

17-2 THROTTLE(EURO III)

	NO.	PART NO.	DES	QTY	REMARK
	10	2110710012	THROTTLE BODY COMPONENTS	1	
		1086001158-01	THROTTLE BODY COMPONENTS (STEP MOTOR)	1	
		1086000674-01	THROTTLE ASSY.	1	1.6L
		2110300008-01	THROTTLE ASSY.	1	AT
	11	1106013071	THROTTLE BODY GASKET	1	1.3L/1.5L
		2110301021	THROTTLE BODY GASKET	1	1.6L
	12		FUEL TUBE FIXING BOLT	2	
	13		HEXAGON FLANGE NUT M8	2	
	14	1107130002	STEP MOTOR	1	1.3L/1.5L
		2150080008	STEP MOTOR	1	1.6L
	15	1106013159	THROTTLE POSITION SENSOR	1	

18 INTAKE MANIFOLD COMPONENTS


	NO.	PART NO.	DES	QTY	REMARK	
	12		ACCELERATOR LEVER CLIP	1		
	13		DOUBLE END STUD M6x25	2		
	14	1106013123		INTAKE MANIFOLD	1	1.3L
	14	2010200102		INTAKE MANIFOLD	1	1.3L/1.5L
	14	1086000511		INTAKE MANIFOLD	1	1.6L
	14	1106016015		INTAKE MANIFOLD(SPECIAL CHILE)	1	1.6L
	15	1106010502		COVER	1	
	16	E010200301		STRAIGHT PIPE JOINT A	1	
	17	E010200601		HEXAGON HEAD PIPE JOINT R1/18x18	1	
	18			DUSTPROOF PLUG	1	
	19	E010200501		STRAIGHT PIPE JOINT B	1	
	23	E010200201		BENDED PIPE JOINT	1	
	24	1106013163		INTAKE TEMPERATURE & PRESSURE SENSOR	1	EURO II
	24	2150010006		INTAKE TEMPERATURE & PRESSURE SENSOR	1	EURO III
	25			HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	M6x16
	26	E110300501		COOLING WATER BYPASS HOSE	2	
	27	1106013081		FUEL RETURN PIPE & BRACKET ASSY.	1	
	28			PREVAILING TORQUE TYPE HEXAGON NUT WITH FLANGE	2	M6
	29	E010001301		INTAKE MANIFOLD GASKET	1	
	31	E010501501		DOUBLE END STUD M8x35	2	
	32			INTAKE MANIFOLD STAY FIXING BOLT M8x16	1	
	33			HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	M6x16
	34	1106013195		INTAKE MANIFOLD STAY	1	
	35	1106013073		FUEL RETURN HOSE	1	
	36			INTAKE MANIFOLD FIXING BOLT	7	

18 INTAKE MANIFOLD COMPONENTS

NO.	PART NO.	DES	QTY	REMARK	NO.	PART NO.	DES	QTY	REMARK
37		DOUBLE END STUD M8x62	2						
40	E010200005	INTAKE MANIFOLD COMPONENTS	1						
41		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	M10x1.25x20					
42		PIPE	2						
43		CLIP	2						
44		CLIP	4						
45		CLIP	2						
46		COVER ϕ 3.5x9 (FOR TRANSPORTATION)	1						
47		COVER ϕ 7x10 (FOR TRANSPORTATION)	1						

19 EXHAUST MANIFOLD COMPONENTS



NO.	PART NO.	DES	QTY	REMARK
10		EXHAUST MANIFOLD	1	
11	2150020006	OXYGEN SENSOR	1	1.3L
	2150020003	OXYGEN SENSOR	1	1.5L
	1106013165	OXYGEN SENSOR	1	EURO II
12		EXHAUST MANIFOLD STAY	1	
13	E010300901	DOUBLE END STUD M10x1.25x40	5	
14	1106013193	UPPER HEAT INSULATOR	1	
15		UPPER/LOWER HEAT INSULATOR FIXING BOLT	6	M6x12
16		EXHAUST MANIFOLD STAY FIXING BOLT M8x25	1	
17		NUT M10x1.25	5	
18	E010300401	LOWER HEAT INSULATOR	1	
19	E010001401	EXHAUST MANIFOLD GASKET	1	
20	E010300005	EXHAUST MANIFOLD COMPONENTS	1	1.3L
	1106015029	EXHAUST MANIFOLD COMPONENTS	1	1.5L
	1106016015	EXHAUST MANIFOLD COMPONENTS(SPECIAL CHILE)	1	1.6L
21		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	M10x1.25x20
22		WIRE CLIP	1	



20 FUEL INJECTOR

	NO.	PART NO.	DES	QTY	REMARK	
	11	E110220005	FUEL INLET HOSE COMPONENTS	1		
	13	E110200401	FUEL HOSE BOLT GASKET	2		
	15	E010201001	FUEL RAIL INSULATOR	2		
	16	1106013169	FUEL PRESSURE REGULATOR	1		
	17	2110110101	O RING	1		
	22	1106013084	FUEL RAIL COMPONENTS	1		
	23	1086000753	FUEL RAIL COMPONENTS	1	RHD	
	23	1106013162	FUEL INJECTOR FIXING BRACKET	4		
	24	1106013158	FUEL INJECTOR ASSY.	4		
	25	1106013286	O RING 15x8x3.5	8		
		32	E100512201	VACUUM HOSE	1	
		33	1601809180	CANISTER DESORPTION HOSE	1	
		33	1601810180	CANISTER AIR INTAKE HOSE	1	
		34	1016001357	CONTROL CANISTER	1	
35		1104148001	FUEL EVAPORATIVE EMISSION HOSE	1		
36		E150090005	CHARCOAL CANISTER VALVE	1		
37		E010004001	PCV HOSE	1		
38						
31						
31						
31						
31						

21 IGNITION CABLE ASSY.



NO.	PART NO.	DES	QTY	REMARK
11	1106013184	REAR HANGER	1	
12		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	M10x1.25x20
13	1106013183	FRONT HANGER	1	
14	1106013243	SPARK PLUG	4	
21	1106013241	IGNITION CABLE	1	
22		FOUR WIRES CLAMP	1	
23		THREE WIRES CLAMP	1	
24		DOUBLE WIRES CLAMP	1	


22 ECU & IGNITION COIL

	NO.	PART NO.	DES	QTY	REMARK
	11		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	4	M6x50
	12	1106013248	IGNITION COIL	1	
	13	1106013242	IGNITION COIL MOUNTING BRACKET	1	
	14		BOLT M8x31	3	
	15	E150110005	ECU (EURO II)	1	1.3L
		2150110003	ECU(EURO III)	1	1.3L
	18	E150110010	ECU (EURO II)	1	1.5L/1.6
		2150110008	ECU (EURO III)	1	1.5L/1.6
	20	1086001116	ECU (EURO III+OBD)	1	1.5L
		1106010227	ECU (EURO III+OBD)	1	1.3L
	16	E000500005	ENGINE WIRING HARNESS ASSY.(EURO II)	1	
	17	2000500024	ENGINE WIRING HARNESS ASSY. (EURO II, DUAL FANS)	1	CK-1
		2000500024-01	ENGINE WIRING HARNESS ASSY. (EURO III)(DUAL FANS)	1	CK-1
		2000500026	ENGINE WIRING HARNESS ASSY. (EURO III) (DUAL FANS,AT)	1	CK-1
	19	1086001110	ENGINE WIRING HARNESS ASSY. (EURO III+OBD)	1	CK-1
		1086001112	ENGINE WIRING HARNESS ASSY. (EURO III+OBD)	1	MK


23 ALTERNATOR COMPONENTS

	NO.	PART NO.	DES	QTY	REMARK
	10	E090200005	ALTERNATOR ADJUSTING BRACKET	1	
	11	2090200501	ADJUSTING BRACKET BOLT M10x1.25x23	2	
	12	E090200201	ADJUSTING BLOCK	1	
	13	2090000801	ALTERNATOR UPPER/LOWER ADJUSTING BOLT	1	M8x89
	14		NUT WITH STOP TAB M10x1.25	1	
	15	E090000101	ALTERNATOR BRACKET	1	
	16	1106013201	ALTERNATOR COMPONENTS 75A	1	1.3L/1.5L
	17	1086001111	ALTERNATOR COMPONENTS 90A	1	1.6L
	18		ALTERNATOR FRONT/REAR ADJUSTING BOLT	1	M8x43
	19		ALTERNATOR BRACKET UPPER FIXING BOLT	2	M8x25
	20		ALTERNATOR BRACKET LOWER FIXING BOLT	1	M8x30
	21	E090000501	ALTERNATOR FIXING BOLT M10x1.25x105	1	
	22	E030000401	DRIVING BELT	1	
	23	1106010346	75A GENERATOR ADJUSTER	1	
	24	1106010347	90A GENERATOR ADJUSTER	1	

24 STARTER





	NO.	PART NO.	DES	QTY	REMARK
	20	E080000010	STARTER COMPONENTS	1	1.3L/1.5L
		E370801021	STARTER COMPONENTS	1	1.6L
	21		HEXAGON HEAD BOLT & SINGLE COIL SPRING LOCK WASHER	2	M10x1.25x40
	22	1106010351	MAGNETIC SWITCH	1	

25 FUEL PUMP ASSY.



NO.	PART NO.	DES	QTY	REMARK
10		FUEL PUMP ASSY.	1	
11		CROSS RECESSED HEXAGON BOLT	8	M5x14
12		FUEL PUMP BRACKET	1	
13		FUEL PUMP	1	
14	1601285180	FUEL PUMP&FUEL LEVEL SENSOR	1	

26 ENGINE MOUNTING



NO.	PART NO.	DES	QTY	REMARK
10		ENGINE REAR MOUNT ASSY.	1	
11		HEXAGON HEAD BOLT & THICK PLAIN WASHER ASSY.	2	M10x1.25x30
12		HEXAGON HEAD BOLT M10x1.25x110	2	
13	1600437180	ENGINE REAR MOUNT INSULATOR ASSY.	1	
14		HEXAGON HEAD BOLT & SINGLE COIL SPRING LOCK WASHER	1	M12x1.25x95
15	1600501180	REAR MOUNT BRACKET CONNECTING PLATE ASSY.	1	
16		HEXAGON FLANGE BOLT-PRODUCT GRADE B M1x1.25x30	3	
17	1600434180	ENGINE REAR MOUNT BRACKET	1	
18		HEXAGON HEAD BOLT & SINGLE COIL SPRING LOCK WASHER	2	M10x1.25x25
20		ENGINE LEFT MOUNT ASSY.	1	
21		HEXAGON FLANGE BOLT-PRODUCT GRADE A M10x1.25	1	
22		HEXAGON HEAD BOLT & SINGLE COIL SPRING LOCK WASHER	1	M12x1.25x25
23	1600564180	ENGINE LEFT MOUNT BRACKET ASSY.	1	
24	1600436180	ENGINE LEFT MOUNT INSULATOR ASSY.	1	
25		THICK PLAIN WASHER M12x1.25x25	1	
26		HEXAGON FLANGE BOLT-PRODUCT GRADE A M12x1.25	1	
27	1600566180	ENGINE RIGHT MOUNT BRACKET REINFORCEMENT	1	
28		HEXAGON HEAD BOLT	2	M12x1.25x30
29		HEXAGON HEAD BOLT & SINGLE COIL SPRING LOCK WASHER	4	M10x1.25x25
31		ENGINE RIGHT MOUNT INSULATOR REINFORCEMENT	1	
32		AXIS PIN	1	
33		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	M12x1.25
34		ENGINE RIGHT UPPER MOUNT BRACKET	1	
35		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	M12x1.25x30
36		HEXAGON HEAD BOLT M10x1.25x38	2	

26 ENGINE MOUNT

NO.	PART NO.	DES	QTY	REMARK	NO.	PART NO.	DES	QTY	REMARK
40	2000410104	ENGINE RIGHT MOUNT BRACKET ASSY.	1						
41		HEXAGON HEAD BOLT & SINGLE COIL SPRING LOCK WASHER	1	M10x1.25x50					
42	1600418180	ENGINE RIGHT MOUNT BRACKET ASSY.	1						
43		HEXAGON HEAD BOLT & SINGLE COIL SPRING LOCK WASHER	1	M12x1.25x95					
44		LONG NUT WITH SPRING WASHER	1						
45		HEXAGON HEAD BOLT & SINGLE COIL SPRING LOCK WASHER	3	M10x1.25x20					
46	1600435180	ENGINE RIGHT MOUNT INSULATOR ASSY.	1						

27 CAMSHAFT POSITION SENSOR

	NO.	PART NO.	DES	QTY	REMARK
	20	E120101001	CAMSHAFT POSITION SENSOR SEAT COMPONENTS	1	
	21	1106013247	CAMSHAFT POSITION SENSOR	1	
	22		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	
	23		HEXAGON HEAD BOLT	2	
	30		CAMSHAFT POSITION SENSOR SENSOR & SEAT COMPONENTS	1	

28 COLD AIR INTAKE BOX

	NO.	PART NO.	DES	QTY	REMARK
	10	1109320005	COLD AIR INTAKE BOX SUB-ASSY.	1	
	11		HEXAGON NUT & WAVE WASHER ASSY. M6	2	
	12		BOWL-SHAPED WASHER	2	
	13		FLEXIBLE WASHER	1	
	16		HEXAGON HEAD BOLT & LARGE PLAIN WASHER ASSY.	1	
	17		WASHER	1	
	18	1109401005	COLD AIR INTAKE BOX LOWER BRACKET	1	


29 CLUTCH ASSY.

	NO.	PART NO.	DES	QTY	REMARK
	11	1106015058	FRICITION PLATE ASSY.	1	
		1106018067	FRICITION PLATE ASSY.	1	1.6L
	12	1106015057	PRESSUREPLATE ASSY.	1	
		1106018008	PRESSUREPLATE ASSY.	1	1.6L
	13		HEXAGON HEAD BOLT M8x16	6	
	14		CLUTCH ASSY.	1	

CONTENT


1	PETROL ENGINE ASSY.	21	IGNITION CABLE ASSY.
2	PETROL ENGINE COMPONENTS	22	ECU & IGNITION COIL
3	CYLINDER BLOCK SUB-ASSY.	23	ALTERNATOR COMPONENTS
4	CYLINDER HEAD COVER COMPONENTS	24	STARTER
5	CYLINDER HEAD	25	FUEL PUMP ASSY.
6	CYLINDER BLOCK COMPONENTS	26	ENGINE MOUNTING
7	TIMING BELT COVER AND BELT PULLEYS	27	PHASE SENSOR AND BASE
8	PISTON CONNECTING ROD COMPONENTS	28	COLD AIR INTAKE BOX
9	CRANKSHAFT FLYWHEEL COMPONENT	29	CLUTCH ASSY.
10	CAMSHAFT		
11	VALVE		
12	TIMING BELT		
13	OIL PUMP ASSY.		
14	OIL STRAINER AND OIL PAN COMPONENTS		
15	THERMOSTAT ASSY.		
16	WATER PUMP ASSY.		
17	THROTTLE		
18	INTAKE MANIFOLD COMPONENTS		
19	EXHAUST MANIFOLD COMPONENTS		
20	FUEL INJECTOR		

1 PETROL ENGINE ASSY.



NO.		DES	QTY	REMARK
10		PETROL ENGINE ASSY.	1	
11		PETROL ENGINE FILM COVER (FOR TRANSPORTATION)	1	1.3L
12		PETROL ENGINE MAINTAINANCE PASTER	1	
13		PETROL ENGINE MAINTAINANCE PASTER	1	1.5L

2 PETROL ENGINE COMPONENTS



3 CYLINDER BLOCK SUB-ASSY.

	NO.	PART NO.	DES	QTY	REMARK
		E000010010	CYLINDER BLOCK SUB-ASSY.	1	1.3L
		E000010002	CYLINDER BLOCK SUB-ASSY.	1	1.5L

4 CYLINDER HEAD COVER COMPONENTS

	NO.	PART NO.	DES	QTY	REMARK
	10	1086001126	CYLINDER HEAD COVER	1	
	11	1106013110	CYLINDER HEAD COVER OIL BAFFLER GASKET	1	
	12	E010400301	OIL BAFFLER A	1	
	13	E010400401	OIL BAFFLER B	1	
	14	1086001127	CYLINDER HEAD COVER GASKET	1	
	15	1106013107	CYLINDER HEAD OIL SEAL ASSY.	4	
	16	1106013115	OIL CAP	1	
	17	E010402001	CONTROL VALVE	1	
	18	E010400501	VENTILATION HOSE JOINT	1	
	19		OIL CAP SEAL WASHER	1	
	20	E010401001	WIRE HARNESS BRACKET	1	
	21		WIRE HARNESS BRACKET FIXING BOLT M6x16	1	
	22	E010400901	SEAL SHEATH	1	
	23		CYLINDER HEAD COVER COMPONENTS	1	
	24	1086000532	CYLINDER HEAD COVER NUT	4	
	25	E010401501	WASHER ASSY.	4	
	26	2000000701	MR479Q PETROL ENGINE SCUTCHEON	1	
	27	1106010506	DOUBLE END STUD M6x83	4	
	28		COVER Φ 7x10 (FOR TRANSPORTATION)	1	
	29		MR479QA PETROL ENGINE SCUTCHEON	1	

5 CYLINDER HEAD

	NO.	PART NO.	DES	QTY	REMARK
	11	E010001601	CYLINDER HEAD GASKET	1	
	12		STEEL BALL	2	
	13	1086090101	CYLINDER HEAD	1	1.5L
	14	1086090100	CYLINDER HEAD	1	1.3L
	15	E010500301	SEALING COVER B	2	
	16	E010500601	SPARK PLUG TUBE	4	
	17	E010500901-01	CYLINDER HEAD BOLT M10x1.25x108	5	
	18	E010500801-01	CYLINDER HEAD BOLT M10x1.25x90	5	
	19	E010501001	WASHER $\Phi 20.5 \times 3$	10	
	20		CYLINDER HEAD PLUG M20x1.5	3	
	21		CYLINDER HEAD PLUG WASHER	3	
	22		ALIGNING PIN BUSH	6	
	23	E010500201	SEALING COVER A	2	
	24	2010001801	SEMICIRCLE PLUG	1	
	25	E010001701	WATER OUTLET	1	
	26		WATER OUTLET FIXING BOLT	2	
	27		WATER OUTLET (FOR SHANGHAI MAPLE ONLY)	1	
	28		COVER $\Phi 32 \times 14$ (FOR TRANSPORTATION)	1	

6 CYLINDER BLOCK COMPONENTS

	NO.	PART NO.	DES	QTY	REMARK
	10	E020300104	CYLINDER BLOCK	1	
	11		MAIN BEARING CAP (1ST, 2ND, 4TH, 5TH)	4	
	12		MAIN BEARING (3RD)	1	
	13	E020300201	ALIGNING PIN $\Phi 11 \times 8$	2	
	14	E020300401	OIL GALLERY BOLT R3/8x10	2	
	15	E020300301	HANGING PIN $\Phi 6 \times 22$	1	
	16	1106013216	UPPER MAIN BEARING	5	
	17	1106013217	LOWER MAIN BEARING	5	
	18	E020301601	CRANKSHAFT UPPER THRUST WASHER	2	
	19	E020301701	CRANKSHAFT LOWER THRUST WASHER	2	
	20	1106010501	SEALING COVER $\Phi 40$	1	
	21	1106010502	SEALING COVER $\Phi 35$	4	
	22	1086001166	KNOCK SENSOR(479Q)	1	
		21500400041	KNOCK SENSOR(479QA)	1	
	23	E020300801	ALIGNING PIN $\Phi 13 \times 12$	2	
	24	E020300501	ALIGNING PIN $\Phi 10 \times 22$	2	
	25	E020300701	ALIGNING PIN $\Phi 6 \times 14$	2	
	26		HEXAGON SOCKET DOUBLE END SCREW CANNULA	1	
	27	1106013268	MASTER BEARING CAP BOLT M10x1.25x60	10	
	28	E020302101	DOUBLE END STUD M6x18	2	
	29		PREVAILING TORQUE TYPE HEXAGON NUT WITH FLANGE	2	M6
	30		CYLINDER BLOCK COMPONENTS	1	
	31		BOLT M8x12	1	

6 CYLINDER BLOCK COMPONENTS

NO.	PART NO.	DES	QTY	REMARK	NO.	PART NO.	DES	QTY	REMARK
32	E020301201	DRAIN PLUG R1/4x12	1						
33	1106013221	OIL FILTER COMPONENTS	1						
34	1106013220	OIL PRESSURE SWITCH	1						
35		SPEED SENSOR MOUNTING BRACKET ALIGNING PIN BUSH	2						
36	E020000201	SPEED SENSOR MOUNTING BRACKET	1						
37	E20110003	HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	3						
38	1086001168	ENGINE SPEED SENSOR	1						
41	2000410104	ENGINE RIGHT MOUNTING BRACKET(CK-1)	1						
	1086000442	ENGINE RIGHT MOUNTING BRACKET(MK)	1						
	E000410101	ENGINE RIGHT MOUNTING BRACKET(OLD TYPE)	1						
42		BOLT	3						
43	E050000301	O RING 34.5x2.65	1						


7 TIMING BELT COVER & BELT PULLEYS

NO.	PART NO.	DES	QTY	REMARK
10	1106013231	CRANKSHAFT PULLEY	1	
11	E030100101	NO.1 TIMING BELTS COVER	1	
12	E030000301	TIMING BELT GUIDE	1	
13	E030000201	CRANKSHAFT TIMING PULLEY	1	
14	E030100201	NO.2 TIMING BELTS COVER	1	
15	E030100301	NO.3 TIMING BELTS COVER	1	
16		HEXAGON FLANGE BOLT-PRODUCT GRADE B	9	M6x20

8 PISTON CONNECTING ROD COMPONENTS

	NO.	PART NO.	DES	QTY	REMARK
	11		TOP COMPRESSION RING	4	
	12		SECOND COMPRESSION RING	4	
	13		OIL RING EXP&ER	4	
	14		OIL RING SIDE RAIL	8	
	15		OIL RING COMPONENTS	4	
	16	E020110010	PISTON RING COMPONENTS	4	
	17	E020100103-01	PISTON	4	1.3L
	26	E020100106	PISTON	4	1.5L
	18	1106013100	PISTON PIN	4	
	19		CONNECTING ROD BODY	4	
	20		CONNECTING ROD BOLT	8	
	21		CONNECTING ROD HEAD	4	
	22		CONNECTING ROD NUT	8	
	23	E020120501	CONNECTING ROD BEARINGS	8	
	24	E020120005	CONNECTING ROD COMPONENTS	4	
	25		PISTON CONNECTING ROD COMPONENTS	4	
	27		MR479QA PISTON CONNECTING ROD COMPONENTS	4	

9 CRANKSHAFT FLYWHEEL COMPONENT




NO.	PART NO.	DES	QTY	REMARK
11	E020210301	CRANKSHAFT BELT PULLEY FIXING BOLT	1	
12		WASHER	1	
13	E020210201	SEMICIRCLE KEY	1	
14	E020210103	CRANKSHAFT MR479Q	1	
15		CRANKSHAFT COMPONENTS	1	
21	E020500201	REAR OIL SEAL RETAINER GASKET	1	
22	E020500005	CRANKSHAFT REAR OIL SEAL RETAINER	1	
23	E20103011	HEXAGON FLANGE BOLT-PRODUCT GRADE B	6	M6x16
24	1106013094	CRANKSHAFT REAR OIL SEAL ASSY.	1	
25		REAR OIL SEAL RETAINER COMPONENTS	1	
26	E020000101	CLUTCH HOUSING PLATE	1	
27		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	M6x13
31	1106013307	FLYWHEEL GEAR RING	1	
32	1086000783	FLYWHEEL	1	
33	E020220501	FLYWHEEL FIXING BOLT M10x1.25x23	6	
34	E020220301	ALIGNING PIN $\Phi 8 \times 20$	3	
35	1106013095	FLYWHEEL COMPONENTS	1	
41		SENSOR PLATE	1	
42		CRANKSHAFT FLYWHEEL COMPONENTS	1	
43	E020210106	CRANKSHAFT MR479QA	1	
44		CRANKSHAFT COMPONENTS	1	
45		MR479QA CRANKSHAFT FLYWHEEL COMPONENTS	1	

10 CAMSHAFT


	NO.	PART NO.	DES	QTY	REMARK
	10	E010110101	INTAKE CAMSHAFT	1	1.3L
		2100603121	INTAKE CAMSHAFT	1	1.5L
	12	E010110301	DRIVING GEAR	1	
	13	E010110501	SUB-GEAR	1	
	14	E010110401	CAMSHAFT GEAR SPRING	1	
	15	E010110701	WAVE WASHER	1	
	16	E010110801	SNAP RING	1	
	17	E010110601	DRIVING GEAR ALIGNING PIN Φ 5x8	1	
	18	E010110201	SUB-GEAR ALIGNING PIN Φ 5x7	1	
	19	E010120201	ALIGNING PIN Φ 5x12	1	
	20	E010000103	INTAKE CAMSHAFT BEARING CAP A	1	
	21		EXHAUST CAMSHAFT BEARING CAP A	1	
	22		EXHAUST CAMSHAFT BEARING CAP B	1	
	23	E010000203	CAMSHAFT BEARING CAP	8	
	25	E010002701	CAMSHAFT BEARING CAP BOLT	18	
	30	E010120101	EXHAUST CAMSHAFT	1	1.5L
		1086001125	EXHAUST CAMSHAFT	1	1.3L
	31	E010120301	TRANSMITTING GEAR	1	
	32	E030000101	CAMSHAFT TIMING BELT GUIDE	1	
	33	1106013187	EXHAUST CAMSHAFT OIL SEAL ASSY.	1	
	34		SNAP RING	1	
	36		INTAKE CAMSHAFT COMPONENTS	1	
	37		EXHAUST CAMSHAFT COMPONENTS	1	
	38	E030000801	CAMSHAFT TIMING BELT GUIDE FIXING BOLT	1	

11 VALVE




NO.	PART NO.	DES	QTY	REMARK
10	E010001201	SHIM	16	
11	1086001194	VALVE TAPPET	16	
12	1106018005	VALVE KEEPER	32	
13	E010000901	VALVE SPRING SEAT	16	
14	E010000801	VALVE SPRING	16	
15	1106013097	INTAKE OIL SEAL ASSY.	8	
16	1106018006	VALVE SPRING RETAINER	16	
17	E010500703	VALVE GUIDE	16	
18	E010000501	INTAKE VALVE	8	
20	E010000601	EXHAUST VALVE	8	
21	1106013098	EXHAUST OIL SEAL ASSY.	8	

12 TIMING BELT

	NO.	PART NO.	DES	QTY	REMARK
	10	E030000701	TIMING BELT	1	
	11	E030000501	TENSION SPRING	1	
	12	1106013230	BELT TENSIONER COMPONENTS	1	
	13	E030000901	TIMING BELT TENSIONER FIXING BOLT	1	M10x1.25x40

13 OIL PUMP ASSY.



NO.	PART NO.	DES	QTY	REMARK
10	E040000401	CRANKSHAFT FRONT OIL SEAL RETAINER GASKET	1	
11		SCREW M6x10	5	
12		OIL PUMP BODY COVER	1	
13		DRIVING ROTOR	1	
14		DRIVEN ROTOR	1	
15		OIL PUMP BODY	1	
16	E040000601	OIL PUMP SHORT FIXING BOLT M8x25	5	
17	E040000701	OIL PUMP FIXING BOLT M8x35	2	
18		PISITION BUSH	1	
19	E040000801	DOUBLE END STUD M6x22	2	
20		RETAINER	1	
21	1106013209	CRANKSHAFT FRONT OIL SEAL ASSY.	1	
22		OIL PUMP PRESSURE RELIEF VALVE	1	
23		SPRING	1	
24		SNAP RING	1	
25		HEXAGON SOCKET PLUG R3/8x10	1	
26		PREVAILING TORQUE TYPE HEXAGON NUT WITH FLANGE	2	M6
27	E040100005	OIL PUMP ASSY.	1	

14 OIL STRAINER & OIL PAN COMPONENTS

	NO.	PART NO.	DES	QTY	REMARK
	10	1106013215	OIL PAN COMPONENT	1	
	11		BAFFLE BOARD	1	
	12		NUT M12x1.25	1	
	13		OIL PAN	1	
	14	E020400201	OIL DRAIN PLUG WASHER	1	
	15		PREVAILING TORQUE TYPE HEXAGON NUT WITH FLANGE	2	M6
	16	E020400101	OIL DRAIN PLUG M12x1.25x16	1	
	17		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	19	M6x12
	21	E020900101	OIL STRAINER GASKET	1	
	22	E020900005	OIL STRAINER	1	
	23		PREVAILING TORQUE TYPE HEXAGON NUT WITH FLANGE	2	M6
	24		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	M6x12
	30	1106013170	OIL DIPSTICK	1	
	31		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	M6x12
32		O RING 10x1.8	1		
33		PETROL ENGINE QUALIFICATION CERTIFICATION	1	1.3L	
34		PETROL ENGINE QUALIFICATION CERTIFICATION	1	1.5L	

15 THERMOSTAT ASSY.

	NO.	PART NO.	DES	QTY	REMARK
	10	1106013089	WATER INLET HOUSING	1	
	11		SIMPLE CIRCULATION WATER INLET/OUTLET PIPE JOINT	2	
	12	1106013067	COOLING WATER BYPASS HOSE JOINT	2	
	13	1086001129	WATER TEMPERATURE SENSOR	1	1.3L
		1086001163	WATER TEMPERATURE SENSOR	1	1.5L
	14	E040000701	OIL PUMP FIXING BOLT	1	
	15	E010400901	SEAL WASHER	1	
	16	1106013088	THERMOSTAT	1	
	17	E060000101	WATER INTEL	1	
	18		DOUBLE END STUD M6x25	2	
	19		PREVAILING TORQUE TYPE HEXAGON NUT WITH FLANGE	2	M6
	20		THERMOSTAT ASSY.	1	
	21	E010501301	DOUBLE END STUD M8x45	2	
	22		WATER INLET	1	
	23		PLUG FOR WATER TEMPERAURE SWITCH SCREW	1	
	24		COVER Φ 32X14 (FOR TRANSPORTATION)	1	
	25		COVER Φ 17X12 (FOR TRANSPORTATION)	2	

16 WATER PUMP ASSY.

	NO.	PART NO.	DES	QTY	REMARK
	10	1106013239	WATER PUMP PULLEY	1	CK
		2160197501	WATER PUMP PULLEY	1	MK
	11		PULLEY SEAT	1	
	12		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	4	M6x12
	13		WATER PUMP PIVOT BEARING	1	
	14		WATER PUMP FIXING BOLT M8x35	3	
	15		WATER PUMP BODY	1	
	16		ROTOR	1	
	17		WATER PUMP GASKET	1	
	18		WATER PUMP SUCTION COVER	1	
	19	E050200501	WATER PUMP INLET PIPE GASKET	1	
	20	E050200201	INLET HOSE	1	
	21	Q67645	CLIP	2	
	22	1106013085	WATER TEMPERATURE GAUGE SENSOR	1	
	23	1086001162	2# WATER INLET PIPE	1	
	24	E050100005	WATER PUMP BODY ASSY.	1	
	25		WATER PUMP SEAL	1	
	26		WATER PUMP ASSY.	1	
	27		DOUBLE END STUD M6x25	1	
	28	E010501401	DOUBLE END STUD M8x33.5	2	

17-2 THROTTLE

	NO.	PART NO.	DES	QTY	REMARK	
	10	2110710012	THROTTLE BODY COMPONENTS	1	1.3L	
		1086001158-01	THROTTLEBODY COMPONENTS	1	1.5L	
		2110300008-01	THROTTLE ASSY.	1	AT	
		11	1086001161	MR 479Q/QA THROTTLE BODY GASKET	1	
		12		FUEL TUBE FIXING BOLT	2	
		13		HEXAGON FLANGE NUT M8	2	
		14	1107130002	STEP MOTOR	1	1.3L
			1086001156	STEP MOTOR	1	1.5L
		15	1106013159	THROTTLE POSITION SENSOR	1	1.3L
			1086001157	THROTTLE POSITION SENSOR	1	1.5L


18 INTAKE MANIFOLD COMPONENTS

	NO.	PART NO.	DES	QTY	REMARK	
	11		HEXAGON FLANGE BOLT M8x14	2		
	12		ACCELERATOR LEVER CLIP	1		
	13		DOUBLE END STUD M6x25	2		
	14	1086001147		INTAKE MANIFOLD	1	1.3L
		1086001172		INTAKE MANIFOLD	1	1.5L
	15	1106010502		COVER	1	
	16	E010200301		STRAIGHT PIPE JOINT A	1	
	17	E010200601		HEXAGON HEAD PIPE JOINT R1/18x18	1	
	18			DUSTPROOF PLUG	1	
	19	E010200501		STRAIGHT PIPE JOINT B	1	
	23	E010200201		BENDED PIPE JOINT	1	
	24	1086001167		INTAKE TEMPERATURE & PRESSURE SENSOR (479Q)	1	
		1086000786		INTAKE TEMPERATURE & PRESSURE SENSOR (479QA)	1	
	25			HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	M6x16
	26	1086005001		COOLING WATER BYPASS HOSE	2	
	27	1086001173		FUEL RETURN PIPE & BRACKET ASSY.(479Q)	1	
		1086001174		FUEL RETURN PIPE & BRACKET ASSY.(479QA)	1	
	28			PREVAILING TORQUE TYPE HEXAGON NUT WITH FLANGE	2	M6
	29	E010001301		INTAKE MANIFOLD GASKET	1	
	31	E010501501		DOUBLE END STUD M8x35	2	
	32			INTAKE MANIFOLD STAY FIXING BOLT M8x16	1	
	33			HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	M6x16
	34	1106013195		INTAKE MANIFOLD STAY	1	
	35	1086001195		FUEL RETURN HOSE	1	
	36			INTAKE MANIFOLD FIXING BOLT	7	


18 INTAKE MANIFOLD COMPONENTS

NO.	PART NO.	DES	QTY	REMARK	NO.	PART NO.	DES	QTY	REMARK
37		DOUBLE END STUD M8x62	2						
40	E010200005	INTAKE MANIFOLD COMPONENTS	1						
41		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	M10x1.25x20					
42		PIPE	2						
43		CLIP	2						
44		CLIP	4						
45		CLIP	2						
46		COVER Φ 3.5x9 (FOR TRANSPORTATION)	1						
47		COVER Φ 7x10 (FOR TRANSPORTATION)	1						
	1086000233	INTAKE TEMPERATURE & PRESSURE SENSOR BRACKET	1						



19 EXHAUST MANIFOLD COMPONENTS

	NO.	PART NO.	DES	QTY	REMARK
	10		EXHAUST MANIFOLD	1	
	11	1086001114	OXYGEN SENSOR	1	1.3L
		2150020003	OXYGEN SENSOR	1	1.5L
	12		EXHAUST MANIFOLD STAY	1	
	13	E010300901	DOUBLE END STUD M10x1.25x40	5	
	14	1106013193	UPPER HEAT INSULATOR	1	
	15		UPPER/LOWER HEAT INSULATOR FIXING BOLT	6	M6x12
	16		EXHAUST MANIFOLD STAY FIXING BOLT M8x25	1	
	17		NUT M10x1.25	5	
	18	E010300401	LOWER HEAT INSULATOR	1	
	19	E010001401	EXHAUST MANIFOLD GASKET	1	
	20	1086001181	EXHAUST MANIFOLD TWC	1	1.5L
		1086001179	EXHAUST MANIFOLD TWC	1	1.3L
	21		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	M10x1.25x20
	22		WIRE CLIP	1	

20 FUEL INJECTOR

	NO.	PART NO.	DES	QTY	REMARK
	11	E110220005	FUEL INLET HOSE COMPONENTS	1	
	13	E110200401	FUEL HOSE BOLT GASKET	2	
	15	E010201001	FUEL RAIL INSULATOR	2	1.3L
		1086001196	FUEL RAIL INSULATOR	2	1.5L
	16	1106013169	FUEL PRESSURE REGULATOR(1.3L)	1	
		1086001155	FUEL PRESSURE REGULATOR(1.5L)	1	
		1086001165	FUEL PRESSURE REGULATOR CASING(1.3L)	1	
		1086001150	FUEL PRESSURE REGULATOR CASING(1.5L)	1	
	17	2110110101	O RING	1	
	22	1086001164	FUEL RAIL COMPONENTS	1	
	23	1106013162	FUEL INJECTOR FIXING BRACKET	4	
	24	1106013158	FUEL INJECTOR ASSY.(1.3L)	4	
		1086001154	FUEL INJECTOR ASSY.(1.5L)	4	
	25	1106013286	O RING 15x8x3.5	8	
	32	1086001160	VACUUM HOSE	1	1.3L
		1086001192	VACUUM HOSE	1	1.5L
	33	1104510101	CHARCOAL CANISTER HOSE	1	
	34	1016001357	CHARCOAL CANISTER	1	
	35	1104148001	FUEL EVAPORATIVE EMISSION HOSE	1	
	36	E150090005	CHARCOAL CANISTER VALVE	1	
	37	E010004001	PCV HOSE	1	

21 IGNITION CABLE ASSY.



NO.	PART NO.	DES	QTY	REMARK
11	1106013184	REAR HANGER	1	
12		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	M10x1.25x20
13	1106013183	FRONT HANGER	1	
14	1106013243	SPARK PLUG	4	
21	1086000785	HIGH PRESSURE LEAD ASSY.	1	
22		FOUR WIRES CLAMP	1	
23		THREE WIRES CLAMP	1	
24		DOUBLE WIRES CLAMP	1	


22 ECU & IGNITION COIL

	NO.	PART NO.	DES	QTY	REMARK
	11		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	4	M6x50
	12	E150130005	IGNITION COIL	1	1.3L
		1086001171	IGNITION COIL	1	1.5L
	13	1106013242	IGNITION COIL INSTALLATION BRACKET	1	
	14		BOLT M8x31	3	
	15	1016000617	ECU	1	1.3L
		1016003757	ECU(ANTI-THEFT)	1	1.3L
	18	1016000619	ECU	1	1.5L
		1016003881	ECU(ANTI-THEFT)	1	1.5L
	17	1086001131	ENGINE WIRING HARNESS ASSY.	1	1.3L
		1017010232	ENGINE WIRING HARNESS ASSY. (ANTI-THEFT)	1	1.3L
	19	1017007988	ENGINE WIRING HARNESS ASSY.	1	1.5L
		1017010233	ENGINE WIRING HARNESS ASSY. (ANTI-THEFT)	1	1.5L


23 ALTERNATOR COMPONENTS

	NO.	PART NO.	DES	QTY	REMARK
	10	E090200005	ALTERNATOR ADJUSTING BRACKET	1	
	11	2090200501	ADJUSTING BRACKET BOLT M10x1.25x23	2	
	12	E090200201	ADJUSTING BLOCK	1	
	13	2090000801	ALTERNATOR UPPER/LOWER ADJUSTING BOLT	1	M8x89
	14		NUT WITH STOP TAB M10x1.25	1	
	15	E090000101	ALTERNATOR BRACKET	1	
	16	1086001111	ALTERNATOR COMPONENTS 90A	1	
	17		ALTERNATOR FRONT/REAR ADJUSTING BOLT	1	M8x43
	18		ALTERNATOR BRACKET UPPER FIXING BOLT	2	M8x25
	19		ALTERNATOR BRACKET LOWER FIXING BOLT	1	M8x30
	20	E090000501	ALTERNATOR FIXING BOLT M10x1.25x105	1	
	21	E030000401	DRIVING BELT	1	
	22	1106010346	75A GENERATOR ADJUSTER	1	
		1106010347	90A GENERATOR ADJUSTER	1	

24 STARTER





	NO.	PART NO.	DES	QTY	REMARK
	20	E08000010	STARTER COMPONENTS	1	
	21		HEXAGON HEAD BOLT & SINGLE COIL SPRING LOCK WASHER	2	M10x1.25x40
	22	2080000102	MAGNETIC SWITCH	1	

25 FUEL PUMP ASSY.



NO.	PART NO.	DES	QTY	REMARK
10		FUEL PUMP ASSY.	1	
11		CROSS RECESSED HEXAGON BOLT	8	M5x14
12		FUEL PUMP BRACKET	1	
13		FUEL PUMP	1	
14	1601285180	FUEL PUMP&FUEL LEVEL SENSOR	1	

26 ENGINE MOUNTING



NO.	PART NO.	DES	QTY	REMARK
10		ENGINE REAR MOUNTING ASSY.	1	
11		HEXAGON HEAD BOLT & THICK PLAIN WASHER ASSY.	2	M10x1.25x30
12		HEXAGON HEAD BOLT M10x1.25x110	2	
13	1600437180	ENGINE REAR MOUNTING INSULATOR ASSY.	1	
14		HEXAGON HEAD BOLT & SINGLE COIL SPRING LOCK WASHER	1	M12x1.25x95
15	1600501180	REAR MOUNTING BRACKET CONNECTING PLATE ASSY.	1	
16		HEXAGON FLANGE BOLT-PRODUCT GRADE B M1x1.25x30	3	
17	1600434180	ENGINE REAR MOUNTING BRACKET	1	
18		HEXAGON HEAD BOLT & SINGLE COIL SPRING LOCK WASHER	2	M10x1.25x25
20		ENGINE LEFT MOUNTING ASSY.	1	
21		HEXAGON FLANGE BOLT-PRODUCT GRADE A M10x1.25	1	
22		HEXAGON HEAD BOLT & SINGLE COIL SPRING LOCK WASHER	1	M12x1.25x25
23	1600564180	ENGINE LEFT MOUNTING BRACKET ASSY.	1	
24	1600436180	ENGINE LEFT MOUNTING INSULATOR ASSY.	1	
25		THICK PLAIN WASHER M12x1.25x25	1	
26		HEXAGON FLANGE BOLT-PRODUCT GRADE A M12x1.25	1	
27	1600566180	ENGINE RIGHT MOUNTING BRACKET REINFORCEMENT	1	
28		HEXAGON HEAD BOLT	2	M12x1.25x30
29		HEXAGON HEAD BOLT & SINGLE COIL SPRING LOCK WASHER	4	M10x1.25x25
31		ENGINE RIGHT MOUNTING INSULATOR REINFORCEMENT	1	
32		AXIS PIN	1	
33		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	M12x1.25
34		ENGINE RIGHT UPPER MOUNTING BRACKET	1	
35		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	2	M12x1.25x30
36		HEXAGON HEAD BOLT M10x1.25x38	2	


26 ENGINE MOUNTING

NO.	PART NO.	DES	QTY	REMARK	NO.	PART NO.	DES	QTY	REMARK
40	2000410104	ENGINE RIGHT MOUNTING BRACKET ASSY.	1						
41		HEXAGON HEAD BOLT & SINGLE COIL SPRING LOCK WASHER	1	M10x1.25x50					
42	1600418180	ENGINE RIGHT MOUNTING BRACKET ASSY.	1						
43		HEXAGON HEAD BOLT & SINGLE COIL SPRING LOCK WASHER	1	M12x1.25x95					
44		LONG NUT WITH SPRING WASHER	1						
45		HEXAGON HEAD BOLT & SINGLE COIL SPRING LOCK WASHER	3	M10x1.25x20					
46	1600435180	ENGINE RIGHT MOUNTING INSULATOR ASSY.	1						

27 CAMSHAFT POSITION SENSOR


	NO.	PART NO.	DES	QTY	REMARK
	20		CAMSHAFT POSITION SENSOR SEAT COMPONENTS	1	
	21	1136000166	CAMSHAFT POSITION SENSOR	1	1.3L
	22		HEXAGON HEAD BOLT & PLAIN WASHER ASSY.	1	M6x20
	23		HEXAGON HEAD BOLT	2	M6x16
	30		CAMSHAFT POSITION SENSOR & SEAT COMPONENTS	1	

28 COLD AIR INTAKE BOX



NO.	PART NO.	DES	QTY	REMARK
10		COLD AIR INTAKE BOX ASSY.	1	
11		HEXAGON NUT & WAVE WASHER ASSY. M6	2	
12		BOWL-SHAPED WASHER	2	
13		FLEXIBLE WASHER	1	
16		HEXAGON HEAD BOLT & LARGE PLAIN WASHER ASSY.	1	
17		WASHER	1	
18	1109401005	COLD AIR INTAKE BOX LOWER BRACKET	1	

29 CLUTCH ASSY.




NO.	PART NO.	DES	QTY	REMARK
11	1106015058	FRICTION PLATE ASSY.	1	
12	1106015057	PRESSUREPLATE ASSY.	1	
13		HEXAGON HEAD BOLT M8x16	6	
14		CLUTCH ASSY.	1	


S160 TRANSMISSION ASSY.

	NO.	PART NO.	DES	QTY	REMARK
	1	3170102101	END CAP	1	
	2	3170122201	PRESS COVER	1	
	3	3170122401	OUTPUT SHAFT SPRING	1	
	4	3170100006	END CAP BOLT	4	
	5	3170121601	O RING-ODOMETER	2	
	6	3230330901	DRIVING GEAR-ODOMETER	1	
	7	3170121005	DRIVEN GEAR-ODOMETER	1	
	8	3170120102	CASE-ODOMETER DRIVEN GEAR	1	
	9	3170121501	SPRING	1	
	10	3170100007	ODOMETER BOLT	1	
	11	3170121301	ODOMETER LOCK WASHER	1	
	12	3380209001	ODOMETER OIL SEAL	1	
	13	3170102002	SHIFT CABLE BRACKET	1	
	14	3170102001	SHIFT CABLE BRACKET	1	
	15	3170122301	SHIFT CABLE BRACKET BOLT	4	
	16	3150010001	SHIFT COVER TIGHTENING BOLT	2	
	17	3160131006	CLUTCH SLAVE PUMP	1	
	18	3160121101	RELEASE FORK	1	
	19	3160122001	CLUTCH BEARING	1	
	20	3160132001	SUPPORTING POST	1	
	21	3160121201	SPRING	1	
	22	3160133005	BOOT	1	
	23	3170216001	SHIFT POSITION ASSY.	1	
	24	3170102301	ATTACHING BOLT	14	
	25	1700201180	VEHICLE SPEED SENSOR	1	

S160 TRANSAXLE ASSY.


	NO.	PART NO.	DES	QTY	REMARK
	1	3170103001	S SHAPE OIL SEAL	1	
	2	3170200005	VENT PLUG ASSY.	1	
	3	3170206101	REVERSE SHIFT FORK SHAFT	1	5TH
	4	3170206001	SHIFT FORK-3RD AND 4TH GEAR	1	
	5	343-6316002	BEARING-INPUT SHAFT	1	
	6	3170205901	FORK SHAFT-1ST AND 2ND GEAR	1	
	7	3204715101	BEARING-OUTPUT SHAFT	1	
	8	3170202401	GEAR SHIFT FORK SHAFT	1	1ST,2ND
		3408018101	DIFFERENTIAL FRONT BEARING	1	
		343-6315701	DIFFERENTIAL REAR BEARING	1	
		3170104901	REAR BEARING-INPUT SHAFT	1	
		3305517101	FRONT BEARING-OUTPUT SHAFT	1	

S160 DIFFERENTIAL ASSY.



NO.	PART NO.	DES	QTY	REMARK
1	3230330901	GEAR-ODOMETER DRIVING	1	
2	3230330701	SIDE GEAR GASKET	2	
3	3230330601	PLANETARY GEAR GASKET	2	
4	3230330301	PLANETARY GEAR	2	
5	3230331001	ELASTIC CYLINDER PIN	1	
6	3230330401	PLANETARY GEAR SHAFT	1	
7	3230330201	SIDE GEAR	2	
8	3230330101	DIFFERENTIAL CASE	1	
9	3230330801	DIFFERENTIAL RING GEAR	1	
	3230331401	DIFFERENTIAL LEFT OIL SEAL	1	
	3230332101	DIFFERENTIAL RIGHT OIL SEAL	1	

S160 COVER-GEARSHIFT ASSY.

	NO.	PART NO.	DES	QTY	REMARK
	1	3170212501	GEARSHIFT GUIDE SHAFT BOOT	1	
	2	3170210101	GUIDE SHAFT-GEARSHIFT	1	
	3	3170211105	ROCKER	1	
	4	3170211001	GEAR SHIFTER	1	
	5	3170214201	GEAR SHIFTER	1	
	6	3170214601	BRACKET -SHIFT LEVER	1	
	7	3170213001	RETURN SPRING B	1	
	8	3170211501	NUT	1	
	9	3170212601	RETURN SPRING A	1	
	10	3170203601	CYLINDER PIN	1	

S160 GEARSHIFT SYSTEM ASSY.

	NO.	PART NO.	DES	QTY	REMARK
	1	3170108201	REVERSE COUNTER GEAR	1	
	2	3170109201	REVERSE COUNTER GEAR SHAFT	1	
	3	3170205401	GUIDE BLOCK-5TH AND REVERSE GEAR	1	
	4	3170202701	GEARSHIFT FORK SHAFT	1	3TH,4TH
	5	3150010002	GEARSHIFT FORK BOLT	2	
	6	3170202901	FIFTH GEAR SHIFT FORK	1	
	7	3170205601	GUIDE BLOCK - REVERSE GEAR	1	
	8	3170209201	PIN	1	
	9	3170205201	GUIDE BLOCK	1	1ST,2ND
	10	3170206301	ELASTIC CYLINDER PIN	2	
	11	3170209401	PIN	1	
	12	3170207701	FORK SHAFT SNAP RING	5	


S160 OUTPUT SHAFT ASSY.

	NO.	PART NO.	DES	QTY	REMARK
	1	3170110601	OUTPUT SHAFT	1	
	2	3343928101	NEEDLY ROLLER BEARING	1	1ST
	3	3170111101	GEAR-1ST SPEED,OUTPUT	1	
	4	3170112801	SYNCHRONIZER GEAR RING	1	1ST
	5	3170112901	SYNCHRONIZER GEAR RING	1	2ND
	6	3170113101	GEAR-2ND SPEED,OUTPUT	1	
	7	3170104301	NEEDLY ROLLER SECLUSION RING	1	
	8	3343923101	NEEDLY ROLLER BEARING	1	2ND
	9	3170113601	GEAR-3RD SPEED,OUTPUT	1	
	10	3170113701	COVER ORIENTATION	1	
	11	3170113801	GEAR-4TH SPEED,OUTPUT	1	2ND
	12	3170114001	GEAR-5TH SPEED,OUTPUT	1	
	13	3170110101	OUTPUT 5TH GEAR RING	1	
	14	3170112005	SYNCHRONIZER ASSY.	1	1ST,2ND

S160 SHAFT-INPUT ASSY.


	NO.	PART NO.	DES	QTY	REMARK
	1	3170104101	SHAFT-INPUT	1	
	2	3170105201	GEAR-3RD SPEED,INPUT	1	
	3	3170106601	RING-3RD SPEED SYNCHRONIZING	1	
	4	3170106701	RING-4TH SPEED SYNCHRONIZING	1	
	5	3170104201	1ST,2ND,3RD,4TH SPEED SPRING	2	
	6	3170105401	GEAR-4TH SPEED,INPUT	1	
	7	3343921101	NEEDLY ROLL BEARING	1	3RD,4TH
	8	3170104401	INPUT FOURTH GEAR THURST WASHER	1	
	9	3170104501	BALL-ORIENTATION	1	4TH
	10	3170105801	GEAR-5TH SPEED,INPUT	1	
	11	3170104601	THRUST WASHER RETAINER	1	4TH
	12	3313620101	NEEDLY ROLLER BEARING	1	5TH
	13	3170107601	RING-5TH SPEED SYNCHRONIZING	1	
	14	3170106001	SYNCHRONIZER ASSY.	1	3RD,4TH
	15	3170107005	SYNCHRONIZER ASSY.	1	5TH

S160G TRANSMISSION ASSY.



NO.	PART NO.	DES.	QTY	REMARK
1	3170102101	END CAP	1	
2	3170122211	PRESS COVER	1	
3	3170122401	OUTPUT SHAFT SPRING	1	
4	3170100006	END CAP BOLT	4	
5	3170121601	O RING-ODOMETER	2	
6	3230330901	DRIVING GEAR-ODOMETER	1	
7	3170121005	DRIVEN GEAR-ODOMETER	1	
8	3170120102	CASE-ODOMETER DRIVEN GEAR	1	
9	3170121501	SPRING	1	
10	3170100007	ODOMETER BOLT	1	
11	3170121301	ODOMETER LOCK WASHER	1	
12	3380209001	ODOMETER OIL SEAL	1	
13	3170102002	SHIFT CABLE BRACKET	1	
14	3170102001	SHIFT CABLE BRACKET	1	
15	3170122301	SHIFT CABLE BRACKET BOLT	4	
16	3150010001	SHIFT COVER TIGHTENING BOLT	2	
17	3160131006	CLUTCH SLAVE PUMP	1	
18	3160121101	RELEASE FORK	1	
19	3160122001	CLUTCH BEARING	1	
20	3160132001	SUPPORTING POST	1	
21	3160121201	SPRING	1	
22	3160133005	BOOT	1	
23	3170216001	SHIFT POSITION ASSY.	1	
24	3170102301	ATTACHING BOLT	14	
25	1700201180	VEHICLE SPEED SENSOR	1	


S160G TRANSAXLE ASSY.




NO.	PART NO.	DES.	QTY	REMARK
1	3170103001	S SHAPE OIL SEAL	1	
2	3170200005	VENT PLUG ASSY.	1	
3	3170206111	REVERSE SHIFT FORK SHAFT	1	5TH
4	3170206011	SHIFT FORK-3RD AND 4TH GEAR	1	
5	343-6316002	FRONT BEARING-INPUT SHAFT	1	
6	3170205911	FORK SHAFT-1ST AND 2ND GEAR	1	
7	3204715101	REAR BEARING-OUTPUT SHAFT	1	
8	3170202401	GEAR SHIFT FORK SHAFT	1	1ST,2ND
	3408018101	DIFFERENTIAL BEARING 6308	1	
	343-6315701	DIFFERENTIAL BEARING 6208	1	
	3170104901	REAR BEARING-INPUT SHAFT	1	
	3305517101	FRONT BEARING-OUTER SHAFT	1	

S160G DIFFERENTIAL ASSY.

NO.	PART NO.	DES.	QTY	REMARK
1	3230330901	GEAR-ODOMETER DRIVING	1	
2	3230330701	SIDE GEAR GASKET	2	
3	3230330601	PLANETARY GEAR GASKET	2	
4	3230330301	PLANETARY GEAR	2	
5	3230331001	ELASTIC CYLINDER PIN	1	
6	3230330402	PLANETARY GEAR SHAFT	1	
7	3230330201	SIDE GEAR	2	
8	3230330111	DIFFERENTIAL CASE	1	
9	3230330811	DIFFERENTIAL RING GEAR	1	
	3230331401	DIFFERENTIAL LEFT OIL SEAL	1	
	3230332101	DIFFERENTIAL RIGHT OIL SEAL	1	




S160G COVER-GEARSHIFT ASSY.



NO.	PART NO.	DES.	QTY	REMARK
1	3170212501	GEARSHIFT GUIDE SHAFT BOOT	1	
2	3170210101	GUIDE SHAFT-GEARSHIFT	1	
3	3170211105	ROCKER	1	
4	3170211001	GEAR SHIFTER	1	
5	3170214201	GEAR SHIFTER	1	
6	3170214601	BRACKET -SHIFT LEVER	1	
7	3170213001	RETURN SPRING B	1	
8	3170211501	NUT	1	
9	3170212601	RETURN SPRING A	1	
10	3170203601	CYLINDER PIN	1	

S160G GEARSHIFT SYSTEM ASSY.



NO.	PART NO.	DES.	QTY	REMARK
1	3170108201	REVERSE COUNTER GEAR	1	
2	3170109201	REVERSE COUNTER GEAR SHAFT	1	
3	3170205401	GUIDE BLOCK-5TH AND REVERSE GEAR	1	
4	3170202711	GEARSHIFT FORK SHAFT	1	3TH,4TH
5	3150010002	GEARSHIFT FORK BOLT	2	
6	3170202901	FIFTH GEAR SHIFT FORK	1	
7	3170205601	GUIDE BLOCK - REVERSE GEAR	1	
8	3170209201	PIN	1	
9	3170205201	GUIDE BLOCK	1	1ST,2ND
10	3170206301	ELASTIC CYLINDER PIN	2	
11	3170209401	PIN	1	
12	3170207701	FORK SHAFT SNAP RING	5	

S160G OUTPUT SHAFT ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	3170110611	OUTPUT SHAFT	1	
	2	3343928111	NEEDLY ROLLER BEARING	1	1ST
	3	3170111111	GEAR-1ST SPEED,OUTPUT	1	
	4	3170112801	SYNCHRONIZER GEAR RING	1	1ST
	5	3170112901	SYNCHRONIZER GEAR RING	1	2ND
	6	3170113111	GEAR-2ND SPEED,OUTPUT	1	
	7	3170104301	NEEDLY ROLLER SECLUSION RING	1	
	8	3343923111	NEEDLY ROLLER BEARING	1	2ND
	9	3170113611	GEAR-3RD SPEED,OUTPUT	1	
	10	3170113711	COVER ORIENTATION	1	
	11	3170113811	GEAR-4TH SPEED,OUTPUT	1	
	12	3170114011	GEAR-5TH SPEED,OUTPUT	1	
	13	3170110101	OUTPUT 5TH GEAR RING	1	
	14	3170112011	SYNCHRONIZER ASSY.	1	1ST,2ND

S160G SHAFT-INPUT ASSY.

	NO.	PART NO.	DES.	QTY	REMARK
	1	3170104111	SHAFT-INPUT	1	
	2	3170105211	GEAR-3RD SPEED,INPUT	1	
	3	3170106601	RING-3RD SPEED SYNCHRONIZING	1	
	4	3170106701	RING-4TH SPEED SYNCHRONIZING	1	
	5	3170104201	1ST,2ND,3RD,4TH SPEED SPRING	2	
	6	3170105411	GEAR-4TH SPEED,INPUT	1	
	7	3343921111	NEEDLY ROLL BEARING	1	3RD,4TH
	8	3170104401	INPUT FOURTH GEAR THURST WASHER	1	
	9	3170104501	BALL-ORIENTATION	1	4TH
	10	3170105811	GEAR-5TH SPEED,INPUT	1	
	11	3170104601	THRUST WASHER RETAINER	1	4TH
	12	3313620111	NEEDLY ROLLER BEARING	1	5TH
	13	3170107601	RING-5TH SPEED SYNCHRONIZING	1	
	14	3170106011	SYNCHRONIZER ASSY.	1	3RD,4TH
	15	3170107011	SYNCHRONIZER ASSY.	1	5TH